SANDIA REPORT

SAND86—2998 • UC—37

Unlimited Release

Printed August 1987

TA489A Calibrator SANDUS

Roy LeBlanc

Prepared by
Sandia National Laboratories
Albuquerque, New Mexico 87185 and Livermore, California 94550
for the United States Department of Energy
under Contract DE-AC04-76DP00789

When printing a copy of any digitized SAND Report, you are required to update the markings to current standards.

Issued by Sandia National Laboratories, operated for the United States Department of Energy by Sandia Corporation.

NOTICE: This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, nor any of their contractors, subcontractors, or their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government, any agency thereof or any of their contractors or subcontractors. The views and opinions expressed herein do not necessarily state or reflect those of the United States Government, any agency thereof or any of their contractors or subcontractors.

Printed in the United States of America
Available from
National Technical Information Service
U.S. Department of Commerce
5285 Port Royal Road
Springfield, VA 22161

NTIS price codes
Printed copy: A03
Microfiche copy: A01

SAND86-2998
Unlimited Release
Printed August 1987

Distribution
Category UC-37

TA489A Calibrator SANDUS

Roy LeBlanc
NTS Instrumentation Development Division
Sandia National Laboratories
Albuquerque, NM 87185

Abstract

The TA489A Calibrator, designed to operate in the MA164 Digital Data Acquisition System, is used to calibrate up to 128 analog-to-digital recording channels. The TA489A calibrates using a dc Voltage Source or any of several special calibration modes. Calibration schemes are stored in the TA489A memory and are initiated locally or remotely through a Command Link.

Contents

1. General	7
1.1 System Definition	7
1.1.1 Data Collection Elements	7
1.1.2 Common Equipment Elements	11
1.1.3 Setup and Playback Equipment	11
1.2 Element Definition	11
2. Technical Description	13
2.1 Physical Description	13
2.2 Functional Description	13
2.3 Calibration Types	13
2.3.1 General Calibrations	17
2.3.2 Other Calibrations	17
2.3.3 Calibration Selections	18
2.3.4 Inputs to TA489A Calibrator	18
2.3.5 Outputs From the TA489A Calibrator	18
2.4 Calibration Sequences	19
2.4.1 Single-Channel Calibration	19
2.4.2 Auto Calibration	21
2.4.3 Signals Asserted During Calibrations	21
2.5 Calibration Options	22
2.5.1 Auto Cal	22
2.5.2 Single Channel	22
2.5.3 Single-Channel Step Select	22
2.5.4 Alternate Source/TA590 Check	22
2.5.5 Auto Cal/Block Select	22
2.5.6 Step Response	22
2.5.7 Auto Cal/Step Select	23
2.6 Aborting Calibration Sequences	23
2.7 Associated Equipment	24
2.7.1 dc Voltage Source	24
3. Description of the TA489A Calibrator	25
3.1 Physical Description	25
3.1.1 Chassis	25
3.1.2 Internal Parts	25
3.1.3 Cabling	25
3.1.4 Connector Types	25
APPENDIX A—List of Drawings for TA489A Calibrator	27
APPENDIX B—DEC Boards Used in TA489A Calibrator	29
APPENDIX C—Jumpers on DEC Board M8047-AA (MXVII-A)	31
APPENDIX D—TA489A Status Register Format	33
APPENDIX E—TA489A Memory Format	35
APPENDIX F—TA489A Calibration Step PROM Program	37
APPENDIX G—TA489A Step Response PROM Program	39
APPENDIX H—TA489A Calibration PROM Code	41
APPENDIX I—Jumpers on DEC Board LSI-11/23 CPU (M8186)	47

Figures

1	SANDUS.....	8
2	MA164 Block Diagram	9
3	MA164 Rack Layout	10
4	TA489A Calibrator	14
5	Block Diagram of TA489A	15
6	SANDUS (MA164) Calibration Flow	16
7	Calibration Timing	20
8	Calibration Sequence	20

Tables

1	List of Special Calibrations	18
2	TA489A Memory Blocks vs. Gages	18
3	Signals Asserted During Calibration Cycles	21

TA489A Calibrator SANDUS

1. General

This manual is intended for the use of individuals responsible for operating and maintaining the TA489A Calibrator.

Nine appendixes are included: Appendix A is a list of drawings for the TA489A; Appendix B is a list of DEC boards used with the TA489A; Appendix C is a list of the jumpers on the DEC board MXVII-1 used in the TA489A; Appendix D is a representation of the formatting of the status registers; Appendix E is a representation of the structuring of the TA489A digital memory; Appendix F presents the coding for the Calibration Step PROM; Appendix G lists the coding for the Step Response PROM; Appendix H presents the coding for the Calibration Sequence PROM; and Appendix I is a list of jumpers on the DEC board LSI-11/23 CPU.

1.1 System Definition

This manual contains the physical, functional, and programming information for the TA489A Calibrator, which forms part of the Common Equipment used in the MA164 Digital Data Acquisition System.*

The MA164 is capable of collecting data from up to 128 unique analog channels. Each input signal (dc to 10 MHz) has its own dedicated signal conditioner, amplifier, and data module. It can also collect data from up to 88 unique 8-bit digital channels. The entire system can be set up and controlled by either a local or a remote computer. Figure 1 shows the enclosure that contains the MA164 Digital Data Acquisition System.

*J. M. Opalka, *SANDUS—MA164 Digital Data Acquisition System Specifications*, SAND83-2038 (Albuquerque, NM: Sandia National Laboratories, November 1983).

Figure 2 is a simplified diagram of the MA164 system. Figure 3, the rack layout, shows where the TA489A is located in the MA164 system.

A standard MA164 system contains all the equipment needed to set up and operate the Data Collection system. This includes the Data Collection elements, several elements referred to as Common Equipment, and the Setup and Playback Equipment.

The MA164 Digital Data Acquisition System is more commonly referred to as SANDUS (Sandia Digital Underground System). The TA489A is one element of SANDUS.

1.1.1 Data Collection Elements

The Data Collection elements comprise the source and translator couplers, signal conditioner/amplifier, data modules, and the crates. The signal conditioner/amplifiers provide for bridge completion, calibration, line termination, and amplification for analog signals. The data modules—up to 128 in the MA164—contain the presample filters, sample rate control, trigger controls, analog-to-digital converters, and the internal memory. The crates provide the Power and Decode commands, and interface the signal conditioner/amplifier and the data modules with the Common Equipment. Each crate can control up to eight signal conditioners or data modules. Analog data may be recorded in two ways: the signals may be digitized and output as real-time data to a remotely located recording facility or they may be stored in internal 16K memory for later readout and processing.

The MA164 also services up to 88 digital data channels of 8 bits each (704 bits). The data is output in the same manner as real-time data.

Figure 1. SANDUS

Figure 2. MA164 Block Diagram

Figure 3. MA164 Rack Layout

1.1.2 Common Equipment Elements

The Common Equipment provides a means of operating the data system from remote locations as well as locally. The elements are the TA484A Multiplexer, TA485A Controller, TA486A Programmer/Timer, TA488B Trigger Generator, TA566A Power Controller/Encoder, and TA489A Calibrator. These elements initiate automatic countdowns, provide arms and triggers for data modules, calibrate systems, control system power, control setup parameters for each channel, and allow output of the digitized data to a remote location.

1.1.3 Setup and Playback Equipment

The computer provides a means to set up and test the individual channels. It also provides data playback and storage.

The test equipment provides communication and some of the calibration equipment. The TA666A Data Selector provides quick-look data displays for channel status.

1.2 Element Definition

The TA489A Calibrator provides internal calibration for the Data Collection channels of the MA164 Digital Data Acquisition System.

The Data Collection channels may be calibrated in any of four programmable memory blocks in the TA489A Calibrator.

2. Technical Description

2.1 Physical Description

The TA489A Calibrator is assembled in an all-metal chassis whose parts have been coated with conductive corrosion inhibitors. The chassis is 19 in. wide $\times$ 7 in. high $\times$ 26 in. deep and can be mounted on a standard rack (Figure 4). Removable top and bottom covers give access to its internal components. Chassis slides provide ready internal access and efficient installation, and make it easy to remove from equipment racks.

Two wire-wrap boards provide area for integrated circuits and input/output interfacing.

One +5-V power supply provides the operating voltage for the logic circuitry, the microprocessor elements, and the calibration relay matrix. A ± 15 -V modular power supply provides operating voltages for the FET switches used in the Step Response calibration mode. A +28-V power supply provides operating voltage for the calibration relays located within the TA590 Signal Conditioner modules of the MA164 Digital Data Acquisition System.

A Digital Equipment Corporation (DEC) LSI 11/23 microprocessor monitors and generates all of the internal calibration functions in the TA489A (refer to Appendix B).

Two solid-state relays provide ac voltage control to the power supplies. The Calibration Relay matrix comprises three PC boards and two large can-type relays.

The front panel contains the local control switches, the indicator lights, and the visual displays. An Input Calibration Source connector is also available on the front panel. The input/output connectors, fan, and a power fuse are located on the rear panel.

2.2 Functional Description

The TA489A Calibrator provides means, both locally and remotely, for the Data Collection channels of the MA164 Digital Data Acquisition System to be calibrated. These calibrations serve as references for later data analysis.

Calibration parameters for the 128 individual recording channels of the MA164 Digital Data Acquisition System are stored in 8K of RAM memory in the TA489A Calibrator. This memory is divided into four sections: Block 0, Block 1, Block 2, and Block 3. For information concerning the reading and writing formats of the TA489A Calibrator, the reader is asked to refer to the MA164 Command System documentation, and to Appendix D.

Once a channel is calibrated, its data are stored in the digital memory of the channel calibrated.

Figure 5 shows a block diagram of the TA489A Calibrator.

2.3 Calibration Types

The TA489A can calibrate either locally or remotely.

Both general and special types of calibration are available. All are the result of a 4-bit PROM code in the TA489A and the calibration sequence of the TA489A. The PROM codes (called Cal Codes 0-3) are sent to the Amplifier/Signal Conditioners and the codes control relays at the Signal Conditioner. The relays allow data lines or attenuators or calibration lines to be applied to the Amplifier inputs.

The various types of calibrations performed by the TA489A Calibrator are defined by programming the TA489A memory for each individual channel in the MA164 Digital Data Acquisition System. Calibration type is dictated by bits 4 to 7 of sub-address 7. (Refer to Appendix E, the memory format, and to the MA164 command format.)

Figure 6 depicts the MA164 calibration flow.

Figure 4. TA489A Calibrator

Figure 5. Block Diagram of TA489A

Figure 6. SANDUS (MA164) Calibration Flow

2.3.1 General Calibrations

2.3.1.1 Zero Cal (Cal Code 0000) (SK1)

This calibration removes the gage from the amplifier inputs and ties each input to ground by means of a resistor. This is accomplished by a relay in the Amplifier/Signal Conditioner controlled by the Cal Codes from the TA489A.

2.3.1.2 Shunt Cal (Cal Code 0001) (SK2)

This selection parallels one leg of a bridge with a known resistance. This is either accomplished at the Amplifier/Signal Conditioner or at the Source Coupler.

2.3.1.3 Step Cal (Cal Code 0010) (SK1 and SK3)

This selection applies a dc voltage from the Voltage Source through the Signal Conditioner to the Source Coupler excitation lines and controls a relay in the Source Coupler. That relay would then apply the dc voltage on the excitation lines and return on the data lines that provide the inputs to the Amplifier. This type of calibration is not considered very reliable if the signal is small because of the noise picked up from the long excitation and data lines. If this mode is selected, a toggle switch on the Amplifier/Signal Conditioner must be set to CAL. This type of calibration is a means of verifying continuity of the excitation and data lines.

2.3.1.4 (+) Internal Test (Cal Code 0011)

This function consists of removing the gage from the Amplifier inputs and applying a positive dc voltage to the inputs. The dc voltage is generated from within the Amplifier/Signal Conditioner module; the Amplifier Gain Code selects the level of voltage applied. This type of calibration may be performed by control from the TA489A, but it is not considered an accurate form of channel calibration.

2.3.1.5 (–) Internal Test (Cal Code 0100)

This calibration function is similar to that described in paragraph 2.3.1.4, except that a negative dc voltage is applied to the Amplifier inputs. The Amplifier then produces a corresponding negative output.

2.3.1.6 Amp Cal (1:1) (Cal Code 0101)

This calibration causes a precise dc voltage from the Voltage Source to be applied to the Amplifier input. The full value of the voltage programmed into

the TA489A memory is applied to the Amplifier input, thus the 1:1 ratio. The input to the Amplifier is relay-controlled, determined by the Cal Codes from the TA489A.

2.3.1.7 Amp Cal (10:1) (Cal Code 0110)

This type of calibration functions the same as that described in paragraph 2.3.1.6, except that the dc voltage applied to the Amplifier inputs is first passed through a 10:1 attenuator. The attenuator is in the Signal Conditioner module and is selected by the Cal Codes from the TA489A. Only the TA590-10 Signal Conditioner has the 10:1 attenuator.

2.3.1.8 Amp Cal (100:1) (Cal Code 0111)

This calibration functions the same as that described in paragraph 2.3.1.6, except that the dc voltage applied to the Amplifier inputs is passed through a 100:1 attenuator. The attenuator is in the Signal Conditioner module and is selected by the Cal Codes from the TA489A. Only the TA590-1 Signal Conditioner has the 100:1 attenuator.

2.3.1.9 Amp Cal (1000:1) (Cal Code 1000)

This calibration functions the same as that described in paragraph 2.3.1.6, except that the dc voltage applied to the Amplifier inputs is passed through a 1000:1 attenuator. The attenuator is in the Signal Conditioner module and is selected by the Cal Codes from the TA489A. Only the TA590-1 Signal Conditioner has the 1000:1 attenuator.

2.3.1.10 Gage Cal (Cal Code 1111)

This calibration provides “real” channel reference. During this calibration, the Amplifier inputs are connected to the gage via the cable data lines. This calibration provides a realistic view of channel characteristics as influenced by external noise, offset parameters, induced voltages, etc. No voltage from the Voltage Source is applied to the Amplifier inputs.

2.3.2 Other Calibrations

The calibrations listed in Table 1 are available from the TA489A. These special calibrations are commanded by the same PROM that produces the Cal Codes for the General Calibration types described in section 2.3.1. The calibrations control relays K1, K2, and K3 in the Source Couplers, the interfaces to the gages and/or the Signal Conditioner. SK1, SK2 and SK3 mean Special K1, Special K2, and Special K3, respectively.

Table 1. List of Special Calibrations

Relays	Cal Code
SK3	1001
SK1, SK2	1010
SK2, SK3	1011
SK1, SK2, SK3	1100

2.3.3 Calibration Selections

Table 2 shows the TA489A memory blocks relative to the types of gages. This method of programming is not mandatory; the blocks may be programmed in any sequence desired, but the sequences shown in the table are historically the way the calibrations have been made.

Table 2. TA489A Memory Blocks vs. Gages

Cal Block	Bridge	Type of Gage	
		Voltage (Bipolar)	Voltage (Unipolar)
0	Zero Cal	Zero Cal	Zero Cal
1	Shunt Cal	+Step Cal	+Step Cal
2	Amp Cal	—Step Cal	+1/2 Step Cal
3	Gage Cal	Gage Cal	Gage Cal

2.3.4 Inputs to TA489A Calibrator

2.3.4.1 Inputs From Voltage Source

The inputs to the TA489A Calibrator from the Voltage Source are made on two coaxial lines. The output of the Voltage Source is a differential voltage. Inputs are routed through a large relay and from there through the Calibration Relay matrix for proper routing to the crate selected for calibration. Most relay contacts are mercury-wetted to minimize voltage losses through the relays in the calibration lines.

2.3.4.2 Inputs From TA485A Controller

All inputs from the TA485A Controller to the TA489A Calibrator are negative true TTL levels using eight Command Data bits, four Function Code bits, four Sub-Address bits, one Power-On Reset line, and a 10-ms Strobe signal.

The Command Data bits, the Function Code bits, and the Sub-Address bits are used to read or write the TA489A memory through its Status Register. These

bits also are used to begin or abort calibrations. The Strobe signal latches addresses, status bits, the Function Codes, the Sub-Addresses, and the Command Data bits. The Power-On Reset provides a clear-all to the TA489A logic for returning to the operational standby mode.

2.3.4.3 Inputs From TA566A Power Controller/Encoder

Only one signal line into the TA489A Calibrator is used from the TA566A Power Controller/Encoder. A positive true level is provided by the TA566A to enable a solid-state relay in the TA489A. This relay controls ac voltage to the TA489A power supplies.

2.3.4.4 Inputs From TA486A Programmer/Timer

All levels from the TA486A Programmer/Timer to the TA489A Calibrator are negative true TTL levels. Three signals are used: AUTO CAL, STOP CAL, and LOCKOUT. AUTO CAL begins the Automatic Calibration cycle; STOP CAL aborts the Calibration cycle; and LOCKOUT aborts the Calibration cycle if in progress and allows no more activity from the TA489A Calibrator until a system Power-On Reset is received via the TA485A Controller. The LOCKOUT signal also causes the +28-V power supply in the TA489A Calibrator to shut off for a predetermined time, usually ~18 s. At the end of this time, the +28 V is reinstated. This is done to ensure that the Amplifier/Signal Conditioner relays are in their relaxed state (data mode) at data collection time.

2.3.4.5 ac Input

The ac power input to the TA489A Calibrator is made up of one Hot line, one Neutral line, and one Ground line.

2.3.5 Outputs From the TA489A Calibrator

2.3.5.1 Outputs to Voltage Source

All outputs from the TA489A Calibrator to the Voltage Source are negative true TTL signals. Twenty value bits determine the level of the Voltage Source output, one bit determines the polarity of the output, and one bit swaps both lines of the differential output of the Voltage Source to the TA489A. This is done by a double-pole, double-throw relay in the Voltage Source.

2.3.5.2 Outputs to TA485A Controller

Only one negative true TTL level output is used from the TA489A Calibrator to the TA485A Controller. It is called Cal Busy and is available to the TA485A register, but is not used by the firmware. This is a do-nothing signal.

2.3.5.3 Outputs to TA484A Multiplexer

All outputs from TA489A Calibrator to the TA484A Multiplexer are negative true TTL levels. They include seven Channel Address bits, two Calibration Block bits, one System-In Cal bit, one Data Ready bit, and one Cal Stable bit. System-In Cal is asserted throughout the calibration cycle.

2.3.5.4 Outputs to TA566A Power Controller/Encoder

All outputs from the TA489A Calibrator to the TA566A Power Controller/Encoder are negative true TTL levels, and include one SYSTEM-IN CAL signal and one POWER OK signal. Both signals are multiplexed into the health-monitor stream by the TA566A.

2.3.5.5 Outputs to TA666A Data Selector

All outputs from the TA489A Calibrator to the TA666A Data Selector are negative true TTL levels, and include seven Channel Address bits and one Strobe. These are used to monitor the channel being calibrated.

2.3.5.6 Outputs to TA488B Trigger Generator

All outputs from the TA489A Calibrator to the TA488B Trigger Generator are negative true TTL levels, and include one Trigger Inhibit Override bit and one Arm bit. The Trigger Inhibit Override bit disables the Inhibit bit in the TA488B and allows triggering of Memory Data modules during calibration; the Arm bit arms the data modules during calibration.

2.3.5.7 Outputs to TA486A Programmer/Timer

All outputs from the TA489A Calibrator to the TA486A Programmer/Timer are negative true TTL levels, and include two Calibration Block bits, one System-In Cal bit, and one Outboard Calibration bit. These signals allow the TA486A to control special calibration equipment and/or experiments during calibration.

2.3.5.8 Outputs to TA493A Crates

Most outputs from the TA489A Calibrator to the TA493A Signal Conditioner Crate are negative true TTL levels. They include four Cal Code bits, one Trigger Strobe bit, one Latch Strobe bit, three Cal Address bits, and one Crate-In Cal signal, $\pm$ Cal Sig from the Calibration Relay matrix, and an isolated voltage output from a +28-V power supply.

2.4 Calibration Sequences

2.4.1 Single-Channel Calibration

To calibrate a single channel, 16 steps are used in the calibration process. Each step is 10 ms long, for a total time of 160 ms.

The data module is armed at the beginning of the 16-step sequence via the TA488B Trigger Generator, which sends the ARM signal to the Data module via the TA493B Data Module Crate. The ARM signal is received at Decode 2 and routed to the proper channel within the TA493B.

At Step 6 in the sequence, a Trigger signal is sent to the Data module via the TA488B Trigger Generator in similar fashion as that described for the Arm signal.

The appropriate Cal Code from the calibration memory is sent to TA493A Signal Conditioner Crate for setup of the Signal Conditioner relays.

At the end of the 160-ms calibration period for the channel selected, the TA489A Calibrator returns to a Standby mode.

Figures 7 and 8 show the calibration cycles and sequence, respectively.

Figure 7. Calibration Timing

Figure 8. Calibration Sequence

2.4.2 Auto Calibration

In Auto Calibration, the time it takes to calibrate each channel is the same as described in paragraph 2.4.1. The difference is that all channels of the MA164 Digital Data Acquisition System will be calibrated. The sequence of that calibration process is described below:

1. Channels 0 through 177 (octal) are each sequentially subjected to a 160-ms calibration cycle using the information programmed into memory Block 0. Note that channels may be skipped by programming a "1" in sub-address 6, bit 7. Refer to Appendix E.
2. When calibration for Block 0 is completed, the TA489A goes into a Wait mode. This is a pause in the calibration process to allow the information from each channel memory to be read and transferred to a remote location for storage on tape. The TA484A Multiplexer reads, multiplexes, and sends the data to a remote trailer via a 20-Mbit data stream. If there are real-time channels, the TA618 Multiplexer is also used to transfer the data.
The wait period is determined by the following process:
 - A. If no channel was calibrated, the TA489A will proceed directly into the next block.

- B. If at least one channel was calibrated, Data Ready to the TA484A is set 410 ms after the final calibration step of the block in progress.
 - C. Data Ready is set for 200 ms, multiplied by the number of channels that were calibrated.
 - D. Data Ready is removed after Setp C and another wait period of 160 ms takes place before the TA489A begins the next calibration block.
3. At the end of the wait period, the TA489A Calibrator again goes into a calibration cycle (described in Step 1 above) but uses the memory information in Block 1. At the end of calibration for Block 1, the TA489A Calibrator returns to the Wait mode for Memory Data transfer.
 4. The TA489A repeats the process described in Steps 1 and 2 for Blocks 2 and 3. At the end of the wait period for the Block 3 calibration, the TA489A reverts to a Standby mode.

2.4.3 Signals Asserted During Calibrations

These signals are given in Table 3. Refer also to Figures 7 and 8.

Table 3. Signals Asserted During Calibration Cycles

Signal	Function
System-In Cal	Signals several elements in the MA164 that a calibration cycle is in progress. The signal is asserted throughout the entire calibration period.
Crate-In Cal	This signal is sent by the TA489A to the appropriate TA493A Crate during a calibration cycle. The signal is asserted for each channel; it is calibrated and the signal is dropped at the end of the 160-ms calibration cycle for that channel.
Arm	The signal is asserted at the beginning of the calibration cycle. This is considered a Broadside Arm to all Data Module memories.
Trigger Strobe	This signal is asserted to the Data Module memory 50 ms into the calibration cycle. It alerts the memory to store the calibration data.
Latch Strobe	This signal is asserted at the beginning of each channel calibration cycle so that it may latch in the address of the module to be calibrated. It is asserted 16 times during one channel calibration and is used at the respective TA493A Crate Decode Board.

2.5 Calibration Options

The options described below may be initiated from the front panel of the TA489A Calibrator, or remotely via the command link through the TA485A Controller. All the options listed are engraved on the TA489A's front panel and may be initiated by pushing the START switch. The option may be cancelled by the operator by pushing the CLEAR switch. As already noted, the options may also be initiated or cancelled remotely.

When a CLEAR signal is received, the microprocessor allows calibration of the channel in progress to be completed before allowing the TA489A Calibrator to revert to a Standby mode.

2.5.1 Auto Cal

This mode of calibration causes all channels in the MA164 Digital Data Acquisition System to be calibrated in the same manner described in paragraph 2.4.2.

2.5.2 Single Channel

This mode of calibration performs exactly as described in paragraph 2.4.1.

2.5.3 Single-Channel Step Select

This calibration is similar to the Single-Channel Mode, except that it can be selected via the front panel or the command link. The calibration will stop at the step selected and wait until the calibration is cancelled by a CLEAR. The TA489A Calibrator will finish the channel calibration in progress and then revert to a Standby mode.

2.5.4 Alternate Source/TA590 Check

This calibration mode allows the operator to choose an external signal and apply it to the front panel connector, labeled ALT SRC, to verify channel function. When this mode is initiated, the TA489A moves to Step 7 of the calibration process and remains there until a CLEAR is received.

The signal applied at connector ALT SRC is routed through the TA489A Calibrator's relay matrix and is applied to the calibration lines going to the appropriate amplifier inputs for channel calibration.

This mode is useful in determining if a channel is functioning within the MA164 Digital Data Acquisition System (SANDUS), but a word of caution is in order. This is not a fool-proof verification of channel

functioning. Since differential input lines to the amplifier are used, data would be displayed at the Data module even if one input to the amplifier were open or shorted to ground. Therefore, discretion and experience are determining factors in whether the channel is functioning properly.

When using this mode, the channel gain, filter, offsets, etc. must be taken into account. The signal level applied should also be considered.

2.5.5 Auto Cal/Block Select

This mode of calibration is similar to Auto Cal described in paragraph 2.5.1, except that a Calibration Memory block must be selected by the operator via the front panel or the command link. When initiated, this mode will then calibrate channels 0 through 177 (octal) sequentially, using only the calibration information stored in the memory block selected. At the end of the calibration sequence, the TA489A will revert to a Standby mode.

2.5.6 Step Response

This mode allows the operator to apply a square wave to the inputs of the amplifier for calibration. This square wave is generated by the TA489A Calibrator by two methods:

1. If the Step Response mode is selected from the front panel, the square wave is generated from the output of the precision dc Voltage Source being applied through two FET switches that chop the dc voltage at a rate selected by the operator. The resulting square wave is applied across the calibration lines so that it may be routed to the amplifier inputs through the Calibration Relay matrix. The algorithm that determines the dc voltage to be applied to the FET switches is described in paragraph 2.5.6.1.
2. If the Step Response mode is selected remotely from the command link, the square wave is generated from two 30- Ω transmission line drivers, which are switching at a rate selected by the operator through the command link. The algorithm that determines the input to the calibration lines is described in paragraph 2.5.6.2.

The operator selects the frequency at which the dc voltage is chopped, and can choose from 15 rates if the mode is selected remotely via the command link, but only 10 rates can be selected from the front panel. Refer to Appendix D.

2.5.6.1 Step Response Algorithm/Front Panel Selection

If Step Response is selected from the front panel, the Cal Code determines which of the two methods described below is to be used in directing the output of the dc Voltage Source.

1. If Cal Code *is not* a 5, 6, 7, or 10:
 - The channel number is taken from the front panel switch.
 - The front panel is set up to display the channel number, Block 2, and Step 7.
 - The calibration is taken from Block 2 of the TA489A Calibrator memory.
 - The Cal Code is set to 5.
 - The binary output to the Voltage Source is set for a voltage output of +3.75 V.
 - The FET chop rate is determined from the front panel switch.
 - The Step Response FET switches are enabled, and the strobes are sent to the crates and to the TA666A Data Selector.
2. If the Cal Code *is* a 5, 6, 7, or 10:
 - The channel number is taken from the front panel switch.
 - The front panel is set up to display the channel number, Block 2, and Step 7.
 - The calibration is taken from Block 2 of the TA489A Calibrator memory.
 - If the voltage value stored in memory is positive, it is doubled, but limited to 10 V.
 - If the voltage value stored in memory is negative, it is inverted.
 - The Cal Code is sent out unchanged to the TA493A Signal Conditioner Crate.
 - The FET chop rate is determined at the front panel switch.
 - The FET switches are enabled and the strobes are sent to the crates and to the TA666A Data Selector.

2.5.6.2 Step Response Algorithm/Command Link Selection

When Step Response is selected from the command link, the signal fed into the input of the amplifier from the calibration lines is obtained from two 30- Ω line drivers within the TA489A Calibrator. The sequence of events follows:

- The channel number is taken from the command link.
- The front panel is set up to display the channel number, Block 2, and Step 7.
- The Cal Code is set to a value of 5.
- The binary output to the Voltage Source is set for a 0-V output from the Voltage Source.
- The 30- Ω driver switching rate is read from the command link.
- The two 30- Ω drivers are enabled and the strobes are sent to the crates and to the TA666A Data Selector.

2.5.7 Auto Cal/Step Select

This calibration mode allows the operator to select a calibration step for the cycle; this step can be selected from the front panel or through the command link. The TA489A will then perform an Auto Cal and stop on Step 7 of the first channel (Channel 0) until a Start is once again initiated. The TA489A will then advance to the next sequential channel and wait for another Start. This process continues until the last channel (Channel 177) has been calibrated, at which time the TA489A will revert to Standby mode.

2.6 Aborting Calibration Sequences

During the calibration sequence initiated by any of the options, calibrations in progress can be aborted in two ways:

1. If a "Clear" command is received from the front panel or a "Stop Cal" is received from the command link, the TA489A Calibrator will continue with the sequence in progress through the 16 steps of calibration for the channel currently being addressed, and then revert to a Standby mode.

2. If a LOCKOUT timing signal is received from the TA486A Programmer/Timer, the TA489A Calibrator immediately drops out of calibration and remains locked out from front panel or remote control until a system POWER-ON RESET signal is received from the TA485A Controller. The isolated +28-V power supply in the calibrator is disabled for ~ 18 s, then the +28-V output is reinstated. This method of aborting calibrations is more definitive and abrupt.

The firmware in the TA489A will prevent calibrations for ~ 10 s after LOCKOUT is removed.

2.7 Associated Equipment

2.7.1 dc Voltage Source

The precision dc Voltage Source referred to in the calibration process is a highly versatile reference source. It is the Model 501 Programmable dc Voltage Standard manufactured by Electronic Development Corporation (EDC).

The Voltage Source was specially modified by EDC for Sandia National Laboratories to provide a differential output. It was further modified at Sandia to enable inverting the differential output, which is controlled only by the TA489A Calibrator.

Solid-state circuitry is used except for a mercury-wetted contact relay installed during the inverting retrofit that Sandia employs.

The output is limited to ± 5.12 V for a differential output of 10.24 V. It may be controlled locally from the front panel or from the calibrator interface.

Accuracy of the resolution is $10 \mu\text{V}$ (see Appendix E).

3. Description of the TA489A Calibrator

3.1 Physical Description

Here we define the mechanical assembly including the electronic components, mechanical parts, and connectors used in the TA489A Calibrator.

3.1.1 Chassis

The TA489A chassis is located in Rack 3 of the MA164 Digital Data Acquisition System. It is in the fourth location from the top of Rack 3 (Figure 3).

The calibrator is equipped with an aluminum chassis mounted on a standard rack with dimensions of 19 in. wide $\times$ 7 in. high $\times$ 26 in. deep (Figure 4). Side panels are made of corrosion-inhibited steel; all other parts are made of corrosion-inhibited aluminum.

The front and rear panels are made of 0.125-thick aluminum. The labeling is engraved and filled in black. The front and all four edges of the front panel are painted with two coats of epoxy, color 23617, per Federal Standard 595. The top and bottom covers are also made of 0.125-thick aluminum, with slots milled out at the front for airflow into the chassis. Both covers are corrosion-inhibited and can be removed for internal access to the chassis.

Cooling is provided by a 113-CFM Rotron fan. Airflow is from front to rear within the chassis; air is drawn into the chassis through slots in the top and bottom front covers, and is expelled at the rear panel. The intake air is not filtered.

3.1.2 Internal Parts

Two universal wire-wrap Schottky TTL Augat boards (P/N 8136-SCH109-54) provide area for logic circuitry. The boards are hinge-mounted for access to the wire-wrap and components underneath, and are installed one behind the other at the same level within the chassis (Figure 4).

One +5-V 10-A, +12-V 1-A, -12-V 1-A KEPCO switching power supply provides operating voltage for the digital logic, calibration relay matrix, microprocessor, and the other calibration relays in the chassis.

One +28-V 2.5-A KEPCO switching power supply provides operating voltage outputs to all TA590 Signal Conditioners. The output from this supply is isolated from ground and all other voltage sources

within the TA489A chassis. The reason this supply is isolated is to prevent back EMF from the TA590 Signal Conditioner relays being introduced into system ground.

One modular ± 15 -V 1-A power supply provides operating voltage for the FET switches used in the Step Response circuitry of the calibrator.

3.1.3 Cabling

All interface connections are made through 17 rear-panel mounted connectors (Figure 4). One connector applies ac power to the TA489A. A "giant banana" jack provides quick connect/disconnect grounding of the TA489A to the MA164 ground bars. Eight connectors provide interfacing to all Data Collection Crates for calibration controls and signals. One connector interfaces to the TA666A Data Selector for proper addressing of the channel during calibration. Another interfaces to the precision dc Voltage Source so that binary values can be sent to the Voltage Source and the differential voltage output can be returned to the TA489A.

One connector interfaces the TA486A Programmer/Timer, one interfaces the TA484A Multiplexer, one interfaces the TA488B Trigger Generator, and another interfaces the TA485A Controller.

One connector provides direct link to an external terminal for communication with the microprocessor.

Two BNC connectors are also provided. One is used as a return for the +28-V power supply for use with the TA665 zero-time simulator. The other is unused.

One BNC interface connector is provided on the front panel to supply a calibration input other than the dc Voltage Source to the TA489A Calibrator.

3.1.4 Connector Types

Except for the BNC connectors and the banana jack, the interface connectors on the rear panel are plastic. Manufactured by AMP Special Industries, they are rugged, molded plastic circular connectors that provide quick connect/disconnect mating. They can accept a variety of pins and sockets, including machined and stamped parts. Sockets and pins that provide a direct interface for coax are also used. Coax and normal PVC-wired pins or sockets may be intermixed within the connector.

APPENDIX A

List of Drawings for TA489A Calibrator

Following is a list of drawings for the TA489A Calibrator:

Drawing No.	Title
T56556	TA489A Calibrator Assembly
CK T56556	TA489A Calibrator Schematic
AL T56556	TA489A Calibrator Parts List (Augat Boards)
T69394	TA489A Calibrator Chassis Modifications
CK T67334	TA489A Calibrator Relay Matrix Schematic
T67334	TA489A Calibrator Relay Matrix Assembly

APPENDIX B

DEC Boards Used in TA489A Calibrator

M8186	Central Processing Unit
M8047-AA	Memory and Asynchronous Serial Line Interface
M9401	Buss Extender
1822, Rev. 1	RAM Memory (This is not a DEC board; the manufacturer is ADAC)

APPENDIX C

Jumpers on DEC Board M8047-AA (MXVII-A)

J6 – J7	Halt on framing error
J10 – J11	2716 EProm
J15 – J29	
J33 – J37	
J36 – J38	
J39 – J40	
J13 – J27	SLU Ch 1 Address 177560
J14 – J25	
J15 – J26	
J19 – J28	
J19 – J24	SLU Ch 0 Address 176500
J18 – J23	
J20 – J21	ROM Memory (000000 Starting Address)
J30 – J34	RAM Memory (100000 Starting Address)
J31 – J34	
J32 – J34	
J51 – J56	SLU Vectors (Ch-0, 300; Ch-1, 60)
J52 – J54	
J54 – J55	
J53 – J57	
	SLU CH 0 Parameters
J64 – J66	Even parity
J62 – J66	8 bits, no parity
J63 – J65	One-stop bit
J45 – J50	Baud rate (38,400)
	SLU CH 1 Parameters
J59 – J66	8 bits, no parity
J61 – J66	Even parity
J60 – J65	One-stop bit
J46 – J48	Baud rate (9600)
J67 – J68	Crystal clock
W1, W3	Installed

APPENDIX D

TA489A Status Register Format

SUB ADDRESS NUMBER													MESSAGE BYTE NUMBER											

	★	7	★	6	★	5	★	4	★	3	★	2	★	1	★	0	★							
	★		★		★		★		★		★		★		★		★							
0	★	MEMORY BLOCK			★	STEP		★	CHANNEL		★	CAL		★	STOP		★	SINGLE		★	AUTO		★	5
	★	(0 - 3)			★	RE-		★	STEP		★	BLOCK		★	CAL		★	CHANNEL		★	CAL		★	
	★				★	SPONSE		★	SELECT		★	SELECT		★			★	CAL		★			★	

	★		★		★		★		★		★		★		★		★							
	★		★		★		★		★		★		★		★		★							
1	★	X	★	S L O T A D D R E S S (0 0 0 - 1 7 7)										★	6									
	★		★		★		★		★		★		★		★		★							
	★		★	1	★	4	★	2	★	1	★	4	★	2	★	1	★							

	★		★		★		★		★		★		★		★		★							
	★		★		★		★		★		★		★		★		★							
2	★	STEP RESPONSE RATE						★	LAST STEP (0 - 15)						★	7								
	★	3		2		1		0	★	3		2		1		0	★							
	★		★		★		★		★		★		★		★		★							

BIT NUMBER				STEP RESPONSE				BIT NUMBER				STEP RESPONSE												
3 2 1 0				PULSE RATE				3 2 1 0				PULSE RATE												
0 0 0 0				5.0 Hz				1 0 0 0				2.0 KHz												
0 0 0 1				10.0 Hz				1 0 0 1				5.0 KHz												
0 0 1 0				20.0 Hz				1 0 1 0				10.0 KHz												
0 0 1 1				50.0 Hz				1 0 1 1				20.0 KHz												
0 1 0 0				100.0 Hz				1 1 0 0				50.0 KHz												
0 1 0 1				200.0 Hz				1 1 0 1				100.0 KHz												
0 1 1 0				500.0 Hz				1 1 1 0				200.0 KHz												
0 1 1 1				1,000.0 Hz				1 1 1 1				FRONT PANEL CONTROL												

	★		★		★		★		★		★		★		★		★							
	★		★		★		★		★		★		★		★		★							
3	★	X	★	X	★	X	★	X	★	X	★	X	★	X	★	X	★	8						
	★		★		★		★		★		★		★		★		★							
	★		★		★		★		★		★		★		★		★							

FUNCTION CODES: 1 - Write One (7-Byte Message)
2 - Read One (7-Byte Message)
5 - Write Four (9-Byte Message)
6 - Read Four (9-Byte Message)

SUB ADDRESS NUMBER	MESSAGE BYTE NUMBER	
0	5	<p>*****</p> <p>★ 7 ★ 6 ★ 5 ★ 4 ★ 3 ★ 2 ★ 1 ★ 0 ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ MEMORY BLOCK ★ X ★ X ★ X ★ X ★ X ★ X ★</p> <p>★ (0 - 3) ★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>*****</p>
1	6	<p>*****</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ X ★ S L O T A D D R E S S (0 0 0 - 1 7 7) ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ ★ 1 ★ 4 ★ 2 ★ 1 ★ 4 ★ 2 ★ 1 ★</p> <p>*****</p>
2	7	<p>*****</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ X ★ X ★ X ★ X ★ X ★ X ★ X ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>*****</p>
3	8	<p>*****</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ X ★ X ★ X ★ X ★ X ★ X ★ X ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>*****</p>
4	9	<p>*****</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>★ SVB 7 ★ SVB 6 ★ SVB 5 ★ SVB 4 ★ SVB 3 ★ SVB 2 ★ SVB 1 ★ SVB 0 ★</p> <p>★ 1.25MV★ 625uV ★312.5uV★~156uV ★ ~78uV ★ ~39uV ★ ~20uV ★ ~10uV ★</p> <p>★ ★ ★ ★ ★ ★ ★ ★ ★ ★</p> <p>*****</p> <p>SVB 4 = 156.25uV</p> <p>SVB 3 = 78.125uV</p> <p>SVB 2 = 39.0625uV</p> <p>SVB 1 = 19.53125uV</p> <p>SVB 0 = 9.765625uV</p>

APPENDIX E

TA489A Memory Format

SUB ADDRESS NUMBER	MESSAGE BYTE NUMBER

★ 7 ★ 6 ★ 5 ★ 4 ★ 3 ★ 2 ★ 1 ★ 0 ★	
★ ★ ★ ★ ★ ★ ★ ★ ★ ★	
5 ★ SVB15 ★ SVB14 ★ SVB13 ★ SVB12 ★ SVB11 ★ SVB10 ★ SVB 9 ★ SVB 8 ★	10
★ 320MV ★ 160MV ★ 80MV ★ 40MV ★ 20MV ★ 10MV ★ 5MV ★ 2.5MV ★	
★ ★ ★ ★ ★ ★ ★ ★ ★ ★	
20 BIT UNSIGNED NUMBER - POLARITY DETERMINED FROM SIGN BIT	

★ ★ ★ ★ ★ ★ ★ ★ ★ ★	
★ ★ ★ ★ ★ ★ ★ ★ ★ ★	
★ ★ ★ ★ ★ ★ ★ ★ ★ ★	
6 ★ JUMP ★ X ★ X ★ POLARITY MSB ★ ★ ★ ★ ★	11
★ CAL ★ ★ ★ ★ ★ REVERSE★ SVB19 ★ SVB18 ★ SVB17 ★ SVB16 ★	
★ ★ ★ ★ ★ (SIGN)★ 5.12V ★ 2.56V ★ 1.28V ★ 640MV ★	
★ ★ ★ ★ ★ BIT ★ ★ ★ ★ ★	

0 - CAL	0 - NORMAL (PLUS)
1 - SKIP (JUMP) THIS	1 - REVERSE (MINUS)
CHANNEL FOR THIS BLOCK	

★ ★ ★ ★ ★ ★ ★ ★ ★ ★	
★ ★ ★ ★ ★ ★ ★ ★ ★ ★	
★ ★ ★ ★ ★ ★ ★ ★ ★ ★	
7 ★ CALIBRATION PROM PROGRAMS ★ X ★ X ★ CALIB.★	12
★ PRMA3 PRMA2 PRMA1 PRMA0 ★ ★ ★ ★ ★	
★ ★ ★ ★ ★ ★ ★ ★ ★ ★	

NORMAL	SPECIAL
0000 - ZERO CAL	SK1
0001 - SHUNT CAL	SK2
0010 - STEP CAL	SK1 & SK3
0011 - +INT TEST	N/A
0100 - -INT TEST	N/A
0101 - AMP CAL (1/1)	N/A
0110 - ATTEN CAL (10/1)	N/A
0111 - ATTEN CAL (100/1)	N/A
1000 - ATTEN CAL (1000/1)	N/A
1001 - N/A	SK3
1010 - N/A	SK1 & SK2
1011 - N/A	SK2 & SK3
1100 - N/A	SK1, SK2 & SK3
1101 - N/A	N/A
1110 - N/A	EXTERNAL
1111 - GAGE	N/A

FUNCTION CODES: 11 - MEMORY WRITE	
12 - MEMORY READ	
(13-Byte MESSAGES)	

APPENDIX F

TA489A Calibration Step PROM Program

OCT ADDR	HEX ADDR	OCT DATA	HEX DATA	STEP
00	00	01	01	01
01	01	02	02	02
02	02	03	03	03
03	03	04	04	04
04	04	05	05	05
05	05	06	06	06
06	06	07	07	07
07	07	10	08	08
10	08	11	09	09
11	09	12	0A	10
12	0A	21	11	11
13	0B	22	12	12
14	0C	23	13	13
15	0D	24	14	14
16	0E	25	15	15
17	0F	36	16	16

PROM Information:

Type — 82S123
Location — CK-T56556 Sh 15
(2AC14)

APPENDIX G

TA489A Step Response PROM Program

OCT ADDR	HEX ADDR	OCT DATA	HEX DATA	RATE SELECTED
1776	3FE	04	04	100 Hz
1775	3FD	05	05	200 Hz
1773	3FB	06	06	500 Hz
1767	3F7	07	07	1 kHz
1757	3EF	10	08	2 kHz
1737	3DF	11	09	5 kHz
1677	3BF	12	0A	10 kHz
1577	37F	13	0B	20 kHz
1377	2FF	14	0C	50 kHz
0777	1FF	15	0D	100 kHz

PROM Information:

Type — 2716
Location — CK-T56556 Sh 32
(2EG19)

APPENDIX H

TA489A Calibration PROM Code

Binary Address	Hexadecimal Address	Binary Data	Calibration Type
000000000000	000	00000000	Zero Cal
000000000001	001	00000000	
000000000010	002	00000000	
000000000011	003	00000000	
000000000100	004	00000000	
000000000101	005	00000000	
000000000110	006	00000000	
000000000111	007	00000000	
000000001000	008	00000000	
000000001001	009	00000000	
000000001010	00A	00000000	
000000001011	00B	00000000	
000000001100	00C	00000000	
000000001101	00D	00000000	
000000001110	00E	00001111	
000000001111	00F	00001111	
000000010000	010	00000001	Shunt Cal
000000010001	011	00000001	
000000010010	012	00000001	
000000010011	013	00000001	
000000010100	014	00000001	
000000010101	015	00000001	
000000010110	016	00000001	
000000010111	017	00000001	
000000011000	018	00000001	
000000011001	019	00000001	
000000011010	01A	00000001	
000000011011	01B	00000001	
000000011100	01C	00000001	
000000011101	01D	00000001	
000000011110	01E	00001111	
000000011111	01F	00001111	

Binary Address	Hexadecimal Address	Binary Data	Calibration Type
00000100000	020	00000010	Step Cal
00000100001	021	00000010	
00000100010	022	00000010	
00000100011	023	00000010	
00000100100	024	00000010	
00000100101	025	00000010	
00000100110	026	00000010	
00000100111	027	00000010	
00000101000	028	00000010	
00000101001	029	00000010	
00000101010	02A	00000010	
00000101011	02B	00000010	
00000101100	02C	00000010	
00000101101	02D	00000010	
00000101110	02E	00001111	
00000101111	02F	00001111	
00000110000	030	00000011	+ Internal Test
00000110001	031	00000011	
00000110010	032	00000011	
00000110011	033	00000011	
00000110100	034	00000011	
00000110101	035	00000011	
00000110110	036	00000011	
00000110111	037	00000011	
00000111000	038	00000011	
00000111001	039	00000011	
00000111010	03A	00000011	
00000111011	03B	00000011	
00000111100	03C	00000011	
00000111101	03D	00000011	
00000111110	03E	00001111	
00000111111	03F	00001111	
00001000000	040	00000100	- Internal Test
00001000001	041	00000100	
00001000010	042	00000100	
00001000011	043	00000100	
00001000100	044	00000100	
00001000101	045	00000100	
00001000110	046	00000100	
00001000111	047	00000100	
00001001000	048	00000100	
00001001001	049	00000100	
00001001010	04A	00000100	
00001001011	04B	00000100	
00001001100	04C	00000100	
00001001101	04D	00000100	
00001001110	04E	00001111	
00001001111	04F	00001111	

Binary Address	Hexadecimal Address	Binary Data	Calibration Type
00001010000	050	00000101	AMP Cal (1:1)
00001010001	051	00000101	
00001010010	052	00000101	
00001010011	053	00000101	
00001010100	054	00000101	
00001010101	055	00000101	
00001010110	056	00000101	
00001010111	057	00000101	
00001011000	058	00000101	
00001011001	059	00000101	
00001011010	05A	00000101	
00001011011	05B	00000101	
00001011100	05C	00000101	
00001011101	05D	00000101	
00001011110	05E	00001111	
00001011111	05F	00001111	
00001100000	060	00000110	Attenuation Cal (10:1)
00001100001	061	00000110	
00001100010	062	00000110	
00001100011	063	00000110	
00001100100	064	00000110	
00001100101	065	00000110	
00001100110	066	00000110	
00001100111	067	00000110	
00001101000	068	00000110	
00001101001	069	00000110	
00001101010	06A	00000110	
00001101011	06B	00000110	
00001101100	06C	00000110	
00001101101	06D	00000110	
00001101110	06E	00001111	
00001101111	06F	00001111	
00001110000	070	00000111	Attenuation Cal (100:1)
00001110001	071	00000111	
00001110010	072	00000111	
00001110011	073	00000111	
00001110100	074	00000111	
00001110101	075	00000111	
00001110110	076	00000111	
00001110111	077	00000111	
00001111000	078	00000111	
00001111001	079	00000111	
00001111010	07A	00000111	
00001111011	07B	00000111	
00001111100	07C	00000111	
00001111101	07D	00000111	
00001111110	07E	00001111	
00001111111	07F	00001111	

Binary Address	Hexadecimal Address	Binary Data	Calibration Type
00010000000	080	00001000	Attenuation Cal (1000:1)
00010000001	081	00001000	
00010000010	082	00001000	
00010000011	083	00001000	
00010000100	084	00001000	
00010000101	085	00001000	
00010000110	086	00001000	
00010000111	087	00001000	
00010001000	088	00001000	
00010001001	089	00001000	
00010001010	08A	00001000	
00010001011	08B	00001000	
00010001100	08C	00001000	
00010001101	08D	00001000	
00010001110	08E	00001111	
00010001111	08F	00001111	
00010010000	090	00001001	Special Cal (K3)
00010010001	091	00001001	
00010010010	092	00001001	
00010010011	093	00001001	
00010010100	094	00001001	
00010010101	095	00001001	
00010010110	096	00001001	
00010010111	097	00001001	
00010011000	098	00001001	
00010011001	099	00001001	
00010011010	09A	00001001	
00010011011	09B	00001001	
00010011100	09C	00001001	
00010011101	09D	00001001	
00010011110	09E	00001111	
00010011111	09F	00001111	
00010100000	0A0	00001010	Special Cal (K1 & K2)
00010100001	0A1	00001010	
00010100010	0A2	00001010	
00010100011	0A3	00001010	
00010100100	0A4	00001010	
00010100101	0A5	00001010	
00010100110	0A6	00001010	
00010100111	0A7	00001010	
00010101000	0A8	00001010	
00010101001	0A9	00001010	
00010101010	0AA	00001010	
00010101011	0AB	00001010	
00010101100	0AC	00001010	
00010101101	0AD	00001010	
00010101110	0AE	00001111	
00010101111	0AF	00001111	

Binary Address	Hexadecimal Address	Binary Data	Calibration Type
00010110000	0B0	00001011	Special Cal (K2 & K3)
00010110001	0B1	00001011	
00010110010	0B2	00001011	
00010110011	0B3	00001011	
00010110100	0B4	00001011	
00010110101	0B5	00001011	
00010110110	0B6	00001011	
00010110111	0B7	00001011	
00010111000	0B8	00001011	
00010111001	0B9	00001011	
00010111010	0BA	00001011	
00010111011	0BB	00001011	
00010111100	0BC	00001011	
00010111101	0BD	00001011	
00010111110	0BE	00001111	
00010111111	0BF	00001111	
00011000000	0C0	00001100	Special Cal (K1, K2 & K3)
00011000001	0C1	00001100	
00011000010	0C2	00001100	
00011000011	0C3	00001100	
00011000100	0C4	00001100	
00011000101	0C5	00001100	
00011000110	0C6	00001100	
00011000111	0C7	00001100	
00011001000	0C8	00001100	
00011001001	0C9	00001100	
00011001010	0CA	00001100	
00011001011	0CB	00001100	
00011001100	0CC	00001100	
00011001101	0CD	00001100	
00011001110	0CE	00001111	
00011001111	0CF	00001111	
00011010000	0D0	00000000	(Not Used)
00011010001	0D1	00000000	
00011010010	0D2	00000000	
00011010011	0D3	00000000	
00011010100	0D4	00000000	
00011010101	0D5	00000000	
00011010110	0D6	00000000	
00011010111	0D7	00000000	
00011011000	0D8	00000000	
00011011001	0D9	00000000	
00011011010	0DA	00000000	
00011011011	0DB	00000000	
00011011100	0DC	00000000	
00011011101	0DD	00000000	
00011011110	0DE	00001111	
00011011111	0DF	00001111	

Binary Address	Hexadecimal Address	Binary Data	Calibration Type
00011100000	OE0	00000000	(Not Used)
00011100001	OE1	00000000	
00011100010	OE2	00000000	
00011100011	OE3	00000000	
00011100100	OE4	00000000	
00011100101	OE5	00000000	
00011100110	OE6	00000000	
00011100111	OE7	00000000	
00011101000	OE8	00000000	
00011101001	OE9	00000000	
00011101010	OEa	00000000	
00011101011	OEb	00000000	
00011101100	OEc	00000000	
00011101101	OEd	00000000	
00011101110	OEe	00001111	
00011101111	OEf	00001111	
00011110000	OF0	00001111	Gage Cal
00011110001	OF1	00001111	
00011110010	OF2	00001111	
00011110011	OF3	00001111	
00011110100	OF4	00001111	
00011110101	OF5	00001111	
00011110110	OF6	00001111	
00011110111	OF7	00001111	
00011111000	OF8	00001111	
00011111001	OF9	00001111	
00011111010	OFa	00001111	
00011111011	OFb	00001111	
00011111100	OFc	00001111	
00011111101	OFd	00001111	
00011111110	OFe	00001111	
00011111111	OFF	00001111	

APPENDIX I

Jumpers on DEC Board LSI-11/23 CPU (M8186)

W1	In	Internal Master Clock Enabled
W2	Out	Memory Management Delay
W3	In	Memory Management Delay
W4	In	Line Time Clock Disabled
W5	Out	Power-Up Mode 0, PC@24, PS@26
W6	Out	Power-Up Mode 0, PC@24, PS@26
W7	Out	ODT on Halt
W8	In	Bootstrap to 173000
W9	In	Bits 9-15 of Bootstrap address (If W8 is out)
W10	In	
W11	In	
W12	In	
W13	In	
W14	In	
W15	In	
W16	In	TTL Clock to Chip E39
W17	In	TTL Clock to Chip E48
W18	Out	Wake-up Circuit Enabled

DISTRIBUTION:

EG&G Energy Measurement Groups (4)

Attn: G. Hughes

M. Johnson

P. Martinez

R. Salas

Kirtland AFB

Albuquerque, NM 87115

2514	L. L. Bonzon
2514	R. F. LeBlanc (12)
7120	M. J. Navratil
7121	E. D. Baker
7121	R. A. David
7121	L. W. Ebinger
7121	R. R. Olsberg
7121	J. M. Opalka (2)
7121	S. G. Sevier
7121	D. K. Werling
7123	R. W. Donohoe
7123	L. J. Keck
7123	G. L. Ogle
7124	M. L. Bakos
7124	D. J. Belding
7124	S. E. Dains
7124	D. A. Geene
7124	W. J. Kluesner
7124	P. L. Nelson
8024	P. W. Dean
3141	S. A. Landenberger (5)
3151	W. L. Garner (3)
3154-1	C. H. Dalin (28)
	For DOE/OSTI (Unlimited Release)