DOE/ET/28354-1/2

THE ANALYTIC SCIENCES CORPORATION

TR-809-2

USER'S MANUAL FOR COVARIANCE AND HYPOTHESIS TESTING PROGRAM

June 1978

DISCLAIMER

This book was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

Prepared Under:

Contract No. E(11-1) - 4084

for

UNITED STATES DEPARTMENT OF ENERGY

Washington, DC

Prepared by:

J. Thomas Parr
Gary P. Bogar
David H. Johnson

Approved by:

Arthur A. Sutherland, Jr.
Joel M. Winett

THE ANALYTIC SCIENCES CORPORATION

Six Jacob Way

Reading, Massachusetts 01867

MASTER

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency Thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

DISCLAIMER

Portions of this document may be illegible in electronic image products. Images are produced from the best available original document.

FOREWORD

This document comprises the user manual for the computer programs developed under Contract No. 18706(14-08-0001-15049) for the U.S. Geological Survey and Contract No. E (11-1) - 4084 for the U.S. Department of Energy. These programs were exercised using geophysical data for geothermal exploration. Most recent results of that study are reported in a companion report, TR-809-1.

TABLE OF CONTENTS

	Page No.
FOREWORD	ii
List of Figures	v
List of Tables	vi
 1. INTRODUCTION	 1-1
2. COVARIANCE PROGRAM (COVAR)	2-1
2.1 Purpose	2-1
2.2 Mathematical Equations	2-1
2.3 COVAR Usage and User Instructions	2-3
2.3.1 COVAR Input	2-3
2.3.2 COVAR Output	2-7
2.4 Program Description	2-9
2.4.1 Main Program	2-9
2.4.2 Subroutine SCOVAR	2-9
2.4.3 Subroutine CHECK	2-14
2.4.4 Subroutine PRNTR	2-14
2.4.5 Subroutine LEIG	2-17
2.4.6 Block Data Routine	2-19
2.4.7 Subroutine SVDRS	2-19
2.4.8 Subroutine QRBD	2-19
2.4.9 Subroutine G1	2-19
2.4.10 Subroutine G2	2-19
2.4.11 Function DIFF	2-20
2.4.12 Subroutine H12	2-20
 3. HYPOTHESIS TESTING PROGRAM (LIKE)	 3-1
3.1 Purpose	3-1
3.2 Mathematical Equations	3-2
3.3 LIKE Usage and User Instructions	3-2
3.3.1 LIKE Input	3-3
3.3.2 LIKE Output	3-5
3.4 Program Description	3-6
3.4.1 Main Program	3-6
3.4.2 Subroutine SLIKE	3-7
3.4.3 Subroutine SLIKE1	3-11
3.4.4 Subroutine PRNTL	3-13
 4. SUMMARY	 4-1

TABLE OF CONTENTS (Continued)

	<u>Page No.</u>
APPENDIX A - COVARIANCE PROGRAM LISTING	A-1
APPENDIX B - SAMPLE EXECUTION OF COVARIANCE PROGRAM	B-1
APPENDIX C - HYPOTHESIS TESTING PROGRAM LISTING	C-1
APPENDIX D - SAMPLE EXECUTION OF HYPOTHESIS TESTING PROGRAM	D-1
APPENDIX E - DESCRIPTION OF THE DELIVERABLE TAPE	E-1
APPENDIX F - JOB CONTROL STATEMENTS	F-1

LIST OF FIGURES

<u>Figure No.</u>		<u>Page No.</u>
1-1	Overview of Computer Processing Steps for Hypothesis Testing	1-3
2.3-1	Interfaces of Programs COVAR and LIKE	2-4
2.4-1	Overview of the Program COVAR	2-10
2.4-2	Flowchart of COVAR (Main Program)	2-11
2.4-3	Flowchart of the Subroutine SCOVAR	2-13
2.4-4	Flowchart of Subroutine CHECK	2-15
2.4-5	Flowchart of Subroutine PRNTR	2-16
2.4-6	Flowchart of Subroutine LEIG	2-18
3.4-1	Overview of the Program LIKE	3-6
3.4-2	Flowchart of LIKE (Main Program)	3-9
3.4-3	Flowchart of Subroutine SLIKE	3-10
3.4-4	Flowchart of Subroutine SLIKE1	3-12
3.4-5	Flowchart of Subroutine PRNTL	3-14

LIST OF TABLES

<u>Table No.</u>		<u>Page No.</u>
2.3-1	Interfaces of Programs COVAR and LIKE	2-4
2.3-2	Record #1 Units 31-34	2-5
2.3-3	Record #2-#21 Units 31-34	2-6
2.3-4	Record #22-END Units 31 and 33	2-6
2.3-5	Record #22 Units 32 and 34	2-6
2.3-6	Disposition of Records on Units 31-34	2-7
2.4-2	Interface with Program SCOVAR	2-12
2.4-3	Interface with Subroutine CHECK	2-14
2.4-4	Interface with Subroutine PRNTR	2-16
2.4-5	Interface with Subroutine LEIG	2-17
3.3-1	Data Input NAMELIST	3-4
3.4-2	Interface with Program SLIKE	3-8
3.4-3	Interface with Subroutine SLIKE1	3-11
3.4-4	Interface with Subroutine PRNTL	3-13

INTRODUCTION

1.

This document describes the statistical data processing programs that were developed for application of hypothesis testing methods to geophysical exploration. A companion document, TR-809-1, should be referred to for a detailed description of the approach and results of the application to the regional evaluation of geothermal potential in the state of Nevada.

The hypothesis testing approach to analysis of geophysical data is a basis for pattern recognition. In the case of interest, patterns are comprised of combinations of "feature indices" that are generated through a preprocessing step. These feature indices are computed from the various geophysical survey data available and are intended to highlight those characteristics of the survey data that are relevant to the resource in question. A wide variety of preprocessing algorithms are possible, depending on the form of the original data, and the mechanism for association with the resource. Simple spatial density transforming algorithms or more sophisticated transforms such as the Fourier transform to extract spatial frequency components might be appropriate, depending on the specifics of the problem. Details of the preprocessing steps employed in the current study are reported in TR-809-1.

Having defined several feature indices at uniformly spaced, commonly referenced grid points encompassing the region of interest, the indices are interpolated to the hot spring locations. The interpolated index values as well as

the index values for the entire region are then merged to form two main data bases for more efficient processing in subsequent steps. These data bases consist of

- Index values for the entire region of interest
- A selected interpolated set of index values corresponding to locations of known resources within the region.

The later set is sometimes referred to as the learning set.

In the present study for evaluation of regional geothermal potential, the learning set is defined by locations of 17 known hot springs with temperature in excess of 150°C. Selected feature index values corresponding to these locations are then employed as a representative signature combination in a search to determine other locations with similar features. The steps involved in this evaluation are summarized in Fig. 1-1 and include preprocessing, merging, selection of appropriate sets of feature indices, and finally the statistical evaluation of these sets of the indices in the Fortran programs COVAR and LIKE.

This document includes a description of the two main programs which involve statistical processing. These programs are denoted as the covariance computation step (COVAR) and the hypothesis testing step (LIKE) as illustrated in Fig. 1-1. The program COVAR computes multidimensional means and standard deviations of the selected indices corresponding to the two major data bases described above. Additional computations are included for principle component analysis. The program LIKE is subsequently exercised to compute a likelihood ratio function for the entire region, considering the statistics output from COVAR. The final output is a

gridded array of likelihood values which indicate relative geothermal potential over the region of study.

R-25932

Figure 1-1 Overview of Computer Processing Steps for Hypothesis Testing

2. THE COVARIANCE PROGRAM (COVAR)

2.1 PURPOSE

The purpose of this program is to compute the statistics and transformation matrices appropriate for selected feature indices to be used in the likelihood evaluation. Estimates of first and second-order multidimensional statistics of the feature indices that pertain to specific locations of known geothermal activity as well as the entire region are generated. In addition, eigenvectors, eigenvalues and transformation matrices for principle component analysis are generated as outputs of this program for use in the subsequent likelihood ratio evaluation.

2.2 MATHEMATICAL EQUATIONS

The averages of the selected indices are computed according to

$$\underline{m}_j = \frac{1}{k_j} \sum_{s_j} \underline{x}$$

where the vector $\underline{x}$ contains elements corresponding to the selected indices and the subscript j denotes the j^{th} hypothesis. k_j refers to the number of points evaluated for the j^{th} hypothesis and s_j defines that set of points for which the j^{th} hypothesis is assumed to be true. Specifically, there are only two hypotheses and we define

- s_1 as the set of all points within a region approximated by the state of Nevada (assumed hypothesis: there is no geothermal energy).
- s_2 as the set of all points within s_1 that are also known locations of hot springs with temperatures in excess of 150°C (assumed hypothesis: there is geothermal energy).

The covariance matrix is computed from

$$P_j = \frac{1}{(k_j-1)} \sum_{s_j} (\underline{x} - \underline{m}_j)(\underline{x} - \underline{m}_j)^T$$

and has a dimension $n \times n$ where n is the number of features extractable from the data.

The correlation matrix provides an obvious indication of the relative redundancy of selected feature indices and is directly computed for each data base from the relevant covariance matrix.

$$C = S P S$$

where S is a diagonal matrix and data base subscripts are omitted for clarity with

$$S_{ii} = 1 / (P_{ii})^{\frac{1}{2}}, \quad i = 1, 2, n.$$

The eigenvalues and eigenvectors are computed for the correlation matrix C using a singular value decomposition method. The eigenvectors are normalized to a unit length and used to form an orthonormal modal matrix, B .

$$B = \begin{bmatrix} \underline{e}_1 & \underline{e}_2 & \dots & \underline{e}_n \end{bmatrix}$$

where $\underline{e}_1, \dots, \underline{e}_n$ are the normalized eigenvectors of the positive definite correlation matrix, C , corresponding to eigenvalues $\lambda_1, \dots, \lambda_n$.

The elements S_{ii} and λ_i , as well as the transformation matrix B , computed for both data bases are then output for direct usage in the Hypothesis Testing Program.

2.3 COVAR USAGE AND USER INSTRUCTIONS

The program COVAR has been written to compute a covariance matrix, standard deviation, correlation matrix, a matrix of eigenvectors, and a set of eigenvalues for each of two data bases. The averages, standard deviations, eigenvectors, and eigenvalues are then saved for program LIKE. Figure 2.3-1 contains an overview of the COVAR and LIKE interfaces.

2.3.1 COVAR Input

Input to COVAR takes two forms:

- Card image input
- Tape and/or disk inputs.

The card image input is on Fortran logical unit 5 and consists of a selection vector to choose the parameters in computing a covariance matrix. The selection vector is input using the NAMELIST identified as DATA and described in Table 2.3-1.

The data bases reside on Fortran logical units 31 through 34. That on units 31 and 32 (Data Base 1) must be the general data base (e.g. for the gridded state of Nevada),

R-25931

Figure 2.3-1 Interfaces of Programs COVAR and LIKE

TABLE 2.3-1
DATA INPUT (NAMELIST)

T-0617

VARIABLE	DESCRIPTION	DEFAULT
SEL(I)	Number of the parameter selected to compute the covariance matrix. SEL(I) is dimensioned 100 and is input using standard NAMELIST convention.	0*

*0 terminates selection vector, i.e., no other values of SEL(I) are used.

while the data base on units 33 and 34 is the specialized one (e.g., for the hot springs locations in Nevada).

Each of the files (31 through 34) have file descriptors on the first 21 records. These file descriptors are necessary to ensure that the proper files are being used and passed to the program LIKE. The 22nd record on units 32 and 34 contains the averages for the index values on units 31 and 33, respectively. The files on units 31 and 33 start on the 22nd record. Each record corresponds to a location and each variable corresponds to some criterion.

The same Fortran format is used for all the records on units 31 to 34 (100A4). Each data base can contain up to 100 feature indices generated by preprocessing of geophysical or other appropriate data. Descriptions of the various records are shown in Tables 2.3-2, 2.3-3, 2.3-4, and 2.3-5. Table 2.3-6 shows the disposition of the records on the various files.

TABLE 2.3-2
RECORD #1 UNITS 31-34

T-0618

VARIABLE	DESCRIPTION
NDT(1)	Month file was updated
NDT(2)	Day file was updated
NDT(3)	Year file was updated
NDT(4)	Seconds of the day file was updated
MDM(1)	First dimension of data base
MDM(2)	Second dimension of data base
MDM(3)	Total number of points in data base
NPAR	Number of parameters actually present on data base
NDB(1)	Alphanumeric information either (DB 1) or (DB 2) for data base 1 or 2
NDB(2)	Alphanumeric information either (PTS) or (AVG)
DTITLE(90)	Title of this particular file

TABLE 2.3-3
RECORDS #2-#21 UNITS 31-34

T-0619

VARIABLE	DESCRIPTION
TITLE(I,J)	Jth word (4 letters, numbers, etc.) of the title of the Ith parameter. Title is dimensioned (100,20)

TABLE 2.3-4
RECORD #22-END UNITS 31 AND 33

T-0620

VARIABLE	DESCRIPTION
YY(I)	Value of Ith parameter. (Note values of over 1.E50 mean data point is not to be used.) YY is dimensioned (100)

TABLE 2.3-5
RECORD #22 UNITS 32 AND 34

T-0621

VARIABLE	DESCRIPTION
YY(I)	Average of Ith parameter. YY is dimensioned (100)

TABLE 2.3-6
DISPOSITION OF RECORDS ON UNITS 31-34

T-0622

UNIT 31	UNIT 32	UNIT 33	UNIT 34
Data Base 1 Values file	Data Base 1 Averages File	Data Base 2 Values File	Data Base 2 Averages File
Record #1 File Descrip- tors	Record #1 File Descrip- tors	Record #1 File Descrip- tors	Record #1 File Descrip- tors
Record #2-#21 Parameter Titles	Record #2-#21 Parameter Titles	Record #2-#21 Parameter Titles	Record #2-#21 Parameter Titles
Record #22 to end Values of Parameters	Record #22 Averages of Parameters	Record #22 to end Values of Parameters	Record #22 Averages of Parameters

Record number 1 on units 31 to 34 contains the file descriptors. This record is used to ensure that the proper files are read.

2.3.2 COVAR Output

The COVAR output takes two forms:

- Printed output on Fortran logical unit 6
- Saved output on tape, disk, or cards on Fortran logical units 21 and 22

The normal printed output consists of the following:

- File descriptors

- Titles of parameters used
- Covariance matrices
- Averages
- Standard deviations
- Correlation matrices
- Eigenvector matrices
- Eigenvalues
- Eigenvalues matrices

If the correct files are not read in proper sequence, the program terminates and an error message indicating the problem is printed.

For each data base, the saved output (in format 20A4) consists of the following.

- Descriptors of the original data base used
- Dimension of the covariance matrix
- Dates that the data bases were updated
- Dimensions of the data bases
- Number of parameters present in the data bases
- Parameter selection vector used
- Titles of the parameters used
- Averages and standard deviations
- Eigenvalues
- Eigenvectors

The organization of the data on the records depends on the dimension of the covariance matrix. The format 20A4 was chosen to facilitate the punching of these saved data sets, if necessary. If a covariance matrix is computed using the maximum dimension of 50, there would be 190 cards for each data base or a total of 380 cards punched; whereas, for a dimension of ten, there would be a total of 44 cards punched.

2.4 PROGRAM DESCRIPTION

COVAR consists of a main program, eleven subroutines, and a block data routine. Figure 2.4-1 gives an overview of the program.

2.4.1 Main Program

The main program contains all of the matrices used, dimensioned to their maximum allowable size of 50. The selection vector is then read using NAMELIST and checked for errors. If there are no errors, then the subroutine SCOVAR is called and the actual dimension of the matrices to be used, NDIM, is passed via COMMON. Figure 2.4-2 is a flowchart of the main program.

2.4.2 Subroutine SCOVAR

SCOVAR is the main computational routine. The matrices used are dimensioned by the actual main routine. The functions of SCOVAR include:

- Setting the unit numbers for the input and output files
- Reading of the standards for the file descriptors

Figure 2.4-1 Overview of the Program COVAR

Figure 2.4-2 Flowchart of the Main Program

- Printing out the file descriptors and the titles of the parameters used
- Calling the subroutine CHECK which reads each file descriptor and checks them against the standard
- Choosing the averages to be used based on the selection vector
- Saving the file descriptors for each data base for use in the program LIKE
- Initializing the eigenvalue matrix and covariance matrix
- Reading the values of each data base using the selection vector to choose the parameter desired

- Rejecting any values which have values over 1.E50
- Computing the covariance matrix
- Computing the correlation matrix
- Computing the standard deviation
- Calling the subroutine LEIG which is used for calculation of the eigenvectors and eigenvalues
- Printing the covariance matrix, averages, standard deviations, and correlation matrix using subroutine PRNTR
- Printing appropriate messages for errors

Figure 2.4-3 is a flowchart of the subroutine SCOVAR. Table 2.4-2 contains the variables passed as an argument list to SCOVAR.

TABLE 2.4-2
INTERFACE WITH PROGRAM SCOVAR

T-0623

VARIABLE	DESCRIPTION
COVM	Covariance matrix to be calculated
VAL	Values used from the data bases to calculate the covariance matrix
CORM	Correlation matrix to be calculated
AVG	The averages of the data base to be read and used
SD	To be used for computing standard deviations
S	To be used in calculating eigenvalues
BB	Dummy matrix
EIGVAL	Eigenvalue matrix

Figure 2.4-3 Flowchart of Subroutine SCOVAR

2.4.3 Subroutine CHECK

Subroutine CHECK is used to read the file descriptors for each file and check them against the descriptors on File 21 which will be used as a standard. If an error occurs, an appropriate error message is written and the program terminates. Figure 2.4-4 is a flowchart of the subroutine, while Table 2.4-3 contains the interface with subroutine CHECK.

TABLE 2.4-3
INTERFACE WITH SUBROUTINE CHECK

T-0624

VARIABLE	DESCRIPTION
MY	Unit number of file to be used
NT	Unit number of file to be written
IDB	Number of data base being used
NVA	Indicator to determine whether value file or average file is being read 1 - value file 2 - average file

2.4.4 PRNTR Subroutine

PRNTR is used to print out a matrix, the dimensions of the matrix, and a title describing the matrix. PRNTR also prints out column headings which can be used to relate the particular columns with the parameters used in calculating them. Figure 2.4-5 is a flowchart of subroutine PRNTR, while Table 2.4-4 contains the interface with subroutine PRNTR.

Figure 2.4-4 Flowchart of Subroutine CHECK

Figure 2.4-5 Flowchart of Subroutine PRNTR

TABLE 2.4-4
INTERFACE WITH SUBROUTINE PRNTR

T-0625

VARIABLE	DESCRIPTION
XMAT	Name of matrix to be printed
NROW	Number of rows of matrix
NCOL	Number of columns of matrix
TITLE	Alphanumeric title of matrix
N	Number of characters in title

2.4.5 LEIG Subroutine

LEIG performs the following functions:

- Initializes the identity matrix and eigenvector matrix
- Calls SVDRS which calculates the eigenvectors and eigenvalues
- Normalizes the eigenvectors
- Computes the eigenvalue matrix as a check (the diagonals must be equal to the eigenvalues computed by SVDRS and the off diagonal elements should be within roundoff accuracy of zero)
- Calls PRNTR to print the eigenvectors, eigenvalue matrix, and eigenvalues
- Saves the eigenvalues and eigenvectors for program LIKE.

Figure 2.4-6 is a flowchart of the subroutine LEIG, while Table 2.4-5 contains the interface with subroutine LEIG.

TABLE 2.4-5
INTERFACE WITH SUBROUTINE LEIG

T-0627

VARIABLE	DESCRIPTION
COVM	Covariance matrix which is replaced by the eigenvector matrix
CORM	Correlation matrix
NT	Output unit number file
S	Eigenvalues
BB	Dummy matrix
EIGVAL	Eigenvalue matrix

Figure 2.4-6 Flowchart of Subroutine LEIG

2.4.6 Block Data Routine

The block data routine is used to initialize the column headings in the named common statement CDATE. These column headings are used to correlate the columns of matrix printouts with the parameters used in calculating them.

2.4.7 Subroutine SVDRS

SVDRS is used to compute eigenvalues and eigenvectors for a symmetric, positive-semi-definite matrix using a singular value decomposition method. SVDRS calls the subroutine H12 which is used to perform Householder transformations and the subroutine QRBD which computes the singular value decomposition of the bidiagonal matrix. If convergence does not occur, an error message is printed and the program abends.

2.4.8 Subroutine QRBD

QRBD is used to compute the singular value decomposition of square bidiagonal matrix. QRBD calls the subroutines G1 and G2 and the function DIFF.

2.4.9 Subroutine G1

G1 is used to construct an orthogonal rotation matrix.

2.4.10 Subroutine G2

G2 is used to perform a matrix-vector product given the orthogonal rotation matrix constructed in subroutine G1.

2.4.11 Function DIFF

DIFF is used to make the test "If $((x+h)-x) \neq 0$ " in place of the test "If $(|h| > p|x|)$ " where p is the relative precision of the machine floating point arithmetic.

2.4.12 Subroutine H12

H12 is used either to compute a Householder transformation or, if one has been defined, to multiply the Householder transformation by a set of m -vectors.

3. HYPOTHESIS TESTING PROGRAM (LIKE)

3.1 PURPOSE

The purpose of this program is to compute the ratio of relative likelihood function values for alternate hypotheses at each gridded location within a given region of interest. The likelihood function pertaining to each of the two alternate hypotheses is computed from the multidimensional set of indices and first- and second-order statistics pertaining to that hypothesis. These statistics are output from COVAR. Principle component transformations also specified by COVAR are incorporated in LIKE for ease in eliminating extraneous components that may be subject to roundoff errors, leading to erroneous results.

The output of the program comprises a two-dimensional array of scalar relative likelihood ratio values. Each of these values correspond to an evaluation of a multidimensional feature index vector relative to the statistical distributions of two classes of data relating to the alternate hypotheses. The relative likelihood ratio is expressed as P_2/P_1 , where P_1 and P_2 are the relative likelihoods that hypotheses H_1 and H_2 are true respectively. This ratio has a value of unity if equal likelihood is computed for each of the alternate hypotheses. A ratio greater than unity would indicate that hypothesis 2 is more likely, whereas an opposite conclusion may be inferred from ratios less than unity.

3.2 MATHEMATICAL EQUATIONS

The likelihood ratio, Λ , is computed from

$$\Lambda(x,y) = \exp \left\{ -\frac{1}{2} (F_2 - F_1) \right\}$$

F_1 and F_2 are scalar values computed from

$$F_J = \sum_{I=1} NSEL(I) y_J(I)^2 / \lambda_J(I)$$

where $NSEL(I)$, $I=1,2,\dots,N$, are elements of a selection vector for specifying which principal components are to be used for the likelihood function calculation. The values of $NSEL(I)$ are either zero or one. The subscript, J denotes one of the two data bases and $I=1,2,\dots,N$, denotes the n components of the difference vector, $\underline{y}_J$. $\lambda_J(I)$ are the n eigenvalues for the J^{th} data base and $y_J(I)$ is the i^{th} element of $\underline{y}_J$.

For each point in the gridded region, the signature difference vector $\underline{y}_J$ relevant to the J^{th} data base is defined

$$\underline{y}_J = B_J^T (\underline{x} - \underline{m}_J)$$

where B_J is the modal transformation matrix defined by COVAR and the superscript T denotes the transpose. The vector $\underline{m}_J$ is an n dimensional vector comprised of mean values of selected indices from the J^{th} data base. The vector $\underline{x}$ is an n dimensional vector comprised of the values of the selected indices, corresponding to a specific location of interest within the region of interest.

3.3 LIKE USAGE AND USER INSTRUCTIONS

LIKE computes a likelihood function using the data saved by program COVAR. This data includes the averages,

standard deviations, eigenvectors, and eigenvalues for each of the two data bases. See Fig. 2.3-1 for the interface between programs COVAR and LIKE.

3.3.1 LIKE Input

Input to LIKE takes the following forms:

- Card image input
- COVAR-generated data on any appropriate device
- Tape or disk input containing Data Base 1 values

The card image input on Fortran logical unit 5 consists of selection vectors to use or delete columns and associated rows of eigenvectors that were output from program COVAR. The selection vectors are input using the NAMELIST, DATA. Table 3.3-1 describes the input data on unit 5.

The output from COVAR resides on logical units 21 and 22 as derived from Data Base 1 and Data Base 2, respectively.

This COVAR output consists of the following:

- Dimension of the covariance matrix generated by COVAR
- Dates that the data bases used by COVAR were updated
- Dimensions of the data bases
- Number of parameters present in the data bases

TABLE 3.3-1
DATA INPUT NAMELIST

T-0628

VARIABLE	DESCRIPTION	DEFAULT
NSELA(I)	Value of the Ith index relating to the Ith column of the eigenvector matrix for Data Base 1 1 - use (default value) 0 - do not use	1
NSELB(I)	Value of the Ith index relating to the Ith column of the eigenvector matrix for Data Base 2 1 - use (default value) 0 - do not use	1
ICARD	ICARD = 1 means output from COVAR is on cards (to stop REWINDS) ICARD $\neq$ 1 means output from COVAR is not on cards	0

- Parameter selection vector used
- Titles of the parameters

Note that all of the above input make up the descriptors of a file. COVAR output also contains the following:

- Averages and standard deviations
- Eigenvalues
- Eigenvectors

The format for this data is 20A4. No table is furnished because the placement of the data depends on the dimension of the eigenvector matrix which is variable. If the proper files are not used, appropriate error messages are printed.

The tape or disk input is the Data Base 1 value file which resides on unit 31. Refer to Tables 2.3-2, 2.3-3, and 2.3-4 for descriptions of the records. The format for this data is 100A4.

3.3.2 LIKE Output

The LIKE output takes two forms:

1. Printed output on Fortran logical unit 6
2. Saved output on tape or disk on Fortran logical unit 10

The normal printed output consists of the following:

- File descriptors
- Titles of parameters used
- Selector vectors
- Descriptors of each set of statistics from COVAR
- Eigenvalues
- Beta (transpose) matrix

Error messages are printed for any conditions that cause an abnormal termination.

The likelihood values are saved on Fortran logical unit 10 in the same order in which the gridded index values of Data Base 1 occur. The format of this output is 100A4 which is consistent with the input data.

3.4 PROGRAM DESCRIPTION

LIKE consists of a main program and three subroutines. Figure 3.4-1 gives an overview of the program.

Figure 3.4-1 Overview of the Program LIKE

3.4.1 Main Program

The main program contains all of the matrices used, dimensioned to their maximum allowable use. The dimensions cannot be less than the ones used by COVAR. The main program reads in selection vectors for using the eigenvector matrix transpose for each data base. The file descriptors are read to ensure that the proper files are being used. The file descriptors are then compared with the file descriptor standards (those found on File 21) and if there are no errors, the subroutine SLIKE is called. Subroutine SLIKE

is actually the main computational routine. Figure 3.4-2 is a flowchart of the main program.

3.4.2 SLIKE Subroutine

SLIKE is the main computational routine. The matrices used are dimensioned by the actual main routine. The functions of SLIKE include:

- Calling SLIKE1 which performs input and output on the various matrices
- Reading in the Data Base 1 value file and using the selection vector passed from COVAR to choose the appropriate values
- Computing the likelihood function at each point
- Saving the likelihood function for every point.

Figure 3.4-3 is a flowchart of the subroutine SLIKE. Table 3.4-2 contains the interface with program SLIKE.

TABLE 3.4-2
INTERFACE WITH PROGRAM SLIKE

T-0629

VARIABLE	DESCRIPTION	INPUT FILE
AVGA	Vector of averages	COVAR
SDA	Vector of standard deviations	COVAR
BETA	Transpose of eigenvector matrix	COVAR
EGVALA	Eigenvalue vector	COVAR
EIGVCA	Eigenvector matrix	COVAR
AVGB	Vector of averages	COVAR
SDB	Vector of standard deviations	COVAR
BETB	Transpose of eigenvector matrix	COVAR
EGVALB	Eigenvalue vector	COVAR
EIGVCB	Eigenvector matrix	COVAR
SELA	Selection vector for eigenvector matrix of Data Base 1	Input Cards
SELB	Selection vector for eigenvector matrix of Data Base 2	Input Cards
DDA	Internally generated values used to compute numerator of exponent in likelihood function	----
DDB	Internally generated values used to compute denominator of exponent in likelihood function	----

Figure 3.4-2 Flowchart of LIKE (Main Program)

Figure 3.4-3 Flowchart of Subroutine SLIKE

3.4.3 SLIKE1 Subroutine

SLIKE1 has the following functions:

- Reads in the file descriptors from the output of data base computations from COVAR
- Checks the descriptors to ensure use of proper files
- Reads in the average and the standard deviation vectors for each data base
- Reads in the eigenvalue vector and the eigenvectors for each data base
- Prints the eigenvalue vector and the eigenvector matrix for each data base
- Prints error messages for abnormal terminations

The printing of the matrices and vectors is done by subroutine PRNTL. Figure 3.4-4 is a flowchart of the subroutine SLIKE1 and Table 3.4-3 gives the interface with subroutine SLIKE1.

TABLE 3.4-3
INTERFACE WITH SUBROUTINE SLIKE1

T-0630

VARIABLE	DESCRIPTION
AVGC	Vector of averages
SDC	Vector of standard deviations
BETC	Transpose of eigenvector matrix
EGVALC	Eigenvalue matrix
EIGVCC	Eigenvector matrix
TITLE	Name of eigenvalue vector
NAME	Name of transpose of eigenvector matrix

Figure 3.4-4 Flowchart of Subroutine SLIKE1

3.4.4 PRNTL Subroutine

PRNTL is used to print out a matrix, the dimensions of the matrix, and a title describing the matrix. Unlike PRNTR in the program COVAR, PRNTL does not print out column headings since they are not applicable.

Figure 3.4-5 is a flow chart of subroutine PRNTL and Table 3.4-4 gives the interface with subroutine PRNTL.

Figure 3.4-5 Flowchart of subroutine PRNTL

TABLE 3.4-4
INTERFACE WITH SUBROUTINE PRNTL

T-0631

VARIABLE	DESCRIPTION
XMAT	Name of matrix to be printed
NROW	Number of rows of matrix
NCOL	Number of columns of matrix
TITLE	Alphanumeric title of matrix
N	Number of characters in the title

4.

SUMMARY

The concept of hypothesis testing is useful in evaluating multiple types of geophysical survey data for exploration. This document describes statistical computer programs which are intended for general usage in evaluating multidimensional feature indices for resource potential. In particular, the computer programs comprise a covariance computation program and a likelihood function evaluation program. These programs have been exercised in this study for geothermal exploration, using as many as 34 selected feature indices from a data base that may include up to 100 distinct indices. It is anticipated that many more indices might be considered simultaneously. Practical limitations occur with large covariances due to numerical errors in computing eigenvalues and eigenvectors.

The basic concept of hypothesis testing as formulated in this study is described in the following steps.

- Identification of signature parameters
- Measurement of statistics of signature parameters in the general region and in a "learning set" of locations, known to be geothermal resource areas
- Computation of a likelihood (ratio) map indicating the relative closeness of an observed signature to the learning set signature, as opposed to the regional signature.

APPENDIX A

COVARIANCE PROGRAM
SOURCE LISTING

	<u>Page No.</u>
A.1 COVAR (MAIN PROGRAM)	A-2
A.2 SCOVAR	A-4
A.3 LEIG	A-9
A.4 PRNTR	A-11
A.5 CHECK	A-12
A.6 SVDRS	A-15
A.7 QRBD	A-19
A.8 H12	A-23
A.9 G1	A-25
A.10 G2	A-26
A.11 DIFF	A-27
A.12 BLOCK DATA	A-28

A.1 COVAR (MAIN PROGRAM)

```

C*****MAI00010
C      PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAM      MAI00020
C      ROUTINE NAME - MAIN          TASC PROGRAM NO - 506      MAI00030
C      MAI00040
C      MAI00050
C      MAI00060
C*****MAI00070
C      THIS PROGRAM WAS PREPARED BY      MAI00080
C      MAI00090
C      THE ANALYTIC SCIENCES CORPORATION (TASC)      MAI00100
C      6 JACOB WAY      MAI00110
C      READING, MASSACHUSETTS 01867      MAI00120
C      MAI00130
C      FOR THE U.S. GEOLOGICAL SURVEY UNDER CONTRACT      MAI00140
C      NO. 18706(14-08-0001-15049) AND THE U.S. DEPARTMENT OF ENERGY      MAI00150
C      UNDER CONTRACT NO. E (11-1) - 4084. IT SHOULD NOT BE RELEASED      MAI00160
C      OUTSIDE THE U.S. GOVERNMENT WITHOUT PERMISSION FROM TASC.      MAI00170
C      MAI00180
C      MAI00190
C*****MAI00200
C      SUBROUTINES AND FUNCTION SUBPROGRAMS REQUIRED      MAI00210
C      SCOVAR      MAI00220
C      MAI00230
C      MAI00240
C*****MAI00250
C      *** THE PROGRAM IS DIMENSIONED TO HANDLE A COVARIANCE      MAI00260
C      MATRIX UP TO FIFTY PARAMETERS      MAI00270
C      MAI00280
C      MAI00290
C      MAI00300
C      COVM - COVARIANCE MATRIX      MAI00310
C      VAL - VALUES USED IN CALCULATING COVARIANCE MATRIX      MAI00320
C      BB - DUMMY MATRIX      MAI00330
C      AVG - AVERAGES OF PARAMETERS USED IN CALCULATING      MAI00340
C      COVARIANCE MATRIX      MAI00350
C      CORM - CORRELATION MATRIX      MAI00360
C      S - WILL CONTAIN EIGEN VALUES AS COMPUTED BY SVDRS      MAI00370
C      EIGVAL - EIGEN VALUE MATRIX      MAI00380
C      MAI00390
C      MAI00400
C      DIMENSION COVM(50,50),VAL(50),BB(50,50),AVG(50),      MAI00410
C      A CORM(50,50),S(50,3),EIGVAL(50,50),SD(50)      MAI00420
C      MAI00430
C      MAI00440
C      USESEL IS USED TO ENSURE THAT THE SELECTION VECTOR      MAI00450
C      DOES NOT HAVE DUPLICATE NON-ZERO ELEMENTS      MAI00460
C      IT IS DIMENSIONED ACCORDING TO THE NUMBER OF      MAI00470
C      POSSIBLE PARAMETERS PRESENT ON THE DATA BASES      MAI00480
C      MAI00490
C      LOGICAL*1 USESEL(100)      MAI00500
C      MAI00510
C      MAI00520
C      MAI00530
C      SEL IS THE SELECTION VECTOR      MAI00540
C      IT SHOULD CONTAIN THE NUMBERS OF THE PARAMETERS      MAI00550
C      SELECTED TO COMPUTE THE COVARIANCE MATRIX      MAI00560
C      IT IS DIMENSIONED ACCORDING TO THE NUMBER OF      MAI00570
C      POSSIBLE PARAMETERS ON THE DATA BASES      MAI00580
C      MAI00590
C      MAI00600
C      INTEGER*4 SEL      MAI00610
C      MAI00620
C      MAI00630
C      NDIM WILL BE THE DIMENSION OF THE COVARIANCE MATRIX.      MAI00640
C      CORRELATION MATRIX, ETC.      MAI00650
C      IT IS COMPUTED FROM THE SELECTION VECTOR      MAI00660
C      MAI00670
C      MAI00680
C      COMMON /ADATA/ NDIM,SEL(100)      MAI00690
C      EQUIVALENCE ( AVG(1),USESEL(1) ), ( VAL(1),SD(1) )      MAI00700
C      MAI00710
C      MAI00720
C      MAI00730
C      MAXDIM IS THE MAXIMUM POSSIBLE DIMENSION OF THE      MAI00740
C      COVARIANCE MATRIX. IT SHOULD BE SET EQUAL TO THE      MAI00750
C      DIMENSIONS OF THE COVARIANCE MATRIX, ETC.      MAI00760
C      MAI00770
C      MAI00780
C      DATA USESEL/100*F/, MAXDIM/50/      MAI00790
C      MAI00800

```

```

C      NDIM = 0
C      NAMELIST /DATA/ SEL
C      *** SELECTION VECTOR IS READ IN HERE USING NAMELIST.
C      SET THE VARIABLES SEL(I) = TO THE NUMBER OF THE
C      PARAMETER DESIRED.
C      SETTING SOME SEL(I) <= 0 TERMINATES THE SELECTION
C      VECTOR, I.E., NO MORE PARAMETERS ARE USED.
C
C      READ (5,DATA,END=99)
C
C      *** SELECTION VECTOR IS NOW BEING CHECKED FOR DUPLICATES
C      AND ALSO THE COUNT OF NUMBER OF PARAMETERS TO BE
C      USED IN THE COVARIANCE MATRIX IS BEING MADE
C
C      DO 10 I = 1,100
C      IF ( SEL(I).LE.0 ) GOTO 20
C      K = SEL(I)
C      IF ( USESEL(K) ) GOTO 99
C      USESEL(K) = .TRUE.
C      NDIM = NDIM + 1
C      10 CONTINUE
C      20 CONTINUE
C
C      *** CHECKING TO SEE THAT THE DIMENSION OF THE COVARIANCE
C      MATRIX IS GREATER THAN ZERO AND NOT GREATER THAN
C      THE MAXIMUM DIMENSION (MAXDIM)
C
C      IF ( NDIM.LT.1 .OR. NDIM.GT.MAXDIM ) GOTO 99
C
C      *** SCDVAR IS ACTUALLY THE MAIN COMPUTATION ROUTINE
C
C      CALL SCDVAR(COVM,VAL,CORM,AVG,SD,S,BB,EIGVAL)
C
C      99 STOP
C      END

```

MAI00810
 MAI00820
 MAI00830
 MAI00840
 MAI00850
 MAI00860
 MAI00870
 MAI00880
 MAI00890
 MAI00900
 MAI00910
 MAI00920
 MAI00930
 MAI00940
 MAI00950
 MAI00960
 MAI00970
 MAI00980
 MAI00990
 MAI01000
 MAI01010
 MAI01020
 MAI01030
 MAI01040
 MAI01050
 MAI01060
 MAI01070
 MAI01080
 MAI01090
 MAI01100
 MAI01110
 MAI01120
 MAI01130
 MAI01140
 MAI01150
 MAI01160
 MAI01170
 MAI01180
 MAI01190
 MAI01200
 MAI01210
 MAI01220
 MAI01230
 MAI01240
 MAI01250
 MAI01260
 MAI01270
 MAI01280

A.2 SCOVAR

```

C*****SC000010
C      PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAM      SC000020
C      ROUTINE NAME - SCOVAR          TASC PROGRAM NO - 507    SC000030
C      SC000040
C      SC000050
C      SC000060
C      SC000070
C      SC000080
C      SC000090
C      SC000100
C      SC000110
C      SUBROUTINE SCOVAR      SC000120
C      SC000130
C      PURPOSE      SC000140
C      SCOVAR IS THE ACTUAL MAIN ROUTINE      SC000150
C      ITS FUNCTIONS ARE:      SC000160
C      * CHECK FILE DESCRIPTORS      SC000170
C      * SET UP UNIT NUMBERS FOR INPUT AND OUTPUT FILES      SC000180
C      * COMPUTE COVARIANCE AND CORRELATION MATRICES      SC000190
C      * CALL LEIG TO COMPUTE EIGEN VECTORS AND EIGEN VALUES      SC000200
C      * PRINT VARIOUS MATRICES      SC000210
C      SC000220
C      SC000230
C      SC000240
C      USAGE      SC000250
C      CALL SCOVAR (COVM,VAL,CORM,AVG,SD,S,BB,EIGVAL)      SC000260
C      SC000270
C      SC000280
C      DESCRIPTION OF PARAMETERS      SC000290
C      COVM - COVARIANCE MATRIX TO BE COMPUTED      SC000300
C      VAL - VALUES OF POINTS READ FROM DATA BASE USED      SC000310
C      IN COMPUTING COVARIANCE MATRIX      SC000320
C      CORM - CORRELATION MATRIX TO BE COMPUTED      SC000330
C      AVG - AVERAGES OF DATA BASE PARAMETERS      SC000340
C      SD - STANDARD DEVIATIONS OF DATA BASE      SC000350
C      S - MATRIX WHICH WILL CONTAIN EIGEN VALUES      SC000360
C      BB - DUMMY MATRIX      SC000370
C      EIGVAL - EIGEN VALUE MATRIX      SC000380
C      SC000390
C      REMARKS      SC000400
C      THERE ARE VARIOUS ERROR ABENDS IF THE FILES BEING      SC000410
C      READ ARE NOT THE PROPER ONES OR NOT IN ORDER      SC000420
C      SC000430
C      SC000440
C      SUBROUTINES AND FUNCTION SUBPROGRAMS REQUIRED      SC000450
C      PRNTR      SC000460
C      LEIG      SC000470
C      CHECK      SC000480
C      SC000490
C      SC000500
C      SC000510
C      SC000520
C      SC000530
C      SC000540
C      SC000550
C      SC000560
C      SC000570
C      SC000580
C      SC000590
C      SC000600
C      SC000610
C      SC000620
C      SC000630
C      SC000640
C      SC000650
C      SC000660
C      SC000670
C      SC000680
C      SC000690
C      SC000700
C      SC000710
C      SC000720
C      SC000730
C      SC000740
C      SC000750
C      SC000760
C      SC000770
C      SC000780
C      SC000790
C      SC000800
C      DTITLE IS TITLE OF DATA BASE

```

A-5

```

C      WRITE (6,300) NDT,NDIM,NDM,NPAR
C
C      *** PRINTING THE TITLES ASSOCIATED WITH THE PARAMETERS
C      SELECTED FOR CALCULATING THE COVARIANCE MARIX
C
C      DO 5 I = 1,NDIM
C      K = SEL(I)
C      WRITE (6,301) I,COL(I),K,(TITLE(K,J),J=1,20)
C      IF ( K.LE.0 .OR. K.GT.NPAR ) GOTC 94
C      5 CONTINUE
C
C      *** IDB IS A COUNTER FOR THE DATA BASES BEING USED
C
C      IDB = 0
C      10 IDB = IDB + 1
C      NY = MY + 1
C      MY = NY + 1
C      NT = NT + 1
C
C      *** SUBROUTINE CHECK IS NOW CALLED TO CCMPARE FILE
C      DESCRIPTORS
C
C      NVA = 2
C      CALL CHECK(MY,IDB,NVA)
C
C      *** NOW READING IN THE AVERAGES FOR ALL THE PARAMETERS
C
C      READ (MY,200,END=99) YY
C
C      *** NOW SELECTING THE AVERAGES TO BE USED BY MEANS OF THE
C      SELECTION VECTOR
C
C      DO 20 I = 1,NDIM
C      K = SEL(I)
C      AVG(I) = YY(K)
C      20 CONTINUE
C
C      REWIND MY
C
C      *** NOW READING IN THE DESCRIPTORS FOR THE DATA BASE
C      WHICH CONTAINS THE VALUES
C
C      NVA = 1
C      CALL CHECK(NY,IDB,NVA)
C
C      *** NOW SAVING THE DESCRIPTORS FOR THE DATA BASE FOR USE
C      BY PROGRAM LIKE
C
C      WRITE (NT,201) NDT,NDIM,NDM,NPAR
C      WRITE (NT,201) ATITLE
C      WRITE (NT,201) (SEL(I),I=1,NDIM)
C
C      DO 30 I = 1,NDIM
C      K = SEL(I)
C      WRITE (NT,201) (TITLE(K,J),J=1,20)
C      30 CONTINUE
C
C      WRITE (6,302) NDB(IDB),ATITLE,NDT,NDM,NPAR
C
C      *** INITIALIZING THE COUNTER OF EVENTS. EIGEN VALUE MATRIX
C      AND THE COVARIANCE MATRIX

```

SCO01610
 SCO01620
 SCO01630
 SCO01640
 SCO01650
 SCO01660
 SCO01670
 SCO01680
 SCO01690
 SCO01700
 SCO01710
 SCO01720
 SCO01730
 SCO01740
 SCO01750
 SCO01760
 SCO01770
 SCO01780
 SCO01790
 SCO01800
 SCO01810
 SCO01820
 SCO01830
 SCO01840
 SCO01850
 SCO01860
 SCO01870
 SCO01880
 SCO01890
 SCO01900
 SCO01910
 SCO01920
 SCO01930
 SCO01940
 SCO01950
 SCO01960
 SCO01970
 SCO01980
 SCO01990
 SCO02000
 SCO02010
 SCO02020
 SCO02030
 SCO02040
 SCO02050
 SCO02060
 SCO02070
 SCO02080
 SCO02090
 SCO02100
 SCO02110
 SCO02120
 SCO02130
 SCO02140
 SCO02150
 SCO02160
 SCO02170
 SCO02180
 SCO02190
 SCO02200
 SCO02210
 SCO02220
 SCO02230
 SCO02240
 SCO02250
 SCO02260
 SCO02270
 SCO02280
 SCO02290
 SCO02300
 SCO02310
 SCO02320
 SCO02330
 SCO02340
 SCO02350
 SCO02360
 SCO02370
 SCO02380
 SCO02390
 SCO02400

```

C      NTOT = 0
C      DO 45 I = 1,NDIM
C      DO 40 J = 1,NDIM
C      EIGVAL(I,J) = 0
C      COVM(I,J) = 0.
40    CONTINUE
45    CONTINUE
C
C      *** NOW READING IN THE VALUES FOR THE CURRENT DATA BASE
C
C      50 READ (NY,200,END=70) YY
C
C      *** NOW ONLY USING THE VALUES DETERMINED BY THE SELECTION
C      VECTOR AND THE INDIVIDUAL VALUES BEING ACCEPTABLE
C
C      DO 55 I = 1,NDIM
C      K = SEL(I)
C      VAL(I) = YY(K)
C      IF ( VAL(I).GT.1.E50 ) GOTO 50
C      VAL(I) = VAL(I) - AVG(I)
55    CONTINUE
C
C      *** NOW COMPUTING THE COVARIANCE MATRIX USING ONLY
C      THOSE VALUES WHICH ARE LESS THAN OR EQUAL TO 1.E50
C
C      NTOT = NTOT + 1
C
C      DO 65 I = 1,NDIM
C      DO 60 J = 1,NDIM
C      COVM(I,J) = COVM(I,J) + VAL(I) * VAL(J)
60    CONTINUE
65    CONTINUE
C      GOTO 50
C
C      *** COVARIANCE MATRIX NOW COMPUTED
C
C      70 CONTINUE
C      REWIND NY
C
C      *** NOW NORMALIZING THE COVARIANCE MATRIX
C
C      T = NTOT - 1
C
C      DO 80 I = 1,NDIM
C      DO 75 J = 1,NDIM
C      COVM(I,J) = COVM(I,J)/T
C      COVM(J,I) = COVM(I,J)
75    CONTINUE
80    CONTINUE
C
C      *** NOW COMPUTING THE STANDARD DEVIATIONS FROM THE
C      COVARIANCE MATRIX
C
C      DO 85 I = 1,NDIM
C      85 SD(I) = SQRT(COVM(I,I))
C
C      *** NOW COMPUTING THE CORRELATION MATRIX FROM THE
C      COVARIANCE MATRIX AND THE STANDARD DEVIATIONS
C
C      DO 90 I = 1,NDIM

```

SCO02410
 SCO02420
 SCO02430
 SCO02440
 SCO02450
 SCO02460
 SCO02470
 SCO02480
 SCO02490
 SCO02500
 SCO02510
 SCO02520
 SCO02530
 SCO02540
 SCO02550
 SCO02560
 SCO02570
 SCO02580
 SCO02590
 SCO02600
 SCO02610
 SCO02620
 SCO02630
 SCO02640
 SCO02650
 SCO02660
 SCO02670
 SCO02680
 SCO02690
 SCO02700
 SCO02710
 SCO02720
 SCO02730
 SCO02740
 SCO02750
 SCO02760
 SCO02770
 SCO02780
 SCO02790
 SCO02800
 SCO02810
 SCO02820
 SCO02830
 SCO02840
 SCO02850
 SCO02860
 SCO02870
 SCO02880
 SCO02890
 SCO02900
 SCO02910
 SCO02920
 SCO02930
 SCO02940
 SCO02950
 SCO02960
 SCO02970
 SCO02980
 SCO02990
 SCO03000
 SCO03010
 SCO03020
 SCO03030
 SCO03040
 SCO03050
 SCO03060
 SCO03070
 SCO03080
 SCO03090
 SCO03100
 SCO03110
 SCO03120
 SCO03130
 SCO03140
 SCO03150
 SCO03160
 SCO03170
 SCO03180
 SCO03190
 SCO03200

```

DO 90 J = 1,NDIM
CORM(I,J) = COVM(I,J)/(SD(I)*SD(J))
90 CORM(J,I) = CORM(I,J)

*** PRNTR IS A SUBROUTINE USED TO PRINT OUT MATRICES
    WITH THEIR HEADINGS

    CALL PRNTR (COVM,NDIM,NDIM,'COVARIANCE MATRIX',17)
    CALL PRNTR (AVG,1,NDIM,'AVERAGES',8)
    CALL PRNTR (SD,1,NDIM,'STANDARD DEVIATIONS',19)
    CALL PRNTR (CORM,NDIM,NDIM,'CORRELATION MATRIX',18)

*** NOW SAVING THE AVERAGES AND STANDARD DEVIATIONS
    FOR THE CURRENT DATA BASE

    WRITE (NT,201)  AVG,SD

*** LEIG IS A SUBROUTINE WHICH IS USED TO CALL SVDRS
    AN EIGEN VALUE SUBROUTINE AND TO PRINT
    AND SAVE THE EIGEN VALUES AND EIGEN VECTORS.

    CALL LEIG(COVM,CORM,NT,S,BB,EIGVAL)

    REWIND NT

    IF ( IDB.EQ.1 ) GOTO 10

    RETURN

300 FORMAT (1H1,10X,'COVARIANCE MATRICES COMPUTATIONS'//
A 15X,'DATA SET USED WAS UPDATED ON ',4I5/
B 15X,'DIMENSION OF COVARIANCE MATRIX IS ',I4,' BY ',I4/
C 15X,'DIMENSIONS OF DATA IS ',I4,' BY ',I4,' = ',I8/
D 15X,'NUMBER OF PARAMETERS PRESENT ON DATA BASE = ',I4/
E 15X,'THE TITLES WITH THEIR SELECTION NUMBERS FOLLOW'/
F 15X,'NOTE USE COLUMN NUMBERS FOR LIKE SELECTION MATRIX')
301 FORMAT (1X,I5,1X,A4,I6,1X,20A4)
302 FORMAT (1H1,10X,'COMPUTATION OF COVARIANCE MATRIX ',A4/
A 11X,20A4/11X,20A4/11X,'UPDATE ON ',4I5/
B 11X,'DIMENSIONS OF DATA BASE = ',I5,' BY ',I5,' = ',I8/
C 11X,'PARAMETERS ON DATA BASE = ',I5/)

200 FORMAT (100A4)
201 FORMAT (20A4)

    ERROR STOPS FOLLOW

94 WRITE (6,401)  K,NPAR
    STOP

95 WRITE (6,400)  NDIM,NPAR
    STOP

99 WRITE (6,402)  MY
    STOP

400 FORMAT ('OEXCEEDED DIMENSION OF COVARIANCE MATRIX (NDIM)',
A 16,' EXCEEDS PARAMETERS ON DATA BASE (NPAR = ',I6,' )')
401 FORMAT ('OSELECTION VECTOR HAS VALUE ',I5,' WHICH IS OUTSIDE OF RA
ANGE OF PARAMETERS ( 0 < VALUE <= ',I6,' )')
402 FORMAT ('OUNEXPECTED END OF FILE HIT ON FILE',I3)

END

```

A.3 LEIG

```

C*****LEI00010
C      PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAM      LEI00020
C      ROUTINE NAME - LEIG          TASC PROGRAM NO - 508      LEI00030
C      LEI00040
C      LEI00050
C      LEI00060
C*****LEI00070
C      LEI00080
C      LEI00090
C      .....LEI00100
C      SUBROUTINE LEIG      LEI00110
C      LEI00120
C      PURPOSE      LEI00130
C      LEIG HAS THE FOLLOWING FUNCTIONS:      LEI00140
C      * CALL SVDRS WHICH COMPUTES THE EIGEN VECTORS AND      LEI00150
C      *   EIGEN VALUES      LEI00160
C      * COMPUTES EIGEN VALUE MATRIX      LEI00170
C      * PRINTS EIGEN VALUES AND EIGEN VECTORS      LEI00180
C      * SAVES EIGEN VECTORS AND EIGEN VALUES FOR PROGRAM LIKE      LEI00190
C      LEI00200
C      LEI00210
C      LEI00220
C      LEI00230
C      USAGE      LEI00240
C      CALL LEIG (EIGVEC,CORM,NT,S,BB,EIGVAL)      LEI00250
C      LEI00260
C      LEI00270
C      DESCRIPTION OF PARAMETERS      LEI00280
C      EIGVEC - EIGEN VECTOR MATRIX TO BE COMPUTED      LEI00290
C      CORM   - CORRELATION MATRIX TO BE COMPUTED      LEI00300
C      NT     - UNIT NUMBER OF SAVED OUTPUT      LEI00310
C      S      - MATRIX WHICH WILL CONTAIN EIGEN VALUES      LEI00320
C      BB     - DUMMY MATRIX      LEI00330
C      EIGVAL - EIGEN VALUE MATRIX      LEI00340
C      LEI00350
C      SUBROUTINES AND FUNCTION SUBPROGRAMS REQUIRED      LEI00360
C      PRNTR      LEI00370
C      SVDRS      LEI00380
C      LEI00390
C      LEI00400
C      .....LEI00410
C*****LEI00420
C      LEI00430
C      LEI00440
C      LEI00450
C      SUBROUTINE LEIG(EIGVEC,CORM,NT,S,BB,EIGVAL)      LEI00460
C      LEI00470
C      INTEGER*4 SEL      LEI00480
C      LEI00490
C      COMMON /ADATA/  NDIM,TITLE(100,20),SEL(100)      LEI00500
C      LEI00510
C      DIMENSION EIGVEC(1),EIGVAL(1),S(NDIM,3),CORM(1),BB(1)      LEI00520
C      LEI00530
C      N = NDIM * NDIM      LEI00540
C      LEI00550
C      LEI00560
C      LEI00570
C      ***  INITIALIZING BB MATRIX TO THE IDENTITY MATRIX      LEI00580
C      INITIALIZING EIGVEC MATRIX TO CORRELATION MATRIX      LEI00590
C      LEI00600
C      DO 10 I = 1,N      LEI00610
C      BB(I) = 0.      LEI00620
C      EIGVEC(I) = CORM(I)      LEI00630
C      10 CONTINUE      LEI00640
C      LEI00650
C      INCR = NDIM + 1      LEI00660
C      LEI00670
C      DO 15 I = 1,N,INCR      LEI00680
C      BB(I) = 1.      LEI00690
C      15 CONTINUE      LEI00700
C      LEI00710
C      LEI00720
C      LEI00730
C      ***  SVDRS IS THE SUBROUTINE WHICH CALCULATES THE      LEI00740
C      EIGEN VALUES      LEI00750
C      LEI00760
C      CALL SVDRS(EIGVEC,NDIM,NDIM,NDIM,BB,NDIM,NDIM,S)      LEI00770
C      LEI00780
C      LEI00790
C      LEI00800

```

```

C *** NORMALIZING THE MATRIX OF EIGEN VECTORS
C
C      DO 30 J = 1,N,NDIM
C      K = J + NDIM - 1
C      XS = 0.
C
C      DO 20 L = J,K
C      XS = XS + EIGVEC(L) * EIGVEC(L)
20  CONTINUE
C
C      XS = SQRT(XS)
C
C      DO 25 L = J,K
C      EIGVEC(L) = EIGVEC(L)/XS
25  CONTINUE
30  CONTINUE
C
C *** NOW COMPUTING EIGVAL THE EIGEN VALUE MATRIX
C      BY THE TRANSPOSE(EIGEN VECTOR MATRIX) *
C      CORRELATION MATRIX * EIGEN VECTOR MATRIX
C
C      DO 50 J = 1,N,NDIM
C      JJ = J - 1
C
C      DO 45 I = 1,NDIM
C      X = 0
C      KK = -NDIM
C
C      DO 35 K = 1,NDIM
C      KK = KK + NDIM
C      IK = I + KK
C      KJ = K + JJ
35  X = X + CORM(IK) * EIGVEC(KJ)
C
C      KK = -NDIM
C
C      DO 40 K = 1,NDIM
C      KK = KK + NDIM
C      IK = I + KK
C      KJ = K + JJ
40  EIGVAL(KJ) = EIGVAL(KJ) + EIGVEC(IK) * X
C
C      45 CONTINUE
C      50 CONTINUE
C
C      CALL PRNTR(EIGVEC,NDIM,NDIM,'MATRIX OF EIGEN VECTORS',23)
C      CALL PRNTR(EIGVAL,NDIM,NDIM,'EIGEN VALUE MATRIX',18)
C      CALL PRNTR(S,NDIM,1,'EIGEN VALUES OUTPUT',19)
C
C *** NOW SAVING THE EIGEN VALUES AND THE MATRIX OF EIGEN
C      VECTORS FOR THE PROGRAM LIKE
C
C      WRITE (NT,200) (EIGVAL(I),I=1,N,INCR),(EIGVEC(I),I=1,N)
200  FORMAT (20A4)
C
C      RETURN
C      END

```

LEI00810
 LEI00820
 LEI00830
 LEI00840
 LEI00850
 LEI00860
 LEI00870
 LEI00880
 LEI00890
 LEI00900
 LEI00910
 LEI00920
 LEI00930
 LEI00940
 LEI00950
 LEI00960
 LEI00970
 LEI00980
 LEI00990
 LEI01000
 LEI01010
 LEI01020
 LEI01030
 LEI01040
 LEI01050
 LEI01060
 LEI01070
 LEI01080
 LEI01090
 LEI01100
 LEI01110
 LEI01120
 LEI01130
 LEI01140
 LEI01150
 LEI01160
 LEI01170
 LEI01180
 LEI01190
 LEI01200
 LEI01210
 LEI01220
 LEI01230
 LEI01240
 LEI01250
 LEI01260
 LEI01270
 LEI01280
 LEI01290
 LEI01300
 LEI01310
 LEI01320
 LEI01330
 LEI01340
 LEI01350
 LEI01360
 LEI01370
 LEI01380
 LEI01390
 LEI01400
 LEI01410
 LEI01420
 LEI01430
 LEI01440
 LEI01450
 LEI01460

A.4 PRNTR

```

C*****PRN00010
C      PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAM      PRN00020
C      ROUTINE NAME - PRNTR          TASC PROGRAM NO - 509      PRN00030
C*****PRN00040
C      PRN00050
C      PRN00060
C      PRN00070
C      PRN00080
C      PRN00090
C      PRN00100
C      PRN00110
C      PRN00120
C      PRN00130
C      PRN00140
C      PRN00150
C      PRN00160
C      PRN00170
C      PRN00180
C      PRN00190
C      PRN00200
C      PRN00210
C      PRN00220
C      PRN00230
C      PRN00240
C      PRN00250
C      PRN00260
C      PRN00270
C      PRN00280
C      PRN00290
C      PRN00300
C      PRN00310
C      PRN00320
C      PRN00330
C      PRN00340
C      PRN00350
C      PRN00360
C      PRN00370
C      PRN00380
C      PRN00390
C      PRN00400
C      PRN00410
C      PRN00420
C      PRN00430
C      PRN00440
C      PRN00450
C      PRN00460
C      PRN00470
C      PRN00480
C      PRN00490
C      PRN00500
C      PRN00510
C      PRN00520
C      PRN00530
C      PRN00540
C      PRN00550
C      PRN00560
C      PRN00570
C      PRN00580
C      PRN00590
C      PRN00600
C      PRN00610
C      PRN00620
C      PRN00630
C      PRN00640
C      PRN00650
C      PRN00660
C      PRN00670

      PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAM
      ROUTINE NAME - PRNTR          TASC PROGRAM NO - 509

      PRNTR IS USED TO PRINT A MATRIX WITH ITS
      DIMENSION AND TITLE LISTING

      USAGE
      CALL PRNTR (ARRAY,N,M,LG,NLG)

      DESCRIPTION OF PARAMETERS
      ARRAY - MATRIX TO BE PRINTED
      N     - NUMBER OF ROWS IN MATRIX
      M     - NUMBER OF COLUMNS IN MATRIX
      LG    - TITLE OF ARRAY
      NLG   - NUMBER OF CHARACTERS IN TITLE

      SUBROUTINE PRNTR(ARRAY,N,M,LG,NLG)
      LOGICAL*1 LG(1)

      *** COL(I) HAS COLUMN NUMBERS TO COORDINATE PRINTOUTS

      COMMON /CDATA/ COL(50)
      DIMENSION ARRAY(N,M)

      WRITE (6,300) N,M,(LG(I),I=1,NLG)
      WRITE (6,301) (COL(I),I=1,M)

      *** NOW PRINTING OUT THE ACTUAL MATRIX

      DO 20 I = 1,N
      WRITE (6,302) I,(ARRAY(I,J),J=1,M)
      20 CONTINUE

      300 FORMAT ('DIMENSIONS ',2I5,5X,60A1)
      301 FORMAT ('1H0,2X,10(4X,A3,6X)/
      A 3X,10(4X,A3,6X))
      302 FORMAT ('1X,12,1P10E13.3/(3X,10E13.3))

      RETURN
      END

```


A.5 CHECK

```

C*****CHE00010
C      PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAMCHE00020
C      ROUTINE NAME - CHECKTASC PROGRAM NO - 510CHE00030
C      CHE00040
C      CHE00050
C      CHE00060
C      CHE00070
C      CHE00080
C      CHE00090
C      CHE00100
C      CHE00110
C      CHE00120
C      CHE00130
C      CHE00140
C      CHE00150
C      CHE00160
C      CHE00170
C      CHE00180
C      CHE00190
C      CHE00200
C      CHE00210
C      CHE00220
C      CHE00230
C      CHE00240
C      CHE00250
C      CHE00260
C      CHE00270
C      CHE00280
C      CHE00290
C      CHE00300
C      CHE00310
C      CHE00320
C      CHE00330
C      CHE00340
C      CHE00350
C      CHE00360
C      CHE00370
C      CHE00380
C      CHE00390
C      CHE00400
C      CHE00410
C      CHE00420
C      CHE00430
C      CHE00440
C      CHE00450
C      CHE00460
C      CHE00470
C      CHE00480
C      CHE00490
C      CHE00500
C      CHE00510
C      CHE00520
C      CHE00530
C      CHE00540
C      CHE00550
C      CHE00560
C      CHE00570
C      CHE00580
C      CHE00590
C      CHE00600
C      CHE00610
C      CHE00620
C      CHE00630
C      CHE00640
C      CHE00650
C      CHE00660
C      CHE00670
C      CHE00680
C      CHE00690
C      CHE00700
C      CHE00710
C      CHE00720
C      CHE00730
C      CHE00740
C      CHE00750
C      CHE00760
C      CHE00770
C      CHE00780
C      CHE00790
C      CHE00800

      PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAM
      ROUTINE NAME - CHECKTASC PROGRAM NO - 510

      .....

      SUBROUTINE CHECK

      PURPOSE
      CHECK IS USED TO COMPARE FILE DESCRIPTORS TO
      ENSURE THAT THE PROPER FILE IS BEING READ

      USAGE
      CALL CHECK (INUNIT,IDB,NVA)

      DESCRIPTION OF PARAMETERS
      INUNIT - UNIT NUMBER OF FILE BEING READ
      IDB - NUMBER OF DATA BASE BEING READ
      NVA - INDICATOR TO SHOW WHETHER VALUE FILE
      OR AVERAGE FILE IS BEING READ

      REMARKS
      IF FILE DESCRIPTORS ARE NOT CORRECT PROGRAM ABENDS

      .....

      SUBROUTINE CHECK(INUNIT,IDB,NVA)

      *** DBT IS AN ARRAY OF ALPHANUMERIC CHARACTERS USED
      TO ENSURE THAT FILES ARE READ IN PROPER ORDER

      INTEGER*4 SEL, DBT
      COMMON /ADATA/ NDM,SEL(100)
      COMMON /BDATA/ NDT(4),NDM(3),NPAR,NCB(2),DTITLE(90),
      A TITLE(100,20),YY(100)
      DIMENSION DBT(2,2), NDA(4), NDM(3)
      DATA DBT/4HDB 1,4HDB 2,4H PTS,4H AVG/
      READ (INUNIT,200,END=99) NDA,NDM,NPAR,NDB,DTITLE

      *** CHECKING THE DATES READ FROM THIS INPUT FILE WITH
      THE TEST DESCRIPTOR DATES

      DO 10 I = 1,4
      IF ( NDA(I).NE.NDT(I) ) GOTO 96
      10 CONTINUE

      *** CHECKING THAT THE DATA BASE IS THE CORRECT ONE
      THAT IT IS THE AVERAGES BEING READ

      IF ( NDB(1).NE.DB(1) ) GOTO 95
      IF ( NDB(2).NE.DB(NVA,2) ) GOTO 96

      *** ENSURING THAT THE NUMBER OF PARAMETERS IS CONSISTENT

```

```
C      IF ( NPAR.NE.MPAR ) GOTO 96
C
C      *** THE TITLES OF EACH INPUT FILE ARE NOW CHECKED TO SEE
C      THAT THEY ARE IDENTICAL
C
C      *** YY ARE THE VARIABLES
C
C      THE OUTER DO LOOP IS DONE 20 TIMES BECAUSE EACH TITLE
C      OF A PARAMETER CONSISTS OF 20 A4 WORDS
C
C      *** TITLE(I,J) ARE THE SET OF TITLES READ IN ORIGINALLY
C      FROM FILE 32 TO ENSURE CONSISTENCY
C
C      DO 30 J = 1,20
C
C      *** NOW READING A RECORD OF TITLES
C
C      READ (INUNIT,200.END=99) YY
C
C      *** NOW COMPARING THE INPUT TITLES WITH THE ORIGINAL SET
C
C      DO 20 I = 1,100
C      IF ( YY(I).NE.TITLE(I,J) ) GOTO 98
C      20 CONTINUE
C      30 CONTINUE
C
C      *** IF VALUES FILE IS BEING READ THEN CHECK DIMENSIONS
C      OF THIS DATA BASE WITH DIMENSIONS OF THE AVERAGE
C      FILE FOR THIS DATA BASE
C
C      IF ( NVA.EQ.1 ) GOTO 50
C
C      *** IF AVERAGES FILE IS BEING READ THEN SAVE DIMENSIONS
C      OF THIS DATA BASE FOR COMPARISON WITH THE VALUES
C      FILE FOR THIS DATA BASE
C
C      DO 40 I = 1,3
C      40 MDM(I) = NDM(I)
C
C      RETURN
C
C      50 CONTINUE
C
C      *** CHECKING THAT THE VARIOUS DIMENSIONS FOR THIS
C      PARTICULAR DATA BASE ARE THE SAME FOR BOTH
C      ITS VALUES AND ITS AVERAGES FILES
C
C      IF ( NDM(1).NE.MDM(1) ) GOTO 97
C      IF ( NDM(2).NE.MDM(2) ) GOTO 97
C      IF ( NDM(3).NE.MDM(3) ) GOTO 97
C
C      RETURN
C
C      *** ERROR STOPS FOLLOW
C
C      95 WRITE (6,400) DBT(IDB,1),DBT(NVA,2),NDB
C      STOP
C
C      96 WRITE (6,401) INUNIT,NDT,NPAR,NDA,MPAR
C      STOP
```

CHE00810
CHE00820
CHE00830
CHE00840
CHE00850
CHE00860
CHE00870
CHE00880
CHE00890
CHE00900
CHE00910
CHE00920
CHE00930
CHE00940
CHE00950
CHE00960
CHE00970
CHE00980
CHE00990
CHE01000
CHE01010
CHE01020
CHE01030
CHE01040
CHE01050
CHE01060
CHE01070
CHE01080
CHE01090
CHE01100
CHE01110
CHE01120
CHE01130
CHE01140
CHE01150
CHE01160
CHE01170
CHE01180
CHE01190
CHE01200
CHE01210
CHE01220
CHE01230
CHE01240
CHE01250
CHE01260
CHE01270
CHE01280
CHE01290
CHE01300
CHE01310
CHE01320
CHE01330
CHE01340
CHE01350
CHE01360
CHE01370
CHE01380
CHE01390
CHE01400
CHE01410
CHE01420
CHE01430
CHE01440
CHE01450
CHE01460
CHE01470
CHE01480
CHE01490
CHE01500
CHE01510
CHE01520
CHE01530
CHE01540
CHE01550
CHE01560
CHE01570
CHE01580
CHE01590
CHE01600

C	97 WRITE (6.404) IDB.(I,NDM(I),MDM(I),I=1,3)	CHE01610
	STOP	CHE01620
C	98 WRITE (6.403) I,INUNIT	CHE01630
	STOP	CHE01640
C	99 WRITE (6.402) INUNIT	CHE01650
	STOP	CHE01660
		CHE01670
		CHE01680
C	200 FORMAT (100A4)	CHE01690
		CHE01700
C	400 FORMAT ('0FILE',I3,' IS THE WRONG FILE'/	CHE01710
	A ' IT SHOULD BE ',A4,1X,A4,' BUT IS ',A4,1X,A4)	CHE01720
	401 FORMAT ('0ON FILE ',I2,' EITHER THE DATES OR THE NUMBER OF PARAMET	CHE01730
	AERS DO NOT MATCH THOSE OF STANDARDS (FILE 32)'/	CHE01740
	B12X,' DATES',25X,'NUMBER OF PARAMETERS'/	CHE01750
	C4X,'FILE 32',3I3,15,20X,I3/' INPUT FILE',3I3,15,20X,I3)	CHE01760
	402 FORMAT ('0UNEXPECTED END OF FILE HIT ON FILE',I3)	CHE01770
	403 FORMAT ('0PARAMETER',I4,' DOES NOT HAVE THE SAME TITLE ON FILE',	CHE01780
	A I3,' AND THE STANDARDS FILE 32')	CHE01790
	404 FORMAT ('0DIMENSIONS FOR VALUES AND AVERAGES FILES ON'	CHE01800
	A,' DATA BASE',I2,' DO NOT MATCH'/	CHE01810
	B ('0DIMENSION(',I1,') =',2I8))	CHE01820
C	END	CHE01830
		CHE01840
		CHE01850
		CHE01860

A.6 SVDRS

```

C*****SVD00010
C      PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAMSVD00020
C      ROUTINE NAME - SVDRS          TASC PROGRAM NO - 511SVD00030
C      SVD00040
C      SVD00050
C      SVD00060
C      SVD00070
C      SVD00080
C      SVD00090
C      SVD00100
C      SVD00110
C      SVD00120
C      SVD00130
C      SVD00140
C      SVD00150
C      SVD00160
C      SVD00170
C      SVD00180
C      SVD00190
C      SVD00200
C      SVD00210
C      SVD00220
C      SVD00230
C      SVD00240
C      SVD00250
C      SVD00260
C      SVD00270
C      SVD00280
C      SVD00290
C      SVD00300
C      SVD00310
C      SVD00320
C      SVD00330
C      SVD00340
C      SVD00350
C      SVD00360
C      SVD00370
C      SVD00380
C      SVD00390
C      SVD00400
C      SVD00410
C      SVD00420
C      SVD00430
C      SVD00440
C      SVD00450
C      SVD00460
C      SVD00470
C      SVD00480
C      SVD00490
C      SVD00500
C      SVD00510
C      SVD00520
C      SVD00530
C      SVD00540
C      SVD00550
C      SVD00560
C      SVD00570
C      SVD00580
C      SVD00590
C      SVD00600
C      SVD00610
C      SVD00620
C      SVD00630
C      SVD00640
C      SVD00650
C      SVD00660
C      SVD00670
C      SVD00680
C      SVD00690
C      SVD00700
C      SVD00710
C      SVD00720
C      SVD00730
C      SVD00740
C      SVD00750
C      SVD00760
C      SVD00770
C      SVD00780
C      SVD00790
C      SVD00800

PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAM
ROUTINE NAME - SVDRS          TASC PROGRAM NO - 511

*****
.....
SUBROUTINE SVDRS
PURPOSE
  SVDRS IS USED TO COMPUTE EIGEN VALUES AND
  EIGEN VECTORS

USAGE
CALL SVDRS(A,MDA,MM,NN,B,MDB,NB,S)

DESCRIPTION OF PARAMETERS
  A      - ORIGINAL MATRIX DESTROYED TO GIVE SOLUTION
  MDA    - ACTUAL ROW DIMENSION OF A
  MM     - ROW DIMENSION OF A TO BE USED
  NN     - COLUMN DIMENSION OF A TO BE USED
  B      - MATRIX IN OUR CASE ORIGINALLY THE IDENTITY
          MATRIX
  MDB    - ACTUAL ROW DIMENSION OF B
  NB     - NUMBER OF COLUMN VECTORS IN B
  S      - TEMPORARY WORKING SPACE
          ON CONCLUSION THE FIRST NN LOCATIONS
          CONTAIN THE ORDERED SINGULAR VALUES OF A

REMARKS
  THE DIMENSIONING PARAMETERS MUST SATISFY MDA >= MAX(MM,NN).
  NN <= ACTUAL NUMBER OF COLUMNS OF A
  MDB >= MM
  NB <= ACTUAL NUMBER OF COLUMNS OF B
  THE ACTUAL DIMENSION OF S >= 3*NN

  IF CONVERGENCE DOES NOT OCCUR IN SUBROUTINE QRBD THEN
  ERROR MESSAGE IS PRINTED AND PROGRAM ABENDS

SUBROUTINES AND FUNCTION SUBPROGRAMS CALLED
  H12
  QRBD
.....
SUBROUTINE SVDRS (A,MDA,MM,NN,B,MDB,NB,S)
THE ARRAY S OCCUPIES 3*NN CELLS.
A OCCUPIES M*NN CELLS.
B OCCUPIES M*NB CELLS.

SPECIAL SINGULAR VALUE DECOMPOSITION SUBROUTINE.
WE HAVE THE M X N MATRIX A AND THE SYSTEM A*X=B TO SOLVE.
EITHER M .GE. N OR M .LT. N IS PERMITTED.
THE SINGULAR VALUE DECOMPOSITION
A = U*S*V*(T) IS MADE IN SUCH A WAY THAT ONE GETS
(1) THE MATRIX V IN THE FIRST N ROWS AND COLUMNS OF A.
(2) THE DIAGONAL MATRIX OF ORDERED SINGULAR VALUES IN
THE FIRST N CELLS OF THE ARRAY S(IP), IP .GE. 3*NN
(3) THE MATRIX PRODUCT U*(T)*B-G GETS PLACED BACK IN B.
(4) THE USER MUST COMPLETE THE SOLUTION AND DO HIS OWN
SINGULAR VALUE ANALYSIS.

*****
GIVE SPECIAL
TREATMENT TO ROWS AND COLUMNS WHICH ARE ENTIRELY ZERO. THIS
CAUSES CERTAIN ZERO SING. VALS. TO APPEAR AS EXACT ZEROS RATHER
THAN AS ABOUT ETA TIMES THE LARGEST SING. VAL. IT SIMILARLY

```

```

C      CLEANS UP THE ASSOCIATED COLUMNS OF U AND V.                                SVD00810
C      METHOD..                                                                    SVD00820
C      1. EXCHANGE COLS OF A TO PACK NONZERO COLS TO THE LEFT.                   SVD00830
C          SET N = NO. OF NONZERO COLS.                                          SVD00840
C          USE LOCATIONS A(1,NN),A(1,NN-1).....A(1,N+1) TO RECORD THE          SVD00850
C          COL PERMUTATIONS.                                                      SVD00860
C      2. EXCHANGE ROWS OF A TO PACK NONZERO ROWS TO THE TOP.                   SVD00870
C          QUIT PACKING IF FIND N NONZERO ROWS. MAKE SAME ROW EXCHANGES          SVD00880
C          IN B. SET M SO THAT ALL NONZERO ROWS OF THE PERMUTED A                SVD00890
C          ARE IN FIRST M ROWS. IF M .LE. N THEN ALL M ROWS ARE                   SVD00900
C          NONZERO. IF M .GT. N THEN THE FIRST N ROWS ARE KNOWN                   SVD00910
C          TO BE NONZERO, AND ROWS N+1 THRU M MAY BE ZERO OR NONZERO.              SVD00920
C      3. APPLY ORIGINAL ALGORITHM TO THE M BY N PROBLEM.                        SVD00930
C      4. MOVE PERMUTATION RECORD FROM A(.) TO S(I), I=N+1.....NN.               SVD00940
C      5. BUILD V UP FROM N BY N TO NN BY NN BY PLACING ONES ON                 SVD00950
C          THE DIAGONAL AND ZEROS ELSEWHERE. THIS IS ONLY PARTLY DONE             SVD00960
C          EXPLICITLY. IT IS COMPLETED DURING STEP 6.                           SVD00970
C      6. EXCHANGE ROWS OF V TO COMPENSATE FOR COL EXCHANGES OF STEP 2.          SVD00980
C      7. PLACE ZEROS IN S(I), I=N+1,NN TO REPRESENT ZERO SING VALS.             SVD00990
C
C      SUBROUTINE SVDRS (A,MDA,MM,NN,B,MDB,NB,S)                                SVD01000
C      DIMENSION A(MDA,NN),B(MDB,NB),S(NN,3)                                    SVD01010
C      ZERO=0.                                                                    SVD01020
C      CNE=1.                                                                      SVD01030
C
C      BEGIN.. SPECIAL FOR ZERO ROWS AND COLS                                   SVD01040
C      PACK THE NONZERO COLS TO THE LEFT                                         SVD01050
C
C      N=NN                                                                        SVD01060
C      IF (N.LE.0.OR.MM.LE.0) RETURN                                              SVD01070
C      J=N                                                                          SVD01080
C      10 CONTINUE                                                                  SVD01090
C          DO 20 I=1,MM                                                            SVD01100
C          IF (A(I,J)) 50,20,50                                                    SVD01110
C      20 CONTINUE                                                                  SVD01120
C
C          COL J IS ZERO. EXCHANGE IT WITH COL N.                                SVD01130
C
C      IF (J.EQ.N) GO TO 40                                                         SVD01140
C          DO 30 I=1,MM                                                            SVD01150
C          A(I,J)=A(I,N)                                                           SVD01160
C      30 CONTINUE                                                                  SVD01170
C          A(1,N)=J                                                                SVD01180
C          N=N-1                                                                    SVD01190
C      50 CONTINUE                                                                  SVD01200
C          J=J-1                                                                    SVD01210
C          IF (J.GE.1) GO TO 10                                                     SVD01220
C
C      IF N=0 THEN A IS ENTIRELY ZERO AND SVD                                     SVD01230
C      COMPUTATION CAN BE SKIPPED                                                  SVD01240
C
C      NS=0                                                                        SVD01250
C      IF (N.EQ.0) GO TO 240                                                       SVD01260
C
C      PACK NONZERO ROWS TO THE TOP                                               SVD01270
C      QUIT PACKING IF FIND N NONZERO ROWS                                       SVD01280
C
C      I=1                                                                          SVD01290
C      M=MM                                                                        SVD01300
C      60 IF (I.GT.N.OR.I.GE.M) GO TO 150                                         SVD01310
C      IF (A(I,1)) 90,70,90                                                       SVD01320
C          DO 80 J=1,N                                                            SVD01330
C          IF (A(I,J)) 90,80,90                                                    SVD01340
C      80 CONTINUE                                                                  SVD01350
C          GO TO 100                                                              SVD01360
C          I=I+1                                                                    SVD01370
C          GO TO 60                                                                SVD01380
C
C      ROW I IS ZERO                                                                SVD01390
C      EXCHANGE ROWS I AND M                                                       SVD01400
C
C      100 IF (NB.LE.0) GO TO 115                                                  SVD01410
C          DO 110 J=1,NB                                                           SVD01420
C          T=B(I,J)                                                                SVD01430
C          B(I,J)=B(M,J)                                                           SVD01440
C          B(M,J)=T                                                                SVD01450
C      110 B(I,J)=T                                                                SVD01460
C          DO 120 J=1,N                                                            SVD01470
C          A(I,J)=A(M,J)                                                           SVD01480
C      120 IF (M.GT.N) GO TO 140                                                    SVD01490
C          DO 130 J=1,N                                                            SVD01500
C          A(M,J)=ZERO                                                            SVD01510
C      130 CONTINUE                                                                SVD01520
C
C      EXCHANGE IS FINISHED                                                       SVD01530
C
C      M=M-1                                                                        SVD01540
C      GO TO 60                                                                    SVD01550
C
C      SVD01560
C      SVD01570
C      SVD01580
C      SVD01590
C      SVD01600

```

```

C 150 CONTINUE
C                                     END.. SPECIAL FOR ZERO ROWS AND COLUMNS
C                                     BEGIN.. SVD ALGORITHM
C METHOD..
C (1) REDUCE THE MATRIX TO UPPER BIDIAGONAL FORM WITH
C HOUSEHOLDER TRANSFORMATIONS.
C       H(N)....H(1)AQ(1)....Q(N-2) = (D**T,0)**T
C WHERE D IS UPPER BIDIAGONAL.
C (2) APPLY H(N)....H(1) TO B. HERE H(N)....H(1)*B REPLACES B
C IN STORAGE.
C (3) THE MATRIX PRODUCT W= Q(1)....Q(N-2) OVERWRITES THE FIRST
C N ROWS OF A IN STORAGE.
C (4) AN SVD FOR D IS COMPUTED. HERE K ROTATIONS RI AND PI ARE
C COMPUTED SO THAT
C       RK...R1*D*P1**T)...PK**T) = DIAG(S1.....SM)
C TO WORKING ACCURACY. THE SI ARE NONNEGATIVE AND NONINCREASING.
C HERE RK...R1*B OVERWRITES B IN STORAGE WHILE
C A*P1**T)...PK**T) OVERWRITES A IN STORAGE.
C (5) IT FOLLOWS THAT, WITH THE PROPER DEFINITIONS.
C U**T)*B OVERWRITES B. WHILE V OVERWRITES THE FIRST N-ROW AND
C COLUMNS OF A.
C L = MINO(M,N)
C THE FOLLOWING LOOP REDUCES A TO UPPER BIDIAGONAL AND
C ALSO APPLIES THE PREMULTIPLYING TRANSFORMATIONS TO B.
C
C DO 170 J=1,L
C IF (J.GE.M) GO TO 160
151 CALL H12 (1,J,J+1,M,A(1,J),1,T,A(1,J+1),1,MDA,N-J)
152 CALL H12 (2,J,J+1,M,A(1,J),1,T,B,1,MDB,NB)
160 IF (J.GE.N-1) GO TO 170
CALL H12 (1,J+1,J+2,N,A(J,1),MDA,S(J,3),A(J+1,1),MDA,1,M-J)
170 CONTINUE
C COPY THE BIDIAGONAL MATRIX INTO THE ARRAY S() FOR QRED.
C
C IF (N.EQ.1) GO TO 190
C DO 180 J=2,N
C S(J,1)=A(J,J)
180 S(J,2)=A(J-1,J)
190 S(1,1)=A(1,1)
C
C NS=N
C IF (M.GE.N) GO TO 200
C NS=M+1
C S(NS,1)=ZERO
C S(NS,2)=A(M,M+1)
200 CONTINUE
C CONSTRUCT THE EXPLICIT N BY N PRODUCT MATRIX. W=Q1*Q2*...*QL*I
C IN THE ARRAY A().
C
C DO 230 K=1,N
C I=N+1-K
C IF (I.GE.N-1) GO TO 210
CALL H12 (2,I+1,I+2,N,A(I,1),MDA,S(I,3),A(1,I+1),1,MDA,N-I)
210 DO 220 J=1,N
220 A(I,J)=ZERO
230 A(I,I)=ONE
C
C COMPUTE THE SVD OF THE BIDIAGONAL MATRIX
C CALL QRBD (IPASS,S(1,1),S(1,2),NS,A,MDA,N,B,MDB,NB)
C
C GO TO (240,310), IPASS
240 CONTINUE
C IF (NS.GE.N) GO TO 260
C NSP1=NS+1
C DO 250 J=NSP1,N
250 S(J,1)=ZERO
260 CONTINUE
C IF (N.EQ.NN) RETURN
C NP1=N+1
C
C MOVE RECORD OF PERMUTATIONS
C AND STORE ZEFOS

```

SVD01610
 SVD01620
 SVD01630
 SVD01640
 SVD01650
 SVD01660
 SVD01670
 SVD01680
 SVD01690
 SVD01700
 SVD01710
 SVD01720
 SVD01730
 SVD01740
 SVD01750
 SVD01760
 SVD01770
 SVD01780
 SVD01790
 SVD01800
 SVD01810
 SVD01820
 SVD01830
 SVD01840
 SVD01850
 SVD01860
 SVD01870
 SVD01880
 SVD01890
 SVD01900
 SVD01910
 SVD01920
 SVD01930
 SVD01940
 SVD01950
 SVD01960
 SVD01970
 SVD01980
 SVD01990
 SVD02000
 SVD02010
 SVD02020
 SVD02030
 SVD02040
 SVD02050
 SVD02060
 SVD02070
 SVD02080
 SVD02090
 SVD02100
 SVD02110
 SVD02120
 SVD02130
 SVD02140
 SVD02150
 SVD02160
 SVD02170
 SVD02180
 SVD02190
 SVD02200
 SVD02210
 SVD02220
 SVD02230
 SVD02240
 SVD02250
 SVD02260
 SVD02270
 SVD02280
 SVD02290
 SVD02300
 SVD02310
 SVD02320
 SVD02330
 SVD02340
 SVD02350
 SVD02360
 SVD02370
 SVD02380
 SVD02390
 SVD02400

	DO 280 J=NP1,NN	SVD02410
	S(J,1)=A(1,J)	SVD02420
	DO 270 I=1,N	SVD02430
270	A(I,J)=ZERO	SVD02440
280	CONTINUE	SVD02450
C	PERMUTE ROWS AND SET ZERO SINGULAR VALUES.	SVD02460
	DO 300 K=NP1,NN	SVD02470
	I=S(K,1)	SVD02480
	S(K,1)=ZERO	SVD02490
	DO 290 J=1,NN	SVD02500
	A(K,J)=A(I,J)	SVD02510
290	A(I,J)=ZERO	SVD02520
	A(I,K)=ONE	SVD02530
300	CONTINUE	SVD02540
C	END..SPECIAL FOR ZERO ROWS AND COLUMNS	SVD02550
	RETURN	SVD02560
310	WRITE (6,320)	SVD02570
	STOP	SVD02580
320	FORMAT (49H CONVERGENCE FAILURE IN QR BIDIAGONAL SVD ROUTINE)	SVD02590
	END	SVD02600

A.7 QRBD

```

C*****
C      PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAM
C      ROUTINE NAME - QRBD                      TASC PROGRAM NO - 512
C*****
C      .....
C      SUBROUTINE QRBD
C      PURPOSE
C      QRBD IS USED TO COMPUTE THE SINGULAR VALUE DECOMPOSITION
C      OF AN N * N BIDIAGONAL MATRIX
C
C      USAGE
C      CALL QRBD (IPASS,Q,E,NN,V,MDV,NRV,C,MDC,NCC)
C
C      DESCRIPTION OF PARAMETERS
C      IPASS - INTEGER FLAG RETURNED WITH EITHER OF THE
C              VALUES 1 OR 2
C              IPASS = 1 MEANS CONVERGENCE OCCURRED
C              IPASS = 2 MEANS CONVERGENCE FAILED
C      Q - ARRAY WHICH ORIGINALLY CONTAINS THE DIAGONAL
C           ELEMENTS OF THE MATRIX E
C           ON RETURN CONTAINS THE NN (NONEGATIVE) SINGULAR
C           VALUES OF B
C      E - INITIALLY CONTAINS THE SUPERDIAGONAL ELEMENTS
C           OF B. CONTENTS ARE MODIFIED BY THE ROUTINE
C      NN - ORDER OF THE MATRIX B
C      V - V INITIALLY CONTAINS AN NRV * N MATRIX
C      MDV - ROW DIMENSION OF MATRIX V
C      NRV - IF NRV <= 0 THEN V AND MDV ARE NOT USED
C            IF NRV >= 1 THEN MDV >= NRV
C      C - C ORIGINALLY CONTAINS AN NN BY NCC MATRIX
C           ON OUTPUT WILL BE REPLACED BY PRODUCT MATRIX
C      MDC - ROW DIMENSION OF C
C      NCC - IF NCC >= 2 THEN MDC >= NN
C            IF NCC <= 0 THEN C AND MDC ARE NOT USED
C            IF NCC = 1 THEN MDC CAN BE ANY VALUE > 0
C
C      SUBROUTINES AND FUNCTION SUBPROGRAMS CALLED
C      G1
C      G2
C      DIFF
C      .....
C*****
C      SUBROUTINE QRBD (IPASS,Q,E,NN,V,MDV,NRV,C,MDC,NCC)
C      THE BIDIAGONAL MATRIX
C
C              (Q1,E2,0... )
C              (  Q2,E3,0... )
C      D=      (      .  0 )
C              (      .  EN )
C              (      0,CN )
C
C      IS PRE AND POST MULTIPLIED BY
C      ELEMENTARY ROTATION MATRICES
C      RI AND PI SO THAT
C
C      RK...R1*D*P1**(T)...PK**(T) = DIAG(S1.....SN)
C
C      TO WITHIN WORKING ACCURACY.
C
C      1. EI AND QI OCCUPY E(I) AND Q(I) AS INPUT.
C      2. RM...R1*C REPLACES 'C' IN STORAGE AS OUTPUT.

```



```

C
C 3. V*P1**(T)...PM**(T) REPLACES 'V' IN STORAGE AS OUTPUT.
C
C 4. SI OCCUPIES Q(I) AS OUTPUT.
C
C 5. THE SI'S ARE NONINCREASING AND NONNEGATIVE.
C
SUBROUTINE QRB0 (IPASS,Q,E,NN,V,MDV,NRV,C,MDC,NCC)
LOGICAL WNTV,HAVERS,FAIL
DIMENSION Q(NN),E(NN),V(MDV,NN),C(MDC,NCC)
ZERO=0.
ONE=1.
TWO=2.
C
N=NN
IPASS=1
IF (N.LE.0) RETURN
N10=10*N
WNTV=NRV.GT.0
HAVERS=NCC.GT.0
FAIL=.FALSE.
NORS=0
E(1)=ZERO
DNORM=ZERO
10 DO 10 J=1,N
DNORM=AMAX1 (ABS(Q(J))+ABS(E(J)),DNORM)
DO 200 KK=1,N
K=N+1-KK
C
TEST FOR SPLITTING OR RANK DEFICIENCIES..
FIRST MAKE TEST FOR LAST DIAGONAL TERM. Q(K), BEING SMALL.
20 IF(K.EQ.1) GO TO 50
IF(DIFF(DNORM+Q(K),DNORM)) 50,25,50
C
SINCE Q(K) IS SMALL WE WILL MAKE A SPECIAL PASS TO
TRANSFORM E(K) TO ZERO.
C
25 CS=ZERO
SN=-ONE
DO 40 II=2,K
I=K+1-II
F=-SN*E(I+1)
E(I+1)=CS*E(I+1)
CALL G1 (Q(I),F,CS,SN,Q(I))
TRANSFORMATION CONSTRUCTED TO ZERO POSITION (I,K).
C
IF (.NOT.WNTV) GO TO 40
DO 30 J=1,NRV
CALL G2 (CS,SN,V(J,I),V(J,K))
ACCUMULATE RT. TRANSFORMATIONS IN V.
C
30
C
40 CONTINUE
C
THE MATRIX IS NOW BIDIAGONAL. AND CF LOWER ORDER
SINCE E(K) .EQ. ZERO..
C
50 DO 60 LL=1,K
L=K+1-LL
IF(DIFF(DNORM+E(L),DNORM)) 55,100,55
IF(DIFF(DNORM+Q(L-1),DNORM)) 60,70,60
55
60 CONTINUE
C
THIS LOOP CAN'T COMPLETE SINCE E(1) = ZERO.
C
GO TO 100
C
CANCELLATION OF E(L). L.GT.1.
70 CS=ZERO
SN=-ONE
DO 90 I=L,K
F=-SN*E(I)
E(I)=CS*E(I)
IF(DIFF(DNORM+F,DNORM)) 75,100,75
CALL G1 (Q(I),F,CS,SN,Q(I))
IF (.NOT.HAVERS) GO TO 90
DO 80 J=1,NCC
CALL G2 (CS,SN,C(I,J),C(L-1,J))
80
90 CONTINUE
C
TEST FOR CONVERGENCE..
100 Z=Q(K)

```

QRB00810
 QRB00820
 QRB00830
 QRB00840
 QRB00850
 QRB00860
 QRB00870
 QRB00880
 QRB00890
 QRB00900
 QRB00910
 QRB00920
 QRB00930
 QRB00940
 QRB00950
 QRB00960
 QRB00970
 QRB00980
 QRB00990
 QRB01000
 QRB01010
 QRB01020
 QRB01030
 QRB01040
 QRB01050
 QRB01060
 QRB01070
 QRB01080
 QRB01090
 QRB01100
 QRB01110
 QRB01120
 QRB01130
 QRB01140
 QRB01150
 QRB01160
 QRB01170
 QRB01180
 QRB01190
 QRB01200
 QRB01210
 QRB01220
 QRB01230
 QRB01240
 QRB01250
 QRB01260
 QRB01270
 QRB01280
 QRB01290
 QRB01300
 QRB01310
 QRB01320
 QRB01330
 QRB01340
 QRB01350
 QRB01360
 QRB01370
 QRB01380
 QRB01390
 QRB01400
 QRB01410
 QRB01420
 QRB01430
 QRB01440
 QRB01450
 QRB01460
 QRB01470
 QRB01480
 QRB01490
 QRB01500
 QRB01510
 QRB01520
 QRB01530
 QRB01540
 QRB01550
 QRB01560
 QRB01570
 QRB01580
 QRB01590
 QRB01600

```

C      IF (L.EQ.K) GO TO 170
C      SHIFT FROM BOTTOM 2 BY 2 MINOR OF 8*(T)*8.
      X=Q(L)
      Y=Q(K-1)
      G=E(K-1)
      H=E(K)
      F=((Y-Z)*(Y+Z)+(G-H)*(G+H))/(TWO*H*Y)
      G=SQRT(ONE+F**2)
      IF (F.LT.ZERO) GO TO 110
      T=F+G
      GO TO 120
110    T=F-G
120    F=((X-Z)*(X+Z)+H*(Y/T-H))/X
C      NEXT OR SWEEP..
      CS=ONE
      SN=ONE
      LP1=L+1
      DO 160 I=LP1,K
        G=E(I)
        Y=Q(I)
        H=SN*G
        G=CS*G
        CALL G1 (F,H,CS,SN,E(I-1))
        F=X*CS+G*SN
        G=-X*SN+G*CS
        H=Y*SN
        Y=Y*CS
        IF (.NOT.WNTV) GO TO 140
C      ACCUMULATE ROTATIONS (FROM THE RIGHT) IN 'V'
      DO 130 J=1,NRV
130      CALL G2 (CS,SN,V(J,I-1),V(J,I))
140      CALL G1 (F,H,CS,SN,Q(I-1))
        F=CS*G+SN*Y
        X=-SN*G+CS*Y
        IF (.NOT.HAVERS) GO TO 160
        DO 150 J=1,NCC
150      CALL G2 (CS,SN,C(I-1,J),C(I,J))
C      APPLY ROTATIONS FROM THE LEFT TO
C      RIGHT HAND SIDES IN 'C'..
160      CONTINUE
        E(L)=ZERO
        E(K)=F
        Q(K)=X
        NQRS=NQRS+1
        IF (NQRS.LE.N10) GO TO 20
        RETURN TO 'TEST FOR SPLITTING'
C      FAIL=.TRUE.
C      **CUTOFF FOR CONVERGENCE FAILURE. 'NQRS' WILL BE 2*N USUALLY.
C      170 IF (Z.GE.ZERO) GO TO 190
        Q(K)=-Z
        IF (.NOT.WNTV) GO TO 190
        DO 180 J=1,NRV
180      V(J,K)=-V(J,K)
190      CONTINUE
C      CONVERGENCE. Q(K) IS MADE NONNEGATIVE..
200      CONTINUE
      IF (N.EQ.1) RETURN
      DO 210 I=2,N
        IF (Q(I).GT.Q(I-1)) GO TO 220
210      CONTINUE
      IF (FAIL) IPASS=2
      RETURN
C      **EVERY SINGULAR VALUE IS IN ORDER..
C      220 DO 270 I=2,N
        T=Q(I-1)
        K=I-1
        DO 230 J=I,N
          IF (T.GE.Q(J)) GO TO 230
          T=Q(J)
          K=J
230      CONTINUE
        IF (K.EQ.I-1) GO TO 270

```

QRB01610
 QRB01620
 QRB01630
 QRB01640
 QRB01650
 QRB01660
 QRB01670
 QRB01680
 QRB01690
 QRB01700
 QRB01710
 QRB01720
 QRB01730
 QRB01740
 QRB01750
 QRB01760
 QRB01770
 QRB01780
 QRB01790
 QRB01800
 QRB01810
 QRB01820
 QRB01830
 QRB01840
 QRB01850
 QRB01860
 QRB01870
 QRB01880
 QRB01890
 QRB01900
 QRB01910
 QRB01920
 QRB01930
 QRB01940
 QRB01950
 QRB01960
 QRB01970
 QRB01980
 QRB01990
 QRB02000
 QRB02010
 QRB02020
 QRB02030
 QRB02040
 QRB02050
 QRB02060
 QRB02070
 QRB02080
 QRB02090
 QRB02100
 QRB02110
 QRB02120
 QRB02130
 QRB02140
 QRB02150
 QRB02160
 QRB02170
 QRB02180
 QRB02190
 QRB02200
 QRB02210
 QRB02220
 QRB02230
 QRB02240
 QRB02250
 QRB02260
 QRB02270
 QRB02280
 QRB02290
 QRB02300
 QRB02310
 QRB02320
 QRB02330
 QRB02340
 QRB02350
 QRB02360
 QRB02370
 QRB02380
 QRB02390
 QRB02400

	Q(K)=Q(I-1)	QRB02410
	Q(I-1)=T	QRB02420
	IF (.NOT.HAVERS) GO TO 250	QRB02430
	DO 240 J=1,NCC	QRB02440
	T=C(I-1,J)	QRB02450
	C(I-1,J)=C(K,J)	QRB02460
240	C(K,J)=T	QRB02470
250	IF (.NOT.WNTV) GO TO 270	QRB02480
	DO 260 J=1,NRV	QRB02490
	T=V(J,I-1)	QRB02500
	V(J,I-1)=V(J,K)	QRB02510
260	V(J,K)=T	QRB02520
270	CONTINUE	QRB02530
C	END OF ORDERING ALGORITHM.	QRB02540
C		QRB02550
	IF (FAIL) IPASS=2	QRB02560
	RETURN	QRB02570
	END	QRB02580

A.8 H12

```

*****H1200010
PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAMH1200020
ROUTINE NAME - H12TASC PROGRAM NO - 513H1200030
*****H1200040
*****H1200050
*****H1200060
*****H1200070
*****H1200080
*****H1200090
*****H1200100
SUBROUTINE H12H1200110
PURPOSEH1200120
H12 IS USED EITHER TO COMPUTE A HOUSEHOLDER TRANSFORMATIONH1200130
OR TO USE A PREVIOUSLY COMPUTED HOUSEHOLDER MATRIXH1200140
TO MULTIPLY IT TIMES A GIVEN SET OF VECTORSH1200150
H1200160
H1200170
H1200180
H1200190
H1200200
USAGEH1200210
CALL H12(MODE,PIVOT,L1,M,U,IUE,UP,C,ICE,ICV,NCV)H1200220
H1200230
H1200240
DESCRIPTION OF PARAMETERSH1200250
MODE - SET BY USER TO 1 OR 2.H1200260
MODE = 1 COMPUTES HOUSEHOLDER MATRIXH1200270
MODE = 2 USES PREVIOUSLY COMPUTED HOUSEHOLDERH1200280
MATRIXH1200290
LPIVOT - SEE REMARKSH1200300
L1 - SEE REMARKSH1200310
M - SEE REMARKSH1200320
U - CONTAINS M ELEMENTS WITH A STORAGE INCREMENT OFH1200330
IUE BETWEEN ELEMENTSH1200340
IF MODE = 1 THEN U MUST INITIALLY CONTAIN THEH1200350
V VECTOR STORED AS U(1+(J-1)*IUE) = V(J)H1200360
IF MODE = 2 THEN U MUST CONTAIN THE RESULTSH1200370
A CALL WHERE MODE = 1H1200380
IUE - INCREMENT VALUEH1200390
UP - ARRAY CONTAINING PART OF U RESULTSH1200400
C - CONTAINS A SET OF NCV M-VECTORSH1200410
ICE - STORAGE INCREMENT BETWEEN ELEMENTS OF VECTORSH1200420
ICV - STORAGE INCREMENT BETWEEN VECTORSH1200430
NCV - IF NCV <= 0 NO ACTION IS TAKEN INVOLVINGH1200440
THE PARAMETERS P, ICV AND NCV.H1200450
H1200460
H1200470
H1200480
REMARKSH1200490
THE INTEGERS MUST SATISFYH1200500
1 <= LPIVOT < L1 < MOTHERWISE NO COMPUTATIONS WILL BE DONEH1200510
GIVEN THE HOUSEHOLDER MATRIX Q AND AN M-VECTOR VH1200520
SUCH THAT Q * V = W WHERE W(I) = V(I) FOR IH1200530
< LPIVOT, ABS(W(LPIVOT)) =H1200540
SQRT(V(LPIVOT)**2 + SUM(V(I)**2) FOR I = 1 TO M).H1200550
W(I) = V(I) FOR LPIVOT < I < L1 ANDH1200560
W(I) = 0 FOR L1 <= I <= MH1200570
H1200580
H1200590
*****H1200600
*****H1200610
*****H1200620
SUBROUTINE H12 (MODE,LPIVOT,L1,M,U,IUE,UP,C,ICE,ICV,NCV)H1200630
CONSTRUCTION AND/OR APPLICATION OF A SINGLEH1200640
HOUSEHOLDER TRANSFORMATION.. Q = I + U*(U**T)/B H1200650
H1200660
H1200670
H1200680
MODE = 1 OR 2 TO SELECT ALGORITHM H1 OR H2 .H1200690
LPIVOT IS THE INDEX OF THE PIVOT ELEMENT.H1200700
L1,M IF L1 .LE. M THE TRANSFORMATION WILL BE CONSTRUCTED TOH1200710
ZERO ELEMENTS INDEXED FROM L1 THROUGH M. IF L1 GT. MH1200720
THE SUBROUTINE DOES AN IDENTITY TRANSFORMATION.H1200730
U(),IUE,UP ON ENTRY TO H1 U() CONTAINS THE PIVOT VECTOR.H1200740
IUE IS THE STORAGE INCREMENT BETWEEN ELEMENTS.H1200750
ON EXIT FROM H1 U() AND UPH1200760
CONTAIN QUANTITIES DEFINING THE VECTOR U OF THEH1200770
HOUSEHOLDER TRANSFORMATION. ON ENTRY TO H2 U()H1200780
AND UP SHOULD CONTAIN QUANTITIES PREVIOUSLY COMPUTEDH1200790
BY H1. THESE WILL NOT BE MODIFIED BY H2.H1200800

```

```

C      C() ON ENTRY TO H1 OR H2 C() CONTAINS A MATRIX WHICH WILL BE H1200810
C      REGARDED AS A SET OF VECTORS TO WHICH THE HOUSEHOLDER H1200820
C      TRANSFORMATION IS TO BE APPLIED. ON EXIT C() CONTAINS THE H1200830
C      SET OF TRANSFORMED VECTORS. H1200840
C      ICE STORAGE INCREMENT BETWEEN ELEMENTS OF VECTORS IN C(). H1200850
C      ICV STORAGE INCREMENT BETWEEN VECTORS IN C(). H1200860
C      NCV NUMBER OF VECTORS IN C() TO BE TRANSFORMED. IF NCV .LE. 0 H1200870
C      NO OPERATIONS WILL BE DONE ON C(). H1200880
C
C      SUBROUTINE H12 (MODE,LPIVOT,L1,M,U,IUE,UP,C,ICE,ICV,NCV) H1200890
C      DIMENSION U(IUE,M),C(1) H1200900
C      DOUBLE PRECISION SM,B H1200910
C      ONE=1. H1200920
C
C      IF (0.GE.LPIVOT.OR.LPIVOT.GE.L1.OR.L1.GT.M) RETURN H1200930
C      CL=ABS(U(1,LPIVOT)) H1200940
C      IF (MODE.EQ.2) GO TO 60 H1200950
C      ***** CONSTRUCT THE TRANSFORMATION ***** H1200960
C      DO 10 J=L1,M H1200970
C      CL=AMAX1(ABS(U(1,J)),CL) H1200980
C      IF (CL) 130,130,20 H1200990
C      CLINV=ONE/CL H1201000
C      SM=(DBLE(U(1,LPIVOT))*CLINV)**2 H1201010
C      DO 30 J=L1,M H1201020
C      SM=SM+(DBLE(U(1,J))*CLINV)**2 H1201030
C      CONVERT DBLE. PREC. SM TO SNGL. PREC. SM1 H1201040
C      SM1=SM H1201050
C      CL=CL*SQRT(SM1) H1201060
C      IF (U(1,LPIVOT)) 50,50,40 H1201070
C      CL=-CL H1201080
C      UP=U(1,LPIVOT)-CL H1201090
C      U(1,LPIVOT)=CL H1201100
C      GO TO 70 H1201110
C      ***** APPLY THE TRANSFORMATION I+U*(U**T)/B TO C. ***** H1201120
C      60 IF (CL) 130,130,70 H1201130
C      70 IF (NCV.LE.0) RETURN H1201140
C      B=DBLE(UP)*U(1,LPIVOT) H1201150
C      B MUST BE NONPOSITIVE HERE. IF B = 0., RETURN H1201160
C      IF (B) 80,130,130 H1201170
C      B=ONE/B H1201180
C      I2=1-ICV+ICE*(LPIVOT-1) H1201190
C      INCR=ICE*(L1-LPIVOT) H1201200
C      DO 120 J=1,NCV H1201210
C      I2=I2+ICV H1201220
C      I3=I2+INCR H1201230
C      I4=I3 H1201240
C      SM=C(I2)*DBLE(UP) H1201250
C      DO 90 I=L1,M H1201260
C      SM=SM+C(I3)*DBLE(U(1,I)) H1201270
C      I3=I3+ICE H1201280
C      IF (SM) 100,120,100 H1201290
C      SM=SM*B H1201300
C      C(I2)=C(I2)+SM*DBLE(UP) H1201310
C      DO 110 I=L1,M H1201320
C      C(I4)=C(I4)+SM*DBLE(U(1,I)) H1201330
C      I4=I4+ICE H1201340
C      110 CONTINUE H1201350
C      120 RETURN H1201360
C      130 END H1201370

```

A.9 G1

```

C *****G1 00010
C PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAMG1 00020
C ROUTINE NAME - G1TASC PROGRAM NO - 514G1 00030
C *****G1 00040
C *****G1 00050
C *****G1 00060
C *****G1 00070
C *****G1 00080
C *****G1 00090
C *****G1 00100
C .....G1 00110
C SUBROUTINE G1G1 00120
C PURPOSEG1 00130
C G1 COMPUTES AN 2 * 2 ORTHOGONAL ROTATION MATRIX GG1 00140
C SUCH THATG1 00150
C      ( X1 ) = ( C S ) ( X1 ) = ( X1X2 ) = ( R )G1 00160
C      G ( ) = ( ) ( ) = ( ) = ( )G1 00170
C      ( X2 ) = ( -S C ) ( X2 ) = ( 0 ) = ( 0 )G1 00180
C      NOTE X1X2 = SQRT(X1**2 + X2**2)G1 00190
C      G1 00200
C      G1 00210
C      G1 00220
C      G1 00230
C      G1 00240
C      G1 00250
C      G1 00260
C      G1 00270
C      G1 00280
C      G1 00290
C      G1 00300
C      G1 00310
C      G1 00320
C      G1 00330
C      G1 00340
C      G1 00350
C      G1 00360
C      G1 00370
C      G1 00380
C      G1 00390
C *****G1 00400
C SUBROUTINE G1 (A,B,COS,SIN,SIG)G1 00410
C COMPUTE ORTHOGONAL ROTATION MATRIX..G1 00420
C COMPUTE.. MATRIX (C, S) SO THAT (C, S)(A) = (SQRT(A**2+B**2))G1 00430
C      (-S,C) (-S,C)(B) ( 0 )G1 00440
C COMPUTE SIG = SQRT(A**2+B**2)G1 00450
C SIG IS COMPUTED LAST TO ALLOW FOR THE POSSIBILITY THATG1 00460
C SIG MAY BE IN THE SAME LOCATION AS A OR B .G1 00470
C      G1 00480
C      G1 00490
C      G1 00500
C      G1 00510
C      G1 00520
C      G1 00530
C      G1 00540
C      G1 00550
C      G1 00560
C      G1 00570
C      G1 00580
C      G1 00590
C      G1 00600
C      G1 00610
C      G1 00620
C      G1 00630
C      G1 00640
C      G1 00650
C      G1 00660
C      G1 00670
C      G1 00680
C      G1 00690
C      G1 00700
C      G1 00710
C
C      ZERO=0.
C      ONE=1.
C      IF (ABS(A).LE.ABS(B)) GO TO 10
C      XR=B/A
C      YR=SQRT(ONE+XR**2)
C      COS=SIGN(ONE/YR,A)
C      SIN=COS*XR
C      SIG=ABS(A)*YR
C      RETURN
10  IF (B) 20,30,20
20  XR=A/B
C      YR=SQRT(ONE+XR**2)
C      SIN=SIGN(ONE/YR,B)
C      COS=SIN*XR
C      SIG=ABS(B)*YR
C      RETURN
30  SIG=ZERO
C      COS=ZERO
C      SIN=ONE
C      RETURN
C      END

```

A.10 G2

```

*****G2 00010
PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAMG2 00020
ROUTINE NAME - G2TASC PROGRAM NO - 515G2 00030
*****G2 00040
G2 00050
G2 00060
G2 00070
G2 00080
G2 00090
G2 00100
G2 00110
SUBROUTINE G2G2 00120
PURPOSEG2 00130
G2 PERFORMS THE MATRIX-VECTOR PRODUCTG2 00140
G2 00150
G2 00160
G2 00170
G2 00180
G2 00190
G2 00200
G2 00210
G2 00220
G2 00230
G2 00240
G2 00250
G2 00260
G2 00270
G2 00280
G2 00290
G2 00300
G2 00310
G2 00320
G2 00330
G2 00340
G2 00350
G2 00360
G2 00370
G2 00380
G2 00390
G2 00400
G2 00410
G2 00420
G2 00430
G2 00440
G2 00450
G2 00460
G2 00470
G2 00480
G2 00490
G2 00500
G2 00510
*****
SUBROUTINE G2 (COS,SIN,X,Y)
XR=COS*X+SIN*Y
Y=-SIN*X+COS*Y
X=XR
RETURN
END

```

A:11 DIFF

```

C*****DIF00010
C      PROGRAM NAME - COVAR - COVARIANCE ANALYSIS PROGRAMDIF00020
C      ROUTINE NAME - DIFFTASC PROGRAM NO - 516DIF00030
C*****DIF00040
C      DIF00050
C      DIF00060
C      DIF00070
C      DIF00080
C      DIF00090
C      .....DIF00100
C      FUNCTION DIFFDIF00110
C      PURPOSEDIF00120
C      DIFF IS USED TO MAKE THE TESTDIF00130
C      IF ((X+H)-X) .NOT.= 0DIF00140
C      WHICH IS USED IN PLACE OF THE TESTDIF00150
C      IF ABS(H)>P*ABS(X) WHERE P IS THE RELATIVE PRECISIONDIF00160
C      OF THE MACHINE FLOATING POINT ARITHMETICDIF00170
C      DIF00180
C      DIF00190
C      DIF00200
C      DIF00210
C      DIF00220
C      DIF00230
C      DIF00240
C      DIF00250
C      USAGEDIF00260
C      .... = DIFF(X,H)DIF00270
C      DIF00280
C      DESCRIPTION OF PARAMETERSDIF00290
C      X - INPUT (SEE PURPOSE)DIF00300
C      H - INPUT (SEE PURPOSE)DIF00310
C      DIF00320
C      DIF00330
C      DIF00340
C      .....DIF00350
C*****DIF00360
C      DIF00370
C      DIF00380
C      DIF00390
C      DIF00400
C      DIF00410
C      DIF00420
C      DIF00430

FUNCTION DIFF(X,Y)
DIFF = X-Y
RETURN
END

```


A-28

APPENDIX B
SAMPLE EXECUTION OF COVARIANCE PROGRAM

COVARIANCE MATRICES COMPUTATIONS

DATA SET USED WAS UPDATED ON 5 31 78 1070
 DIMENSION OF COVARIANCE MATRIX IS 4 BY 4
 DIMENSIONS OF DATA IS 91 BY 87 = 7917
 NUMBER OF PARAMETERS PRESENT ON DATA BASE = 100
 THE TITLES WITH THEIR SELECTION NUMBERS FOLLOW
 NOTE USE COLUMN NUMBERS FOR LIKE SELECTION MATRIX

1 C 1	4 AVERAGE RELEASED STRAIN - 16 KM RAD.
2 C 2	25 LENGTH OF LINEARS (45 - 50 DEGS) - 16 KM RAD.
3 C 3	28 LENGTH OF LINEARS (110 - 115 DEGS) - 16 KM RAD.
4 C 4	35 TOTAL LENGTH OF LINEARS - 8 KM RAD.

COMPUTATION OF COVARIANCE MATRIX DB 1
 GEOTHERMAL DATA FOR GRIDDED LOCATIONS INSIDE STATE OF NEVADA
 VALUES OVER 1.E65 ARE NOT USED
 UPDATE ON 5 31 78 1070
 DIMENSIONS OF DATA BASE = 91 BY 87 = 7917
 PARAMETERS ON DATA BASE = 100

DIMENSIONS 4 4 COVARIANCE MATRIX

	C 1	C 2	C 3	C 4
1	1.921E 07	2.332E 02	8.123E 02	4.436E 03
2	2.332E 02	7.016E 00	-1.472E-01	3.609E 00
3	8.123E 02	-1.472E-01	1.374E 01	5.165E 00
4	4.436E 03	3.609E 00	9.169E 00	1.824E 02

DIMENSIONS 1 4 AVERAGES

	C 1	C 2	C 3	C 4
1	4.151E 03	1.340E 00	2.222E 00	2.170E 01

DIMENSIONS 1 4 STANDARD DEVIATIONS

	C 1	C 2	C 3	C 4
1	4.383E 03	2.649E 00	3.706E 00	1.351E 01

DIMENSIONS 4 4 CORRELATION MATRIX

	C 1	C 2	C 3	C 4
1	1.000E 00	2.009E-02	5.000E-02	7.493E-02
2	2.009E-02	1.000E 00	-1.499E-02	1.009E-01
3	5.000E-02	-1.499E-02	1.000E 00	1.832E-01
4	7.493E-02	1.009E-01	1.832E-01	1.000E 00

DIMENSIONS 4 4 MATRIX OF EIGEN VECTORS

	C 1	C 2	C 3	C 4
1	-3.583E-01	6.275E-02	9.288E-01	7.051E-02
2	-2.807E-01	-8.850E-01	-7.609E-02	3.635E-01
3	-5.785E-01	4.577E-01	-3.000E-01	6.045E-01
4	-6.769E-01	-5.740E-02	-2.037E-01	-7.050E-01

DIMENSIONS 4 4 EIGEN VALUE MATRIX

	C 1	C 2	C 3	C 4
1	1.238E 00	-3.465E-07	-2.580E-07	7.745E-07
2	-3.576E-07	1.013E 00	-3.725E-02	8.121E-07
3	-1.788E-07	-7.451E-08	9.658E-01	7.153E-07
4	8.345E-07	7.190E-07	8.345E-07	7.833E-01

DIMENSIONS 4 1 EIGEN VALUES OUTPUT

	C 1
1	1.238E 00
2	1.013E 00
3	9.658E-01
4	7.833E-01

COMPUTATION OF COVARIANCE MATRIX PTS
 GEOTHERMAL DATA FOR HOT SPRINGS LOCATIONS
 THESE ARE LOCATED IN NEVADA
 UPDATE ON 5 31 78 1070
 DIMENSIONS OF DATA BASE = 91 BY 87 = 7917
 PARAMETERS ON DATA BASE = 100

DIMENSIONS 4 4 COVARIANCE MATRIX

	C 1	C 2	C 3	C 4
1	2.846E 07	-6.064E 02	-1.405E 03	-1.531E 04
2	-6.064E 02	1.821E-01	-2.580E-02	1.121E 00
3	-1.405E 03	-2.580E-02	1.818E 00	1.514E 00
4	-1.531E 04	1.121E 00	1.514E 00	1.386E 02

DIMENSIONS 1 4 AVERAGES

	C 1	C 2	C 3	C 4
1	5.515E 03	1.035E-01	6.566E-01	2.393E 01

DIMENSIONS 1 4 STANDARD DEVIATIONS

	C 1	C 2	C 3	C 4
1	5.334E 03	4.267E-01	1.349E 00	1.177E 01

DIMENSIONS 4 4 CORRELATION MATRIX

	C 1	C 2	C 3	C 4
1	1.000E 00	-2.664E-01	-1.953E-01	-2.438E-01
2	-2.664E-01	1.000E 00	-4.484E-02	2.233E-01
3	-1.953E-01	-4.484E-02	1.000E 00	9.535E-02
4	-2.438E-01	2.233E-01	9.535E-02	1.000E 00

DIMENSIONS 4 4 MATRIX OF EIGEN VECTORS

	C 1	C 2	C 3	C 4
1	-6.071E-01	1.256E-01	-4.028E-01	-6.733E-01
2	5.095E-01	5.155E-01	3.673E-01	-5.829E-01
3	2.778E-01	-8.430E-01	7.734E-02	-4.546E-01
4	5.429E-01	8.810E-02	-8.348E-01	2.640E-02

DIMENSIONS 4 4 EIGEN VALUE MATRIX

	C 1	C 2	C 3	C 4
1	1.531E 00	5.998E-07	3.576E-07	1.244E-06
2	6.557E-07	1.047E 00	-8.456E-07	5.527E-07
3	3.576E-07	-7.745E-07	7.753E-01	3.017E-07
4	1.259E-06	5.041E-07	2.086E-07	6.472E-01

DIMENSIONS 4 1 EIGEN VALUES OUTPUT

	C 1
1	1.531E 00
2	1.047E 00
3	7.753E-01
4	6.472E-01

LIKELIHOOD EVALUATION PROGRAM
SOURCE LISTING

		Page <u>No.</u>
C.1	LIKE (MAIN PROGRAM)	C-2
C.2	SLIKE	C-6
C.3	SLIKE1	C-9
C.4	PRNTL	C-12

C.1 LIKE (MAIN PROGRAM)

```

C *****
C PROGRAM NAME - LIKE - LIKELIHOOD EVALUATION PROGRAM
C ROUTINE NAME - MAIN TASC PROGRAM NO - 518
C *****
C THIS PROGRAM WAS PREPARED BY
C THE ANALYTIC SCIENCES CORPORATION (TASC)
C 6 JACOB WAY
C READING, MASSACHUSETTS 01867
C FOR THE U.S. GEOLOGICAL SURVEY UNDER CONTRACT
C NO. 18706(14-08-0001-15049) AND THE U.S. DEPARTMENT OF ENERGY
C UNDER CONTRACT NO. E (11-1) - 4084. IT SHOULD NOT BE RELEASED
C OUTSIDE THE U.S. GOVERNMENT WITHOUT PERMISSION FROM TASC.
C *****
C .....
C MAIN PROGRAM - LIKE
C PURPOSE
C LIKE HAS THE FOLLOWING FUNCTIONS
C * SETS MAXIMUM DIMENSIONS FOR MATRICES
C * READS FILE DESCRIPTOR STANDARDS
C * READS COLUMNS SELECTION VECTORS
C * PRINTS FILE DESCRIPTORS
C * CALLS SLIKE WHICH IS REALLY THE MAIN COMPUTATIONAL
C ROUTINE
C * PRINTS ERROR MESSAGES IF ERROR SITUATIONS OCCUR
C .....
C *****
C *** COMMON /ADATA/ VARIABLES
C
C NDIM - DIMENSION OF EIGEN VECTOR MATRIX AS COMPUTED
C AND SAVED BY PROGRAM COVAR
C
C NDT - DATE OF ORIGINAL FILES USED
C NDT(1) = MONTH OF UPDATE
C NDT(2) = DAY OF UPDATE
C NDT(3) = YEAR OF UPDATE
C NDT(4) = MINUTES OF DAY OF UPDATE
C
C NDM - DIMENSIONS OF DATA BASE 1 USED
C NDM(1) = ROWS OF DATA BASE 1
C NDM(2) = COLUMNS OF DATA BASE 1
C NDM(3) = TOTAL POINTS OF DATA BASE 1
C
C NPAR - NUMBER OF PARAMETERS ON DATA BASE
C
C NSEL - SELECTION VECTOR OF PARAMETERS AS SAVED BY COVAR
C
C TITLES - MATRIX OF TITLES OF PARAMETERS
C
C YY - VARIABLES ON DATA BASE
C
C STITLE - TITLE OF DATA BASE
C
C ICARD READ IN NAMELIST. USED ONLY IF OUTPUT FROM
C COVAR IS ON CARDS THEN SET ICARD = 1. THIS
C PREVENTS REWINDS OF CARD FILES
C
C COMMON /ADATA/ NDIM, NDT(4), NDM(3), NPAR, NSEL(100),
C A TITLES(100,20), YY(100), STITLE(40), ICARD
C *****
C *** MAXDIM AND ALL THE APPROPRIATE DIMENSIONS MUST BE EQUAL

```

```

C      TO OR GREATER THAN THE DIMENSICNS PASSED BY THE
C      PROGRAM COVAR
C
C      AVGA AND AVGB ARE THE AVERAGE VECTORS (*1)
C      SDA AND SDB ARE THE STANDARD DEVIATION VECTORS (*1)
C      EIGVCA AND EIGVCB ARE THE EIGEN VECTOR MATRICES (*1)
C      EGVALA AND EGVALB ARE THE EIGEN VALUE VECTORS(*1)
C      NSELA AND NSELB ARE SELECTION VECTORS WHICH
C      CORRESPOND TO THE EIGEN VECTORS (*1)
C      DDA AND CDB ARE THE VALUES USED TO COMPUTE THE
C      NUMERATOR AND DENOMINATOR OF THE LIKELIHOOD
C      EXPONENT (*1)
C      SELA AND SELB ARE THE REAL VALUES OF NSELA AND NSELB (*1)
C
C      NOTE (*1) ANY OF THE ABOVE AVAIABLES ENDING IN
C      THE LETTER A REFER TO DATA BASE 1 WHILE THOSE
C      ENDING IN B REFER TO DATA BASE 2
C      MDT - DATES READ IN AND COMPARED WITH NDT
C      MDM - DIMENSIONS READ IN AND COMPARED WITH NDM
C      NDB - DESCRIPTORS FOR DATA BASE1 VALUE FILE
C      MDB - DESCRIPTORS READ IN WHICH MUST MATCH NDB
C
C      DIMENSION AVGA(50),AVGB(50),SDA(50),SDB(50),BETA(50,50),
C      A BETB(50,50),EIGVCA(50,50),EIGVCB(50,50),EGVALA(50),
C      B EGVALB(50),NSELA(50),NSELB(50),DCA(50),ODB(50),
C      C SELA(1),SELB(1),MDT(4),MDM(3),NDB(2),MDB(2)
C
C      EQUIVALENCE (NSELA(1),SELA(1)),(NSELB(1),SELB(1))
C
C      *** NSELA AND NSELB ARE SELECTION VECTORS WHICH
C      CORRESPOND TO A ROW AND COLUMN OF THE
C      TWO COVARIANCE MATRICES RESPECTIVELY
C
C      THE DEFAULT VALUES ARE 1 WHICH MEAN USE THE ROW
C      AND COLUMN.
C      ZERO MEANS DO NOT USE THAT ROW AND COLUMN
C      ANY OTHER VALUE CAUSES AN ERROR ABEND
C
C      NAMELIST /DATA/ NSELA, NSELB, ICARD
C
C      DATA NSELA/50*1/,NSELB/50*1/,MAXDIM/50/,
C      A NDB/4HDB 1,4H PTS/
C
C      *** NOW READING IN THE SELECTION VECTORS
C
C      ICARD = 0
C      READ (5,DATA,END=99)
C
C      *** NOW READING IN SET OF DESCRIPTORS AS SAVED BY PROGRAM
C      COVAR. THESE DESCRIPTORS WILL BE USED TO ENSURE
C      THAT THE PROPER FILES ARE BEING USED
C
C      READ (21,200,END=98)  NDM,NDT,NDM,NPAR
C      READ (21,200,END=98)  STITLE
C      READ (21,200,END=98)  (NSEL(I),I=1,NDIM)
C      READ (21,200,END=98)  ((TTITLES(I,J),J=1,20),I=1,NDIM)
C      IF ( ICARD.NE.1 ) REWIND 21
C
C      *** PRINTING OUT SOME OF THE FILE DESCRIPTORS
C
C      WRITE (6,300)  NDM,NDT,NDM,NPAR
C
C      *** NOW CHECKING THAT THE DIMENSION OF THE CORRELATION
C      MATRICES, ETC.. IS GREATER THAN 0 AND DOES NOT
C      EXCEED MAXDIM

```

```

MAI00810
MAI00820
MAI00830
MAI00840
MAI00850
MAI00860
MAI00870
MAI00880
MAI00890
MAI00900
MAI00910
MAI00920
MAI00930
MAI00940
MAI00950
MAI00960
MAI00970
MAI00980
MAI00990
MAI01000
MAI01010
MAI01020
MAI01030
MAI01040
MAI01050
MAI01060
MAI01070
MAI01080
MAI01090
MAI01100
MAI01110
MAI01120
MAI01130
MAI01140
MAI01150
MAI01160
MAI01170
MAI01180
MAI01190
MAI01200
MAI01210
MAI01220
MAI01230
MAI01240
MAI01250
MAI01260
MAI01270
MAI01280
MAI01290
MAI01300
MAI01310
MAI01320
MAI01330
MAI01340
MAI01350
MAI01360
MAI01370
MAI01380
MAI01390
MAI01400
MAI01410
MAI01420
MAI01430
MAI01440
MAI01450
MAI01460
MAI01470
MAI01480
MAI01490
MAI01500
MAI01510
MAI01520
MAI01530
MAI01540
MAI01550
MAI01560
MAI01570
MAI01580
MAI01590
MAI01600

```

```

C
C
C      IF ( NDIM.LT.1 .OR. NDIM.GT.MAXDIM ) GOTO 97
C
C      *** ENSURING THAT THE SELECTION VECTORS HAVE ONLY VALUES
C      OF 1 OR 0
C
C      DO 10 I = 1,NDIM
C      IF ( NSELA(I).LT.0 .OR. NSELA(I).GT.1 ) GOTO 97
C      IF ( NSELB(I).LT.0 .OR. NSELB(I).GT.1 ) GOTO 97
C      10 CONTINUE
C
C      *** NOW READING IN DESCRIPTORS FROM THE VALUE FILE
C
C      READ (31,201,END=96) MDT,MDM,MPAR,MDE
C
C      *** CHECKING THAT THE FILES ARE CONSISTENT WITH THE
C      ORIGINAL DESCRIPTORS
C
C      DO 15 I = 1,3
C      IF ( MDM(I).NE.NDM(I) ) GOTO 95
C      15 CONTINUE
C
C      *** CHECKING FILE 31 IS INDEED THAT THE VALUE FILE
C      FOR DATA BASE 1
C
C      DO 20 I = 1,2
C      IF ( MDB(I).NE.NDB(I) ) GOTO 93
C      20 CONTINUE
C
C      *** PRINTING OUT THE DESCRIPTORS FOR THE FILES
C
C      WRITE (6,301) MDT,MDM,MPAR
C      WRITE (6,302) ((TITLES(I,J),J=1,20),I=1,NDIM)
C      WRITE (6,303)
C
C      *** PRINTING OUT THE SELECTION VECTORS FOR THE EIGEN
C      VECTOR MATRICES FOR THE TWO DATA BASES
C
C      DO 25 I = 1,NDIM
C      WRITE (6,304) I,NSELA(I),NSELB(I)
C
C      SELA(I) = NSELA(I)
C      SELB(I) = NSELB(I)
C      25 CONTINUE
C
C      *** ENSURING THAT THE PARAMETERS ARE CONSISTENT
C      WITH THE ONES USED IN PROGRAM COVAR
C
C      DO 35 J = 1,20
C      READ (31,201,END=96) YY
C
C      DO 30 I = 1,NDIM
C      K = NSEL(I)
C      IF ( YY(K).NE.TITLES(I,J) ) GOTO 94
C      30 CONTINUE
C      35 CONTINUE
C
C      *** SUBROUTINE SLIKE IS THE MAIN COMPUTATIONAL SUBROUTINE
C
C      CALL SLIKE(AVGA,SDA,BETA,EGVALA,EIGVCA,AVGB,SDB,
C      A BETB,EGVALB,EIGVCB,SELA,SELB,DDA,DCB)

```

MAI01610
 MAI01620
 MAI01630
 MAI01640
 MAI01650
 MAI01660
 MAI01670
 MAI01680
 MAI01690
 MAI01700
 MAI01710
 MAI01720
 MAI01730
 MAI01740
 MAI01750
 MAI01760
 MAI01770
 MAI01780
 MAI01790
 MAI01800
 MAI01810
 MAI01820
 MAI01830
 MAI01840
 MAI01850
 MAI01860
 MAI01870
 MAI01880
 MAI01890
 MAI01900
 MAI01910
 MAI01920
 MAI01930
 MAI01940
 MAI01950
 MAI01960
 MAI01970
 MAI01980
 MAI01990
 MAI02000
 MAI02010
 MAI02020
 MAI02030
 MAI02040
 MAI02050
 MAI02060
 MAI02070
 MAI02080
 MAI02090
 MAI02100
 MAI02110
 MAI02120
 MAI02130
 MAI02140
 MAI02150
 MAI02160
 MAI02170
 MAI02180
 MAI02190
 MAI02200
 MAI02210
 MAI02220
 MAI02230
 MAI02240
 MAI02250
 MAI02260
 MAI02270
 MAI02280
 MAI02290
 MAI02300
 MAI02310
 MAI02320
 MAI02330
 MAI02340
 MAI02350
 MAI02360
 MAI02370
 MAI02380
 MAI02390
 MAI02400


```

C      STOP
C
C      *** THE FOLLOWING ARE ERROR MESSAGES AND ABENDS
C
C      93 WRITE (6,508)   MDB.NDB
C      STOP
C
C      94 WRITE (6,500)   I
C      STOP
C
C      95 WRITE (6,501)   MDM.NDM
C      STOP
C
C      96 WRITE (6,502)
C      STOP
C
C      97 WRITE (6,503)   NDIM,MAXDIM
C      WRITE (6,504)   NDIM,(NSELA(I),I=1,NDIM)
C      WRITE (6,505)   NDIM,(NSELB(I),I=1,NDIM)
C      STOP
C
C      98 WRITE (6,506)
C      STOP
C
C      99 WRITE (6,507)
C      STOP
C
C      200 FORMAT (20A4)
C      201 FORMAT (100A4)
C
C      300 FORMAT ('1DIMENSION OF CORRELATION MATRICES,ETC =',I5/
C      A'DATE OF DATA BASES USED IN COVAR',4I6/
C      B'DIMENSIONS OF VALUES DATA BASE 1 USED IN COVAR',3I8/
C      C'NUMBER OF PARAMETERS PRESENT ON DATA BASE USED IN COVAR',I4)
C      301 FORMAT ('0 VALUES OF VARIOUS INDICATORS READ FROM FILE 31',
C      A 'DATA BASE 1 VALUES',0DATE OF DATA BASE 1 VALUES USED',4I6/
C      B'DIMENSIONS OF DATA BASE USED',3I8/
C      C'NUMBER OF PARAMETERS PRESENT ON DATA BASE',I4)
C      302 FORMAT ('0INDICES INPUT FOR LIKELIHOOD RATIO COMPUTATION:'//
C      A (1X,20A4))
C      303 FORMAT ('0TERMS INCLUDED IN LIKELIHOOD SUMATION'//1X.
C      A ' I NSELA NSELB')
C      304 FORMAT (1X,I7,I10,I8)
C
C      500 FORMAT ('0PARAMETER',I4,' DOES NOT HAVE THE SAME TITLE ON FILE',
C      A ' 31 AND THE STANDARDS FILE 21')
C      501 FORMAT ('0DIMENSIONS OF DATA BASE OF FILE 31 ('',3I6,'') DO NOT MATCH
C      A'5X,' THE DIMENSIONS OF THE DATA BASE AS SAVED ON UNIT 21 ('',
C      B 3I6,'')')
C      502 FORMAT ('0UNEXPECTED END OF FILE REACHED ON FILE 31')
C      503 FORMAT ('0INPUT NAMEDLIST VALUES',
C      A ' EXCEED LIMITS'//' NDIM ',I5,' MUST BE',
C      B ' GREATER THAN 0 AND NOT EXCEED MAXDIM ('',I5,'')')
C      504 FORMAT (' THE FOLLOWING VALUES OF NSELA',
C      A ' MUST BE EITHER 0 OR 1'/(50(1X,I1)))
C      505 FORMAT (' THE FOLLOWING VALUES OF NSELB',
C      A ' MUST BE EITHER 0 OR 1'/(50(1X,I1)))
C      506 FORMAT ('0UNEXPECTED END OF FILE REACHED ON FILE 21')
C      507 FORMAT ('0UNEXPECTED END OF FILE REACHED ON FILE 5')
C      508 FORMAT ('0FILE 31 IS NOT THE CORRECT FILE'// IT SHOULD BE ',A4,
C      A 1X,A4,' BUT IS INSTEAD ',A4,1X,A4)
C
C      END

```

```

MAI02410
MAI02420
MAI02430
MAI02440
MAI02450
MAI02460
MAI02470
MAI02480
MAI02490
MAI02500
MAI02510
MAI02520
MAI02530
MAI02540
MAI02550
MAI02560
MAI02570
MAI02580
MAI02590
MAI02600
MAI02610
MAI02620
MAI02630
MAI02640
MAI02650
MAI02660
MAI02670
MAI02680
MAI02690
MAI02700
MAI02710
MAI02720
MAI02730
MAI02740
MAI02750
MAI02760
MAI02770
MAI02780
MAI02790
MAI02800
MAI02810
MAI02820
MAI02830
MAI02840
MAI02850
MAI02860
MAI02870
MAI02880
MAI02890
MAI02900
MAI02910
MAI02920
MAI02930
MAI02940
MAI02950
MAI02960
MAI02970
MAI02980
MAI02990
MAI03000
MAI03010
MAI03020
MAI03030
MAI03040
MAI03050

```

C.2 SLIKE

```

C*****SLI00010
C      PROGRAM NAME - LIKE - LIKELIHOOD EVALUATION PROGRAM      SLI00020
C      ROUTINE NAME - SLIKE          TASC PROGRAM NO - 519      SLI00030
C      SLI00040
C      SLI00050
C      SLI00060
C*****SLI00070
C      SLI00080
C      SLI00090
C      SLI00100
C      SLI00110
C      SUBROUTINE SLIKE      SLI00120
C      SLI00130
C      PURPOSE      SLI00140
C      SLIKE IS THE ACTUAL MAIN COMPUTATIONAL ROUTINE      SLI00150
C      ITS FUNCTIONS ARE:      SLI00160
C      * CALLS SLIKE1 WHICH READS THE DATA SAVED FROM      SLI00170
C      THE PROGRAM COVAR      SLI00180
C      * COMPUTES THE LIKELIHOOD VALUES FOR THE DATA      SLI00190
C      BASE 1 VALUES      SLI00200
C      * SAVES THE LIKELIHOOD VALUES      SLI00210
C      SLI00220
C      SLI00230
C      SLI00240
C      USAGE      SLI00250
C      CALL SLIKE (AVGA,SDA,BETA,EGVALA,EIGVCA,AVGB,SDB,BETB,      SLI00260
C      EGVALB,EIGVCB,SELA,SELB,DDA,DOB)      SLI00270
C      SLI00280
C      SLI00290
C      DESCRIPTION OF PARAMETERS      SLI00300
C      AVGA - AVERAGES DATA BASE 1      SLI00310
C      SDA - STANDARD DEVIATIONS DATA BASE 1      SLI00320
C      BETA - BETA MATRIX DATA BASE 1      SLI00330
C      EGVALA - EIGEN VALUES DATA BASE 1      SLI00340
C      EIGVCA - EIGEN VECTORS DATA BASE 1      SLI00350
C      AVGB - AVERAGES DATA BASE 2      SLI00360
C      SDB - STANDARD DEVIATIONS DATA BASE 2      SLI00370
C      BETB - BETA MATRIX DATA BASE 2      SLI00380
C      EGVALB - EIGEN VALUES DATA BASE 2      SLI00390
C      EIGVCB - EIGEN VECTORS DATA BASE 2      SLI00400
C      SELA - COLUMN SELECTION VECTOR DATA BASE 1      SLI00410
C      COVARIANCE MATRIX      SLI00420
C      SELB - COLUMN SELECTION VECTOR DATA BASE 2      SLI00430
C      COVARIANCE MATRIX      SLI00440
C      DDA - INTERMEDIATE VALUES FROM DATA BASE 1      SLI00450
C      DOB - INTERMEDIATE VALUES FROM DATA BASE 2      SLI00460
C      SLI00470
C      SLI00480
C      SLI00490
C*****SLI00500
C      SLI00510
C      SLI00520
C      SLI00530
C      SLI00540
C      SLI00550
C      SLI00560
C      SUBROUTINE SLIKE(AVGA,SDA,BETA,EGVALA,EIGVCA,      SLI00570
C      AAVGB,SDB,BETB,EGVALB,EIGVCB,SELA,SELB,DDA,DOB)      SLI00580
C      SLI00590
C      DIMENSION AVGA(1),SDA(1),BETA(NDIM,1),      SLI00600
C      A EIGVCA(NDIM,1),AVGB(1),SDB(1),BETB(NDIM,1),      SLI00610
C      B EIGVCB(NDIM,1),EGVALA(1),EGVALB(1),Z(100),      SLI00620
C      C SELA(1),SELB(1),DDA(1),DOB(1)      SLI00630
C      COMMON /ADATA/ NDIM, NDT(4), NDM(3), NPAR, NSEL(100),      SLI00640
C      A TTLES(100,20), YY(100), STITLE(40), ICARD      SLI00650
C      SLI00660
C      *** Z(I) ARE THE LIKELIHOOD VALUES. THEY ARE      SLI00670
C      ACCUMULATED UP TO 100 AND THEN SAVED.      SLI00680
C      THEY ARE SAVED IN THE SAME ORDER THAT THE VALUES      SLI00690
C      FROM DATA BASE 1 ARE READ      SLI00700
C      SLI00710
C      SLI00720
C      DATA Z/100 * 1.E70/      SLI00730
C      SLI00740
C      SLI00750
C      *** N IS THE TOTAL NUMBER OF POINTS IN THE MATRICES      SLI00760
C      SLI00770
C      SLI00780
C      SLI00790
C      N = NDIM * NDIM      SLI00800

```

```

C *** SUBROUTINE SLIKE1 READS IN THE AVERAGES,
C STANDARD DEVIATIONS, EIGEN VALUES AND
C EIGEN VECTORS THAT WERE SAVED BY PROGRAM COVAR
C
C SLIKE1 ALSO NORMALIZES THE EIGEN VECTORS
C
C CALL SLIKE1( AVGA, SDA, BETA, EGVALA, EIGVCA,
A 'EIGEN VALUES FOR DATA BASE 1',
B 'TRANSPPOSE OF THE EIGEN VECTOR MATRIX FOR DATA BASE 1')
C
C CALL SLIKE1( AVGB, SDB, BETB, EGVALE, EIGVCB,
A 'EIGEN VALUES FOR DATA BASE 2',
B 'TRANSPPOSE OF THE EIGEN VECTOR MATRIX FOR DATA BASE 2')
C
C *** THE COMPUTATION OF THE LIKELIHOOD FUNCTION BEGINS
C
C THE VALUES FROM THE VALUES FILE OF DATA BASE 1 ARE
C READ IN AND USED FOR THE CALCULATIONS
C
C THE LIKELIHOOD FUNCTIONS ARE SAVED IN THE VECTOR Z
C AND OUTPUT 100 AT A TIME
C
C IF THERE ARE NO VALUES TO BE USED IN COMPUTING THE
C LIKELIHOOD FUNCTION THEN THE Z(I) HAVE A DEFAULT
C VALUE OF 1.E70
C
C 10 CONTINUE
C
C DO 50 JJ = 1,100
C
C READ (31,200,END=60) YY
C
C DO 20 I = 1,NDIM
C
C *** NSEL(I) IS THE SELECTION VECTOR SAVED FROM COVAR
C WHICH SELECTS THE PARAMETERS TO BE USED
C
C K = NSEL(I)
C VAL = YY(K)
C
C *** VAL GREATER THAN OR EQUAL TO 1.E50 MEANS
C VALUE IS NOT TO BE USED
C
C IF ( VAL.GE.1.E50 ) GOTO 50
C
C DDA(I) = ( VAL-AVGA(I) ) / SDA(I)
C DDB(I) = ( VAL-AVGB(I) ) / SDB(I)
C
C 20 CONTINUE
C
C TBA = 0.
C
C DO 40 I = 1,NDIM
C
C XA = 0.
C XB = 0.
C
C DO 30 J = 1,NDIM
C
C SA = BETA(I,J) * DDA(J)
C SB = BETB(I,J) * DDB(J)
C
C XA = XA + SA
C XB = XB + SB
C
C 30 CONTINUE
C
C TA = ( XA * XA * SELA(I) ) / EGVALA(I)
C TB = ( XB * XB * SELB(I) ) / EGVALB(I)
C
C TBA = TBA + TA - TB

```

SLI00810
 SLI00820
 SLI00830
 SLI00840
 SLI00850
 SLI00860
 SLI00870
 SLI00880
 SLI00890
 SLI00900
 SLI00910
 SLI00920
 SLI00930
 SLI00940
 SLI00950
 SLI00960
 SLI00970
 SLI00980
 SLI00990
 SLI01000
 SLI01010
 SLI01020
 SLI01030
 SLI01040
 SLI01050
 SLI01060
 SLI01070
 SLI01080
 SLI01090
 SLI01100
 SLI01110
 SLI01120
 SLI01130
 SLI01140
 SLI01150
 SLI01160
 SLI01170
 SLI01180
 SLI01190
 SLI01200
 SLI01210
 SLI01220
 SLI01230
 SLI01240
 SLI01250
 SLI01260
 SLI01270
 SLI01280
 SLI01290
 SLI01300
 SLI01310
 SLI01320
 SLI01330
 SLI01340
 SLI01350
 SLI01360
 SLI01370
 SLI01380
 SLI01390
 SLI01400
 SLI01410
 SLI01420
 SLI01430
 SLI01440
 SLI01450
 SLI01460
 SLI01470
 SLI01480
 SLI01490
 SLI01500
 SLI01510
 SLI01520
 SLI01530
 SLI01540
 SLI01550
 SLI01560
 SLI01570
 SLI01580
 SLI01590
 SLI01600

C	40 CONTINUE	SLI01610
C	IF (TBA.GT.-10) GOTO 45	SLI01620
C	Z(JJ) = 0.	SLI01630
C	GOTO 50	SLI01640
C	45 Z(JJ) = EXP(TBA/2.)	SLI01650
C	50 CONTINUE	SLI01660
C	*** THE Z VECTOR (LIKELIHOOD FUNCTIONS) ARE SAVED ON	SLI01670
C	UNIT 10	SLI01680
C	WRITE (10,200) Z	SLI01690
C	*** REINITIALIZING Z TO THE DEFAULT VALUES	SLI01700
C	DO 55 I = 1,100	SLI01710
C	55 Z(I) = 1.E70	SLI01720
C	GOTO 10	SLI01730
C	60 CONTINUE	SLI01740
C	*** SAVING LAST RECORD OF Z AND CLOSING FILE	SLI01750
C	WRITE (10,200) Z	SLI01760
C	REWIND 10	SLI01770
C	*** NOTE FORMAT USED IS CONSISTENT WITH OTHER TAPE	SLI01780
C	FORMATS	SLI01790
C	200 FORMAT (100A4)	SLI01800
C	RETURN	SLI01810
C	END	SLI01820
		SLI01830
		SLI01840
		SLI01850
		SLI01860
		SLI01870
		SLI01880
		SLI01890
		SLI01900
		SLI01910
		SLI01920
		SLI01930
		SLI01940
		SLI01950
		SLI01960
		SLI01970
		SLI01980
		SLI01990
		SLI02000
		SLI02010
		SLI02020
		SLI02030
		SLI02040
		SLI02050
		SLI02060


```

C      IF ( MDIM.NE.NDIM ) GOTO 98
C
C      *** CHECKING THE DATES FROM UNIT NT WITH THE ORIGINAL
C      DATES
C
C      DO 10 I = 1,4
C      IF ( MDT(I).NE.NDT(I) ) GOTO 98
C      10 CONTINUE
C
C      *** COMPARING NUMBERS OF PARAMETERS
C
C      IF ( NPAR.NE.MPAR ) GOTO 98
C
C      *** PRINTING OUT DESCRIPTORS OF UNIT NT
C
C      WRITE (6,300) MDIM,MDT,MDM,MPAR,DTITLE
C
C      *** READING IN PARAMETER SELECTION VECTOR FROM UNIT NT
C
C      READ (NT,200,END=99) (KSEL(I),I=1,NDIM)
C
C      *** COMPARING SELECTION VECTORS
C
C      DO 15 I = 1,NDIM
C      IF ( KSEL(I).NE.NSEL(I) ) GOTO 97
C      15 CONTINUE
C
C      *** READING IN PARAMETER TITLES FROM UNIT NT
C
C      DO 25 I = 1,NDIM
C      READ (NT,200,END=99) ATITLE
C
C      *** COMPARING PARAMETER TITLES
C
C      DO 20 J = 1,20
C      IF ( ATITLE(J).NE.TITLES(I,J) ) GOTO 96
C      20 CONTINUE
C      25 CONTINUE
C
C      30 CONTINUE
C
C      *** NOW READING IN THE AVERAGES, STANDARD DEVIATIONS,
C      EIGEN VALUES AND EIGEN VECTORS FROM UNIT NT
C
C      READ (NT,200,END=99) (AVGC(I),I=1,NDIM),
C      A (SDC(I),I=1,NDIM)
C
C      READ (NT,200,END=99) (EGVALC(I),I=1,NDIM),
C      A ((EIGVCC(I,J),I=1,NDIM),J=1,NDIM)
C
C      IF ( ICARD.NE.1 ) REWIND NT
C
C      NT = NT + 1
C
C      *** SETTING THE BETC MATRIX EQUAL TO THE TRANSPOSE OF THE
C      EIGEN VECTOR MATRIX
C
C      DO 45 I = 1,NDIM
C      XX = 0.

```

```

SLI00810
SLI00820
SLI00830
SLI00840
SLI00850
SLI00860
SLI00870
SLI00880
SLI00890
SLI00900
SLI00910
SLI00920
SLI00930
SLI00940
SLI00950
SLI00960
SLI00970
SLI00980
SLI00990
SLI01000
SLI01010
SLI01020
SLI01030
SLI01040
SLI01050
SLI01060
SLI01070
SLI01080
SLI01090
SLI01100
SLI01110
SLI01120
SLI01130
SLI01140
SLI01150
SLI01160
SLI01170
SLI01180
SLI01190
SLI01200
SLI01210
SLI01220
SLI01230
SLI01240
SLI01250
SLI01260
SLI01270
SLI01280
SLI01290
SLI01300
SLI01310
SLI01320
SLI01330
SLI01340
SLI01350
SLI01360
SLI01370
SLI01380
SLI01390
SLI01400
SLI01410
SLI01420
SLI01430
SLI01440
SLI01450
SLI01460
SLI01470
SLI01480
SLI01490
SLI01500
SLI01510
SLI01520
SLI01530
SLI01540
SLI01550
SLI01560
SLI01570
SLI01580
SLI01590
SLI01600

```

```

      DO 35 J = 1,NDIM
      XX = XX + EIGVCC(J,I) * EIGVCC(J,I)
C
      XX = SQRT(XX)
C
      DO 40 J = 1,NDIM
      40 BETC(I,J) = EIGVCC(J,I)/XX
C
      45 CONTINUE
C
C
C *** PRNTL PRINTS OUT MATRICES WITH THEIR DIMENSIONS
C      AND TITLES
C
      CALL PRNTL(EGVALC,NDIM,1,LG1,28)
C
      CALL PRNTL(BETC,NDIM,NDIM,LG2,52)
C
      RETURN
C
C *** ERROR MESSAGES AND ERROR ABENDS FOLLOW
C
      96 WRITE (6,500) I,NT
      STOP
C
      97 WRITE (6,501) NT,I,KSEL(I),NSEL(I)
      STOP
C
      98 WRITE (6,502) NT,NDIM,NDT,NPAR,MDIM,MDT,MPAR
      STOP
C
      99 WRITE (6,503) NT
      STOP
C
      200 FORMAT (20A4)
C
      300 FORMAT ('1 DIMENSION OF CORRELATION MATRICES, ETC =',I5/
      A' DATE OF DATA BASES USED IN COVAR',4I6/
      B' DIMENSIONS OF VALUES DATA BASE 1 USED IN COVAR',3I8/
      C' NUMBER OF PARAMETERS PRESENT ON DATA BASES USED IN COVAR',I4//
      D 20X,'TITLE OF DATA SET'/
      E (5X,20A4))
C
      500 FORMAT ('0 PARAMETER',I4,' DOES NOT HAVE THE SAME TITLE ON FILE',
      A I3,' AND THE STANDARDS FILE 21')
      501 FORMAT ('0 ERROR ON FILE',I3,' SELECTION CRITERIA I =',
      A ,I5,'. KSEL(I) =',I5,' IS NOT EQUAL TO NSEL(I) =',I5/
      B 5X,' ON STANDARDS FILE 21')
      502 FORMAT ('0 ON FILE',I3,' EITHER THE DIMENSION OF THE COVARIANCE MAT
      RIX, DATES OF FILE UPDATE OR',5X,' THE NUMBER OF PARAMETERS ON THE
      B DATA BASE DO NOT MATCH THOSE ON THE STANDARDS FILE 21'/
      C '0',I5X,' DIMENSION DATES',I5X,' NUMBER OF PARAMETERS'/
      D' FILE 21',5X,I5,8X,I3,I6,10X,I5/
      E' INPUT FILE',5X,I5,8X,I3,I6,10X,I5)
      503 FORMAT ('0 UNEXPECTED END OF FILE REACHED ON FILE',I3)
C
      END

```

SLI01610
 SLI01620
 SLI01630
 SLI01640
 SLI01650
 SLI01660
 SLI01670
 SLI01680
 SLI01690
 SLI01700
 SLI01710
 SLI01720
 SLI01730
 SLI01740
 SLI01750
 SLI01760
 SLI01770
 SLI01780
 SLI01790
 SLI01800
 SLI01810
 SLI01820
 SLI01830
 SLI01840
 SLI01850
 SLI01860
 SLI01870
 SLI01880
 SLI01890
 SLI01900
 SLI01910
 SLI01920
 SLI01930
 SLI01940
 SLI01950
 SLI01960
 SLI01970
 SLI01980
 SLI01990
 SLI02000
 SLI02010
 SLI02020
 SLI02030
 SLI02040
 SLI02050
 SLI02060
 SLI02070
 SLI02080
 SLI02090
 SLI02100
 SLI02110
 SLI02120
 SLI02130
 SLI02140
 SLI02150
 SLI02160
 SLI02170
 SLI02180
 SLI02190
 SLI02200

C.4 PRNTL

```

C *****PRN00010
C PROGRAM NAME - LIKE - LIKELIHOOD EVALUATION PROGRAMPRN00020
C ROUTINE NAME - PRNTL TASC PROGRAM NO - 521PRN00030
C *****PRN00040
C .....PRN00050
C .....PRN00060
C .....PRN00070
C .....PRN00080
C .....PRN00090
C .....PRN00100
C .....PRN00110
C .....PRN00120
C .....PRN00130
C .....PRN00140
C .....PRN00150
C .....PRN00160
C .....PRN00170
C .....PRN00180
C .....PRN00190
C .....PRN00200
C .....PRN00210
C .....PRN00220
C .....PRN00230
C .....PRN00240
C .....PRN00250
C .....PRN00260
C .....PRN00270
C .....PRN00280
C .....PRN00290
C .....PRN00300
C .....PRN00310
C .....PRN00320
C .....PRN00330
C *****PRN00340
C SUBROUTINE PRNTL (ARRAY,N,M,LG,NLG)PRN00350
C LOGICAL*1 LG(1)PRN00360
C DIMENSION ARRAY(N,M)PRN00370
C WRITE (6,300) N,M,(LG(I),I=1,NLG)PRN00380
C DO 20 I = 1,NPRN00390
C WRITE (6,302) I,(ARRAY(I,J),J=1,M)PRN00400
C 20 CONTINUEPRN00410
C 300 FORMAT ('0DIMENSIONS ',2I5,5X,60A1)PRN00420
C 302 FORMAT (1X,I2,1P10E13.3/(3X,10E13.3))PRN00430
C RETURNPRN00440
C ENDPRN00450
C .....PRN00460
C .....PRN00470
C .....PRN00480
C .....PRN00490
C .....PRN00500
C .....PRN00510
C .....PRN00520
C .....PRN00530
C .....PRN00540

```


APPENDIX D
SAMPLE EXECUTION OF HYPOTHESIS TESTING PROGRAM

DIMENSION OF CORRELATION MATRICES.ETC = 4
DATE OF DATA BASES USED IN COVAR 5 31 78 1070
DIMENSIONS OF VALUES DATA BASE 1 USED IN COVAR 91 87 7917
NUMBER OF PARAMETERS PRESENT ON DATA BASE USED IN COVAR 100
VALUES OF VARIOUS INDICATORS READ FROM FILE 31 DATA BASE 1 VALUES
DATE OF DATA BASE 1 VALUES USED 5 31 78 1070
DIMENSIONS OF DATA BASE USED 91 87 7917
NUMBER OF PARAMETERS PRESENT ON DATA BASE 100
INDICES INPUT FOR LIKELIHOOD RATIO COMPUTATION:
AVERAGE RELEASED STRAIN - 16 KM RAD.
LENGTH OF LINEARS (45 - 50 DEGS) - 16 KM RAD.
LENGTH OF LINEARS (110 - 115 DEGS) - 16 KM RAD.
TOTAL LENGTH OF LINEARS - 8 KM RAD.
TERMS INCLUDED IN LIKELIHOOD SUMATION

I	NSELA	NSELB
1	1	1
2	1	1
3	1	1
4	1	1

DIMENSION OF CORRELATION MATRICES, ETC = 4
DATE OF DATA BASES USED IN COVAR 5 31 78 1070
DIMENSIONS OF VALUES DATA BASE 1 USED IN COVAR 91 87 7917
NUMBER OF PARAMETERS PRESENT ON DATA BASES USED IN COVAR 100

TITLE OF DATA SET
GEOTHERMAL DATA FOR GRIDDED LOCATIONS INSIDE STATE OF NEVADA
VALUES OVER 1.E65 ARE NOT USED

DIMENSIONS 4 1 EIGEN VALUES FOR DATA BASE 1
1 1.238E 00
2 1.013E 00
3 9.658E-01
4 7.833E-01

DIMENSIONS 4 4 TRANSPOSE OF THE EIGEN VECTOR MATRIX FOR DATA BASE 1
1 -3.583E-01 -2.807E-01 -5.785E-01 -6.765E-01
2 6.275E-02 -8.850E-01 4.577E-01 -5.740E-02
3 9.288E-01 -7.609E-02 -3.000E-01 -2.037E-01
4 7.051E-02 3.635E-01 6.049E-01 -7.050E-01

DIMENSION OF CORRELATION MATRICES.ETC = 4
DATE OF DATA BASES USED IN COVAR 5 31 78 1070
DIMENSIONS OF VALUES DATA BASE 1 USED IN COVAR 91 87 7917
NUMBER OF PARAMETERS PRESENT ON DATA BASES USED IN COVAR 100

TITLE OF DATA SET
GEOTHERMAL DATA FOR HOT SPRINGS LOCATIONS
THESE ARE LOCATED IN NEVADA

DIMENSIONS 4 1 EIGEN VALUES FOR DATA BASE 2
1 1.531E 00
2 1.047E 00
3 7.753E-01
4 6.472E-01

DIMENSIONS 4 4 TRANSPOSE OF THE EIGEN VECTOR MATRIX FOR DATA BASE 2
1 -6.071E-01 5.095E-01 2.778E-01 5.429E-01
2 1.256E-01 5.155E-01 -8.437E-01 8.810E-02
3 -4.028E-01 3.673E-01 7.734E-02 -8.348E-01
4 -6.733E-01 -5.829E-01 -4.540E-01 2.640E-02

APPENDIX E
DESCRIPTION OF THE DELIVERABLE TAPE

The deliverable tape contains the following six files.

- File 1 - Value file (Data Base 1)
- File 2 - Average file (Data Base 1)
- File 3 - Value file (Data Base 2)
- File 4 - Average file (Data Base 2)
- File 5 - Program COVAR with all of its subroutines
- File 6 - Program LIKE with all of its subroutines

The tape is an unlabeled (NL) tape written in 9-track format at 1600 bpi. The DCB characteristics for each file are as follows:

	<u>RECFM</u>	<u>LRECL</u>	<u>BLKSIZE</u>
File 1	FB	400	32000
File 2	FB	400	8000
File 3	FB	400	8000
File 4	FB	400	8000
File 5	FB	80	32000
File 6	FB	80	32000

APPENDIX F
JOB CONTROL STATEMENTS

The following JCL statements provide a sample case.

```
//JOBNAME JOB J809.GPB.CLASS=B.TIME=5
//COVAR EXEC FORTGCG
//FORT.SYSIN DD UNIT=TAPE9,
// LABEL=(5,NL),VOL=SER=491,DISP=(OLD,PASS),
// DCB=(RECFM=FB,LRECL=80,BLKSIZE=32000)
// * UNIT 31 IS VALUE FILE FOR DATA BASE 1
//GO.FT31F001 DD UNIT=TAPE9,
// LABEL=(1,NL,IN),VOL=SER=491,DISP=(OLD,PASS),
// DCB=(RECFM=FB,LRECL=400,BLKSIZE=32000)
// * UNIT 32 IS AVERAGE FILE FOR DATA BASE 1
//GO.FT32F001 DD UNIT=AF=FT31F001,
// LABEL=(2,NL,IN),VOL=SER=491,DISP=(OLD,PASS),
// DCB=(RECFM=FB,LRECL=400,BLKSIZE=8000)
// * UNIT 33 IS VALUE FILE FOR DATA BASE 2
//GO.FT33F001 DD UNIT=AF=FT31F001,
// LABEL=(3,NL,IN),VOL=SER=491,DISP=(OLD,PASS),
// DCB=(RECFM=FB,LRECL=400,BLKSIZE=8000)
// * UNIT 34 IS AVERAGE FILE FOR DATA BASE 2
//GO.FT34F001 DD UNIT=AF=FT31F001,
// LABEL=(4,NL,IN),VOL=SER=491,DISP=OLD,
// DCB=(RECFM=FB,LRECL=400,BLKSIZE=8000)
// * UNIT 21 IS THE INTERFACE BETWEEN COVAR AND LIKE FOR DATA BASE 1
//GO.FT21F001 DD DSN=J809.COVRA,
// SPACE=(CYL,(1,1)),DISP=(NEW,CATLG),UNIT=SYSDA,
// DCB=(RECFM=FB,LRECL=80,BLKSIZE=4000)
// * UNIT 22 IS THE INTERFACE BETWEEN COVAR AND LIKE FOR DATA BASE 2
//GO.FT22F001 DD DSN=J809.COVRA,
// SPACE=(CYL,(1,1)),DISP=(NEW,CATLG),UNIT=SYSDA,
// DCB=(RECFM=FB,LRECL=80,BLKSIZE=4000)
// * UNIT 5 IS CARD READER FOR SELECTION VECTOR
//GO.FT05F001 DD *
//DATA SEL=4.25.28.35 &END
//
//
```

```

//JOBNAME JOB J809.GPB.CLASS=B.TIME=5
//LIKE EXEC FORTGCC
//FORT.SYSIN DD UNIT=TAPE9.
// LABEL=(6,NL),VOL=SER=491,DISP=(OLD,PASS),
// DCB=(RECFM=FB,LRECL=80,BLKSIZE=32000)
//* UNIT 31 IS VALUE FILE FOR DATA BASE 1
//GO.FT31F001 DD UNIT=TAPE9.
// LABEL=(1,NL,,IN),VOL=SER=491,DISP=OLD,
// DCB=(RECFM=FB,LRECL=400,BLKSIZE=32000)
//* UNIT 21 IS THE INTERFACE BETWEEN COVAR AND LIKE FOR DATA BASE 1
//GO.FT21F001 DD DSN=J809.COVRA,DISP=SHR
//* UNIT 22 IS THE INTERFACE BETWEEN COVAR AND LIKE FOR DATA BASE 2
//GO.FT22F001 DD DSN=J809.COVRB,DISP=SHR
//* UNIT 10 IS THE FILE OF LIKELIHOOD VALUES
//GO.FT10F001 DD DSN=J809.LIKE,
// SPACE=(CYL,(1,1)),UNIT=SYSDA,DISP=(NEW,CATLG),
// DCB=(RECFM=FB,LRECL=400,BLKSIZE=8000)
//* UNIT 5 IS THE CARD INPUT FOR THE COLUMN SELECTION VECTORS
//FT05F001 DD *
CADATA
NSELA=4*1,46*0.
NSELB=4*1,46*0
CEND
/*
//

```