LBL--32063

DE93 001536

SAN JOAQUIN - TULARE CONJUNCTIVE USE MODEL

Detailed Model Description

Nigel W.T. Quinn

Earth Sciences Division
Lawrence Berkeley Laboratory
University of California
Berkeley, California 94720

March 1992

This work was supported in part by the US Bureau of Reclamation, under U.S. Department of the Interior Interagency Agreement No. 0-AA-20-09410, through U.S. Department of Energy Contract No. DE-AC03-76SF00098.

MASTER
DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

Abstract

The San Joaquin - Tulare Conjunctive Use Model (SANTUCM) was originally developed for the San Joaquin Valley Drainage Program to evaluate possible scenarios for long-term management of drainage and drainage - related problems in the western San Joaquin Valley of California. A unique aspect of this model is its coupling of a surface water delivery and reservoir operations model with a regional groundwater model. The model also performs salinity balances along the tributaries and along the main stem of the San Joaquin River to allow assessment of compliance with State Water Resources Control Board water quality objectives for the San Joaquin River.

This document is a detailed description of the various subroutines, variables and parameters used in the model and complements the review document "Evaluation and Suggestions for Further Development of the San Joaquin-Tulare Conjunctive Use Model (SANTUCM)" by Tabios, Quinn, Shen and Zhao. Version 1.0 of the SANTUCM model was provided to the research team at UC Berkeley and LBL by Dr Alireza Taghavi, formerly of Boyle Engineering Corporation.

TABLE OF CONTENTS

	Page
1. General description and study objectives	6
1.1 Overview	6
1.2 General description of SANTUCM	6
1.2.1 Tulare operations module	9
1.2.2 Millerton operations module	10
1.2.3 Salinity Model	12
1.3 Variable definitions	12
1.4 Abbreviations	12
1.5 Linkage parameter files	13
1.5.1 .INC files	13
1.5.2 .CMN files	13
1.5.3 .BLK files	13
1.6 Groundwater Model parameter files	14
1.6.1 .INC files	14
1.6.2 .CMN files	14
1.6.3 .BLK files	14
1.7 Surface Water Model parameter files	23
1.7.1 .INC files	23
1.7.2 .CMN files	23
1.7.3 .BLK files	28
1.8 Output routines	29
1.8.1 .INC files	29
1.8.2 .CMN files	29
1.8.3 .BLK files	29
1.9 Salt Model parameter Files	30
1.9.1 .INC files	30
1.9.2 .CMN files	30
1.9.3 .BLK files	30
1.10 Binary switches	31
2. Flowcharts and variable descriptions by subroutine	32
2.1 Main program and linkage subroutines	32
2.1.1 TULARE.for (main)	32
2.1.2 SGTRANS.for (linkage)	35
2.2 Groundwater model subroutines - PASS1	37
2.2.1 GW1.for	37
2.2.2 GETG.for	40
2.2.3 NDFG.for	43
2.2.4 ELEM.for	45

2.2.5	WLOCA.for	46
2.2.6	TIMDAT.for	49
2.2.7	SKIP.for	50
2.2.8	IOSUB.for	51
2.3	Groundwater model subroutines - PASS2	52
2.3.1	GW21.for	52
2.3.2	GW22.for	55
2.3.3	GETGD.for	57
2.3.4	INITI.for	61
2.3.5	GENER.for	66
2.3.6	GETQ.for	68
2.3.7	SURFL.for	71
2.3.8	BOUND.for	73
2.3.9	ASIGNP.for	75
2.3.10	RIVER.for	76
2.3.11	CONE2.for	79
2.4	Groundwater model : solver subroutine	81
2.4.1	SOLVE.for	81
2.5	Groundwater model : output subroutines	83
2.5.1	OUTC.for	83
2.5.2	OUTPH.for	85
2.5.3	OUTPQ.for	86
2.5.4	OUTPV.for	88
2.5.5	IOSUB.for	89
2.5.6	SKIP.for	89
2.6	Surface water model subroutines	90
2.6.1	SURFINP.for	90
2.6.2	SURFACE.for (main and internal)	95
2.6.3	SJROUTE.for	100
2.6.4	TLROUTE.for	103
2.6.4.1	tlroute	103
2.6.4.2	tsource	105
2.6.4.3	tlnode	106
2.6.5	CSROUTE.for	108
2.6.6	MOD1.for	110
2.6.6.1	resvr	110
2.6.6.2	snowmlt	111
2.6.6.3	smaray	112
2.6.6.4	sannode	113
2.6.6.5	realloc	115
2.6.6.6	floadj	116
2.6.7	MOD2.for	117
2.6.7.1	spcall	117
2.6.7.2	space	118
2.6.7.3	vsrta	119
2.6.7.4	pumpmax	120
2.6.7.5	cvpdel	121
2.6.7.6	fwpars	122
2.6.7.7	fwintp	124
2.6.7.8	goodwin	125

2.6.8	MOD3.for	127
2.6.8.1	milflod	127
2.6.8.2	mildelv	128
2.6.8.3	wq	130
2.6.8.4	initial	131
2.6.8.5	skipln	131
2.6.8.6	ndchek1	131
2.6.8.7	ndchek2	131
2.6.8.8	zero2	132
2.6.8.9	zero1	132
2.6.8.10	izero1	132
2.6.8.11	area	133
2.7	Model output subroutines	134
2.7.1	SURFWRITE.for	134
2.7.1.1	wrtonce	134
2.7.1.2	sltonce	137
2.7.1.3	writtim	138
2.7.1.4	saltim	140
2.7.2	WRITE.for	141
2.7.2.1	writonce	141
2.7.2.2	writtime	144
2.8	Balance sheet : BALSHEET.for	146
2.8.1.	TUOL.for	148
2.8.2	MERC.for	149
2.8.3	SJKN.for	150
2.8.4	KTCK.for	152
2.8.5	CAST.for	153
2.8.6	TDAU.for	154
2.8.7	BSUB.for	155
2.9	Post-processor : SANVAR.for	157
2.9.1	CALCX1	159
2.10	Salinity model	160
2.10.1	SALT.for	160
3.0	Model status	163
4.0	References	164

Acknowledgements

This document was produced for the US Bureau of Reclamation (USBR), MP-710, resulting from an initiative within Reclamation to maintain and more fully understand the decision support tools being used to make planning decisions. I would like to thank Susan Hoffman and Bob Edwards of the USBR for funding this effort and Derek Hilts for his diligence in reviewing the first draft of this document and his efforts as COTR on this project. I also wish to thank Glen Tabios at UC Berkeley for his helpful suggestions and Sally Benson, Lawrence Berkeley Laboratory for initiating the project and managing the USBR contract. My appreciation also to both Glen Tabios and Sally Benson for their review comments.

This work was supported in part by the US Bureau of Reclamation, under U.S. Department of the Interior Interagency Agreement No. 0-AA-20-09410, through U.S. Department of Energy Contract No. DE-AC03-76SF00098.

SAN JOAQUIN - TULARE CONJUNCTIVE USE MODEL

1.1. Overview

SANTUCM is a linked surface water - groundwater, hydrosalinity model which simulates reservoir operations and surface - groundwater interactions on a monthly timestep. The current model is an extension of previous U.S. Bureau of Reclamation models and was developed by Boyle Engineering Corporation and Water Resources Management Inc. while under contract to the San Joaquin Valley Drainage Program. The purpose of this document is to aid comprehension of the model code. The document is organized into two parts as follows :

- o Overview and general description
- o Flowcharts and variable descriptions by subroutine
 - Linkage subroutines
 - Ground water model subroutines
 - Surface water model subroutines
 - Salinity model subroutines

A supplementary document has been prepared by Tabios et al. (1992), which reviews and evaluates the SANTUCM model and makes suggestions for improvements to the existing model.

1.2 General description of SANTUCM

SANTUCM comprises three separate models: a surface water model; a groundwater model; and a salinity model. The surface water model is similar to the San Joaquin Area Simulation Model (SANJASM), with the addition of computer code that links the surface water model to the groundwater model. The surface water and groundwater models are coupled and can be run separately or conjunctively as linked models. The salinity model utilises output from the surface water model in order to perform mass balance calculations of salinity levels in the San Joaquin River. Another difference between SANTUCM and

SANJASM is that SANTUCM covers a greater geographic area, simulating surface and subsurface hydrology in both the San Joaquin and Tulare basins.

Surface water flows into the Tulare Basin originate from seven primary sources: the King's, Kaweah, Tule, and Kern rivers, the Delta-Mendota Canal, the California Aqueduct and the Friant-Kern Canal. Flow diversions or reservoir spills transported by King's River and that can be accommodated within the James By-Pass, flow north into the San Joaquin River at Mendota Pool. Operational spills that exceed the capacity of the James By-Pass flow to the Tulare Lake bed, together with spills from the Kaweah, Tule, and Kern rivers.

The Delta Mendota Canal (DMC) and California Aqueduct (CAQ), originate in the San Francisco Bay Delta and provide much of the irrigation water used on the west side of the San Joaquin Valley and in the Tulare Basin. The Friant-Kern Canal (FKC) delivers water from Millerton Lake to users along the foothills of the eastern slope of the Sierra. The Cross Valley Canal (CVC) is the other major surface water conveyance structure in the San Joaquin Valley which transports water from the Aqueduct to users along the eastern slope of the Sierra Nevada mountain range.

There are four main reservoirs in use in the area: Pine Flat Lake, Kaweah Lake, Lake Success and Lake Isabella (on King's, Kaweah, Tule and Kern rivers, respectively). These reservoirs are owned and operated by numerous agencies, with many provisions for banking and delivery of water upon demand. This type of operation is difficult to codify and almost impossible to describe using generalized rules or algorithms. Hence, Tulare basin reservoir operations were not simulated by the developers of the model. The reservoir file contains no rule or storage-area-elevation data for these reservoirs.

Inflows for the four rivers into the Basin are based on the historical outflows from the four reservoirs. Inflow into the DMC and the CAQ comes from PROSIM output. Inflow into the Friant Kern Canal is computed in the model according to criteria set by the US Bureau of Reclamation. These take into account Class 1, Class 2 (long term) and Class 2 (short term) flows.

The nodes in the Tulare basin portion of the model (south of the area included in the SANJASM model) are primarily of two types: junction nodes and Detailed Analysis Units (DAUs), where irrigation water is consumptively used. The nodes that are designated DAUs are labelled using the DAU number, except for DAU 216, which is divided into three subareas and labelled 216-1, 216-2

SAN JOAQUIN - TULARE CONJUNCTIVE USE MODEL

SURFACE WATER MODEL NETWORK

Figure 1. Schematic of SANTUCM

Figure 2. Schematic of the groundwater model finite element network

and 216-3. Other types of nodes used within the model are shown in Figure 1. These include non-DAU demand nodes, PROSIM nodes (linkage nodes to the PROSIM model) and reservoirs.

The Tulare is modeled as a series of sources and sinks, where the sinks are the DAUs. The sources are:

- 1) Friant-Kern Canal,
- 2) King's River,
- 3) Kaweah River,
- 4) Tule River,
- 5) Kern River,
- 6) PROSIM nodes 45 and 46,
- 7) PROSIM node 47,
- 8) PROSIM node 32,
- 9) PROSIM node 35,
- 10) PROSIM node 36,
- 11) Cross Valley Canal (PROSIM node 37), and
- 12) PROSIM node 38.

The Friant-Kern Canal (FKC) source is handled somewhat differently than the others. Each March, the volume of Class 1 and 2 water to be released from Millerton for the year (March through the following February) is computed. A percentage of this water flows down the Madera Canal, with the remainder flowing down the FKC. The Class 2 FKC water is further split into long- and short-term flows based on the four river index. The four river index is the sum of the April through July inflows to Millerton, Exchequer, Don Pedro and New Melones. These designated annual flow volumes are then distributed among the sinks (diversion points) that obtain water from the FKC and further distributed by month to determine monthly surface water deliveries to each Detailed Analysis Unit (DAU).

For many of the FKC-supplied DAUs along King's, Kaweah, Tule and Kern rivers, the FKC water is diverted into the rivers, and the diversions are then taken from the rivers. This is the case for DAUs 233, 236, 238, 241, 242, 243, 254, and 256-258. Note that half of the FKC diversion to DAU 242 is taken directly from the FKC and half from the Kaweah River. The remainder of

Figure 3. Hydrologic mass balances performed in SANTUCM

the sources obtain water on a monthly basis. Monthly inflows from each source are read in as input data. The diversion from a source to each DAU is computed based on the percentage of the source flow going to that DAU and the year type (wet, normal or dry).

1.2.1 Tulare operations module

In the Tulare portion of the model reservoir operations are substantially different from those in the San Joaquin area. In the San Joaquin area, reservoirs are operated according to some set rules, and releases computed. Then additional releases are made if needed to satisfy downstream requirements.

While the reservoir operations in the San Joaquin tend to be serial in nature, the Tulare operations tend to be parallel. The Tulare Basin is more heavily interconnected by canals and water exchanges, which make it far more complex than the San Joaquin area. Except for the King's River, any spills from the rivers in the Tulare basin end up in Tulare Lake and are lost to the atmosphere through evaporation.

Subroutine TLROUTE is called from subroutine SJROUTE. First TLROUTE sets diversions from each source to each sink. One of the input items in the Tulare Basin data file (currently named TULBASIN.DAT) is a table of source node numbers and the corresponding sink node numbers that obtain water from that source node. Also included in this data set are the distribution (percent) of flow from a source to a particular sink node.

Subroutine TSOURCE is called for all source nodes to set the diversions, except for the source nodes representing the Friant-Kern Canal. For each month and year-type the diversion is calculated as the flow from the source multiplied by the percentage of the flow diverted to a given sink. The total surface deliveries (SDELV) from all sources to a sink are summed and this nodal value is used in subroutine TULNODE and in the surface water balance subroutines. Flows leaving each Tulare surface water node (non-sinks) are also computed and subroutine TULNODE is called, which uses the surface water deliveries to compute the amount of agricultural (AG.) and municipal and industrial (M&I) use. (In the Tulare Basin the majority of usage is agricultural). Deliveries are split between AG. and M&I based on the ratio of AG. and M&I demands in the input data. If surface water deliveries don't meet the demands, groundwater is used up to a certain maximum allowable safe yield

in order to meet the remaining demands. If the annual safe yield from groundwater pumping is exceeded a shortage is declared and the amount of shortage calculated by the model.

1.2.2 Millerton operations module

Some revisions were made to subroutine MILDELV in module MOD3.for to permit the accounting of Friant-Kern Canal exports. Class 1 and 2 exports are and divided between the Madera and Friant-Kern canals. Then the FKC Class 2 exports are divided further into long- and short-term exports. This division is based on a regression equation, developed by Boyle Engineering Corp, which uses the four river index (April through July inflows to Millerton, Exchequer, Don Pedro, and New Melones) as an independent variable. These three annual volumes (Class1, Class 2L and Class 2S) are then divided among the sinks that obtain water from the FKC, based on the percentage of each of the three volumes allocated to each DAU. These annual volumes for each DAU are then summed to obtain a single annual delivery volume to each DAU. The annual volumes for each DAU are then divided into monthly volumes using the percentage of annual flow for that sink for the month in question. The percentages used to divide the FKC flows spatially and temporally are all specified in the input data.

1.2.3 Salinity model

The salt model takes input from three files. The control file (Table 4) contains file names and years and nodes for which output is desired. The salt data file (Table 5) contains initial salt concentrations for each reservoir, inflow, gain, return and groundwater flow. The salt model also reads all the flow data that it needs from the binary file, which is written by the flow model for use with the salt model.

The salt model works as follows: Each flow variable (streamflow, inflow, gain, return, import or groundwater pumping) has a corresponding salt concentration (parts per million or ppm). At each node, the salt flux (flow times concentration, expressed in tons) is computed for each source of inflow to that node. These fluxes are summed and divided by the summed flows to get a concentration of salt leaving the node. The concentration of water diverted to the users for that node, or "applied" in the terminology of the program, is

SANTUCM

Figure 4. Input - output flowchart of SANTUCM

SANTUCM

Figure 5.1 SANTUCM input file description

SANTUCM

Figure 5.2 SANTUCM input file description (cont.)

assumed to be the concentration of the flow leaving the node. This assumes perfect mixing in each node, including the reservoirs.

Monthly values of the initial salinity concentrations at the surface water model nodes are read from a salt data file. A single annual salinity value is assumed for each of the reservoirs on the surface water model network. The salinity of groundwater pumpage is obtained from the input file if the groundwater model is not used. If the groundwater model is used, groundwater concentrations are obtained from the linkage subroutines that transfer information between the surface and groundwater models.

1.3 Variable definitions

- o Variable definitions are grouped by common block.
- o Array dimensions are shown as (,).
- o All flows are in thousands of acre feet (KAF) unless otherwise noted.
- o Input variable declarations may be real or integer except for those variables which assume the standard FORTRAN defaults.
- o "Project demands" refer to demands that may use withdrawals from reservoir storage. This includes CVP demand areas, as well as other areas such as Merced, Modesto, Turlock, Oakdale, South San Joaquin, City of Stockton, City of San Francisco.

1.4 Abbreviations :

d/s	-	downstream
u/s	-	upstream
GW	-	groundwater
FW	-	fish and wildlife
M&I	-	municipal and industrial demands
DMC	-	Delta Mendota Canal
CAQ	-	California Aqueduct
FKC	-	Friant-Kern Canal
DAU	-	Detailed Analysis Unit
conc.	-	TDS concentration in ppm

1.5 Linkage Parameter Files :

1.5.1 .INC files

1.5.1.1 SGTRANS.inc

niwd	-	water district ID (district-element cross index)
nddmnd	-	surface water demand node numbers
allocs	-	fraction of surface water for each DAU allocated to the corresponding water district
allocg	-	fraction of pumped water for each DAU allocated to the corresponding water district
nbyl	-	groundwater element number
nibwd	-	water district ID (district-DAU cross index)
prcn	-	percentage of each groundwater element within each water district
dsdlv	-	total surface water delivered to district j
dgdlv	-	total ground water delivered to district j

1.5.2 .CMN files

none

1.5.3 .BLK files

none

1.6 Groundwater Model Parameter Files :

1.6.1 .INC files

none

1.6.2 .CMN files

common blocks all contained within COMM1.BLK

1.6.3 .BLK files

contains all common blocks for the groundwater model

1.6.3.1 COMM1.blk - Contains common blocks used in the groundwater model

gw1

ide	-	node number associated with element ne
nld	-	number of effective layers for each node
iud	-	index to indicate the status of a node as confined/unconfined or ineffective
itd	-	node number of aquifer below
njd	-	cumulative number of nodes surrounding each node
jnd	-	node numbers surrounding a node
ise	-	index indicating position of the stiffness matrix elements in the array AT
iprnt	-	groundwater node number for which heads are printed
iouth	-	node at which a groundwater hydrograph is to be printed
iouthl	-	layer number for which a groundwater hydrograph is to be printed
ioutr	-	river node to be printed in hydrograph output

gw2

x	-	x co-ordinate of each groundwater node location
y	-	y co-ordinate of each groundwater node location
elg	-	ground surface elevation for each groundwater node
dh	-	bedrock elevation
dht	-	top elevation of the aquifer for each GW node
sd	-	area associated with each groundwater node
se	-	area of each groundwater element
vbase	-	bedrock leakage term for layer (j)
krsta	-	rainfall station identifier

gw3

xwell	-	x coordinate of well location
ywell	-	y coordinate of well location
rwell	-	well radius
cwell	-	well capacity (gals/min)
perft	-	top of well screen perforations
perfb	-	wetted perimeter (ft) at HRTB water surface elevation
perfi	-	adjusted well perforation interval (partial penetrating well)
pwel	-	distribution coefficient to allocate pumpage to each node
cwd	-	effective well capacity at each node
idwd	-	node index (set equal to id)
nwd	-	number of wells assigned to a node
fwd	-	not used
erwr	-	effective radius of node / radius of well

erdw	-	effective radius of a well
cone	-	final drawdown at the well
iwd	-	node label for nodes with pumping assigned set equal to iwl*(10+i)
iwell	-	element number assigned to the pumping well
pwe	-	effective well pumping rate
dxe	-	logarithm of the ratio $c / w(i)$: $\log(\text{aquifer thickness} / \text{thickness of aquiclude})$

gw4

ibur	-	first upstream node number
ibdr	-	last downstream node
idwn	-	not used
idr	-	groundwater node corresponding to each stream node
botr	-	elevation of stream bottom (ft) at node ID
hrtb	-	water surface elevation (ft) above BOTR
prtb	-	wetted perimeter (ft) at HRTB water surface elevation
qrtb	-	flow rates (cfs) at HRTB water surface elevation
idiv	-	bypass diversion number for each stream node
divx	-	streamflow in the bypass diversion rating table
divy	-	diversion amount in the bypass diversion rating table
irngn	-	corresponding stream node that surface water will flow to. If gw node does not flow to a stream node - enter 0
qrdiv	-	river flow diversion demand
qmind	-	minimum flow prior to diversion
ndivo	-	index indicating diversion node

gw5

condp	-	hydraulic conductivity (ft/day)
stop	-	storage coefficient (ft/ft)
sydp	-	specific yield (ft/ft)
clp	-	vertical conductivity (ft/day)
fcon	-	factor to weight conductivity values to get ft/day
fsto	-	factor to weight storage coefficient values
fsyd	-	factor to weight specific yield values
fcl	-	factor to weight vertical hydraulic conductivities of the overlying aquiclude to get ft/day
xp	-	x coordinate of node IC
yp	-	y coordinate of node ICi
dep	-	not used

gw6

cond	-	hydraulic conductivity (ft/day)
trans	-	aquifer transmissivity
as	-	specific yield of aquifer / aquifer storage coefficient
an	-	aquifer specific yield for an unconfined or confined case
clt	-	vertical leakance
clk	-	vertical leakance
cl	-	vertical hydraulic conductivity (ft/day)
trane	-	transmissivity of element
epor	-	effective porosity
ieta	-	element number
conda	-	conductivity value to overwrite element IETA for layer (ia)

gw6b

at	-	hydraulic conductivity in horizontal direction
ae	-	non-zero stiffness matrix component resulting from FEM

gw7

rco - retention capacity of element (*)
 rc - maximum available soil moisture
 pvo - fraction of element (*) that is pervious
 pv - fraction of area that is pervious to infiltration
 idrn - not used
 ilake - index for lake in each element
 slake - area of each element that is covered with water
 hlake - water surface elevation of lake
 soilr - soil moisture retained in the soil
 hbase - initial water table elevations at nodes
 rl - stream bed conductivity (ft/day)
 rlk - river leakance (if perch < 1)
 river vertical conductivity * river length for node i
 perch - thickness of streambed lining at node i (ft)
 soili - variable set equal to 25% of available soil moisture
 pirig - percentage of area associated with a node that is
 irrigated
 rcn1,2,3,4 - coefficients in the rainfall - runoff equation
 rdhn - root zone depth at a node
 cdhn - capillary rise (feet) data for node
 rechmxn - monthly recharge at an individual node (i)
 sirrtnd - percentage of applied water to return flow at an
 individual node (i)

gw8

idtpu - distribution table to be used
 icolpu - column of pumping data file to be applied at node IDPU
 fracpu - fraction of pumping from column ICOLPU which is
 agricultural water
 idpu - node where pumping occurs
 also monthly distribution table to be applied to node
 IDUP, Set equal to zero if monthly data provided
 idtwl - monthly pumping distribution table to be used for well
 IDUM. Enter 0 for monthly values
 icolwl - column number in pumping data set to be used for
 specifying amounts of pumping for each well
 fracwl - fraction used to quantify pumping or recharge for a
 single well
 qpc - volume of water pumped from a single well
 defined as $fpumo(icolwl(iwl)) * fracwl(iwl)$
 yddist - fraction of annual pumping occurring in month (j)
 dpump - not used
 fpumo - total groundwater pumped from each element
 fpuyr - pumping in the year ITPUYR for column i
 nlpu - number of nodes or elements pumping in layer (i)
 ieimp - element receiving imported water
 idtim - monthly imported water distribution table applied to
 element IEIMP, set equal to 0 if monthly data provided
 icolim - column of imported water data file applied at element
 IEIMP
 fracim - fraction of water imported
 yimdt - fraction of annual imported water occurring in month (j)
 fimmo - monthly imported water data
 fimyr - annual imported water corresponding to node at column i
 factst - conversion factor to convert discharges to cfs for the
 stream inflow (i)

fpapl	-	fraction of irrigation water applied at a node
fwapl	-	fraction of pumping from column ICOLWL to be applied at well IDUM
iyear	-	index for year type
iyrtpl	-	year type associated with each year
kgwpmpl	-	switch = 0 if pumping overwritten by surface water model
 gw10		
nqb	-	number of flux boundary nodes for each layer
iqb	-	index counter for boundary nodes
qqb	-	flux across the model boundary at a specified flux boundary node
wqb	-	totalled flux at flux boundary nodes for output water balances
fqb	-	factor for flux
nhb	-	number of constant head boundary nodes in each layer
ihb	-	node numbers for boundary nodes
qhb	-	aquifer influx or efflux due to the source/sink term
whb	-	flux due the source/sink term from layer j
fhb	-	constant to add to prescribed head boundary nodes
nmb	-	number of rating table boundary nodes in each layer
imb	-	index counter for boundary nodes
qmb	-	flux for rating table and general boundary nodes
wmb	-	boundary flux into or out of layer (j)
fmb	-	factor to change rating table and combined head flux to af/yr
hbm	-	not used
klb	-	error code for flux boundary conditions (-1,0 +1)
nmtb	-	flag ; set equal to -1 for general head boundary
hmtb	-	head in the rating table
qmtb	-	flux in the rating table
hnb	-	total flux at a boundary node
tqbi	-	total annual discharge from controlled boundary in
tqbo	-	total annual discharge from controlled boundary out
thbi	-	constant head boundary (in)
thbo	-	constant head boundary (out)
tmbi	-	total flux from head controlled boundary (in)
tmbo	-	total flux from head controlled boundary (out)
 gw11		
qpump	-	total well pumping from an element after accounting for any negative pumping p
wpump	-	groundwater pmping from an element
qrech	-	quantity of aquifer recharge to an element
wrech	-	recharge to aquifer layer for element
qsurf	-	surface water infiltration
wsurf	-	cumulative surface water infiltration at node (id) for the simulation period
qrain	-	quantity of incident rainfall in each element
wrain	-	rainfall incident on layer i at node (id)
qevap	-	evapotranspiration from each element area
wevap	-	total amount of evaporation at a node during simulation
qbase	-	discharge from bedrock at each node
wbase	-	discharge from bedrock at each node
qlake	-	flux from the lake
wlake	-	seepage to lake from layer i at node (id)
qleak	-	aquifer leakage between semiconfined and confined aquifer
wleak	-	cumulative leakage term from element idl

qr	-	river flow
wr	-	sum of flow in a reach (accumulated river flow)
qrinf	-	gain/loss at each river node in groundwater model
wrinf	-	sum of gains and losses
qrtr	-	upstream and tributary inflow for each stream node
idst	-	river node corresponding to inflow listed in column i of the stream flow data file
qstrm	-	inflow at river node IDST(i)
trech	-	total artificial aquifer recharge specified by user
tpump	-	total groundwater pumping
t leak	-	total annual leakage between aquifers
qaply	-	irrigation applied water at a node
waply	-	irrigation applied water to layer i at node (id)
qevsl	-	not used
vole	-	storage volume of element for layer il of element le
headelm	-	average head for each element (array)

gw12

dtpu	-	not used
dtre	-	not used
dtrn	-	rainfall for month (imo)
dtst	-	not used
dtev	-	potential evapotranspiration
rain	-	not used
title	-	title to be printed on all output

gw13

hp	-	variable set equal to hn, groundwater head at each node
hn	-	groundwater head at each groundwater node
qd	-	source/sink term (pumping etc.)
w	-	id for layer (idl)
	-	constant to add to initial condition data for layer 1,2
wa	-	temporary variable
wb	-	temporary variable
wc	-	temporary variable
wx	-	temporary variable
ibh	-	index variable used as a counter
qb	-	not used

col

koutg	-	switch to print geometric data
kout	-	switch to control output
kdeb	-	1 - to print debugging data : 0 - no print out
kwell	-	switch to use wells, input
krain	-	switch to use rainfall
kstr	-	switch to use stream data
klake	-	number of elements with lakes, input
kbase	-	switch to use constant head in bedrock
initm	-	first month of simulation
lastm	-	ending date of the simulation (years/months)
deltm	-	simulation time steps in months
iyra	-	first year of detailed simulation
lyra	-	year to end detailed simulation
imoa	-	first month of detailed simulation
lmoa	-	last year of detailed simulation
ndya	-	number of days in each detailed simulation
delta	-	time step in hours for the detailed simulation
mrwth	-	months between print of heads

mwrtd	-	months between print of water balance
mwrtd	-	control for print of detailed discharge data
mwrta	-	number of detailed simulation outputs
mpcx	-	number of sequential print control pairs
mpcy	-	number of non-sequential print control pairs
lpc	-	0 to print heads for all layers
king	-	temporary variable : set equal to unit number
koutp	-	switch to control plotter output
ndpu	-	number of nodes or elements pumping in a layer = nlpu
ndst	-	number of stream nodes where water enters the system
npuyr	-	number of nodes with pumping
npumo	-	number of columns of monthly pumping data
ktpu	-	dummy variable used in pumping data input file
ktst	-	not used
ktrn	-	initial month of data
itpuyr	-	year of pumping records
itpumo	-	year and month of pumping (Sep 1980 = 198009)
itst	-	year and month of stream inflow
itrn	-	year of rainfall
ntyc	-	not used
ntyd	-	number of monthly pumping distribution tables to be provided
nyyd	-	not used
kpuyr	-	variable counter for number of years in pumping file
kpumo	-	variable counter for number of months in pumping file
kimp	-	switch to use imported water
ndtim	-	number of monthly imported water distribution tables
neimp	-	number of elements receiving imported water
nimmno	-	number of different imported monthly values
nimyr	-	number of annual imported water values (columns)
kimmo	-	monthly counter for imported water data input
kimyr	-	annual counter for imported water data input
itmmo	-	not used
itmyr	-	not used
iin	-	decision variable ; set to 20 at beginning of subroutine
iou	-	unit number used in output control
kouth	-	switch to control head output
ktim	-	first month of imported water data
nskip	-	number of lines to skip
koutr	-	switch to print river nodes as hydrograph output
iwrtd	-	temporary variable set equal to mwrtd
iwrth	-	counter for the months at which to write water budgets
kaply	-	switch to use irrigation applied water data
itimmo	-	month of monthly imported data
itimyr	-	year of annual imported water data
kpmp	-	switch to use pumping
kplot	-	switch to control plot output
kyplot	-	not used
kgwsalt	-	flag set to 1 if the salt model is being used

co2

nd	-	number of nodes
ne	-	number of elements
nl	-	number of layers
ndl	-	array storage variable (maximum dimension) = nd * nl
ndb	-	set equal to nd + 1
ne4	-	number of elements multiplied by 4
ns	-	number of nodes surrounding elementsneta

nsh	-	defined as ns/2
na	-	not used
nj	-	sum of the number of nodes surrounding each G_n nodenr
nrh	-	number of reaches
ndiv	-	dummy variable not previously used
nrnt	-	not used
ndnt	-	not used
nwell	-	number of wells simulated in the system
nwell4	-	nwell multiplied by 4
nwell6	-	nwell multiplied by 6
nwenl4	-	nwell multiplied by 4 and by nl (number of layers)
nxe	-	set equal to irdr (counter for number of pumping wells)
nrwr	-	loop counter for wells with effective radius of pumping assigned to a given node
nrdr	-	loop counter for wells with effective radius of pumping assigned to a given node
ntr	-	not used
nrtb	-	number of data points with a diversion
ndtb	-	number of data points indicating a diversion
nthb	-	number of boundary nodes where constant heads specified
ntqb	-	number of boundary nodes where the constant fluxes are specified
ntmb	-	number of boundary nodes where the relationship between head and flux is specified
ndp	-	number of nodes in the parameter grid
nep	-	number of elements in the parameter grid
ndwd	-	total number of nodes with associated wells
nel	-	product of ne and nl (layers * elements)
ndla	-	temporary variable set equal to nd * (nl - 1)
nyr	-	number of years in the table
lph	-	switch to print head output (lph=0) matrix format (lph=1)

co3

factxd	-	map scaling factor for node coordinates
factwx	-	scaling factor for x and y locations
factpm	-	factor to change pumping rate to cubic ft/ month
factpy	-	conversion factor 1000 acre-ft to cubic ft/month
factr	-	conversion factor : divides area by 12 and timestep deltm
factw	-	conversion factor : divides by square feet/acre
facto	-	conversion factor : cfs - cubic ft/month
factyc	-	not used
rcl-4	-	amount of rainfall consumptively used on average (ins)
rdh	-	root zone depth (ft)
cdh	-	capillary rise (feet) data for element
scl	-	coefficient k in the seepage equation (ft/day)
sc2	-	thickness of sediment deposits in the lake bottom (ft)
dcl	-	temporary variable set equal to dcl * del
dc2	-	not used
dil	-	temporary variable set equal to dil * del
di2	-	not used
cbase	-	bedrock hydraulic conductivity for layer (i)
rechmx	-	maximum monthly recharge (ins/month)
traina	-	rainfall (annual values for each region)
troff	-	rainfall runoff (annual values for each region)
area	-	model area
areax	-	temporary variable : model area
areair	-	irrigated area
tstimp	-	annual stream inflow

troffs	-	rainfall runoff from element which is diverted to an adjacent stream
aroff	-	not used
voli	-	initial storage
volf	-	final storage
sirrtn	-	percentage of applied water to return flow
tevrt	-	total volume of evaporated water (ET)
nrsta	-	number of stations
tstdiv	-	total annual diversion
timp	-	total annual imported water
factim	-	factor to convert acres to square feet (43560)
factiy	-	factor to change imported water values to cubic ft/year
factq	-	conversion factor : changes sign and divides by timestep
facts	-	conversion factor : divides by timestep

co4

kyr	-	year counter : may be advanced or retarded for linkage between the surface water and groundwater models
imo	-	month during the simulation : value set equal to initm - kyr * 100
itime	-	time during the simulation e.g March 1980 = 198006
iflag	-	number of months from beginning of simulation
idt	-	temporary variable set equal to deltm (time step)
ldt	-	variable set equal to idt(time step) : incremented by -1
delt	-	time in an average month
delh	-	not used
itmed	-	not used
ntmed	-	not used
omega	-	implicit - explicit weighting factor. Omega = 0 for fully explicit and 1 for fully implicit
relax	-	relaxation parameter for sor method to accelerate convergence (0 - 2 : typically 1.6)
niter	-	maximum number of iterations for convergence (10-30)
stopc	-	convergence criterion deviation between iterations (0.1 -1.0)
filena	-	generic variable for name of file
itwqa	-	temporary variable set equal to itwq (initial time)
iter	-	iteration number
itwq	-	initial time
omegb	-	temporary variable : set equal to 1 - omega

1.6.3.3 TULARE.blk

	-	contains include files and common blocks (defined in surface water model section)
params.inc	-	model variable and parameter file
demands.cmn	-	demand and delivery variables
files.cmn	-	names of files called by program
flows.cmn	-	flow variables for each node
fwreqs.cmn	-	fish and wildlife requirement variables
goodcom.cmn	-	variables used to describe Goodwin dam operation
gwpump.cmn	-	project and non-project pumping variables
inflows.cmn	-	variables used in gain and inflow calculations
millier.cmn	-	variables used to describe Friant dam operation
misc.cmn	-	time and initialization
nodenos.cmn	-	nodal array variables
remain.cmn	-	remaining flow variables
reservoir.cmn	-	reservoir rule variables unless otherwise specified
returns.cmn	-	project and non-project return variables
tempor.cmn	-	temporary variables

tulbasn.cmn	-	tulare basin specific variables
usage.cmn	-	file of partition coefficients among uses
write.cmn	-	input/output control variables

1.7 Surface Water Model Parameter Files :

1.7.1 .INC files

1.7.1.1 PARAMS.inc (used in dimension statements)

kdnd	-	dimension on nodes
kdrs	-	dimension on reservoirs
kdusn	-	dimension on u/s nodes
kdusr	-	dimension on u/s return nodes
kdyr	-	dimension on number of years (used in output routines)
kdcon	-	dimension on number of nodes for salt routine output
kdconyr	-	dimension on number of years for salt routine output
kdsr	-	dimension on number of "sources" in the Tulare area
kdsnk	-	dimension on number of DAUs receiving water from a source in the Tulare area

1.7.2 .CMN files

1.7.2.1 DEMANDS.cmn - demand and delivery variables

adj	-	groundwater adjustments from subroutine GWCOMP (kdnd,12)
ageffnon	-	agric monthly efficiencies for noncritical years (kdnd,12)input
ageffcri	-	agric. " " critical years (kdnd,12), input
agrpat	-	agric. monthly pattern at a node (kdnd,12), input
anagdem	-	annual agric. demand at a node (kdnd), input
anagcon	-	annual agric. contract at a node (kdnd), input
anmidem	-	annual M&I demand at a node (kdnd), input
anmicon	-	annual M&I contract at a node (kdnd), input
contag	-	contracted delivery (agric) (kdnd,12) ANAGCON*AGRPAT
contmi	-	contracted delivery (M&I) (kdnd,12) ANMICON*MNIPAT
gwst	-	groundwater storage (kdnd,12), from subroutine GWCOMP
mieffnon	-	M&I monthly efficiencies for noncritical years (kdnd,12), input
mieffcri	-	M&I " " critical years (kdnd,12), input
mnipat	-	(real) M&I monthly pattern at a node (kdnd,12),input
npdel	-	(real) nonproject demands (kdnd,12), input
npeffnon	-	(real) nonproj. noncritical year monthly efficiencies (kdnd,12), input
npeffcri	-	(real) nonproj. critical year monthly efficiencies (kdnd,12), input
pdel	-	PDELM1+PDELAG for all demand nodes except SWP in CAQ
pdelag	-	adjusted project deliveries (agri.) (kdnd,12)
pdelmi	-	adjusted project deliveries (M&I) (kdnd,12)
tpdem	-	total target project demand (kdnd,12) TPDMM1+TPDMAG
tpdmag	-	target project demand (agri.) (kdnd,12) ANAGDEM*AGRPAT
tpdmmi	-	target project demand (M&I) (kdnd,12) ANMIDEM*MNIPAT
xaggw	-	maximum ag. GW pumping, (kdnd,12)
xmigw	-	maximum M&I GW pumping, (kdnd,12)
xnpgw	-	maximum GW pumping, (kdnd,12)
yaggw	-	minimum ag. GW pumping, (kdnd,12)
ymigw	-	minimum M&I GW pumping, (kdnd,12)
ynpgw	-	minimum GW pumping, (kdnd,12)

1.7.2.2 FILES.cmn - file names, all character variables in the control file

binfil	-	name of binary output file
eerrfil	-	name of file that errors and warnings are written to.
flodfil	-	name of file with time series of flood control rule storages
fwfil	-	name of file with F&W data
gainfil	-	name of file with time series of GAINS
glogfil	-	name of run log file for GW portion
goodfil	-	name of Goodwin Dam data file
gwcfil	-	name of file with GW control data
gwdfil	-	name of file with GW time series data
gwtsfil	-	name of file with time series of historical GW pump.
inffil	-	name of file with time series of inflows
npdmfil	-	name of file with nonproject demand data, including time series of demands
milfil	-	name of file for Millerton operation data
pdmfil	-	name of file with project demand data
pdtsfil	-	name of file with time series of project demands
powrfil	-	name of file with CVP system power variables
pumpfil	-	name of file with min. and max. GW pumping data
resfil	-	name of file with reservoir data
saltfil	-	name of binary file written for use with the salt routine
schmfil	-	name of file with data from PROSIM
slogfil	-	name of run log file for surface model
tuldfil	-	name of file with Tulare data
usndfil	-	name of file with u/s node data
wyrfil	-	name of file with year types

1.7.2.3 GWPUMP.cmn

xpmpnp	-	maximum annual nonproject GW pumping for a demand node, 3 year types, input (kdnd,3)
xmppp	-	maximum annual project GW pumping for a demand node, 3 year types, input (kdnd,3)
xppatp	-	monthly pattern of max. project GW pumping, %, input (kdnd,12,3)
xppatnp	-	monthly pattern of max. nonproject GW pumping, %, input (kdnd,12,3)
ypmpnp	-	minimum annual nonproject GW pumping for a demand node, 3 year types, input (kdnd,3)
ymppp	-	minimum annual project GW pumping for a demand node, 3 year types, input (kdnd,3)
yppatp	-	monthly pattern of min. project GW pumping, %, 3 year types, input, (kdnd,12,3)
yppatnp	-	monthly pattern of min. nonproject GW pumping, %, 3 year types, input (kdnd,12,3)

1.7.2.4 GWCOMP.cmn

mieffnon	-	M&I monthly efficiencies for noncritical years (kdnd,12), input
mieffcri	-	M&I " " critical years (kdnd,12), input
mnipat	-	(real) M&I monthly pattern at a node (kdnd,12),input
npdel	-	(real) nonproject demands (kdnd,12), input
npeffnon	-	(real) nonproj. noncritical year monthly efficiencies (kdnd,12), input
npeffcri	-	(real) nonproj. critical year monthly efficiencies

		(kdnd,12), input
pdel	-	PDELM1+PDELAG for all demand nodes except SWP in CAQ
pdelag	-	adjusted project deliveries (agri.) (kdnd,12)
pdelmi	-	adjusted project deliveries (M&I) (kdnd,12)
tpdem	-	total target project demand (kdnd,12) TPDMMI+TPDMAG
tpdmag	-	target project demand (agri.) (kdnd,12) ANAGDEM*AGRPAT
tpdmmi	-	target project demand (M&I) - (kdnd,12) ANMIDEM*MNIPAT
xaggw	-	maximum ag. GW pumping, (kdnd,12)
xmiggw	-	maximum M&I GW pumping, (kdnd,12)
xnpgw	-	maximum GW pumping, (kdnd,12)
yaggw	-	minimum ag. GW pumping, (kdnd,12)
ymiggw	-	minimum M&I GW pumping, (kdnd,12)
ynpgw	-	minimum GW pumping, (kdnd,12)

1.7.2.5 ENERGY.cmn

hydropower variables

datum	-	elevation from which head on turbines is computed, (kdnd), input
mwh	-	(real) monthly megawatt hours of energy at each dam, (kdnd,12)
teff	-	array of turbine efficiencies, (kdnd)

1.7.2.6 FLOWS.cmn

flow	-	flow leaving a node (kdnd,12), doesn't include returns from that node
------	---	---

1.7.2.7 FWREQS.cmn

fwclas	-	array of fw req.values at 7 levels (kdnd,12,7),input
fwequn	-	array of fw req. "equations" in character variables, (kdnd), input
fwreq	-	flowby requirements for f&w (kdnd,12)
fwtrig	-	array of fw req. trigger values (kdnd,7), input
kfwfor	-	same as KFRCSST, used for F&W req. computations (12)
triggr	-	trigger value to calculate FWREQ

1.7.2.8 GOODCOM.cmn

clsgood	-	annual vol of FW flow at Goodwin, 4 values (4), input
exppat	-	monthly export pattern from Goodwin, (12), input
excarry	-	export carry over, amount of EXPORT 110 that can't be used, carried to the next month
fwgood	-	monthly fraction of annual FW flow at Goodwin, monthly values for each CLSGOOD, (12,4) input
ossjdem	-	maximum annual diversion from Goodwin, input
ossjspl	-	split of Goodwin diversions between Oakdale-South (delivery to 110) and Oakdale-North plus South San Joaquin (EXPORT 110)

1.7.2.9 INFLOWS.cmn

dmcq	-	flow from Mendota pool into node 15, (12)
forinf	-	forecasted inflow from current month to the end of the water year, (kdnd,12)
gain	-	gains (kdnd,12), input
infl.o	-	(real) inflows to reservoirs, (kdnd,12), input
schmflo	-	array of monthly DMC and CAQ deliveries computed in PROSIM, input, (9,12)
yrtype	-	(integer) array of year types, input (kdyr)

1.7.2.10 MILLER.cmn

(all values input unless noted)

dismad	-	array of monthly fractions of Madera Canal (EXPORT 25) water from Millerton going to node 25, remainder goes to node 35, input (12)
fkcl	-	monthly volume of Friant-Kern (FKC) Class1 flow (12)
fkcl2	-	monthly volume of FKC Class 2 flow (12)
fkcl2l	-	monthly volume of FKC Class 2 long-term flow (12)
fkcl2s	-	monthly volume of FKC Class 2 short-term flow (12)
fkmspl	-	fraction of Class 1 and Class 2 water going to Friant-Kern Canal. remainder goes to Madera Canal (EXPORT 25). input, (5)
madcl	-	monthly volume of Class 1 flow in Madera Canal (12)
madcl2	-	monthly volume of Class 2 flow in Madera Canal (12)
madxpat	-	(real) monthly pattern of Madera Canal exports, input, (12,5)
milinf	-	natural monthly inflow into Millerton, assuming no upstream storage, real, input, (12)
upstore	-	storage in reservoirs u/s from Millerton, input (12) used to compute Millerton flood storages and spills

1.7.2.11 MISC.cmn

(all values input unless otherwise noted)

rtitle	-	run title, 80 characters
myear,	-	variable to get a time stamp from the computer - year
mmonth,	-	" " month
mday,	-	" " day
mhour,	-	" " hour
mmunit,	-	" " minute
msecs,	-	" " secs
ml00th	-	" " 0.01 secs
begmo	-	(integer) month number of beginning of simulation
begsim	-	(integer) year in which simulation starts
begyr	-	(integer) year at beginning of run, input (1922 -)
capcty	-	capacity of links (kdnd)
lastyr	-	last year in simulation
nyear	-	number of years in simulation, LASTYR-BEGSIM+1
wqtar	-	quality target at node 27, units are mg/l, input (12)

1.7.2.12 NODENOS.cmn

(numbers - all values input)

frusret	-	array of percentage of return from an u/s node going to the current node, (kdusr,kdnd)
knodcp	-	array of nodes with capacities (kdnd)
knodcvp	-	array of nodes with CVP demands (kdnd)
knoddm	-	array of nodes with demands (kdnd)
knodfw	-	array of nodes with F&W req. (kdnd)
knodgn	-	array of nodes with gain (kdnd)
knodgts	-	array of nodes with time series of historical GW pumping
knodin	-	array of nodes with inflow (kdnd)
knodnp	-	array of nodes with nonproject demands (kdnd)
knodpmp	-	array of nodes with GW pumping (kdnd)
knodprj	-	array of nodes with project demands (kdnd)
knodpts	-	array of nodes with time series of project demands (kdnd)
knodrs	-	array of nodes with reservoir (kdrs)
knodtul	-	list of node numbers of Tulare DAUs, input, (kdnd)

maxusnd	-	maximum number of nodes immed. u/s from current node
maxusrt	-	maximum number of nodes with returns immed. u/s from current node
n	-	array of subscript numbers corresponding to the array of node numbers - NDNUM, (6*kdnd) - (for example, N for node 5 is 1, N for node 95 is 19)
ncap	-	number of nodes with capacities
ndnum	-	array of node numbers (kdnd)
ncvpdm	-	number of CVP demand nodes
ndemd	-	number of nodes with demand
nfw	-	number of nodes with fish & wild require. (min flow)
ngain	-	number of nodes with gains
ngwts	-	number of nodes with time series of GW pumping
ninfl	-	number of nodes with inflow
nnodes	-	number of nodes in model
nnpdem	-	number of nonproject demand nodes
nprjdm	-	number of nodes with project demands
nprjts	-	number of nodes with time series of project demands
npump	-	number of nodes with GW pumping
nres	-	number of reservoirs
nsources	-	number of sources of water in the Tulare area, input
ntuldm	-	number of Tulare-area DAUs
nusnod	-	number of immediately u/s nodes
nusret	-	number of immediately u/s nodes with returns going to current node
nwretn	-	number of nodes w/ returns from west side of valley
usnode	-	(integer) node numbers of nodes immediately u/s of current node (kdusn,kdnd)
usret	-	(integer) node numbers of nodes with returns immediately u/s of current node (kdusn,kdnd)

1.7.2.13 REMAIN.cmn - remaining flow variables

flowin	-	flow entering a node (kdnd)
reqrel	-	extra release needed to get up to FWREQ. (kdnd)
rgain	-	remaining gain at a node (kdnd)
rinf	-	remaining inflow at a node (kdnd)
rnpret	-	remaining non-project returns at a node (kdnd)
rpret	-	remaining project returns at a node (kdnd)

1.7.2.14 RESERVOR.cmn - reservoir rule data, input unless otherwise noted

arel	-	array of additional releases needed to meet requirements, computed, (kdnd)
bstor	-	beginning storage for month (kdnd), input - computed every year
ev	-	reservoir evaporation depth (.01 ft) (kdnd,12)
kswsmlt	-	array of binary switches to turn on snowmelt routine (kdnd)
qpow	-	release limit for hydropower (kdnd,12)
rstor	-	running storage (kdnd)
snomlt	-	array of snowmelt releases (kdnd,12)
spcvec	-	vector of outlet capacities for space rule calls at 3 areas, nodes 40, 95, 125 (3,kdnd)
srule	-	storage rule (kdnd,12)
starcf	-	storage-area curve coeffs. (kdnd,4)
stelcf	-	storage-elevation curve coeffs. (kdnd,4)
strf	-	storable inflows to reservoirs (kdnd)
xqpow	-	hydraulic capacity of powerhouse (kdnd)
xstfld	-	flood control rule (kdnd,12)

xstor	-	maximum storage (kdnd)
ystor	-	minimum storage (kdnd)
ystrsv	-	minimum reserve storage (kdnd,12)

1.7.2.15 RETURNS.cmn - project and nonproject returns

npret	-	(real) nonproject returns (kdnd,12)
pret	-	project returns (kdnd,12)

1.7.2.16 TULBASN.cmn

div	-	surface diversion from source to sink in a month (kdsr, kdnd, 12)
jbpexs	-	excess flow that can't go down the James Bypass (12)
lsink	-	node numbers of DAUs getting water from a sink, input, (kdsr, kdnd)
nsink	-	number of DAUs getting water from a sink, input, (kdsr)
sdelv	-	total surface delivery into a DAU, (kdnd, 12)
tsr, ksnk	-	fraction of flow from a source to a DAU for a month and year type, input, (kdsr, kdsnk, 12, 3)

1.7.2.17 USAGE.cmn - how water is split among various uses. all (kdnd, 12)

npgnus	-	(real) non-project gain
npgwus	-	(real) non-project groundwater usage
npinus	-	(real) non-project inflow
npretus	-	(real) non-project return flow
npsht	-	(real) non-project shortage
paggw	-	project groundwater used by agriculture
pagsht	-	project agricultural shortage
pagus	-	project surface water used by agriculture
pmigw	-	project groundwater used for M&I
pmisht	-	project M&I shortage
pmius	-	project surface water used for M&I

1.7.2.18 WRITE.cmn - variables passed to time series output subroutine

evap	-	reservoir evaporation (KAF) (kdnd, 12)
export	-	exports (kdnd, 12)
sjqual	-	San Joaquin water quality for the month, units are mg/l (12)
stor	-	end of month storages, used only for output (kdnd, mo)
tempag	-	end of month storage (PDEL, AG):output (kdnd, 12)
tempdel	-	deliveries (PDEL):output (kdnd, 12)
tempfw	-	fish and wildlife requirements (FWREQ):output (kdnd, 12)
tempmi	-	municipal and industrial demand (PDELM, I):output (kdnd, 12)
vqual	-	quality at Vernalis, units are mg/l (12)
wqrel	-	quality release made from New Melones to meet WQTAR at Vernalis, node 27 (12)

1.7.3 .BLK files

none

1.8 Output Parameter Files :

1.8.1 .INC files

none

1.8.2 .CMN files

1.8.2.1 BALANCE .cmn

tdelv	-	total surface water delivered to an area
balance	-	surface water balance at a stream node
pdelgr	-	project delivery groundwater
pdelstu	-	project deliver surface water
npsur	-	non-project delivery surface water
return	-	combined return flow
usflow	-	flow at the upstream surface water node

1.8.3 .BLK files

1.8.3.1 TULARE.blk	-	contains include files and common blocks (previously defined in surface water model section)
params.inc	-	model variable and parameter file
demands.cmn	-	demand and delivery variables
files.cmn	-	names of files called by program
flows.cmn	-	flow variables for each node
fwreqs.cmn	-	fish and wildlife requirement variables
goodcom.cmn	-	variables used to describe Goodwin dam operation
gwpump.cmn	-	project and non-project pumping variables
inflows.cmn	-	variables used in gain and inflow calculations
millier.cmn	-	variables used to describe Friant dam operation
misc.cmn	-	time and initialization variables
nodenos.cmn	-	nodal array variables
remain.cmn	-	remaining flow variables
reservoir.cmn	-	reservoir rule variables unless otherwise specified
returns.cmn	-	project and non-project return variables
tempor.cmn	-	temporary variables
tulbasn.cmn	-	tulare basin specific variables
usage.cmn	-	file of coefficients for split between uses of water
write.cmn	-	input/output control variables

1.8.3.2 COMM1.blk - common blocks used in the groundwater model
(previously defined in groundwater model section)

1.9 Salinity Model Parameter Files :

1.9.1 .INC files

none

1.9.2 .CMN files

1.9.2.1 SALT.cmn

concret	-	return flow TDS concentration
concxp	-	TDS concentration of exports
concfl	-	TDS concentration of flow
vole	-	last year's monthly groundwater storage
concing	-	initial concentration of each groundwater element
ratelch	-	rate of salt leachate from applied irrigation water

1.9.2.2 SALTCOM.cmn - salt model variables

caplmat	-	conc. application matrix used for writing results (12,kdconyr,kdcon)
concapl	-	conc. of applied water (kdnd,12)
concfl	-	conc. of FLOWS leaving a node (kdnd,12)
concg	-	conc. of GAINS, input, (kdnd,12)
concgw	-	conc. of GW, either input or computed, (kdnd,12)
concim	-	conc. of imports (kdnd,12)
concin	-	conc. of INFLOWS, input, (kdnd,12)
concmat	-	conc. matrix for writing results (12,kdconyr,kdcon)
concret	-	conc. of surface returns, input, (kdnd,12)
concost	-	conc. of initial reservoir storage, input (kdnd,12)
flowmat	-	flow matrix for writing results (12,kdconyr,kdcon)
inodes	-	array of input node numbers used to insure node numbering consistency (kdnd)
knodwrt	-	array of node numbers for output, input, (kdnd)
nord	-	array of node numbers in the order in which computations are done, in BLOCK DATA (kdnd)
rconcost	-	running concentration in storage nodes (kdnd)

1.9.2.3 QUALITY.cmn

concret	-	conc. of surface returns, input, (kdnd,12)
concxp	-	TDS concentration of exports
concfl	-	conc. of FLOWS leaving a node (kdnd,12)

1.9.2.4 GW14.cmn

cvx	-	coefficients of the shape function
qx	-	not used
qy	-	not used
vold	-	not used
ax	-	coefficients of shape function
ay	-	coefficients of shape function
ije	-	non-zero stiffness matrix node number associated with element

1.9.3 .BLK files

1.9.3.1 TULSALT.blk	-	invokes include files and common blocks
params.inc	-	model variable and parameter file

misc.cmn	-	time and initialization
nodenos.cmn	-	nodal array variables
returns.cmn	-	project and non-project return variables
tulbasn.cmn	-	tulare basin specific variables
usage.cmn	-	file of partition coefficients among uses
saltcom.cmn	-	parameters for salinity control file

1.9.3.2 GW14.blk - invokes common block GW14

1.9.3.3 TULARE.blk - contains include files and common blocks (defined in surface water model section)

params.inc	-	model variable and parameter file
demands.cmn	-	demand and delivery variables
files.cmn	-	names of files called by program
flows.cmn	-	flow variables for each node
fwreqs.cmn	-	fish and wildlife requirement variables
goodcom.cmn	-	variables used to describe Goodwin dam operation
gwpump.cmn	-	project and non-project pumping variables
inflows.cmn	-	variables used in gain and inflow calculations
millier.cmn	-	variables used to describe Friant dam operation
misc.cmn	-	time and initialization
nodenos.cmn	-	nodal array variables
remain.cmn	-	remaining flow variables
reservoir.cmn	-	reservoir rule variables unless otherwise specified
returns.cmn	-	project and non-project return variables
tempor.cmn	-	temporary variables
tulbasn.cmn	-	tulare basin specific variables
usage.cmn	-	file of coefficients for split between uses of water
write.cmn	-	input/output control variables

1.9.3.4 TULSALT.blk - Include block for the salinity model

params.inc	-	model variable and parameter file
misc.cmn	-	time and initialization variables
nodenos.cmn	-	nodal array variables
returns.cmn	-	project and non-project return variables
saltcom.cmn	-	salt concentration and salt balance variables
tulbasn.cmn	-	tulare basin specific variables
usage.cmn	-	file of coefficients for split between uses of water

1.10 Binary Switches

(All input. 0 is off, 1 is on)

knpzero	-	switch to set negative nonproject demands to zero
kswgw	-	switch to turn calls to groundwater routines on and off
kswpow	-	switch to turn calls to power routines on and off

2. FLOWCHARTS AND VARIABLE DESCRIPTIONS

2.1 Main program and linkage subroutines

2.1.1 TULARE.for

MAIN program which reads groundwater and grid information and transfers surface water delivery and groundwater pumping activity levels, for those surface nodes with groundwater interaction, to groundwater elements. The groundwater model simulates groundwater flow conditions under the new streamflows, surface water diversions and pumping rates and calculates updated stream gains and/or losses. After the groundwater contributions have been calculated, the stream gains and/or losses are transferred from the groundwater stream nodes to the surface water model nodes and reservoir releases are adjusted a second time with the updated estimates. These transformations occur at each monthly timestep and are made within the TULARE and SGTRANS subroutines. The gains and/or losses calculated for the preceding month are used as initial conditions for the first iteration of the surface water model during the current month.

Variables and parameters :

begyr	-	beginning year of simulation
export(nd,mo)	-	exports (kdnd,12)
fkdaup	-	monthly delivery pattern for Friant - Kern Canal water to each DAU
flow(nd,mo)	-	flow leaving a node (does not include returns) (kdnd,12)
forinf(nrn,mo)	-	forecasted volume for given month until end of year (nrn,12)
fwreq(nd,mo)	-	in stream flow requirements for fish and wildlife (kdnd,12)
gain(nd,mo)	-	gains (input) - (kdnd,12)
imo	-	month counter : may be advanced or retarded for linkage between the surface water and groundwater models
inflow(nd,mo)	-	real inflows to reservoirs (input) - (kdnd,12)
init	-	beginning time of simulation
itime	-	time during the simulation e.g March 1980 = 198006
iy	-	do loop index for year
kdnd	-	dimension on nodes
knodin(nd)	-	array of nodes with inflow (kdnd)
kswgw	-	switch to turn calls to groundwater routines on and off
kwsalt	-	switch to output surface water data for Salt Balance model
kyr	-	year counter : may be advanced or retarded for linkage between the surface water and groundwater models
last	-	ending time of simulation
lastyr	-	last year in simulation
mo	-	do loop index for month
ndi	-	defined as n(knodprj(in))
nfw	-	number of nodes with fish and wildlife requirements (min)
ninfl	-	number of nodes with inflow
npgrus(nd,mo)	-	(real) non-project gain upstream (kdnd,12)
npgrus(nd,mo)	-	(real) non-project groundwater used (kdnd,12)
npinus(nd,mo)	-	(real) non-project inflow used (kdnd,12)
npret(nd,mo)	-	non-project surface returns (kdnd,12)
npretus(nd,mo)	-	(real) non-project return flow used (kdnd,12)
nprjdm	-	number of nodes with project demands
npsht	-	(real) non-project storage

nrn	-	defined as n(knodin(i))
nsink	-	number of elements where pumping or recharge is specified
pagsh	-	project agricultural shortage
pagus(nd,mo)	-	project surface water used by agriculture (kdnd,12)
pdel(nd,mo)	-	project deliveries (kdnd,12)
pdelag(nd,mo)	-	adjusted project deliveries (agricultural) (kdnd,12)
pdelmi(nd,mo)	-	adjusted project deliveries M & I (kdnd,12)
pmisht(nd,mo)	-	project M & I shortage (kdnd,12)
pmius(nd,mo)	-	project surface water for M & I (kdnd,12)
pret(nd,mo)	-	project returns (kdnd,12)
tempag	-	dummy variable which stores the current value of pdelag
tempdel	-	dummy variable which stores the current value of pdel
tempdv	-	dummy variable which stores the current value of div
tempex	-	dummy variable which stores the current value of export
tempfw	-	dummy variable which stores the current value of fwreq
tempgn1	-	dummy variable which stores the current value of gain
tempgn2	-	dummy variable which stores the current value of gain
tempmi	-	dummy variable which stores the current value of pdelmi
xaggw(nd,mo)	-	maximum agricultural groundwater pumping (kdnd,12)
xmigw(nd,mo)	-	maximum M & I groundwater pumping (kdnd,12)
xnpgw(nd,mo)	-	maximum groundwater pumping (kdnd,12)
yaggw(nd,mo)	-	minimum agricultural groundwater pumping (kdnd,12)
ymigw(nd,mo)	-	minimum M & I groundwater pumping (kdnd,12)
ynpgw(nd,mo)	-	minimum groundwater pumping (kdnd,12)

Subroutine calls (in order of calling) :

maxfiles(err)	-	fortran utility obtained from Lahey to allow large numbers of files to be open at once.
date(rundate)	-	fortran function which returns current date
time(runtime)	-	fortran function which returns current time of day
timdat	-	obtains the system time and date
titpag	-	puts out a title block and queries the user about the type of run to make
gw21(init,last)	-	reads in groundwater options file and reads all input data for the time loop
gw22(init,last, iyr,mo)	-	time dependent routines used by the groundwater model.
surfinp(fkdaup)	-	reinitializes to zero appropriate arrays and reads reservoir data from files before they are closed.
wrtonce	-	writes out the initialization data to file (30)
sltonce	-	writes out the initialization data to the salt file (31)
sgtrans(*,mo)	-	transforms surface water diversion, pumping and streamflow data from SW nodes to GW model elements.
surface(iyr,mo, fkdaup)	-	reads in the time series data and handles surface water routing, calling other subroutines .
zero2(*,kdnd,12)	-	zeros out a two dimensional array
writtim	-	writes annual results to a binary file (30)
salttim	-	writes annual results to a binary salt file (31)

Files read from:

Calls to subroutines sgtrans.for and gw21.for to read in grid information and hydrologic parameters.

Files written to:

slogfile (unit=44)

Flowchart :

-
- o begin execution
 - o read groundwater information
grid information
hydrologic parameters
 - o initiate simulation and monthly loop
 - o replace monthly gains for nodes with groundwater interactions with
gains calculated by the groundwater model.
 - o transfer surface water delivery and groundwater pumping from the
surface water model to the groundwater model.
 - o transfer stream gains or losses from stream nodes to surface water
nodes.
 - o iterate to obtain final value for stream gains and losses
 - o write annual results to a binary file
-

2.1.2 SGTRANS.for

Program interface linking the surface water and groundwater models. Transforms surface water diversion, pumping and streamflow data from surface water nodes to finite elements of the groundwater model using a DAU to district cross-indexing table. The stream nodes were located to be consistent with Detailed Analysis Units (DAU's) and the groundwater elements arranged to geographically recognize water district boundaries. This subroutine is called by the main program to transform stream seepage gains/losses calculated by the groundwater model to surface water nodes.

Variables and parameters :

allocg(i)	-	fraction of pumped water for each DAU allocated to the corresponding water district
allocs(i)	-	fraction of surface water for each DAU allocated to the corresponding water district
cnf	-	conversion factor from cubic feet to 1000's of acre-feet
dsdlv(j)	-	total surface water delivered to district j
dgdlv(j)	-	total ground water delivered to district j
fimmo(i)	-	total surface water delivered to each ground water element
flow(n(i),mo)	-	flow leaving a node (kdnd,12), doesn't include returns from that node
fpumo(i)	-	total groundwater pumped from each element
gain(n(i),mo)	-	gains (kdnd,12), input
knodgn(i)	-	array of nodes with gain (kdnd)
moplus*	-	monthly index incremented by one month
n(nddmnd(i))	-	array of subscript numbers corresponding to the array of node numbers - NDNUM, (6*kdnd).
nb	-	assigned equal to nbyl(i)
nbyl(i)	-	groundwater element number
ncross	-	number of cross-index variables (1503)
nddmnd(i)	-	surface water demand node numbers
ndist	-	number of water districts
nflag	-	decision variable flag
nibwd	-	water district ID (district-DAU cross index)
niwd	-	water district ID (district-element cross index)
nm	-	subscript variable equivalent to n(nddmnd(i))
npgnus(nm,mo)	-	non-project upstream gain (usage)
npinus(nm,mo)	-	(real) non-project inflow (usage)
npretus(nm,mo)	-	(real) non-project return flow (usage)
paggw(nm,mo)	-	(real) project groundwater pumpage for agriculture
pagus(nm,mo)	-	project surface water used by agriculture
pmius(nm,mo)	-	project surface water used by M & I
prcn(i)	-	percentage of each groundwater element within each water district
qrinf(l)	-	gain/loss at each river node in groundwater model
qstrm(n)	-	inflow at river node IDST(i)
tmp**	-	temporary variable

Subroutine calls :

none

Files read from:

dauswdat.bin (unit=21)
distdat.bin (unit=22)

Files written to:

none

Flowchart :

- o read grid data from distdat.bin
 - o read in district cross-indexing table from dauswdat.bin
 - o calculate each district's water delivery for the month
 - o transform streamflow from surface water nodes to stream nodes
 - o write out data to TULIMP.DAT in a suitable form for input into the groundwater model
 - o transfer stream gains/losses from groundwater nodes to surface water nodes. (+ gains ; - losses). Values are stored in the file QRINF(i) in cubic feet per month.
-

Table 1.0

		Comparison of variable value assignment in surface only and linked models	
Variables	Variable definition	Surface water model	Linked SANTUCM model
flow	flow leaving a node (monthly)	Calculated within the surface water model.	Calculated during first iteration of surface water model. Flow is recalculated during the second iteration and adjusted by the new values of stream gains/losses.
gain	stream gain (loss) (monthly)	Read from hydrologic time series file. Not changed.	Read initially from the time series file. After month 1 the previous month's gain is used for the initial monthly gain. Updated with the calculated gain from the groundwater model.
gwpts	groundwater pumping (monthly)	Determined according to year type and total annual demand for ag. and M&I from time series hydrology.	Read initially from the time series file. Groundwater pumping is recalculated during a second iteration and the current value overwritten by the calculated value
npgwus	non-project groundwater pumping (monthly)	Determined according to year type and total annual demand for ag. and M&I from time series hydrology.	Read initially from the time series file. Groundwater pumping is recalculated during a second iteration and the current value overwritten by the calculated value
npgnus	non-project gain (monthly)	Read from hydrologic time series file. Not changed.	Read initially from the time series file. After month 1 the seepage loss is calculated from the groundwater model and used to determine monthly gain.
pdelag	adjusted ag. deliveries (monthly)	Calculated during first iteration of surface water model.	Calculated during first iteration of surface water model. Ag. deliveries are recalculated during the second iteration and variable pdelag is updated with the current value.
pdelmi	adjusted M&I deliveries (monthly)	Calculated during first iteration of surface water model.	Calculated during first iteration of surface water model. M&I. deliveries are recalculated during the second iteration and variable pdelmi is updated with the current value.
pdel	total project delivery (M&I + ag) (monthly)	Calculated during first iteration of surface water model.	Calculated during first iteration of surface water model. Total deliveries are the sum of ag. and M&I deliveries recomputed in the second iteration.
qrinf	seepage loss at each stream node (monthly)	Groundwater variable Not used	Read initially from the time series file. After month 1 the seepage loss is calculated from the groundwater model and used to determine monthly gain.
qstrm	streamflow at each ground water model stream node (monthly)	Groundwater variable Not used	Calculated during first iteration of surface water model. Streamflow is recalculated during the second iteration and variable qstrm is updated with the current value.
xnpgw	maximum groundwater pumping (M&I + ag) (monthly)	Determined according to year type and total annual demand for ag. and M&I.	Maximum pumping can be replaced by a time series value for monthly groundwater pumping.
ynpgw	minimum ground water pumping (M&I + ag) (monthly)	Determined according to year type and total annual demand for ag. and M&I.	Minimum pumping can be replaced by a time series value for monthly groundwater pumping.

2.2. Groundwater model subroutines- PASS1

2.2.1 GW1.for

The main program **gwfm141** in PASS1 of SANTUCVM specifies the sizes of all the adjustable arrays. The program processes the control input file and generates both a standard output file and a binary output file. The binary output file is read during execution of PASS2 subroutines in the SANTUCM model.

Variables and parameters :

ae(i)	-	non-zero stiffness matrix component resulting from FEM
ael	-	element areas
area	-	watershed area
botr(ir)	-	elevation of stream bottom (ft) at node ID
cr	-	diameter of well in feet
cw	-	well capacity conversion to cubic feet/day
cwell(iwl)	-	well capacity (gals/min)
delta	-	time step in hours for the detailed simulation
deltm	-	simulation time steps in months
delz	-	elevation difference between the soil surface and stream bottom
dh(*)	-	bedrock elevation
dht(*)	-	top elevation of the aquifer for each GW node
elg(id)	-	ground surface elevation for each groundwater node
id	-	node number
ide(*)	-	node number associated with element ne
idr(ir)	-	groundwater node corresponding to each stream node
ie	-	element number containing a lake
ii	-	counter variable
iin	-	decision variable ; set to 20 at beginning of subroutine
ije	-	non-zero stiffness matrix node number associated with element
il	-	index for top layer of element
imoa	-	first month of detailed simulation
initm	-	first month in simulation
iyra	-	first year of detailed simulation
iou	-	unit number used in output control
ip	-	well number
ipl	-	well numbering variable : set equal to $ipl + 4 * nl$
ise	-	index indicating position of the stiffness matrix elements in the array AT
itd	-	node number of aquifer below
iud(id)	-	index to indicate the status of a node as confined/unconfined or ineffective
iwell(iwl)	-	index for pumping nodes in an element
iwl	-	well number index
jnd	-	node numbers surrounding a node
kbase	-	switch to use constant head in bedrock
kdeb	-	switch to print debug aids
kimp	-	switch to use imported water
kl	-	temporary variable
klake	-	number of elements with lakes
kout	-	switch to control output
koutg	-	switch to print geometric data
kouth	-	switch to control head output
koutp	-	switch to control plotter output

koutr	-	switch to print river node hydrographs
kp	-	pumping type index
kplot	-	switch to control plot output
kpm	-	switch to use pumping
krain	-	switch to use rainfall station data
krsta(id)	-	rainfall station identifier
kstr	-	switch to use stream data
kwell	-	switch to use wells, input
lastm	-	last month in simulation, input
lmoa	-	last year of detailed simulation
lpc	-	print head results for this layer
lph	-	print head levels in matrix (1) or by elements (2)
lyra	-	year to end detailed simulation
mpcx	-	number of sequential print control pairs
mpcy	-	number of non-sequential print control pairs
mwrta	-	number of detailed simulation outputs
mwrth	-	months between print of heads
mwrtd	-	months between print of water balance
mwrtd	-	control for print of detailed discharge data
na	-	not used
nd	-	number of nodes
ndya	-	number of days in each detailed simulation
ne	-	number of elements
niter	-	maximum number of iterations for convergence (10-30)
nj	-	sum of the number of nodes surrounding each GW node
nl	-	number of layers
nld(id)	-	number of effective layers for each node
	-	number of lakes
nrdw	-	loop counter for wells with effective radius of pumping assigned to a given node
nrwr	-	loop counter for wells with effective radius of pumping assigned to a given node
ns	-	number of nodes surrounding elements
nskip	-	number of skipped lines
nwell	-	number of pumping wells
nxer	-	set equal to irdr (counter for number of pumping wells)
omega	-	implicit - explicit weighting factor. Omega = 0 for fully explicit and 1 for fully implicit.
perfi(*)	-	adjusted well perforation interval (partial penetrating well)
pwell(*)	-	distribution coefficient to allocate pumpage to each node
relax	-	relaxation parameter for sor method to accelerate convergence (0 - 2 : typically 1.6)
rwell(iwl)	-	well radius
sd(id)	-	area associated with each groundwater node
se(ka)	-	area of each groundwater element
stopc	-	convergence criterion deviation between iterations (0.1 -1.0)
w(*)	-	thickness of aquiclude
	-	id for layer (idl)
	-	constant to add to initial condition data for layer 1,2..
x(*)	-	x co-ordinate of each groundwater node location.
xwell(iwl)	-	x coordinate of well location
y(*)	-	y co-ordinate of each groundwater node location
ywell(iwl)	-	y coordinate of well location
 Subroutine calls :		
skip	-	skips a specified number of lines

timdat - gets the system time and date
getg - reads in and analyzes the geologic, geographic
 element/node configuration data

Files read from :

tulresp1.dat - response file
tulcont.dat - control file

Files written to:

none

Flowchart :

- o read value of variable iin
 - o if iin = 20 read from the response file "tulresp1.dat" otherwise read
 in name of response file
 - o open output file and obtain title of run
 - o read and write control parameters from control file
-

2.2.2 GETG.for

Reads and analyzes the geologic, geographic element/node configuration data

Variables and parameters :

ae(i)	-	non-zero stiffness matrix component resulting from FEM
area	-	watershed area
ax	-	coefficients of shape function
ay	-	coefficients of shape function
bot	-	bottom elevation of stream
c	-	average aquifer thickness of each layer
cb	-	percentage of element area that is under water (lake)
	-	flux at node CA
cc	-	average head of a lake
ct	-	sum of all the c values for each node of an element
cvx	-	coefficients of the shape function
cvy	-	coefficients of the shape function
cwd	-	effective well capacity at each node
cwell(iwl)	-	well capacity (gals/min)
dh(idl)	-	bedrock elevation
dht(idl)	-	top elevation of the aquifer for each GW node
divx	-	streamflow in the bypass diversion rating table
divy	-	diversion amount in the bypass diversion rating table
dxe	-	logarithm of the ratio $c / w(i)$:
	-	$\log (\text{aquifer thickness} / \text{thickness of aquiclude})$
elg(id)	-	ground surface elevation for each groundwater node
elv	-	variable initially set equal to elg(id)
erdw	-	effective radius of a well
erwn	-	effective radius of a node / radius of well
factxd	-	map scaling factor for node coordinates
factxw	-	scaling factor for x and y locations
hlake	-	water surface elevation of lake
hrtb	-	water surface elevation (ft) above BOTR
ia	-	node number with diversion
ib	-	node number where diversion applied
ibdr	-	last downstream node
ibur	-	first upstream node number
ic	-	reach id
id	-	node number
ide(*)	-	node number associated with element ne
idiv(*)	-	bypass diversion number for each stream node
idl	-	index set equal to id, idl or idr(temporary index)
idr(ir)	-	groundwater node corresponding to each stream node
idwd	-	node index (set equal to id)
idwn	-	node number to which this reach is flowing
ie	-	element number containing a lake
iin	-	test variable : equal to file unit number
ije	-	non-zero stiffness matrix node number associated with element
il	-	index for top layer of element
ili	-	index for bottom layer of element
ill	-	temporary counter variable
iou	-	groundwater node number for boundary flux
ip	-	well number
ir	-	do loop counter
irngn	-	corresponding stream node that surface water will flow to. If gw node does not flow to a stream node - enter 0.
ise	-	index indicating position of the stiffness matrix elements in the array AT

iud(id)	-	index to indicate the status of a node as confined/unconfined or ineffective
iw(*)	-	groundwater node index
iwd	-	node label for nodes with pumping assigned set equal to iwl*(10+i)
iwell(iwl)	-	element number assigned to the pumping well
ji	-	temporary counter variable : ji = njd(i)
j1	-	temporary counter variable : j1 = njd(i+1) -1
jnd(j)	-	node numbers surrounding a node
ka	-	counter for number of nodes
ke	-	counter in increments of 4 for quadrilateral elements
king	-	temporary variable : set equal to unit number
klake	-	number of elements with lakes, input
krain	-	switch to use rainfall
krsta(id)	-	rainfall station identifier
kstr	-	switch to use stream data
kwell	-	switch to use wells, input
ld	-	array storage variable set equal to ily * nd
na	-	not used
nd	-	number of nodes
ndb	-	set equal to nd + 1
ndiv	-	number of diversion nodes
ndl	-	array storage variable (maximum dimension) = nd * nl
ndtb	-	number of data points indicating a diversion
ndwd	-	total number of nodes with associated wells
ne	-	number of elements
nel	-	product of ne and nl
nj	-	sum of the number of nodes surrounding each GW node
njd	-	cumulative number of nodes surrounding each node
nl	-	number of layers
nld(id)	-	number of effective layers for each node
nr	-	number of lakes
nrdr	-	number of river nodes with stream-aquifer interaction
nrh	-	number of diversions for which the amount of diversion is specified
nrt	-	number of reaches
nrtb	-	number of reaches * number of points in rating table
nrwb	-	number of data points with a diversion
nrwr	-	total number of nodes surrounding pumping wells set equal to nwell * 4
ns	-	number of nodes surrounding elements
nsh	-	defined as ns/2
ntr	-	not used
nwd	-	number of wells assigned to a node
nwdt	-	not used
nwell	-	number of wells
nwell4	-	nwell multiplied by 4
nwenl4	-	nwell multiplied by 4 and by nl (number of layers)
nxer	-	set equal to irdr (counter for number of pumping wells)
perfb	-	bottom of well screen perforations
perfi(*)	-	adjusted well perforation interval (partial penetrating well)
perft	-	top of well screen perforations
prtb	-	wetted perimeter (ft) at HRTB water surface elevation
pwell(*)	-	distribution coefficient to allocate pumpage to each node
qrtb	-	flow rates (cfs) at HRTB water surface elevation
rerfb	-	not used
rwell(iwl)	-	well radius

sd(id)	-	area associated with each groundwater node
se(ka)	-	area of each groundwater element
slake(*)	-	area of each element that is covered with water
top	-	top elevation of each aquifer layer
vbase(j)	-	bedrock leakage term for layer (j)
w(*)	-	id for layer (idl)
	-	constant to add to initial condition data for layer 1,2..
x(id)	-	x co-ordinate of each groundwater node location
xwell(iwl)	-	x coordinate of well location
y(id)	-	y co-ordinate of each groundwater node location
ywell(iwl)	-	y coordinate of well location

Subroutine calls :

ndfg	-	performs element-node computations
elem	-	performs element level computations
skip	-	skips designated number of lines

Files read from:

tulcont.swh (5)	-	control file
tulelem.dat (7)	-	element data
gwmxy.dat (7)	-	node data
tulstra.dat (8)	-	stratigraphy data
tulstrm.dat (9)	-	stream control
lake datafile (3)	-	lake data (not used)
well datafile (4)	-	recharge well file (not used)

Files written to:

tulplb.dat	-	binary output file - pass1
tulout1.out	-	standard output file

Flowchart :

```

o   read filename with element data -
      read node data from file
      read global node numbers from the file
o   read filename with x-y co-ordinate data
      read x-y co-ordinate data
o   call subroutine NDFG
o   call subroutine ELEM
o   read filename with stratigraphy data
      read elevations of aquifer layers and compute intervals
o   read filename with stream-aquifer data
      read node numbers along each reach
      read file of diversion nodes
      read data containing hydraulic characteristics of each stream
o   read lake data file
      read lake data, surface elevations and surface area
o   read well data file
      read number of wells and well perforation intervals
      calculate weighting functions to distribute well pumping to
      element nodes
o   call subroutine WLOCA
o   write output to a standard output file
o   write output to a binary file for transfer to PASS2 of the SANTUCM
    groundwater model

```

2.2.3 NDFG.for

Performs node-element computations

Variables and parameters :

ia	-	smallest number of two adjacent nodes
ib	-	largest number of two adjacent nodes
iba	-	set equal to ib - 1
id	-	node number
idd	-	first node number of an element
ide(*)	-	node number associated with element ne
ie	-	element number containing a lake
iea	-	element number - 1
ier	-	error flag - not used
ij	-	do loop counter (temporary variable)
ije(*)	-	non-zero stiffness matrix node number
ik	-	counter in increments of 6
iq	-	counter from 1 - 4 for quadrilateral elements
ise(*)	-	index indicating position of the stiffness matrix elements in the array AT
it	-	counter from 1 to 3 for triangular elements
iud(id)	-	index to indicate the status of a node as confined/unconfined or ineffective
iw(*)	-	temporary variable defined as iw(ia) + 1
ja	-	temporary variable defined as iw(ib) + 1
jb	-	smaller of two numbers + 1
jc	-	larger of two numbers + 1
jdd	-	second node number of element
je	-	temporary variable set equal to (ie - jea)
jea	-	counter from 1 to iea
jnd(j)	-	node numbers surrounding a node
kdd	-	third node number of element
ke	-	counter in increments of 4 for quadrilateral elements
kej	-	counter which decrements by 4 for quadrilateral elements
ki	-	temporary variable set to 1, 3 or 5 used to define position of elements in the stiffness matrix
kj	-	temporary variable set to 1, 3 or 5 used to define position of elements in the stiffness matrix
ldd	-	fourth node number of an element
nd	-	number of nodes
ne	-	number of elements
ne4	-	number of elements multiplied by 4
nj	-	sum of the number of nodes surrounding each GW node
njd	-	cumulative number of nodes surrounding each node
ns	-	number of nodes surrounding elements

Subroutine calls :

none

Files read from:

none

Files written to:

none

Flowchart :

- o determine the label of adjacent nodes connected to each node
 - o calculate the number of nodes connected to each node
 - o determine the position of the links that make up each element
-

2.2.4 ELEM.for

Performs element level computations

Variables and parameters :

ae(*)	-	non-zero stiffness matrix component resulting from FEM
area	-	element area
at(*)	-	hydraulic conductivity in horizontal direction
ax	-	coefficients of shape function
ay	-	coefficients of shape function
c	-	sum of vector products
c32	-	constant defined as $1/256$
ca	-	constant set equal to $1.67*c$
cb	-	constant set equal to $0.5/c$
	-	flux at node CA
cj	-	coefficient of shape function
ck	-	coefficient of shape function
cm	-	coefficient of shape function
cx	-	coefficient of shape function
cy	-	coefficient of shape function
gp	-	constant set equal to $1/\sqrt{3}$
gpx(*)	-	numeric data defined in data statement
gpy(*)	-	numeric data defined in data statement
ide(*)	-	node number associated with element ne
ie	-	element number containing a lake
ise(*)	-	index indicating position of the stiffness matrix elements in the array AT
ka	-	counter in increments of 6
kb	-	counter in increments of 4
ke	-	counter in increments of 4 for quadrilateral elements
ks	-	counter in increments of 12
na	-	not used
ne	-	number of elements
sd(*)	-	area associated with each groundwater node
se(*)	-	area of each groundwater element
x(*)	-	x co-ordinate of each groundwater node location
y(*)	-	y co-ordinate of each groundwater node location

Subroutine calls :

none

Files read from:

none

Files written to:

none

Flowchart :

- o calculate the area and shape function for each groundwater node
 - o calculate the area associated with each groundwater element
 - o determine the interpolation function for aquifer hydraulic conductivity in the horizontal direction between nodes
-

2.2.5 WLOCA.for

This is called when the well package is invoked and performs the following functions :

- o Locates wells within a grid element
- o Determines the weight by which groundwater pumping is distributed to the nodes that bound each grid element
- o Calculates the effective radius of a well at each node
- o Calculates the necessary log function based on well distance and the effective radius of a node

Variables and parameters :

a	-	
ax	-	coefficients of shape function
ay	-	coefficients of shape function
bot	-	bottom elevation of stream
c	-	average aquifer thickness of each layer
ca	-	fraction of pumping from column ICOLWL to be applied at well IDUM
cb	-	percentage of element area that is under water (lake)
	-	flux at node CA
cwd	-	effective well capacity at each node
cwell(iwl)	-	well capacity (gals/min)
dh(idl)	-	bedrock elevation
dht(idl)	-	top elevation of the aquifer for each GW node
dxx	-	logarithm of the ratio $c / w(i)$:
	-	$\log(\text{aquifer thickness} / \text{thickness of aquiclude})$
dyy	-	x-coordinate of the distance between adjacent wells
elg(id)	-	y-coordinate of the distance between adjacent wells
erdw	-	ground surface elevation for each groundwater node
erwr	-	effective radius of a well
id	-	effective radius of node / radius of well
ide(*)	-	node number
idl	-	node number associated with element ne
idw	-	index set equal to id, idl or idr(temporary index)
idwd	-	counter for nodes with pumping assigned
ie	-	node index (set equal to id)
ier	-	scalar assigned to element containing a pumping well
il	-	variable set equal to -iwl
ip	-	index for top layer of element
ipl	-	well number
irdr	-	well numbering variable : set equal to $ipl + 4 * nl$
it	-	counter for number of pumping wells based on effective radius, with pumping assigned to a node
itd	-	constant set equal to 3 or 4
iud(*)	-	node number of aquifer below
	-	index to indicate the status of a node as
	-	confined/unconfined or ineffective
iw(*)	-	corresponding groundwater number
iwd	-	well counter set equal to $iwl * 10 + i$
iwell(iwl)	-	element number assigned to the pumping well
iwl	-	counter for well number
jwl	-	scalar variable set equal to $iwl(j)/10$
k*	-	temporary variables assigned to each element
kp	-	pumping type index
nd	-	number of nodes
ndwd	-	total number of nodes with pumping assigned
ne	-	number of elements
nj	-	sum of the number of nodes surrounding each GW node

njd	-	cumulative number of nodes surrounding each node
nl	-	number of layers
nld(id)	-	number of effective layers for each node
	-	number of lakes
nrdr	-	loop counter for wells with effective radius of pumping assigned to a given node
nrwr	-	loop counter for wells with effective radius of pumping assigned to a given node
ns	-	number of nodes surrounding elements
nwd	-	number of wells assigned to a node
nwell	-	number of wells
nxer	-	set equal to irdr (counter for number of pumping wells)
perf	-	total length of well perforation
perfb	-	bottom of well screen perforations
perfi(*)	-	adjusted well perforation interval (partial penetrating well)
perft	-	top of well screen perforations
pwell(*)	-	distribution coefficient to allocate pumpage to each node
rwell(iwl)	-	well radius
top	-	top elevation of each aquifer layer
w(*)	-	thickness of aquiclude
	-	id for layer (idl)
	-	constant to add to initial condition data for layer 1,2..
x(*)	-	y co-ordinate of each groundwater node location
xmax	-	maximum of x co-ordinate values for well location
xmin	-	minimum of x co-ordinate values for well location
xpp	-	scalar variable set equal to xwell(iwl)
xt	-	well weighting function
xwell(iwl)	-	x coordinate of well location
y(*)	-	y co-ordinate of each groundwater node location
ymax	-	maximum of y co-ordinate values for well location
ymin	-	minimum of y co-ordinate values for well location
ypp	-	scalar variable set equal to ywell(iwl)
yt	-	well weighting function
ywell(iwl)	-	y coordinate of well location

Subroutine calls :
none

Files read from:
none

Files written to:
none

Flowchart :

- o determine the elements in which pumping wells are located
- o loop through elements to distinguish triangular and quadrilateral elements
- o perform loop to determine weighting function for triangular elements
- o calculate well weighting function to distribute pumping to nodes
- o perform loop to determine weighting function for quadrilateral elements
- o calculate well weighting function to distribute pumping to nodes
- o store information and organize in arrays for future use
- o determine perforation variable PERFI and make adjustment to PERFI for partially penetrating well
- a

- o calculate the effective radius for each node based on well pumping
 - o loop on the number of nodes with pumping assigned
 - o sum the shape functions for all surrounding nodes
 - o calculate the distance between nodes
 - o use effective radius to calculate log function
 - o loop only for nodes with pumping assigned in the region in which the effective radius is being considered
 - o loop for nodes associated with triangular elements and well of interest
 - o calculate the distance between well and other wells and calculate the required log function using the effective radius
 - o loop for nodes associated with quadrilateral elements and well of interest
 - o calculate the distance between well and other wells and calculate the required log function using the effective radius
-

2.2.6 TIMDAT.for

Obtains system date and time for use in output subroutines

Variables and parameters :

rdate	-	current system date
rtime	-	current system time

Subroutine calls :

date(rdate)	-	retrieves system date
time(rtime)	-	retrieves system time

Files read from:

none

Files written to:

none

2.2.7 SKIP.for

Skips a specified number of records in a file

Variables and parameters :

junk	-	dummy data
nrecs	-	number of records to be skipped

Subroutine calls :

none

Files read from:

ifile	-	file specified in calling subroutine
-------	---	--------------------------------------

Files written to:

ifile	-	file specified in calling subroutine
-------	---	--------------------------------------

2.2.8 IOSUB.for

Facilitates input and output for the main program

Variables and parameters :

ix(j)	-	input/output variable with dimension n
l1	-	temporary variable
l2	-	temporary variable
n	-	dimension of variable x1
n1	-	set equal to n / 256
x(j)	-	input/output variable with dimension n

Internal subroutines :

readi(ix,n,in)	-	reads input variable ix in fields of 256 characters from unit in
readr(x,n,in)	-	reads input variable x in fields of 256 characters from unit in
writei(ix,n,io)	-	writes output variable ix in fields of 256 characters to unit io
writer(x,n,io)	-	writes output variable x in fields of 256 characters to unit io

Files read from:

in	-	unit specified in input calling routine
----	---	---

Files written to:

io	-	unit specified in output calling routine
----	---	--

2.3.1 Groundwater model subroutines - PASS2

2.3.1 GW21.for

Sets up and analyzes all the requisite data for the time loop. Performs data conversions and summations and initializes all requisite variables used in the groundwater model.

Variables and parameters :

ae(i)	-	non-zero stiffness matrix component resulting from FEM
area	-	watershed area
c	-	temporary variable set equal to idt and deltm
cbase(i)	-	bedrock hydraulic conductivity for layer (i)
cl(i)	-	vertical hydraulic conductivity (ft/day)
clk(id)	-	vertical leakance
clt(id)	-	vertical leakance
dcl	-	temporary variable set equal to dcl * deltm
delt	-	temporary variable set equal to average days per month (30.43) * deltm
delta	-	time step in hours for the detailed simulation
deltm	-	simulation time steps in months
dil	-	temporary variable set equal to dil * deltm
facto	-	conversion factor : cfs - cubic ft/month
factq	-	conversion factor : changes sign and divides by timestep
factr	-	conversion factor : divides area by 12 and timestep deltm
facts	-	conversion factor : divides by timestep
factw	-	conversion factor : divides by square feet/acre
id	-	node number
idt	-	temporary variable set equal to deltm (time step)
iflag	-	flag variable
ihsu	-	temporary variable : initially set = 2
iin	-	temporary variable : initially set = 20
imo	-	month during the simulation : value set equal to initm - kys * 100
imoa	-	first month of detailed simulation
init	-	temporary variable set equal to initm
initm	-	first month of simulation
iou	-	groundwater node number for boundary flux
itd(i)	-	node number of aquifer below
itime	-	time during the simulation e.g March 1980 = 198006
itwq	-	temporary variable set equal to init
iwrth	-	counter for the months at which to write water budgets
iwrtq	-	temporary variable set equal to mwrtq
iyra	-	year to begin the detailed simulation (0 if no detailed simulation)
kbase	-	switch to use constant head in bedrock
kdeb	-	switch to print debug aids
kimp	-	switch to use imported water
klake	-	number of elements with lakes, input
kout	-	switch to control output
koutg	-	switch to print geometric data
kouth	-	switch to control head output
koutp	-	switch to control plotter output
koutr	-	switch to print river nodes as hydrograph output
kplot	-	switch to control plot output
kpmp	-	switch to use pumping
krain	-	switch to use rainfall
kstr	-	switch to use stream data

kswgw	-	switch to turn calls to groundwater routines on and off
kwell	-	switch to use wells, input
kyr	-	temporary variable set equal to initm / 100
last	-	temporary variable set equal to lastm
lastm	-	last month in simulation, input
lmoa	-	last year of detailed simulation
lpc	-	print head results for this layer
lph	-	print head levels in matrix (1) or by elements (2)
lyra	-	year to end detailed simulation
mpcx	-	number of sequential print control pairs
mpcy	-	number of non-sequential print control pairs
mwrta	-	number of detailed simulation outputs
mwrth	-	months between print of heads
mwrtd	-	months between print of water balance
nd	-	control for print of detailed discharge data
nd	-	number of nodes
ndl	-	array storage variable (maximum dimension) = nd * nl
ndla	-	temporary variable set equal to nd * (nl - 1)
nel	-	variable set equal to the product of ne and nl
ndya	-	number of days in each detailed simulation
niter	-	maximum number of iterations for convergence (10-30)
nj	-	sum of the number of nodes surrounding each GW node
njl	-	product of nj and nl : total number of nodes
nl	-	number of layers
nr	-	number of river nodes with stream-aquifer interaction
ns	-	number of nodes surrounding elements
nsh	-	defined as ns/2
nskip	-	number of lines to skip
ntmb	-	number of boundary nodes where the relationship between head and flux is specified
ntqb	-	number of boundary nodes where the constant fluxes are specified
omega	-	implicit - explicit weighting factor. Omega = 0 for fully explicit and 1 for fully implicit.
omegb	-	temporary variable : set equal to 1 - omega
qmtb(i)	-	flux in the rating table
qqb(i)	-	flux across the model boundary at a boundary node
relax	-	relaxation parameter for sor method to accelerate convergence (0 - 2 : typically 1.6)
rlk(i)	-	river leakance (if perch < 1)
scl	-	coefficient k in the seepage equation (ft/day)
stopc	-	convergence criterion deviation between iterations (0.1 -1.0)
title(j)	-	title to be printed on all output

Subroutine calls :

getgd	-	obtain grid information, geologic and hydrologic parameters
timdat	-	obtains system date and time
skip	-	skips a designated number of lines
initl	-	obtains initial conditions, boundary conditions, pumping and import control data

Files read from:

tulresp2.dat (20)	-	response file (pass2) to obtain file names
tulcont.swh (5)	-	input control file

Files written to:

grunlog(41)	-	file containing run-time information
-------------	---	--------------------------------------

tulout2.out(6) - standard output file
tulplb.dat (2) - output binary file (pass2)
gsalt.bin (27) - binary file containing the aquifer storage information
 for use by the salt model
user-specified (3)- final head output to external file

Flowchart :

- o open response file tulresp2.dat
 - o read and echo parameters from response file
 - o call timdat to obtain starting time of simulation
 - o call subroutine getgd to read in grid information, geologic and hydrologic parameters.
 - o call subroutine initi to initialize variables
 - o open binary files to store output after data manipulation and transformations
-

2.3.2 GW22.for

Main time dependent subroutine of the groundwater model. Controls subroutines to perform hydrologic balances and checks.

Variables and parameters :

as(id)	--	specific yield of aquifer / aquifer storage coefficient
at(11j)	-	hydraulic conductivity in horizontal direction
c	-	volume of inflow or outflow from aquifer at gw node
cbase(i)	-	bedrock hydraulic conductivity for layer (i)
clk(id)	-	vertical leakance / hydraulic conductivity
dh(id)	-	bedrock elevation
elg(i)	-	ground surface elevation for each groundwater node
factxd	-	map scaling factor for node coordinates
hn(id)	-	groundwater head at each groundwater node
hp(idl)	-	variable set equal to hn, groundwater head at each node
icount	-	counter for time loop during simulation increments by 1
id	-	node number
idl	-	index set equal to id, idl or idr(temporary index)
idl1	-	counter variable : set equal to idl + nd
idt(i)	-	temporary variable set equal to deltm (time step)
iflag	-	number of months from beginning of simulation
ii	-	counter variable for loop
im	-	end of range for loop : equal to total constant head boundary nodes + 1
imo	-	month during the simulation
istart	-	flag set at beginning of time loop: set equal to 1
itd(i)	-	node number of aquifer below
itime	-	time during the simulation e.g March 1980 = 198006
itmem	-	counter : incremented by one for each loop of simulation
iud(idl1)	-	index to indicate the status of a node as confined/unconfined or ineffective
ji	-	variable set equal to cumulative number of nodes surrounding each node (njd)
j1	-	set equal to njd(id - 1) -1
kbase	-	flag set to indicate inflow from bedrock
kplot	-	flag set to create plot file of groundwater heads
kstr	-	switch to use stream data
kswgw	-	switch to turn calls to groundwater routines on and off
kwell	-	switch to use wells, input
kyr	-	year counter : may be advanced or retarded for linkage between the surface water and groundwater models
last	-	last month of simulation
ld	-	array storage variable set equal to ily x nd
ldt	-	variable set equal to idt (time step) : incremented by -1
nd	-	number of nodes
nhb	-	number of constant head boundary nodes in each layer
njd(id)	-	cumulative number of nodes surrounding each node
nld(i)	-	number of effective layers for each node
	-	number of lakes
nthb	-	number of boundary nodes where constant heads specified
omega	-	implicit - explicit weighting factor. Omega = 0 for fully explicit and 1 for fully implicit.
qd(id)	-	source/sink term (pumping etc.)
qbase	-	discharge from bedrock at each node
qhb(i)	-	aquifer influx or efflux due to the source/sink term
qleak(idl)	-	aquifer leakage between semiconfined and confined aquifer
sd(i)	-	area associated with each groundwater node
wbase	-	flux into or out of bedrock for the base layer

whb(i) - flux due the source/sink term from layer j
 wleak(idl) - cumulative leakage term from element idl
 x(j) - x co-ordinate of each groundwater node location
 y(j) - y co-ordinate of each groundwater node location

Subroutine calls :

gener(istart) - generates finite element form of the governing equations
 getq - reads in and processes the source and sink terms
 river - computes the river-aquifer interaction
 surfl - performs the soil moisture accounting
 bound - adjusts for specified flux and rating table boundary
 conditions
 solve - solves the finite element equations by the SOR method
 cone2 - estimates the head due to drawdown at each well
 outc - controls most of the program output

Files read from:

none

Files written to:

tulout2.out(6) - standard output file
 grunlog(41) - log file of simulation run
 tulplot.out(19) - final head output for plotter
 tulhead.out(26) - hydrograph and final head output

Flowchart :

- o begin time loop, adjusting the timer for the groundwater model if the surface and groundwater models are run conjunctively.
 - o call subroutines to perform hydrologic mass balances and model checks.
 - o send output to specified devices such as a pen plotter.
-

2.3.3 GETGD.for

Reads in the grid information and the hydrologic and geologic parameters for the groundwater model.

Variables and parameters :

ae	-	non-zero stiffness matrix component resulting from FEM
aevap	-	annual evaporation (ins)
an(idl)	-	aquifer specific yield for an unconfined or confined case
area	-	watershed area
as(idl)	-	specific yield of aquifer / aquifer storage coefficient
botr	-	elevation of stream bottom at node ID (ft)
ca	-	fraction of pumping from column ICOLWL to be applied at well IDUM
cb	-	percentage of element area that is under water (lake)
	-	flux at node CA
cbase(*)	-	bedrock hydraulic conductivity for layer (*) ft/day
cdh	-	capillary rise (ft)
cdhn(i)	-	capillary rise (feet) data for node
cl(idl)	-	vertical hydraulic conductivity (ft/day)
clp(idl)	-	vertical hydraulic conductivity (ft/day)
cond(idl)	-	hydraulic conductivity (ft/day)
conda(i)	-	hydraulic conductivity value to overwrite element ieta for layer i
condp(idl)	-	hydraulic conductivity (ft/day)
cwd	-	effective well capacity at each node
cwell	-	capacity of the well (gpm)
dh	-	bedrock elevation
dht	-	top elevation of the aquifer for each GW node
dtev(i)	-	fraction of annual evaporation occurring in month i
dxer	-	logarithm of the ratio $c / w(i)$: log (aquifer thickness / thickness of aquiclude)
elg	-	ground surface elevation at node id
epor(id)	-	effective porosity
erdw	-	effective radius of a well
erwr	-	effective radius of node/radius of well
factxd	-	scaling factor for coordinate of nodes
factxw	-	scaling factor for x and y locations
fcl(il)	-	factor to weight vertical hydraulic conductivities of the overlying aquiclude to get ft/day
fcon(il)	-	factor to weight conductivity values to get ft/day
fsto(il)	-	factor to weight storage coefficient values
fsyd(il)	-	factor to weight specific yield values
hlake	-	water surface elevation of lake
hrtb	-	water surface elevation (ft) above BOTR
ia	-	previous node in sequence to where diversion applied
ib	-	node number where diversion applied
ibdr(irh)	-	last downstream node
ibur	-	first upstream node number
ic	-	groundwater node number
ide(*)	-	node number associated with element ne
idep(*)	-	coarse grid parameter counter
idl	-	index set equal to id, idl or idr(temporary index)
idr	-	groundwater node corresponding to each stream node
idwd	-	node index (set equal to id)
idwn	-	stream node number to which this reach flows
ie	-	element number containing a lake
ieta(ic)	-	element number
irh	-	river reach index

irngn	-	corresponding stream node that surface water will flow to. If gw node does not flow to a stream node - enter 0.
is	-	groundwater node in upstream reach
isb	-	variable defined as is + 1
ise	-	index indicating position of the stiffness matrix elements in the array AT
itd	-	node number of aquifer below
iud(idl)	-	index to indicate the status of a node as confined/unconfined or ineffective
iwd	-	corresponding groundwater grid node
iwell	-	element number assigned to the pumping well
jnd	-	node numbers surrounding a node
kdeb	-	1 - to print debugging data : 0 - no print out
ke	-	counter in increments of 4 for quadrilateral elements
klake	-	number of elements with lakes, input
koutp	-	1 - for storing parameter data : 0 - no storage of data
krain	-	1 - if precip, runoff and infiltration options are used 0 - no options used
krsta	-	rainfall station identifier
kstr	-	switch to use stream data
ld	-	array storage variable set equal to ily x nd
na	-	not used
nd	-	number of nodes
ndb	-	set equal to nd + 1
ndiv	-	dummy variable not previously used
ndl	-	array storage variable (maximum dimension) = nd * nl
ndp	-	number of nodes in the parameter grid
ndtb	-	number of data points indicating a diversion
ndwd	-	total number of nodes with associated wells
ne	-	number of elements
ne4	-	number of elements multiplied by 4
nel	-	product of ne and nl
nep	-	number of elements in the parameter grid
neta	-	number of elements where the parameter grid will be overwritten
nj	-	sum of the number of nodes surrounding each GW node
njd	-	cumulative number of nodes surrounding each node
nl	-	number of aquifer layers to be simulated (not including aquitards)
nld	-	number of effective layers for each node
nr	-	number of nodes with stream-aquifer interaction
nrh	-	number of reaches
nrdw	-	loop counter for wells with effective radius of pumping assigned to a given node
nrt	-	number of reaches * number of points in rating table
nrtb	-	number of data points with a diversion in rating table
nrwr	-	loop counter for wells with effective radius of pumping assigned to a given node
ns	-	number of nodes surrounding elements
ntr	-	not used
nwd	-	number of wells assigned to a node
nwdt	-	not used
nwell	-	number of wells simulated in the system
nxer	-	set equal to irdr (counter for number of pumping wells)
nxn	-	node number for rainfall-runoff parameter table
perch(i)	-	thickness of streambed lining at node i (ft)
perfb	-	elevation of the bottom of the perforated interval (ft)

perfi	-	adjusted well perforation interval (partial penetrating well)
perv	-	constant infiltration capacity (pervious soils) of non-irrigated areas used in the model
prtb	-	wetted perimeter (ft) at HRTB water surface elevation
pv(id)	-	fraction of area that is pervious to infiltration
pvo(*)	-	fraction of element (*) that is pervious
pwel1	-	distribution coefficient to allocate pumpage to each node
qrtb	-	flow rates (cfs) at HRTB water surface elevation
rc1/rc4	-	rainfall runoff coefficients
rcap	-	constant retention capacity of soil to be used throughout the model
rcn*(i)	-	coefficients in the rainfall - runoff equation
rco(*)	-	retention capacity of element (*)
rdh	-	root zone depth (ft)
rdhn(i)	-	root zone depth at a node
rechmx	-	maximum monthly recharge (ins/month)
rechmxn(i)	-	monthly recharge at an individual node (i)
rl(i)	-	vertical conductivity of streambed at stream node i (ft/day)
rlk(is)	-	river leakance (if perch < 1)
scl	-	the coefficient k in the seepage equation (ft/day)
sc2	-	thickness of sediment deposits in the lake bottom (ft)
sd(id)	-	area associated with each groundwater node
se(*)	-	area of each groundwater element
sirrtn	-	percentage of applied water to return flow
slake	-	area of each element that is covered with water
stop(idl)	-	storage coefficient (ft/ft)
sydp(idl)	-	specific yield (ft/ft)
vbase(*)	-	bedrock leakance term for layer (*)
w(*)	-	thickness of aquiclude
	-	id for layer (idl)
	-	constant to add to initial condition data for layer 1,2..
x(*)	-	x co-ordinate of each groundwater node location
xp(id)	-	x coordinate of node IC
xwell	-	x coordinate of well location
y(*)	-	y co-ordinate of each groundwater node location
yp(id)	-	y coordinate of node IC
ywell	-	y coordinate of well location

Subroutine calls :

assignp	-	assigns element information to surrounding nodes
readi	-	facilitates input/output for the program
readr	-	facilitates input/output for the program
skip	-	skips n lines
writer	-	writes input/output

Files read from:

tulplb.dat(2)	-	binary output file from pass1
---------------	---	-------------------------------

Files written to:

tulparm.dat(4)	-	parameter data file
----------------	---	---------------------

Flowchart :

- o read grid data from binary file **tulp1b.dat**
 - o read parameters at each node if coarse grid is not specified $ndp \leq 0$
 - o read coarse grid parameter if $ndp > 0$
 - o read in rainfall-runoff parameters for each node
 - o for urban areas use runoff parameters from a file for each element
 - o read in stream data
 - o if $koutp > 0$ write parameters into a user specified output file
-

2.3.4 INITI.for

Subroutine used to initialize various variables in the groundwater model and provide initial conditions, boundary conditions and pumping data to the groundwater model

Variables and parameters :

areair	-	irrigated area
an(idl)	-	aquifer specific yield for an unconfined or confined case
as(idl)	-	specific yield of aquifer / aquifer storage coefficient
at(i)	-	hydraulic conductivity in horizontal direction
c	-	variable set equal to aquifer storage (hp - dh)
ca	-	fraction of pumping from column ICOLWL to be applied at well IDUM
	-	node number
care	-	0.0 for the rating table boundary or area through which flow occurs for the combination head-flux boundary
cb	-	percentage of element area that is under water (lake)
	-	number of entries in the rating table for rating table boundary or the constant head at a distance CDIST from node CA for the combination head - flux boundary
	-	prescribed head node CA
	-	flux at node CA
cc	-	average head of a lake
cdist	-	0.0 for the rating table boundary or distance between CA and CB for the combination head-flux boundary
cl(idl)	-	vertical hydraulic conductivity (ft/day)
clk(i)	-	vertical leakance
clt(idl)	-	vertical leakance
cond(id)	-	hydraulic conductivity (ft/day)
dh(idl)	-	bedrock elevation
dht(idl)	-	top elevation of the aquifer for each GW node
elg(id)	-	ground surface elevation for each groundwater node
elv	-	ground surface elevation at a node
erdw	-	effective radius of a well
erwr	-	effective radius of node/radius of well
factim	-	factor to convert acres to square feet (43560)
factiy	-	factor to change imported water values to cubic ft/year
factpm	-	factor to change pumping rate to cubic ft/ month
factpy	-	conversion factor 1000 acre-ft to cubic ft/month
factst(i)	-	conversion factor to convert discharges to cfs for the stream inflow (i)
fbase	-	calibration variable added to initial aquifer heads
fhb(ii)	-	constant to add to prescribed head boundary nodes
fmb(ii)	-	factor to change rating table and combined head flux to af/yr
fpapl(i)	-	fraction of irrigation water applied at a node
fqb	-	factor for flux
fracim(i)	-	factor
fracpu(i)	-	fraction of pumping from column ICOLPU which is agricultural water
fracwl(i)	-	fraction used to quantify pumping or recharge for a single well
fwapl(i)	-	fraction of pumping from column ICOLWL to be applied at well IDUM
hbase	-	initial water table elevations at nodes
hnb(ji)	-	total flux at a boundary node
hmtb(j)	-	head in the rating table
hn(i)	-	groundwater head at each groundwater node

hp(i)	-	variable set equal to hn, groundwater head at each node
ia	-	node number with diversion
ib	-	node number where diversion applied
ic	-	groundwater node number
icolim(i)	-	column of imported water data file applied at element IEIMP
icolpu(i)	-	column of pumping data file to be applied at node IDPU
icolwl(i)	-	column number in pumping data set to be used for specifying amounts of pumping for each well
id	-	node number
ide(*)	-	node number associated with element ne
idl	-	index set equal to id, idl or idr (temporary index)
idpu(i)	-	node where pumping occurs also monthly distribution table to be applied to node IDUP, Set equal to zero if monthly data provided
idtim(i)	-	monthly imported water distribution table applied to element IEIMP, set equal to 0 if monthly data provided
idtpu(i)	-	distribution table to be used
idtwl(i)	-	monthly pumping distribution table to be used for well IDUM. Enter 0 for monthly values.
idum	-	layer number
ieimp(i)	-	pump identification number
ieimp(i)	-	element receiving imported water
ihb(ii)	-	node numbers for boundary nodes
ihsu	-	data flag for pumping control file
iidl	-	node number set equal to id for imported water file
iin	-	decision variable ; set to file unit number
il	-	index for top layer of element
ioutr	-	river node to be printed in hydrograph output
iouth	-	node at which a groundwater hydrograph is to be printed
itd	-	node number of aquifer below
itimyr	-	year of annual imported water data
itmem	-	counter : incremented by one for each loop of simulation
itpumo	-	year and month of pumping (Sep 1980 = 198009)
itpuyr	-	year of pumping records
itrn	-	year of rainfall
itst	-	year and month of stream inflow
iud(id)	-	index to indicate the status of a node as confined/unconfined or ineffective
lyrtp	-	year type associated with each year
iwell(iwl)	-	element number assigned to the pumping well
kbase	-	switch to use constant head in bedrock
kdeb	-	switch to print debug aids
kevap	-	switch to utilize evapotranspiration data
kgwpm	-	switch = 0 if pumping overwritten by surface water model
khh(ii)	-	error code for flux boundary conditions (-1,0 +1)
kimmo	-	monthly counter for imported water data input
kimp	-	switch to use imported water
kimyr	-	annual counter for imported water data input
klake	-	number of elements with lakes, input
kouth	-	switch to control head output
kpmp	-	switch to use pumping
kpumo	-	variable counter for number of months in pumping file
kpuyr	-	variable counter for number of years in pumping file
krain	-	switch to use rainfall
kstr	-	switch to use stream data
kswgw	-	switch to turn calls to groundwater routines on and off

ktim	-	first month of imported water data
ktpu	-	dummy variable used in pumping data input file
ktrn	-	initial month of data
kwell	-	switch to use wells, input
ld	-	array storage variable set equal to ily x nd
mpcx	-	number of sequential print control pairs
mpcy	-	number of non-sequential print control pairs
nd	-	number of nodes
ndb(ily)	-	set equal to nd + 1
ndef	-	pumping control data switch
ndiv	-	number of diversion nodes
ndl	-	array storage variable (maximum dimension) = nd * nl
ndla	-	temporary variable set equal to nd * (nl - 1)
ndpu	-	number of nodes or elements pumping in a layer = nlpu
ndst	-	number of stream nodes where water enters the system
ndtim	-	number of monthly imported water distribution tables
ndx	-	variable, initially set equal to 20 ; for printer control
ndy	-	variable, set equal to id/ndx ; for printer control
ne	-	number of elements
neimp	-	number of elements receiving imported water
nel	-	product of ne and nl
nhb(ily)	-	number of constant head boundary nodes in each layer
nimmo	-	number of different imported values
nimyr	-	number of annual imported water values (columns)
njl	-	product of nj and nl : total number of nodes
nl	-	number of layers
nld(id)	-	number of effective layers for each node
	-	number of lakes
nlpu(i)	-	number of nodes or elements pumping in layer (i)
nmb(ily)	-	number of rating table boundary nodes in each layer
nmtb(ki)	-	flag ; set equal to -1 for general head boundary
npumo	-	number of columns of monthly pumping data
npuyr	-	number of nodes with pumping
nqb(ily)	-	number of flux boundary nodes for each layer
nr	-	number of river nodes with stream-aquifer interaction
nskip	-	number of lines to skip
nthb	-	number of boundary nodes where constant heads specified
ntmb(ki)	-	number of boundary nodes where the relationship between head and flux is specified
ntmbt	-	set equal to the total number of head values in the flow - stage rating table
ntqb	-	number of boundary nodes where the constant fluxes are specified
ntyd	-	number of monthly pumping distribution tables to be provided
nwd	-	number of wells assigned to a node
nwell	-	number of wells simulated
nyr	-	number of years in the table
pirig(i)	-	percentage of area associated with a node that is irrigated
qmtb(j)	-	flux in the rating table
qqb(i)	-	flux across the model element boundary
rc(i)	-	maximum available soil moisture
sd(id)	-	area associated with each groundwater node
se(ka)	-	area of each groundwater element
soili(i)	-	variable set equal to 25% of available soil moisture
soilr(i)	-	soil moisture retained in the soil
tevrt	-	total volume of evaporated water (ET)

temp	-	total imported water supply
traina	-	rainfall (annual values for each region)
trane(i)	-	transmissivity of element
trans(idl)	-	aquifer transmissivity at a node
troff	-	rainfall runoff (annual values for each region)
troffs	-	rainfall runoff from element which is diverted to an adjacent stream
tstdiv	-	total annual diversion
tstimp	-	stream inflow
vbase(j)	-	bedrock leakage term for all elements in layer (j)
voli	-	initial storage
waply(i)	-	irrigation applied water to all elements in layer i
wbase(i)	-	initial heads in layer i
wevap(i)	-	evaporation from all elements in layer i
whb(i)	-	flux due the source/sink term from layer i
wlake(i)	-	seepage to lake from layer i at node (id)
wleak(i)	-	aquifer leakance from all elements in layer i
wmb(i)	-	boundary flux into or out of layer (j)
wpump(i)	-	aquifer pumping from all elements in layer i
wr(i)	-	sum of flow in a reach (accumulated river flow)
wrain(i)	-	rainfall incident on all elements in layer i
wrech(i)	-	recharge to aquifer layer from element
wrinf(i)	-	sum of gains and losses for layer i
wsurf(i)	-	cumulative surface water infiltration to layer i
yddist(j)	-	fraction of annual pumping occurring in month (j)
yimdt(j)	-	fraction of annual imported water occurring in month (j)

Subroutine calls :

outph	-	outputs the head values in different forms
skip	-	skips n lines

Files read from:

tulcont.dat(5)	-	input control file
tulboun.dat(9)	-	boundary conditions
tulpmp.dat(10&11)	-	monthly pumping data file
tulstq41.dat(12)	-	streamflow data file
tulinit.dat(15)	-	initial conditions
tulpic.dat(17)	-	pumping control data
tulprcp.dat(13)	-	precipitation data
tulimp.dat(14&16)	-	monthly imported water data
tulyrt.dat(18)	-	year type table file

Files written to:

tuldvrs.out(25)	-	stream diversion file
tulhead.out(26)	-	final head values
tulout2.out(6)	-	standard output file

Flowchart :

- o read in filenames for well drawdown data, stream diversion data, final head values and boundary conditions
- o open files for storing well drawdown values and stream diversion data
- o read in boundary condition data
- o read in rating table boundary data
- o read in pumping control data
 - o perform separate routines for element and nodal data

- o read in imported water data
 - o perform separate routines for element and nodal data
 - o read in stream flow data
 - o read in rainfall data
 - o read in printer control file
 - o read in year type data file
 - o read in initial conditions from a file and initialize variables
-

2.3.5 GENER.for

Determines the effective aquifer transmissivities for triangular and quadrilateral elements. Determines the surrounding node hydraulic conductivities and prints out the hydraulic conductivity for each node.

Variables and parameters :

ae(i)	-	non-zero stiffness matrix component resulting from FEM
an	-	aquifer specific yield for the unconfined case
as	-	aquifer storage coefficient
at(ij)	-	hydraulic conductivity in horizontal direction
c	-	set equal to ae * trane (element transmissivity)
clk(idl)	-	vertical leakance
cond(id)	-	hydraulic conductivity (ft/day)
conda(ia)	-	conductivity value to overwrite element IETA for layer (ia)
dh(idl)	-	bedrock elevation
dht(idl)	-	top elevation of the aquifer for each GW node
epor(id)	-	effective porosity
hn(i)	-	groundwater head at each groundwater node
ia	-	node number with diversion
id	-	node number
idl	-	index set equal to id, idl or idr(temporary index)
idu	-	node identifier set equal to idl
ie	-	element number containing a lake
ieta	-	element number
im	-	subscript for node number of surrounding nodes
ip	-	well number
ipl	-	well numbering variable : set equal to ipl + 4 * nl
istart	-	flag set at beginning of time loop: set equal to 1
ise(*)	-	index indicating position of the stiffness matrix elements in the array AT
it	-	constant with value of 3 for triangular and 4 for quadrilateral elements
itd	-	node number of aquifer below
iud(id)	-	index to indicate the status of a node as confined/unconfined or ineffective
iw(*)	-	corresponding groundwater number
iwell(iwl)	-	element number assigned to the pumping well
iwl	-	well number index
jnd(j)	-	node numbers surrounding a node
ka	-	subscript variable for nodes surrounding a node
kb	-	subscript variable for nodes surrounding a node
ke	-	counter in increments of 4 for quadrilateral elements
kp	-	pumping type index
nd	-	number of nodes
ne	-	number of elements
neta	-	number of elements where the parameter grid will be overwritten
njd	-	cumulative number of nodes surrounding each node
nld(id)	-	number of effective layers for each node
	-	number of lakes
nwell	-	number of wells
perfi(*)	-	adjusted well perforation interval (partial penetrating well)
pwe(*)	-	effective well pumping rate
pwell(*)	-	distribution coefficient to allocate pumpage to each node
qmtb(j)	-	flux in the rating table
trane(im)	-	transmissivity of element

trans(idl) - aquifer transmissivity at a node

Subroutine calls :
none

Files read from:
none

Files written to:
none

Flowchart :

- o determine effective well pumping rate in accordance with the length
 of well perforations in each aquifer layer
- o determine effective aquifer transmissivity for triangular and
 quadrilateral elements
- o determine effective vertical permeabilities of each layer
- o determine surrounding node hydraulic conductivities and print out the
 effective hydraulic conductivity for each node

2.3.6 GETQ.for

Reads in and processes the sink and source terms

Variables and parameters :

facto	-	conversion factor : cfs - cubic ft/month
factst(i)	-	conversion factor to convert discharges to cfs for the stream inflow (i)
fimmo(i)	-	monthly imported water data
fimyr(i)	-	annual imported water corresponding to node at column i
fpapl(i)	-	fraction of irrigation water applied at a node
fpumo(i)	-	total groundwater pumped from each element
fpuyr(i)	-	pumping in the year ITPUYR for column i
fracim(i)	-	fraction of area associated with element IEIMP which receives imported water
fracpu(i)	-	fraction of pumping from column ICOLPU which is agricultural water
fracwl(i)	-	fraction used to quantify pumping or recharge for a single well
fwapl(i)	-	fraction of pumping from column ICOLWL to be applied at well IDUM
ia	-	node number counter
icolim(i)	-	column of imported water data file applied at element IEIMP
icolpu(i)	-	column of pumping data file to be applied at node IDPU
icolwl(i)	-	column number in pumping data set to be used for specifying amounts of pumping for each well
id	-	node number
ide(*)	-	node number associated with element ne
idl	-	index set equal to id, idl or idr(temporary index)
idst(i)	-	river node corresponding to inflow listed in column i of the stream flow data file
idpu(i)	-	node where pumping occurs also monthly distribution table to be applied to node IDUP, Set equal to zero if monthly data provided
idtim(i)	-	monthly imported water distribution table applied to element IEIMP, set equal to 0 if monthly data provided
idtpu(i)	-	distribution table to be used
idtwl(i)	-	monthly pumping distribution table to be used for well IDUM. Enter 0 for monthly values.
idu	-	node identifier set equal to idl
idum	-	well identification layer number
ieimp(i)	-	element receiving imported water
iidt	-	set equal to idtpu(i) - 1 * 12 + imo
il	-	index for top layer of element
imo	-	month during the simulation
ip	-	well number
ipl	-	well numbering variable : set equal to ipl + 4 * nl
itd	-	node number of aquifer below
itime	-	time during the simulation e.g March 1980 = 198006
itimmo	-	month of monthly imported data
itimyr	-	year of annual imported water data
itmem	-	counter : incremented by one for each loop of simulation
itpumo	-	year and month of pumping (Sep 1980 = 198009)
itpuyr	-	year of pumping records
itq	-	iteration counter set to 3 for triangular elements and 4 for quadrilateral elements
itrn	-	year of rainfall

itst	-	year and month of stream inflow
iyrr	-	variable set equal to itime/100 : (non-integer value)
iyrt	-	year type associated with each year
iwell(iwl)	-	element number assigned to the pumping well
iwl	-	well number index
kimmo	-	monthly counter for imported water data input
kimp	-	switch to use imported water
kimyr	-	annual counter for imported water data input
kpmp	-	switch to use pumping KPMP = 0, for no pumping KPMP = 1, for pumping by element KPMP = 2, for pumping by node
kpumo	-	variable counter for number of months in pumping file
kpuyr	-	variable counter for number of years in pumping file
krain	-	switch to use rainfall
kstr	-	switch to use stream data
kswgw	-	switch to turn calls to groundwater routines on and off
ktim	-	first month of imported water data
ktp	-	variable set equal to year type of current year
ktpuu	-	dummy variable used in pumping data input file
ktrn	-	initial month of data
ld	-	array storage variable set equal to ily x nd
nd	-	number of nodes
ndivo	-	index indicating diversion node
ndl	-	array storage variable (maximum dimension)
ndpu	-	number of nodes or elements pumping in a layer = nlpu calculated in subroutine init1
ndst	-	number of stream nodes where water enters the system
ndtim	-	number of monthly imported water distribution tables
neimp	-	number of elements receiving imported water
nhb(il)	-	number of constant head boundary nodes in each layer
nimmo	-	number of different imported monthly values
nimyr	-	number of annual imported water values (columns)
nl	-	number of layers
nld(id)	-	number of effective layers for each node
	-	number of lakes
nlpu(i)	-	node or element pumping in layer (i)
nlpua	-	total number of nodes or elements pumping in layer (i)
npumo	-	number of columns of monthly pumping data
npuyr	-	number of nodes with pumping
nr	-	number of river nodes with stream-aquifer interaction
nrsta	-	number of stations
nwell	-	number of wells
nyr	-	number of years in the table
pwe(ip)	-	effective well pumping rate
qaply(i)	-	irrigation applied water at a node
qd	-	source/sink term (pumping etc.)
qdum	-	dummy variable : flow values are dummy numbers
qpc(iwl)	-	volume of water pumped from a single well defined as $fpumo(icolwl(iwl)) * fracwl(iwl)$
qpump(i)	-	total well pumping from an element after accounting for any negative pumping p
qrdv(i)	-	river flow diversion demand
qrech(i)	-	quantity of aquifer recharge to an element
qrtr(i)	-	upstream and tributary inflow for each stream node
qstrm(i)	-	inflow at river node IDST(i)
rain	-	annual rainfall to an an element
se(ka)	-	area of each groundwater element

tevrt	-	total volume of evaporated water (ET)
timp	-	cumulative imported water
tstimp	-	cumulative stream inflow
wpump(i)	-	groundwater pumping from an element
wrech(i)	-	recharge to aquifer layer for element
yddist(j)	-	fraction of annual pumping occurring in month (j)
yimdt(j)	-	fraction of annual imported water occurring in month (j)

Subroutine calls :

none

Files read from:

tulpmp.dat(10&11)	-	monthly pumping data file
tulstq41.dat(12)	-	streamflow data file
tulprcp.dat(13)	-	precipitation data
tulimp.dat(14&16)	-	monthly imported water data

Files written to:

none

Flowchart :

- o read in annual data if variable counter for pumping > 0
 - o read in monthly pumping data if conjunctive use model is not used
 - o distribute element level pumping values to corresponding nodes
assume one pumping value per element (recharge +ve)
 - o add in pumping from each element for all layers
 - o if using annual values of pumping use the monthly distribution table
icolpu(nlpua) and yydist(iidt) to obtain monthly pumping amounts
groundwater model supplies pumping values on an annual basis
surface water model supplies pumping values on a monthly basis
 - o calculate the amount of irrigation water applied at each node (qaply)
for both triangular and quadrilateral elements
 - o read in annual imported water data if the conjunctive use model is
not being used (kswgw = -1)
 - o distribute the annual imported water based on geographic location
(idtim > 0)
 - o calculate the total imported water for mass balance analysis
 - o perform similar check for imported water on a node basis
 - o if the conjunctive use model is being used overwrite with streamflow
data from the surface water model
 - o read streamflows and diversions from data files
 - o read rainfall data in annual format if krain = 1
 - o read rainfall data in monthly format if krain = 2
-

2.3.7 SURFL.for

Performs soil moisture accounting

Variables and parameters :

aimp	-	area of element that is impervious
airg	-	area associated with a groundwater node that is irrigated
	-	set to the minimum of sda and associated area irrigated
airig	-	area of element that is irrigated
aper	-	area of element that is pervious excluding irrigated area
aply	-	depth of irrigation applied water
as(idl)	-	specific yield of aquifer / aquifer storage coefficient
c	-	soil moisture content
cdh	-	capillary rise (feet) data for element
cdhn(i)	-	capillary rise (feet) data for node
ck	-	vertical conductance : vertical hydraulic conductivity /
		area associated with each node
cl(idl)	-	vertical hydraulic conductivity (ft/day)
clk(i)	-	vertical leakance
cn	-	aquifer yield from storage
		specific yield / area associated with each node
depth	-	moisture retained in the unsaturated zone (ft)
deptha	-	depth of the unsaturated zone (surface - water table)
dtev	-	potential evapotranspiration
dtrn(krs,imo)	-	rainfall for month (imo)
eg	-	amount of water that can be evaporated from the root zone
elg(id)	-	ground surface elevation at each groundwater node
es	-	minimum soil moisture value
evap	-	evapotranspiration of applied water
facto	-	conversion factor : cfs - cubic ft/month
filt	-	water infiltrating during the month
hlake(i)	-	water surface elevation of lake
hn(i)	-	groundwater head at each groundwater node
id	-	node number
idl	-	index set equal to id, idl or idr(temporary index)
imo	-	month during the simulation
irngn(i)	-	corresponding stream node that surface water will flow
		to. If gw node does not flow to a stream node - enter 0.
itd	-	node number of aquifer below
klake	-	number of elements with lakes, input
krain	-	switch to use rainfall
krs	-	rainfall station identifier (scalar)
krsta(i)	-	rainfall station identifier for a node
kstr	-	switch to use stream data
nd	-	number of nodes
pirig(i)	-	percentage of area associated with a node that is
		irrigated
pv	-	fraction of area that is pervious to infiltration
qaply(i)	-	irrigation applied water at a node
qd(idl)	-	source/sink term (pumping etc.)
qevap	-	evapotranspiration from each element area
qlake(i)	-	flux from the lake
grain(i)	-	quantity of incident rainfall in each element
qrtr(*)	-	upstream and tributary inflow for each stream node
qsurf(id)	-	surface water infiltration
ra	-	maximum value of either incident rainfall or maximum
		infiltration capacity
rcl(i)	-	maximum available soil moisture
rcn(*)	-	coefficients in the rainfall - runoff equation

rdh*	-	root zone depth (feet)
rdhn*	-	root zone depth at a node
rech	-	groundwater recharge
rechmx	-	maximum monthly recharge (ins/month)
rechmxn	-	monthly recharge at an individual node (i)
roff	-	rainfall runoff
roffa	-	actual runoff limited by rainfall (depth)
roffd	-	total volume of runoff
rp	-	amount of rainfall that infiltrates
sd(id)	-	area associated with each groundwater node
sda	-	area at a groundwater node ; set equal to sd(id)
sirrtn	-	percentage of applied water to return flow
sirrtn(i)	-	percentage of applied water to return flow at an individual node (i)
slake(id)	-	area of each element that is covered with water
soilc	-	set to 50% of available soil moisture
soilm	-	soil moisture storage
soilmt	-	maximum available soil moisture
soilr(i)	-	soil moisture retained in the soil
srtm	-	total runoff from irrigation applied water
tevrt	-	total volume of evaporated water (ET)
traina	-	rainfall (annual values for each region)
troff	-	rainfall runoff (annual values for each region)
troffs	-	rainfall runoff from element which is diverted to the adjacent stream
wevap(i)	-	total amount of evaporation at a node during simulation
wrain(i)	-	total rainfall at a node for the simulation period
wsurf(i)	-	cumulative surface water infiltration at node (id) for the simulation period

Subroutine calls :
none

Files read from:
none

Files written to:
none

Flowchart :

- o if rainfall - runoff parameters are by node use the nodal values using rainfall station data
 - o for non-irrigated areas perform the following rainfall balance
 - o apply rainfall - runoff relationship
 - o calculate rainfall that goes to groundwater recharge based on soil moisture. A limiting value is set by the vertical hydraulic conductivity.
 - o calculate rainfall that goes to evaporation
 - o assign water that doesn't infiltrate or evaporate to surface runoff
 - o for irrigated areas perform the following rainfall balance
 - o determine the percentage of applied water that becomes runoff
 - o calculate the amount of applied water that becomes groundwater recharge based on soil moisture. Limit this amount to a maximum equal to the hydraulic conductivity of the aquifer.
 - o calculate evapotranspiration of surface applied water.
 - o assign water that doesn't infiltrate or evaporate to surface runoff
 - o account for any interaction with lakes
-

2.3.8 BOUND.for

Adjusts groundwater finite element fluxes and rating table boundary conditions in the groundwater model. (Constant head boundary inflow is calculated in main program GWFM142 after the matrix is solved at each time step.

Variables and parameters :

as(idl)	-	specific yield of aquifer / aquifer storage coefficient
at(i)	-	hydraulic conductivity in horizontal direction
c	-	limiting value for boundary inflow
ca	-	flux inflow from surrounding nodes to boundary node of interest
cb	-	boundary flux based on one dimensional darcy's law
dh(idl)	-	bedrock elevation
elg(id)	-	ground surface elevation for each groundwater node
hmtb(j)	-	head in the rating table
hn(i)	-	groundwater head at each groundwater node
ib	-	node number where diversion applied
ic	-	groundwater node number
id	-	node number
ii	-	set equal to im + 1
il	-	index for top layer of element
im	-	variable counter for number of flux boundary nodes
imb(ki)	-	index counter for boundary nodes
iqb(i)	-	index counter for boundary nodes
it	-	iteration index
ita	-	temporary index variable set to previous value
jnd	-	node numbers surrounding a node
ld	-	array storage variable set equal to ily x nd
nd	-	number of nodes
nj	-	sum of the number of nodes surrounding each GW node
njd(*)	-	cumulative number of nodes surrounding each node
nl	-	number of layers
nmb(il)	-	number of rating table boundary nodes in each layer
nmtb(ki)	-	flag ; set equal to -1 for general head boundary
nqb(il)	-	number of flux boundary nodes for each layer
ntmb(ki)	-	number of boundary nodes where the relationship between head and flux is specified
ntqb	-	number of boundary nodes where the constant fluxes are specified
qd(id)	-	source/sink term (pumping etc.)
qmb(i)	-	flux for rating table and general boundary nodes
qqb(i)	-	flux across the model boundary at a specified flux boundary node
qmtb(j)	-	flux in the rating table
wmb(i)	-	totalled flux at head dependent and general head boundary nodes for output water balance
wqb(i)	-	totalled flux at flux boundary nodes for output water balances

Subroutine calls :

none

Files read from:

none

Files written to:

none

Flowchart :

- o adjust the specified flux for a flux boundary
 - o adjust the rating table boundary conditions for a general head boundary condition nmtb = 0
 - o just the rating table boundary conditions for a general head boundary condition nmtb = -1
 - o limit the flux value based on the flux from surrounding nodes and the available aquifer storage
 - o calculate the flux inflow from surrounding nodes to the boundary node of interest
 - o calculate the boundary fluxes based on one dimensional Darcy flow.
 - o check the limiting value for boundary outflow.
 - o sum up boundary flux values for output water balance check.
-

2.3.9 ASIGNP.for

Assigns element information to the surrounding nodes

Variables and parameters :

a*	-	temporary variable used in shape function computation
an(idl)	-	aquifer specific yield for an unconfined or confined case
as(idl)	-	aquifer specific yield/storage coefficient
ax	-	coefficients of shape function, 1st node
ay	-	coefficients of shape function, 1st node
bx	-	coefficients of shape function, 2nd node
by	-	coefficients of shape function, 2nd node
cl(idl)	-	vertical hydraulic conductivity (ft/day)
clp(1*)	-	vertical conductivity (ft/day)
cond(idl)	-	hydraulic conductivity (ft/day)
condp(1*)	-	hydraulic conductivity (ft/day)
cx	-	coefficients of shape function, 3rd node
cy	-	coefficients of shape function, 3rd node
det	-	variable used in calculation of shape function
dx	-	coefficients of shape function, 4th node
dy	-	coefficients of shape function, 4th node
idep(k)	-	coarse grid parameter counter
iep	-	do loop counter
ier	-	variable set equal to final value of iep
itd(id)	-	node number of aquifer below
k*	-	node numbers of adjacent nodes
ll	-	temporary variable assigned equal to number of effective layers (nld)
nd	-	number of nodes
ndp	-	number of nodes in the parameter grid
nep	-	number of elements in the parameter grid
nld(id)	-	number of effective layers for each node
	-	number of lakes
stop(1*)	-	storage coefficient (ft/ft)
sydp(1*)	-	specific yield (ft/ft)
xp(k*)	-	x coordinate of node ic
xmax	-	maximum value of xp(k)
xmin	-	minimum value of xp(k)
ymax	-	maximum value of yp(k)
ymin	-	minimum value of yp(k)
yp(k*)	-	y coordinate of node ic

Subroutine calls :

none

Files read from:

none

Files written to:

tulout2.out - standard output file

Flowchart :

- o assign element information to the surrounding nodes
 - c if variable ier = iep then print out error statement
-

2.3.10 RIVER.for

Performs mass balances on stream nodes and calculates stream gains or losses as the major component of stream - aquifer interaction.

Variables and parameters :

as(idl)	-	specific yield of aquifer / aquifer storage coefficient
at(*,*)	-	hydraulic conductivity in horizontal direction
botr(ir)	-	elevation of stream bottom (ft) at node ID
c	-	multiple definitions
	-	factor to convert cfs to acre-ft/year
	-	river leakance calculated from rating table and gw heads
ca	-	river flow - set equal to qr(ia)
cc	-	average head of a lake
cl(*)	-	vertical hydraulic conductivity
clt	-	vertical hydraulic conductivity
cnvf	-	conversion factor 1000's acre-ft to cfs
divx	-	streamflow in the bypass diversion rating table
divy	-	diversion amount in the bypass diversion rating table
facto	-	conversion factor : cfs - cubic ft/month
factst(i)	-	conversion factor to convert discharges to cfs for the stream inflow (i)
hg	-	groundwater elevation at a stream node
hn(i)	-	groundwater head at each groundwater node
hrtb(ita)	-	water surface elevation (ft) above BOTR
hs	-	elevation of stream at stream node
ia	-	node number with diversion
ib	-	node number where diversion applied
ibdr	-	last downstream node
ibur	-	first upstream node number
ic	-	groundwater node number
id	-	node number
idiv(*)	-	bypass diversion number for each stream node
idl	-	index set equal to id, idl or idr(temporary index)
idr(ir)	-	groundwater node corresponding to each stream node
idwn	-	node number to which this reach is flowing
il	-	last node of stream reach
ily	-	integer form of variable il
irh	-	river reach index
is	-	groundwater node in upstream reach
isb	-	beginning node in stream reach
it	-	counter for nodes in a reach
ita	-	temporary index variable set to previous value
itime	-	time during the simulation e.g March 1980 = 198006
itl	-	last node in a stream reach
its	-	first node in a stream reach
iud(id)	-	index to indicate the status of a node as confined/unconfined or ineffective
jnd(j)	-	node numbers surrounding a node
ld	-	array storage variable set equal to ily x nd
nd	-	number of nodes
ndiv	-	number of diversion nodes
ndivo	-	index indicating diversion node
ndl	-	array storage variable (maximum dimension) = nd * nl
ndtb	-	number of data points indicating a diversion
nj	-	sum of the number of nodes surrounding each GW node
njd(id)	-	cumulative number of nodes surrounding each node
nr	-	number of river nodes with stream-aquifer interaction
nrh	-	number of river reaches

nrtb	-	number of data points with a diversion
perch(i)	-	streambed thickness
prtb(ita)	-	wetted perimeter (ft) at HRTB water surface elevation
ps	-	interpolated value of wetted perimeter
qd(*)	-	source/sink term (pumping etc.)
qr(i)	-	river flow
qrdv(ia)	-	river flow diversion demand
qrinf(i)	-	gain/loss at each river node in groundwater model
qmind(ia,mo)	-	minimum flow prior to diversion
qrtb	-	flow rates (cfs) at HRTB water surface elevation
qrtr(ia)	-	upstream and tributary inflow for each stream node
rl	-	stream bed conductivity (ft/day)
rlk(i)	-	river leakance (if perch < 1)
		river vertical conductivity * river length for node i
tstdiv	-	total annual diversion
wr(i)	-	sum of flow in a reach (accumulated river flow)
wrinf(i)	-	sum of gains and losses
z(*)	-	variables assigned to diversion and flow parameters

Subroutine calls :

none

Files read from:

none

Files written to:

tulout2.out (6)	-	standard output file
tuldvrs.out (25)	-	stream diversion file

Flowchart :

- o repeat for each reach
- o repeat for each streamnode per reach loop
- o calculate diversions specified as negative inflow and write the demand vs diversion results
- o calculate and adjust for diversions specified using the rating table
- o begin the calculations of river - groundwater interactions
- o determine flow-stage relationship from rating table and calculate whether the river node is a losing or gaining reach
- o begin calculations for a losing river reach
 - for a losing reach river level (hs) > (hg) groundwater level
- o check that river leakage is consistent with geohydrologic parameters
- o account for leakage between aquifer layers on available storage space
- o choose minimum river leakage from C1, C2 and C3 algorithms
 - C1 : calculated river leakage from the rating table and groundwater levels
 - C2 : head difference * specific yield + adjustment for leakage between aquifers
 - C3 : vertical hydraulic conductivity * area of node * assumed unsaturated flow gradient of 1.0
- o begin calculations for a gaining reach
 - groundwater level (gw) > (hs) river elevation
- o interpolate head from the rating table
- o check that river leakage is consistent with geohydrologic parameters

- o account for leakage between aquifer layers on available storage space
 - o choose minimum river leakage from C1, C2 and C3 algorithms
 - C1 : calculated river leakage from the rating table and groundwater levels
 - C2 : head difference * specific yield + adjustment for leakage between aquifers
 - C3 : vertical hydraulic conductivity * area of node * assumed unsaturated flow gradient of 1.0
 - o repeat calculations of river flow and leakance for each river node for each reach
 - o sum flows along each river reach and print output
-

2.3.11 CONE2.for

Estimates the effect of well drawdown on aquifer heads

Variables and parameters :

c	-	average tdrawdown at a well
cone(iwl)	-	final drawdown at the well
cq	-	pumping rate from each node
delt	-	time in an average month
dh(idl)	-	bedrock elevation
dxer	-	logarithm of the ratio $c / w(i)$: $\log(\text{aquifer thickness} / \text{thickness of aquiclude})$
erdw	-	effective radius of a well
erwr	-	effective radius of node/radius of well
hn(i)	-	groundwater head at each groundwater node
hw	-	groundwater head for an element
id	-	node number
ide(*)	-	node number associated with element (ne)
irdr	-	counter for number of pumping wells based on effective radius, with pumping assigned to a node
it	-	number of nodes associated with an element
iwd	-	node label for nodes with pumping assigned
iwell(iwl)	-	element number assigned to the pumping well
iwl	-	well number index
ji	-	scalar assigned to node of interest
j1	-	scalar assigned to $njd(id+1) - 1$
jnd(j)	-	node numbers surrounding a node
kn	-	assigned a value equal to $(iwell(iwl)-1)/4$
kwl	-	well number assigned to the node of interest
nd	-	number of nodes
njd	-	cumulative number of nodes surrounding each node
nwd	-	number of wells assigned to a node
nwell	-	number of pumping wells
pwe(*)	-	effective well pumping rate
q	-	pumping rate for each element
qpc(kwl)	-	percentage of pumpage assigned to each node
trans(idj)	-	aquifer transmissivity

Subroutine calls :

none

Files read from:

none

Files written to:

tuldvrs.out (25) - stream diversion file

Flowchart :

- o repeat for each pumping well and calculate the drawdown influence of surrounding nodes based on the effective radius
- o repeat for the number of nodes associated with each element
- o repeat for the number of nodes surrounding the node of interest
- o repeat for the number of wells assigned to the node of interest and calculate Q at the assigned node
- o branch around wells if they lie outside the area of interest
- o once through nested loops calculate CQ and HW
- o calculate final heads at the pumping wells due to superposition of drawdown due to other wells surrounding the node, whose effective

radius is being used. Also calculate the drawdown due to the well itself.

- o repeat for the number of wells, the nodes associated with each element and for the confined and unconfined aquifers
 - o calculate drawdown due to other wells. Note that only wells with pumping assigned to the node with effective radius are considered.
 - o repeat for surrounding nodes and branch around any wells of interest
 - o output drawdown results to a file at the end of each month
-

2.4 Groundwater model : solver routine

2.4.1 SOLVE.for

Subroutine for solving the partial differential equation for groundwater flow by the finite element method. The iterative numerical technique used in solving these equations is the Successive Over-Relaxation Method (SOR).

Variables and parameters :

as(idl)	-	specific yield of aquifer / aquifer storage coefficient
at(1lj)	-	hydraulic conductivity in horizontal direction
c	-	calculated head dependent leakance
cb	-	percentage of element area that is under water (lake)
	-	flux at node CA
cd	-	lateral flow calculated from aquifer transmissivity and head gradient
clk(id)	-	vertical leakance
dif	-	maximum head difference between iterations
hn(id)	-	groundwater head at each groundwater node
hp(idl)	-	variable set equal to hn, groundwater head at each node
ibh	-	index variable used as a counter
id	-	node number
ide(*)	-	node number associated with element ne
idl	-	index set equal to id, idl or idr(temporary index)
idlu	-	defined as $idl - nd * ii$
il	-	set equal to $(idl-1)/nd$
itd(i)	-	node number of aquifer below
iter	-	iteration number
iud(idl)	-	index to indicate the status of a node as confined/unconfined or ineffective
jnd	-	node numbers surrounding a node
ld	-	array storage variable set equal to $ily \times nd$
lj	-	defined as $il * nd$
nbh	-	index variable used as counter
nd	-	number of nodes
nj	-	sum of the number of nodes surrounding each GW node
njd(idl)	-	cumulative number of nodes surrounding each node
nld(i)	-	number of effective layers for each node
	-	number of lakes
omega	-	implicit - explicit weighting factor. Omega = 0 for fully explicit and 1 for fully implicit.
qd(idl)	-	source/sink term (pumping etc.)
qhb(i)	-	aquifer influx or efflux due to the source/sink term
qleak(idl)	-	aquifer leakage between semiconfined and confined aquifer
relax	-	relaxation parameter for sor method to accelerate convergence (0 - 2 : typically 1.6)
stopc	-	convergence criterion
w(idl)	-	id for layer (idl)
	-	constant to add to initial condition data for layer 1,2..
wa(*)	-	temporary variable
wb(*)	-	temporary variable
whb(i)	-	flux due the source/sink term from layer i
wleak(idl)	-	cumulative leakance from elements idl
wx(*)	-	temporary variable

Subroutine calls

none

Files read from:

none

Files written to:

tulhead.out (41) - output file of groundwater heads

Flowchart :

- o determine heads in surrounding nodes
 - o calculate the heads at each node iteratively until the difference between successive approximations is less than the convergence criterion (i.e dif is less or equal to stopc)
-

2.5 Groundwater model subroutines : output

2.5.1 OUTC.for

Controls most of the output from the program

Variables and parameters :

as(idl)	-	specific yield of aquifer / aquifer storage coefficient
ca	-	fraction of pumping from column ICOLWL to be applied at well IDUM
cb	-	percentage of element area that is under water (lake)
	-	flux at node CA
cc	-	average head of a lake
dh(idl)	-	bedrock elevation
gnode	-	literal variable set equal to 'g'
hn(idl)	-	groundwater head at each groundwater node
id	-	node number
idl	-	index set equal to id, idl or idr(temporary index)
iflag	-	number of months from beginning of simulation
il	-	index for top layer of element
imo	-	month during the simulation
itime	-	time during the simulation e.g March 1980 = 198006
itwq	-	initial time
itwqa	-	temporary variable set equal to itwq (initial time)
iouth(i)	-	node at which a groundwater hydrograph is to be printed
iouthl(i)	-	layer number for which a groundwater hydrograph is to be printed
iud(idl)	-	index to indicate the status of a node as confined/unconfined or ineffective
iwrth	-	counter for the months at which to write water budgets
kbase	-	switch to use constant head in bedrock
klake	-	number of elements with lakes, input
kout	-	switch to control output
koutr	-	switch to print river nodes as hydrograph output
kouth	-	switch to print groundwater node hydrographs
krain	-	switch to use rainfall
kstr	-	switch to use stream data
kswgw	-	switch to turn calls to groundwater routines on and off
mwrth	-	monthly interval for writing head values
ndl	-	array storage variable (maximum dimension) = nd * nl
ndla	-	temporary variable set equal to nd * (nl - 1)
nl	-	number of layers
nthb	-	number of boundary nodes where constant heads specified
ntmb	-	number of boundary nodes where the relationship between head and flux is specified
ntqb	-	number of boundary nodes where the constant fluxes are specified
p	-	total well pumping in an element
qbase	-	discharge from bedrock at each node
qevap	-	evapotranspiration from each element area
qhb	-	aquifer influx or efflux due to the source/sink term
qlake	-	flux from the lake
qleak	-	aquifer leakage between semiconfined and confined aquifer
qmb	-	flux for rating table and general boundary nodes
qpump	-	total well pumping from an element after accounting for any negative pumping p

qqb	-	flux across the model boundary at a boundary node
qr(*)	-	river flow
qrain	-	quantity of incident rainfall in each element
qrech	-	quantity of aquifer recharge to an element
qrinf	-	gain/loss at each river node in groundwater model
qsurf	-	surface water infiltration
rnode	-	literal variable set equal to 'r'
vbase(il)	-	bedrock leakage term for layer (j)
w(*)	-	id for layer (idl)
	-	constant to add to initial condition data for layer 1,2..

Subroutine calls

outph	-	outputs head values in various forms
outpq	-	computes and prints out an aquifer water budget

Files read from:

none

Files written to:

tulout2.out(6)	-	standard output file
tulhead.out(26)	-	groundwater heads

2.5.2 OUTPH.for

Outputs the head values in different forms

Variables and parameters :

headelm(le)	-	average head for each element (array)
hn(*)	-	groundwater head at each groundwater node
ia	-	node number with diversion
ide(*)	-	node number associated with element ne
ie	-	element number containing a lake
il	-	index for top layer of element
imo	-	month during the simulation
iprnt	-	groundwater node number for which heads are printed
iy	-	do loop counter
kmo	-	character variable for month
ld	-	array storage variable set equal to ily x nd
le	-	element subscript
lpc	-	0 to print heads for all layers
lph	-	switch to print head output (lph=0) matrix format (lph=1)
mpcx	-	number of columns for writing heads (unit 6)
mpcy	-	number of rows for writing heads (unit 6)
nd	-	number of nodes
ndx	-	variable, initially set equal to 20 ; for printer control
ne	-	number of elements
nl	-	number of layers
se(*)	-	area of each groundwater element
w(j)	-	id for layer (j)
	-	constant to add to initial condition data for layer 1,2..

Subroutine calls

none

Files read from:

none

Files written to:

tulout2.out(6)	-	standard output file
----------------	---	----------------------

2.5.3 OUTPQ.for

Computes and outputs the system water budget

Variables and parameters :

an(idl)	-	aquifer specific yield for an unconfined or confined case
area	-	model area
areair	-	irrigated area
as(idl)	-	specific yield of aquifer / aquifer storage coefficient
c	-	average aquifer thickness of each layer
delvol	-	change in storage
dh(idl)	-	bedrock elevation
dht(idl)	-	top elevation of the aquifer for each GW node
factw	-	conversion factor : divides by square feet/acre
hn(idl)	-	groundwater head at each groundwater node
ia	-	node number with diversion
ib	-	node number where diversion applied
ic	-	groundwater node number
id	-	node number
ideltim	-	defined as (last month)/100 - (initial month)/100
idl	-	index set equal to id, idl or idr(temporary index)
idr(i)	-	groundwater node corresponding to each stream node
idwn(irh)	-	node number to which this reach is flowing
ihb	-	node numbers for boundary nodes
ii	-	increments various variables by 1
il	-	index for top layer of element
imb(j)	-	node numbers for rating table boundary nodes
initm	-	first month of simulation
iqb	-	groundwater nodes where flux boundary conditions are specified
ir	-	do loop counter
irh	-	river reach index
itd(id)	-	node number of aquifer below
itime	-	time during the simulation e.g March 1980 = 198006
itwqa	-	initial time
iud(idl)	-	index to indicate the status of a node as confined/unconfined or ineffective
kaply	-	switch to use irrigation applied water data
kbase	-	switch to use constant head in bedrock
klake	-	number of elements with lakes, input
krain	-	switch to use rainfall
kstr	-	switch to use stream data
lastm	-	ending date of the simulation (years/months)
ld	-	array storage variable set equal to ily x nd
ll	-	total number of layers
mwrtcd	-	control for print of detailed discharge data
nd	-	number of nodes
ndl(id)	-	array storage variable (maximum dimension) = nd * nl
nhb	-	number of constant head boundary nodes in each layer
nl	-	number of layers
nmb	-	number of rating table boundary nodes in each layer
nqb(i)	-	number of flux boundary nodes for each layer
nr	-	number of river nodes with stream-aquifer interaction
nrh	-	number of river reaches
taply	-	total water applied to land
tbase	-	seepage inflow from bedrock (annual)
tevap	-	total ET from a shallow water table
tevirt	-	total consumptive use (ET)
thbi(i)	-	constant head boundary (in)

thbo(i)	-	constant head boundary (out)
timp	-	total annual imported water
tlake	-	total annual seepage to lake
t leak(il)	-	total annual leakage between aquifers
tmbi(i)	-	total flux from head controlled boundary (in)
tmbo(i)	-	total flux from head controlled boundary (out)
tpump(i)	-	total groundwater pumping
tqbi(i)	-	total annual discharge from controlled boundary in
tqbo(i)	-	total annual discharge from controlled boundary out
train	-	total annual rainfall recharge to groundwater
traina	-	rainfall (annual values for each region)
trech(i)	-	total artificial aquifer recharge specified by user
trecht	-	total annual groundwater recharge
trloss	-	total annual soil moisture accretion
troff	-	rainfall runoff (annual values for each region)
troffs	-	total annual direct runoff diverted to a stream
tstdiv	-	total annual diversion
tstimp	-	annual stream inflow
tstin	-	annual streamflow loss to aquifer
tstout	-	annual stream outflow
tsurf	-	surface discharge
vbase(il)	-	bedrock leakage term for layer (j)
volf	-	ending storage
voli	-	initial storage
volum	-	storage volume for the node
waply(id)	-	irrigation applied water to layer i at node (id)
wbase(id)	-	discharge from bedrock at each node
wevap(id)	-	evapotranspiration from layer i at node (id)
whb(j)	-	flux due the source/sink term from layer j
wlake(id)	-	seepage to lake from layer i at node (id)
wleak(id)	-	aquifer leakage from layer i at node (id)
wmb(j)	-	boundary flux into or out of layer (j)
wpump(j)	-	volume of pumpage from layer i at node (id)
wqb(j)	-	totalled flux at flux boundary nodes for output water balances
wr(ir)	-	sum of flow in a reach (accumulated river flow)
wrain(id)	-	rainfall incident on layer i at node (id)
wrech(id)	-	recharge to aquifer layer i at node (id)
wrinf(ir)	-	sum of gains and losses from layer i at node (id)
wsurf(id)	-	cumulative surface water infiltration at node (id)
z	-	conversion factor to acre-ft (1/(12*43560))

Subroutine calls
timdat -

Files read from:
none

Files written to:
tulout2.out(6) - standard output file

2.5.4 OUTPV.for

Outputs storage volume for each element

Variables and parameters :

an(idl*)	-	aquifer specific yield for an unconfined or confined case
as(idl*)	-	specific yield of aquifer / aquifer storage coefficient
dh(idl*)	-	bedrock elevation
dht(idl*)	-	top elevation of the aquifer for each GW node
factw	-	conversion factor . divides by square feet/acre
hn(idl*)	-	groundwater head at each groundwater node
ia	-	node number with diversion
ide(*)	-	node number associated with element ne
idl*	-	index set equal to id, idl or idr(temporary index)
itd(*)	-	node number of aquifer below
itime	-	time during the simulation e.g March 1980 = 198006
ie	-	element number containing a lake
k(*)	-	index for adjacent elements
kgwsalt	-	flag set to 1 if the salt model is being used
nd	-	number of nodes
ne	-	number of elements
nl	-	number of layers
nlz	-	counter which increments by ne in do loop
sd(idl*)	-	area associated with each groundwater node
se(*)	-	area of each groundwater element
vbase(il)	-	bedrock leakage term for layer (j)
vol*	-	storage volume for each node of each layer of element ie
vole(le)	-	storage volume of element for layer il of element le
volelm	-	storage volume of element for layer il

Subroutine calls

none

Files read from:

none

Files written to:

tulout2.out(6) - standard output file

2.5.5 IOSUB.for

Facilitates input/output for the program

Variables and parameters :

i	-	index variable used as counter
in	-	unit number
ix(j)	-	variable to be read in
j	-	index variable used as counter
l1	-	printer control variable initial counter value for j
l2	-	printer control variable ending counter value for j
n	-	dimension of variable to be read in
n1	-	set equal to n/256; used as a counter

Subroutine calls

none

Files read from:

in -

Files written to:

none

2.5.6 SKIP.for

Skips 'n' records in a file

Variables and parameters :

junk	-	dummy records
nrecs	-	number of records

Subroutine calls

none

Files read from:

none

Files written to:

none

2.6 Surface Water Model Subroutines

2.6.1 SURFINP.for

Zeros out arrays that need to be cleared and reads data from the input data deck.

Variables and parameters :

agefcrl(nd,mo)	-	agricultural monthly efficiencies for non-critical years (kdnd,12),input
agefnon(nd,mo)	-	agric. monthly efficiencies for non-critical years (kdnd,12), input
agrecf(nd,mo)	-	agricultural recharge factor, (kdnd,12) input
agrpatt(nd,mo)	-	agric. monthly pattern at a node (kdnd,12), input
anagcon(nd)	-	annual agric. contract at a node (kdnd), input
anagdem(nd)	-	annual agric. demand at a node (kdnd), input
andvcsj	-	annual diversion to the Central San Joaquin WD
andvsew	-	annual diversion to the Stockton East WD
anmicon(nd)	-	annual M&I contract at a node (kdnd), input
anmidem(nd)	-	annual M&I demand at a node (kdnd), input
begsim	-	(integer) year in which simulation starts
begyr	-	(integer) year at beginning of run, (1922)
binfil	-	name of binary output file
bstor(n(*))	-	beginning storage for month (kdnd), input
capcty(n)	-	capacity of links (kdnd)
clsgood(i)	-	annual volume of FW flow at Goodwin, 4 values,input
contag(nd,mo)	-	monthly contracted agricultural deliveries at a node product of anagcon(nd) and agrpat(kdnd,12)
contmi(nd,mo)	-	monthly contracted M&I deliveries at a node product of anmicon(nd) and mnipat(kdnd,12)
dismad(mo)	-	array of monthly fractions of Madera Canal (EXPORT 25) water from Millerton going to node 25,remainder goes to node 35, input (12)
dpindx(mo)	-	index of required inflows to Don Pedro reservoir
ev(nd,mo)	-	reservoir evaporation depth (.01 ft) (kdnd,12)
exppat(*,mo)	-	monthly export pattern from Goodwin, (12), input
fkmspl(i)	-	fraction of Class 1 and Class 2 water going to Friant-Kern Canal. remainder goes to Madera Canal (EXPORT 25). input, (5)
floodfil	-	name of file with time series of flood control rule storages
frusret(j,nd)	-	array of percentage of return from an u/s node going to the current node, (kdusr,kdnd)
fwclas(nd,mo,i5)	-	array of fw req.values at 7 levels (kdnd,12,7),input
fwfil	-	name of file with F&W data
fwgood(mo,i)	-	monthly fraction of annual FW flow at Goodwin, monthly values for each CLSGOOD, (12,4) input
fwequn(nd)	-	array of fw req. "equations" in character variables, (kdnd), input
fwpars(iyr,mo,nd,rstor)	-	parses the "equation" in the fish and wildlife (FW) input routine into a value for TRIGGR
fwtrig(nd,i5)	-	array of fw req. trigger values (kdnd,7), input
gainfil	-	name of file with time series of GAINS
glogfil	-	name of run log file for GW portion
goodfil	-	name of Goodwin Dam data file
gwtsfil	-	name of file with time series of historical GW pump
inode	-	temporary variable for node number

inffil	-	name of file with time series of inflows
kdummy	-	dummy variable
kfrfst	-	forecast option for Millerton inflows
kfwfor(mo)	-	fish and wildlife water requirements (12)
knodcp(i)	-	array of nodes with capacities (kdnd)
knodcvp(i)	-	array of nodes with CVP demands (kdnd)
knoddm(i)	-	array of nodes with demands (kdnd)
knodfw(i)	-	array of nodes with F&W req. (kdnd)
knodgn(i)	-	array of nodes with gain (kdnd)
knodpts(i)	-	array of nodes with time series of historical GW pumping
knodin(i)	-	array of nodes with inflow (kdnd)
knodnp(i)	-	array of nodes with nonproject demands (kdnd)
knodpmp(i)	-	array of nodes with GW pumping (kdnd)
knodprj(i)	-	array of nodes with project demands (kdnd)
knodrs(i)	-	array of nodes with reservoirs (kdrs)
knodtul(i)	-	list of node numbers of Tulare DAUs, input, (kdnd)
knzero	-	switch to set negative nonproject demands to zero
kstop	-	switch to stop program whenever an error in input occurs
kswhist(n)	-	switch to set reservoir storages to historic input, input (kdnd)
kswpow	-	switch to turn calls to power routines on and off
kswsalt	-	switch to output sw data for Salt Balance model
kswsmlt(n(*))	-	array of binary switches to turn on snowmelt routine (kdnd)
lastyr	-	last year in simulation
madxpat(mo,i)	-	(real) monthly pattern of Madera Canal exports, input, (12,5)
maxusnd	-	maximum upstream nodes
maxusrt	-	maximum number of nodes with returns immediately upstream from current node
miefnon(nd,mo)	-	monthly M&I efficiency for non-critical years, (kdnd,12) input
miefcri(nd,mo)	-	M&I efficiency for critical years, (kdnd,12) input
milfil	-	name of file for Millerton operation data
mirecf(nd,mo)	-	M&I recharge factor, (kdnd,12) input
mnipat(nd,mo)	-	(real) M&I monthly pattern at a node (kdnd,12),input
ncap	-	number of nodes with capacities
ncvpdm	-	number of CVP demand nodes
nd	-	number of nodes
ndd	-	temporary variable for node number
ndchek1	-	temporary variable for node check or input data
ndemd	-	number of nodes with demand
ndnum(i)	-	array of node numbers (kdnd)
nfw	-	number of nodes with fish & wild require. (min flow)
ngain	-	number of nodes with gains
ngwts	-	number of nodes with time series of GW pumping
ninfl	-	number of nodes with inflow
nj	-	defined as n(usret(j,nd))
nnodes	-	number of nodes in the model
nnpdem	-	number of nonproject demand nodes
npdmfil	-	file containing non-project time series demand data
npefcric(nd,mo)	-	(real) non-project critical year monthly efficiencies (kdnd,12)
npefnon(nd,mo)	-	(real) non-project non-critical year monthly efficiencies (kdnd,12)
nprecf(nd,mo)	-	non-project recharge factor

nprjdm	-	number of nodes with project demands
nprjts	-	number of nodes with time series of project demands
npump	-	number of nodes with GW pumping
nres	-	number of reservoirs
nstts	-	number of reservoirs for which historic storages are to be used in the simulation
ntuldm	-	number of Tulare-area DAUs
nusnod(nd)	-	number of immediately upstream nodes (kdnd)
nusret	-	number of immediately u/s nodes with returns going to current node
nyear	-	number of years in simulation, LASTYR-BEGSIM+1
ossjdem	-	maximum annual diversion from Goodwin, input
ossjspl	-	split of Goodwin diversions between Oakdale-South (delivery to 110) and Oakdale-North plus South San Joaquin (EXPORT 110)
pdel(nd,mo)	-	Total project delivery to all demand nodes (kdnd,12) sum of pdelmi(nd,mo) and pdelag(nd,mo)
pdelag(nd,mo)	-	adjusted project deliveries (agri.) (kdnd,12)
pdelmi(nd,mo)	-	adjusted project deliveries (M&I) (kdnd,12)
pdmfil	-	name of file with project demand data
pdtstfil	-	name of file with time series of project demands
powrfil	-	name of file with CVP system power variables
pumpfil	-	name of file with min. and max. GW pumping data
qpow(nd,mo)	-	release limit for hydropower (kdnd,12)
qpowdef	-	default value for qpow
redcsse	-	deficiencies used for Central San Joaquin and Stockton East Water Districts based on water year type
resfil	-	name of file with reservoir data
riprn55(i)	-	riparian demands on Merced river at node 55, input
rstor(n(*))	-	current month (running) reservoir storage (nd)
rttitle	-	run title, 80 characters
saltfil	-	name of binary file written for use with the salt routine
schmfil	-	name of file with data from PROSIM
slogfil	-	name of run log file for surface model
spcvec(*,n(*))	-	vector of outlet capacities for space rule calls at three locations (nodes 40,95 and 125) (3,kdnd)
spvtuol(*)	-	space vector on Tuolumne river system
srule(nd,mo)	-	storage rule (kdnd,12)
starcf(nd,j)	-	storage-area curve coefficients
stelcf(nd,j)	-	storage-elevation curve coeffs. (kdnd,4)
strf(n(*))	-	storable inflows to reservoirs (kdnd)
tn	-	temporary variable for tfr
tfr	-	upstream return flow fraction array, input
tpdem(nd,mo)	-	target monthly project demand (kdnd,12)
tpdmag(nd,mo)	-	target monthly project agricultural demand (kdnd,12)
tpdmml(nd,mo)	-	target monthly project M&I demand (kdnd,12)
tuldfil	-	name of file with the Tulare data
usndfil	-	name of file with the upstream node data
usnode(j,nd)	-	(integer) node numbers of nodes immediately upstream of current node (kdusn,kdnd)
usret(j,nd)	-	(integer) node numbers of nodes with returns immediately upstream of current node (kdusn,kdnd)
wqtar(mo)	-	monthly water quality target at node 27, Vernalis (mg/l) (12)
wyrfil	-	name of file with year types
ypmpnp(nd,*)	-	minimum annual non-project groundwater pumping for a demand node (3 year types input) (kdnd,3)

ypmpp(nd,*)	-	minimum annual project groundwater pumping for a demand node (3 year types input) (kdnd,3)
yrtype(k)	-	integer array of year types, input (kdyr)
ystor(n(*))	-	minimum storage (kdnd)
ystrsv(nd,mo)	-	minimum reservoir reserve storage (kdnd,12)
xpmpnp(nd,*)	-	maximum annual non-project groundwater pumping for a demand node (3 year types input) (kdnd,3)
xmppp(nd,*)	-	maximum annual project groundwater pumping for a demand node (3 year types input) (kdnd,3)
xqpow(n(*))	-	hydraulic capacity of powerhouse (kdnd)
xstor(n(*))	-	maximum reservoir storage (kdnd)

Subroutine calls :

initial	-	initializes a series of arrays to zero
zerol	-	zeros out a one dimensional array
skipln	-	skips three input lines
ndchek2	-	checks node correspondence in time series files
ndchek1	-	checks node correspondence in non time series files

Files read from:

tulare.con	-	control data file for SANTUCM
slogfil	-	file for error check data
glogfil	-	file for error check data
usndfil	-	upstream node data table
resfil	-	reservoir data table
fwfil	-	fish and wildlife data
npdmfil	-	non-project demand file
pdmfil	-	project demand file
tuldfil	-	Tulare area demand data
pdtsfil	-	project demand time series file
pumpfil	-	groundwater pumping file
gwtsfil	-	groundwater pumping time series file
sttsfil	-	historical storage time series file
goodfil	-	Goodwin operations data
milfil	-	Millerton operations data
inffil	-	Millerton inflows
gainfil	-	Millerton gains
flodfil	-	Millerton flood control
schmfil	-	PROSIM output file
wyrfil	-	water year type

Files written to:

binfil	-	binary output file
saltfil	-	binary output file

Summary flowchart :

- o initialize arrays to zero
- o read node table
- o check for errors and that the return fraction (FRUSRET) for each node adds to either 0.0 or 1.0
- o read in all data that is read in only once
- o read rules for power operations and convert beginning storages (BSTOR) to running storages (RSTOR)
- o read storage targets, minimum storage reserves, evaporation data
- o read storage-area and storage-elevation regression equations
- o read fish and wildlife, non-project and project demand data
- o compute monthly nodal demands from annual and distribution data

- o read Tulare area demand node data - class 1 and class 2 distributions for each node
- o read the surface diversion data (DIV) by source and sink
- o read groundwater pumping file for both project and non-project demand nodes
- o read groundwater pumping time series
- o read historical time series of reservoir storage
- o read Goodwin Dam (node 110) data and Goodwin fish and wildlife release data
- o read Millerton Lake operations data
- o read time series files for inflow, gains, flood control, PROSIM output and the water year type

2.6.2 SURFACE.for

SURFACE performs the surface water routing by making calls to other subroutines.

Variables and parameters :

arel(n(*))	-	array of additional releases needed to meet requirements, computed, (kdnd)
begsim	-	(integer) year in which simulation starts
begyr	-	(integer) year at beginning of run, input (1922 -)
bstor(nd)	-	beginning storage for month (kdnd), input - computed every year
contag(nd,mo)	-	monthly contracted agricultural deliveries at a node product of anagcon(nd) and agrpat(nd,mo)
delsum(nd,mo)	-	monthly water delivery to each node
div(1,n(*),mo)	-	surface diversion from source to sink in a month (kdsr, kdnd, 12)
export	-	exports (kdnd, 12)
fkdaup(*, kdsnk)	-	monthly delivery pattern for Friant-Kern Canal water to each DAU, input
flowin(nd)	-	flow entering a node (kdnd)
forinf(nd,mo)	-	forecasted inflow from current month to the end of the water year, (kdnd, 12)
fwreq(nd,mo)	-	flowby requirements for f&w (kdnd, 12)
gain(nd,mo)	-	gains (kdnd, 12), input
gwpts(nd,mo)	-	monthly groundwater pumping time series for each node
histsto(n(*),mo)	-	monthly reservoir historic storages
inflo(n(*),mo)	-	(real) inflows to reservoirs, (kdnd, 12), input
indxrp	-	temporary variable for node 55, riparian diversion index
iy	-	year during the simulation
kdnd	-	dimension on nodes
kdsnk	-	dimension on number of DAUs receiving water from a source in the Tulare area
kfrfst(mo)	-	used for F&W req. computations (12)
kfwfor(mo)	-	same as KFRFST, used for F&W req. computations (12)
knodgn(i)	-	array of nodes with gain (kdnd)
knodin(i)	-	array of nodes with inflow (kdnd)
knodnp(i)	-	array of nodes with nonproject demands (kdnd)
knodpts(id)	-	array of nodes with time series of project demands (kdnd)
knodrs(in)	-	array of nodes with reservoirs (kdrs)
knzero	-	switch to set negative nonproject demands to zero
milinf(mo)	-	natural monthly inflow into Millerton assuming no upstream storage, real, input (12)
nfw	-	number of nodes with fish & wild require. (min flow)
ngwts	-	number of nodes with time series of GW pumping
npdel(nd,mo)	-	(real) nonproject deliveries (kdnd, 12), input
npgnus(nd,mo)	-	(real) non-project gain (kdnd, 12)
npinus(nd,mo)	-	(real) non-project inflow (kdnd, 12)
nprjdm	-	number of nodes with project demands
nprjts	-	number of nodes with time series of project demands
nres	-	number of reservoirs
nsink(*)	-	number of DAUs getting water from a sink, input, (kdsr)
nstts	-	number of reservoirs for which historic storages are used
pagus(nd,mo)	-	project surface water used by agriculture (kdnd, 12)
pdel(nd,mo)	-	Total project delivery to all demand nodes (kdnd, 12)
pdelag(nd,mo)	-	adjusted project deliveries (agri.) (kdnd, 12)

pdelmi (nd,mo)	-	adjusted project deliveries (M&I) (kdnd,12)
pmius (nd,mo)	-	project surface water used for M&I (kdnd,12)
red	-	reduction in project delivery due to year type
repn55	-	riparian diversions on the Merced river, node 55
reqrel (n(*))	-	extra releases needed to meet fish and wildlife required in-stream flows (FWREQ). (kdnd)
rgain	-	remaining gain at a node (kdnd)
rinf	-	remaining inflow at a node (kdnd)
rnpret	-	remaining non-project returns at a node(kdnd)
rpret	-	remaining project returns at a node(kdnd)
rstor (nd)	-	accumulator variable for reservoir storage (kdnd)
schmflo (i,mo)	-	schmflo - array of monthly DMC and CAQ deliveries computed in PROSIM, input, (9,12)
spill (n(*),mo)	-	spillage at node (*)
srule (nd,mo)	-	storage rule (kdnd,12)
stor (nd,mo)	-	end of month storages : output (kdnd,mo)
tempag (nd,mo)	-	temporary variable ag deliveries output (kdnd,12)
tempdel (nd,mo)	-	temporary variable total deliveries output (kdnd,12)
tempdvl (j,mo)	-	temporary variable diversions output (kdnd,12)
tempex (nd,mo)	-	temporary variable exports output (kdnd,12)
tempfw (nd,mo)	-	fish and wildlife requirements (FWREQ):output (kdnd,12)
tempmi (nd,mo)	-	municipal and industrial demand (PDELM):output (kdnd,12)
tpdem (nd,mo)	-	target monthly project demand (kdnd,12)
tdpmag (nd,mo)	-	target monthly agricultural demand (kdnd,12)
tdpmmi (nd,mo)	-	target monthly M&I demand (kdnd,12)
upstore (mo)	-	storage in reservoirs u/s from Millerton, input (12) used to compute Millerton flood storages and spills
xaggw (nd,mo)	-	maximum monthly agricultural GW pumping, (kdnd,12)
xstfld (nd,mo)	-	flood control rule (kdnd,12)
yaggw (nd,mo)	-	minimum monthly agricultural GW pumping, (kdnd,12)
yrtype (iyr)	-	(integer) array of year types, input (kdyr)
ystor (nd)	-	minimum storage (kdnd)

Subroutine calls :

zerol	-	zeroes out a one dimensional array
mildelv	-	computes class1 and class2 water leaving Millerton Lake bound for Friant-Kern Canal and Madera Canal.
cvpdel	-	performs the CVP demand reduction
pumpmax	-	sets the minimum and maximum groundwater pumping for each node
goodwin	-	computes exports at Goodwin Dam (node 110) and the fish and wildlife requirement (FWREQ) for the node
fwpars	-	parses the "equation" in the fish and wildlife (FW) input routine into a value for TRIGGR
sjroute	-	performs the routing for the entire system except for the Stanislaus and Calaveras rivers
csroute	-	performs routing for the Calaveras and Stanislaus rivers
spcall	-	calculates required releases according to the space rule
floadj	-	recalculates flows due to space routine calls

Files read from:

none

Files written to:

(44) - write running storages into storage array.

Summary flowchart :

- o compute maximum available water supply each month to determine spill
- o reinitialize arrays to zero to zero out remaining usable gain
- o set beginning storage to running storage volume
- o if the switch knpzero is zero set negative non-project demands to zero
- o recompute monthly nodal demands for nodes with time series data
contracted and adjusted agricultural deliveries are set equal to target deliveries
- o call subroutine Mildelv to calculate Millerton exports if starting simulation or in month 6 (March) of any other year
- o call cvpdel to compute CVP deficiencies,
- o call pumpmax set minimum and maximum pumping and storage rules
- o set the flood control rule equal to the storage rule, if xstfld = 0
- o for nodes with time series data maximum and minimum agricultural groundwater pumping values are replaced with the time series values
- o call goodwin to compute exports at nodes 150 and 155 and the fish and wildlife flow requirement at node 110 at march (mo=6) of each year
- o monthly riparian demands at node 55 are met by releases made by Merced ID according to a monthly schedule between February and September
- o sjroute and csroute called to perform surface water routing
- o perform flow and running storage adjustments and calculate additional releases required from the reservoir.
- o call the space rule to determine required releases
- o write forecast deliveries, exports and diversions to temporary arrays
- o calculate spill as the difference between actual reservoir releases and that needed to meet deliveries and fish and wildlife requirements.
- o return to main program

2.6.2.1 Subroutine timeinp.for

Variables and parameters :

gain(n(*),mo)	-	monthly gain
gwpts(n(*),mo)	-	monthly groundwater pumping time series for each node (kdnd,12)
histsto(n(*),mo)	-	monthly reservoir historioic storages (kdnd,12)
inflo(n(*),mo)	-	(real) inflows to reservoirs, (kdnd,12), input
iyrr	-	year during the simulation
knodrs(i)	-	array of nodes with reservoirs (kdrs)
knodgn(i)	-	array of nodes with gain (kdnd)
knodgts(i)	-	array of nodes with time series of historical GW pumping (kdnd)
knodin(i)	-	array of nodes with inflow (kdnd)
knodnp(i)	-	array of nodes with nonproject demands (kdnd)
knodpts(i)	-	array of nodes with time series of project demands (kdnd)
milinf(mo)	-	natural monthly inflow into Millerton, assuming no upstream storage, real, input, (12)
ngain	-	number of nodes with gains
ngwts	-	number of nodes with time series of GW pumping
ninfl	-	number of nodes with inflow
nnpdem	-	number of nonproject demand nodes
nprjts	-	number of nodes with time series of project demands
nres	-	number of reservoirs
nstts	-	number of reservoirs for which historic storages are used
schmflo(i,mo)	-	array of monthly DMC and CAQ deliveries computed in PROSIM, input, (9,12)
tpdmag(n(*),mo)	-	target project agricultural demand (kdnd,12)
upstore(mo)	-	storage in reservoirs u/s from Millerton, input, (12) used to compute Millerton flood storages and spills
xstfld(n(*),mo)	-	flood control rule (kdnd,12)

Subroutine calls :

none

Files read from :

millr	(39)	-	Millerton data
inflo	(32)	-	inflow
gain	(33)	-	gains
xstfld	(34)	-	flood control rules
npdel	(38)	-	demands
tpdmag	(40)	-	project agricultural demands
schism	(37)	-	PROSIM node data
gwpts	(42)	-	groundwater pumping time series
histsto	(43)	-	historical storage time series

Files written to:

none

Summary flowchart :

- o read monthly Millerton data
- o read time series data
- o if the groundwater model is being used calculate the gains for all nodes except for nodes 70, 110 and 140.
- o read flood control rules

- o read demand data
- o read PROSIM node data
- o read project agricultural demand data
- o read groundwater pumping time series
- o read historical storage time series

2.6.3 SJROUTE.for

Performs the flow routing for the middle San Joaquin subsystem with the exception of the Stanislaus and Calaveras Rivers. The middle San Joaquin subsystem includes the San Joaquin river from Millerton to the confluence with the Stanislaus River including Chowchilla, Fresno, Merced and the Tuolumne rivers. Water is first routed through Millerton to determine Millerton releases and the exports to the Madera and Friant-Kern Canals. Hidden and Buchanan reservoirs are operated according to the rules. Releases are made from Exchequer on the Merced River to meet demands downstream (nodes 45,50,55). The Tuolumne River is simulated next (nodes 60,65,70,75,80,85,90,95). Hetchy-Hetchy and Cherry/Eleanor lakes are used in historical operations because they are used heavily for power. Don Pedro is operated according to rules - water is diverted into Turlock and Modesto reservoirs during wet months to accumulate as much storage as possible.

The subroutine is divided into eight sections labelled SJROUTE1 -

SJROUTE8. These sections are organized as follows:

SJROUTE1	-	Millerton operations
SJROUTE2	-	Hidden and Buchanan operations
SJROUTE3	-	Nodes 10 and 15. Flow not needed to meet demands at 10 and 15 is sent down the eastside bypass.
SJROUTE4	-	Merced river operations
SJROUTE5	-	Tuolumne river operations.....

Variables and parameters :

adex*	-	additional export to node *
area(n(*))	-	reservoir surface area (kdnd)
arel(n(*))	-	array of additional releases needed to meet requirements, computed, (kdnd)
avds	-	difference between FLOW 95 and FWREQ 95. This is the amount "available" to export to 80 or 85
avs80	-	availability for more storage in Modesto
avs85	-	availability for more storage in Turlock
avstot	-	sum of AVS80 + AVS85
bstor(n(*))	-	beginning storage for month (kdnd), input - computed every year
capcty(n(*))	-	capacity of links (kdnd)
class1	-	total annual Millerton class1 deliveries
class2	-	total annual Millerton class2 deliveries
d80	-	surface water used to meet demands at node 80
d85	-	same as D80 for node 85
def80	-	deficit at 80, volume needed to bring storage up to rule and supply demand
def85	-	same as DEF80 but for Turlock
dely	-	demands satisfied directly from reservoir for New Don Pedro, Modesto, and Turlock
diff	-	difference computed for Millerton releases and storages
dismad(mo)	-	array of monthly fractions of Madera Canal (EXPORT 25) water from Millerton going to node 25, remainder to node 35, input (12)
goes	-	surface diversion from source to sink in a month (kdsrc,kdnd,12)
div(1,md,mo)	-	flow from Mendota pool into node 15, (12)
dmcq(mo)	-	index used to compute the SJR four-river index
dpindx(mo)	-	reservoir evaporation depth (.01 ft) (kdnd,12)
ev(n(*),mo)	-	reservoir evaporation (KAF) (kdnd,12)
evap(n(*),mo)	-	sum of EXPORT 25 and EXPORT 35
ex2535	-	exports (kdnd,12)
export(n(*),mo)	-	

extrel	-	extra release made from any reservoir
fkcl(mo)	-	monthly volume of Friant-Kern Class1 flow (12)
fkcl2(mo)	-	monthly volume of FKC Class 2 flow (12)
flow(n(*),mo)	-	flow leaving a node (kdnd,12), doesn't include returns from that node
frac	-	fractions used for flow adjustments at nodes 5, 20 and 30
kswhist(n(*))	-	switch to set reservoir storages to historic input, input (kdnd)
fwreq(n(*),mo)	-	flowby requirements for f&w (kdnd,12)
gain(n(*),mo)	-	gains (kdnd,12), input
inflo(n(*),mo)	-	(real) inflows to reservoirs, (kdnd,12), input
iy	-	year during the simulation
lsink(1,j)	-	node numbers of DAUs getting water from a sink, input, (kdsr, kdnd)
madcl(mo)	-	monthly volume of Class 1 flow in Madera Canal (12)
madcl2(mo)	-	monthly volume of Class 2 flow in Madera Canal (12)
nd	-	current node number
npdel(n(*),mo)	-	(real) nonproject deliveries (kdnd,12), input
npref(n(*),mo)	-	non-project return flow
nsink(1)	-	number of DAUs getting water from a sink, input, (kdsr)
numres(*)	-	node numbers of reservoirs in space call
pagmil5	-	sum of Ag. and M&I surface deliveries at node 15
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pdelmi(n(*),mo)	-	adjusted project deliveries (M&I) (kdnd,12)
pmius(n(*),mo)	-	project surface water used for M&I (kdnd,12)
pret(n(*),mo)	-	project returns (kdnd,12)
rgain(n(*))	-	remaining gain at a node (kdnd)
reqrel(n(*))	-	extra releases needed to meet fish and wildlife required in-stream flows (FWREQ). (kdnd)
rstor(n(*))	-	running storage (kdnd)
srule(n(*),mo)	-	storage rule (kdnd,12)
spill(10)	-	spillage at node 10
tempfeb	-	adjustment to Millerton Feb. flood storage
temphi	-	adjustment to Millerton flood storage
templo	-	adjustment to Millerton flood storage
texport	-	total exports for Millerton
tin	-	total inflow to reservoir
xstor(n(*))	-	maximum reservoir storage (kdnd)
yrtype(iyr)	-	(integer) array of year types, input (kdyr)
ystor(n(*))	-	minimum storage (kdnd)

Subroutine calls :

resvr	-	computes reservoir releases based on the rule curves
smaray	-	sums returns from upstream connected nodes
tlroute	-	allocates surface and groundwater deliveries to the Tulare nodes
sannode	-	allocates flow to demands from various sources

Files read from:

none

Files written to:

none

Summary flowchart :

- o operate Millerton :
- o calculate exports to the Friant-Kern Canal and Madera canal. Call RESVR to compute reservoir releases based on rule curves.
- o If below the minimum pool reduce class 2 diversions first, then class 1 diversions. Reduce exports to Tulare DAU's and set storage to prevent violation of minimum and maximum storage pool.
- o call TLROUTE to compute deliveries to non-SANJASM nodes.
- o operate Hidden and Buchanan sequentially
- o call subroutines RESVR, SMARAY and SANNODE in sequence to compute deliveries from Hidden and Buchanan reservoirs
- o calculate flows from from nodes 20 and 30 and make Millerton exports available at downstream nodes
- o operate Mendota Pool
- o compute Mendota demands and eastside bypass exports
- o if demand at node 15 is met by Fresno slough inflows then meet demands at node 15 from node 10 spills and the remainder from DMC deliveries. Adjust flow to node 15 by the DMC required releases. If demand is not met at node 15 set the spill down the SJR to zero and route flow down the East Side Bypass.
- o operate Exchequer
- o call subroutines RESVR, SMARAY and SANNODE in sequence to operate Exchequer by rules and determine monthly releases.
- o operate Hetchy-Hetchy and Cherry/Eleanor
- o call subroutines RESVR, SMARAY and SANNODE in sequence to operate Hetchy-Hetchy and Cherry/Eleanor by rules and to determine monthly releases.
- o if not using historic time series data then operate reservoirs by rules. When insufficient water is entering New Don Pedro increase the release from both reservoirs using the space rule.
- o divert available Tuolumne flow into Modesto and Turlock ID's using the rules.
- o operate lower portions of the Tuolumne and Merced using rules.
- o calculate available storage in Modesto and Turlock. If storage space is available, determine excess flows available and recalculate river flows if these are utilized.

2.6.4 TLROUTE.for

Allocates surface and ground water deliveries to the Tulare nodes.

2.6.4.1 Subroutine tlroute(iyr,iyt,exports)

Variables and parameters :

div(isrc,nd,mo)	-	surface diversion from source to sink in a month (kdsrc,kdnd,12)
export5	-	exports at node 5
flow(n(*),mo)	-	flow leaving a node (kdnd,12), doesn't include returns from that node
fsnkcls	-	monthly percentage of annual FKC going to a given DAU, input, (kdsnk,12)
gain(n(*),mo)	-	gains (kdnd,12), input
inflo(n(*),mo)	-	(real) inflows to reservoirs, (kdnd,12), input
isrc	-	source of water for any DAU
iyt	-	temporary variable for year type
jbpexs(mo)	-	excess flow that cant go down the James Bypass (12)
jiter	-	iteration counter
knodtul(in)	-	list of node numbers of Tulare DAUs, input, (kdnd)
ktype	-	year type for Tulare demands
lsink(isrc,j)	-	node numbers of DAUs getting water from a sink,input, (kdsrc,kdnd)
nd	-	current node number
nsink(isrc)	-	number of DAUs getting water from a sink,input, (kdsrc)
nsource	-	number of sources of water in the Tulare area,input
ntuldm	-	number of Tulare-area DAUs
schmflo(*,mo)	-	array of monthly DMC and CAQ deliveries computed in PROSIM, input, (9,12)
sdelv(nd,mo)	-	total surface delivery into a DAU, (kdnd,12)

Subroucine calls :

tsource	-	computes the volume of surface delivery from a Tulare source to a Tulare demand node
tulnode	-	allocates flow to demands from various sources. Demand nodes are project or non-project.

Files read from:

none

Files written to:

none

Summary flowchart :

- o Set inflow (INFLO) to nodes along the Delta Mendota Canal and California Aqueduct to SCHMFLO from PROSIM
- o Call TSOURCE for each "source" other tah the Friant-Kern Canal and nodes 216 and 217 to compute DIV(i,j), the diversion from source i to sink (DAU) j.
- o Set DIV for nodes 216 and 217.
- o Compute surface delivery (SDELV) for each Tulare node (DAU) as the sum of the diversions (DIV) from each source into the node (sink).
- o Along the Friant-Kern canal, set the Flow leaving the node as the FLOW leaving the upstream node minus the diversion (DIV). Do this for each node along the Friant-Kern Canal except 300, 320 and 330; these are confluences with Kings, Koweah and Tule rivers.
- o Set FLOW values along the Kings River.
- o Set FLOW values along the Koweah, Tule and Kern Rivers.

- o Set FLOW values along the Cross Valley Canal, California Aqueduct and Delta Mendota Canal.
- o Call TULNODE to set surface and groundwater usages at each node, PMIUS, PAGUS, PMIGW and PAGGW.

2.6.4.2 Subroutine tsource(xflow,isrc,mo,ktype)

Variables and parameters :

isrc	-	source of water for any DAU
ktype	-	year type for Tulare demands
nsink(isrc)	-	number of DAUs getting water from a sink,input,(kdsrc)
tsrcsnk(isrc,j, mo,ktype)	-	fraction of flow from a source to a DAU for a month and year type, input, (kdsrc,kdsnk,12,3)
xflow	-	total flow available at one of the 12 sources to supply a DAU

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o Set surface diversion (DIV) to flow into source (XFLOW) * fraction of flow from each source to given sink (node), variable TSRCSENK.

2.6.4.3 Subroutine tulnode(lyr,nd,mo,iyt)

Variables and parameters :

agefnon(nd,mo)	-	agricultural use efficiency for non-critical years (kdnd,12)
agrecf(nd,mo)	-	agricultural water recharge factor (kdnd,12)
lyr	-	year during the simulation
iyt	-	temporary variable for year type
knodtrd	-	array of Tulare demand nodes
miefcri(nd,mo)	-	M&I use efficiency for critical years (kdnd,12)
miefnon(nd,mo)	-	M&I use efficiency for non-critical years (kdnd,12)
mirecf(nd,mo)	-	M&I water recharge factor (kdnd,12)
nd	-	node numbers
npef	-	non-project efficiency
npefcric(nd,mo)	-	non-project efficiency for critical years (kdnd,12)
npefnon(nd,mo)	-	non-project efficiency for non-critical years (kdnd,12)
ntr	-	node flag for Tulare demand nodes
ntred	-	number of Tulare demand deficiency nodes
pagef	-	project agricultural use efficiency
paggw(nd,mo)	-	project groundwater used by agriculture (kdnd,12)
pagsht(nd,mo)	-	project agricultural shortage (kdnd,12)
pagus(nd,mo)	-	project surface water used by agriculture (kdnd,12)
pdel(nd,mo)	-	Total project delivery to all demand nodes (kdnd,12)
pdelag(nd,mo)	-	adjusted project deliveries (agri.) (kdnd,12)
pdelmi(nd,mo)	-	adjusted project deliveries (M&I) (kdnd,12)
pmief	-	project M&I efficiency
pmigw(nd,mo)	-	project groundwater used for M&I (kdnd,12)
pmisht(nd,mo)	-	project M&I shortage (kdnd,12)
pmius(nd,mo)	-	project surface water used for M&I (kdnd,12)
pret(nd,mo)	-	project returns (kdnd,12)
sdelv(nd,mo)	-	surface water delivery into a node
tpdmag(nd,mo)	-	target project agricultural demand (kdnd,12)
tpdmmi(nd,mo)	-	target project M&I demand (kdnd,12)
tred(nred,*)	-	array of Tulare demand deficiency nodes (ntred)
tulred	-	deficiency factor
xaggw(nd,mo)	-	maximum monthly agricultural GW pumping, (kdnd,12)
xmigw(nd,mo)	-	maximum monthly M&I groundwater pumping (kdnd,12)

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o Set efficiencies based on year type
- o Set deficiency factor (TULRED) for flagged nodes
- o Set project surface water usage (PMIUS) and project agricultural water usage PAGUS from surface water deliveries (SDELV)
- o Set project groundwater use by agriculture (PAGGW) and project groundwater use by M&I according to demands and surface usage
- o Determine shortages and returns

2.6.5 CSROUTE.for

Performs the flow routing for the Calaveras and Stanislaus Rivers.

Variables and parameters :

(subroutine variables, all computed)

area(n(*))	-	reservoir surface area (kdnd)
avd*	-	water available to meet demand at ** from node *
avex*	-	amount of storage in * that's available to meet demand at node *
avs*	-	availability to increase storage in *
bnck*	-	"bottleneck" in link connecting nodes 110 and *, which is the remaining capacity in the link
capcty(n(*))	-	capacity of links (kdnd) (channel capacity, input)
d*	-	"bottleneck" in link connecting nodes 110 and *, which is the remaining capacity in the link
def*	-	"deficit" at node * that can't be met
deficit	-	amount of TDEM150 that can't be met
delv	-	demand met directly from a reservoir
diff*	-	difference computed between reservoir releases and storages
ev(n(*),mo)	-	reservoir evaporation depth (.01 ft) (kdnd,12)
evap(n(*),mo)	-	reservoir evaporation (KAF) (kdnd,12)
export(n(*),mo)	-	exports (kdnd,12)
extra*	-	EXPORT from node 110 that can't be exported
flow(n(*),mo)	-	flow leaving a node (kdnd,12), doesn't include returns from that node
fvol*	-	free volume for increased storage in *
fwreq(n(*),mo)	-	minimum flow requirement to meet fishery flow (kdnd,12)
inflo(n(*),mo)	-	(real) inflows to reservoirs, (kdnd,12), input
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pmius(n(*),mo)	-	project surface water used for M&I (kdnd,12)
req*	-	additional releases needed to meet F&W required in-stream flows to account for any exports from the node
reqrel(n(*))	-	total releases needed to meet fish and wildlife required in-stream flows (FWREQ) accounting for any exports from the node. (kdnd)
rstor(n(*))	-	current month reservoir storage (kdnd,12)
texpt	-	total exports from Goodwin reservoir facilities
tdem*	-	sum of surface deliveries to node *
xstor(n(*))	-	maximum reservoir storage (kdnd)
ystor(n(*))	-	minimum reservoir storage (kdnd)
ynpgw(n(*),mo)	-	minimum non-project pumping (kdnd,12)

Subroutine calls :

realloc	-	reallocates deliveries and shortages and adjusts monthly deliveries
resvr	-	computes reservoir releases based on the rule curves
smaray	-	sums returns from upstream connected nodes
sannode	-	allocates flow to demands from various sources

Files read from:

none

Files written to:

none

Summary flowchart :

- o Set inflow (INFLO) to nodes along the Delta Mendota Canal and California Aqueduct to SCHMFLO from the PROSIM model
- o Call subroutine TSOURCE for each "source" other than Friant - Kern and nodes 216 and 217 to compute the diversions DIV(i,j) from source i into sink DAU(j)
- o Set diversions DIV(i,j) at nodes 216 and 217
- o Compute surface deliveries (SDELV) for each Tulare node (DAU) equal to the sum of the diversions from each source into the node (sink)
- o Along the Friant-Kern Canal, determine the flow leaving the node by subtracting the diversion (DIV) from the flow leaving the upstream node. This is done for each node along the Friant-Kern Canal except nodes 300, 320 and 330, which are confluences with the Kings, Koweah and Tule Rivers
- o Set flows along the Kings River
- o Set flows along the Koweah, Tule and Kern Rivers
- o Set flows along the Cross Valley Canal, California Aqueduct and Delta Mendota Canal
- o Call subroutine TULNODE to set surface and groundwater usage at each node, PMIUS, PAGUS, PMIGW and PAGGW

2.6.6 MOD1.for

This module contains the subroutines which provide the operating rules for water allocations and deliveries

2.6.6.1 Subroutine resvr(nd,mo,evap,rel,fwreq,delv)

This subroutine computes reservoir releases based on the rule curves.

Variables and parameters :

area(nd)	-	reservoir surface area (kdnd)
delv	-	demands or EXPORTs taken directly from the reservoir
ev(nd,mo)	-	reservoir evaporation depth (0.01ft) (kdnd,12)
evap	-	reservoir evaporation (KAF) (kdnd,12)
fwreq(nd,mo)	-	flowby requirements for f&w (kdnd,12)
histsto(nd,mo)	-	Millerton historic monthly storage (kdnd,12)
kswhist(nd)	-	switch to set reservoir storages to historic input, input (kdnd)
kswsmlt(nd)	-	array of binary switches to turn on snowmelt routine (kdnd)
nd	-	number of nodes
ndnum(nd)	-	array of node numbers (kdnd)
qpow(nd,mo)	-	release limit for hydropower (kdnd,12)
rel	-	computed release from reservoir
rstor(nd)	-	current month reservoir storage (kdnd)
snomlt(nd,mo)	-	array of snowmelt releases (kdnd,12)
srule(nd,mo)	-	storage rule (kdnd,12)
tempfeb	-	adjustment to Millerton Feb. flood storage
temphi	-	adjustment to Millerton flood storage
templo	-	adjustment to Millerton flood storage
tempst	-	temporary storage
tinf	-	total inflow to reservoir
xstfld(nd,mo)	-	flood control rule (kdnd,12)

Subroutine calls :

snowmlt	-	adjusts reservoir releases during mar-jun for snowmelt
milflood	-	estimates flood control storage for Millerton for months February - June.

Files read from:

none

Files written to:

none

Summary flowchart :

- o Call subroutine SNOMELT during months March through June to estimate expected snowmelt
- o For node 5, and for months February through June ; call subroutine MILFLOOD

2.6.6.2 Subroutine snowmelt(mo,nd)

Adjusts reservoir releases during March - June due to expected snowmelt.
Works for all reservoirs except San Luis and the terminal reservoirs.

Variables and parameters

kdnd	-	dimension on nodes
knodrs(nd)	-	array of nodes with reservoirs (kdrs)
month	-	do loop index for a month
rstor(nd)	-	current month reservoir storage (kdnd)
sminflo	-	sum of inflow from current month to month 9 (June)
snowmelt(nd,mo)	-	array of snowmelt releases (kdnd,12)
xmon	-	real value for number of months from current month to month 9
xstor(nd)	-	maximum reservoir storage (kdnd)

Subroutine calls :

zerol	-	zeros out values of sminflo by node
zero2	-	zeros out values of snowmelt by node and month

Files read from:

none

Files written to:

none

Summary flowchart :

- o zero out previous values of sminflo and snowmelt.
- o set a counter that decrements from 9 to 0 by 1 (June to October).
- o sum monthly inflows from current month to June and assign value to sminflo.
- o estimate snowmelt as the sum of inflow and current storage less maximum storage. Divide by the counter value to obtain an average monthly snowmelt value.

2.6.6.3 Subroutine smaray(nd,mo)

Sums up the running gain,inf,pret,npret arrays by adding what is available at the current node to the running values from the upstream node.

Variables and parameters

flow(un,mo)	-	flow leaving a node (kdnd,12), doesn't include returns from that node
flowin(nd)	-	flow entering a node (kdnd)
frusret(i,nd)	-	array of percentage of return from an u/s node going to the current node, (kdusr,kdnd)
gain(nd,mo)	-	gains (kdnd,12), input(nd)
inflo(nd,mo)	-	(real) inflows to reservoirs, (kdnd,12), input
milfish(mo)	-	optional Millerton release for fish and wildlife (12)
npret(ur,mo)	-	non-project return flow (kdnd,12)
npretrn	-	(real) total non-project return going into a node
nusnod(nd)	-	number of immediately u/s nodes
nusret(nd)	-	number of immediately u/s nodes with returns going to current node
pret(ur,mo)	-	project return flow (kdnd,12) (pret <= rnpret)
pretrn	-	(real) total project return going into a node
rgain(nd)	-	remaining gain at a node (kdnd)
rinf(nd)	-	remaining inflow at a node (kdnd)
rnpret(nd)	-	remaining non-project returns at a node(kdnd) (remaining project and non-project returns are cobined into remaining non-project returns)
rpret(ur)	-	remaining project returns at a node(kdnd)
un	-	upstream node
usnode(i,nd)	-	(integer) node numbers of nodes immediately u/s of current node (kdusn,kdnd)
ur	-	upstream <u>return</u> node
usret(i,nd)	-	(integer) node numbers of nodes with returns immediately u/s of current node (kdusn,kdnd)

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o Initialize rgain(nd) to gain(nd,mo), rinf(nd) to inflo(nd,mo), and flowin(nd) to gain(nd,mo) + inflow(nd,mo).
- o Add the running project returns RPRET to the running non-project return RNPRET
- o Sum the returns from upstream connected nodes.
- o Add RGAIN, RINF at upstream connected nodes to RGAIN and RINF at the current node.
- o For node 10 (Eastside bypass), the remaininmg inflow and the inflow to a node should be reduced by the volume of the release.
- o Add upstream project and non-project returns to the inflow at each site.

2.6.6.4 Subroutine sannode(kswitch,tsfused,iyr,nd,mo,fwreq)

Allocates flow to demands from various sources. A demand node is either non-project or project, with non-project having priority.

Variables and parameters

agrecf(nd,mo)	-	agricultural recharge factor, input (kdnd,12)
agefcrit(nd,mo)	-	agricultural water use efficiency for critical years, input (kdnd,12)
agefnon(nd,mo)	-	agricultural use efficiency for non-critical years (kdnd,12)
del	-	maximum project and non-project deliveries to a node
flow(nd,mo)	-	flow leaving a node (kdnd,12), doesn't include returns from that node
flowin(nd)	-	flow entering a node (kdnd)
fwreq(nd,mo)	-	flowby requirements for f&w (kdnd,12)
iyr	-	year during the simulation
kswitch	-	switch to skip FLOW computation
miefcrit(nd,mo)	-	M&I efficiency for critical years, input (kdnd,12)
miefnon(nd,mo)	-	monthly M&I efficiency for non-critical years, input (kdnd,12)
mirecf(nd,mo)	-	M&I recharge factor, input (kdnd,12)
nd	-	node number
npdel(nd,mo)	-	(real) nonproject deliveries (kdnd,12), input
npef	-	nonproject demand efficiency
npeffcrit(nd,mo)	-	(real) nonproj. critical year monthly efficiencies (kdnd,12), input
npeffnon(nd,mo)	-	(real) nonproj. noncritical year monthly efficiencies (kdnd,12), input
npgnus(nd,mo)	-	(real) non-project surface water usage (kdnd,12)
npgwus(nd,mo)	-	(real) non-project groundwater usage (kdnd,12)
npret(nd,mo)	-	(real) non-project return (kdnd,12)
npretus(nd,mo)	-	(real) non-project return flow usage (kdnd,12)
npsht(nd,mo)	-	(real) non-project shortage
pagef	-	project AG. demand efficiency
paggw(nd,mo)	-	project groundwater used by agriculture
pagsh(nd,mo)	-	project agricultural shortage
pagus(nd,mo)	-	project surface water used by agriculture (kdnd,12)
pdelag(nd,mo)	-	adjusted project deliveries (agric.) (kdnd,12)
pdelmi(nd,mo)	-	adjusted project deliveries (M&I) (kdnd,12)
pmigw(nd,mo)	-	project groundwater used for M&I (kdnd,12)
pmief	-	project M&I demand efficiency
pmius(nd,mo)	-	project surface water used for M&I (kdnd,12)
pmisht(nd,mo)	-	project M&I shortage (kdnd,12)
pret(nd,mo)	-	project returns (kdnd,12)
reqrel(nd)	-	extra releases needed to meet fish and wildlife required in-stream flows (FWREQ). (kdnd)
rgain(nd)	-	remaining gain at a node (kdnd)
rinf(nd)	-	remaining inflow at a node (kdnd)
rnpdem	-	remaining non-project demand to be satisfied
rnpret(nd)	-	remaining non-project returns at a node(kdnd)
rpgnus(nd,mo)	-	remaining project gains used at a node(kdnd,12)
rpinus(nd,mo)	-	remaining project inflow used at a node(kdnd,12)
splag	-	amount of negative nonproject demand to be allocated to agriculture
splmi	-	amount of negative nonproject demand to be allocated to M&I.

surfdel(nd,mo)	-	maximum agricultural surface water delivered to nodes 110, 150, 155 and 160
tpdmag(nd,mo)	-	target project agricultural demand (kdnd,12)
tpdmml(nd,mo)	-	target project M&I demand (kdnd,12)
tpsus	-	sum of AG. and M&I surface water deliveries
tsfusd	-	total surface water used at a node to satisfy demands
xaggw(nd,mo)	-	maximum monthly agricultural GW pumping, (kdnd,12)
xnpgw(nd,mo)	-	maximum monthly non-project GW pumping, (kdnd,12)
yaggw(nd,mo)	-	minimum monthly agricultural GW pumping, (kdnd,12)
ymigw(nd,mo)	-	minimum monthly M&I GW pumping, (kdnd,12)
ynpgw(nd,mo)	-	minimum non-project monthly GW pumping, (kdnd,12)
yrtype(iyr)	-	(integer) array of year types, input (kdyr)

Subroutine calls :

smaray	-	sums up the running gain, inflow, non-project and project return arrays by adding current node water availability to running values from the upstream node
--------	---	--

Files read from:

none

Files written to:

none

Summary flowchart :

- o call subroutine SMARAY
- o set efficiencies according to year - type
- o set in order variable NPGWUS, NPGNUS, NPINUS, NPRETURN, TSFUSD
- o reset values of RGAIN, RINF and RNPRET
- o set NPRET and NPSHT
- o set project M&I surface use, GW use and shortages PMIUS, PMIGW and PMISHT
- o if node is 25 or 35 allow PAGUS to draw storage at nodes 20 and 30 only, down to the minimum storage reserve, YSTRSV
- o if the node takes water from Goodwin (110, 150, 155, 160, 165) then set PAGUS according to the surface delivery (SURFDEL)
- o set project agricultural groundwater pumping according to agricultural water usage (PAGUS). Set shortage equal to PAGSHT.
- o add PAGUS and PMIUS to TSFUSD
- o compute REQREL and FLOW if required to compute flow leaving the node (kswitch = 1)

2.6.6.5 Subroutine realloc(iyr,nd,mo,deliv)

Reallocates the deliveries and shortages. Deliveries to nodes 27 and 30 in the Calaveras-Stanislaus system can be limited by channel capacities. If these are limiting, this subroutine is called to adjust monthly deliveries. Non-project demands are much smaller than project demands and are rarely limited by channel capacities. No reallocations are performed, therefore for non-project demands.

Variables and parameters

agefori(nd,mo)	-	agricultural water use efficiency for critical years, input (kdnd,12)
agefnon(nd,mo)	-	agricultural use efficiency for non-critical year
deliv	-	total project delivery (kdnd,12)
flow(nd,mo)	-	flow leaving a node (kdnd,12), doesn't include returns from that node
nd	-	node number
pagef	-	project AG. demand efficiency
paggw(nd,mo)	-	project groundwater used by agriculture (kdnd,12)
pagsh(nd,mo)	-	project agricultural shortage (kdnd,12)
pagus(nd,mo)	-	project surface water used by agriculture (kdnd,12)
pcentag	-	fraction of total monthly delivery to a node that is allocated to agriculture
pdel(nd,mo)	-	project delivery (kdnd,12)
pmigw(nd,mo)	-	project groundwater used for M&I (kdnd,12)
pmief	-	project M&I demand efficiency
pmius(nd,mo)	-	project surface water used for M&I (kdnd,12)
pmisht(nd,mo)	-	project M&I shortage (kdnd,12)
pret(nd,mo)	-	project returns (kdnd,12)
tempag(nd,mo)	-	initial estimate of the total surface water allocation to agriculture (kdnd,12)
tempmi(nd,mo)	-	initial estimate of the total surface water allocation to M&I (kdnd,12)
tpdmag(nd,mo)	-	target project agricultural demand (kdnd,12)
tpdmmi(nd,mo)	-	target project M&I demand (kdnd,12)
xaggw(nd,mo)	-	maximum monthly agricultural GW pumping, (kdnd,12)
yaggw(nd,mo)	-	minimum monthly agricultural GW pumping, (kdnd,12)
ymigw(nd,mo)	-	minimum monthly M&I GW pumping, (kdnd,12)
yrtype(iyr)	-	(integer) array of year types, input (kdyr)

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o set efficiency based on year type
- o set REMPMI and TEMPAG values based on actual surface deliveries (DELIV) to each node
- o recompute the surface deliveries, groundwater deliveries, water shortage and surface returns

2.6.6.6 Subroutine floadj(nd,mo,arel,reqrel)

Is used to recalculate flows after the subroutine SPACE has been called.

Variables and parameters

arel(nd)	-	array of additional releases needed to meet requirements (kdnd)
flow(nd,mo)	-	flow leaving a node (kdnd,12), doesn't include returns from that node
nd	-	node number
reqrel(nd)	-	extra releases that need to be made at a node to meet fish and wildlife requirements (kdnd)
nusnod(nd)	-	number of immediately upstream nodes (kdnd)
usnode(i,nd)	-	node numbers of nodes immediately upstream of current node (kdusn,kdnd)

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o if there are no upstream nodes (NUSNOD = 0) set flow array FLOW to include additional releases AREL needed to meet requirements
- o if node = 70 add additional releases at nodes 60, 65 and 70 to FLOW at node 70
- o set the additional releases for each node to - REQREL
- o sum additional upstream releases and update the monthly flow with the final value of AREL

2.6.7 MOD2.for

2.6.7.1 Subroutine spcall (mo,iyr,reqrel)

Initiates a call to subroutine SPACE.

Variables and parameters :

dscap	-	d/s (outlet) capacity of a reservoir. value comes from SPCVEC
knodrs(i)	-	array of nodes with reservoirs (kdrs)
nd	-	node number
nr	-	number of usable reservoirs in the space call. usable reservoirs have positive DSCAP values
nres	-	number of reservoirs
numres(nr)	-	node numbers of reservoirs in space call (kdnd)
reqrel(n(*))	-	extra releases needed to meet fish and wildlife required in-stream flows (FWREQ). (kdnd)
spcvec(j,nd)	-	vector of outlet capacities for space rule calls at three locations (nodes 40,95 and 125) (3,kdnd)
treqrel(*)	-	total of extra releases (REQREL) determined in subroutine spacecall(kdnd) (3)

Subroutine calls :

space	-	computes reservoir releases to meet downstream demands that aren't met when the reservoirs are operated using the rule curves.
-------	---	--

Files read from:

none

Files written to:

none

Summary flowchart :

- o set the total of the extra releases TREQREL(1), TREQREL(2) and TREQREL(3) to the required releases REQREL at nodes 40, 95, (120 + 125)
- o perform the doo loop for three calls to the SPACE routine
- o set the number of reservoirs in the call (NR) to SPACE to value = 0
- o repeat for the number of reservoirs in the model (NRES)
- o if SPCVEC for the node and the call is > 0 then increment NR and set the reservoir number (NUMRES) and set the downstream capacity DSCAP
- o if all the reservoirs have been considered then call subroutine SPACE
- o repeat inner and outer loops until i = nres and j = 3

2.6.7.2 Subroutine space(nr,numres,mo,dscap,rdem)

Computes reservoir releases to meet downstream demands that aren't met when the reservoirs are operated by rule curves.

Variables and parameters :

actv(k)	-	switch which determines if reservoir is active
arel(kr)	-	array of additional releases needed to meet requirements, computed, (kdnd)
delrat	-	minimum slope between RAT values and RDEM to TSTRF
dscap(k)	-	d/s capacity, capacity of outlet
kr	-	index set equal to numres(k)
krat(k)	-	current ratio of free volume to inflow
nr	-	number of usable reservoirs in the space call.
		usable reservoirs have positive DSCAP values
numres	-	node numbers of reservoirs in space call
rat(k)	-	sorted vector of breakpoints
rdem	-	total volume of water that must be released from the available reservoirs to meet requirements
rstor(kr)	-	current month reservoir storage
strf(kr)	-	storable inflows to reservoirs (kdnd)
tstrf	-	summed storable inflow (STRF)
xrat(k)	-	max. free volume/storage ratio for each reservoir
xstor(kr)	-	maximum reservoir storage (kdnd)
ystrsv(kr,mo)	-	minimum reservoir reserve storage (kdnd,12)

Subroutine calls :

vsrta	-	vector sorting routine used to sort breakpoints in ascending order
-------	---	--

Files read from:

none

Files written to:

none

Summary flowchart :

- o calculate the maximum free volume: storable inflow ratio (XRAT) for each reservoir
- o calculate the free volume : storable inflow ratio (KRAT) for each reservoir
- o call subroutine VSTRA to create a sorted vector of the breakpoints
- o for each reservoir visit each of the breakpoints in ascending order of breakpoint ratio
- o if the current ratio is less than the maximum ratio and the next breakpoint ratio is greater than the current ratio then add the storable inflow to the total storable inflow and make the reservoir active by setting ACTV = 1
- o if the summed storable inflows are positive (> 0.00001) then set the target ratio so as to just meet the remaining demand otherwise release all the way to the next breakpoint

2.6.7.3 Subroutine vsrta(a,n)

This is a quick vector sorting routine adapted from Kernighan and Richie (C language) and called within the SPACE subroutine. The sort routine is applied to the vector of breakpoints obtained by calculating both the current free volume/storable inflow ratio and the maximum ratio for each reservoir node.

Variables and parameters :

a(j)	-	test variable
igap	-	counter index; set to the number of reservoirs
n	-	end of range index
temp	-	temporary variable

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o set igap to number of reservoirs
- o if igap has a value greater than 1 - iterate for the number of reservoirs
- o visit each breakpoint node in order
- o reverse the order of the breakpoints a(j) and a(j+igap) if a(j) is greater than a(j+igap)
- o return the sorted vector of the breakpoints

2.6.7.4 Subroutine pumpmax(lyt)

Sets the minimum and maximum pumping for each node. The code converts the groundwater pumping patterns to the appropriate XNPGW, YNPGW, X**GW and T**GW arrays. The pumping type is based on the year type which is passed in as IYT.

IYT = 1 or 2 : pumping type 1
IYT = 3 : pumping type 2
IYT = 4 or 5 : pumping type 3

The project pumping is split between agriculture and M & I based on the ratio of the total annual demand for agriculture and M & I.

Variables and parameters :

anagdem(nd)	-	annual agricultural demand at a node (kdnd), input
anmidem(nd)	-	annual M&I demand at a node (kdnd), input
iyt	-	temporary variable for year type
knodpmp(i)	-	array of nodes with GW pumping (kdnd)
kp	-	pumping type index
nd	-	node number
npump	-	number of pumping nodes
psplit	-	project GW pumping split between M&I and ag. demands
tdm	-	total project demand at a node with GW pumping
xaggw(nd,mo)	-	maximum monthly agricultural GW pumping, (kdnd,12)
xmigw(nd,mo)	-	maximum monthly M&I GW pumping, (kdnd,12)
xnpgw(nd,mo)	-	maximum monthly non-project GW pumping, (kdnd,12)
xpmpnp(nd,kp)	-	maximum annual non-project groundwater pumping for a demand node (3 year types input) (kdnd,3)
xpmpnp(nd,kp)	-	maximum annual project groundwater pumping for a demand node (3 year types input) (kdnd,3)
xppatp(nd,mo,kp)	-	monthly distribution corresponding to maximum pumping
yaggw(nd,mo)	-	minimum monthly agricultural GW pumping, (kdnd,12)
ymigw(nd,mo)	-	minimum monthly M&I GW pumping, (kdnd,12)
ypmpnp(nd,kp)	-	minimum annual project groundwater pumping for a demand node (3 year types input) (kdnd,3)
yppatp(nd,mo,kp)	-	monthly distribution corresponding to minimum pumping (kdnd,12,*)

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o Set the pumping type index (KP) according to year type (IYT)
- o Set variable PSPLIT equal to the fraction of groundwater pumping for M&I
- o Set the minimum and maximum non-project pumping (YNPGW and XNPGW) for each node, month and year type
- o Set the minimum and maximum M&I and agricultural pumping (YMIGW, XMIGW, XAGGW, YAGGW) for node, month, year type and the split between M&I and agricultural water use

2.6.7.5 Subroutine cvpdel(lyr,red)

Performs the CVP demand reduction.

Variables and parameters :

contag(nd,im)	-	monthly contracted agricultural deliveries at a node product of anagcon(nd) and agrpat(kdnd,mo)
contmi(nd,im)	-	monthly contracted M&I deliveries at a node product of anmicon(nd) and mnipat(kdnd,mo)
im	-	index of months
lyr	-	year during the simulation
knodcvp(in)	-	array of nodes with CVP demands (kdnd)
ncvpdm	-	number of CVP demand nodes
nd	-	node number corresponding to CVP demand node
pdel(nd,im)	-	total project delivery to all demand nodes (kdnd,12)
pdelag(nd,im)	-	project deliveries to agriculture (kdnd,12)
pdelmi(nd,im)	-	project deliveries to M&I (kdnd,12)
red	-	CVP demand deficiency factor - set according to water year - type
tpdmag(nd,im)	-	target project agricultural demand (kdnd,12)
tpdmmi(nd,im)	-	target project M&I demand (kdnd,12)
yrtype(lyr)	-	(integer) array of year types, input (kdyr)

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o Set the deficiency factor (RED) according to San Joaquin basin water year-type
- o Set the deficiency for Mendota Pool (node 15) according to the Sacramento basin water year type
- o For each CVP demand node, set project agricultural deliveries (PDELAG) and project M&I deliveries PDELMi to the contract delivery corrected for any project mandated deficiencies. If no deficiency is set deliveries are set equal to the total project agricultural demand TPDmag and the total M&I demand TPDMMi respectively.

2.6.7.6 Subroutine fwpars(iyr,mo,nd,rstor)

Parses the equation in the FW input into a value for routine TRIGGR. The equation is read in sets of up to four characters each. The subroutine parses the first character of each four character set into an algebraic sign (+ - * /) and the remaining characters as either (a) a flow variable and node number or (b) a scale factor. The second character is a switch - if it is a number it is a multiplier or divisor for the computed value of TRIGGR. In this case the third and fourth characters are the appropriate node numbers and these single characters are assigned to variable INDX.

If the second character is an alphabetic character the trigger value is computed in subroutines FORINF, INFLO, GAIN or STOR. Characters three and four contain the remainder of the scale factor. This value is scaled by the factor 0.01 to avoid decimal points.

Variables and parameters :

equ(*)	-	set equivalent to the fish and wildlife requirement at a given node
fwclas(nd,month, iyrtml)	-	array of fw req.values at 7 levels (kdnd,12,7),input
fwequn(nd)	-	array of fw req.values at 7 levels (kdnd,12,7),input
fwreq(nd,month)	-	flowby requirements for f&w (kdnd,12)
ichar(eq*)	-	ascii conversion from character to integer variable
idnx	-	node number obtained from parsing equation
ieq*	-	parsing variable
iyrt	-	year type
leng	-	length of a character string
month	-	month
ndd	-	temporary variable for node number
ndnum(nd)	-	array of node numbers (kdnd)
rstor(kn)	-	current month reservoir storage
scale	-	scale factor invoked if a '*' or "/" occurs in the parsing equation
triggr	-	trigger value to calculate FWREQ
yrtype(iyr)	-	(integer) array of year types, input (kdyr)

Subroutine calls :

fwintp	-	calculates fish and wildlife flow requirement (FWREQ) by interpolation of a table of 6 classes of trigger values (FWTRIG).
--------	---	--

Files read from:

none

Files written to:

none

Summary flowchart :

- o if the first year of simulation set the year-type to current year-type otherwise use the previous year
- o check the parsing equation for the string 'trig'
- o if using water year-types, set the fish and wildlife requirements within the monthly DO loop
- o for Tuolumne nodes 70 and 75, set the fish and wildlife requirements on last year's year-type
- o determine the number of words in the parsing equation
- o assign each character in parsing equation to a separate variable
- o reassign each of these character variables to integer variables

- o if the second character of the equation is a switch (value 0-9) compute the scaling factor from the remaining digits in the equation - multiply by 0.01 to avoid the decimal point
- o if the second character isn't a switch the last two digits are a node number 0-99 which is assigned to variable indx
- o if the second character isn't a switch and is equal to a character "f", 'g', 'i' or 's' set the trigger in terms of forecasted inflow (forinf), stream gains (gain), reservoir inflows (inflo) or storage (stor)
- o multiply or divide the fish and wildlife requirement trigger by the scaling factor
- o once parsing is completed call subroutine fwintp to interpolate between classes of fish and wildlife requirement values

2.6.7.7 Subroutine fwintp(nd,triggr)

Calculates FWREQ values. The FWREQ values interpolated from the 6 classes of fish and wildlife requirement values are based on the trigger array (FWTRIG) and the value of TRIGGR. The value of TRIGGR is interpolated from the FWTRIG array. If TRIGGR is greater or equal to the highest value of FWTRIG or if TRIGGR is less than or equal to the lowest value of FWTRIG then FWTRIG is assigned to be equal to the highest or lowest FWCLAS value.

Variables and parameters :

fwclas(nd,mo,*)	-	array of fw req.values at 7 levels (kdnd,12,7),input
fwreq(nd,mo)	-	flowby requirements for f&w (kdnd,12)
fwtrig(nd,*)	-	array of fw req. trigger values (kdnd,7), input
triggr	-	trigger value to calculate FWREQ

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o if TRIGGR is $\geq$ the highest value of FWTRIG then set FWREQ to the highest FWCLAS value (FWCLAS(nd,mo,1)) - return
- o if TRIGGR is $\leq$ the lowest value of FWTRIG then set FWREQ to the lowest FWCLAS value (FWCLAS(nd,mo,5)) - return
- o if neither of the above cases apply $1 < \text{FWTRIG} < 6$ then perform interpolation
- o set x equal to fraction of interval between the FWTRIG values
- o for each month determine the current and previous month FWCLAS values
- o calculate each monthly FWREQ value based on the FWCLAS value, downward adjusted by the FWCLAS interval multiplied by x.
- o if interpolation fails print out an error message

2.6.7.8 Subroutine goodwin(n,iyt,export,forinf,npdel,fwreq)

Calculates exports at Goodwin Dam and the FWREQ for node 110. EXPORT (110) and FWREQ (110) are computed according to the negotiated contractual agreements as of 8/7/89.

Variables and parameters :

afw	-	annual fish and wildlife in-stream flow requirement
andiv110	-	annual diversion at node 110, PAGUS 110 + EXPORT 110
andv150	-	annual diversions from Goodwin for Oakdale and South San Joaquin Irrigation Districts
andvcsj	-	annual diversion from Goodwin to Central San Joaquin Irrigation District
andvsew	-	annual diversion from Goodwin to Stockton East Water District
anevap	-	annual evaporation from New Melones Reservoir
area(n(*))	-	reservoir surface area (kdnd)
annpdel	-	annual non-project demand at node 115
cap110	-	capacity of link 110-150
clsgood(i)	-	annual volume of fish and wildlife releases at Goodwin
ev(n(*),mo)	-	evaporation from the lake surface (kdnd,12)
export(n(*),mo)	-	monthly export from reservoir node (kdnd,12)
exppat(*,mo)	-	monthly export pattern from reservoir node (kdnd,12)
forinf(n(*),*)	-	forecasted inflow from current month to the end of the water year, (kdnd,12)
fwgood(mo,kgood)	-	monthly fraction of the total annual fish and wildlife flow requirement to be released from Goodwin Dam
fwreq(n(*),mo)	-	flowby requirements for f&w (kdnd,12)
kgood	-	fish and wildlife release class for Goodwin releases
npdel(n(*),mo)	-	non-project surface water deliveries to a node
ossjdem	-	Oakdale and South San Joaquin District demands at a node
ossjspl(*)	-	split between Oakdale Irrigation District (North and South) and South San Joaquin Irrigation District
redcsse(iyt)	-	monthly deficiency factor based on year type (5)
rstor(n(*))	-	current month reservoir storage (kdnd)
srule(n(*),12)	-	monthly reservoir storage rule (kdnd,12)
surfdel(n(*),mo)	-	surface water delivery to a node (kdnd,12)
tpgmag	-	total monthly project demand for agriculture (kdnd,12)

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o compute annual diversions at Goodwin and South San Joaquin Irrigation Districts based on demand and forecasted flows
- o if New Melones historical data is not used - set surface deliveries to nodes 110, 150 and 165 according to annual diversions for OID and SSJID and monthly delivery patterns
- o if using New Melones historical data - set surface deliveries to nodes 110, 150 and 165 according to historical values

- o set surface deliveries at nodes 155 and 160 according to distribution pattern
- o set exports at nodes 150 and 155
- o set annual fish and wildlife requirement (AFW) by forecasted inflows, storage and deliveries
- o set FWREQ for Goodwin by AFW and 98, 122, 215 and 302 kaf classes

2.6.8 MOD3.for

2.6.8.1 Subroutine milflod(mo,nd,milstor,milred)

Computes the flood control storage XSTFLD for Millerton for months February through June and sums up the forecast natural inflow to Millerton from the present through July. The current values of Millerton storage MILSTOR is calculated as the beginning of month storage + inflow - exports and evaporation losses. If this value may be higher than the maximum storage the project is corrected using SPILL to return to the maximum storage. Likewise if the total space needed for flood control exceeds the space available, releases are made to bring the reservoir down to the flood control diagram level.

Variables and parameters :

fkcl(mo)	-	monthly volume of Friant-Kern (FKC) Class1 flow (12)
fkcl2(mo)	-	monthly volume of FKC Class 2 flow (12)
fwreq5	-	flowby requirements for f&w (kdnd,12)
madcl(mo)	-	monthly volume of Madera Canal Class1 flow (12)
madcl2(mo)	-	monthly volume of Madera Canal Class 2 flow (12)
milfsh(mo)	-	additional releases for fish along the SJR
milinf(im)	-	natural monthly inflow into Millerton, assuming no upstream storage, real, input, (12)
milrel	-	Millerton release
milstor	-	Millerton storages
spill	-	spillage at node (*)
tinf	-	total Millerton INFLO from current month thru June.
totfld	-	total flood control space required
totspace	-	flood control space available in Millerton and the u/s reservoirs (UPSTORE)
upstore(mo)	-	storage in reservoirs u/s from Millerton, input, (12)
xstfld(nd,mo)	-	used to compute Millerton flood storages and spills
xstor(nd)	-	flood control rule (kdnd,12)
	-	maximum reservoir storage (kdnd)

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o set spill as any amount of TEMPST (from RESVR subroutine) above maximum storage
- o set TINF as the sum of MILINF from next month through July. MILINF is the "natural" inflow to Millerton without SCE storage
- o set the flood control volume (TOTFLD) for February - June based on equations from the flood - control manual
- o compute the space available (TOTSPACE), then compute Millerton release (MILREL) from equations
- o reset MILREL to account for class1 and class2 exports from Millerton (SPILL). Reset MILSTOR.

2.6.8.2 Subroutine mildelv(iyt,fkdaup)

Computes the Class1 and Class2 water leaving Millerton bound for the Friant-Kern Canal and the Madera Canal. Millerton storage availability (AVAIL) is calculated as the end of February Millerton storage plus the March through September inflow (INFLO) minus Millerton dead storage. The availability of water from Friant is calculated from regression equations.

Variables and parameters :

avail	-	accumulated INFLO to Millerton from March - September
class1	-	total annual Millerton class 1 deliveries
class2	-	total annual Millerton class 2 deliveries
div(1,nd,mo)	-	total monthly diversion from the Friant-Kern Canal after correcting for water year (FSNKCLS(J,MO))
fkac1	-	volume of class 1 water going to the Friant-Kern Canal
fkac1t	-	temporary variable : equal to (fkac1-130,000 acre-ft)
fkac2	-	volume of class 2 water going to the Friant-Kern Canal
fkac2l	-	portion of class 2 water flow that is long-term water
fkac2s	-	portion of class 2 water flow that is short-term water
fkcl(mo)	-	monthly volume of Friant-Kern (FKC) Class 1 flow (12)
fkcl2l(mo)	-	monthly volume of FKC Class 2 long-term flow (12)
fkcl2s(mo)	-	monthly volume of FKC Class 2 short-term flow (12)
fkdaul	-	monthly diversion of Class 1 water from the Friant-Kern Canal to a DAU (12)
fkdaul2l	-	monthly long-term diversions of Class 2 water from the Friant-Kern Canal to a DAU
fkdaul2s	-	monthly short-term diversions of Class 2 water from the Friant-Kern Canal to a DAU
fkdaup(*,kdsnk)	-	monthly delivery pattern for Friant-Kern Canal water to each DAU, input
fkmspl(iyt)	-	fraction of Class 1 and Class 2 water going to Friant-Kern Canal. remainder goes to Madera Canal (EXPORT 25). input, (5)
fsnkcls(j,mo)	-	deficiency factor for Friant Kern Canal diversions set according to water year type
gain(n(*),im)	-	gains (kdnd,12), input
inflo(n(*),im)	-	(real) inflows to reservoirs, (kdnd,12), input
iyt	-	temporary variable for year type
madcl(mo)	-	monthly volume of Class1 flow in Madera canal (12)
madc2(mo)	-	monthly volume of Class2 flow in Madera canal (12)
madxpat(mo,iyt)	-	(real) monthly pattern of Madera Canal exports input, (12,5)
milinf	-	natural monthly inflow into Millerton, assuming no upstream storage, real, input, (12)
nsink(*)	-	number of DAUs getting water from a sink, input, (kdsrc)
r4indx	-	four river index based on April through July flows for Millerton, Exchequer, Don Pedro and New Melones
rstor(n(*))	-	current month reservoir storage
upstore(*)	-	storage in reservoirs u/s from Millerton, input, (12)
ystor(n(*))	-	used to compute Millerton flood storages and spills minimum storage (kdnd)

Subroutine calls :

none

Files read from:

none

Files written to:
none

Summary flowchart :

- o set the availability of water for diversion, based on Millerton storage, forecasted inflow (March - September)
- o calculate the 4-river index
- o if sufficient water, set full entitlements for Class1 deliveries
- o if insufficient water, based on 4-river index, use regression equations to set annual CLASS1 and CLASS2 diversions
- o For each DAU getting water from a sink determine the Friant-Kern Canal Class 1 and Class 2 long and short term delivery patterns from delivery totals
- o Calculate monthly diversions from each source
- o Distribute class 1 and class 2 to the Madera Canal by month, taking into account project deliveries to the Friant-Kern Canal

2.6.8.3 Subroutine wq(mo,rsjwq,sjflo,trel,qtar,rwqrel,rwq)

Performs the water quality computations. Water quality is calculated only at the Vernalis station. Upstream water quality is determined using a regression equation - a single number is used for monthly TDS from the Tuolumne and Stanislaus rivers.

Variables and parameters :

c*(mo)	-	regression coefficients (12)
factor(mo)	-	factor to convert units (12)
qtar	-	target water quality objective (mg/l TDS)
rsjwq	-	water quality objective in the San Joaquin River
rwq	-	water quality below Vernalis monitoring station
rwqrel	-	required release to meet water quality objective in the San Joaquin River
sjflo	-	San Joaquin River flow (acre-ft/month)
sjqual	-	San Joaquin River river water quality (mg/l TDS)
stflo	-	Stanislaus River flow (acre-ft/month)
stqual	-	Stanislaus River water quality (mg/l TDS)
trel	-	Stanislaus River flow set equal to target flow
vflo	-	combined flow of the Stanislaus and San Joaquin River (above the Stanislaus) - equal to the flow below the Vernalis gauging station

Subroutine calls :

none

Files read from:

none

Files written to:

none

Summary flowchart :

- o set San Joaquin River water quality (SJQUAL) from the regression equation, minimum value of 75 ppm TDS
- o assume Stanislaus River water quality (STQUAL) is 50 ppm TDS. Compute water quality below Vernalis (RWQ)
- o if RWQ is below the target, set the required New Melones release (RWQREL) to adjust water quality to the target concentration

2.6.8.4 Subroutine initial

Zeros out arrays that contain blanks (zeros).

Variables and parameters :

capcty(i)	-	capacity of links (kdnd) (channel capacity)
fwclas(i,mo,j)	-	array of fw req.values at 7 levels (kdnd,12,7),input
kdnd	-	node dimension

Subroutine calls :

zero2	-	produces zero values in a two dimensional array
zerol	-	produces zero values in a one dimensional array
izerol	-	produces zero values in a one dimensional integer array

Files read from:

none

Files written to:

none

2.6.8.5 Subroutine skipIn(kunit,n)

Skips a designated number of lines.

Variables and parameters :

kunit	-	unit number to be read
n	-	number of lines to be skipped

Files read from:

input	-	designated by kunit
-------	---	---------------------

Files written to:

none

2.6.8.6 Subroutine ndchek1(node,inode,label)

Does a node number check for non-time series files

Variables and parameters :

inode	-	matching node number
label	-	label indicating node mismatch
node	-	original node number

Files read from:

none

Files written to:

output	-	output to screen
--------	---	------------------

2.6.8.7 Subroutine ndchek2(kunit,nnod,knodes,label)

Does a node number check for time series files.

Variables and parameters :

inodes(i) - matching node number
knodes(i) - original node number
label - label indicating a node mismatch
nnod - number of nodes

Files read from:

none

Files written to:

output - output to screen

2.6.8.8 Subroutine zero2(x,ni,nj)

Zeros out a two dimensional array

Variables and parameters :

ni - rows of two dimensional array
nj - columns of two dimensional array
x(i,j) - array of variables to be assigned zero values

Files read from:

none

Files written to:

none

2.6.8.9 Subroutine zero1(x,ni)

Zeros out a one dimensional array.

Variables and parameters :

n(i) - number of elements to be assigned zero values
x(i) - variable to be assigned a zero value

Files read from:

none

Files written to:

none

2.6.8.10 Subroutine izer01(j,ni)

Zeros out a one dimensional integer array.

Variables and parameters :

n(i) - number of elements to be assigned zero values
j(i) - integer variable to be assigned a zero value

Files read from:

none

Files written to:

none

2.6.8.11 Function area(nr)

Calculates reservoir surface area from storage.

Variables and parameters :

area	-	reservoir surface area
rstor(nr)	-	current month reservoir storage
starcf(nr,*)	-	

Files read from:

none

Files written to:

none

2.7 Model output subroutines

2.7.1 SURFWRIT.for

2.7.1.1 Subroutine wrtonce

Writes the initialization data to a file (unit 30)

Variables and parameters :

agefcrit(nd,mo)	-	agricultural monthly efficiencies for non-critical years (kdnd,12),input
agefnon(nd,mo)	-	agric monthly efficiencies for non-critical years (kdnd,12), input
agrpat(nd,mo)	-	monthly agricultural demand pattern at a node (kdnd,12)
anagcon(nd)	-	annual agric. contract at a node (kdnd), input
anagdem(nd)	-	annual agric. demand at a node (kdnd), input
anmicon(nd)	-	annual M&I contract at a node (kdnd), input
anmidem(nd)	-	annual M&I demand at a node (kdnd), input
begsim	-	(integer) year in which simulation starts
begyr	-	(integer) year at beginning of run,(1922)
binfil	-	name of binary output file
bstor(n(*))	-	beginning storage for month (kdnd), input
capcty(n)	-	capacity of links (kdnd)
contag(nd,mo)	-	monthly contracted agricultural deliveries at a node product of anagcon(nd) and agrpat(kdnd,12)
contmi(nd,mo)	-	monthly contracted M&I deliveries at a node product of anmicon(nd) and mnipat(kdnd,12)
dismad(mo)	-	array of monthly fractions of Madera Canal (EXPORT 25) water from Millerton going to node 25,remainder goes to node 35, input (12)
ev(nd,mo)	-	reservoir evaporation depth (.01 ft) (kdnd,12)
fkmspl(i)	-	fraction of Class 1 and Class 2 water going to Friant-Kern Canal. remainder goes to Madera Canal (EXPORT 25). input, (5)
flodfil	-	name of file with time series of flood control rule storages
frusret(j,nd)	-	array of percentage of return from an u/s node going to the current node, (kdusr,kdnd)
fsnkcls	-	deficiency factor for Friant-Kern Canal diversions set according to year type (kdnd,12)
fwclas(nd,mo,i5)	-	array of fw req.values at 7 levels (kdnd,12,7),input
fwfil	-	name of file with F&W data
fwegun(nd)	-	array of fw req. "equations" in character variables, (kdnd), input
fwtrig(nd,i5)	-	array of fw req. trigger values (kdnd,7), input
gainfil	-	name of file with time series of GAINS
glogfil	-	name of the run log file for the groundwater portion
inffil	-	name of file with time series of inflows
kfrfst	-	forecast option for Millerton inflows
kfwfor	-	fish and wildlife water requirements (12)
knodcp(i)	-	array of nodes with capacities (kdnd)
knodcvp(i)	-	array of nodes with CVP demands (kdnd)
knoddm(i)	-	array of nodes with demands (kdnd)
knodfw(i)	-	array of nodes with F&W req. (kdnd)
knodgn(i)	-	array of nodes with gain (kdnd)

knodin(i)	-	array of nodes with inflow (kdnd)
knodnp(i)	-	array of nodes with nonproject demands (kdnd)
knodpmp(i)	-	array of nodes with GW pumping (kdnd)
knodprj(i)	-	array of nodes with project demands (kdnd)
knodpts(i)	-	array of nodes with time series of historical GW pumping
knodrs(i)	-	array of nodes with reservoirs (kdrs)
knodtul(i)	-	list of node numbers of Tulare DAUs, input, (kdnd)
kswgw	-	switch to use groundwater model only
kswpow	-	switch to turn calls to power routines on and off
kswsmlt(n(*))	-	array of binary switches to turn on snowmelt routine (kdnd)
lastyr	-	last year in simulation
lsink	-	node numbers of DAU's getting water from a sink (kdsrcc,kdnd)
maxusnd	-	maximum upstream nodes
maxusrt	-	maximum number of nodes with returns immediately upstream from current node
miefnon(nd,mo)	-	monthly M&I efficiency for non-critical years, (kdnd,12) input
miefcri(nd,mo)	-	M&I efficiency for critical years, (kdnd,12) input
mnipat(nd,mo)	-	(real) M&I monthly pattern at a node (kdnd,12),input
ncap	-	number of nodes with capacities
ncvpdm	-	number of CVP demand nodes
ndemd	-	number of nodes with demand
ndnum(i)	-	array of node numbers (kdnd)
nfw	-	number of nodes with fish & wild require. (min flow)
ngain	-	number of nodes with gains
ninfl	-	number of nodes with inflow
nnodes	-	number of nodes in the model
nnpdem	-	number of nonproject demand nodes
npdmfil	-	file containing non-project time series demand data
npefcric(nd,mo)	-	(real) non-project critical year monthly efficiencies (kdnd,12)
npefnon(nd,mo)	-	(real) non-project non-critical year monthly efficiencies (kdnd,12)
nprjdm	-	number of nodes with project demands
nprjts	-	number of nodes with time series of project demands
npump	-	number of nodes with GW pumping
nres	-	number of reservoirs
nsink	-	number of DAU's getting water from a sink (kdsrcc)
nsourcc	-	number of surface water sources in the Tulare area
ntuldm	-	number of Tulare-area DAUs
nusnod(nd)	-	number of immediately upstream nodes (kdnd)
nusret	-	number of immediately u/s nodes with returns going to current node
nwretn	-	undefined variable
nyear	-	number of years in simulation, LASTYR-BEGSIM+1
pdmfil	-	name of file with project demand data
pdtstfil	-	name of file with time series of project demands
powrfil	-	name of file with CVP system power variables
pumpfil	-	name of file with min. and max. GW pumping data
qpow(nd,mo)	-	release limit for hydropower (kdnd,12)
resfil	-	name of file with reservoir data
rtitlc	-	run title, 80 characters
rundate	-	date on which model simulation is run
runtime	-	time at which model simulation is run
schmfil	-	name of file with data from PROSIM

slogfil	-	name of run log file from surface water model
srule(nd,mo)	-	storage rule (kdnd,12)
starcf(nd,j)	-	storage-area curve coefficients (kdnd,12)
stelcf(nd,j)	-	storage-elevation curve coeffs. (kdnd,4)
strf(n(*))	-	storable inflows to reservoirs (kdnd)
tpdem(nd,mo)	-	target monthly project demand (kdnd,12)
tpdmag(nd,mo)	-	target monthly project agricultural demand (kdnd,12)
tpdmmi(nd,mo)	-	target monthly project M&I demand (kdnd,12)
tsrcsnk	-	fraction of flow from a source to a DAU for a month and year type, input (kdsrsc,kdsnk,12,3)
tuldfil	-	name of file with the Tulare data
usndfil	-	name of file with the upstream node data
usnode(j,nd)	-	(integer) node numbers of nodes immediately upstream of current node (kdusn,kdnd)
usret(j,nd)	-	(integer) node numbers of nodes with returns immediately upstream of current node (kdusn,kdnd)
wqtar(mo)	-	monthly water quality target at node 27, Vernalis (mg/l) (12)
wyrfil	-	name of file with year types
xaggw(nd,mo)	-	maximum monthly agricultural GW pumping, (kdnd,12)
xmigw(nd,mo)	-	maximum monthly M&I groundwater pumping (kdnd,12)
xnpgw(nd,mo)	-	maximum monthly non-project groundwater pumping (kdnd,12)
xppatp(nd,mo,*)	-	project groundwater pumping pattern for maximum annual withdrawal (kdnd,12,3)
xppatnp(nd,mo,*)	-	non- project groundwater pumping pattern for maximum annual withdrawal (kdnd,12,3)
xpmpnp(nd,*)	-	maximum annual non-project groundwater pumping for a demand node (3 year types input) (kdnd,3)
xpmpnp(nd,*)	-	maximum annual project groundwater pumping for a demand node (3 year types input) (kdnd,3)
xstor(n(*))	-	maximum reservoir storage (kdnd)
yaggw(nd,mo)	-	minimum monthly groundwater pumping
ymigw(nd,mo)	-	minimum monthly M&I GW pumping, (kdnd,12)
ynpgw(nd,mo)	-	minimum non-project monthly GW pumping (kdnd,12)
yppatp(nd,mo,*)	-	project groundwater pumping pattern for minimum annual withdrawal (kdnd,12,3)
yppatnp(nd,mo,*)	-	non- project groundwater pumping pattern for minimum annual withdrawal (kdnd,12,3)
ypmpnp(nd,mo)	-	minimum annual non-project groundwater pumping for a demand node (3 year types input) (kdnd,3)
ypmpnp(nd,mo)	-	minimum annual project groundwater pumping for a demand node (3 year types input) (kdnd,3)
yrtype(k)	-	integer array of year types, input (kdyr)
ystor(n(*))	-	minimum storage (kdnd)
ystrsv(nd,mo)	-	minimum reservoir reserve storage (kdnd,12)

Files read from:
none

Files written to:
tulare.out - output file designated as unit 30

2.7.1.2 Subroutine sltonce

Writes the initialization data to the salt file (unit 31)

Variables and parameters :

begsim	-	(integer) year in which simulation starts
bstor(n(*))	-	beginning storage for month (kdnd), input
frusret(j,nd)	-	array of percentage of return from an u/s node going to the current node, (kdusr,kdnd)
knodcvp(i)	-	array of nodes with CVP demands (kdnd)
knoddm(i)	-	array of nodes with demands (kdnd)
knodgn(i)	-	array of nodes with gain (kdnd)
knodin(i)	-	array of nodes with inflow (kdnd)
knodnp(i)	-	array of nodes with nonproject demands (kdnd)
knodpmp(i)	-	array of nodes with GW pumping (kdnd)
knodprj(i)	-	array of nodes with project demands (kdnd)
knodpts(i)	-	array of nodes with time series of historical GW pumping
knodrs(i)	-	array of nodes with reservoirs (kdrs)
knodtul(i)	-	list of node numbers of Tulare DAUs, input, (kdnd)
kswgw	-	switch to use groundwater model only
kswsalt	-	switch to output sw data for Salt Balance model
lastyr	-	last year in simulation
lsink	-	node numbers of DAU's getting water from a sink (kdsr, kdnd)
maxusnd	-	maximum upstream nodes
maxusrt	-	maximum number of nodes with returns immediately upstream from current node
ncvpdm	-	number of CVP demand nodes
nnpdem	-	number of nonproject demand nodes
nprjdm	-	number of nodes with project demands
nprjts	-	number of nodes with time series of project demands
npump	-	number of nodes with GW pumping
nsink	-	number of DAU's getting water from a sink (kdsr)
nsource	-	number of surface water sources in the Tulare area
ntuldm	-	number of Tulare-area DAUs
nusnod(nd)	-	number of immediately upstream nodes
nusret	-	number of immediately u/s nodes with returns going to current node
rttitle	-	run title, 80 characters
rundate	-	date on which model simulation is run
runtime	-	time at which model simulation is run
usnode(j,nd)	-	(integer) node numbers of nodes immediately upstream of current node (kdusn, kdnd)
usret(j,nd)	-	(integer) node numbers of nodes with returns immediately upstream of current node (kdusn, kdnd)

Files read from:

none

Files written to:

salt.out - output file designated as unit 31

2.7.1.3 Subroutine writtim

Writes the annual results to a binary file.

Variables and parameters :

div(is,n(*),mo)	-	monthly surface diversion from source to sink (kdsrc,kdnd,12)
dmcq(*)	-	flow from mendota Pool into node 15 (12)
evap(n(*),mo)	-	reservoir evaporation (kdnd,12)
export(n(*),mo)	-	exports (kdnd,12)
flow	-	flow leaving a node (kdnd,12)
fwreq(n(*),mo)	-	flowby requirements for fish and wildlife (kdnd,12)
gain(n(*),mo)	-	gains (kdnd,12)
histsto(n(*),mo)	-	Millerton historic monthly storage (kdnd,12)
inflo(n(*),mo)	-	inflows to reservoirs (kdnd,12)
jpbexs(mo)	-	remaining monthly flow above 5000 cfs (302 kaf) down the James Bypass (12)
knoddrs(i)	-	array of nodes(kdnd)
knodfw(i)	-	array of nodes with F&W req. (kdnd)
knodgn(i)	-	array of nodes with gain (kdnd)
knodin(i)	-	array of nodes with inflow (kdnd)
knodnp(i)	-	array of nodes with nonproject demands (kdnd)
knodprj(i)	-	array of nodes with project demands (kdnd)
knodrs(i)	-	array of nodes with reservoirs (kdrs)
knodtul(i)	-	list of node numbers of Tulare DAU's (kdnd)
lsink	-	node numbers of DAU's getting water from a sink (kdsrc,12)
nfw	-	number of nodes with fish & wild require. (min flow)
ngain	-	number of nodes with gains
ngwts	-	number of nodes with time series of GW pumping
ninfl	-	number of nodes with inflow
nnpdem	-	number of nonproject demand nodes
npinus(n(*),mo)	-	non-project inflow (kdnd,12)
npgnus(n(*),mo)	-	non-project gain (kdnd,12)
npgwus(n(*),mo)	-	non-project groundwater usage (kdnd,12)
npret(n(*),12)	-	non-project surface returns (kdnd,12)
npretus(n(*),mo)	-	non-project return flow usage
nprjdm	-	number of nodes with project demands
npsht(n(*),mo)	-	non-project shortage (kdnd,12)
nres	-	number of reservoirs
nsink	-	number of sinks
nsource	-	number of sources
ntuldm	-	number of Tulare-area DAUs
paggw(n(*),mo)	-	project groundwater used by agriculture (kdnd,12)
pagsh(n(*),mo)	-	project agricultural shortage (kdnd,12)
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pdel(n(*),mo)	-	total project deliveries (kdnd,12)
pdelag(n(*),mo)	-	project deliveries to agriculture (kdnd,12)
pdelmi(n(*),mo)	-	project deliveries to M&I (kdnd,12)
pmigw(n(*),mo)	-	project groundwater used for M&I (kdnd,12)
pmisht(n(*),mo)	-	project M&I shortage (kdnd,12)
pmius(n(*),mo)	-	project M&I usage (kdnd,12)
pret(n(*),mo)	-	project returns (kdnd,12)
schmflo	-	array of monthly DMC and CAQ deliveries computed in PROSIM (kdnd,12)
sdelv(n(*),12)	-	surface water delivery to a node (kdnd,12)
sjqual(mo)	-	San Joaquin River water quality (mg/l TDS) (12)
spill(n(10))	-	spillage at node 10
vqual(mo)	-	Vernalis water quality mg/l TDS (12)

wqrel (mo)	-	additional water required to meet water quality target at node 125 (12)
wqtar (mo)	-	monthly target water quality objectives in the san Joaquin River (input) (12)
xstfld(n(*),12)	-	flood control rule (kdnd,12)

```
Files read from:
none
```

```
Files written to:
tulare.bin      -      output binary file designated as unit 30
```

2.7.1.4 Subroutine salttim

Writes the annual results to the binary salt file.

Variables and parameters :

div(is,n(*),mo)	-	monthly surface diversion from source to sink (kdsr,c,kdnd,12)
evap(n(*),mo)	-	reservoir evaporation (kdnd,12)
export(n(*),mo)	-	exports (kdnd,12)
flow	-	flow leaving a node (kdnd,12)
gain(n(*),mo)	-	gains (kdnd,12)
histsto(n(*),mo)	-	Millerton historic monthly storage (kdnd,12)
inflo(n(*),mo)	-	inflows to reservoirs (kdnd,12)
knodrs(i)	-	array of nodes(kdnd)
knodgn(i)	-	array of nodes with gain (kdnd)
knodin(i)	-	array of nodes with inflow (kdnd)
knodrp(i)	-	array of nodes with nonproject demands (kdnd)
knodtul(i)	-	list of node numbers of Tulare DAU's (kdnd)
lsink	-	node numbers of DAU's getting water from a sink (kdsr,c,12)
ngain	-	number of nodes with gains
ngwts	-	number of nodes with time series of GW pumping
ninfl	-	number of nodes with inflow
nnpdem	-	number of nonproject demand nodes
npinus(n(*),mo)	-	non-project inflow (kdnd,12)
npgnus(n(*),mo)	-	non-project gain (kdnd,12)
npgwus(n(*),mo)	-	non-project groundwater usage (kdnd,12)
npres(n(*),12)	-	non-project surface returns (kdnd,12)
npresus(n(*),mo)	-	non-project return flow usage
nprjdm	-	number of nodes with project demands
npsht(n(*),mo)	-	non-project shortage (kdnd,12)
nres	-	number of reservoirs
nsink	-	number of sinks
nsource	-	number of sources
paggw(n(*),mo)	-	project groundwater used by agriculture (kdnd,12)
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pmigw(n(*),mo)	-	project groundwater used for M&I (kdnd,12)
pmius(n(*),mo)	-	project M&I usage (kdnd,12)
pret(n(*),mo)	-	project returns (kdnd,12)
sdelv(n(*),12)	-	surface water delivery to a node (kdnd,12)
stor(n(*),mo)	-	end of month storage, output (kdnd,12)

Files read from:

none

Files written to:

salt.bin	-	output binary file designated as unit 31
----------	---	--

2.7.2 WRITE.for

2.7.2.1 Subroutine writonce

Writes the initialization data to a file (unit 30)

Variables and parameters :

agefcrit(nd,mo)	-	agricultural monthly efficiencies for non-critical years (kdnd,12),input
agefnon(nd,mo)	-	agric monthly efficiencies for non-critical years kdnd,12), input
agrfcrit(nd,mo)	-	agricultural water use efficiency for critical years (kdnd,12) input
agrpat	-	monthly agricultural demand pattern at a node (kdnd,12) input
anagcon(nd)	-	annual agric. contract at a node (kdnd), input
anagdem(nd)	-	annual agric. demand at a node (kdnd), input
anmicon(nd)	-	annual M&I contract at a node (kdnd), input
anmidem(nd)	-	annual M&I demand at a node (kdnd), input
begmo	-	(integer) month in which simulation starts
begsim	-	(integer) year in which simulation starts
begyr	-	(integer) year at beginning of run, (1922)
binfil	-	name of binary output file
bstor(n(*))	-	beginning storage for month (kdnd), input
capcty(n)	-	capacity of links (kdnd)
contag(nd,mo)	-	monthly contracted agricultural deliveries at a node product of anagcon(nd) and agrpat(nd,mo)
contmi(nd,mo)	-	monthly contracted M&I deliveries at a node product of anmicon(nd) and mnipat(nd,mo)
dismad(mo)	-	array of monthly fractions of Madera Canal (EXPORT 25) water from Millerton going to node 25,remainder goes to node 35, input (12)
errfil	-	name of ASCII file containing error statements
ev(nd,mo)	-	reservoir evaporation depth (.01 ft) (kdnd,12)
flodfil	-	name of file with time series of flood control rule storages
frmspl(i)	-	fraction of Class 1 and Class 2 water
frusret(j,nd)	-	array of percentage of return from an u/s node going to the current node, (kdusr,kdnd)
fwclas(nd,mo,i5)	-	array of fw req.values at 7 levels (kdnd,12,7),input
fwfil	-	name of file with F&W data
fwrequn(nd)	-	array of fw req. "equations" in character variables, (kdnd), input
fwtrig(nd,i5)	-	array of fw req. trigger values (kdnd,7), input
gainfil	-	name of file with time series of GAINS
imnode	-	temporary variable for node number
inffil	-	name of file with time series of inflows
kfrfst	-	forecast option for Millerton inflows
kfwfor	-	fish and wildlife water requirements (12)
knodcp(i)	-	array of nodes with capacities (kdnd)
knodcvp(i)	-	array of nodes with CVP demands (kdnd)
knoddm(i)	-	array of nodes with demands (kdnd)
knodfw(i)	-	array of nodes with F&W req. (kdnd)
knodgn(i)	-	array of nodes with gain (kdnd)
knodin(i)	-	array of nodes with inflow (kdnd)
knodnp(i)	-	array of nodes with nonproject demands (kdnd)
knodpmp(i)	-	array of nodes with GW pumping (kdnd)
knodprj(i)	-	array of nodes with project demands (kdnd)

knodpts(i)	-	array of nodes with time series of historical GW pumping
knodrs(i)	-	array of nodes with reservoirs (kdrs)
knodwr	-	undefined variable
kswgw	-	switch to use groundwater model only
kswpow	-	switch to turn calls to power routines on and off
kswsmlt(n(*))	-	array of binary switches to turn on snowmelt routine (kdnd)
lastyr	-	last year in simulation
maxusnd	-	maximum upstream nodes
maxusrt	-	maximum number of nodes with returns immediately upstream from current node
mday	-	time in days
mhour	-	time in hours
miefnon(nd,mo)	-	monthly M&I efficiency for non-critical years, (kdnd,12) input
miefcri(nd,mo)	-	M&I efficiency for critical years, (kdnd,12), input
mminut	-	time in minutes
mmonth	-	time in months
mnipat(nd,mo)	-	(real) M&I monthly pattern at a node (kdnd,12),input
msecs	-	time in seconds
myear	-	time in years
m100th	-	time in 100ths of a second
n	-	counter variable
ncap	-	number of nodes with capacities
ncvpdm	-	number of CVP demand nodes
ndemd	-	number of nodes with demand
ndnum(i)	-	array of node numbers (kdnd)
nfw	-	number of nodes with fish & wild require. (min flow)
ngain	-	number of nodes with gains
ninfl	-	number of nodes with inflow
nnodes	-	number of nodes in the model
nnpdem	-	number of nonproject demand nodes
npefcric(nd,mo)	-	(real) non-project critical year monthly efficiencies (kdnd,12)
npefnon(nd,mo)	-	(real) non-project non-critical year monthly efficiencies (kdnd,12)
nprjdm	-	number of nodes with project demands
nprjts	-	number of nodes with time series of project demands
npump	-	number of nodes with GW pumping
nres	-	number of reservoirs
nusnod(nd)	-	number of immediately upstream nodes
nusret	-	number of immediately u/s nodes with returns going to current node
nwretn	-	undefined variable
nyear	-	number of years in simulation, LASTYR-BEGSIM+1
pdmfil	-	name of file with project demand data
pdtstfil	-	name of file with time series of project demands
powrfil	-	name of file with CVP system power variables
pumpfil	-	name of file with min. and max. GW pumping data
qpow(nd,mo)	-	release limit for hydropower (kdnd,12)
resfil	-	name of file with reservoir data
rttitle	-	run title, 80 characters
schmfil	-	name of file with data from PROSIM
srule(nd,mo)	-	storage rule (kdnd,12)
starcf(nd,j)	-	storage-area curve coefficients
stelcf(nd,j)	-	storage-elevation curve coeffs. (kdnd,4)
strf(n(*))	-	storable inflows to reservoirs (kdnd)

tpdem(nd,mo)	-	target monthly project demand (kdnd,12)
tpdmag(nd,mo)	-	target monthly project agricultural demand (kdnd,12)
tpdmmi(nd,mo)	-	target monthly project M&I demand (kdnd,12)
usnode(j,nd)	-	(integer) node numbers of nodes immediately upstream of current node (kdusn,kdnd)
usret(j,nd)	-	(integer) node numbers of nodes with returns immediately upstream of current node (kdusn,kdnd)
wqtar(mo)	-	monthly water quality target at node 27, Vernalis (mg/l)
wyrfil	-	name of file with year types
xaggw(nd,mo)	-	maximum monthly agricultural GW pumping, (kdnd,12)
xmigw(nd,mo)	-	maximum monthly M&I groundwater pumping (kdnd,12)
xnpgw(nd,mo)	-	maximum monthly non-project groundwater pumping (kdnd,12)
xppatp(nd,mo,*)	-	project groundwater pumping pattern for maximum annual withdrawal (kdnd,12,3)
xppatnp(nd,mo,*)	-	non- project groundwater pumping pattern for maximum annual withdrawal (kdnd,12,3)
xpmpnp(nd,*)	-	maximum annual non-project groundwater pumping for a demand node (3 year types input) (kdnd,3)
xstor(n(*))	-	maximum reservoir storage (kdnd)
yaggw(nd,mo)	-	minimum monthly groundwater pumping
ymigw(nd,mo)	-	minimum monthly M&I GW pumping, (kdnd,12)
ynpgw(nd,mo)	-	minimum non-project monthly GW pumping (kdnd,12)
yppatp(nd,mo,*)	-	project groundwater pumping pattern for minimum annual withdrawal (kdnd,12,3)
yppatnp(nd,mo,*)	-	non- project groundwater pumping pattern for minimum annual withdrawal (kdnd,12,3)
ypmpnp(nd,mo)	-	minimum annual non-project groundwater pumping for a demand node (3 year types input) (kdnd,3)
ypmpp(nd,mo)	-	minimum annual project groundwater pumping for a demand node (3 year types input) (kdnd,3)
yrtype(k)	-	integer array of year types, input (kdyr)
ystor(n(*))	-	minimum storage (kdnd)
ystrsv(nd,mo)	-	mimimum reservoir reserve storage (kdnd,12)

Files read from:
none

Files written to:
tulare.out - output file designated as unit 30

2.7.2.2 Subroutine writtime

Writes the annual results to a binary file.

Variables and parameters :

div(is,n(*),mo)	-	monthly surface diversion from source to sink (kdsr,c,kdnd,12)
dmcq(*)	-	flow from mendota Pool into node 15 (12)
evap(n(*),mo)	-	reservoir evaporation (kdnd,12)
export(n(*),mo)	-	exports (kdnd,12)
flow	-	flow leaving a node (kdnd,12)
fwreq(n(*),mo)	-	flowby requirements for fish and wildlife (kdnd,12)
gain(n(*),mo)	-	gains (kdnd,12)
histsto(n(*),mo)	-	Millerton historic monthly storage (kdnd,12)
inflow(n(*),mo)	-	inflows to reservoirs (kdnd,12)
jpbexs(mo)	-	remaining monthly flow above 5000 cfs (302 kaf) down the James Bypass (12)
knodrs(i)	-	array of nodes with reservoirs (kdnd)
knodfw(i)	-	array of nodes with F&W req. (kdnd)
knodgn(i)	-	array of nodes with gain (kdnd)
knodin(i)	-	array of nodes with inflow (kdnd)
knodnp(i)	-	array of nodes with nonproject demands (kdnd)
knodprj(i)	-	array of nodes with project demands (kdnd)
knodrs(i)	-	array of nodes with reservoirs (kdrs)
knodtul(i)	-	list of node numbers of Tulare DAU's (kdnd)
lsink	-	node numbers of DAU's getting water from a sink (kdsr,c,12)
mwh(n(*),mo)	-	undefined variable
nfw	-	number of nodes with fish & wild require. (min flow)
ngain	-	number of nodes with gains
ngwts	-	number of nodes with time series of GW pumping
ninfl	-	number of nodes with inflow
nnpdem	-	number of nonproject demand nodes
npinus(n(*),mo)	-	non-project inflow (kdnd,12)
npgnus(n(*),mo)	-	non-project gain (kdnd,12)
npgwus(n(*),mo)	-	non-project groundwater usage (kdnd,12)
npret(n(*),mo)	-	non-project surface returns (kdnd,12)
npretus(n(*),mo)	-	non-project return flow usage
nprjdm	-	number of nodes with project demands
npsht(n(*),mo)	-	non-project shortage (kdnd,12)
nres	-	number of reservoirs
nsink	-	number of sinks
nsourc	-	number of sources
ntuldm	-	number of Tulare-area DAUs
paggw(n(*),mo)	-	project groundwater used by agriculture (kdnd,12)
pagsht(n(*),mo)	-	project agricultural shortage (kdnd,12)
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pdcl(n(*),mo)	-	total project deliveries (kdnd,12)
pdclag(n(*),mo)	-	project deliveries to agriculture (kdnd,12)
pdclmi(n(*),mo)	-	project deliveries to M&I (kdnd,12)
pmigw(n(*),mo)	-	project groundwater used for M&I (kdnd,12)
pmisht(n(*),mo)	-	project M&I shortage (kdnd,12)
pmius(n(*),mo)	-	project M&I usage (kdnd,12)
pret(n(*),mo)	-	project returns (kdnd,12)
schmflo	-	array of monthly DMC and CAQ deliveries computed in PROSIM (kdnd,12)
sclv(n(*),mo)	-	surface water delivery to a node (kdnd,12)
sjqual(mo)	-	San Joaquin River water quality (mg/l TDS) (12)
spill(n(10))	-	spillage at node 10

tempdel(n(*),mo)	-	temporary variable - total delivery to a node (kdnd,12)
tempfw(n(*),mo)	-	temporary variable - fish and wildlife requirements (kdnd,12)
tempmi(n(*),mo)	-	temporary variable - municipal and industrial demands (kdnd,12)
vqual(mo)	-	Vernalis water quality mg/l TDS (12)
wqrel(mo)	-	additional water required to meet water quality target at node 125 (12)
wqtar(mo)	-	monthly target water quality objectives in the san Joaquin River (input) (12)
xstfld(n(*),mo)	-	flood control rule (kdnd,12)

Files read from:

none

Files written to:

tulare.bin	-	output binary file designated as unit 30
------------	---	--

2.8 BALSHEET.for

Writes the balance sheets for each of the model subregions. BALSHEET prompts for the name of the output control file which contains the information which the balance sheets require as input and the years they are to be written for. Appropriate subroutines are called to write the output.

Variables and parameters :

begsim	-	(integer) year in which simulation starts
bstor(n(*))	-	beginning storage for month (kdnd)
contfil	-	control file
flow(n(*),mo)	-	flow leaving a node (kdnd,12)
frusret(j,nd)	-	array of percentage of return from an u/s node going to the current node, (kdusr,kdnd)
thead	-	header lines in control file
inflow(n(*),mo)	-	inflow to a reservoir (kdnd,12)
iperiod	-	interval between beginning and ending dates to be analyzed with balsheet
iyrend	-	last year to be included in balsheet
iystr	-	starting year for balsheet
ksheet(*)	-	series of binary switches which call subregion balance subroutines
kyr	-	year counter
lastyr	-	last year in simulation
ndnum	-	array of node numbers
nnodes	-	number of nodes in the model
npngus(n(*),mo)	-	non-project gain (kdnd,12)
npgwus(n(*),mo)	-	non-project groundwater use (kdnd,12)
npinus(n(*),mo)	-	non-project inflow (kdnd,12)
npret(ku,mo)	-	non project returns (kdnd,12)
npretus(n(*),mo)	-	non-project return flow usage (kdnd,12)
npsur(n(*),mo)	-	summation of non-project gains, inflows and returns (kdnd,12)
nres	-	number of reservoirs
nusnod(nd)	-	number of immediately upstream nodes (kdnd)
nusret	-	number of immediately u/s nodes with returns going to current node
paggw(n(*),mo)	-	project groundwater used by agriculture (kdnd,12)
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pdel(n(*),mo)	-	total project deliveries (kdnd,12)
pdelgr(n(*),mo)	-	total project delivery from groundwater sources (kdnd,12)
pdelsu(n(*),mo)	-	total project delivery from surface water sources (kdnd,12)
pmigw(n(*),mo)	-	project groundwater used for M&I (kdnd,12)
pret(ku,mo)	-	project return flows (kdnd,12)
return(n(*),mo)	-	total project and non-project returns (kdnd,12)
rtitle	-	run title, 80 characters
rundate	-	date on which model simulation is run
runtime	-	time at which model simulation is run
schmflo(*,mo)	-	array of monthly DMC and CAQ deliveries computed in PROSIM (kdnd,12)
section(i)	-	basin section for which data is output (6)
stor(n(*),mo)	-	end of month storage (kdnd,mo)
usflow(n(*),mo)	-	flow upstream of a node flowing into a node (kdusn,12)
usnode(i,nd)	-	array of node numbers of nodes immediately upstream of current node (kdusn,mo)
usret(i,nd)	-	array of node numbers of nodes with returns immediately upstream of current node (kdusn,12)

Subroutine calls:

ktck(kf,kyr)	-	output routine for the Friant Kern Canal, Kaweah, Tule, Kings River and Cross Valley Canal
sjkn(kf,kyr)	-	output routine for the middle San Joaquin River and King's River
merc(kf,kyr)	-	output routine for the Merced River
tuol(kf,kyr)	-	output routine for the Tuolumne River
cast(kf,kyr)	-	output routine for the Calaveras - Stanislaus Rivers
tdau(kf,kyr)	-	output routine for the Tulare basin

Files read from:

binfil	-	binary output file containing all the hydrologic output from a SANTUCM scenario run
control	-	control file containing the switches to create tables of water balances for each sub-basin
imbal.err	-	error file containing the year and the node number where imbalances occur

Files written to:

outfil	-	tables of water balances at each stream node within a sub-basin. Sub-basins defined by unit number variable kf : where kf takes values of 51 - 56.
	-	ktck.bas (unit = 51)
	-	sjkn.bas (unit = 52)
	-	merc.bas (unit = 53)
	-	tuol.bas (unit = 54)
	-	cast.bas (unit = 55)
	-	tdau.bas (unit = 56)

2.8.1 TUOL.for

Output mass balance error checking routine for the Tuolomne River. Includes nodes 60, 65, 70, 75, 80, 85, 90 and 95.

Variables and parameters :

balance	-	sum of all the inflows to and outflows from a node
bstor(n(*))	-	beginning storage for the month (kdnd)
evap(n(*),mo)	-	reservoir evaporation (kdnd,12)
export(n(*),mo)	-	exports (kdnd,12)
flow(n(*),mo)	-	flow leaving a node (not including returns) (kdnd,12)
fwreq(n(*),nd)	-	flowby requirements for fish and wildlife (kdnd,12)
gain(n(*),mo)	-	gains (kdnd,12)
inflo(n(*),mo)	-	inflow to reservoirs(kdnd,12)
kf	-	unit number corresponding to sub-basin
kyear	-	year counter
npwgus(n(*),mo)	-	non-project groundwater use (kdnd,12)
npsht(n(*),mo)	-	non - project shortage (kdnd,12)
paggw(n(*),mo)	-	project groundwater used by agriculture (kdnd,12)
pagsht(n(*),mo)	-	project agricultural shortage (kdnd,12)
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pdel(n(*),mo)	-	total project deliveries (kdnd,12)
pdelgr(n(*),mo)	-	total project delivery from groundwater sources (kdnd,12)
pmigw(n(*),mo)	-	project groundwater used for M&I (kdnd,12)
pmisht(n(*),mo)	-	project M&I shortage
pmius(n(*),mo)	-	project surface water use for M&I (kdnd,12)
stor(n(*),mo)	-	end of month storage (kdnd,mo)
tinf(mo)	-	total inflow to a node (12)
tdelv(mo)	-	total surface delivery to a node (12)
usflow(n(*),mo)	-	flow upstream of a node flowing into a node (kdusn,12)

Subroutine calls:

resbal(n(*),bstor,balance)	-	routine to calculate mass balances for reservoirs
imbalnc(kyear,nd,balance)	-	routine for finding any imbalances in the output file and printing them out in the error file
totdelv(n(*),tdelv)	-	sums the total monthly deliveries to a node (works with the CVP/SWP balance routines)

Functions:

atot(n(*),mo)	-	sum of the monthly values of a particular variable (kdnd,mo)
---------------	---	--

Files read from:

none

Files written to:

tuol.bas or a specified in control file

2.8.2 MERC.for

Output mass balance error checking routine for the Merced River. Includes nodes 40,45,50 and 55

Variables and parameters :

balance	-	sum of all the inflows to and outflows from a node
bstor(n(*))	-	beginning storage for the month (kdnd)
evap(n(*),mo)	-	reservoir evaporation (kdnd,12)
export(n(*),mo)	-	exports (kdnd,12)
flow(n(*),mo)	-	flow leaving a node (not including returns) (kdnd,12)
fwreq(n(*),nd)	-	flowby requirements for fish and wildlife (kdnd,12)
gain(n(*),mo)	-	gains (kdnd,12)
inflo(n(*),mo)	-	inflow to reservoirs(kdnd,12)
kf	-	unit number corresponding to sub-basin
kyear	-	year counter
npgwus(n(*),mo)	-	non-project groundwater use (kdnd,12)
npsht(n(*),mo)	-	non - project shortage (kdnd,12)
paggw(n(*),mo)	-	project groundwater used by agriculture (kdnd,12)
pagsht(n(*),mo)	-	project agricultural shortage (kdnd,12)
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pdel(n(*),mo)	-	total project deliveries (kdnd,12)
pdelgr(n(*),mo)	-	total project delivery from groundwater sources (kdnd,12)
pmigw(n(*),mo)	-	project groundwater used for M&I (kdnd,12)
pmisht(n(*),mo)	-	project M&I shortage
pmius(n(*),mo)	-	project surface water use for M&I (kdnd,12)
stor(n(*),mo)	-	end of month storage (kdnd,mo)
tinf(mo)	-	total inflow to a node (12)
tdelv(mo)	-	total surface delivery to a node (12)
usflow(n(*),mo)	-	flow upstream of a node flowing into a node (kdusn,12)

Subroutine calls:

resbal(n(*),bstor,balance)	-	routine to calculate mass balances for reservoirs
imbalnc(kyear,nd,balance)	-	routine for finding any imbalances in the output file and printing them out in the error file
totdelv(n(*),tdelv)	-	sums the total monthly deliveries to a node (works with the CVP/SWP balance routines)

Functions:

atot(n(*),mo)	-	sum of the monthly values of a particular variable (kdnd,mo)
---------------	---	--

Files read from:

none

Files written to:

merc.bas or a specified in control file

2.8.3 SJKN.for

Output mass balance error checking routine for the upper San Joaquin River.
Includes nodes 5, 10, 300, 305, 310, 315, 15, 20, 25, 30 and 35.

Variables and parameters :

balance	-	sum of all the inflows to and outflows from a node
bstor(n(*))	-	beginning storage for the month (kdnd)
div(*,n(*),mo)	-	monthly surface diversion from source to sink (kdsrce,kdnd,12)
dmcq(mo)	-	flow from Mendota Pool into node 15 (12)
evap(n(*),mo)	-	reservoir evaporation (kdnd,12)
export(n(*),mo)	-	exports (kdnd,12)
flow(n(*),mo)	-	flow leaving a node (not including returns) (kdnd,12)
fwreq(n(*),mo)	-	flowby requirements for fish and wildlife (kdnd,12)
gain(n(*),mo)	-	gains (kdnd,12)
inflo(n(*),mo)	-	inflow to reservoirs(kdnd,12)
jbpexs(mo)	-	excess flow that can't go down James Bypass (12)
kf	-	unit number corresponding to sub-basin
kyear	-	year counter
milfsh(mo)	-	additional releases for fish along the SJR (12)
milgn(mo)	-	additional gains from Millerton operations (12)
npgrws(n(*),mo)	-	non-project groundwater use (kdnd,12)
npret(n(*),mo)	-	non-project returns (kdnd,12)
npsht(n(*),mo)	-	non - project shortage (kdnd,12)
npsur(n(*),mo)	-	non-project delivery surplus (kdnd,12)
paggw(n(*),mo)	-	project groundwater used by agriculture (kdnd,12)
pagsh(n(*),mo)	-	project agricultural shortage (kdnd,12)
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pdel(n(*),mo)	-	total project deliveries (kdnd,12)
pdelag(n(*),mo)	-	project deliveries to agriculture (kdnd,mo)
pdelmi(n(*),mo)	-	project deliveries to M&I (kdnd,12)
pdelgr(n(*),mo)	-	total project delivery from groundwater sources (kdnd,12)
pmigw(n(*),mo)	-	project groundwater used for M&I (kdnd,12)
pmisht(n(*),mo)	-	project M&I shortage
pmius(n(*),mo)	-	project surface water use for M&I (kdnd,12)
pret(n(*),mo)	-	project returns (kdnd,12)
stor(n(*),mo)	-	end of month storage (kdnd,mo)
tinf(mo)	-	total inflow to a node (12)
tdelv(mo)	-	total surface delivery to a node (12)
tpdem(n(*),mo)	-	monthly project demand target (kdnd,12)
usflow(n(*),mo)	-	flow upstream of a node flowing into a node (kdusn,12)

Subroutine calls:

resbal(n(*),bstor,balance)	-	routine to calculate mass balances for reservoirs
imbalnc(kyear,nd,balance)	-	routine for finding imbalances in the output file and printing error lines in an error file
totdelv(n(*),tdelv)	-	sums the total monthly deliveries to a node (works with the CVP/SWP balance routines)

Functions:

atot(n(*),mo)	-	sums the monthly values of a particular variable (kdnd,mo)
divtot(*,n(*))	-	sums monthly surface diversions (*,kdnd)

gentot(*,n(*),*) - sums values of a one or two dimensional array into an
annual total (ni,nd,array)

Files read from:
none

Files written to:
sjkn.bas or as specified in the control file

2.8.4 KTCK.for

Output mass balance error checking routine for the Friant-Kern Canal, Cross-Valley Canal and Kern River. Includes nodes 234,270, 240, 275, 285, 290, 295, 296, 320, 325,330, 335, 340, 341, 342, 343, 365, 370, 375, 380 and 261.

Variables and parameters :

balance	-	sum of all the inflows to and outflows from a node
div(*,n(*),mo)	-	monthly surface diversion from source to sink (kdsr,c,kdnd,12)
export(n(*),mo)	-	exports (kdnd,12)
flow(n(*),mo)	-	flow leaving a node (not including returns) (kdnd,12)
gain(n(*),mo)	-	gains (kdnd,12)
inflo(n(*),mo)	-	inflow to reservoirs(kdnd,12)
jbpexs(mo)	-	excess flow that can't go down James Bypass (12)
kf	-	unit number corresponding to sub-basin
kyear	-	year counter

Subroutine calls:

imbalnc(kyear,nd,balance)	-	routine for finding any imbalances in the output file and printing them out in the error file
---------------------------	---	---

Functions:

atot(n(*),mo)	-	sums the monthly values of a particular variable (kdnd,mo)
divtot(*,n(*))	-	sums monthly surface diversions (*,kdnd)

Files read from:

none

Files written to:

ktck.bas or as specified in the control file

2.8.5 CAST.for

Output mass balance error checking routine for the Calaveras - Stanislaus Rivers. Includes nodes 100, 105, 110, 150, 155, 160, 165, 115, 120, 125, 130, 135, 140 and 145.

Variables and parameters :

balance	-	sum of all the inflows to and outflows from a node
bstor(n(*))	-	beginning storage for the month (kdnd)
evap(n(*),mo)	-	reservoir evaporation (kdnd,12)
export(n(*),mo)	-	exports (kdnd,12)
flow(n(*),mo)	-	flow leaving a node (not including returns) (kdnd,12)
fwreq(n(*),mo)	-	flowby requirements for fish and wildlife (kdnd,12)
gain(n(*),mo)	-	gains (kdnd,12)
inflo(n(*),mo)	-	inflow to reservoirs (kdnd,12)
kf	-	unit number corresponding to sub-basin
kyear	-	year counter
npwgus(n(*),mo)	-	non-project groundwater use (kdnd,12)
npsht(n(*),mo)	-	non - project shortage (kdnd,12)
npsur(n(*),mo)	-	non-project delivery surplus (kdnd,12)
paggw(n(*),mo)	-	project groundwater used by agriculture (kdnd,12)
pagsht(n(*),mo)	-	project agricultural shortage (kdnd,12)
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pdelgr(n(*),mo)	-	total project delivery from groundwater sources (kdnd,12)
pmigw(n(*),mo)	-	project groundwater used for M&I (kdnd,12)
pmisht(n(*),mo)	-	project M&I shortage
pmius(n(*),mo)	-	project surface water use for M&I (kdnd,12)
stor(n(*),mo)	-	end of month storage (kdnd,mo)
tinfl(mo)	-	total inflow to a node (12)
tdelv(mo)	-	total surface delivery to a node (12)

Subroutine calls:

resbal(n(*),bstor,balance)	-	routine to calculate mass balances for reservoirs
imbalnc(kyear,nd,balance)	-	routine for finding any imbalances in the output file and printing them out in the error file
totdelv(n(*),tdelv)	-	sums the total monthly deliveries to a node (works with the CVP/SWP balance routines)

Functions:

atot(n(*),mo)	-	sums the monthly values of a particular variable (kdnd,mo)
gentot(*,n(*),*)	-	sums values of a one or two dimensional array into an annual total (ni,nd,array)

Files read from:

none

Files written to:

cast.bas or a specified in control file

2.8.6 TDAU.for

Output for the DAU's in the Tulare basin. The subroutine checks the node flags along the Friant - Kern Canal to see if they are subject to deficiencies in dry or critical water years. The subroutine produces a mass balance once these deficiencies have been applied.

Variables and parameters :

begsim	-	year in which simulation starts
div(isrc,nd,mo)	-	monthly surface diversion from source to sink (kdsrc,kdnd,12)
isrc	-	source of water for any DAU
iy	-	year during the simulation
iyt	-	temporary variable for year type
kf	-	unit number corresponding to sub-basin
knodtrd(*)	-	array of Tulare demand nodes
knodtul	-	list of node numbers of Tulare DAU's (kdnd)
kyear	-	year counter
lsink(isrc,j)	-	node numbers of DAU's getting water from a sink (kdsrc,kdnd)
nsink (isrc)	-	number of DAU's getting water from a sink (kdsrc)
nsources	-	number of sources of water in the Tulare area
ntr	-	node flag for Tulare demand nodes
ntred	-	number of Tulare demand deficiency nodes
ntuldm	-	number of Tulare demand nodes
paggw(n(*),mo)	-	project groundwater used by agriculture (kdnd,12)
pagsht(n(*),mo)	-	project agricultural shortage (kdnd,12)
pagus(n(*),mo)	-	project surface water used by agriculture (kdnd,12)
pdel(n(*),mo)	-	total project deliveries (kdnd,12)
sdelv(nd,mo)	-	surface water delivery to a node (kdnd,12)
srcnam(isrc)	-	labels for the various rivers and channels in the Tulare basin
tempdl(nd,mo)	-	project delivery adjusted for deficiencies (kdnd,12)
tred(nd)	-	array of Tulare demand deficiency nodes (ntred)
tulred(nred,*)	-	deficiency factor
yrtype(iy)	-	array of year types (kdyr)

Subroutine calls:

none

Functions:

atot(n(*),mo)	-	sums the monthly values of a particular variable (kdnd,mo)
divtot(*,n(*))	-	sums monthly surface diversions (*,kdnd)

Files read from:

none

Files written to:

tdau.bas or as specified in control file

2.8.7 BSUB.for

Several generic subroutines and functions are included in this module that are called by the output routine to produce monthly and annual totals of flows into and out of each stream node.

Functions

2.8.7.1 Function atot(node,array) :

Sums 12 monthly values into annual totals.

Variables and parameters

array(nd,mo)	-	two dimensional array of variables to be added (kdnd,12)
atot	-	annual total
kdnd	-	total number of nodes
node	-	node number
total	-	cumulative total

2.8.7.2 Function gentot(ni,nd,array)

Sums values from one and two dimensional arrays into an annual total.

Variables and parameters

array(nd,mo)	-	two dimensional array of variables to be added (kdnd,12)
gentot	-	annual total
kdnd	-	total number of nodes
nd	-	node number
ni	-	array variable
total	-	cumulative total

2.8.7.3 Function divtot(isrc,node)

Sums twelve monthly values of Tulare basin diversions to obtain an annual total. Works with the SANTUCM flow balancing routines.

Variables and parameters

div(isrc,node,mo)	-	monthly diversion to a node
divtot	-	total diversion to a node
node	-	node number
total	-	cumulative total

Subroutines

2.8.7.4 Subroutine totdelv (nd,tdelv)

Calculates total annual deliveries to a node

Variables and parameters

npgnus(nd,mo)	-	non-project gain (upstream node)
npgwus(nd,mo)	-	non-project groundwater pumping
npinus(nd,mo)	-	non-project inflow (upstream node)
npretus(nd,mo)	-	non-project return flow
paggw(nd,mo)	-	project groundwater used by agriculture
pagus(nd,mo)	-	project surface water used by agriculture

pmigw(nd,mo)	-	project ground water used by M&I
pmius(nd,mo)	-	project surface water used by M&I
tdelv(*)	-	total delivery to a node (kdnd)

Summary flowchart

- o add all project and non-project component inflows to a node
- o total all monthly inflows to a node to obtain an annual delivery

2.8.7.5 Subroutine resbal(nd,bstor,balance)

Computes reservoir mass balances

Variables and parameters

balance(mo)	-	net flow into or out of a stream or reservoir node after taking account of all flow into and out of the node (12)
bstor(nd)	-	beginning reservoir storage for the month (nd)
evap(nd,mo)	-	reservoir evaporation (kdnd,12)
export(nd,mo)	-	exports (kdnd,12)
flowin	-	flow entering a node
flow(nd,mo)	-	flow leaving a node (not including returns from the node (kdnd)
inflo(nd,mo)	-	inflows to reservoirs (kdnd,12)
pagus(nd,mo)	-	project surface water used by agriculture (kdnd,12)
pmius(nd,mo)	-	project surface water used by M&I
stor(nd,mo)	-	end of month storage (kdnd,12)
xpt	-	combined project surface water use by both agriculture and M&I

Summary flowchart

- o set flow into the reservoir
- o for node 105 set Tulloch inflow to New Melones releases + net accretions
- o set total agricultural and M&I releases from Millerton equal to sum of exports from nodes 5, 25 and 35.
- o set total agricultural and M&I releases from Hetchy-Hetchy equal to sum of exports from node 60.
- o for the first month only include the end of year reservoir storage in the flow balance equation

2.8.7.6 Subroutine imbalnc (iyear,node,balance)

Routine which tests for flow imbalances

Variables and parameters

balance(mo)	-	net flow into or out of a stream or reservoir node after taking account of all flow into and out of the node (12)
iyear	-	year of simulation
tol	-	tolerance above which flag for imbalance message is set

Summary flowchart

- o Loop through each month of the year
- o Compare the absolute value of the balance against the tolerance
- o If the tolerance is greater than the tolerance write to the printer and to an external file. Print year, month, node and value.

2.9 SANVAR.for

SANVAR is used to extract any single or combination of variables in the binary file out into a one page table (month x year) of all values of the variable for a given year or range of years. A table of "equations" are used to select the variables SANVAR should look at. The program reads the equation and compares the variables with the data statement and allows the user to correct any errors. Subroutine LOWER takes the input variable name given in the equation and converts it to lower case to agree with the data statement to make validation easier.

Subroutine CALCX1 selects the model variable and puts the monthly values into array X1. X1 is passed back into MAIN and stored in the three-dimensional array X3. Totals are computed and the arrays are written to the output file. Most units are kaf, but groundwater storage (GWST) needs to be converted to Maf, or the values will be too big for the fields.

Example INPUT instruction file

The input file looks like this:

line no. | column 1 of input file is at the pipe symbol

```
1   run6.bin
2   output
3   1922 1925
4   Delta outflow
5   +flow      30
6   gains between Keswick and nav. control point
7   +inflo    99+gain    99
```

line 1 is the input file name

line 2 is the output file name

line 3 is the range of years for the requests

line 4 is the title for the request, 80 chars. max.

line 5 is the equation to get Delta outflows. be very careful of format

lines 6 and 7 are the input to request 2

Variables and parameters :

cnt	-	used as a subscript for number of years
answr	-	holds single character responses from various questions
exists	-	logical used to check if input file exists or not
flow_af	-	holds data display type - TAF/CFS
goodyr	-	holds year if it is within the range requested
inpt_nam	-	contains variable name from input that is passed to 'lower' for conversion to lower case
inpvnam	-	character array (KDVAR,KDFUN) of variable names read as input
kdfun	-	dimension of model variables that make up a request (equation)
kdvar	-	dimension of requests that can be written
kdvnam	-	dimension of variable names stored in this program
kpsw	-	switch to suppress printing of annual totals for storage and quality variables
linecnt	-	controls page overflow for output report
minus	-	character with minus sign
nfunc	-	array (KDVAR) with number of variables that make up a request

node - array (KDVAR,KDFUN) with node numbers of variables
 nreq - number of separate request
 out_file - name of output file
 pageno - counter for page number control
 plus - character with plus sign
 rptseq - holds response for sequence of report
 sign - character array (KDVAR,KDFUN) with input + or - sign
 scale - array (KDVAR) with scale factors. 1 for kaf, .001 for Maf
 seq - used as subscript for report by annual total
 srtdyr - sorted array of years by annual total
 title - array (KDVAR) of titles for each request, such as
 'flow at navigation control point'
 totalmo - integer array (KDVAR,12) with monthly averages
 totalan - " annual totals
 totalvr - integer array (KDVAR) with annual averages
 unit - character with either 'TAF' or 'MAF'
 varnam - character array (KDVNAM) of variable names that are stored
 in this program
 x3 - integer array (KDVAR,12,KDYR) storing values for output
 x1 - integer array (12) with monthly variable values, these go
 into X3
 year1 - first year for selected report
 year2 - ending year for selected report

Subroutine calls:

lower(inpt_nam) - converts user input to lower case.
 sortmon(x3,nreq,noyrs,kdvar,kdyr) - sorts a three dimensional array into descending order by column.
 sortann(srtdyr,totalan,nreq,noyrs,kdvar,kdyr) - creates an array (srtdyr) to keep track of monthly data and sorts the total annual array in descending order,

Files read from:

binfil - binary file containing the SANTUCM model output

Files written to:

user specified output file

2.9.1 Subroutine CALCX1 (mo,in,kpsw,nreq, x1,lnpvnam,node, varnam,flow_af)

This subroutine puts values into the x1 vector by finding the appropriate matching variable name

Variables and parameters

evap(nd,mo)	-	reservoir evaporation (kdnd,12)
export(nd,mo)	-	monthly export from a reservoir node (kdnd,12)
flow_af	-	flow volume in acre-ft
fwreq(nd,mo)	-	flowby requirements for fish and wildlife (kdnd,12)
gain(nd,mo)	-	monthly gains (kdnd,12)
gwst(nd,mo)	-	groundwater storage (salt model) (kdnd,12)
histsto(nd,mo)	-	monthly historic reservoir storage (kdnd,12)
lnpvnam(in,nf)	-	input variable name to be placed in X-1 vector
kpsw	-	switch for printing results
npdel(nd,mo)	-	non-project deliveries (kdnd,12)
npgnus(nd,mo)	-	non-project gain (upstream node)
npgwus(nd,mo)	-	non-project groundwater pumping
npinus(nd,mo)	-	non-project inflow (upstream node)
npret(nd,mo)	-	non-project return flows (kdnd,12)
npretus(nd,mo)	-	non-project return flows used (kdnd,12)
npsht(nd,mo)	-	non-project shortage (kdnd,12)
nreq	-	number of required iterations in tabular summary
paggw(nd,mo)	-	project groundwater used by agriculture
pagsht(nd,mo)	-	project agricultural shortage (kdnd,12)
pagus(nd,mo)	-	project surface water used by agriculture
pdel(nd,mo)	-	project delivery to a node (kdnd,12)
pdelag	-	project delivery to agriculture (kdnd,12)
pdelmi(nd,mo)	-	project delivery to M&I (kdnd,12)
pmigw(nd,mo)	-	project ground water used by M&I (kdnd,12)
pmisht(nd,mo)	-	project M&I shortage (kdnd,12)
pmsus(nd,mo)	-	project surface water used by M&I
pret(nd,mo)	-	project return flow to a node (kdnd,12)
sjqual(*)	-	San Joaquin river water quality (mg/l TDS)
stor(nd,mo)	-	end of month storage (kdnd,12)
tdelv(*)	-	total delivery to a node (kdnd)
varnam(*)	-	matching variable name
vqual(mo)	-	Vernalis water quality (mg/l TDS)
wqrel(nd,mo)	-	additional water required to meet water quality target at node 125
x1(mo)	-	nearest integer value of expression

Summary flowchart

- o Loop through each month of the year
- o Compare the absolute value of the balance against the tolerance
- o If the tolerance is greater than the tolerance write to the printer and to an external file. Print year, month, node and value.

2.10. Salinity Model Subroutines

Main program

2.10.1 SALT.for1

Calculates the mass flux of total dissolved solids from the concentration of flows (CONCFL), return flows (CONCRET), inflow (CONCIN), gains (CONCGN), and exports (CONCXPT). The total mass flux is equal to the discharge times the concentration for each flow.

Variables and parameters :

begsim	-	beginning year of SANTUCM simulation
bsalyr	-	beginning year for which salt balances are to be computed
bstor(n(*))	-	beginning storage for month (kdnd)
ckswgw	-	switch to use salinity algorithm in conjunctive mode
conc*** (nd,mo)	-	concentration (conc***) where variables are: concFL for flow values concRET for return flow values concIN for inflow values concGN for stream gain values concXPT for export values concGW for pumped groundwater (gwuse) concING for initial concentration of each groundwater finite element concIM for import water concAPL for applied water concST for
conctot	-	total mass of salt in both upper and lower aquifers
div(isrc,nd,mo)	-	stream diversion
divflux	-	salt flux from the diversion points to the DAU's
export(nd,mo)	-	export from a node (kdnd,12)
flow(nd,mo)	-	flow in a stream leaving a node (kdnd,12)
fractn(i)	-	fraction of an element that lies within a DAU
frc	-	fraction of a DAU that lies within an element
gnodvol(*,mo)	-	set equal to totvol, groundwater storage in upper and lower aquifers (kdnd,12)
gwuse(nd,mo)	-	groundwater usage at each sw node
import(nd,mo)	-	project import water supply (kdnd,12)
inflo(nd,mo)	-	inflow to a node (kdnd,12)
influx(nd,mo)	-	mass of salt flowing into a node
inodes(in)	-	surface water node numbers
knoddm(in)	-	array of nodes with demands (kdnd)
knodpmp(in)	-	array of nodes with groundwater pumping (kdnd)
knodwrt	-	array of nodes for which concentrations will be written (kdnd)
knodrs(in)	-	array of nodes with reservoirs (kdnd)
knodtul(in)	-	list of node numbers of Tulare DAU's
kswgw	-	switch for surface, groundwater and conjunctive models
kswnd(nd)	-	switch preventing node from being scanned more than once
lastyr	-	ending year of SANTUCM simulation
lelem(i)	-	groundwater node number
lsalyr	-	ending year for which salt balances are to be computed

mominsl	-	subscript variable for last month
ndemd	-	number of demand nodes
ndau(i)	-	number of DAU's in the model
nelem(i)	-	DAU number or element number
ninfl	-	number of inflows to reservoirs
nmz	-	subscript set equal to the pumping node number
nord(in)	-	node numbers
npret(ur,mo)	-	non-project returns (kdnd,12)
npump	-	number of nodes with groundwater pumping
nres	-	number of reservoirs
nsink	-	number of sinks
nsource	-	number of water sources
ntuldm	-	number of Tulare demand nodes
nusret(i,nd)	-	number of immediately upstream nodes with returns going to current node
nwrite	-	number of nodes that results are written for
paggw(nd,mo)	-	project agricultural groundwater pumped (kdnd,12)
pmigw(nd,mo)	-	project M&I groundwater pumped
pret(ur,mo)	-	project returns (kdnd,12)
qin(nd,mo)	-	incoming FLOWS + IMPORT + RETURNS
ratelch(j)	-	rate of salt leachate from irrigation applied water through soil media
rconcost(nd)	-	initial TDS concentration in reservoirs
retin	-	incoming return flows
retus	-	total project and non-project returns (upstream)
sdelv(nd,mo)	-	total surface water delivery into a DAU (kdnd,12)
snodvol(nmz,mo)	-	surface water node volume (GW - SW transformation)
stor(nd,mo)	-	end of month storage (kdnd,12)
surfuse(nd,mo)	-	surface water usage at each surface water node (kdnd,12)
swnode(j)	-	surface water node (DAU) number
tmpcon(*)	-	groundwater concentration last month - set equal to initial condition at start of month next year
tmpconc(mo)	-	TDS concentration of inflow
tmpvol(*)	-	groundwater storage last month - set equal to initial condition at start of month next year
totvol	-	total groundwater storage in layers 1 and 2
use	-	total water usage or applied water at each surface water node
usf	-	up-stream flow (set equal to flow)
usret(i,nd)	-	node numbers with returns immediately upstream of current node
vole(nez,mominsl)	-	last year's groundwater storage during same month
vol*	-	initial groundwater storage in designated layer '**'
vol*f	-	final values of groundwater storage

Subroutine calls :

skipln(*,*)	-	skips a specified number of lines (usually 3)
date(rundate)	-	current date from internal clock
time(runtime)	-	current time from internal clock

Files read from:

elemdau	-	binary groundwater element - DAU conversion table
salt.con	-	control file for salt balance model
saltfil	-	salt input file name

saltgwm - initial concentrations for each element
saltlch - leachate rates for the groundwater model elements

Files written to:

gbinfil - salt binary output from SANTUCM groundwater model
outfil - output file name for salinity balance model
sbinfil - salt binary output from SANTUCM surface water model

Flowchart :

- o read surface and groundwater information from binary files
- o read initial TDS concentrations in reservoirs, inflows to nodes, gains and surface returns
- o if running conjunctive use model calculate TDS of pumped groundwater otherwise read it in from an external file
- o enter monthly loop
- o for flow nodes perform checks for multiple exports from a node and for Friant-Kern Canal exports to the Kings, Tule, Kaweah and Kern Rivers
- o calculate concentration of applied water to flow nodes based on concentrations of surface water diversions, project import water, upstream return flows and pumped groundwater
- o for flow nodes calculate salt leaching to the semiconfined aquifer based on surface applied water
- o for non-flow nodes calculate the TDS of diversions entering each DAU
- o for each DAU calculate the mass of salt reaching layer 1 and layer 2 of the regional aquifer (semi-confined and confined aquifers respectively)
- o write out an output file and salt budget of all TDS mass fluxes for each surface water node

3.0. Model status

An evaluation of the SANTUCM model was performed during 1991 and is reported in " Evaluation and Suggestions for Further Development of the San Joaquin - Tulare Conjunctive Use Model (SANTUCM) " by Tabios, Quinn, Shen and Zhao (March, 1992). In its current form the model has utility for a number of studies, specific to water supply and water quality issues, in the San Joaquin Valley. A summary table which describes these applications appears in Table 2. Limitations and suggested improvements to the existing model are given in the evaluation report.

Table 1. Use of SANTUCM for USBR Planning Studies

Studies	Features used	Level of confidence in SANTUCM results	Ease of performing studies : changes necessary to existing model	Other models that can be used instead of SANTUCM
1 Evaluation of SJVDP recommended plan : Components include land retirement, groundwater pumping and changes in on - farm irrigation and drainage practices	Groundwater model Salinity model	Low - moderate Evaluation of the SJVDP requires use of the linked surface - groundwater model. Numerical instabilities in the computation of gains / losses limit the utility of the model in scenarios which allow significant surface water - groundwater interaction. The salinity model cannot be used without calibration for planning studies. Moderate : The model is marginally superior to SANJASM for planning studies where surface - groundwater interactions may deviate from historic gains or losses. The nodal network has been extended into the Tulare basin in SANTUCM. Utility for planning purposes would be increased by improving the surface - groundwater linkage Moderate In the San Joaquin Basin results are compromised only by instabilities in the gain / loss computation. These may not be a significant proportion of flow during most months. In the Tulare Basin reservoir operating rules have not been codified - this limits the utility of the model for fish planning studies.	Most scenarios would require changes to existing datalines e.g for groundwater pumping, irrigation recharge and surface water returns. This is easy to perform. Scenarios that require assessment of water quality cannot be performed until the salinity model is calibrated. Projected runs require assumptions of future land use and a time series of rainfall and reservoir inflows. Most scenarios are simple to construct using existing model and would require modifications to existing data files. Any changes to the network could require substantial recoding. Scenarios can be built easily by modifying existing data files	WADE, CVGSM, USGS regional flow model(Belitz) USGS RASA model (Williamson) SANTUCM (groundwater model)
2 Water supply studies : e.g. Friant-Kern renewal of water supply contracts.	Surface water model Groundwater model	Moderate The model is marginally superior to SANJASM for planning studies where surface - groundwater interactions may deviate from historic gains or losses. The nodal network has been extended into the Tulare basin in SANTUCM. Utility for planning purposes would be increased by improving the surface - groundwater linkage Moderate In the San Joaquin Basin results are compromised only by instabilities in the gain / loss computation. These may not be a significant proportion of flow during most months. In the Tulare Basin reservoir operating rules have not been codified - this limits the utility of the model for fish planning studies.	Projected runs require assumptions of future land use and a time series of rainfall and reservoir inflows. Most scenarios are simple to construct using existing model and would require modifications to existing data files. Any changes to the network could require substantial recoding. Scenarios can be built easily by modifying existing data files	SANJASM * DWRSIM SANJASM is limited to the San Joaquin Basin and does not cover the Friant-Kern service area.
3 San Joaquin River fish studies	Surface Water Model Groundwater Model	Moderate In the San Joaquin Basin results are compromised only by instabilities in the gain / loss computation. These may not be a significant proportion of flow during most months. In the Tulare Basin reservoir operating rules have not been codified - this limits the utility of the model for fish planning studies.	Projected runs require assumptions of future land use and a time series of rainfall and reservoir inflows. Most scenarios are simple to construct using existing model and would require modifications to existing data files. Any changes to the network could require substantial recoding. Scenarios can be built easily by modifying existing data files	SANJASM DWRSIM
4 Water quality compliance studies TDS objectives at Vernalis , Se and B water quality objectives at Newman	Surface Water Model Groundwater Model Salinity Model	Low : The Flow - EC algorithm at Vernalis has not been validated for all river conditions . The SANTUCM salinity model currently uses dummy data and therefore cannot be used for planning studies.	Once the salinity database has been developed scenarios can be run readily. Code modifications may be necessary to separately account for salt loading from west-side ag lands. Regression relationships may be capable of relating EC levels to concentrations of dissolved constituents.	SJRIO 1 SJRIO II SANJASM (Vernalis only)
5 Reservoir re-operation and planning studies	Surface Water Model	Moderate to High In the San Joaquin basin where model operations have been translated into rules SANTUCM should perform as reliably as other models. If the groundwater model is to be used the results may be compromised by inherent instabilities in the linkage. The model is less useful in the Tulare basin because the logic for reservoir operations has not been developed.	Some code changing may be necessary depending on the proposed changes in reservoir operations. This may involve considerable changes in model coding. Operating rules need to be developed for Pine Flat, Terminus Success and Isabella reservoirs in the Tulare Basin.	SANJASM DWRSIM

4.0. References

- Boyle Engineering Corporation. 1991. Documentation and Users Manual for FEGW14 - A finite element groundwater flow (model).
- Boyle Engineering Corporation. 1991. San Joaquin-Tulare Conjunctive Use Model.
- Tabios, G.Q, N.W.T. Quinn, H.W. Shen and D.H. Zhao. 1992. Evaluation and suggestions for further development of the San Joaquin - Tulare Conjunctive Use Model (SANTUCM). Topical Report, UCB/LBL. March, 1992.

END

**DATE
FILMED**

12 / 8 / 92