ENGINEERING CHANGE NOTICE

1. ECN 613319

Page 1 of 2

Proj.
ECN

2. ECN Category (mark one) Supplemental ☐ Direct Revision ☒ Change ECN ☐ Temporary ☐ Standby ☐ Supersedeure ☐ Cancel/Void ☐	3. Originator's Name, Organization, MSIN, and Telephone No. GA Barnes/SED/H5-09 376-2241	3a. USR Required? ☐ Yes ☒ No	4. Date January 24, 1995
	5. Project Title/No./Work Order No. W71130/N3064	6. Bldg./Sys./Fac. No. NA	7. Approval Designator Q
	8. Document Numbers Changed by this ECN (includes sheet no. and rev.) WHC-SD-WM-ATP-077, REV 1	9. Related ECN No(s). NA	10. Related PO No. NA

11a. Modification Work ☐ Yes (fill out Blk. 11b) ☒ No (NA Blks. 11b, 11c, 11d)	11b. Work Package No. NA	11c. Modification Work Complete NA _____ Cog. Engineer Signature & Date	11d. Restored to Original Condition (Temp. or Standby ECN only) NA _____ Cog. Engineer Signature & Date
---	---------------------------------	--	--

12. Description of Change ETN-94-0036 - Replace Rev 1 of WHC-SD-WM-ATP-077, with Rev 2 (attached).

13a. Justification (mark one)			
Criteria Change ☐	Design Improvement ☒	Environmental ☐	Facility Deactivation ☐
As-Found ☐	Facility Const. ☐	Const. Error/Omission ☐	Design Error/Omission ☐

13b. Justification Details This ATP is being revised to clarify confusing steps and to allow Maintenance personnel to perform the tests.

14. Distribution (include name, MSIN, and no. of copies) GA Barnes H5-09 AK Sharma H5-60 JH Huber R1-49 Central Files L8-04 FM Jones L7-06	RELEASE STAMP OFFICIAL RELEASE (21) BY WAC DATE JAN 30 1995 25-21
---	---

MASTER

ENGINEERING CHANGE NOTICE				Page 2 of 2	1. ECN (use no. from pg. 1) 613319																			
15. Design Verification Required ☒ Yes ☐ No	16. Cost Impact <table style="width: 100%; border: none;"> <tr> <th colspan="2" style="text-align: center;">ENGINEERING</th> <th colspan="2" style="text-align: center;">CONSTRUCTION</th> </tr> <tr> <td style="width: 30%;">Additional</td> <td style="width: 10%; text-align: center;">☐</td> <td style="width: 30%;">Additional</td> <td style="width: 10%; text-align: center;">☐</td> </tr> <tr> <td></td> <td style="text-align: center;">\$</td> <td></td> <td style="text-align: center;">\$</td> </tr> <tr> <td>Savings</td> <td style="text-align: center;">☐</td> <td>Savings</td> <td style="text-align: center;">☐</td> </tr> <tr> <td></td> <td style="text-align: center;">\$NA</td> <td></td> <td style="text-align: center;">\$NA</td> </tr> </table>			ENGINEERING		CONSTRUCTION		Additional	☐	Additional	☐		\$		\$	Savings	☐	Savings	☐		\$NA		\$NA	17. Schedule Impact (days) Improvement ☐ Delay ☐ NA
ENGINEERING		CONSTRUCTION																						
Additional	☐	Additional	☐																					
	\$		\$																					
Savings	☐	Savings	☐																					
	\$NA		\$NA																					
18. Change Impact Review: Indicate the related documents (other than the engineering documents identified on Side 1) that will be affected by the change described in Block 12. Enter the affected document number in Block 19.																								
SDD/DD ☐ Functional Design Criteria ☐ Operating Specification ☐ Criticality Specification ☐ Conceptual Design Report ☐ Equipment Spec. ☐ Const. Spec. ☐ Procurement Spec. ☐ Vendor Information ☐ OM Manual ☐ FSAR/SAR ☐ Safety Equipment List ☐ Radiation Work Permit ☐ Environmental Impact Statement ☐ Environmental Report ☐ Environmental Permit ☐	Seismic/Stress Analysis ☐ Stress/Design Report ☐ Interface Control Drawing ☐ Calibration Procedure ☐ Installation Procedure ☐ Maintenance Procedure ☐ Engineering Procedure ☐ Operating Instruction ☐ Operating Procedure ☐ Operational Safety Requirement ☐ IEFD Drawing ☐ Cell Arrangement Drawing ☐ Essential Material Specification ☐ Fac. Proc. Samp. Schedule ☐ Inspection Plan ☐ Inventory Adjustment Request ☐	Tank Calibration Manual ☐ Health Physics Procedure ☐ Spares Multiple Unit Listing ☐ Test Procedures/Specification ☐ Component Index ☐ ASME Coded Item ☐ Human Factor Consideration ☐ Computer Software ☐ Electric Circuit Schedule ☐ ICRS Procedure ☐ Process Control Manual/Plan ☐ Process Flow Chart ☐ Purchase Requisition ☐ Tickler File ☐																						
19. Other Affected Documents: (NOTE: Documents listed below will not be revised by this ECN.) Signatures below indicate that the signing organization has been notified of other affected documents listed below.																								
<table style="width: 100%; border: none;"> <tr> <td style="width: 33%;">Document Number/Revision</td> <td style="width: 33%;">Document Number/Revision</td> <td style="width: 33%;">Document Number/Revision</td> </tr> <tr> <td>NA</td> <td></td> <td></td> </tr> </table>						Document Number/Revision	Document Number/Revision	Document Number/Revision	NA															
Document Number/Revision	Document Number/Revision	Document Number/Revision																						
NA																								
20. Approvals																								
Signature		Date		Signature		Date																		
<u>OPERATIONS AND ENGINEERING</u>				<u>ARCHITECT-ENGINEER</u>																				
Cog. Eng. GA Barnes		<i>[Signature]</i>		PE		_____																		
Cog. Mgr. TL Moore		<i>[Signature]</i> FOR TLM		QA		_____																		
QA AK Sharma		<i>AK Sharma</i>		Safety		_____																		
Safety		_____		Design		_____																		
Environ.		_____		Environ.		_____																		
Other Information Review		_____		Other		_____																		
JH Huber		<i>JCHB PER TELECOM</i>		_____		_____																		
_____		_____		_____		_____																		
_____		_____		_____		_____																		
_____		_____		_____		_____																		
				<u>DEPARTMENT OF ENERGY</u>																				
				Signature or a Control Number that tracks the Approval Signature																				

				<u>ADDITIONAL</u>																				

DISCLAIMER

Portions of this document may be illegible in electronic image products. Images are produced from the best available original document.

RELEASE AUTHORIZATION

Document Number: WHC-SD-WM-ATP-077, Rev. 2

Document Title: ENRAF SERIES 854 ADVANCED TECHNOLOGY GAUGE (ATG)
ACCEPTANCE TEST PROCEDURE

Release Date: 1/24/95

**This document was reviewed following the
procedures described in WHC-CM-3-4 and is:**

APPROVED FOR PUBLIC RELEASE

WHC Information Release Administration Specialist:

V.L. Birkland

1/24/95

TRADEMARK DISCLAIMER. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof or its contractors or subcontractors.

This report has been reproduced from the best available copy. Available in paper copy and microfiche. Printed in the United States of America. Available to the U.S. Department of Energy and its contractors from:

U.S. Department of Energy
Office of Scientific and Technical Information (OSTI)
P.O. Box 62
Oak Ridge, TN 37831
Telephone: (615) 576-8401

Available to the public from: U.S. Department of Commerce
National Technical Information Service (NTIS)
5285 Port Royal Road
Springfield, VA 22161
Telephone: (703) 487-4650

SUPPORTING DOCUMENT		1. Total Pages ^{KN} 26
2. Title ENRAF SERIES 854 ADVANCED TECHNOLOGY GAUGE (ATG) ACCEPTANCE TEST PROCEDURE	3. Number WHC-SD-WM-ATP-077	4. Rev No. 2
5. Key Words ENRAF, ATG, Series 854	6. Author Name: GA Barnes Signature: <i>[Signature]</i> Organization/Charge Code 71130/N3064	
7. Abstract This Acceptance Test Procedure was written to test the ENRAF series 854 ATG prior to installation in the Tank Farms. The procedure sets various parameters and verifies that the gauge is functional.		
8. RELEASE STAMP <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> OFFICIAL RELEASE (21) BY WHC DATE JAN 30 1995 <i>[Signature]</i> 21 </div>		

WHC-SD-WM-ATP-077
REV 2

ENRAF SERIES 854 ADVANCED TECHNOLOGY GAUGE (ATG)
ACCEPTANCE TEST PROCEDURE

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

MASTER

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

21

TABLE OF CONTENTS

1.0 INSTRUCTIONS	2
1.1 PURPOSE	2
1.2 SCOPE	2
1.3 REFERENCES	2
1.4 RESPONSIBILITIES	2
1.5 DESCRIPTION OF THE SYSTEM	3
1.6 TEST CONDITIONS AND EQUIPMENT REQUIRED	3
2.0 TEST EXECUTION SECTION	4
2.1 INITIALIZING THE GAUGE	5
2.2 TESTING THE DISPLAY	5
2.3 CHECKING FOR ERROR CODES	6
2.4 TESTING THE LEVEL GAUGE OPERABILITY	7
2.7 ANALOG OUTPUT CARD CALIBRATION AND TESTING	11
2.8 TRANSPORTING THE LEVEL GAUGE	14
3.0 EXCEPTIONS TO ACCEPTANCE TEST	14
4.0 TEST DATA MANAGEMENT	15
4.1 ACCEPTANCE TEST REPORT GUIDANCE	15
TEST EXECUTION DATA SHEET	16
EXCEPTIONS DATA SHEET	17
APPENDIX A	A-1
APPENDIX B	B-1
APPENDIX C	C-1

ENRAF SERIES 854 ADVANCED TECHNOLOGY GAUGE (ATG)
ACCEPTANCE TEST PROCEDURE

1.0 INSTRUCTIONS

1.1 PURPOSE

This procedure checks that the shipment of the gauge to Hanford did not cause a failure. This procedure does not certify the gauge operation; that is done by the manufacturer.

1.2 SCOPE

This procedure provides acceptance testing for Enraf Series 854 level gauges used to monitor levels in Hanford Waste Storage Tanks. The test will verify that the gauge functions according to the manufacturer's instructions and specifications and is properly setup prior to being delivered to the tank farm area.

1.3 REFERENCES

- Instruction Manual Series 854 ATG Level Gauge, Enraf Inc., Part No. 4416.220, Version 2.2 (See CV-31560, vendor information file).
- Installation & Set-Up Manual MPU Analog Output 4-20 ma, Enraf Inc., Part No. 4416.222, Version 2.0 (See CV-31560, vendor information file).

1.4 RESPONSIBILITIES

- 1.4.1 The Person In Charge (PIC) is responsible for coordinating the level gauge testing.
- 1.4.2 Maintenance (Instrument Craft) is responsible for performing the testing and recording the test results.
- 1.4.3 Quality Assurance is responsible for witnessing the tests, signing the data sheets when testing is completed and placing a "green tag" on the gauge after successful completion of the test. The "green tag" will identify the tank number that the gauge was setup for.

1.5 DESCRIPTION OF THE SYSTEM

Enraf-Nonius Series 854 level gauges are certified by Factory Mutual (FM) for National Fire Protectional Association (NFPA 70) hazardous Class I, Division 1, Groups B, C, and D Locations. Its measuring principle is based on the detection of variations in the weight of a displacer suspended in the process fluid. The displacer is connected to a wire wound on a precision measuring drum. A level change causes a change in the weight of the displacer which will be detected by the force transducer. Electronics within the gauge cause a servo motor to adjust the position of the displacer and compute the tank level based on the new position of the displacer drum. The gauge displays the level in decimal inches. An analog output signal transmits the level data for remote data processing.

1.6 TEST CONDITIONS AND EQUIPMENT REQUIRED

The equipment listed below is required to perform this procedure.

- Portable Enraf Terminal (PET) Model No. 847
- Digital Volt Meter (DVM) with a current accuracy less than 10 μ A.
- Enraf Test Weights (Enraf PN 1854-061)
- 15-24 Vdc power supply.
- Reamer (Enraf PN 4563.030) or #31 drill
- Enraf Extraction Tool (optional)

2.0 TEST EXECUTION SECTION

NOTE:

The commands typed on the PET or computer are shown in square brackets "[]" (The square brackets are NOT to be typed as part of the command). Included is any additional information the command requires. After typing the text within the square brackets, press the ENTER key. If an error is made during the typing of the command, use the backspace (BS) key to delete the error.

After entering a command, the PET or computer will give one of two responses: The first response will show the entered command with an "&" character at the end (i.e. "TG&"). This response tells the user that the gauge accepted the command. The second response will show the two digit command (i.e. TG) followed by a "!" and a three digit error code (i.e. "TG!053"). This command tells the user that the gauge did not accept the command. For a list of error codes, see the Enraf 854 ATG Level Gauge Instruction Manual, section 12.4.

PROCEDURE NOTE

In the following steps, if values are requested, the values shall be recorded in the Test Execution Data Sheet for the appropriate step number in the Value column. If verification is requested, write accept in the accept/reject column in the Test Execution Data Sheet for the appropriate step number.

If an error occurs in any step, an exception will be entered in the Exceptions Data Sheet listing the step where the error occurred, and a general description of the error. Corrective actions shall be in accordance with section 3.0.

2.1 INITIALIZING THE GAUGE

INFORMATION

This section prepares the gauge for testing. It connects power and unlocks the servo motor.

- 2.1.1 Mount the gauge per the 854 ATG Level gauge Instruction Manual. Provide electrical connections to the gauge per the 854 ATG Level Gauge Instruction Manual, the National Fire Protection Association (NFPA 70) and the National Electrical Code.
- 2.1.2 Install the drum and displacer per the Enraf Series 854 ATG Level Gauge Instruction Manual, Section 8.4.
- 2.1.3 Unlock the servo motor prior to connecting power per the 854 ATG Level Gauge Instruction Manual, Section 8.5.
- 2.1.4 Connect the PET to the optical port located on the side of the gauge housing or connect a computer to the gauge using the RS-232C pigtail, PET and bi-phase mark connector (see appendix A for connection instructions).
- 2.1.5 Connect the gauge to a 120 Vac (+/- 5 Vac) power source, per the 854 ATG Level Gauge Instruction Manual, Section 4.3.1. The display screen on the gauge will show one dark line. After approximately 20 seconds, the display will show the gauge initializing.
- 2.1.6 If the gauge is not setup to measure level in inches, reconfigure the gauge per appendix A (changing level dimensions).

2.2 TESTING THE DISPLAY

INFORMATION

This section tests the ability of the gauge to change from the Level Display to the Analog Display. The Analog Display will only be used for diagnostics during gauge operation.

- 2.2.1 Enter Command [W1=ENRAF1]. This command enters protection level 1.

- 2.2.2 Enter Command [DF=J]. This command enters the analog display format J.
- 2.2.3 Enter Command [EX]. This command exits protection level 1.
- 2.2.4 Verify that the analog display screen (format J) is displayed after gauge initialization (See fig 7.9 in the Enraf Series 854 ATG Level Gauge Instruction manual). Record verification in the Data Sheet.
- 2.2.5 Enter Command [W1=ENRAF1].
- 2.2.6 Enter Command [DF=B]. This command enters the level display, format B.
- 2.2.7 Enter Command [EX].
- 2.2.8 Verify that the level display (format B) screen is displayed after gauge initialization (See fig 7.3 in the Enraf Series 854 ATG Level Gauge Instruction manual). Record verification in the Data Sheet.

2.3 CHECKING FOR ERROR CODES

INFORMATION

Record any errors on the data sheet. Correct the errors, or enter it as an exception. For a list of error codes, see the Enraf 854 ATG Level Gauge Instruction Manual.

- 2.3.1 Enter Command [EP] = "XPU error code". Verify that EP000 is displayed. Record verification in the data sheet.
- 2.3.2 Enter Command [ES] = "SPU error code". Verify that ES0000 is displayed. Record verification in the data sheet.

2.4 TESTING THE LEVEL GAUGE OPERABILITY

INFORMATION

This section enters data into the memory of the level gauge.
These values tailor the gauge for the specific tank.

- 2.4.1 Enter Command [UN]. This command unlocks the gauge and allows the displacer to move downward to the floor or other hard surface.

NOTE:

If the displacer does not move downward, check to make sure that the drum moves freely on the bearings. If the drum does not move freely, perform the drum bearing removal/reconditioning procedure in Appendix B. If the drum does move freely, re-calibrate the force transducer using the procedure in Appendix C. After drum bearing reconditioning or force transducer re-calibration, perform step 2.4.1 again. Document the drum bearing reconditioning or force transducer re-calibration as an exception.

- 2.4.2 Enter Command [W2=ENRAF2]. This command enters protection level 2.
- 2.4.3 Enter Command [TI=.aaaaa]. This command enters the tank identifier. Verify proper parameter entry and record the verification in the Data Sheet.

NOTE:

The tank identifier is shown as ".aaaaa" and is the tank number that the gauge is being setup for (See the work package to determine tank number). The a's stand for characters.

For Tanks with only one letter, the identifier is "..aaaa"

example: C-103 would be "..C103"

For Tanks with two letters, the identifier is ".aaaaa" example:
AW-101 would be ".AW101"

2.4.4 Enter the following parameters into the gauge (Verify proper parameter entry and record the verification in the Data Sheet):

- [TT=+00900.00] ("TANK TOP" parameter)
- [UR=+00900.00] ("UPPER REFERENCE" parameter)
- [MH=+00890.00] ("MOTOR HIGH" parameter)
- [MZ=+00880.00] ("LOCK TEST LIMIT" parameter)
- [HH=+00870.00] ("HIGH HIGH ALARM" parameter)
- [HA=+00860.00] ("HIGH ALARM" parameter)
- [LA=+00006.00] ("LOW ALARM" parameter)
- [LL=+00003.00] ("LOW LOW ALARM" parameter)
- [ML=+00001.00] ("MOTOR LIMIT SWITCH LOW" parameter)

2.4.5 Enter parameter [RL=+xxxxx.xx] This command enters the "REFERENCE LEVEL" parameter. See the work package (ECN against drawing H-2-817634) for the RL value. Verify proper parameter entry and record the value in the Data Sheet.

NOTE:

Enter five digit decimal number (xxx.xx) as [+xxxxx.xx].

Example: For RL = 580.70, enter [RL=+00580.70]

2.4.6 Enter command [AR]. This command directs the gauge to accept the current value for "RL".

2.4.7 Enter command [EX].

NOTE:

Prior to executing step 2.4.8, verify that the opening to the gauge flange is blocked so that the displacer cannot be raised up into the drum housing.

- 2.4.8 Enter Command [CA]. This command raises the displacer. Verify that the displacer raises up to the gauge flange and stops. Record the verification in the data sheet.
- 2.4.9 Enter Command [UN].
- 2.4.10 After the gauge stabilizes, verify that the level reading in the gauge LCD display is reading within 0.10 inches of the RL value programmed in step 2.4.5. Record the verification in the data sheet.
- 2.4.11 Enter command [TG]. This commands tests the gauge.
- 2.4.12 Verify that the displacer rises a couple of inches and then goes back down to the RL. Record the verification in the data sheet.

2.5 DRUM CIRCUMFERENCE VERIFICATION

- 2.5.1 Enter Command [DC]. This command displays the preprogrammed drum circumference.
- 2.5.2 Verify that the drum circumference value displayed (DC) is the same as the value for the Drum circumference found engraved on the wire drum. Record the value in the data sheet. If the Drum Circumference value engraved on the wire drum does not exactly match the preprogrammed Drum Circumference (DC) value, perform steps 2.5.3 through 2.5.5, otherwise go to step 2.6

NOTE:

This value is displayed in scientific notation.

The value will look like "DC=+.33000000E+00".

- 2.5.3 Enter Command [W2=ENRAF2].

2.5.4 Enter Command [DC=+.XXXXXXXXXE+00]. The value for XXXXXXXX is the Drum Circumference value engraved on the wire drum. Record the value in the data sheet.

2.5.5 Enter command [EX].

2.6 DISPLACER WEIGHT VERIFICATION

2.6.1 Enter command [CA].

2.6.2 After the displacer rises a few inches, enter command [FR]. This command stops the displacer.

2.6.3 Enter command [MF]. This command measures the motor frequency.

2.6.4 After "FR" appears in the gauge's LCD display, PET display or computer display, enter command [WQ]. This command measures the weight of the displacer. Record the WQ value in the data sheet.

NOTE:

This value is displayed in scientific notation.

The value will look like "WQ=+.22300000E+03".

2.6.5 Verify that the WQ value is within 3 grams of the weight engraved on the displacer. Record the verification in the data sheet.

NOTE:

If the value for WQ is not within 3 grams (.00300000E+03) of the weight engraved on the displacer, calibrate the force transducer per the force transducer calibration procedure found in Appendix C. Document this calibration as an exception. After force transducer calibration, perform step 2.6.5 again.

2.7 ANALOG OUTPUT CARD CALIBRATION AND TESTING

2.7.1 Disconnect the gauge from the power source. Use a Personal Locking Device (PLD) to lock out the power.

2.7.2 Remove Terminal Compartment Cover

NOTE:

If using a fluke 87, hold down the yellow key and rotate the selector over to the mA scale. This will give an accuracy of $\pm 1 \mu\text{A}$.

2.7.3 Connect the 15-24 Vdc power supply and the DVM to terminals 1 and 2 (brown terminal strip) in the terminal compartment (see Fig. 2). Adjust the power supply so that the output is 16 ± 1 Vdc.

2.7.4 Re-install the Terminal Compartment Cover.

2.7.5 Remove the PLD and re-connect the gauge to the power source.

2.7.6 Enter Command [W2=ENRAF2].

2.7.7 Enter Command [A5]. A current of approximately 4mA will flow in the output circuit. Record the A5 value obtained from the DVM in the Data Sheet.

2.7.8 Enter the exact A5 value obtained from the DVM into A3.
Example: An A5 current of 4.021mA must be entered as [A3=+.40210000E+01].

2.7.9 Enter Command [A6]. A current of approximately 18mA will flow in the output circuit. Record the A6 value obtained from the DVM in the Data sheet.

2.7.10 Enter the exact A6 value obtained from the DVM into A4.
Example: An A6 current of 17.996 mA must be entered as [A4=+.179960000E+02].

2.7.11 Enter Command [AK=0]. Setting AK=0 will allow a current to be entered manually via. the PET or computer.

2.7.12 Enter Command [EX].

2.7.13 Enter Command [AF=+.40000000E+01]. This command will generate a 4.000 mA current in the output circuit. Verify that the

Figure 1

- 2.7.13 Enter Command [AF=+.40000000E+01]. This command will generate a 4.000 mA current in the output circuit. Verify that the DVM reading is 4.000 +/- .012 mA. Repeat this step for the following currents:

8.000 mA
12.000 mA
16.000 mA
20.000 mA.

Record the DVM readings and verifications in the data sheet.

- 2.7.14 Enter Command [W2=ENRAF2].

- 2.7.15 Enter Command [AK=A]. This command places the analog output device back in normal mode.

INFORMATION

The values set into AM and AN (4 and 20 milliamp level values respectively) adjust the analog output for the gauge. The default values set by this procedure are approximately 25 inches below (4 ma) and 25 inches above (20 ma) the existing waste level.

- 2.7.16 Enter parameter [AM=+xxxxx.xx]. This command enters the level setting which corresponds to the 4 mA output current. The AM parameter should be set to approximately 25" below the current waste level. Contact the Surveillance Office at 373-1945 for the current waste level. Record the current waste level and the AM value entered in the Data Sheet.
- 2.7.17 Enter parameter [AN=+xxxxx.xx]. This command enters the level setting which corresponds to the 20 mA output current. The AN parameter should be set to approximately 25" above the current waste level. Record the AN value entered in the Data Sheet.
- 2.7.18 Enter Command [EX].

2.8 TRANSPORTING THE LEVEL GAUGE

CAUTION

This section prepares the gauge for transport. The motor must be locked to prevent possible damage to the force transducer.

- 2.8.1 If using a computer for the testing, log the gauge data onto the computer (see Appendix A).
- 2.8.2 Disconnect the gauge from the power source.
- 2.8.3 Disconnect the 15-24 Vdc power supply and the DVM that is connected to terminals 1 and 2 (brown terminal strip) in the terminal compartment (see Fig. 1).
- 2.8.4 "Lock" the servo motor, per the 854 ATG Level Gauge Instruction Manual, Section 8.5, prior to transporting the gauge.
- 2.8.5 Remove the drum and displacer, per the 854 ATG Level Gauge Instruction Manual, Section 8.4, prior to transporting the gauge.

2.9 DATA

- 2.9.1 Mail a copy of the completed data sheets, vender information, and hardcopy of the logfile to G. A. Barnes at MSIN H5-09 or J. H. Huber at R1-67.

3.0 EXCEPTIONS TO ACCEPTANCE TEST

Exceptions to the test are dispositioned and agreed to by all witnesses. Actions taken regarding disposition are noted on the "Exception to Acceptance Test" sheet. Typical dispositions are:

- Test approved with exception (i.e., rerun of the acceptance test unnecessary).
- Entire acceptance test to be repeated after the discrepancy has been corrected.
- ATP step(s) affected to be repeated after the discrepancy has been corrected.

4.0 TEST DATA MANAGEMENT

The test data shall be entered on the attached data sheets. Witness signatures at the bottom of the data sheet indicates that the witness agrees to the accuracy of the data recorded and comparisons made.

Upon successful completion of testing activities, the master copy of the DATA SHEETS will be signed by the Test Witnesses. An appropriate "Acceptance Test Report" shall be generated to publish the results of testing activities.

4.1 ACCEPTANCE TEST REPORT GUIDANCE

The data sheets which are completed during the testing activities will be included in the Acceptance Test Report. If additional gauges are tested using this procedure, the data sheets will be added to the ATR as a revision.

TEST EXECUTION DATA SHEET

Date: _____

Gauge serial number: _____ Tank Number: _____

Test Performed by: _____

Reference Sequence	Attribute	Accept/Reject	Value	Comment
2.2.4	DF=J			
2.2.8	DF=B			
2.3.1	EP			
2.3.2	ES			
2.4.3	TI			
2.4.4	PARAMETERS			
2.4.5	RL			
2.4.8	CA			
2.4.10	RL			
2.4.12	RL			
2.5.2	DC			
2.5.4	DC			
2.6.4	WQ			
2.6.5	WQ			
2.7.7	A5			
2.7.9	A6			
2.7.13	4.000 mA			
2.7.13	8.000 mA			
2.7.13	12.000 mA			
2.7.13	16.000 mA			
2.7.13	20.000 mA			
2.7.16	WASTE LEVEL			
2.7.16	AM			
2.7.17	AN			
2.8.4	MOTOR LOCK			

Test Witnesses:

PIC _____ Date _____

Quality Assurance _____ Date _____

Maintenance _____ Date _____

EXCEPTIONS DATA SHEET

Gauge Serial Number: _____

Paragraph No.	Description/Disposition
<p><u>TEST APPROVED - NO EXCEPTIONS:</u></p> <p>PIC _____ Date _____</p> <p>Quality Assurance _____ Date _____</p> <p>Maintenance _____ Date _____</p>	<p><u>TEST APPROVED - WITH EXCEPTIONS:</u></p> <p>PIC _____ Date _____</p> <p>Quality Assurance _____ Date _____</p> <p>Maintenance _____ Date _____</p>

ENRAF SERIES 854 ADVANCED TECHNOLOGY GAUGE (ATG)
ACCEPTANCE TEST PROCEDURE

APPENDIX A

COMPUTER SETUP:

1. Load the LOGGER program onto the computer.
2. Connect computer and PET to the gauge as shown in Figure A-1.
3. Place the PET in RS-232 mode and with a baudrate of 2400, per the PET Manual.
4. Start the LOGGER program (LOGV17.EXE).
5. Enter the "SETUP SYSTEM" menu.
6. Verify that the parameters shown in the "SETUP MENU" display matches the parameters shown below.

SETUP MENU

1) RS232C port & Baudrate	(part 1 @ 2400 Baud.)
2) Add header to every file	(N)
3) Ciu address	()
*4) Gauge Address	(XX)
5) Max. number of records in file LOGV17.CYC	(100)
6) Name cyclusfile	(LOGV17.CYC)
7) Max. number of retries per CIU request	(3)
8) Timeout CIU	(.9 sec.)
9) Turn around delay	(0 sec.)
A) ITEM directory	(C:\LOGGER\ITEMS\)
B) CYC file directory	(C:\LOGGER\CYC\)
C) LOG file directory	(C:\LOGGER\LOG\)
D) file to Field file directory	(C:\LOGGER\FTF\)
E) Library directory	(C:\LOGGER\LIB\)
F) RAM disk	(\)
G) Return to main menu	

*XX is obtained from gauge parameter [TA]

7. Return to the "MAIN MENU".
8. Enter "SEND ITEMS".

ENRAF SERIES 854 ADVANCED TECHNOLOGY GAUGE (ATG)
ACCEPTANCE TEST PROCEDURE

9. The computer should now be setup to operate the gauge.

CHANGING LEVEL DIMENSIONS:

1. From LOGGER'S "MAIN MENU", enter the "SPECIAL MENU".
2. Enter the "CHANGE DIMENSIONS" menu.
3. Enter the gauge's "TRANSMISSION ADDRESS" (TA).
4. Enter "1) LEVEL DIMENSION (XXXXXX)"
5. Enter "TO INCHES"
6. Return to the "MAIN MENU"
7. Return to "SEND ITEMS"

LOGGING GAUGE DATA ONTO COMPUTER:

1. From LOGGER'S "MAIN MENU", enter the "SPECIAL MENU".
2. Enter "1) GAUGE LOGGING TO DISK".
3. Enter the gauge's "TRANSMISSION ADDRESS" (TA).

ENRAF SERIES 854 ADVANCED TECHNOLOGY GAUGE (ATG)
ACCEPTANCE TEST PROCEDURE

Figure A-1

ENRAF SERIES 854 ADVANCED TECHNOLOGY GAUGE (ATG)
ACCEPTANCE TEST PROCEDURE

APPENDIX B

DRUM BEARING REMOVAL/RECONDITIONING

1. Disconnect the gauge from the power source. Use a PLD to lock out power.
2. "Lock" the servo motor, per the 854 ATG Level Gauge Instruction Manual, Section 8.5.
3. Remove the drum and displacer per the 854 ATG Level Gauge Instruction Manual, Section 8.4.
4. Remove the drum shaft bushing from the gauge per the 854 ATG Level Gauge Instruction Manual, Figure 9.3.
5. Remove the bearings (2 black disks on each end of the bushing) from the drum shaft bushing per the 854 ATG Level Gauge Instruction Manual, Figure 9.3.
6. Use the reamer or the #31 drill to ream out both bearings.
7. Reinstall the reconditioned drum bearings into the drum shaft bushing.
8. Reinstall the drum shaft bushing into the gauge.
9. Reinstall the drum and displacer, per the 854 ATG Level Gauge Instruction Manual, Section 8.4.
10. "Unlock" the servo motor, per the 854 ATG Level Gauge Instruction Manual, Section 8.5.
11. Connect the gauge to the power source.

ENRAF SERIES 854 ADVANCED TECHNOLOGY GAUGE (ATG)
ACCEPTANCE TEST PROCEDURE

APPENDIX C

FORCE TRANSDUCER CALIBRATION

1. Raise the displacer to approximately 6" below the gauge flange by entering command [CA]. To stop the displacer, enter command [FR].
2. Enter command [W2=ENRAF2].
3. Enter command [WT=DDD]. This command disables the "wire-rupure" protection.
4. Remove the displacer and the snap from the measuring wire.
5. Attached the 25 gram weight to the measuring wire loop. The 25 gram weight is the smallest of weights in the set and has two hooks.
6. Enter command [BT]. This command activates a BALANCE TEST. The BALANCE TEST will take approximately five minutes to complete.
7. After "FR" appears in the gauge's LCD display, PET display or computer display, enter command [BF]. This command will display the frequency measured during the BALANCE TEST. Record this frequency (F0) below:
F0=_____
8. Attach the 75 gram weight to the 25 gram weight. The 75 gram weight is the third smallest in the set. Note: If there is insufficient room for the test weights to move downward (approximately 12"), perform step 1 to raise the test weights.
9. Repeat steps 6 and 7. Record the frequency (F1) below:
F1=_____
10. Remove the 75 gram weight and attach the 150 gram weight to the 25 gram weight. The 150 gram weight is the second largest weight in the set. Note: If there is insufficient room for the test weights to move downward (approximately 12"), perform step 1 to raise the test weights.
11. Repeat steps 6 and 7. Record the frequency (F2) below:
F2=_____

WHC-SD-WM-ATP-077
REV 2

ENRAF SERIES 854 ADVANCED TECHNOLOGY GAUGE (ATG)
ACCEPTANCE TEST PROCEDURE

12. Remove the 150 gram weight and attach the 225 gram weight to the 25 gram weight. The 225 gram weight is the largest weight in the set. Note: If there is insufficient room for the test weights to move downward (approximately 12"), perform step 1 to raise the test weights.
13. Repeat steps 6 and 7. Record the frequency (F3) below:
F3=_____
14. Enter command [W2=ENRAF2].
15. Enter command [F0=+.XXXXXXXXXE+XX]. This command re-programs frequency 0. The value of F0 is the value obtained in step 7.
16. Repeat step 15 for frequencies F1, F2 and F3. The values for F1, F2 and F3 are the values obtained in steps 9, 11 and 13 respectively.
17. Enter command [WT=EDE]. This command enables the "wire-rupure" protection.
18. Enter command [EX].