ANL-92/34

ANL--92/34

DE93 006096

**ARGONNE NATIONAL LABORATORY
9700 South Cass Avenue
Argonne, Illinois 60439**

**COMMIX-1AR/P: A THREE-DIMENSIONAL TRANSIENT
SINGLE-PHASE COMPUTER PROGRAM
FOR THERMAL HYDRAULIC ANALYSIS
OF SINGLE AND MULTICOMPONENT SYSTEMS**

Volume 3: Programmer's Guide

by

P. L. Garner, R. N. Blomquist, and E. M. Gelbard

Reactor Analysis Division

September 1992

MASTER

EP

PREFACE

The documentation of the computer program COMMIX-1AR/P has been divided into four volumes, each addressing different aspects of the documentation process and written from different perspectives. A brief summary of the four volumes is as follows:

Volume 1: "Equations and Numerics" (ANL-90/45)

Presents the basic equations, assumptions, finite-difference techniques, and solution methods.

Volume 2: "User's Guide" (ANL-92/33)

A step-by-step description of how to use the program, including an input guide and a sample problem.

Volume 3: "Programmer's Guide" (ANL-92/34)

A description of each subroutine and variable, showing linkage among these and their relation to the equations and variables presented in Volume 1.

Volume 4: "Verification and Validation"

A collection of representative problems run on this computer program and a comparison of the results obtained to those from theory, experiments, and other computer programs.

The normal user will primarily use the information in Volumes 1, 2, and 4 and will be using a controlled configuration of the program. Volume 3 is designed as a consolidated source of reference material for those involved in the program development effort.

TABLE OF CONTENTS

Page

ABSTRACT	vii
EXECUTIVE SUMMARY	viii
1. INTRODUCTION	1-1
2. OVERVIEW	2-1
2.1 General Considerations	2-1
2.2 Variables	2-3
2.3 Program Organization	2-6
3. FILES	3-1
3.1 Card-Image Input File	3-1
3.2 Printable Output File	3-6
3.3 Restart File	3-7
3.4 Plot File	3-11
3.5 GRPH File	3-14
4. GLOBAL VARIABLES	4-1
4.1 COMMON BLOCK /I4VAR/	4-2
4.2 COMMON BLOCK /R4VAR/	4-17
4.3 COMMON BLOCK /I4ARY/	4-31
4.4 COMMON BLOCK /R4ARY/	4-37
4.5 COMMON BLOCK /R8ARY/	4-48
4.6 COMMON BLOCK /ADDCON/	4-50
4.7 COMMON BLOCK /SPACE/	4-54
4.8 COMMON BLOCK /MACHIN/	4-99
4.9 COMMON BLOCK /REBALS/	4-100
4.10 COMMON BLOCK /IMPL/	4-102
4.11 COMMON BLOCK /CSCAN/	4-102
4.12 COMMON BLOCK /TIMING/	4-103
4.13 COMMON BLOCK /TEMPRY/	4-106
4.14 COMMON BLOCK /ARINC/	4-107
4.15 COMMON BLOCK /ARINI/	4-108
4.16 COMMON BLOCK /INDLIM/	4-109
4.17 COMMON BLOCK /CCORR/	4-111
4.18 COMMON BLOCK /CHEATC/	4-112
4.19 COMMON BLOCK /CPUMP/	4-114
4.20 COMMON BLOCK /CR/	4-121
4.21 Index of Global Variables	4-122

TABLE OF CONTENTS (Cont'd)

	Page
5. DESCRIPTION OF ROUTINES	5-1
ACKNOWLEDGMENTS	Ref-1
REFERENCES	Ref-2

LIST OF TABLES

	Page
2.1 Code Modules Referenced by "-INC" LIBRARIAN Directives	2-2
2.2 CONVTCD Keywords Used to Identify Source Code Type	2-3
2.3 Subprogram Calling Order	2-7
3.1 Ordering of Blocks in the Card-Image Input File	3-2

**COMMIX-1AR/P: A THREE-DIMENSIONAL TRANSIENT
SINGLE-PHASE COMPUTER PROGRAM
FOR THERMAL HYDRAULIC ANALYSIS
OF SINGLE AND MULTICOMPONENT SYSTEMS**

Volume 3: Programmer's Guide

by

P. L. Garner, R. N. Blomquist, E. M. Gelbard

ABSTRACT

The COMMIX-1AR/P computer program is designed for analyzing the steady-state and transient aspects of single-phase fluid flow and heat transfer in three spatial dimensions. This version is an extension of the modeling in COMMIX-1A to include multiple fluids in physically separate regions of the computational domain, modeling descriptions for pumps, radiation heat transfer between surfaces of the solids which are embedded in or surround the fluid, a $k-\epsilon$ model for fluid turbulence, and improved numerical techniques. The porous-medium formulation in COMMIX allows the program to be applied to a wide range of problems involving both simple and complex geometrical arrangements. The internal aspects of the COMMIX-1AR/P program are presented, covering descriptions of subprograms, variables, and files.

EXECUTIVE SUMMARY

The COMMIX (COMponent MIXing) computer programs are designed for analyzing steady-state and transient aspects of fluid flow and heat transfer in three spatial dimensions. Program versions in this series having a "1" in the suffix are for single-phase fluids having limited compressibility.

The COMMIX-1AR/P version is an extension of the COMMIX-1A version to include:

- allowance for multiple fluids in physically separate regions,
- radiation heat transfer between surfaces of solids embedded in or surrounding the fluid,
- a k - ϵ model for fluid turbulence, and
- improved numerical methods.

Numerous second-order changes have been implemented to increase the user's flexibility in specifying boundary conditions and material properties and in utilizing a wide range of modern mainframe computers.

The three-dimensional modeling in COMMIX is achieved using a porous-medium formulation. This has been implemented using the concepts of volume porosity (the fraction of a control volume occupied by fluid), directional surface porosity (the fraction of a control volume surface through which fluid may flow), distributed resistances to fluid flow, and distributed heat sources. Either Cartesian or cylindrical coordinates may be used. The fluid conservation equations for mass, momentum, and energy and the transport equations for the turbulence parameters are put into finite-difference form by averaging over the local control volumes in the system. This process allows simulations of simple problem geometries (e.g. straight pipe) and complex problem geometries (e.g. fuel bundle, heat exchanger, reactor vessel). Although primarily developed for nuclear reactor applications, the models in COMMIX are sufficiently general to be used for analyzing other engineering systems.

The material properties for the fluids and embedded solids, heat transfer coefficients, and friction factors are assumed to have various basic forms to which the user supplies coefficients. In some cases, the user may supply the coding to override these basic forms. Detailed fluid property packages are included for liquid sodium, liquid water (both normal and heavy), and helium gas, as well as a library of friction factors for specific applications.

The discretized conservation equations are solved as an initial-value problem in time and a boundary-value problem in space. The user is provided with a broad range of boundary condition choices, allowing the simulation of the usual types of boundary conditions encountered in real systems. The boundary conditions and embedded heat sources may be functions of time. The formulation of the conservation equations is implicit in time.

Previous reports presented (1) the modeling features (covering the basic equations and underlying assumptions) and the numerical methods (covering spatial differencing, implicitness of temporal differencing, and iterative solution methods) and (2) how to use the computer program (covering input preparation and program execution). Given this background, the present report concentrates on explaining the internal aspects of the computer program, covering subprogram descriptions, variable definitions, and file structures. An additional report provides assessments of the modeling.

1. INTRODUCTION

The COMMIX-1AR/P computer program is intended for steady-state and transient analysis of fluid flow and heat transfer in three dimensions. Although primarily developed for nuclear reactor applications, the COMMIX-1AR/P computer program can be used to analyze the fluid behavior in other engineering systems.

Previous reports (Refs. 1 and 2) described the features of COMMIX-1AR/P (including the specific equations being solved in each area of the modeling) and how to use the program (covering input preparation and execution). The person using this report is assumed to have read these prior reports and have them available as reference sources.

The present report focusses on the internal workings of the COMMIX-1AR/P computer program. Section 2 provides an overview of the coding, covering many basic items such as programming language, allowances made for various machine types, and source code structure. The other three sections provide specific details on the files (Sec. 3), global variables (Sec. 4), and subprogram units (Sec. 5). With the exception of Sec. 3.5 (which discusses the file used to pass information from program TDSC to program GRPH), the information in this report is specifically for the COMMIX-1AR/P computer program; similar descriptions for the four graphics postprocessor computer programs (i.e. VECT, TEMP, TDSC, and GRPH) will be provided in a future edition of this report.

Those who have worked with the coding in COMMIX-1 (Ref. 3), COMMIX-1A (Refs. 4 and 5), or COMMIX-1B (Refs. 6 and 7) should have little difficulty understanding the coding in COMMIX-1AR/P -- much of the program structure and many of the variable names are essentially unchanged from these prior program versions. In most cases, new coding and variables have been added to supplement, rather than replace, existing coding.

2. OVERVIEW

2.1 General Considerations

The COMMIX-1AR/P program is a continuation of the development of the COMMIX code series that began with COMMIX-1 (Ref. 3). The present program has been developed by making changes to a 1985 version of COMMIX-1A (Ref. 4 and 5), which was the successor program to COMMIX-1. During this development, new models and calculational techniques have been added (e.g. conjugate-gradient technique for solving the pressure equation system, capability for multiple fluids, and automatic time step control). The basic program structure and data storage techniques are unchanged from COMMIX-1A.

The COMMIX-1AR/P program package is written in ANSI standard FORTRAN-77 (Ref. 8) with one exception: the NAMELIST construct is used for portions of the card-image input file; the NAMELIST extension to the ANSI standard is available within FORTRAN compilers on many computers. The conformance to the standard in other respects allows the program to be used on a wide range of computers.

The source code is maintained on the IBM-3084 mainframe computer at Argonne National Laboratory (ANL) as a single partitioned dataset using the LIBRARIAN program (Ref. 9). A batch job is run when making permanent updates to the code, allowing the modification history to be preserved. Sections of coding which are used in more than one routine (e.g. COMMON BLOCKs and statement functions) are maintained as separate modules by LIBRARIAN and referenced by a "-INC module" LIBRARIAN directive in the appropriate routines; LIBRARIAN inserts these code sections in the proper places when writing out the source code for compilation. The code modules used in this manner are shown in Table 2.1. Routines are grouped together by category and stored as a module within LIBRARIAN (e.g. all routines associated with thermal structures (except TSCAN) are stored as module THRMSTRC); a cross-reference listing showing which modules contain which routines is maintained in module INDEX.

Table 2.1 Code Modules Referenced by "-INC" LIBRARIAN Directives

MODULE NAME	DESCRIPTION
ADDCON	COMMON BLOCK /ADDCON/
ARIN	COMMON BLOCKs /ARINC/ and /ARINI/
CCORR	COMMON BLOCK /CCORR/
CHEATC	COMMON BLOCK /CHEATC/
CPUMP	COMMON BLOCK /CPUMP/
HTXPROP	-not currently used- (replaced by SIMPROP)
NAMelist	NAMelistS GEOM, DATA, and INPUTQ
SHARED	COMMON BLOCKs /I4VAR/, /R4VAR/, /I4ARY/, /R4ARY/, and /R8ARY/
SIMPROP	Statement functions for fluid properties (FCOND, FENTH, FDENSE, FTEMP, FVISC, and GDENSE)

In spite of the program being written in standard FORTRAN, there are places where allowances must be made for differences between computers. The two primary examples of this are (1) whether the machine has a short (e.g. IBM and DEC/VAX) or a long (e.g. Cray and CDC) word length and (2) whether the machine has vector hardware. This is accomplished by having the appropriate coding for each machine type within the same source code file bracketed by flag records. These flag records are of the form "Cxxx" (optionally followed by a "-"), where the "C" is in position 1 of the record (so they look like COMMENT statements to the FORTRAN compiler); the source code is then passed through an ANL-written (Ref. 10) preprocessor program, CONVTCd, to select which coding sections to use when preparing source code for a specific computer. An input directive to CONVTCd specifies the keywords corresponding to the types of coding sections to be activated; CONVTCd (1) changes position 1 to a blank on the records which are bracketed by (a) the specified keywords or (b) the unspecified keywords followed by a "-" and (2) changes position 1 to the character "C" on the records which are bracketed by (a) all unspecified keywords or (b) the specified keywords followed by a "-". (Thus, coding sections bracketed by "Cxxx" and "Cxxx-" are mutually exclusive.) The keywords used in COMMIX-1AR/P in this manner are shown in Table 2.2. (The use of keywords CF66 and CF77 to distinguish between FORTRAN-66 and FORTRAN-77

Table 2.2 CONVTCD Keywords Used to Identify Source Code Type

KEYWORD	CODING TYPE IDENTIFIED
CANL	ANL computers
CF66	FORTRAN-66
CF77	FORTRAN-77
CIBM	IBM computers
CLW	Computers having a long word length
CRAY	Cray computers
CRS6	IBM RS6000 Computers
CSUN	Sun Computers
CSW	Computers having a short word length
CVEC	Computers having vector hardware
CVMS	DEC/VAX computers

coding is being phased out; backward compatibility to FORTRAN-66 is no longer being maintained.) When exporting the program to other sites, a version is sent for a specific machine; therefore, the destination site does not need the CONVTCD program.

2.2 Variables

The variable names used in the program generally follow the default implicit typing specification in FORTRAN: (1) variable names beginning with the letters I, J, K, L, M, and N are integer numbers (i.e. type INTEGER) and (2) variable names beginning with all other letters are real numbers. Real number variables are of type REAL on long-word machines but are of type DOUBLE PRECISION on short-words machines. Allowance for this difference is accomplished by having

```

CSW
  IMPLICIT DOUBLE PRECISION (A-H,O-Z)
CSW

```

in the appropriate sections of the source code file (and using CONVTCDD to activate or deactivate this declaration statement when preparing a source code version for a specific machine). Earlier versions of COMMIX for short-word machines only used the DOUBLE PRECISION specification for the variables in COMMON BLOCK /R8ARY/, the pressure array (P), and the arrays used for the coefficients in the finite-difference equations (ACOFi, $i=0,1,\dots,6$, and BCOF0); later code-use experiences indicated that other variables needed to be declared DOUBLE PRECISION on short-word machines in order to avoid truncation errors; this list of variables continued to grow, and has resulted in the decision to make all real number variables DOUBLE PRECISION for short-word machines.

The program also uses a few LOGICAL and CHARACTER variables; these variables follow no particular naming convention; explicit typing specification statements are used in the appropriate subprograms.

Most global variables in the program are allocated to storage in various COMMON BLOCKS. The definitions of these variables, organized by COMMON BLOCK, are given in Sec. 4. In many instances, a variable is passed from one routine to another via the routine's argument list, rather than by including the entire COMMON BLOCK(s) in the called routine.

Units for real number variables generally conform to the International System of Units (SI) (Ref. 11), where the base units are kilogram [kg] for mass, meter [m] for length, and second [s] for time. As an exception to the SI standard, all temperatures are in degrees Celsius [$^{\circ}\text{C}$] rather than in kelvins [K]. As an additional exception, the pump speed, both as input and as used internally in the program, is in units of revolutions per minute [rev/min], rather than radians per second [s^{-1}]. Typical of the derived units used for variables are pascal [Pa] for pressure, joule [J] for energy, and watt [W] for power. The notation "[-]" indicates a quantity is dimensionless. All integer variables are dimensionless; therefore, the notation "[-]" is omitted for brevity.

Quantities for fluid cells and boundary surface elements are stored in arrays indexed by a fluid cell number ($1 \leq M \leq \text{NM1}$) or a boundary surface element number ($1 \leq L \leq \text{NL1}$), rather than using arrays having two or three spatial indices. Storage space in these arrays is only allocated for fluid cells and boundary surface elements which actually exist. The fluid cell and

boundary surface element numberings are not purely geometric; the mappings between these numberings and the spatial location indices are given by array element $IJK(M)$ for fluid cell number M and array element $IJK(MB(L))$ for boundary surface element number L ; similarly, the fluid cell numbers or boundary surface element numbers which are immediately adjacent to the six faces of fluid cell number M are given by array elements $MIM(M)$, $MIP(M)$, $MJM(M)$, $MJP(M)$, $MKM(M)$, and $MKP(M)$ (cf. COMMON BLOCK /SPACE/ in Sec. 4 for more complete descriptions of these arrays). This results in minimizing the computer core storage required for these arrays when the computational geometry is irregularly shaped. (Unfortunately, this storage pattern inhibits vectorization of certain coding sections; for some of these sections (notably, the conjugate-gradient solution method for the pressure equation system), new arrays have been created having a purely geometric storage order into which the base arrays are copied in order to allow the coding section to be vectorized.)

Most fluid cell quantities (e.g. temperature, density, pressure, and volume porosity) are associated with the cell center and stored by cell number, as described in the previous paragraph. The few quantities associated with cell faces (e.g. the three velocity components and surface porosities) are also stored by cell number, such that the value stored in array element number M is the value of the quantity on the face in the plus direction (e.g. $UL(M)$ is the velocity component in the x (or r) direction on the $+I$ face of fluid cell number M). The value on the face in the minus direction for cell number M must be indexed by referring to the value on the plus face of the cell on the minus side of cell number M ; this indirect addressing is accomplished using the six "Mij" arrays noted above (e.g. $UL(MIM(M))$ is the velocity component in the x (or r) direction on the $-I$ face of fluid cell number M). There are several exceptions to this general indexing: (1) If the value in one of the six "Mij" arrays is negative but not -9999 , then the corresponding face of the cell is an element on a REGular boundary surface (rather than there being an adjacent cell) and the value of the quantity on this cell face must be obtained from the appropriate boundary surface element array (e.g. the velocity component in the x (or r) direction on the $-I$ face of cell number M is $VELBN(-MIM(M))$ when $MIM(M) < 0$ (but $MIM(M) \neq -9999$) and the velocity component in the x (or r) direction on the $+I$ face of cell number M is $-VELBN(-MIP(M))$ when $MIP(M) < 0$ (but $MIP(M) \neq -9999$)). (2) If the value in one of the six "Mij" arrays is -9999 , then the corresponding face of cell number M is an

element on an IREGular boundary surface and the corresponding boundary surface element number is M; at most, only one of the six faces of a cell may be an IREGular boundary surface element. (3) The surface porosity is not defined for cell faces which are boundary surface elements; the flow area must be obtained from boundary surface array AREA.

2.3 Program Organization

The COMMIX-1AR/P program has one PROGRAM (named AAMAIN), one BLOCK DATA subprogram, 140 SUBROUTINE subprograms, and 10 FUNCTION subprograms; there are an additional 9 (or more) FUNCTION subprograms for each set of detailed fluid properties. Each subprogram has a set of COMMENT statements at the beginning of the source code to document what it does and the variables appearing in the argument list. This information on the function of each subprogram is summarized in Sec. 5 of this report, alphabetically by subprogram name. Table 2.3 shows which subprograms call which other subprograms for the entire program, with the following exceptions: calls to subprogram ERRCHK, to the fluid and solid property subprograms, and to standard FORTRAN intrinsics are not shown. In this listing, the called subprogram(s) are to the right of and below the calling subprogram. Moving down through this table, subprograms are shown in the approximate order in which they are called; however, multiple calls of one subprogram from another subprogram are not usually shown. An asterisk (*) following a subprogram name in this table indicates that the subprograms called by this subprogram have been shown at a higher location in the table. Two subprogram names separated by a slash (/) indicate that the subprogram preceding the slash is called on scalar machines and the subprogram after the slash is called on vector machines (e.g. FACINC/FACNCV).

The calculational order shown in Table 2.3 is summarized in the next few paragraphs. PROGRAM AAMAIN reads portions of the card-image input file and the input restart file. (The five files used by the program are discussed in Sec. 3.) Using this information it performs storage allocations within COMMON BLOCK /SPACE/ by setting the elements of array IS. It then calls subprogram AMAIN, which is effectively the driver for the rest of the run.

Table 2.3 Subprogram Calling Order

```

AAMAIN
  LOCF
  CLEAR
    LOCF
  TSCAN
  -----/MXPLNS
  ALTER
    LOCF
  AMAIN
    GEOM3D
      BOXES
        FILLM
          SHOME
          TLEFTS
        QTRPIN
          FILLM *
          RARRAY
          INTWIR
            WIRE
            WIRVOL
              WIRE
            RARRAY
            GETWIR
            THETAS
          FULPIN
            FILLM *
            RARRAY
          TLEFTS
          MARRAY
          IARRAY
          RARRAY
        INITAL
          NPROPS
          RESTAR
            LOCF
            PLTAPE
          INITA3
          INITA2
            LBLE
          FITIT
            SMOOTH
          GETF

```

Table 2.3 Subprogram Calling Order (Cont'd)

```

QGENER
    AXHEF
    RARRAY
IREBAL
INHTX
INPUMP
INFORC
INPSTR
RESTAR
ICTEMP
BARIN
    DSET3
    RSET3
    ISET3
    REDEF2
    DSET2
    RSET2
    ISET2
    REDEF
CHKHTX
INTURK
BCFLOT
    GETF
BCTEMT
    GETF
BCTEM0
    GETF
    HEATCF
        HEATCU
    QDUCTW
        GETF
        HEATCF *
BCTEMP
    DUCTWA
        GETF
        HEATCF *
BCFLOW
BCPRES
    GETF
GDDDP
GETMTS
GETIJK
ERRTSC
LODODD

```

Table 2.3 Subprogram Calling Order (Cont'd)

```

HSTRUC
    HEATCF *
TSTRUC
    GETF
QSTRUC
    GETF
    QSTRDS
        GETF
INITZ1
    BCPRES *
    BCTEM0 *
    BCTEMP *
    BCFLOT *
    HSTRUC *
    TSTRUC *
    QSTRUC *
INITUR
    TLFIX
    INTURK
    VISFIX
        VELOG
            VELCEN
TURV12
OUTPUT
    GETF
    RARRAY
    RSURFO
    ISURFO
    LBLE
    PSTRUC
GDCONV
GDDDH
PLTAPE
TLEFTS
WATSTP
GDCONV
GETEKL
TIMSTP
    BCPRES *
    MOLOOP
        BCFLOT *
        XMOMI
            WLFNCV
                YOFRE

```

Table 2.3 Subprogram Calling Order (Cont'd)

```

FORCES
PUMPQ
GETF
YMOMI
WLFNCV  *
FORCES
PUMPQ  *
ZMOMI
WLFNCV  *
FORCES
PUMPQ  *
PEQN
GETDL
REBAZG
GETDL
TDMA
REBAZ
GETDL
TDMA
GETDL
TLEFTS
SOLVIT
REBAZG  *
REBAZ  *
GETDL
CGLOOP
STORE
UPDATE
COMMAT
BOUND
ELIM
VOLCEL
WRPTST
SORTC
-----/MXPLNS
-----/RESORT
CNGRIC
FACINC/FACNCV
-----/COFSRT
OPERXC/OPERXD
LOWFAC/LOWFCV
UPPFAC/-----
DDOTC
DAXPYC

```

Table 2.3 Subprogram Calling Order (Cont'd)

```

                                DAXPXC
                                GETDL
                                MOMENI
                                BCFLOW
VISFIX *
BCTURB
TKLOOP
    TKSORC
        VELCEN
            TKENER
                WLFNCK
                    YOFRE
TLEFTS
SOLVEN/SOLVEV
TDLOOP
    TDNER
        TLEFTS
            SOLVEN/SOLVEV
TURV12
ENLOOP
    BCTEMT *
    HSTRUC *
    ESORCE
        GETF
        BCTEM0 *
        QSTRUC *
    ENERGI
        GETIJK
    TLEFTS
    SOLVEN/SOLVEV
    ENRBAL
TLEFTS
GETEKL
BCPRES *
BCTEMP *
TSTRUC *
QSRAD
    SGEFA
    SGESL
MALOOP
    DLCALC
    XMOM
        FORCES
    YMOM

```

Table 2.3 Subprogram Calling Order (Cont'd)

```

FORCES
ZMOM
FORCES
GDDDP
MOMENT
BCFLOT *
BCFLOW
REBALX
MOMENT
BCFLOW
REBALY
MOMENT
BCFLOW
REBALZ
MOMENT
BCFLOW
REBAL
DLCALC
MOMENT
BCFLOW
DLCALC
MOMENT
BCFLOW
TLEFTS
BCPRES *
BCTEM0 *
DLCALC
GDDDH
ENERGY
BCTEMT *
HSTRUC
GETF
BCTEM0 *
QSTRUC *
BCTEMP *
TSTRUC *
BCFLOF
LBLE
TLEFTS
WATSTP
PLTAPE
BOIL
WATSTP
WATTIM

```


Table 2.3 Subprogram Calling Order (Cont'd)

OUTPUT *
TLEFTS
RESTAR *
WATSTP
OUTPUT *

Subprogram GEOM3D (and the subprograms which it calls) continues the input process, initializing the arrays associated with the geometry for the case; the values input for IGEOM and IPART determine which one of subprograms BOXES ($IGEOM \leq 0$), QTRPIN ($IGEOM > 0$ and $IPART = 0$), or FULPIN ($IGEOM > 0$ and $IPART = 1$) is called by subprogram GEOM3D. Subprograms INITAL up through PLTAPE in Table 2.1 (and the subprograms which they call) complete the input and initialization processes. The call to subprogram TIMSTP from AMAIN results in advancing all calculational variables across one complete time step; further discussion of subprogram TIMSTP is given in the next two paragraphs. Following the return from subprogram TIMSTP, the calls to the remaining subprograms (WATSTP through OUTPUT) in Table 2.3 from AMAIN process output. Checks are made at the end of subprogram AMAIN for run completion; if the run is complete, a STOP statement is executed; otherwise, control is transferred to the point from which subprogram TIMSTP is called to advance the solution across the next time step.

Within subprogram TIMSTP, there are two calculational paths: implicit and explicit; the implicit path is described in this paragraph and the explicit path is described in the next paragraph. The pressures and velocities (combined momentum and mass equation systems) are advanced by subprograms BCPRES and MOLOOP. As called from subprogram MOLOOP, subprograms XMOMI, YMOMI, and ZMOMI set up the coefficient arrays for the three momentum equations, subprogram PEQN uses these arrays to form the pressure equation system, which is solved by subprogram SOLVIT (successive overrelaxation) or CGLOOP (conjugate gradient) for the new pressures, and subprogram MOMENI computes new velocity components from the new pressures. Subprograms BCxxxx handle various types of boundary

conditions. Some of the terms needed to construct the momentum equation coefficient arrays are provided by subprograms WLFNCV (turbulent wall shear), FORCES (force structure model), and PUMPQ (pump model). Subprograms REBAZG and REBAZ perform mass rebalancing. Both of the solution methods (subprograms SOLVIT and CGLOOP) contain an inner iteration process. The next group of subprograms handle various portions of the fluid turbulence modeling: VISFIX computes new turbulent viscosity and thermal conductivity values when the mixing-length model is used, TKLOOP advances the turbulent kinetic energy when the k or k - ϵ turbulence models are used, TDLOOP advances the turbulent kinetic energy dissipation rate when the k or k - ϵ turbulence models are used, and TURV12 computes new turbulent viscosity and thermal conductivity values when the k or k - ϵ turbulence models are used; both TKLOOP and TDLOOP call other subprograms to construct (TKSORC, TKENER, and TDNER) and solve (SOLVEN) their respective equation systems; the solution method in subprogram SOLVEN (or SOLVEV on vector machines) is successive overrelaxation and contains an inner iteration process. Subprogram ENLOOP advances the fluid enthalpies; subprograms ESORCE and ENERGI construct the coefficient arrays; this equation system is solved using the same subprogram used to solve the equation system(s) in the k and k - ϵ turbulence models; subprogram QSTRUC provides the heat transfer contribution to the fluid energy equation system from the thermal structure model. Following the return from ENLOOP, new fluid densities and temperatures are computed from the equation of state in subprogram TIMSTP. This completes an outer iteration; if the outer iteration convergence criteria have not been satisfied and the maximum number of outer iterations has not been exceeded, control is transferred to the point where MOLOOP is called to begin the next outer iteration; if the maximum number of outer iterations has been reached and the change-based automatic time-step-size control method is in use, the time step size is reduced and the time step is repeated. After the outer iteration process has converged, subprogram TSTRUC updates the thermal structure temperatures, subprogram QSRAD computes new radiation heat transfer rates, and subprogram BCFLOF adjusts the volume porosities for expansion cells. Control is then returned to subprogram AMAIN.

The rest of the subprograms shown as called from subprogram TIMSTP in Table 2.3 are for the explicit solution method. This is old coding which has not been kept totally up to date;

therefore, all cases must be run using the implicit solution method, which was described in the preceding paragraph. Nevertheless, a brief summary of the calculational flow for the explicit solution method is as follows. The pressures and velocities (combined momentum and mass equation systems) are advanced by subprogram MALOOP. As called from subprogram MALOOP, subprograms XMOM, YMOM, and ZMOM set up the coefficient arrays for the three momentum equations, which are used by subprogram DLCALC to set up and solve the pressure equation system for new pressures, and subprogram MOMENT computes new velocity components from the new pressures; subprograms REBAxx perform mass rebalancing as a part of the solution process. Subprogram ENERGY sets up and solves the fluid energy equation system for new enthalpies; it also computes new fluid densities and temperatures from the equation of state. Many of the other subprograms (e.g. BCxxxx for boundary conditions, FORCES for force structures, and xSTRUC for thermal structures) called in this explicit-solution path are the same as those called within the implicit-solution path.

In addition to the subprograms shown in Table 2.3, there are additional subprograms which must be present for fluid properties, solid properties, and several nonstandard system routines. A set of nine FUNCTION subprograms are used to provide the properties for fluid number 1 when IFPROP=0: CPLIQ, DRODHL, FLUDID, HLIQ, PSAT1, ROLIQ, THCLIQ, TLIQ, and VISLIQ. Currently, there are sets of these routines for four fluids: sodium (module SOPROPS at ANL), normal water (module WATRPROP), heavy water (module D2OPROPS), and helium (module HEPROPS); only one of these sets may be linked with the rest of the COMMIX-1AR/P coding at any given time. Some of these fluid property sets contain more than nine subprograms; the additional subprograms are only called by other subprograms within that particular property set. Properties for (1) fluid number 1 when IFPROP=1 and (2) all other fluid numbers are computed using a set of six statement functions: FCOND, FENTH, FDENSE, FTEMP, FVISC, and GDENSE (which are stored in module SIMPROP at ANL); the definitions of these statement functions are included in the source coding where needed using the "-INC SIMPROP" LIBRARIAN directive. The specific heat capacity and thermal conductivity for all solid materials are computed using FUNCTION subprograms CPSOL1 and XKSOL1, respectively; as defined, these subprograms compute the appropriate value using a second-order polynomial in temperature and the coefficients as input by the user (arrays CiCP and CiK,

$i=0,1,2$); this approach afford the user the opportunity to override these functions with more complicated expressions. (A similar capability is not provided for the density of solid materials.) As noted in Appendix C of Reference 2, there are four other system subprograms needed by the program which may not be automatically available on other machines: (1 and 2) SUBROUTINES SGEFA and SGESL (or DGEFA and DGESL on short-word machines), which are part of LINPACK (Ref. 12) and are called by subprogram QSRAD to solve the matrix system for the radiation heat transfer model, (3) the subprogram called by FUNCTION LOCF to return the core address of a variable, and (4) the subprogram called by FUNCTION TLEFTS to return the CPU time remaining. Although not shown in Table 2.3 (except for the LINPACK subprograms), these properties and system subprograms are listed in Sec. 5, including their appearance in the "Calls ..." entry for subprograms which call them.

3. FILES

The COMMIX-1AR/P program uses up to five different files during execution. These are as follows: (1) a card-image input file, (2) a printable output file, (3) a binary-format input restart file, (4) a binary-format output restart file, and (5) a binary-format plot output file. The first two of these files are required; the other three files are optional. Descriptions of these files and where they are accessed are given in Secs. 3.1 through 3.4. Section 3.5 discusses the format of the GRPH file, which is used to pass information from the TDSC program to the GRPH program, both of which are graphics postprocessor programs for COMMIX-1AR/P.

3.1 Card-Image Input File

The card-image input file is the primary source of user input when beginning a new case (indicated by ISTATE=0 in NAMELIST DATA). During a continuation run (ISTATE > 0), the card-image input file is read after reading the input restart file and, thus, may be used to change the values of variables which were read from the input restart file. The format of the card-image input file was discussed fairly extensively in Ref. 2; only a limited description is given here. This file consists of namelist and fixed-format blocks; the ordering of these blocks is given in Table 3.1. Within each block, each record is 80 characters or less. This file is accessed as FORTRAN unit number 5 (which is DDNAME stepname.FT05F001 on IBM mainframe machines and file name ./CARDIN on most other machines). It is read and echoed to the printable output file at the beginning of a run in the main program to provide the user a record of the input used for the case. After that, the file is rewound and the various blocks in the file are read by various input processing routines. As noted in Table 3.1, some blocks are always present, some blocks are only allowed at various ISTATE values, and some blocks are only present based on other values in the input file. As noted in Sec. 2 of Ref. 3.1, the user may include comments at numerous places in the file (typically, between namelist blocks). A summary of each block, when it is present, and where it is read is given below.

Block #1:   Problem Description: This input block consists of all records up to the beginning of NAMELIST GEOM. These records are only read in connection with echoing the card-image input file to the printable output file in the main program. Any number of records (including none) may be present.

Table 3.1 Ordering of Blocks in the Card-Image Input File

Block Type	ISTATE ¹				Notes ¹
	0	1	2	3	
Problem Description	O	O	O	O	
NAMelist GEOM	R	RL	RL	RL	
Boundary Surface Identification	R ²	N	N	N	E
NAMelist DATA	R	RL	RL	RL	
NAMelist INPUTQ	O	N	*L	N	
Rebalancing Regions	O	N	O	N	E
Fluid Cell Locations	O	N	N	N	E
NAMelist PUMP	O	N	*L	N	
Pump Locations	O	N	*L	N	E
Force Structure Locations	O	N	O	N	E
NAMelist STRUCT	O	N	O	N	
Thermal Structure Prototypes	O	N	O	N	E
Thermal Structure Locations	O	N	O	N	E
Boundary Value Initializations	R	RL	RL	RL	E
Internal Cell Initializations	R	RL	RL	RL	E

Notes:

- Key to codes used under ISTATE and Notes in above table:
E: An 'END ' record is part of and terminates this block.
L: Limited input allowed.
N: Not allowed.
O: Optional (depending on other flags in input stream).
R: Required.
*: If block was present at ISTATE=0, it must be present at ISTATE=2 (even if there are no changes).
- Required for IGEOM ≤ 0; not allowed for IGEOM > 0.

- Block #2:   NAMELIST GEOM:**   The variables in this namelist are primarily associated with the problem geometry. The primary read of this namelist is in the main program. (The namelist is subsequently reread by other routines, but these are really file-positioning actions.) Several variables in this namelist are used in connection with the quasidynamic storage allocation of arrays within **COMMON BLOCK /SPACE/**: **IFREB**, **IMAX**, **JMAX**, **KMAX**, **NFORCE**, **NL1**, and **NM1**. This input block must always be present; however, minimal input is required for **ISTATE** ≥ 1 .
- Block #3:   Boundary Surface Identification:**   This fixed-format input block describes the specific locations of all boundary surfaces. These records are read in routine **BOXES**. A record containing 'END ' in positions 1 through 4 is part of and terminates this input block. This input block is only present when **ISTATE**=0 and **IGEOM** ≤ 0 .
- Block #4:   NAMELIST DATA:**   This input block contains most of the variables which describe boundary conditions, material properties, and case-control options. It is read in routine **INITAL**. This input block must always be present; however, minimal input is required for **ISTATE** ≥ 1 .
- Block #5:   NAMELIST INPUTQ:**   This input block contains variables associated with heat sources which are introduced without using the thermal structure model; these heat sources are typically used in conjunction with the hexagonal fuel assembly model option (**IGEOM** ≥ 1). It is read in routine **QGENER**. This input block is only be present when (1) **IFROD** > 0 and (2) **ISTATE**=0 or **ISTATE**=2.
- Block #6:   Rebalancing Region Location:**   This fixed-format input block describes the rebalancing regions and surfaces for the user-specified mass rebalancing model. It is read in routine **IREBAL**. A record containing 'END ' in positions 1 through 4 is part of and terminates this input block. This input block is only present if **IFREB** > 0 and **NEWREB**=1; this combination is only allowed if **ISTATE**=0 or

ISTATE=2. If the input block is present at ISTATE=2, it must contain information for all rebalancing regions and surfaces, not just for those to be changed relative to ISTATE=0 specifications.

Block #7:   **Fluid Cell Location:**   This fixed-format input block identifies which fluid cells contain a fluid other than fluid number 1. It is read in routine INHTX. A record containing 'END ' in positions 1 through 4 is part of and terminates this input block. This input block is only present when IFHTX $\geq$ 2 and ISTATE=0.

Block #8:   **NAMelist PUMP:**   This input block contains variables associated with the pump model. It is read in routine INPUMP. This input block is only present if (1) IFPUMP > 0 and (2) ISTATE=0 or ISTATE=2; however, minimal input is required at ISTATE=2.

Block #9:   **Pump Location:**   This fixed-format input block associates a particular pump with a particular momentum cell. It is read in routine INPUMP. A record containing 'END ' in positions 1 through 4 is part of and terminates this input block. This input block is only present when (1) IFPUMP > 0 and (2) ISTATE=0 or ISTATE=2. This input block should usually just consist of the 'END ' record at ISTATE=2 (i.e. do not change the location of any pumps).

Block #10:   **Force Structure Location:**   This fixed-format input block associates a particular force structure prototype number with one or more specific momentum cells. It is read in routine INFORC. A record containing 'END ' in positions 1 through 4 is part of and terminates this input block. This input block is only present if NFORCE > 0 and NEWFOR=1, which is only allowed when ISTATE=0 or ISTATE=2; if this input block is present at ISTATE=2, information must be specified for all force structures, not just for those to be changed from ISTATE=0 specifications.

Block #11: NAMELIST STRUCT: This input block contains a flag (ISTBUG) indicating whether the thermal structure control block table is to be printed. It is read in routines TSCAN and INPSTR, and its reading serves to position the card-image input file to the beginning of the thermal structure prototype input block. This input block is only present when ISTRUC=2 and NEWTS=1, which is only allowed when ISTATE=0 or ISTATE=2.

Block #12: Thermal Structure Prototype: This input block describes the thermal structure prototypes. It consists of multiple occurrences of NAMELISTs T (begins a new prototype), F (fluid interaction with prototype surfaces), and M (material regions within a prototype); the ordering of these namelists is significant, as described in Sec. 5.2 of Ref. 2. A record containing 'END ' in positions 1 through 4 is part of and terminates this input block. This input block is initially read in routine TSCAN; the logic in this routine requires the ampersand (&) preceding the namelist name to be in position 2 (in addition to the normal namelist restrictions of the namelist name being in position 3 and positions 1 and 4 being blank); the order in which the namelists occur in this input block is stored in COMMON BLOCK /CSCAN/. Based on the information in COMMON BLOCK /CSCAN/, routine INPSTR rereads this input block; it is during these reads that the values input for variables are assigned into their proper core storage locations. This input block is only present if ISTRUC=2 and NEWTS=1, which is only allowed when ISTATE=0 or ISTATE=2; if this input block is present at ISTATE=2, then it must contain information for all thermal structure prototypes, not just for those which differ from the ISTATE=0 specifications.

Block #13: Thermal Structure Location: This fixed-format input block associates the surface(s) of each thermal structure prototype with one or more fluid cells. A record containing 'END ' in positions 1 through 4 is part of and terminates this input block. This input block is initially read in routine TSCAN (to count the number of fluid interactions for each prototype) and then reread in routine

INPSTR (to store the actual fluid cell numbers in the proper storage locations). This input block is only present if ISTRUC=2 and NEWTS=1, which is only allowed when ISTATE=0 or ISTATE=2; if this input block is present at ISTATE=2, information must be specified for all prototypes, not just for those to be changed from ISTATE=0 specifications.

Block #14: Boundary Value Initialization: This fixed-format input block is used to assign values to variables on boundary surfaces. It is read in routine BARIN. A record containing 'END' in positions 1 through 4 is part of and terminates this input block. This input block is always present, although minimal input (usually none) is specified at $ISTATE \geq 1$. (Even if no values are to be input, the 'END' record must still be present.) The values specified using these records override values specified elsewhere in the card-image input file or read from the binary-format restart file. (Exception: There is no constructive purpose served by reading 'HLB', 'PB', or 'RLB' records, since the corresponding array elements are always computed internally by the program.)

Block #15: Internal Cell Initialization: This fixed-format input block is used to assign values to variables for fluid cells. It is read in routine BARIN. A record containing 'END' in positions 1 through 4 is part of and terminates this input block. This input block is always present, although minimal input (usually none) is specified at $ISTATE \geq 1$. (Even if no values are to be input, the 'END' record must still be present.) The values specified using these records override values specified elsewhere in the card-image input file or read from the binary-format restart file. (Exception: There is no constructive purpose served by reading 'HL' records, since the corresponding array elements are always computed internally by the program.)

3.2 Printable Output File

The printable output file produced by the program is identified by FORTRAN unit

number 6 (which is DDNAME stepname.FT06F001 on IBM mainframe machines and the "stdout" file on most other machines). The records in this file have 133 characters or less, the first of which is used for carriage control. The format of this file and the input variables which control the content of the file are described in Sec. 12.6 of Ref. 2. Numerous routines contain the WRITE statements which create this file.

3.3 Restart File

This binary-format file is used to pass information from one computer run to the next when multiple runs are needed to complete a calculational sequence for a case. This file is written and read using unformatted WRITE and READ statements. There are up to 17 records in the file; the record length varies from record to record; some record lengths are a function of the case being run. When IFRES=1, 3, or 4, an output restart file is written using FORTRAN unit number 10 (which is DDNAME stepname.FT10F001 on IBM mainframe machines and file name ./CMXNEW on most other machines); this file is written at the "normal end" of a run and contains sufficient information on the current values of variables for the case to be continued in a successor run. When IFRES=2, 3, or 4, an input restart file is read using FORTRAN unit number 9 (which is DDNAME stepname.FT09F001 on IBM mainframe machines and file name ./CMXOLD on most others machines). When IFRES=0, neither the input or output restart files are used. The first record of the file is processed (either read or written) in the main program; records 2 through 10 are processed (either read or written) in routine RESTAR. Records 11 through 17 are identified as the "plot file appendage" of the restart file; they are written in routine PLTAPE; they are not read by this program but are read by graphics postprocessor programs VECT and TEMP. In addition to being used as input to a successor COMMIX run, this file may also be used as input to graphics postprocessor programs VECT and TEMP (which actually get their useful information from "plot file appendage" of the restart file). The record structure of this file is given below; variables are shown in their order of occurrence within each record; unless noted otherwise, definitions of the variable names in these records are given in Sec. 4.

Record #1: Key Storage Allocations: This record contains the key variables used to allocate storage:

NM1, NL1, NFORCE, IWIRE, ITURKE, ISYMCH, IFITEN, IFREB,
ISTRUC, IMAX, JMAX, KMAX, IGEOM, NSTRUC, NPARTS,
NREGTS, NSURTS, NTTs, IFHTX

The values of NM1, NL1, and IFREB in this record are the values as input in NAMELIST GEOM at ISTATE=0, and, as such, may be estimates; the actual values ($\leq$ estimate) are in record #3. If ISTRUC=2 was input in NAMELIST GEOM, the value is reset to 1 before writing this record.

Record #2: Common Block Lengths: This record contains the lengths of the various common blocks which are in record #3:

IPL, L1, L2, L3, L4, L5, L6, L7, L8, L9, L10, L11, L12, NEEDED

These lengths are all in units of "computer words" and are associated with COMMON BLOCK /name/ as follows:

L1: /I4VAR/	L2: /R4VAR/
L3: /I4ARY/	L4: /R4ARY/
L5: /R8ARY/	L6: /CCORR/
L7: /CHEATC/	L8: /CPUMP/
L9: 0 (future)	L10: 0 (future)
L11: 0 (future)	L12: 0 (future)
NEEDED: /SPACE/	

Variable IPL has a value of 10 (the unit number on which the file is written) as written to the restart file; the value read into this variable from the restart file is not used later.

Record #3: Common Blocks: This record contains the eight common blocks whose lengths are given by variables L1 through L8 in record #2:

/I4VAR/, /R4VAR/, /I4ARY/, /R4ARY/, /R8ARY/, /CCORR/,
/CHEATC/, /CPUMP/

Within each common block, the variables are written in the order of storage (cf. Sec. 4). The first item from common block n follows the last item from common block n-1 for the eight common blocks in this record.

Block #4: **COMMON BLOCK /SPACE/ Sublengths:** This record contains the lengths of the seven sections into which **COMMON BLOCK /SPACE/** is logically divided:

LBL1, LBL2, LBL3, LBL4, LBL5, LBL6, LBL7

These lengths are all in units of "computer words"; a length of 0 indicates that the variables in this part of the common block are not used in the case. The variables stored in the common block sections associated with the six lengths **LBL1** through **LBL6** are in record #5 through record #10, respectively, of the restart file if the corresponding **LBLi** value is non-zero; if **LBLi=0**, the corresponding block is not present on the restart file. The common block section associated with length **LBL7** is no longer present on the restart file (even though **LBL7** is usually nonzero); these variables are recomputed by the program at the beginning of a continuation run, rather than being saved on the restart file (primarily, to minimize the size of the file). See Sec. 4.6 (**COMMON BLOCK /ADDCON/**) for more information on the use of variables **LBLi** and array **IS**.

Record #5: **Basic Variables:** This record of the restart file contains the arrays in **COMMON BLOCK /SPACE/** which are always allocated (nonoptional), preceded by the record length:

LBL1, (S(IS(75)+L-1),L=1,LBL1)

This corresponds to the arrays identified by index array **IS(i)** for *i* values of 75, 1 through 8, 10, 13 through 35, 41 through 50, and 78 through 84.

Record #6: **Force Structure Variables:** This record of the restart file contains the arrays in **COMMON BLOCK /SPACE/** which are allocated for the force structure model, preceded by the record length:

LBL2, (S(IS(9)+L-1),L=1,LBL2)

This corresponds to the arrays identified by index array **IS(i)** for *i* values of 9 and 60 through 63. This record is only present if **LBL2 > 0** (implies **NFORCE > 0**).

Record #7: Rebalancing Variables: This record of the restart file contains the array in **COMMON BLOCK /SPACE/** which is allocated for the user-specified mass rebalancing model, preceeded by the record length:

LBL3, (S(IS(11)+L-1),L=1,LBL3)

This corresponds to the array identified by index array IS(11). This record is only present if **LBL3 > 0** (implies **IFREB > 0**).

Record #8: Turbulence Variables: This record of the restart file contains the arrays in **COMMON BLOCK /SPACE/** which are allocated for the turbulence model, preceeded by the record length:

LBL4, (S(IS(37)+L-1),L=1,LBL4)

This corresponds to the arrays identified by index array IS(i) for i values of 37, 76, 12, 36, 61, 167, and 168 through 172. (The number of these arrays actually on the restart file depends on the value of **ITURKE**.) This record is only present if **LBL4 > 0** (implies **ITURKE > 0**).

Record #9: Wire Wrap Variables: This record of the restart file contains the arrays in **COMMON BLOCK /SPACE/** which are allocated for the wire wrap model, preceeded by the record length:

LBL5, (S(IS(38)+L-1),L=1,LBL5)

This corresponds to the arrays identified by index array IS(i) for i values of 38 through 40. This record is only present if **LBL5 > 0** (implies **IWIRE > 0**).

Record #10: Thermal Structure Variables: This record of the restart file contains the arrays in **COMMON BLOCK /SPACE/** which are allocated for the thermal structure model, preceeded by the record length:

LBL6, (S(IS(52)+L-1),L=1,LBL6)

This corresponds to the arrays identified by index array IS(i) for i values of 52 through 59, 64 through 66, and 77. This record is only present if **LBL6 > 0** (implies **ISTRUC > 0**).

- Record #11: Plot File Header Record #1:** This record is identical to that described for the plot file in Sec. 3.4.
- Record #12: Plot File Header Record #2:** This record is identical to that described for the plot file in Sec. 3.4.
- Record #13: Plot File Header Record #3:** This record is identical to that described for the plot file in Sec. 3.4. It is only present on the restart file if $ISTRUC > 0$.
- Record #14: Plot File Transient Record #1:** This record is identical to that described for the plot file in Sec. 3.4 and contains data for the last time step in the run.
- Record #15: Plot File Transient Record #2:** This record is identical to that described for the plot file in Sec. 3.4 and contains data for the last time step in the run.
- Record #16: Plot File Transient Record #3:** This record is identical to that described for the plot file in Sec. 3.4 and contains data for the last time step in the run.
- Record #17: Plot File Transient Record #4:** This record is identical to that described for the plot file in Sec. 3.4 and contains data for the last time step in the run. It is only present on the restart file if $ISTRUC > 0$.

3.4 Plot File

This binary-format file is used to pass information from a COMMIX run to the graphics postprocessor programs VECT, TEMP, and TDSC. This file is written using unformatted WRITE statements in routine PLTAPE using FORTRAN unit number 76 (which is DDNAME stepname.FT76F001 on IBM mainframe machines and file name ./PLTDAT on most other machines). The file is written at the time step numbers indicated by the user in array NTPLOT. If $NTPLOT(1)=0$, the file is never opened. If $NTPLOT(1) \neq 0$, the file is opened at the time

step number indicated by NTPLOT(1) and consists of a group of header records followed by a group of transient records for each time step number indicated in the NTPLOT array:

```

Header Record #1
Header Record #2
Header Record #3 (optional)
Transient Record #1 for 1st requested time step
Transient Record #2 for 1st requested time step
Transient Record #3 for 1st requested time step
Transient Record #4 for 1st requested time step (optional)
Transient Record #1 for 2nd requested time step
Transient Record #2 for 2nd requested time step
Transient Record #3 for 2nd requested time step
Transient Record #4 for 2nd requested time step (optional)
. . . . .
. . . . .
. . . . .
. . . . .
Transient Record #1 for last requested time step
Transient Record #2 for last requested time step
Transient Record #3 for last requested time step
Transient Record #4 for last requested time step (optional)

```

The header records are written during the call to PLTAPE that writes the set of records for the first requested time step. (A copy of the three header records and a set of the four transient records for the last time step in the run are always appended to the output restart file regardless of NTPLOT(1).) The structure of each record is given below; variables are shown in their order of occurrence within each record; unless noted otherwise, definitions of the variable names in these records are given in Sec. 4.

Header Record #1: Simple Constants: This records contains the key variables used to allocate storage and some geometry constants:

```

IPL, IMAX, JMAX, KMAX, NSURF, NM, NM1, NL1, IGEOM,
IPART, CLADOD, PITCH, WALLCL, WODIN, WODOUT, ZAT0,
WIREP, IWIRE, NPINS, ITURKE, ISTRUC, NSTRUC, NPARTS,
NREGTS, NSURTS, NTTs, LBL6, (JUNK(I),I=1,19)

```

Variable IPL has the value 76 if this is the plot file and the value 10 if this is the "plot file appendage" of the restart file (i.e. the value of the unit number on which the file was written); array JUNK is filled with zeros (allowing for future variables without changing the length of the header block; the values of IPL and

JUNK are not used after being read from the file. The values of IPART, CLADOD, PITCH, WALLCL, WODIN, WODOUT, ZAT0, WIREP, IWIRE, and NPINS are not useful when $IGEOM \leq 0$. The values for NSTRUC, NPARTS, NREGTS, NSURTS, NTTTS, and LBL6 are not useful when ISTRUC=0.

Header Record #2: Array Constants: This record contains the constant arrays which are associated with the geometry for the case:

(X(I),DX(I),I=1,IMAX),
 (Y(J),DY(J),J=1,JMAX),
 (Z(K),DZ(K),K=1,KMAX),
 (XNORML(N),YNORML(N),ZNORML(N),N=1,NSURF),
 (MB(L),ISURF(L),AREA(L),L=1,NL1),
 (IJK(M),MIP(M),MIM(M),MJP(M),MJM(M),MKP(M),MKM(M),
 AL(M),ALX(M),ALY(M),ALZ(M),QSOUR(M),M=1,NM1)

Note that (unlike other records) all array elements for a given index type are stored consecutively (e.g. X(1), DX(1), X(2), DX(2), ..., X(IMAX), DX(IMAX)), rather than each array being in contiguous locations in this record.

Header Record #3: Thermal Structure Constants: This block contains constant arrays associated with the thermal structure model:

(S(IS(52)+L-1),L=1,LBL6)

which is the following arrays of indicated size

ITSCB(11,NSTRUC), HYDRA1(NSTRUC), HYDRA2(NSTRUC),
 RODFR(NSTRUC), STAREA(NPARTS), STVOL(NPARTS),
 MATERL(NREGTS), HEAT(NREGTS), SIZE(NREGTS),
 ICEL(NSURTS), HSTREL(NSURTS), TTS(NTTS)

(This is identical to record #10 on the restart file.) This record is only present if ISTRUC > 0.

Transient Record #1: Step Identification: This record contains the time and time step number:

NTIME, TIME

and is essentially a header record for the group of transient records.

Transient Record #2: Internal Cell Values: This record contains velocity and temperature values for internal fluid cells:

(UL(N),N=1,NM1), (VL(N),N=1,NM1), (WL(N),N=1,NM1),
(TL(N),N=1,NM1)

for the time indicated in transient record #1.

Transient Record #3: Boundary Surface Values: This record contains velocity and temperature data for boundary surface elements:

(VELBN(N),N=1,NL1), (TLB(N),N=1,NL1)

for the time indicated in transient record #1.

Transient Record #4: Thermal Structure Values: This block contains values associated with the thermal structure model:

(TTS(N),N=1,NTTS), (QSOUR(N),N=1,NM1)

for the time indicated in transient record #1. This record is only present if
ISTRUC $\geq$ 1.

3.5 GRPH File

This binary-format file is used to pass information from program TDSC (when run in data extraction mode) to program GRPH, both of which are graphics postprocessor programs. This file is written by program TDSC using unformatted WRITE statements in routines HEADER and TIMSTP using FORTRAN unit number 16 (which is DDNAME stepname.FT16F001 on IBM mainframe machines and file name ./fort.16 on most other machines); the file is read by routines AAGRPH and GDRIVE of program GRPH using various FORTRAN unit numbers, depending on whether it is the primary file or an alternate file. The file is written at the time step numbers between NBEG and NEND which are an integral multiple of NTPRNT, where NBEG, NEND, and NTPRNT are all input by the user to program TDSC (cf. Sec. D.4 of Ref. 2). The file consists of two header records followed by a transient record for each time step number selected by NTPRNT:

```

Header Record #1
Header Record #2
Transient Record for 1st requested time step
Transient Record for 2nd requested time step
.....
.....
.....
Transient Record for last requested time step

```

The header records are written during the call to HEADER that reads the header of the binary input file (which is a plot file (cf. Sec. 3.4), written by COMMIX-1AR/P or a previous TDSC run). The structure of each record is given below; variables are shown in their order of occurrence within each record; definitions of the variable names in these records are shown, since they do not correspond by name to any of the variables in COMMIX-1AR/P which are given in Sec. 4.

Header Record #1: Size Information: This record contains a single variable used to indicate record lengths and allocate storage:

NVARBL

Variable NVARBL is the number of items of data extracted for each time step; its value is set by counting the number of entries in user-input array NTHPR (cf. Sec. D.4 of Ref. 2) which precede the first occurrence of a "0" entry; the value of NVARBL is used to determine the lengths of the other records on this file and to dimension arrays in program GRPH; the value is in the range $0 \leq \text{NVARBL} \leq 100$. This record is written by routine HEADER of the TDSC program and read by routine AAGRPH of the GRPH program.

Header Record #2: Array Constants: This record contains the constant arrays which identify the variables in the Transient Records:

(NTHPR(N),N=1,NVARBL), (ITHPR(N),N=1,NVARBL),
(NNTHPR(N),N=1,NVARBL)

Arrays ITHPR and NTHPR are input to the TDSC program by the user in NAMELIST SET (cf. Sec. D.4 of Ref. 2) and indicate variable type and spatial location. Array NNTHPR is set internally based on the other two arrays; more specifically, array element NNTHPR(N) holds the actual index used to retrieve

the value for the indicated variable from the appropriate array (which will then be stored in array element TVARBL(N), which is part of the Transient Records) and is either (1) the fluid cell number ($\leq \text{NM1}$) corresponding to spatial location NTHPR(N) when ITHPR(N)=1, 2, 3, 4, or 7, (2) the boundary surface element number ($\leq \text{NL1}$) corresponding to spatial location NTHPR(N) when ITHPR(N)=5 or 6, or (3) the thermal structure partition number ($\leq \text{NTTS}$) given by the value of NTHPR(N) when ITHPR(N)=10; variables NL1, NM1, and NTTS are defined in Sec. 4.1 (COMMON BLOCK /I4VAR/). The interrelations between the four arrays may be summarized as follows:

<u>ITHPR(N)</u>	<u>NTHPR(N)</u>	<u>NNTHPR(N)</u>	<u>TVARBL(N)</u>
1	iijjkk	Cell #	UL(NNTHPR(N))
2	iijjkk	Cell #	VL(NNTHPR(N))
3	iijjkk	Cell #	WL(NNTHPR(N))
4	iijjkk	Cell #	TL(NNTHPR(N))
5	nniijjkk	SurfEl #	TLB(NNTHPR(N))
6	nniijjkk	SurfEl #	VLB(NNTHPR(N))
7	iijjkk	Cell #	QSOUR(NNTHPR(N))
10	m	ThStPt #	TTS(NNTHPR(N))=TTS(m)

In the above listing, "ii", "jj", and "kk" are the spatial cell location indices in the I-, J-, and K-directions, respectively; "nn" is the boundary surface number; "m" is the thermal structure partition number; arrays UL, VL, WL, TL, TLB, VELBN, QSOUR, and TTS are defined in Sec. 4.7 (COMMON BLOCK /SPACE/); and the value of N ranges from 1 up to NVARBL. This record is written by routine HEADER of the TDSC program and read by routine GDRIVE of the GRPH program.

Transient Record: Data for Time Step: This record contains the requested variable values for one time step:

NTIME, TIME, (TVARBL(N),N=1,NVARBL)

Variables NTIME and TIME are the time step number and the case time [s], respectively, for which data are written in this record. Array element TVARBL(N) contains the value of variable type ITHPR(N) for location NTHPR(N) and is, thus, element number NNTHPR(N) of array UL, VL, WL,

TL, QSOUR, TLB, VLEBN, or TTS, depending on ITHPR(N). This record is written by routine TIMSTP of the TDSC program and read by routine GDRIVE of the GRPH program.

4. GLOBAL VARIABLES

Most variables used globally in the program are stored in named common blocks. Sections 4.1 through 4.20 provide a description of each common block, showing the storage order of variables within the block and usage notes (for specialized blocks). This is followed by an alphabetized listing of the variables in the block, showing the definition and usage notes. Section 4.21 provides an alphabetized index of all variables defined in Secs. 4.1 through 4.20 as an aid to locating a particular variable's definition. Unless noted otherwise, the variables conform to the default naming convention discussed in Sec. 2.2.

The first five common blocks presented (/I4VAR/, /R4VAR/, /I4ARY/, /R4ARY/, and /R8ARY/) always appear together in the program and appear in numerous routines. They are stored as code module SHARED at ANL. Module SHARED also includes the IMPLICIT typing specification used to make all real number variables DOUBLE PRECISION on short-word machines and the setting of three variables via PARAMETER statements:

```
CSW
  IMPLICIT DOUBLE PRECISION (A-H,O-Z)
CSW
  INTEGER PNSTRU,PNRAD,PIFHTX
  PARAMETER (PNSTRU=99, PNRAD=99, PIFHTX=5)
```

preceding the five common blocks. (The use of "CSW" in bracketing coding sections is discussed in Sec. 2.1.) The definitions of the three variables set by the PARAMETER statement are as follows (since they are not actually in any of the common blocks).

PIFHTX   This type INTEGER variable sets the maximum number of fluids allowed in any calculation (i.e. the maximum value allowed for input variable IFHTX in NAMELIST GEOM). This variable is used to dimension arrays in COMMON BLOCKs /I4ARY/ and /R4ARY/ and as a loop index in some input processing routines. The value must be at least 1; there is no upper limit imposed (however, some FORMAT statements only allow a 1-digit output field).

PNRAD

This type INTEGER variable sets the maximum number of radiation surfaces allowed in any calculation (i.e. the maximum value allowed for input variable NRAD in NAMELIST DATA). This variable is used to dimension arrays in COMMON BLOCK /R4ARY/, dimension local arrays in routine QSRAD, and as a loop index in some input processing routines. The value must be at least 1; there is no useful purpose served by the value being greater than 2*PNSTRU (however, some FORMAT statements only allow a 3-digit output field width).

PNSTRU

This type INTEGER variable sets the maximum number of thermal structure prototypes allowed in any calculation (i.e. the maximum number of occurrences of NAMELIST T in the thermal structure prototype block of the card-image input file and the maximum value allowed for input variable N in these namelists). This variable is used to dimension arrays in COMMON BLOCK /I4ARY/ and /R4ARY/ and as a loop index in some input processing routines. The value must be at least 1; the storage algorithm requires that this value not exceed 9999 (however, some FORMAT statements only allow a 3-digit output field width).

The five common blocks which form the rest of module SHARED are discussed in Secs. 4.1 through 4.5.

4.1 COMMON BLOCK /I4VAR/

This common block contains simple integer variables. The declaration statement defining the storage order is given by

```
COMMON /I4VAR / ISYMCH,IOUT01,IOUT02,IOUT03,IMAX, JMAX, KMAX,  
1 NSURF, NM, NM1, NL, NL1, IOUT04,IGEOM, IXMBUG,IYMBUG,  
2 IZMBUG,IDLBUG,IMOBUG,IENBUG,IINBUG,IOUT05,IFENER,ITIBUG,IOUT06,  
3 ITURK, IOUT08,NFCN, ISTATE,IDRAG, LMPRNT,NOFQT, IFROD, IFFLOT,  
4 IFRES, NTMAX, ICONV, NTIME, NPR, LASTDT,ITERMX,ITER, IZREB,  
5 LASTIT,IWIRE. IPART, IOUT09,NPL, NPINS, NSTREL,NREBP ,ITKBUG,  
6 IFMAX, IWA5EN,IBOIL, ISTOP1,ITURKE,IWASMO,ISTRUC,NRAD, ITDBUG,
```

A IFHTX, IFRAD, ICALL, IFACTR, IUPDAT, ITLAST, ITKMX, ITMAXK, NTJUMP,
 7 NSTRUC, NPARTS, NREGTS, NSURTS, NTTTS, ISETEN, NEWTS, NMATER, IREBIT,
 8 NFORCE, NCORR, IDTIME, IDDDP, IXREB, IYREB, IFPROP, IFREB, NREBRT,
 9 ISETMO, LCONV, NHEATC, ITMAXE, ITENER, IFITEN, ICONVE, LHEAD, IGETCN,
 A ITMASX, ITMAXP, ITMOMX, ITENMX, IBSBUG, IHTOUT, IFPUMP,
 B ITAUTO, IFSHRT, IFLONG, ICHANG, I4VEND

This declaration statement is part of code module SHARED at ANL. The definitions of these variable are as follows.

I4VEND Last variable in COMMON BLOCK /I4VAR/. Value is irrelevant.
 Storage location is only referenced in connection with calculating the length of the common block.

IBOIL Flag indicating whether code (routine BOIL) is to check for boiling of fluid number 1. Input in NAMELIST DATA. Key values: 0: no; 1: yes (requires IFPROP=0); 2: boiling was detected (set internally by routine BOIL).

IBSBUG Flag indicating whether the Boundary Surface Summary is to be printed. Input in NAMELIST GEOM. Key values: 0: no; 1: yes; 2: yes and terminate execution.

ICALL Counter used in determining whether to recompute the factorization of the matrix for the pressure equation system within the conjugate-gradient solution method. Initialized to 0 in routine INITAL. Incremented by 1 during each call to routine CGLOOP (i.e. every outer iteration).

ICHANG Flag indicating whether time step size (DTIME) or maximum number of outer iterations per time step (ITERMX) is being changed at this time step. Set by routines AMAIN and TIMSTP and tested by routine AMAIN. Key values: 0: no; 1: yes.

ICONV   Flag indicating convergence of the pressure (combined momentum and mass) equation system. Set by routines MALOOP and REBAL. Obsolete; only used in explicit-mode calculation.

ICONVE   Flag indicating convergence of the fluid energy equation system. Set by routine ENERGY. Key values: 0: no; 1: yes. Obsolete; only used in explicit-mode calculations.

IDDDP   Flag to select role of variable DDDP. Input in NAMELIST DATA. Obsolete: only used in explicit-mode calculations.

IDLBUG   Flag to activate debug printing during construction of pressure equation in routine PEQN. Input in NAMELIST DATA. Key values: 0: off; >0: on.

IDRAG   Flag to select drag force model for IGEOM>0. Input in NAMELIST DATA. Key values: 0: none; 1: nominal; 2: porosity adjusted.

IDTIME   Flag to select time step size control method. Input in NAMELIST DATA. Key values: 0: manual; 1: Courant-based automatic; 2: change-based automatic.

IENBUG   Flag to activate debug printing associated with fluid and structure energy equations in routines QSRAD, TSTRUC, ENERGI, and ENRBAL. Input in NAMELIST DATA. Key values: 0: off; >0: on.

IFACTR   Flag indicating whether new matrix factorization is to be computed in the conjugate-gradient solution of the pressure equation system. Set by routine CGLOOP based on criteria ((a) first step in calculation, (b) first step in computer run, or (c) it has been more than NUPDAT (=3) outer iterations since the last factorization and the last outer iteration required more than NTLAST (=5) inner

iterations to converge the pressure equation system); used by routine CNGRIC.
Key values: 0: no; 1: yes.

IFENER   Flag to activate energy calculation. Input in NAMELIST DATA.
When $ISETEN \neq 1$, routine AMAIN sets IFENER=0 on the step for which the energy calculation is not being performed; the original input value is saved in variable IWASEN for use by routine AMAIN in restoring IFENER after the step is completed. Key values: 0: off; 1: on; 2: on with porosity-adjusted conduction. (The enthalpy, temperature, and density remain constant during a time step when IFENER=0.)

IFFLOT   Flag indicating whether there are any transient velocity boundary conditions. Set by routine INITAL. Key values: 0: none; 1: some.

IFHTX   Flag indicating the number of fluids in the case. Input in NAMELIST GEOM. Must not exceed the value of PARAMETER PIFHTX.

IFITEN   Flag to select calculational mode for energy equation. Input in NAMELIST GEOM. Key values: 0,1,2: obsolete explicit modes; 3: implicit mode.

IFLONG   Flag indicating that the time step size was too big for this step when IDTIME=2. Set to 0 initially for each step by routine TIMSTP; set to 1 by routine TIMSTP if time step size was too big (i.e. per step changes exceeded CHGMAX) to signal the need to cut the time step size by DTFAC and repeat the time step.

IFMAX   Not currently used. (Input in NAMELIST INPUTQ; default of 25 set in routine QGENER.)

IFPROP   Flag indicating whether fluid number 1 uses detailed or simplified

properties. Input in NAMELIST DATA. Key values: 0: detailed; 1: simplified.

IFPUMP Flag indicating type of pump model in use (for all pumps in the case). Input in NAMELIST DATA. Key values: 0: none; 1: specified speed; 2: specified pressure; 3: homologous; 4: homologous with reverse flow precluded.

IFRAD Flag indicating whether the radiation heat transfer model is being used. Input in NAMELIST DATA. Key values: 0: no; >0: yes.

IFREB Flag indicating whether the user-specified rebalancing model is being used. Input in NAMELIST GEOM. Key values: 0: no; >0: yes and value is the amount of storage requested for this option.

IFRES Flag indicating use of restart file. Input in NAMELIST GEOM. Key values: 0: no; 1: write at end; 2: read at beginning; 3: read at beginning and write at end; 4: read velocity and temperature guess at beginning and write normal restart file at end.

IFROD Flag indicating whether fuel rod model is used (and whether to read NAMELIST INPUTQ). Input in NAMELIST DATA. Key values: 0: no; 1: yes; 2: yes and perform one-dimensional initialization of fluid.

IFSHRT Flag indicating whether time step size was too small when IDTIME=2. Initially set to 0; incremented by 1 in routine TIMSTP if time step size was smaller than allowed by CHGMIN and CHGMAX limits; after the value gets up to NSTEPS, then time step size is multiplied by DTFACT and IFSHRT is reset to 0; any automatic time step size decrease will also result in resetting IFSHRT to 0.

IGEOM Flag indicating the fluid geometry coordinate system. Input in NAMELIST GEOM. Key values: -1: cylindrical (r, θ, z); 0: Cartesian (x, y, z);

> 0: hexagonal fuel assembly (value is number of fuel pins) in Cartesian system.

IGETCN   Flag indicating whether new values of DCONV (pressure equation system convergence criterion) and Courant-based time step size are to be computed during this time step by routine GDCONV. Set by routine WATSTP based on variable NTIME and array NTHCON. Key values: 0: no; 1: yes.

IHTOUT   Not currently used.

IINBUG   Flag activating debug printing from routine INITZ1. Input in NAMELIST DATA. Key values: 0: off; >0: on.

IMAX   Maximum number of fluid cells in direction of first spatial position coordinate index (I, which corresponds to x or r). Input in NAMELIST GEOM. Must be in range $1 \leq \text{IMAX} \leq 99$.

IMOBUG   Flag activating debug printing associated with the momentum equation in routines AMAIN, TIMSTP, CGLOOP, and CNGRIC. Input in NAMELIST DATA. Key values: 0: off; >0: on.

IOUT01   Not currently used.

IOUT02   Not currently used.

IOUT03   Not currently used.

IOUT04   Not currently used.

IOUT05   Not currently used.

IOUT06   Not currently used.

IOUT08	Not currently used.
IOUT09	Not currently used.
IPART	Flag indicating type of partitioning for hexagonal fuel assembly (IGEOM > 0). Input in NAMELIST GEOM. Key values: 0: quarter pin; 1: full pin.
IREBIT	Mass rebalancing frequency: Mass rebalancing is performed before every IREBIT th inner iteration in the pressure equation solution if ISYMCH < 5 and IFREB > 0, IXREB > 0, IYREB > 0, or IZREB > 0; must have IREBIT > 0. Input in NAMELIST DATA.
ISETEN	Flag to allow performing or skipping the energy equation solution at time step numbers which are an integral multiple of ISETEN. Input in NAMELIST DATA. Key values: <0: skip; >0: perform.
ISETMO	Flag to allow performing or skipping the momentum equation solution at time step numbers which are an integral multiple of ISETMO. Input in NAMELIST DATA. Key values: <0: skip; >0: perform.
ISTATE	Flag indicating type of run. Input in NAMELIST DATA. Key values: 0: begin steady state; 1: continue steady state; 2: begin transient; 3: continue transient.
ISTOP1	Flag indicating that run is to terminate after this time step due to the volume porosity in an expansion cell being too low. (Allows orderly termination with final print and restart file.) Set by routine BCFLOF; tested by routine AMAIN. Key values: 0: continue; 1: terminate.
ISTRUC	Flag indicating use of thermal structure model and presence of

card-image input. Input in NAMELIST GEOM. Key values: 0: no; 1: yes but no input; 2: yes and read input. An input value of 2 is reset to 1 after the input has been read.

ISYMCH   Flag indicating solution method for pressure (combined mass and momentum) equation system. Input in NAMELIST GEOM. Key values: 0,1,2: obsolete explicit modes; 3: implicit successive overrelaxation; 4: implicit Jacobi; 5: implicit conjugate gradient. If $ISETMO \neq 1$, then ISYMCH is temporarily set to -1 by routine AMAIN during steps in which the pressure equation solution is skipped; the value is restored by AMAIN for the next step from variable IWASMO. Other logic in the program requires this to be the first variable in COMMON BLOCK /I4VAR/.

ITAUTO   Flag indicating whether change-based automatic time step control is activated. Initially set to 0 by routine INITAL; reset by routine TIMSTP if IDTIME=2 and solution has satisfied CHGMIN limits once in a steady-state calculation. (Used to preclude drastic time step size reductions at the beginning of a steady-state calculation.) Key values: 0: off; 1: on.

ITDEBUG   Flag activating debug printing associated with turbulent kinetic energy dissipation rate in routines TDLOOP and TDNER. Input in NAMELIST DATA. Key values: 0: off; >0: on.

ITENER   Iteration counter for explicit-mode fluid energy calculation.
(Obsolete.)

ITENMX   Maximum number of times per outer iteration to execute loop containing calls to routines ESORCE, ENERGI, and SOLVEN/SOLVEV in routine ENLOOP. Default value of 1 set in routine INITAL. (Although this variable appears in NAMELIST DATA, the default value of 1 must not be overridden by the user.)

ITER Outer iteration counter for a time step. Initialized to 0 at the beginning of a new time step in routine **AMAIN** (or in routine **TIMSTP** if repeating a time step); incremented by 1 at the beginning of each outer iteration in routine **TIMSTP**.

ITERMX Current maximum number of outer iterations allowed per time step. Set in routine **AMAIN** to (1) **IT(1)** initially and (2) **IT(2)** when the time step number first exceeds **LASTIT**.

ITIBUG Flag to activate debug printing associated with general iteration progression by routines **AMAIN**, **TIMSTP**, **ENLOOP**, **SOLVEN**, **MOLOOP**, **SOLVIT**, and **INITAL**. Input in **NAMELIST DATA**. Key values: 0: off; >0: on.

ITKBUG Flag activating debug printing associated with turbulent kinetic energy equation in routines **TKLOOP**, **TKENER**, **TKSORC**, **VELOG**, and **VISFIX**. Input in **NAMELIST DATA**. Key values: 0: off; >0: on.

ITKMX Maximum number of times per outer iteration to execute (1) loop containing calls to routines **TKSORC**, **TKENER**, and **SOLVEN/SOLVEV** in routine **TKLOOP** and (2) loop containing calls to routines **TDNER** and **SOLVEN/SOLVEV** in routine **TDLOOP**. Default value of 1 set in routine **INITAL**. (Although this variable appears in **NAMELIST DATA**, the default value of 1 must not be overridden by the user.)

ITLAST Number of inner iterations required to converge the pressure equation system on the previous call to routine **CGLOOP**. Set by **CGLOOP**. Part of test used in setting **IFACTR=1** in **CGLOOP** (every **NUPDAT**-th (=3) outer iteration if **ITLAST** $\geq$ **NTLAST**(=5)).

ITMASX Maximum number of times per call to routines **XMOMI**, **YMOMI**,

and ZMOMI to execute loop containing calls to routines PEQN, SOLVIT/CGLOOP, and MOMENI in routine MOLOOP. Default value of 1 set in routine INITAL. (Although this variable appears in NAMELIST DATA, the default value of 1 must not be overridden by the user.)

ITMAXE   Maximum number of inner iterations allowed per outer iteration in solving the fluid energy equation system. Input in NAMELIST DATA. Passed to routine SOLVEN/SOLVEV from ENLOOP.

ITMAXK   Maximum number of inner iterations allowed per outer iteration in solving the turbulent kinetic energy and turbulent kinetic energy dissipation rate equation systems. Input in NAMELIST DATA. Passed to routine SOLVEN/SOLVEV from routines TKLOOP and TDLOOP.

ITMAXP   Maximum number of inner iterations allowed per outer iteration in solving the pressure equation system. Input in NAMELIST DATA. Passed to routine SOLVIT or CGLOOP from routine MOLOOP.

ITMOMX   Maximum number of times per outer iteration to execute loop containing calls to routines XMOMI, YMOMI, ZMOMI, and the nested loop shown under variable ITMASX (in which routines PEQN, SOLVIT/CGLOOP, and MOMENI are called) in routine MOLOOP. Default value of 1 set in routine INITAL. (Although this variable appears in NAMELIST DATA, the default value of 1 must not be overridden by the user.)

ITURK   Flag indicating which turbulence quantities are to be initialized at the beginning of this run. Set in routine INITAL as follows:

$$\text{ITURKE} = 100 * (\text{ITURKE value from restart file or } 0 \text{ if } \text{ISTATE}=0) \\ + (\text{ITURKE value for this run})$$

Allows turbulence model to be turned on and properly initialized if the value of ITURKE is changed during a continuation run.

ITURKE   Flag indicating type of fluid turbulence model. Input in NAMELIST GEOM. Key values: 0: user specified constant in space; 1: user specified variable in space; 10: mixing length; 11: k; 12: k- ϵ .

IUPDAT   Outer iteration number (counts from beginning of calculation) at which the matrix factorization was last computed in the conjugate-gradient solution of the pressure equation system. Set by routine CGLOOP.

IWASEN   Holds original value of IFITEN during step when energy calculation is being skipped. Set by routine INITAL and used by routine AMAIN to restore the value of IFITEN after the skipped step.

IWASMO   Holds original input value of ISYMCH during step when pressure (combined mass and momentum) calculation is being skipped. Set by routine INITAL and is used by routine AMAIN to restore the value of ISYMCH after the skipped step.

IWIRE   Flag indicating wire-wrap model type when hexagonal fuel assembly is being used. Input in NAMELIST GEOM. Key values: 0: none; 1: smeared; 2: discrete (cell integrated).

IXMBUG   Flag activating debug printing associated with momentum equation construction for first spatial coordinate direction (x or r) by routine XMOMI. Input in NAMELIST DATA. Key values: 0: off; >0: on.

IXREB   Flag activating plane-by-plane mass rebalancing in direction of first spatial coordinate (x or r). Input in NAMELIST DATA. Key values: 0: off; 1: on.

IYMBUG   Flag activating debug printing associated with momentum equation construction for second spatial coordinate direction (y or θ) by routine YMOMI.

Input in NAMELIST DATA. Key values: 0: off; >0: on.

IYREB   Flag activating plane-by-plane mass rebalancing in direction of second spatial coordinate (y or θ). Input in NAMELIST DATA. Key values: 0: off; 1: on.

IZMBUG   Flag activating debug printing associated with (1) momentum equation construction for third spatial coordinate direction (z) by routine ZMOMI, (2) transient velocity boundary conditions in routine BCFLOT, and (3) expansion cell velocity boundary conditions in routine BCFLOF. Input in NAMELIST DATA. Key values: 0: off; >0: on.

IZREB   Flag activating plane-by-plane mass rebalancing in direction of third spatial coordinate direction (z). Input in NAMELIST DATA. Key values: 0: off; 1: on.

JMAX   Maximum number of fluid cells in direction of second spatial coordinate index (J, which corresponds to y or θ). Input in NAMELIST GEOM. Must be in range $1 \leq JMAX \leq 99$.

KMAX   Maximum number of fluid cells in direction of third spatial position coordinate index (K, which corresponds to z). Input in NAMELIST GEOM. Must be in range $1 \leq KMAX \leq 99$.

LASTDT   Time step number after which to switch from time step size of DT(1) to DT(2) when (1) IDTIME=0 or (2) IDTIME=2 but ITAUTO=0. Input in NAMELIST DATA.

LASTIT   Time step number after which to switch from IT(1) to IT(2) maximum number of outer iterations per time step. Input in NAMELIST DATA.

LCONV Flag indicating whether routine GDCONV (which computes new values for variables DCONV, VELMAX, and COURDT) was called during this time step. Set to 1 by routine GDCONV; reset to 0 by routine TIMSTP at the end of the time step.

LHEAD Flag indicating whether page header (page eject and column headings for end-of-time-step print line) are to be written to the printable output file before beginning the current time step. Key values: 0: no; 1: yes. Set to 1 (1) initially in routine INITAL, (2) by a call to routine OUTPUT, and (3) every 50th time step by routine TIMSTP; reset to 0 after page header is written by routine TIMSTP.

LMPRNT Flag activating debug printing of geometry arrays for fluid cells (arrays IJK, MIM, MIP, MJM, MJP, MKM, MKP, AL, ALX, ALY, and ALZ) and boundary surfaces (arrays MB, ISURF, and AREA) by routine GEOM3D. Input in NAMELIST GEOM; incremented by 1 if routine FILLM detects fatal geometry input errors. Key values: 0: off; 1: cell arrays; 2: cell and boundary surface arrays; >0: execution terminates after the requested information is printed.

NCORR Number of friction factor correlation sets input by user. Input in NAMELIST DATA. Must be in range $1 \leq \text{NCORR} \leq 20$.

NEWTS Flag indicating whether thermal structure definition input is present in the card-image input file. Input in NAMELIST DATA. Key values: 0: no; 1: yes (and must also have ISTRUC=2).

NFCN Number of transient functions defined by input in arrays TVAL, FVAL, and NEND in NAMELIST DATA. Set in routine INITAL to the number of consecutive nonzero entries in array NEND.

NFORCE Number of force structure prototypes. Input in NAMELIST GEOM. Must be in range $0 \leq \text{NFORCE} \leq 99$.

NHEATC   Number of basic heat transfer correlations for which user is supplying coefficients. Input in NAMELIST DATA. Must be in range $1 \leq \text{NHEATC} \leq 20$.

NL   Number of irregular surface elements. Set by routine BOXES, FULPIN, or QTRPIN.

NL1   Total number of surface elements (regular plus irregular). Value input in NAMELIST GEOM is used to allocate storage. If user inputs an overestimate, the value is reset by routine BOXES, FULPIN, or QTRPIN to the actual number of surface elements before beginning the calculation (but after storage allocation). There will be problems if this (1) exceeds 9998 or (2) is input at ISTATE > 0.

NM   Number of irregular fluid cells. Set by routine BOXES, FULPIN, or QTRPIN.

NM1   Total number of fluid cells (regular plus irregular). The value input in NAMELIST GEOM is used to allocate storage. If the users inputs an overestimate, the value is reset by routine BOXES, FULPIN, or QTRPIN to the actual number of cells before beginning the calculation (but after allocating storage). There will be a problem if the user inputs this value at ISTATE > 0.

NMATER   Number of structure materials. Input in NAMELIST DATA. Must be in the range $1 \leq \text{NMATER} \leq 20$.

NOFQT   Indicates which transient function number is used in connection with direct heat source in coolant. Input in NAMELIST DATA or INPUTQ; if input in both places, the value in NAMELIST INPUTQ will be used. A value of 0 indicates that heat source is constant; a value in the range $1 \leq \text{NOFQT} \leq 25$ indicates a transient function number.

NPARTS   Total number of partitions in all thermal structure prototypes. Set by routine TSCAN and is used to allocate storage.

NPINS   Number of fuel pins when IGEOM > 0. Set by routine FULPIN or QTRPIN to the value input for variable IGEOM in NAMELIST GEOM.

NPL   Pointer indicating which element of array NTPLOT is currently being used to decide whether routine PLTAPE (which writes a set of records to the plot file) is to be called at the end of this time step. Initialized to 1 at the beginning of routine AMAIN; reset as needed by routine WATSTP as called from routine AMAIN.

NPR   Pointer indicating which element of array NTPRNT is currently being used to decide whether routine OUTPUT (which writes a set of records to the printable output file) is to be called at the end of this time step. Initialized to 1 at the beginning of routine AMAIN; reset as needed by routine WATSTP as called from routine AMAIN.

NRAD   Total number of radiating surfaces. Input in NAMELIST DATA.

NREBP   Number of rebalancing passes. Although this variable appears in NAMELIST DATA, the default value of 1 must not be overridden. (Reserved for a future option.)

NREBRT   Number of user-specified rebalancing regions. Input in NAMELIST DATA. Must be in range $1 \leq \text{NREBRT} \leq 99$ when IFREB > 0.

NREGTS   Total number of material regions in all thermal structure prototypes. Set by routine TSCAN.

NSTREL   Total number of thermal structure elements. Set by routine TSCAN.

NSTRUC   Number of thermal structure prototypes. Set by routine TSCAN.

NSURF   Number of boundary surfaces. Input in NAMELIST GEOM. Must be in range $1 \leq \text{NSURF} \leq 99$.

NSURTS   Number of thermal structure surface elements. Set by routine TSCAN.

NTIME   Current time step number. Set to 0 at the beginning of runs having ISTATE=0 or 2 by routine INITAL or AMAIN; incremented by 1 before each time step by routine AMAIN.

NTJUMP   Turbulence equation system(s) is solved every NTJUMPth time step. Input in NAMELIST DATA. Must have NTJUMP > 0.

NTMAX   Time step number after which this run is to terminate. Input in NAMELIST DATA.

NTTS   Number of thermal structure partitions. Set by routine TSCAN.

4.2 COMMON BLOCK /R4VAR/

This common block contains simple real number variables. (In some earlier versions of COMMIX, these variables were declared to be REAL*4 on short-word machine, thus the "4" in the block name; the current practice in COMMIX-1AR/P is for all real number variables to be DOUBLE PRECISION on short-word machines.) The declaration statement defining the storage order is given by

```

COMMON /R4VAR / EG ,XMAXX ,YMAXX ,ZMAXX ,TSTART,TIMAX ,GRAVX,
1 GRAVY ,GRAVZ ,AO ,BO ,OMEGA ,DDDP ,OMEGAT,ALPHA ,OMEGAD,
2 PRNDLD,PRNDLK,PRNDLH,EPS6 ,CT1 ,CT2 ,TKIN ,TDIN ,
3 EPS1 ,EPS2 ,DCONV ,DLMAX ,TURBV ,TURBC ,DLSUM ,TREST ,QFLUX ,
4 CLADOD,PITCHX,PITCHY,FCX1 ,FCX2 ,FCX3 ,FCX4 ,FCX5 ,FCY1 ,
5 FCY2 ,FCY3 ,FCY4 ,FCY5 ,EPS3 ,DHOH ,ECMAX ,DTIME ,TIME ,
6 DUMAX ,DVMAX ,DWMAX ,VELMAX,WODIN ,WODOUT,CLOD ,SQRT3 ,PITCH,
7 WALLCL,CHARRE,CHART ,ZAT0 ,WIREP ,CWIREX,CWIREY,CWIREZ,
8 ROUT01,OMEGAR,ROUT02,CDTURB,TURBCO,CDRAGX,CDRAGY,CDRAGZ,
9 CWIREI,CWIREO,HYDALL,HYDIN,HYDOUT,DLCUT,DCONV1,RELAXK,OMEGAK,
A AKAPPA,QSCOOL,CDQTR ,PI ,EE ,COURDT,DTFUEL,DTWALL,RDTIME,
F DDPOT ,QRADTW,EMIW ,AREAW ,FINM ,OMR ,
G DTENER,DDDHMX,OMEGAE,EPS5 ,OMEGAV,DUMAXT,RELAXE,DVMAXT,
H DWMAXT,DHOHT ,CHGMIN,CHGMAX,DTFACT,R4VEND

```

This declaration statement is part of code module SHARED at ANL. The definitions of these variables are as follows.

AKAPPA κ : von Karman constant in turbulence model. Set by routine
INITAL to be $0.23/CDTURB^{**}0.25$.

ALPHA Future allowance for less than fully implicit advancement of
variables. Appears in NAMELIST DATA but user should not override the
default value of 1.0.

AO Constant in central/donor spatial differencing for explicit-mode
calculations. Input in NAMELIST DATA. (Obsolete.)

AREAW Not currently used.

BO Constant in central/donor spatial differencing for explicit-mode
calculations. Input in NAMELIST DATA. (Obsolete.)

CDQTR $C_{\mu}^{0.25}$: Constant in turbulence modeling. Set by routine INITAL
to be $CDTURB^{**}0.25$.

CDRAGX $C_{f,x}$: Hexagonal assembly fuel-pin drag-force multiplier for x direction for $IDRAG > 0$. Input in NAMELIST DATA.

CDRAGY $C_{f,y}$: Hexagonal assembly fuel-pin drag-force multiplier for y direction for $IDRAG > 0$. Input in NAMELIST DATA.

CDRAGZ $C_{f,z}$: Hexagonal assembly fuel-pin drag-force multiplier for z direction for $IDRAG > 0$. Input in NAMELIST DATA.

CDTURB C_μ : Constant in calculation of turbulent viscosity. Input in NAMELIST DATA.

CHARRE Re_{ch} : Characteristic Reynolds number used to calculate turbulent thermal conductivity when $ITURKE < 10$. Input in NAMELIST DATA.

CHART T_{ch} : Characteristic temperature used to calculate turbulent thermal conductivity when $ITURKE < 10$. Input in NAMELIST DATA.

CHGMAX $\varepsilon_{t,max}$: Upper limit on step-to-step changes in kinetic energy, temperature, and total viscosity when $IDTIME=2$; if changes exceed CHGMAX, the time step size will be reduced by DTFAC and the current time step will be repeated. Input in NAMELIST DATA.

CHGMIN $\varepsilon_{t,min}$: Lower limit on step-to-step changes in kinetic energy, temperature, and total viscosity when $IDTIME=2$; if changes remain below CHGMIN for NSTEPS consecutive steps, the time step size will be increased by DTFAC. Input in NAMELIST DATA.

CLADOD   Fuel pin outer diameter [m] in hexagonal fuel assembly model. Input in NAMELIST GEOM or INPUTQ.

CLOD   Fuel pin outer diameter [m] in hexagonal fuel assembly model. Set to value of variable CLADOD by routine FULPIN, QTRPIN, or WIRE.

COURDT   Courant-based time step size limit. Set in routine GDCONV to density/UVWMAX (cf. variable DCONV in this common block). When IDTIME=1, the time step size will be set to RDTIME*COURDT in routine GDCONV.

CT1 C_1 : Constant in source term of equation for turbulent kinetic energy dissipation rate. Input in NAMELIST DATA.

CT2 C_2 : Constant in source term of equation for turbulent kinetic energy dissipation rate. Input in NAMELIST DATA.

CWIREI $C_{t,in}$: Multiplier on wire force for cells in interior of hexagonal fuel assembly model. Input in NAMELIST GEOM.

CWIREO $C_{t,out}$: Multiplier on wire force for cells adjacent to wall of hexagonal fuel assembly model. Input in NAMELIST GEOM.

CWIREX C_x : Multiplier on x-direction wire force in hexagonal fuel assembly model. Input in NAMELIST DATA.

CWIREY C_y : Multiplier on y-direction wire force in hexagonal fuel assembly model. Input in NAMELIST DATA.

CWIREZ C_z : Multiplier on z-direction wire force in hexagonal fuel assembly model. Input in NAMELIST DATA.

DCONV $(\delta/V)_{p,ref}$: Convergence basis for pressure equation system; mass residual must be reduced below DCONV for convergence to be achieved. Set by

routine GDCONV to be $\text{EPS1} * (\text{UVWMAX} + \text{EPS2})$, where UVWMAX is the current maximum mass flow rate per cell volume for the case.

DCONV1 Value of $\text{DLCUT} * \text{DCONV}$ as used to eliminate cells from the mass-momentum iteration for explicit-mode calculations. Set by routine MALOOP. (Obsolete.)

DDDHMX Selects basis for DDDH in energy equation convergence in explicit-mode calculations. Input in NAMELIST DATA. (Obsolete.)

DDDP Set by routine GDCONV to $\text{DDPOT} * \text{DTIME}$. Used by routine DLCALC when solving the pressure equation system instead of $\text{DDDPOT}(M) * \text{DTIME}$ for cell number M if $\text{IDDDP} \neq 0$. (Obsolete: only used for explicit-mode calculations.)

DDPOT Set by routine GDDDP to be the maximum element in array $\text{DDDPOT}(M)$, where $1 \leq M \leq \text{NM1}$. (Obsolete: only used for explicit-mode calculations.)

DHOH Maximum step-to-step fractional change in enthalpy over all fluid cells. Set by routine ENLOOP; used in convergence checks.

DHOHT Maximum outer-to-outer fractional change in enthalpy over all fluid cells. Set by routine ENLOOP; used in convergence checks.

DLCUT Multiplier of $0.5 * \text{DCONV}$ used to eliminate cells from mass-momentum iterations for explicit-mode calculations. Input in NAMELIST DATA. (Obsolete.)

DLMAX Maximum mass residual (i.e. $\max(\text{DL}(M))$, for $1 \leq M \leq \text{NM1}$). Calculated by routine SOLVIT or CNGRIC; reset to $\text{DLMAX} / \text{DCONV}$ in routine

TIMSTP after returning from routine MOLOOP.

- DLSUM**   Sum of the elements in the mass residual array (DL(M)) for all fluid cells (M=1,2,...,NM1). Computed and printed by routine OUTPUT; no other references.
- DTENER**   Time step size for explicit-mode energy calculation. Input in NAMELIST DATA. (Obsolete.)
- DTFACT** β_2 : Factor by which current time step size is increased (by routine AMAIN) and decreased (by routine TIMSTP) when IDTIME=2. Input in NAMELIST DATA. Must have DTFACT $\geq$ 1.0.
- DTFUEL**   Time step size [s] for thermal structure energy calculation. Although this variable appears in NAMELIST INPUTQ, the user should not input a value. This time step size is set to 1.E40 for ISTATE $\leq$ 1 and to DTIME for ISTATE $\geq$ 2 by routines AMAIN and TIMSTP.
- DTIME**   Current time step size [s]. Set by routines AMAIN and TIMSTP.
- DTWALL**   Time step size [s] for duct wall energy equation boundary conditions (KTEMP=500+nf). Although this variable appears in NAMELIST DATA, the user should not input a value. This time step size is set to 1.E40 for ISTATE $\leq$ 1 and to DTIME for ISTATE $\geq$ 2 by routines AMAIN and TIMSTP.
- DUMAX**   Maximum time-step-to-time-step change in the I-direction velocity component (array UL(M)) over all fluid cells M (=1,2,...,NM1) divided by the maximum fluid speed (variable VELMAX, which is defined elsewhere in this section). Computed in routine MOLOOP.
- DUMAXT**   Maximum outer-iteration-to-outer-iteration change in the I-direction

velocity component (array $UL(M)$) over all fluid cells M ($=1,2,\dots,NM1$). Computed in routine MOMENI; reset to $DUMAXT/(VELMAX*OMEGA)$ in routine MOLOOP after returning from routine MOMENI. (OMEGA and VELMAX are defined elsewhere in this section.)

DVMAX Maximum time-step-to-time-step change in the J-direction velocity component (array $VL(M)$) over all fluid cells M ($=1,2,\dots,NM1$) divided by the maximum fluid speed (variable VELMAX, which is defined elsewhere in this section). Computed in routine MOLOOP.

DVMAXT Maximum outer-iteration-to-outer-iteration change in the J-direction velocity component (array $VL(M)$) over all fluid cells M ($=1,2,\dots,NM1$). Computed in routine MOMENI; reset to $DVMAXT/(VELMAX*OMEGA)$ in routine MOLOOP after returning from routine MOMENI. (OMEGA and VELMAX are defined elsewhere in this section.)

DWMAX Maximum time-step-to-time-step change in the K-direction velocity component (array $WL(M)$) over all fluid cells M ($=1,2,\dots,NM1$) divided by the maximum fluid speed (variable VELMAX, which is defined elsewhere in this section). Computed in routine MOLOOP.

DWMAXT Maximum outer-iteration-to-outer-iteration change in the K-direction velocity component (array $WL(M)$) over all fluid cells M ($=1,2,\dots,NM1$). Computed in routine MOMENI; reset to $DWMAXT/(VELMAX*OMEGA)$ in routine MOLOOP after returning from routine MOMENI. (OMEGA and VELMAX are defined elsewhere in this section.)

ECMAX Not currently used.

EE E: Constant in turbulence model. Set by routine INITAL to be

$\text{EXP}(20.0 \cdot \text{CDQTR} \cdot \text{AKAPPA}) / (20.0 \cdot \text{CDQTR})$.

- EG Value is not currently used; however, other logic in the program requires this to be the first variable in COMMON BLOCK /R4VAR/.
- EMIW Not currently used.
- EPS1 ε_1 : Constant in pressure equation inner iteration convergence criterion. Input in NAMELIST DATA.
- EPS2 ε_2 : Constant [$\text{kg/m}^3 \cdot \text{s}$] in pressure equation inner iteration convergence criterion. Input in NAMELIST DATA.
- EPS3 ε_3 : Velocity and enthalpy outer iteration convergence criterion. Input in NAMELIST DATA.
- EPS5 ε_h : Fluid enthalpy inner iteration convergence criterion. Input in NAMELIST DATA.
- EPS6 ε_k and ε_ε : Turbulent kinetic energy and turbulent kinetic energy dissipation rate inner iteration convergence criterion. Input in NAMELIST DATA.
- FCX1 Constant in x-direction friction for the hexagonal fuel assembly model. Set by routine QGENER to $3.0 \cdot ((\text{PITCHY} - \text{CLADOD}) / (\text{PITCHY} - 0.93 \cdot \text{CLADOD}))^2$. Used by routine XMOMI.
- FCX2 Constant in x-direction friction for the hexagonal fuel assembly model. Set by routine QGENER to $0.6 \cdot \text{PITCHY} / \text{CLADOD} \cdot (0.25 + 0.118 / ((\text{PITCHY} / \text{CLADOD} - 1.0)^{1.08}))$. Used by routine XMOMI.

FCX3 Set by routine QGENER to $1.0-(CLADOD/PITCHY)**2$. Not currently used.

FCX4 Set by routine QGENER to $PITCHY-CLADOD$. Not currently used.

FCX5 Constant in x-direction friction for hexagonal fuel assembly model. Set by routine QGENER to $FCX1/(1.0+2.16*CLADOD/(PITCHY-CLADOD))$. Used by routine XMOMI.

FCY1 Constant in y-direction friction for the hexagonal fuel assembly model. Set by routine QGENER to $3.0*((PITCHX-CLADOD)/(PITCHX-0.93*CLADOD))**2$. Used by routine YMOMI.

FCY2 Constant in y-direction friction for the hexagonal fuel assembly model. Set by routine QGENER to $0.6*PITCHX/CLADOD*(0.25+0.118/((PITCHX/CLADOD-1.0)**1.08))$. Used by routine YMOMI.

FCY3 Set by routine QGENER to $1.0-(CLADOD/PITCHX)**2$. Not currently used.

FCY4 Set by routine QGENER to $PITCHX-CLADOD$. Not currently used.

FCY5 Constant in y-direction friction for hexagonal fuel assembly model. Set by routine QGENER to $FCY1/(1.0+2.16*CLADOD/(PITCHX-CLADOD))$. Used by routine YMOMI.

FINM Not currently used.

GRAVX g_x : Component of gravitational acceleration vector [m/s^2] in x

direction. Input in NAMELIST DATA.

GRAVY g_y : Component of gravitational acceleration vector [m/s²] in y direction. Input in NAMELIST DATA.

GRAVZ g_z : Component of gravitational acceleration vector [m/s²] in z direction. Input in NAMELIST DATA.

HYDALL $D_{h,all}$: Overall hydraulic diameter [m] for hexagonal fuel assembly model. Although this variable appears in NAMELISTs DATA and INPUTQ, it should not be input; the value will be computed and printed in routine FULPIN or QTRPIN but is not used subsequently.

HYDIN $D_{h,in}$: Hydraulic diameter [m] for (1) interior region of hexagonal fuel assembly model and (2) turbulence model. Input in NAMELISTs DATA and INPUTQ. Should not be input for IGEOM > 0 when IPART=0; the input value will be overridden by routine QTRPIN.

HYDOUT $D_{h,out}$: Hydraulic diameter [m] adjacent to wall of hexagonal fuel assembly model. Although in NAMELISTs DATA and INPUTQ, HYDOUT should not be input when IPART=0; its value will be calculated by routine QTRPIN.

OMEGA ω_p : Relaxation factor for solution of the pressure equation system when ISYMCH=3. Input in NAMELIST DATA.

OMEGAD Ω_ϵ : Relaxation factor for solution of the turbulent kinetic energy dissipation rate equation system. Input in NAMELIST DATA.

OMEGAE Ω_h : Relaxation factor for solution of the fluid energy equation system. Input in NAMELIST DATA.

OMEGAK Ω_k : Relaxation factor for solution of the turbulent kinetic energy equation system. Input in NAMELIST DATA.

OMEGAR Ω_ρ : Underrelaxation factor for advancement of fluid density across a time step by routine TIMSTP when $0 < \text{OMEGAR} \leq 1$. If $\text{OMEGAR} < 0$, then this signals that the fluid density remains at its initial value (in array RL, by cell) in all terms except for the buoyancy term of the momentum equations (for which the current density is obtained from array RLBOUS, as filled in routine MOLOOP). Input in NAMELIST DATA.

OMEGAT Ω_t : Underrelaxation factor for advancement of turbulent viscosity across a time step. Input in NAMELIST DATA.

OMEGAV Ω_v : Relaxation factor for coefficients in the momentum equations. Input in NAMELIST DATA.

OMR Ω_r : Underrelaxation factor for advancement of radiation heat transfer rate across a time step. Input in NAMELIST DATA.

PI π : Defined by routine BOXES, FULPIN, QTRPIN, or QGENER to be $4.0 \cdot \text{ATAN}(1.0)$.

PITCH   Center-to-center pin spacing in hexagonal fuel assembly model. Input in NAMELIST GEOM.

PITCHX P_x : x-direction component of center-to-center pin spacing in hexagonal fuel assembly model. Default value is set by routine QGENER, but this may be overridden by input in NAMELIST INPUTQ. Only used in routine QGENER to set values of variables FCY1 through FCY5.

PITCHY P_y : y-direction component of center-to-center pin spacing in

hexagonal fuel assembly model. Default value is set by routine QGENER, but this may be overridden by input in NAMELIST INPUTQ. Only used in routine QGENER to set the values of variables FCX1 through FCX5.

PRNDLD σ_t : Turbulence Prandtl number used to compute an effective viscosity for use in turbulent kinetic energy dissipation rate equation system. Input in NAMELIST DATA.

PRNDLH σ_h : Turbulence Prandtl number used to compute turbulent thermal conductivity for thermal energy transfer. Input in NAMELIST DATA.

PRNDLK σ_k : Turbulence Prandtl number used to compute an effective viscosity for use in turbulent kinetic energy equation system. Input in NAMELIST DATA.

QFLUX   Average constant heat flux [W/m²] for pins in hexagonal fuel assembly model. Input in NAMELIST INPUTQ.

QRADTW   Not currently used.

QSCOO   Average volumetric heat source [W/m³] in coolant. Input in NAMELIST INPUTQ.

R4VEND   Last variable in COMMON BLOCK /R4VAR/. Value is irrelevant. Storage location is only referenced in connection with calculating the length of the common block.

RDTIME β_1 : Factor which multiplies Courant-based maximum time step size to get the actual time step size when IDTIME=1. Input in NAMELIST DATA.

RELAXE ω_h : Relaxation factor for solution of the fluid energy equation

system. Input in NAMELIST DATA.

RELAXK ω_k and ω_ϵ : Relaxation factor for solution of the turbulent kinetic energy and turbulent kinetic energy dissipation rate equation systems. Input in NAMELIST DATA.

ROUT01   Not currently used.

ROUT02   Not currently used.

SQRT3 $\sqrt{3}$: Set by routine FULPIN or QTRPIN to be SQRT(3.0).

TDIN $C_{\epsilon, \text{in}}$: Constant [m^{-1}] in equation which relates initial and inlet turbulent kinetic energy dissipation rate to turbulent kinetic energy. Input in NAMELIST DATA.

TIMAX   Case time [s] after which this run will terminate. Input in NAMELIST DATA.

TIME   Current case time [s]. Initialized to TSTART by routine INITAL at the beginning of a run having ISTATE=0 or 2. Incremented by DTIME in routine AMAIN at the beginning of each time step.

TKIN $C_{k, \text{in}}$: Constant in equation which relates initial and inlet turbulent kinetic energy to initial or inlet velocity. Input in NAMELIST DATA.

TREST   Amount of central processor unit time [CPU s] to be reserved at the end of a run to do any final edits and write a restart file. Compared with value returned by routine TLEFTS after every (1) outer iteration in routine TIMSTP and (2) time step in routine AMAIN. Input in NAMELIST DATA.

TSTART Initial case time in this run. Used to initialize TIME in routine INITIAL at ISTATE=0 and 2. Should be input as 0.0 in NAMELIST DATA at ISTATE=0 and 2 and omitted from NAMELIST DATA at other times.

TURBC λ_{t0} : Constant turbulent thermal conductivity [$\text{W}/\text{m}^2 \cdot ^\circ\text{C}$]. Input in NAMELIST DATA.

TURBCO λ_t : Turbulent thermal conductivity [$\text{W}/\text{m}^2 \cdot ^\circ\text{C}$]. Initially set to TURBC in routine INITIAL; overridden by other values if ITURKE > 0.

TURBV μ_{t0} : Constant turbulent viscosity [$\text{Pa} \cdot \text{s}$]. Input in NAMELIST DATA.

VELMAX Maximum fluid speed [m/s]. Set by routine GDCONV.

WALLCL Clearance [m] between fuel pin and duct wall in hexagonal fuel assembly model. Input in NAMELIST GEOM.

WIREP P_w : Pitch [m] of wire wrap on pins in hexagonal fuel assembly model. Sign of WIREP indicates direction of spiral when looking in the negative z direction: >0 is counter clockwise and <0 is clockwise. Input in NAMELIST GEOM.

WODIN $d_{w,in}$: Diameter [m] of wire wrap on pins in interior of hexagonal fuel assembly model. Input in NAMELIST GEOM.

WODOUT $d_{w,out}$: Diameter [m] of wire wrap on pins adjacent to wall in hexagonal fuel assembly model. Input in NAMELIST GEOM.

XMAXX Set to $X(\text{IMAX}) + 0.5 \cdot \text{DX}(\text{IMAX})$ by routine BOXES, FULPIN, or QTRPIN and only used within these routines.

YMAXX Set to $Y(JMAX)+0.5*DY(JMAX)$ by routine FULPIN or QTRPIN and only used within these routines.

ZAT0 z_0 : Axial position [m] at which wire wrap on pins is positioned along the positive x axis relative to the pin center in the hexagonal fuel assembly model. Input in NAMELIST GEOM.

ZMAXX Set to $Z(KMAX)+0.5*DZ(KMAX)$ by routine BOXES, FULPIN, or QTRPIN and only used within these routines.

4.3 COMMON BLOCK /I4ARY/

This common block contains integer array variables. The declaration statement defining the storage order is given by

```
COMMON /I4ARY /      LCX (99),LCY (99),LCZ (99),  
1 LCI (99),KFLOW (99),KTEMP (99),KPRES (99),MATWAL(99),  
2 IHTWAL(99),LBS (99),LES (99),NTHPR (50),NTPRNT(51),  
3 ISTPR (50),NTHCON(11),NLAST (25),NEND (25),KPROP (99),IT(2),  
A KRADTS(1),INDTRO(PNSTRU),INDTRI(PNSTRU),NOHTX(PIFHTX),IBCFS(10),  
4 NTPLOT(26),NREBM (99),NREBX (99),NREBY (99),NREBZ (99),  
5 IMREB(99,4),NREBRS(5),MPIN (19),MWIRE(50,19),I4AEND
```

This declaration statement is part of code module SHARED at ANL. The definitions of these variables are as follows.

I4AEND Last variable in COMMON BLOCK /I4ARY/. Value is irrelevant. Storage location is only referenced in connection with calculating the length of the common block.

IBCFS (10) Fluid cell number which is adjacent to the i^{th} Boundary Surface which is using the expansion-cell velocity boundary condition, where i is the array index. Set by routine INITA2.

IHTWAL(99) Element n of this array is the heat transfer correlation index number to be used between boundary surface n and the adjacent fluid cell, where $1 \leq n \leq \text{NSURF}$. Input in NAMELIST DATA. Values must be in range $0 \leq \text{IHTWAL}(n) \leq \text{NHEATC}$ for basic forms and $51 \leq \text{IHTWAL}(n) \leq 99$ for user-coded forms. CAUTION: Array element IHTWAL(99) is also currently used to hold the flag which indicates the type of numerical approximation employed for heat flux between thermal structures and fluid; key values: 0: old; 1: better; 2: best.

IMREB (99,4) Index offsets within cell-number array MREB (which is stored in COMMON BLOCK /SPACE/) for use in the user-specified mass rebalancing model. Filled in routine IREBAL such that MREB(IMREB(n,m))) has the following meanings:

- ($n,1$): first fluid cell number in rebalancing region number n ;
- ($n,2$): first fluid cell number whose +I face is part of rebalancing surface number n ;
- ($n,3$): first fluid cell number whose +J face is part of rebalancing surface number n ;
- ($n,4$): first fluid cell number whose +K face is part of rebalancing surface number n ;

INDTRI(PNSTRU) Element n is the radiation surface number to which the inner surface of the n^{th} thermal structure belongs, where $n \leq \text{NSTRUC}$. Array is filled by routine INPSTR based on the values input for KRAD in NAMELISTs M. Values are in the range $0 \leq \text{INDTRI}(n) \leq \text{NRAD}$.

INDTRO(PNSTRU) Element n is the radiation surface number to which the outer surface of the n^{th} thermal structure belongs, where $n \leq \text{NSTRUC}$. Array is filled by routine INPSTR based on the values input for KRAD in NAMELISTs M. Values are in the range $0 \leq \text{INDTRO}(n) \leq \text{NRAD}$.

ISTPR (50) Indicates which planes of which variables or which thermal structures are to be printed on the first call to routine OUTPUT in a run having ISTATE=0 or 2 (i.e at t=0). Meanings of values are same as for array NTHPR. Input in NAMELIST DATA.

IT (2) Maximum number of outer iterations allowed. Array elements are as follows:

(1): Value used through time step number LASTIT.

(2): Value used after time step number LASTIT.

KFLOW (99) Element n is the type of velocity boundary condition for boundary surface number n, where $1 \leq n \leq \text{NSURF}$. Input in NAMELIST DATA. Key values: -6: expansion cell; -5: continuative mass flow; -4: uniform velocity; -3: free slip; -2: continuative velocity; -1: continuative mass flux; 1: constant; 100+nf: specified using transient function number nf; 200+nf: specified using transient function number nf and temperature of radiation surface number nf.

KPRES (99) Element n is the type of pressure boundary condition for boundary surface number n, where $1 \leq n \leq \text{NSURF}$. Input in NAMELIST DATA. Key values: 0: not specified; 1: constant; 100+nf: specified using transient function number nf. $\text{KPRES}(n) > 0$ is only allowed on boundary surfaces having $\text{KFLOW}(n) = -6, -5, -2, \text{ or } -1$.

KPROP (99) Element n is the fluid number adjacent to boundary surface number n, where $1 \leq n \leq \text{NSURF}$. Input in NAMELIST DATA. Values must be in range $1 \leq \text{KPROP}(n) \leq \text{IFHTX}$.

KRADTS(1) Not currently used.

KTEMP (99) Element n is the type of fluid energy boundary condition for boundary surface number n, where $1 \leq n \leq \text{NSURF}$. Input in NAMELIST DATA.

Key values: 1: constant temperature; 100+nf: temperature specified using transient function number nf; 200: constant heat flux; 300+nf: heat flux specified using transient function number nf; 400: adiabatic; 500+nf: duct wall with heat source from transient function number nf; 600+m: recirculation temperature from boundary surface m.

- LBS (99) Not currently used.
- LCI (99) Indexing array associating boundary surfaces with boundary surface elements. IREGular boundary surface number N, for $N=1,2,\dots,NSURF$, is composed of boundary surface element numbers $LCI(N-1)+1$ (or 1 for $N=1$) through $LCI(N)$. Set in routine BOXES, FULPIN, or QTRPIN.
- LCX (99) Indexing array associating boundary surfaces with boundary surface elements. REGular boundary surface number N, for $N=1,2,\dots,NSURF$, having its unit surface-normal vector pointing in the $\pm I$ direction is composed of boundary surface element numbers $LCZ(N-1)+1$ (or $LCI(NSURF)+1$ for $N=1$) through $LCX(N)$. Set in routine BOXES, FULPIN, or QTRPIN. Other logic in the program requires that this be the first item in COMMON BLOCK /I4ARY/.
- LCY (99) Indexing array associating boundary surfaces with boundary surface elements. REGular boundary surface number N, for $N=1,2,\dots,NSURF$, having its unit surface-normal vector pointing in the $\pm J$ direction is composed of boundary surface element numbers $LCX(N)+1$ through $LCY(N)$. Set in routine BOXES, FULPIN, or QTRPIN.
- LCZ (99) Indexing array associating boundary surfaces with boundary surface elements. REGular boundary surface number N, for $N=1,2,\dots,NSURF$, having its unit surface-normal vector pointing in the $\pm K$ direction is composed of boundary surface element numbers $LCY(N)+1$ through $LCZ(N)$. Set in routine BOXES, FULPIN, or QTRPIN.

- LES (99) Not currently used.
- MATWAL(99) Element n is the structure material number of wall for boundary surface number n , where $1 \leq n \leq \text{NSURF}$. Input in NAMELIST DATA. Values are in the range $0 \leq \text{MATWAL}(n) \leq \text{NMATER}$. If $\text{KTEMP}(n) = 500 + n_f$ then must have $\text{MATWAL}(n) > 0$.
- MPIN (19) Element n is the fluid cell number in the $K=1$ plane which is adjacent to the lower-left quarter of fuel pin number n in the hexagonal fuel assembly model when $\text{IPART}=0$. Filled in routine QTRPIN at the beginning of a run having $\text{ISTATE}=0$; used in routine INTWIR. (BUG: This array should be dimensioned dynamically based on IGEOM, rather than having a fixed dimension.)
- MWIRE (50,19) Element (k,n) is the fluid cell number in K -plane number k in which the centroid of the wire wrap for fuel pin number n is located in the hexagonal fuel assembly model when $\text{IWIRE}=2$. Set and printed in routine INTWIR; not used otherwise. (BUG: This array should be dimensioned dynamically based on IGEOM and KMAX, rather than having fixed dimensions.)
- NEND (25) Pointer array associated with transient functions. As input in NAMELIST DATA, element n is the number of pairs of data in arrays TVAL and FVAL used to define transient function number n . During input processing, routine INITAL alters these values such that element n becomes the total number of data pairs used to define transient functions number 1 through number n . A 0 in element n indicates that there are only $n-1$ transient functions.
- NLAST (25) Element n indicates the coefficient set number which was used the last time that transient function number n was evaluated. Updated by routine GETF on each call. Value used to be used to start the search process to determine which coefficient set should be used on this call; no longer used to start the search process.

- NOHTX (PIFHTX)**   Element n is the number of cells containing fluid number n , where $1 \leq n \leq \text{IFHTX}$. Set by routine INITA3 based on input in the Fluid Cell Location input block.
- NREBM (99)**   Element n is the number of fluid cells in user-defined mass rebalancing region number n , where $n \leq \text{NREBRT}$. Input in NAMELIST DATA.
- NREBRS(5)**   Future allowance for multipass mass rebalancing. Although this is in NAMELIST DATA, the user should not input any values.
- NREBX (99)**   Element n is the number of x (or r)-direction cell faces forming rebalancing surface n , where $n \leq \text{NREBRT}$. Input in NAMELIST DATA.
- NREBY (99)**   Element n is the number of y (or θ)-direction cell faces forming rebalancing surface n , where $n \leq \text{NREBRT}$. Input in NAMELIST DATA.
- NREBZ (99)**   Element n is the number of z -direction cell faces forming rebalancing surface n , where $n \leq \text{NREBRT}$. Input in NAMELIST DATA.
- NTHCON(11)**   List of time step numbers at which routine GDCONV is to be called to calculate (1) the time step size under IDTIME=1 and (2) the convergence criteria variables DCONV and VELMAX. Input in NAMELIST DATA. Key values: <0: time step frequency; =0: end of array; >0: time step number.
- NTHPR (50)**   Indicates which geometrical groupings of which variables are to be printed by routine OUTPUT on all calls to routine OUTPUT except the first call in an ISTATE=0 or 2 run (which is governed by the list in array ISTPR). Input in NAMELIST DATA. Values are signed 5-digit integers having one of three forms: (1) $\pm 8\text{NNNN}$: print thermal structure number NNNN; (2) $\pm 9\text{VVLL}$: print variable code number VV (01=VELBN, 02=QBN, 03=MB, 04=HLB,

05=TLB, 06=AREA, 07=RLB, 08=PB, 09=IJK, 10=surface heat transfer coefficient, 11=TURKB, and 12=TKEDB) for boundary surface number LL; (3) $\pm$ VVPLL: print variable code number VV (01=UL, 02=VL, 03=WL, 04=HL, 05=TL, 06=AL, 07=RL, 08=P+PSTAT0, 09=DL, 10=ALX, 11=ALY, 12=ALZ, 13=DRDT, 14=TURK, 15=QSOUR, 16=PSTAT0, 17=P, 18=DDDPOT, 19=DDDH, 20=TURCON, 21=TURVIS, and 22=TKED) for all cells or cell faces in plane number LL ($\leq$ IMAX, JMAX, or KMAX) of plane type P (1=I, 2=J, and 3=K). A positive value prints only the specified cell plane, boundary surface, or thermal structure; a negative value prints (inclusively) all cell planes, boundary surfaces, or thermal structures between the one specified by this value and the one specified by the next value in the array. A value of 0 indicates the end of this array.

NTPLOT(26) List of time step numbers at which routine PLTAPE is called to write information to the binary-format plot file. Input in NAMELIST DATA. Key values: <0: time step frequency; =0: end of array; >0 time step number.

NTPRNT(51) List of time step numbers at which routine OUTPUT is called to print the variables indicated in arrays ISTPR and NTHPR. Input in NAMELIST DATA. Key values: <0: time step frequency; =0: end of array; >0: time step number.

4.4 COMMON BLOCK /R4ARY/

This common block contains real number array variables. (In some earlier versions of COMMIX, these array variables were declared to be REAL*4 on short word machines, thus the "4" in the block name; the current practice in COMMIX-1AR/P is for all real number variables to be declared DOUBLE PRECISION on short-word machines.) The declaration statement defining the storage order is given by

```

COMMON /R4ARY /      GRAVR (99),GRAVTH(99),TEMP (99),
1 VELOC (99),XNORML(99),YNORML(99),ZNORML(99),PRES (99),
2 HYDWAL(99),WALLDX(99),WALLQS(99),TSINK (99),HSINK (99),
3 TPRNT (51),TVAL (100),FVAL (100),YCOEF(100),CCOEF(100,3),
4 TEMP0(PIFHTX), PRES0(PIFHTX), DENSE0(PIFHTX),
5 XPRES0(PIFHTX), YPRES0(PIFHTX), ZPRES0(PIFHTX),
6 FC0K(PIFHTX), FC1K(PIFHTX), FC0MU(PIFHTX), FC1MU(PIFHTX),
7 FC0H(PIFHTX), FC1H(PIFHTX), FC0RO(PIFHTX), FC1RO(PIFHTX),
8 FC0T(PIFHTX), FC1T(PIFHTX), GASMW(PIFHTX), FC0HR(PIFHTX),
A AREATR(PNRAD),TROD(PNRAD),QFLUID(2*PNSTRU),QSOLID(PNSTRU),
B QROLD(PNRAD),FVIEW(PNRAD,PNRAD),BCFSIN(10,4),PINPOW(1),
4 EMITS(PNRAD),AREATO(PNSTRU),AREATI(PNSTRU),QRNET(PNRAD),C0K(20),
5 C1K (20),C2K (20),C0CP (20),C1CP (20),C2CP (20),
6 C0RO (20),C1RO (20),C2RO (20),QK (99),QJ (10,10),
7 ALXN (10,10),ALYN (10,10),ALZN (10,10),WETLEN(10,10),R4AEND

```

This declaration statement is part of code module SHARED at ANL. The definitions of these variables are as follows.

ALXN (10,10)   Not currently used. (Originally used within the hexagonal fuel assembly model. Although present in NAMELIST GEOM, values should not be input.)

ALYN (10,10)   Not currently used. (Originally used within the hexagonal fuel assembly model. Although present in NAMELIST GEOM, values should not be input.)

ALZN (10,10)   Not currently used. (Originally used within the hexagonal fuel assembly model. Although present in NAMELIST GEOM, values should not be input.)

AREATI(PNSTRU)   Element n is the total area [m²] of all inner surface elements of thermal structure number n. Set by routine INPSTR.

AREATO(PNSTRU)   Element n is the total area [m²] of all outer surface elements of thermal structure number n. Set by routine INPSTR.

AREATR(PNRAD) Element n is the total area [m^2] of radiation surface number n , where $1 \leq n \leq \text{NRAD}$. Set by routine INPSTR.

BCFSIN(10,4) Element (n,i) stores information of type i for the n -th boundary surface which is utilizing a $\text{KFLOW}=-6$ velocity boundary condition, where the meaning of index i is as follows:

- 1: mass flow [kg] for this time step;
- 2: mass flow [kg] since $t=0$;
- 3: convected enthalpy [J] for this time step;
- 4: convected enthalpy [J] since $t=0$.

Set by routine BCFLOF at end of time step.

COCP (20) C_{0c} : Element n is the 0th-order coefficient [$\text{J/kg} \cdot ^\circ\text{C}$] in the polynomial form for specific heat capacity of structure material number n , where $n \leq \text{NMATER}$. Input in NAMELIST DATA.

COK (20) $C_{0\lambda}$: Element n is the 0th-order coefficient [$\text{W/m} \cdot ^\circ\text{C}$] in the polynomial form for thermal conductivity of structure material number n , where $n \leq \text{NMATER}$. Input in NAMELIST DATA.

CORO (20) $C_{0\rho}$: Element n is the 0th-order coefficient [kg/m^3] in the polynomial form for density of structure material number n , where $n \leq \text{NMATER}$. Input in NAMELIST DATA.

C1CP (20) C_{1c} : Element n is the 1st-order coefficient [$\text{J/kg} \cdot ^\circ\text{C}^2$] in the polynomial form for specific heat capacity of structure material number n , where $n \leq \text{NMATER}$. Input in NAMELIST DATA.

C1K (20) $C_{1\lambda}$: Element n is the 1st-order coefficient [$\text{W/m} \cdot ^\circ\text{C}^2$] in the polynomial form for thermal conductivity of structure material number n , where $n \leq \text{NMATER}$. Input in NAMELIST DATA.

C1RO (20) $C_{1\rho}$: Element n is the 1st-order coefficient [$\text{kg}/\text{m}^3 \cdot ^\circ\text{C}$] in the polynomial form for density of structure material number n , where $n \leq \text{NMATER}$. Input in NAMELIST DATA.

C2CP (20) C_{2c} : Element n is the 2nd-order coefficient [$\text{J}/\text{kg} \cdot ^\circ\text{C}^3$] in the polynomial form for specific heat capacity of structure material number n , where $n \leq \text{NMATER}$. Input in NAMELIST DATA.

C2K (20) $C_{2\lambda}$: Element n is the 2nd-order coefficient [$\text{W}/\text{m} \cdot ^\circ\text{C}^3$] in the polynomial form for the thermal conductivity of structure material number n , where $n \leq \text{NMATER}$. Input in NAMELIST DATA.

C2RO (20) $C_{2\rho}$: Element n is the 2nd-order coefficient [$\text{kg}/\text{m}^3 \cdot ^\circ\text{C}^2$] in the polynomial form for density of structure material number n , where $n \leq \text{NMATER}$. Input in NAMELIST DATA.

CCOEF (100,3) Coefficients in polynomial representations of transient functions. Computed in routine FITIT based on values input using arrays TVAL, FVAL, and NEND in NAMELIST DATA. When $\text{TVAL}(i) < t < \text{TVAL}(i+1)$, the transient function value is computed (in routine GETF) from

$$f(t) = ((\text{CCOEF}(i,3) \cdot (t - \text{TVAL}(i)) + \text{CCOEF}(i,2)) \cdot (t - \text{TVAL}(i)) + \text{CCOEF}(i,1)) \cdot (t - \text{TVAL}(i)) + \text{YCOEF}(i))$$

The first $\text{NEND}(1)$ entries in arrays TVAL, FVAL, YCOEF, and CCOEF are for transient function number 1; entries $\text{NEND}(1)+1$ through $\text{NEND}(2)$ are for transient function number 2; etc.

DENSE0(PIFHTX) ρ_{ref} : Element n is the reference density [kg/m^3] for fluid number n , where $n \leq \text{IFHTX}$, and is computed at temperature $\text{TEMPO}(n)$ and pressure $\text{PRES0}(n)$ from the appropriate equation of state by routine INITAL.

EMITS (PNRAD) ε : Element n is the emissivity of radiation surface number n , $n \leq \text{NRAD}$. Input in NAMELIST DATA.

FC0H (PIFHTX) C_{0h} : Element n is the 0th-order coefficient [J/kg] in the "simplified" properties enthalpy expression for fluid number n , where $n \leq \text{IFHTX}$. Input in NAMELIST DATA.

FC0HR (PIFHTX)   Element n is $d\rho/dh$ [$\text{kg}^2/\text{m}^3 \cdot \text{J}$] in the simplified properties for fluid number n . Computed in routine INITA3 based on values input for the coefficients used in the density and enthalpy functions. (Note: The term $d\rho/dh$ is a function of temperature and pressure, rather than being constant, when $\text{GASMW}(n) > 0$ and is computed as needed.)

FC0K (PIFHTX) C_{0k} : Element n is the 0th-order coefficient [$\text{W}/\text{m} \cdot ^\circ\text{C}$] in the simplified properties thermal conductivity expression for fluid number n , where $n \leq \text{IFHTX}$. Input in NAMELIST DATA.

FC0MU (PIFHTX) $C_{0\mu}$: Element n is the 0th-order coefficient [$\text{Pa} \cdot \text{s}$] in the simplified properties laminar viscosity expression for fluid number n , where $n \leq \text{IFHTX}$. Input in NAMELIST DATA.

FC0RO (PIFHTX) $C_{0\rho}$: Element n is the 0th-order coefficient [kg/m^3] in the simplified properties linear density expression for fluid number n , where $n \leq \text{IFHTX}$. Input in NAMELIST DATA. If $\text{FC0RO}(n) = 0$, then the ideal-gas-law density expression will be used for fluid number n and $\text{GASMW}(n)$ must be nonzero.

FC0T (PIFHTX)   Element n is the 0th-order coefficient [$^\circ\text{C}$] in the simplified properties temperature expression for fluid number n , where $n \leq \text{IFHTX}$. Computed by routine INITA3 based on values input for $\text{FC0H}(n)$ and $\text{FC1H}(n)$ in NAMELIST DATA.

FC1H (PIFHTX) C_{1h} : Element n is the first-order coefficient [$\text{J}/\text{kg} \cdot ^\circ\text{C}$] in the simplified properties enthalpy function for fluid number n , where $n \leq \text{IFHTX}$. Input in NAMELIST DATA.

FC1K (PIFHTX) C_{1k} : Element n is the first-order coefficient [$\text{W/m} \cdot ^\circ\text{C}^2$] in the simplified thermal conductivity expression for fluid number n , where $n \leq \text{IFHTX}$. Input in NAMELIST DATA.

FC1MU (PIFHTX) $C_{1\mu}$: Element n is the first-order coefficient [$\text{Pa} \cdot \text{s}/^\circ\text{C}$] in the simplified properties laminar viscosity expression for fluid number n , where $n \leq \text{IFHTX}$. Input in NAMELIST DATA.

FC1RO (PIFHTX) $C_{1\rho}$: Element n is the first-order coefficient [$\text{kg/m}^3 \cdot ^\circ\text{C}$] in the simplified properties linear density expression for fluid number n , where $n \leq \text{IFHTX}$. Input in NAMELIST DATA.

FC1T (PIFHTX) Element n is the first-order coefficient [$^\circ\text{C} \cdot \text{kg/J}$] in the simplified properties temperature function for fluid number n , where $n \leq \text{IFHTX}$. Computed by routine INITA3 based on values input for FC0H(n) and FC1H(n) in NAMELIST DATA.

FVAL (100) Element n is the value of the transient function at TVAL(n). Input in NAMELIST DATA. See array NEND in COMMON BLOCK /I4ARY/ for information on indexing of transient functions.

FVIEW (PNRAD,PNRAD) F : Element (n,m) is the view factor for radiation heat transfer from radiation surface n to radiation surface m (i.e. the fraction of the radiant energy leaving radiation surface n which arrives at radiation surface m), where $m \leq \text{NRAD}$ and $n \leq \text{NRAD}$. Input in NAMELIST DATA.

GASMW (PIFHTX) $C_{1\rho}$: Element n is molecular weight [kg/kg-mole] used in the simplified properties ideal-gas-law density function for fluid number n , $n \leq \text{IFHTX}$. Input in NAMELIST DATA. To use the ideal-gas-law density for fluid number n , input FC0RO(n)=0 and GASMW(n)>0.

GRAVR (99) g_r : Element j is the r -direction component of the gravitational acceleration vector [m/s^2] for fluid cells having the second spatial position index j , $1 \leq j \leq \text{JMAX}$, when $\text{IGEOM} = -1$. Computed in routine **INITAL** based on input values of **GRAVX** and **GRAVY**. Other logic in the program requires this to be the first item in **COMMON BLOCK /R4VAR/**.

GRAVTH(99) g_θ : Element j is the θ -direction component of the gravitational acceleration vector [m/s^2] for fluid cells having the second spatial position index j , for $1 \leq j \leq \text{JMAX}$, when $\text{IGEOM} = -1$. Computed in routine **INITAL** based on input values of **GRAVX** and **GRAVY**.

HSINK (99) U_s : Element n is the boundary-surface-to-sink heat transfer coefficient [$\text{W/m}^2 \cdot ^\circ\text{C}$] for boundary surface n , for $1 \leq n \leq \text{NSURF}$; only used for boundary surfaces having $\text{KTEMP} = 500 + \text{nf}$. Input in **NAMELIST DATA**.

HYDWAL(99) D_h : Element n is the characteristic length [m] used in the fluid-to-boundary-surface heat transfer coefficient correlation for boundary surface n , where $1 \leq n \leq \text{NSURF}$, when $\text{IHTWAL}(n) \neq 0$. Input in **NAMELIST DATA**.

PINPOW(1) Not currently used. (Input in **NAMELIST INPUTQ**.)

PRES (99) P_{b0} : Element n [Pa] is used in connection with the "specified" pressure boundary condition for boundary surface n , where $1 \leq n \leq \text{NSURF}$; when $\text{KPRES}(n) = 1$, **PRES**(n) is the pressure; when $\text{KPRES}(n) = 100 + \text{nf}$, the pressure is **PRES**(n) $\cdot f_{\text{nf}}(t)$, where $f_{\text{nf}}(t)$ is the value of transient function number nf at time t . Input in **NAMELIST DATA**.

PRES0 (PIFHTX) P_{ref} : Element n is the reference pressure [Pa] at Cartesian-coordinate position (**XPRES0**(n), **YPRES0**(n), **ZPRES0**(n)) for fluid number r , for $1 \leq n \leq \text{IFHTX}$. Input in **NAMELIST DATA**. Used by routine **INITAL** to fill array **PSTAT0**.

QFLUID(2*PNSTRU) Net heat transfer rate [W] from thermal structure to fluid; element n is for the outer surface of thermal structure n , and element $2*n$ is for the inner surface of thermal structure n . Computed by routine QSTRUC; only used in connection with printing thermal structure results in routine OUTPUT.

QIJ (10,10) Element (i,j) is the relative power distribution for fluid cells having the first spatial location index i , for $1 \leq i \leq \text{IMAX}$, and the second spatial location index j , for $1 \leq j \leq \text{JMAX}$; used in conjunction with (1) arrays WALLQS and QK for heat source in the boundary surface adjacent to the fluid cell and (2) variable QSCOOOL and array QK for direct heat source in the fluid cell (including the hexagonal fuel assembly model). Input in NAMELIST INPUTQ.

QK (99) Element m is the relative power distribution at spatial location index m . The meaning of m depends on the model section: (1) for direct heat source to coolant (using variable QSCOOOL) and heat source in a boundary surface (using variable WALLQS), m is the third spatial location index k , $1 \leq k \leq \text{KMAX}$; (2) for heat sources in thermal structures (using variable Q), the right-most digit of IXYZ (either 1, 2, or 3) as input in NAMELIST T specifies which spatial location index (first ($1 \leq i \leq \text{IMAX}$), second ($1 \leq j \leq \text{JMAX}$), or third ($1 \leq k \leq \text{KMAX}$)) is used for index m in array QK. Input in NAMELIST DATA or INPUTQ.

QRNET (PNRAD) q_r : Element n is the net radiation heat transfer rate to radiation surface n , for $1 \leq n \leq \text{NRAD}$. Computed in routine QSRAD at the end of a fully converged time step.

QROLD (PNRAD) Same as array QRNET except the values are for the previous time step. Array is filled from array QRNET in routine QSRAD before computing new values for QRNET.

QSOLID(PNSTRU) Element n is the net rate of energy storage in thermal structure n .

Computed in routine TSTRUC; only used for printing thermal structure results in routine OUTPUT.

R4AEND Last variable in COMMON BLOCK /R4ARY/. Value is irrelevant. Storage location is only referenced in connection with calculating the length of the common block.

TEMP (99) T_{bo} or q_{bo} : Element n is used to set energy boundary conditions for boundary surface n , where $n \leq \text{NSURF}$. Meaning depends on $\text{KTEMP}(n)$: (1) for $\text{KTEMP}(n)=1$, $\text{TEMP}(n)$ is the temperature [$^{\circ}\text{C}$]; (2) for $\text{KTEMP}(n)=100+nf$, the temperature [$^{\circ}\text{C}$] is $\text{TEMP}(n)*f_{nf}(t)$; (3) for $\text{KTEMP}(n)=200$, $\text{TEMP}(n)$ is the heat flux [W/m^2]; (4) for $\text{KTEMP}(n)=300+nf$, the heat flux [W/m^2] is $\text{TEMP}(n)*f_{nf}(t)$; (5) for $\text{KTEMP} \geq 400$, $\text{TEMP}(n)$ is not used. (In the preceding, $f_{nf}(t)$ is the value of transient function number nf at time t .) Input in NAMELIST DATA.

TEMPO (PIFHTX) T_{ref} : Element n is the initial reference temperature [$^{\circ}\text{C}$] for fluid number n , $1 \leq n \leq \text{NSURF}$. Input in NAMELIST DATA.

TPRNT (51) List of case times [s] at which routine OUTPUT is to be called to produce printed output; the routine is called when the case time equals or first exceeds the times specified in this array; the time step size is not adjusted to hit a print time exactly. Input in NAMELIST DATA. Key values: $\text{TPRNT}(n) < 0.0$: call OUTPUT at times which are an integral multiple of $|\text{TPRNT}(n)|$ and are at (or after) time $\text{TPRNT}(n+1)$ for the rest of the case; $\text{TPRNT}(n)=0.0$: end of array; $\text{TPRNT}(n) > 0.0$: call OUTPUT at (or after) time $\text{TPRNT}(n)$ and the call after this one is governed by $\text{TPRNT}(n+1)$.

TROD (PNRAD) T_r : Element n is the temperature [$^{\circ}\text{C}$] of radiation surface number n , for $1 \leq n \leq \text{NRAD}$. Computed by routine TSTRUC.

- TSINK (99)** T_s : Element n is the sink temperature [$^{\circ}\text{C}$] (on the nonfluid side) for boundary surface n , for $n \leq \text{NSURF}$, when $\text{KTEMP}(n) = 500 + \text{nf}$. Input in NAMELIST DATA.
- TVAL (100)** Element n is the value of the independent variable at which the transient function has the value $\text{FVAL}(n)$. (The independent variable is the temperature [$^{\circ}\text{C}$] of radiation surface nf for $\text{KFLOW} = 200 + \text{nf}$ and is time [s] for all other transient functions.) Input in NAMELIST DATA. The first $\text{NEND}(1)$ values are for transient function number 1; values $\text{NEND}(1) + 1$ through $\text{NEND}(2)$ are for transient function number 2, etc.
- VELOC (99)** u_{n0} : Element m is used to set the velocity in the direction of the unit surface normal vector for boundary surface m , where $m \leq \text{NSURF}$; for $\text{KFLOW}(m) = 1$, $\text{VELOC}(m)$ is the velocity [m/s]; for $\text{KFLOW}(m) = 100 + \text{nf}$ or $200 + \text{nf}$, the velocity [m/s] is $\text{VELOC}(m) * f_{\text{nf}}(x)$, where $f_{\text{nf}}(x)$ is the value of transient function nf at time $x = t$ or temperature $x = \text{TROD}(\text{nf})$; for other $\text{KFLOW}(m)$ values, $\text{VELOC}(m)$ is not used. Input in NAMELIST DATA.
- WALLDX(99)** L_w : Element n is the wall thickness [m] for boundary surface n , $n \leq \text{NSURF}$. Input in NAMELIST DATA. Required when $\text{KTEMP}(n) = 500 + \text{nf}$; optional when $\text{KTEMP}(n) < 400$; not used for $\text{KTEMP}(n) = 400$ or $600 + \text{nss}$.
- WALLQS(99)** q'''_{w0} : Element n is the reference heat source [W/m^3] in boundary surface n , $n \leq \text{NSURF}$, when $\text{KTEMP}(n) = 500 + \text{nf}$. Input in NAMELIST DATA. Used in conjunction with arrays $\text{QIJ}(i,j)$ and $\text{QK}(k)$ and transient function number nf .
- WETLEN(10,10)** Element (i,j) is the wetted perimeter (due to fuel pins, assembly wall, etc.) for the fluid cell having spatial location indices $I=i$ and $J=j$ for the hexagonal fuel assembly model. Computed in routine FULPIN or QTRPIN. (BUG: This array should be dimensioned dynamically based on IGEOM and

IPART, rather than having fixed dimensions.)

XNORML(99) n_x or n_r : Element n is the component in the first spatial coordinate direction (x or r) of the unit surface normal vector (points toward the fluid) for boundary surface number n , where $1 \leq n \leq \text{NSURF}$. Input in NAMELIST GEOM. Must be in range $-1 \leq \text{XNORML}(n) \leq 1$.

XPRES0(PIFHTX) x_{ref} : Element n is the x coordinate [m] of the position at which the reference pressure $\text{PRES0}(n)$ is specified for fluid number n , for $1 \leq n \leq \text{IFHTX}$. Input in NAMELIST DATA.

YCOEF (100)   Values of the zeroth-order coefficient in the transient function range covering the independent variable range $\text{TVAL}(i)$ through $\text{TVAL}(i+1)$. Computed by routine FITIT. The first $\text{NEND}(1)$ values are for transient function number 1; values $\text{NEND}(1)+1$ through $\text{NEND}(2)$ are for transient function number 2; etc. See array CCOEF in this section for further information.

YNORML(99) n_y or n_θ : Element n is the component in the second spatial coordinate direction (y or θ) of the unit surface normal vector (points toward the fluid) for boundary surface number n , where $1 \leq n \leq \text{NSURF}$. Input in NAMELIST GEOM. Must be in range $-1 \leq \text{YNORML}(n) \leq 1$.

YPRES0(PIFHTX) y_{ref} : Element n is the y coordinate [m] of the position at which the reference pressure $\text{PRES0}(n)$ is specified for fluid number n , for $1 \leq n \leq \text{IFHTX}$. Input in NAMELIST DATA.

ZNORML(99) n_z : Element n is the component in the third spatial coordinate direction (z) of the unit surface normal vector (points toward the fluid) for boundary surface number n , where $1 \leq n \leq \text{NSURF}$. Input in NAMELIST GEOM. Must be in range $-1 \leq \text{ZNORML}(n) \leq 1$.

ZPRES0(PIFHTX) z_{ref} : Element n is the z coordinate [m] of the position at which the reference pressure PRES0(n) is specified for fluid number n, for $1 \leq n \leq \text{IFHTX}$.
Input in NAMELIST DATA.

4.5 COMMON BLOCK /R8ARY/

This common block contains real number arrays and a few simple real number variables. (In some earlier versions of COMMIX, these were the only real number variables declared to be REAL*8 on short-word machines, thus the "8" in the block name; the current practice in COMMIX-1AR/P is for all real number variables to be DOUBLE PRECISION on short-word machines.) The declaration statement defining the storage order is given by

```
COMMON /R8ARY /      DX  (99),DY  (99),DZ  (99),
1 X  (99),Y  (99),Z  (99),DT  ( 4),TIME8, DTIME8,R8AEND
```

This declaration statement is par. of code module SHARED at ANL. The definitions of these variables are as follows.

DT (4)   Array of time step size [s] information. Input in NAMELIST DATA. Array elements are defined as follows:

- (1): Δt_1 : time step size through step number LASTDT.
- (2): Δt_2 : time step size after step number LASTDT; also holds current time step size when IDTIME=2 and ITAUTO=1.
- (3): Δt_{min} : minimum time step size allowed when IDTIME=2.
- (4): Δt_{max} : maximum time step size allowed when IDTIME=2.

DTIME8 Δt : Current time step size [s]. (Same value as stored in variable DTIME in COMMON BLOCK /R4VAR/.) Set by routine AMAIN.

DX (99) Δx_i or Δr_i : Width [m] in first spatial coordinate direction of main control volume identified by spatial location indices (i,j,k). Array is indexed by

first spatial location index i , for $1 \leq i \leq \text{IMAX}$. Input in NAMELIST GEOM for $\text{IGEOM} \leq 0$; calculated by QTRPIN or FULPIN for $\text{IGEOM} > 0$. Other logic in the program requires this to be the first item in COMMON BLOCK /R8ARY/.

DY (99) Δy_j or $\Delta \theta_j$: Width [m or radian] in second spatial coordinate direction of main control volume identified by spatial location indices (i,j,k) . Array is indexed by second spatial location index j , for $1 \leq j \leq \text{JMAX}$. Input in NAMELIST GEOM for $\text{IGEOM} \leq 0$; calculated by QTRPIN or FULPIN for $\text{IGEOM} > 0$.

DZ (99) Δz_k : Width [m] in third spatial coordinate direction of main control volume identified by spatial location indices (i,j,k) . Array is indexed by third spatial location index k , for $1 \leq k \leq \text{KMAX}$. Input in NAMELIST GEOM.

R8AEND Last variable in COMMON BLOCK /R8ARY/. Value is irrelevant. Storage location is only referenced in connection with calculating the length of the common block.

TIME8 t : Current case time [s]. (Same value as stored in variable TIME in COMMON BLOCK /R4VAR/.) Set by routine AMAIN.

X (99) x_i or r_i : First spatial position coordinate [m] of center of main control volume identified by spatial location indices (i,j,k) . Array is indexed by first spatial location index i , for $1 \leq i \leq \text{IMAX}$. Computed by routine BOXES, FULPIN, or QTRPIN to be

$$X(I) = 0.5 * DX(I) \text{ for } I=1$$

$$X(I) = X(I-1) + 0.5 * (DX(I-1) + DX(I)) \text{ for } I=2,3,\dots,\text{IMAX}$$

Y (99) y_j or θ_j : Second spatial position coordinate [m or radian] of center of main control volume identified by spatial location indices (i,j,k) . Array is indexed by second spatial location index j , for $1 \leq j \leq \text{JMAX}$. Computed by routine BOXES, FULPIN, or QTRPIN to be

$$Y(J) = 0.5*DY(J) \text{ for } J=1$$

$$Y(J) = Y(J-1)+0.5*(DY(J-1)+DY(J)) \text{ for } J=2,3,\dots,JMAX$$

Z (99) z_k : Third spatial position coordinate [m] of center of main control volume identified by spatial location indices (i,j,k). Array is indexed by third spatial location index k, for $1 \leq k \leq KMAX$. Computed by routine BOXES, FULPIN, or QTRPIN to be

$$Z(K) = 0.5*DZ(K) \text{ for } K=1$$

$$Z(K) = Z(K-1)+0.5*(DZ(K-1)+DZ(K)) \text{ for } K=2,3,\dots,KMAX$$

4.6 COMMON BLOCK /ADDCON/

This common block contains integer variables. The declaration statement defining the storage order is given by

COMMON /ADDCON/ IS(250),LBL1,LBL2,LBL3,LBL4,LBL5,LBL6,LBL7

This declaration statement is code module ADDCON at ANL. The block contains storage pointers and block lengths on the restart file. Brief definitions follow; further specifics are described under COMMON BLOCK /SPACE/ (Sec. 4.7).

IS(250) Element n points to the beginning storage position of the array identified by index number n within array S in COMMON BLOCK /SPACE/, for $1 \leq n \leq 179$. Element number 250 is the total length of storage, in units of computer words, needed for COMMON BLOCK /SPACE/ for this computer run. These array elements are set by the main program at the beginning of a computer run. Elements 180 through 249 are reserved for future array allocations. The correspondence between the index n and the actual array which is stored beginning at location S(IS(n)) in COMMON BLOCK /SPACE/ is shown by the following listing.

<u>n</u>	<u>S(IS(n))</u>	<u>n</u>	<u>S(IS(n))</u>	<u>n</u>	<u>S(IS(n))</u>
1	MIP	2	MIM	3	MJP
4	MJM	5	MKP	6	MKM
7	IJK	8	IDODL#	9	IFORCE
10	MSWEEP#	11	MREB	12	TURKO
13	ALX	14	ALY	15	ALZ
16	AL	17	RL	18	UL
19	VL	20	WL	21	DL
22	HL	23	TL	24	DRDT
25	ARUL	26	ARVL	27	ARWL
28	REALB	29	QSOUR	30	DDDPOT
31	DDDH	32	OARU	33	OARV
34	OARW	35	PSTAT0	36	TURK
37	TURVIS	38	UWIRE	39	VWIRE
40	WWIRE	41	P	42	MB
43	ISURF	44	AREA	45	RLB
46	VELBN	47	QBN	48	HLB
49	TLB	50	PB	51	TURKB
52	ITSCB	53	HYDRA1	54	HYDRA2
55	RODFR	56	STAREA	57	STVOL
58	MATERL	59	HEAT	60	ICORR
61	CLENTH	62	REYLEN	63	FORCEF
64	SIZE	65	ICEL	66	HSTREL
67	AC1	68	AC2	69	AC3
70	AC4	71	AC5	72	AC6
73	AC0	74	BC0	75	DUMMY1
76	TURCON	77	TTS	78	INDHTX
79	EKL	80	EKLOLD	81	TLOLD
82	POLD	83	RLOLD	84	DRDTOL
85	ICELL+	86	JCELL+	87	NMNP+
88	NA+	89	NM+	90	R+
91	P+	92	F+	93	FF+
94	BP0+	95	VOL+	96	AL+
97	AU+	98	A+	99	MIMNv
100	MIPNv	101	MJMNv	102	MJPNv
103	MKMNv	104	MKPNv	105	IREdv
106	TEMP01v	107	TEMP02v	108	TEMP03v
109	TEMP04v	110	M0TOMRw	111	MTOMRw
112	MTOMDw	113	IIw	114	JJw
115	KKw	116	MDTOMRw	117	MIMDw
118	MJMDw	119	MKMDw	120	MIPDw
121	MJPDw	122	MKPDw	123	MRTOMDw
124	IICELw	125	NDGw	126	MINDEXw
127	NMAXw	128	NLw	129	NUw
130	NMMw	131	NAAw	132	FFFw
133	XXXw	134	DDINVw	135	C1w
136	C2w	137	C3w	138	C1Uw

<u>n</u>	<u>S(IS(n))</u>	<u>n</u>	<u>S(IS(n))</u>	<u>n</u>	<u>S(IS(n))</u>
139	C2Uw	140	C3Uw	141	AAw
142	AALw	143	AAUw	144	MIMTS
145	MIPTS	146	MJMTS	147	MJPTS
148	MKMTS	149	MKPTS	150	NIMTS
151	NIPTS	152	NJMTS	153	NJPTS
154	NKMTS	155	NKPTS	156	MIME
157	MIPE	158	MJME	159	MJPE
160	MKME	161	MKPE	162	MTSODD
163	NTSODD	164	SPHODL	165	QNOGHT
166	QPRIME	167	ALNG	168	TKED
169	TKEDO	170	TKEDB	171	BKOLD
172	BDOLD	173	MIMT	174	MIPT
175	MJMT	176	MJPT	177	MKMT
178	MKPT	179	TURVIO		

For index n values of 8,10,16, 25-28, 30-34, 67-74, and 106-109, multiple array names are associated with storage location S(IS(n)); only the primary name is shown in the above list; however, all names are shown in Sec. 4.7. The suffixes used with variable names in the above list have the following meanings: (1) a "+" indicates that the array is only used in the conjugate-gradient-solution routines; some of these names are used for other variables in the rest of the program; (2) a "v" indicates that the array is only used in vectorized versions of the program; (3) a "w" indicates that the array is only used in the vectorized conjugate-gradient-solution routines; (4) a "#" indicates that storage is allocated based on the array containing real numbers (i.e. DOUBLE PRECISION on short-word machines) rather than integer numbers. None of these suffixes are part of the actual variable name; they merely indicate a characteristic of the variable.

LBL1

Length, in units of computer words, of record number 5 on the restart file. This record contains nonoptional arrays, as identified by their IS array index, in the following order ("- " indicates an inclusive range): 75, 1-8, 10, 13-35, 41-50, 78-84. Set by the main program at the beginning of a computer run.

LBL2 Length, in units of computer words, of record number 6 on the restart file. This record contains arrays associated with the force structure model, as identified by their IS array index, in the following order ("- indicates an inclusive range): 9, 60-63. If $NFORCE=0$, then $LBL2=0$, these arrays are not used, and this record is not present on the restart file. Set by the main program at the beginning of a computer run.

LBL3 Length, in units of computer words, of record number 7 on the restart file. This record contains an array associated with the user-specified mass rebalancing model, as identified by its IS array index: 11. If $IFREB=0$, then $LBL3=0$, this array is not used, and this record is not present on the restart file. Set by the main program at the beginning of a computer run.

LBL4 Length, in units of computer words, of record number 8 on the restart file. This record contains arrays associated with the turbulence model, as identified by their IS array index, in the following order ("- indicates an inclusive range): 37, 76, 12, 36, 51, 167, 168-172. If $ITURKE=0$, then $LBL4=0$, these arrays are not used, and this record is not present on the restart file. If $ITURKE>0$, then the number of these arrays actually used and, thus, present on the restart file depends on the value of $ITURKE$: $ITURKE \geq 1$: 37 and 76; $ITURKE \geq 10$: add 12, 36, 51, and 167; $ITURKE \geq 11$: add 168-172. Set by the main program at the beginning of a computer run.

LBL5 Length, in units of computer words, of record number 9 on the restart file. This record contains arrays associated with the wire wrap model, as identified by their IS array index, in the following order ("- indicates an inclusive range): 38-40. If $IWIRE=0$, then $LBL5=0$, these arrays are not used, and this record is not present on the restart file. Set by the main program at the beginning of a computer run.

LBL6   Length, in units of computer words, of record number 10 on the restart file. This record contains arrays associated with the thermal structure model, as identified by their IS array index, in the following order ("- indicates an inclusive range): 52-59, 64-66, 77. If ISTRUC=0, then LBL6=0, these arrays are not used, and this record is not present on the restart file. Set by the main program at the beginning of a computer run.

LBL7   Length, in units of computer words, of the storage block holding temporary arrays; these arrays are not written to the restart file. This block contains implicit solution procedure arrays, as identified by their IS array index, in the following order ("- indicates an inclusive range): 67-74, 85-98, 99-143, 144-155, 156-161, 162-166, 173-179. Some of these arrays are only allocated for certain model choices and on certain machine types: 99-143 are only for vector machines; 144-155 and 162-166 are only for ISTRUC>0; 173-179 are only for ITURKE $\geq$ 11 on vector machines. Set by the main program at the beginning of a computer run.

4.7 COMMON BLOCK /SPACE/

This common block contains the arrays whose lengths vary depending on the complexity of the case. The formal declaration statements which define the storage order are given by

```
INTEGER S,SPAEND  
COMMON /SPACE/ S(sdim),SPAEND
```

The dimension of array S (i.e. sdim) is specified by the user explicitly in routine ALTER (which is supplied by the user for compilation during each computer run -- cf. App. C of Ref. 2); all other routines having this common block have the sdim value as 2; the value of sdim in routine ALTER governs the true space allocation. Variable SPAEND is only used in connection with finding the length of the block; its value is irrelevant. The meaning of array S is somewhat more complicated and is discussed below.

Arrays are allocated in this common block based on the storage allocation array IS in COMMON BLOCK /ADDCON/. The storage order is such that the arrays shown under LBL1 are allocated first (in the order shown there, i.e. DUMMY1, MIP, MIM, ..., DRDTOL), followed by the variables shown under LBL2 (i.e. IFORCE, ..., FORCEF), LBL3 (i.e. MREB), LBL4 (i.e. TURVIS, ..., BDOLD), LBL5 (i.e. UWIRE, VWIRE, WWIRE), LBL6 (i.e. ITSCB, ..., TTS), and LBL7 (i.e. AC1, ..., TURVIO). Effectively, the first element of each one of these arrays is EQUIVALENCed with its proper location in array S. By way of example, the first element of the TL array (fluid temperature) is stored at location S(IS(23)), and this array may be passed from one routine to another by specifying S(IS(23)) in the actual argument list in the CALL statement. A prime example of this array passing may be seen by comparing the argument list in the CALL of routine AMAIN from the main program with routine AMAIN's entry point description. This indexing is a little tricky on short-word machines, since both integer and real number arrays are being stored in array S and real number variables are declared to be DOUBLE PRECISION; the indexing provided by array IS is always an offset in words, not number of variables, and array S is declared to be INTEGER (or REAL*4) for the purposes of this storage scheme.

The following arrays are stored in COMMON BLOCK /SPACE/; the listing is alphabetized for ease of reference. Shown for each array are the effective dimension (i.e. number of entries) in parentheses, the corresponding index in the IS array in square brackets, the definition (either in words or in terms of other variables), and what routine(s) define or alter the values. The array dimensions are shown in terms of the following FORTRAN variables:

NL1: maximum number of surface elements allowed (as input in NAMELIST GEOM).

NM1: maximum number of fluid cells allowed (as input in NAMELIST GEOM).

NPLANS: number of fully diagonal planes (=IMAX+JMAX+KMAX-2).

NTSCUP: maximum number of nonadjacent cells coupled to another cell by thermal structures (as set by a PARAMETER statement in the source code -- same value as defined for NODD).

MAXPTP: maximum number of cells in a diagonal plane (computed by routine MXPLNS).

MIJK: maximum number of cells in a regular plane (=max(IMAX*JMAX, JMAX*KMAX, IMAX*KMAX)).

MTP1: one plus the maximum number of fluid cells possible in a three dimensional region which is **IMAX** cells in the **I** direction by **JMAX** cells in the **J** direction by **KMAX** cells in the **K** direction ($=1+IMAX*JMAX*KMAX$).

Other variable names used in this regard (i.e. **NFORCE**, **NREGTS**, **NSURTS**, **NSTRUC**, **IFREB**, **NPARTS**, **NTTS**) are defined in **COMMON BLOCK /I4VAR/**. The symbol "v", "w", "+", or "#" following an array name indicates an array type, as discussed in Sec. 4.6.

A+ (7,NM1) [IS(98)] Coefficient matrix in conjugate-gradient solution procedure for the pressure equation system. Stored in stripe form; indexed using indirect addressing. Filled in routine **COMMAT** to be $A(i,m) = \pm ACOF_j(m) * AL0(m)$, where $m=1,2,\dots,NM1$, $i=1,2,3,4,5,6,7$ correspond to $j = 0,3,1,5,6,2,4$, the sign is plus for $i=1$ and minus for all other i values, **ACOFj** are the original coefficient arrays from routine **PEQN**, and **AL0** is the volume porosity. (Array **AA** is the analogue of this array on vector machines.)

AALw (6,MTP1) [IS(142)] Lower triangular factor of matrix **AA** in conjugate-gradient solution procedure for the pressure equation system on vector machines. Stored in stripe form using regular geometric cell numbering (second index). Filled by routine **FACNCV**. (Array **AL** is the analogue of this array on scalar machines.)

AAUw (7,MTP1) [IS(143)] Upper triangular factor of matrix **AA** in conjugate-gradient solution procedure for the pressure equation system on vector machines. Stored in stripe form using regular geometric cell numbering (second index). Filled by routine **FACNCV**. (Array **AU** is the analogue of this array on scalar machines.)

AAw (7,MTP1) [IS(141)] Coefficient matrix in conjugate-gradient solution procedure for the pressure equation system on vector

machines. Stored in stripe form using regular geometric cell numbering (second index). Filled by routine RESORT. (Array A is the analogue of this array on scalar machines)

- AC0 (NM1) [IS(73)] a_0^ϕ : Element n is the coefficient of ϕ_0 (central term) in the finite-difference equation for variable ϕ for fluid cell number n . This array is also referred to by the names AT0 and ACOF0 in the program. Set by one of the equation-builder routines (PEQN, TKENER, TDNER, or ENERGI) and passed to one of the solver routines (SOLVIT, CGLOOP, SOLVEN, or SOLVEV).
- AC1 (NM1) [IS(67)] a_1^ϕ : Element n is the coefficient of ϕ_1 (coupling to -I direction) in the finite-difference equation for variable ϕ for fluid cell number n . This array is also referred to by the names AT1 and ACOF1 in the program. Set by one of the equation-builder routines (PEQN, TKENER, TDNER, or ENERGI) and passed to one of the solver routines (SOLVIT, CGLOOP, SOLVEN, or SOLVEV).
- AC2 (NM1) [IS(68)] a_2^ϕ : Element n is the coefficient of ϕ_2 (coupling to +I direction) in the finite-difference equation for variable ϕ for number cell number n . This array is also referred to by the names AT2 and ACOF2 in the program. Set by one of the equation-builder routines (PEQN, TKENER, TDNER, or ENERGI) and passed to one of the solver routines (SOLVIT, CGLOOP, SOLVEN, or SOLVEV).
- AC3 (NM1) [IS(69)] a_3^ϕ : Element n is the coefficient of ϕ_3 (coupling to -J direction) in the finite-difference equation for variable ϕ for fluid cell number n . This array is also referred to by the names AT3 and ACOF3 in the program. Set by one of the equation-builder routines (PEQN, TKENER, TDNER, or ENERGI) and passed to one of the solver routines (SOLVIT, CGLOOP, SOLVEN, or SOLVEV).

AC4	(NM1)	[IS(70)]	a_4^ϕ : Element n is the coefficient of ϕ_4 (coupling to +J direction) in the finite-difference equation for variable ϕ for fluid cell number n . This array is also referred to by the names AT4 and ACOF4 in the program. Set by one of the equation-builder routines (PEQN, TKENER, TDNER, or ENERGI) and passed to one of the solver routines (SOLVIT, CGLOOP, SOLVEN, or SOLVEV).
AC5	(NM1)	[IS(71)]	a_5^ϕ : Element n is the coefficient of ϕ_5 (coupling to -K direction) in the finite-difference equation for variable ϕ for fluid cell number n . This array is also referred to by the names AT5 and ACOF5 in the program. Set by one of the equation-builder routines (PEQN, TKENER, TDNER, or ENERGI) and passed to one of the solver routines (SOLVIT, CGLOOP, SOLVEN, or SOLVEV).
AC6	(NM1)	[IS(72)]	a_6^ϕ : Element n is the coefficient of ϕ_6 (coupling to +K direction) in the finite-difference equation for variable ϕ for fluid cell number n . This array is also referred to by the names AT6 and ACOF6 in the program. Set by one of the equation-builder routines (PEQN, TKENER, TDNER, or ENERGI) and passed to one of the solver routines (SOLVIT, CGLOOP, SOLVEN, or SOLVEV).
ACOF0	(NM1)	[IS(73)]	a_0^ϕ : See array AC0.
ACOF1	(NM1)	[IS(67)]	a_1^ϕ : See array AC1.
ACOF2	(NM1)	[IS(68)]	a_2^ϕ : See array AC2.
ACOF3	(NM1)	[IS(69)]	a_3^ϕ : See array AC3.
ACOF4	(NM1)	[IS(70)]	a_4^ϕ : See array AC4.

ACOF5	(NM1)	[IS(71)]	a_5^ϕ : See array AC5.
ACOF6	(NM1)	[IS(72)]	a_6^ϕ : See array AC6.
AL	(NM1)	[IS(16)]	γ_v : Element n is the volume porosity for fluid cell number n. Default values set by routine BOXES, FULPIN, QTRPIN, or FILLM; overridden by values specified using 'AL' records in the Internal Cell Initialization block of the card-image input file. When IGEOM=-1, routine REDEF alters the values stored in this array to be the product of the volume porosity and the cell-center radius (X(i)); therefore, the value of $AL(n)*DX(i)*DY(j)*DZ(k)$ is the fluid volume of fluid cell number n whose spatial location indices are (i,j,k) for all values of IGEOM. (Identified by the name AL0 in the conjugate-gradient solution routines.)
AL+	(6,NM1)	[IS(96)]	Lower-triangular factor of matrix A in the conjugate-gradient solution procedure for the pressure equation system. Stored in stripe form; indexed using indirect addressing. Filled in routine FACINC. (Array AAL is the analogue of this array on vector machines.)
AL0	(NM1)	[IS(16)]	γ_v : See array AL.
ALNG	(NM1)	[IS(167)]	ℓ : Element n is the turbulence length scale [m] for fluid cell number n when ITURKE=10 or 11. Set by routine TLFIX.
ALX	(NM1)	[IS(13)]	γ_x or γ_r : Element n is the surface porosity in the x or r direction on the +I face of fluid cell number n. Default values set by routine BOXES, FULPIN, QTRPIN, or FILLM; overridden by values specified using 'ALX' records in the Internal Cell Initialization block of the card-image input file. When IGEOM=-1, routine REDEF alters the values stored in this array to be the product of the surface porosity and the cell-edge

radius ($X(i) + 0.5 \cdot DX(i)$); therefore, the value of $ALX(n) \cdot DY(j) \cdot DZ(k)$ is fluid flow area on the +I face of fluid cell number n whose spatial location indices are (i,j,k) for all values of IGEOM. If the +I face of a cell lies on a boundary surface, the area must be obtained from array AREA rather than using arrays ALX, DY, and DZ.

ALY (NM1) [IS(14)] γ_y or γ_θ : Element n is the surface porosity in the y or θ direction on the +J face of fluid cell number n. Default values set by routine BOXES, FULPIN, QTRPIN, or FILLM; overridden by values specified using 'ALY' records in the Internal Cell Initialization block of the card-image input file. When IGEOM=-1, routine REDEF alters the values stored in this array to be the product of the surface porosity and the cell-center radius ($X(i)$); therefore, the fluid flow area on the +J face of fluid cell number n whose spatial location indices are (i,j,k) is $ALY(n) \cdot DX(i) \cdot DZ(k)$ for $IGEOM \geq 0$ and $ALY(n) \cdot DX(i) \cdot DZ(k) / X(i)$ for $IGEOM = -1$. If the +J face of a cell lies on a boundary surface, the area must be obtained from array AREA rather than using arrays ALY, DX, and DZ.

ALZ (NM1) [IS(15)] γ_z : Element n is the surface porosity in the z direction on the +K face of fluid cell number n. Default values set by routine BOXES, FULPIN, QTRPIN, or FILLM; overridden by values specified using 'ALZ' records in the Internal Cell Initialization block of the card-image input file. When IGEOM=-1, routine REDEF alters the values stored in this array to be the product of the surface porosity and the cell-center radius ($X(i)$); therefore, the value of $ALZ(n) \cdot DX(i) \cdot DY(j)$ is fluid flow area on the +K face of fluid cell number n whose spatial location indices are (i,j,k) for all values of IGEOM. If the +K face of a cell lies on a boundary surface, the area must be obtained from array AREA rather than using arrays ALZ, DX, and DY.

AREA (NL1) [IS(44)] A_b : Element n is the area of boundary surface element number n. Set by routine BOXES (using values input

in the Boundary Surface Identification block of the card-image input file) for $IGEOM \leq 0$ and by routine FULPIN or QTRPIN (based on input values in NAMELIST GEOM) for $IGEOM > 0$.

ARUL	(NM1)	[IS(25)]	Coefficient array used in the I-direction momentum equation for the explicit-in-time formulation, which is not the recommended solution method; set in routine XMOM; used in routine MOMENT. (Storage location S(IS(25)) is also used for the following temporary arrays: IDUM4 in routine OUTPUT and SCHL in routine ENLOOP.)
ARVL	(NM1)	[IS(26)]	Coefficient array used in the J-direction momentum equation for the explicit-in-time formulation, which is not the recommended solution method; set in routine YMOM; used in routine MOMENT. (Storage location S(IS(26)) is also used for the following temporary arrays: IDUM2 in routine OUTPUT and μ_{tot}^{n-1} in routine TIMSTP.)
ARWL	(NM1)	[IS(27)]	Coefficient array used in the K-direction momentum equation for the explicit-in-time formulation, which is not the recommended solution method; set in routine ZMOM; used in routine MOMENT. (Storage location S(IS(27)) is also used for the following temporary arrays: IDUM3 in routine OUTPUT, RMU in routines TDLOOP and TKLOOP, and μ_{tot}^n in routine TIMSTP.)
AT0	(NM1)	[IS(73)]	a_0^ϕ : See array AC0.
AT1	(NM1)	[IS(67)]	a_1^ϕ : See array AC1.
AT2	(NM1)	[IS(68)]	a_2^ϕ : See array AC2.
AT3	(NM1)	[IS(69)]	a_3^ϕ : See array AC3.

AT4	(NM1)	[IS(70)]	a_4^ϕ : See array AC4.
AT5	(NM1)	[IS(71)]	a_5^ϕ : See array AC5.
AT6	(NM1)	[IS(72)]	a_6^ϕ : See array AC6.
AU+	(7,NM1)	[IS(97)]	Upper-triangular factor of matrix A in the conjugate-gradient solution procedure. Stored in stripe form; indexed using indirect addressing. Filled in routine FACINC. (Array AAU is the analogue of this array on vector machines.)
BC0	(NM1)	[IS(74)]	b_0^ϕ : Element n is the constant term in the finite-difference equation for variable ϕ for fluid cell number n. This array is also referred to by the names BT0 and BCOF0 in the program. Set by one of the equation-builder routines (PEQN, TKENER, TDNER, or ENERGI) and passed to one of the solver routines (SOLVIT, CGLOOP, SOLVEN, or SOLVEV).
BCOF0	(NM1)	[IS(74)]	b_0^ϕ : See array BC0.
BDOLD	(NM1)	[IS(172)]	Beginning of step BC0 array values for the turbulent kinetic energy dissipation rate equation system when $\text{ALPHA} < 1.0$. Current program requires $\text{ALPHA} = 1.0$.
BKOLD	(NM1)	[IS(171)]	Beginning of step BC0 array values for the turbulent kinetic energy equation system when $\text{ALPHA} < 1.0$. Current program requires $\text{ALPHA} = 1.0$.
BP0+	(NM1)	[IS(94)]	Element n is the constant term in the pressure equation for fluid cell number n in the conjugate-gradient solution method. Loaded from array BC0 in routine CGLOOP; modified in routine UPDATE to include the effect of pressure boundary conditions.

BT0	(NM1)	[IS(74)]	b_0^ϕ : See array BC0.
C1w	(MTP1)	[IS(135)]	Coupling coefficients to cells in the preceding diagonal plane in the conjugate-gradient solution of the pressure equation system on vector machines. Filled in routine COFSRT.
C1Uw	(MTP1)	[IS(138)]	Coupling coefficients to cells in the following diagonal plane in the conjugate-gradient solution of the pressure equation system on vector machines. Filled in routine COFSRT.
C2w	(MTP1)	[IS(136)]	Coupling coefficients to cells in the preceding diagonal plane in the conjugate-gradient solution of the pressure equation system on vector machines. Filled in routine COFSRT.
C2Uw	(MTP1)	[IS(139)]	Coupling coefficients to cells in the following diagonal plane in the conjugate-gradient solution of the pressure equation system on vector machines. Filled in routine COFSRT.
C3w	(MTP1)	[IS(137)]	Coupling coefficients to cells in the preceding diagonal plane in the conjugate-gradient solution of the pressure equation system on vector machines. Filled in routine COFSRT.
C3Uw	(MTP1)	[IS(140)]	Coupling coefficients to cells in the following diagonal plane in the conjugate-gradient solution of the pressure equation system on vector machines. Filled in routine COFSRT.
CLENTH	(NFORCE)	[IS(61)]	D_{hln} : Element n is the characteristic length [m] for force structure prototype number n . Input in NAMELIST DATA. If CLENTH(n) < 0, then the appropriate cell width (i.e. DX(i), DY(j)) (or X(i)*DY(j)), or DZ(k)) will be used for D_{hln} for each cell in which this force structure prototype is used.

DDDH	(NM1)	[IS(31)]	$d(\delta_p/V_f)/dh$: Element n is the derivative of the mass residual with respect to the enthalpy for fluid cell number n in the explicit-mode solution, which is not the recommended mode; computed in routine GDDDH; used in routine ENERGY. (Storage location S(IS(31)) is also used for array WLOLD in the implicit-mode solution.)
DDDPOT	(NM1)	[IS(30)]	$d(\delta_p/V_f)/dP$: Element n is the derivative of the mass residual with respect to the pressure for fluid cell number n in the explicit-mode solution, which is not the recommended mode; computed in routine GDDDP; used in routine DLCALC if IDDDP $\neq$ 0. (Storage location S(IS(30)) is also used for array VLOLD in the implicit-mode solution.)
DDINVw	(MTP1)	[IS(134)]	Used in the conjugate-gradient solution of the pressure equation system on vector machines. Set in routine COFSRT to DDINV(MRTOMD(M))=1.0/AAU(1,M) for later use in routine LOWFCV.
DL	(NM1)	[IS(21)]	δ_p/V_f : Element n is the mass residual [$\text{kg}/\text{m}^3 \cdot \text{s}$] for fluid cell number n. Computed by routines SOLVIT or CNGRIC and DLCALC.
DRDT	(NM1)	[IS(24)]	$d\rho/dt$: Element n is the derivative of fluid density with respect to time [$\text{kg}/\text{m}^3 \cdot \text{s}$] for fluid cell number n. Computed in routine TIMSTP near the end of each outer iteration during a transient calculation. (DRDT is zero during a steady-state calculation.)
DRDTOL	(NM1)	[IS(84)]	Same as array DRDT except that values are for the end of the previous time step. Set to DRDT(n) in routine TIMSTP at the beginning of a time step.

DUMMY1	(MIJK)	[IS(75)]	Multipurpose scratch array: used primarily by routine OUTPUT to organize the information to be printed by planes.
EKL	(NM1)	[IS(79)]	E: Element n is the kinetic energy of fluid cell number n. Computed in routine TIMSTP near the end of each outer iteration. Only used in connection with the change-based automatic time-step-size control (IDTIME=2).
EKLOLD	(NM1)	[IS(80)]	Same as array EKL except that values are for the end of the previous time step. Set to EKL(n) at the beginning of a time step in routine TIMSTP.
F+	(NM1)	[IS(92)]	Modified source term in the conjugate-gradient solution of the pressure equation system. Filled in routine COMMAT to be $F(M)=BP0(M)*AL0(M)$, where BP0 is the original source term from routine PEQN and AL0 is the volume porosity.
FF+	(NM1)	[IS(93)]	Intermediate result from solving the upper-triangular matrix system in the conjugate-gradient solution of the pressure equation system. Computed by routine UPPFAC.
FFFw	(MTP1)	[IS(132)]	Right-hand side of upper- and lower-triangular matrix systems in the conjugate-gradient solution of the pressure equation system on vector machines. Computed and used only within routine FACNCV; initially filled from array F.
FORCEF	(NFORCE)	[IS(63)]	C_m : Element n is the overall force multiplier for force structure prototype number n. Input in NAMELIST DATA.

HEAT (NREGTS) [IS(59)] q''' and U_{gap} : Element ITSCB((n-1)*11+3)+2*r-1 is the volumetric heat source [W/m³] in region number r of thermal structure number n; set in routine INPSTR based on the values input for Q in NAMELISTs M. Element ITCSB((n-1)*11+3)+2*r is the gap heat transfer coefficient [W/m²·°C] between region numbers r and r+1 of thermal structure number n; set in routine INPSTR based on the values input for HGAP in NAMELISTs M.

HL (NM1) [IS(22)] h: Element n is the fluid enthalpy [J/kg] in fluid cell number n. Computed by routine SOLVEN or SOLVEV for every inner and outer iteration.

HLB (NL1) [IS(48)] h_b : Element n is the fluid enthalpy [J/kg] for boundary surface element number n. Initialized by routine ICTEMP from the equation of state based on the values input for temperature and pressure. Computed by routine BCTEMP, BCTEMT, BCTEM0, or DUCTWA depending on the type of energy boundary condition.

HOLD (NM1) [IS(10)] Same as array HL except that values are for the end of the previous time step. Set in routine TIMSTP at the beginning of each time step. (Storage location S(IS(10)) is also used for array MSWEEP.)

HSTREL (NSURTS) [IS(66)] U_{cool} : Element ITSCB((n-1)*11+3)+e is the heat transfer coefficient [W/m²·°C] between the surface of element number e of thermal structure number n and the adjacent fluid cell; if only one surface (outside or inside) interacts with fluid then this value is for that surface. If both sides of thermal structure number n interact with fluid, then the above value is for the outside surface and element ITSCB((n-1)*11+3)+(ITSCB((n-1)*11+1)/10000+e is the value for the inside surface. Computed in routine HSTRUC based on the values input for IHT and HYD in NAMELISTs F and the local fluid conditions.

HYDRA1 (NSTRUC) [IS(53)] D_h : Element n is the characteristic length [m] used in converting the Nusselt number to a heat transfer coefficient for the outside surface of thermal structure number n . Set in routine INPSTR based on the values input for HYD in NAMELISTs F.

HYDRA2 (NSTRUC) [IS(54)] D_h : Element n is the characteristic length [m] used in converting the Nusselt number to a heat transfer coefficient for the inside surface of thermal structure number n . Set in routine INPSTR based on the values input for HYD in NAMELISTs F.

ICEL (NSURTS) [IS(65)] Element ITSCB(($n-1$)*11+3)+ e is the fluid cell number ($\leq NM1$) adjacent to the surface of element number e of thermal structure number n ; if only one surface (inside or outside) interacts with fluid then this is the cell adjacent to that surface. If both sides of thermal structure number n interact with fluid, this is the cell adjacent to the outside surface and element ITSCB(($n-1$)*11+3)+ITSCB(($n-1$)*11+1)/10000+ e is the number of the cell adjacent to the inside surface. Set in routine INPSTR based on the 'OUT' and 'IN' records in the Thermal Structure Location block of the card-image input file.

ICELL+ (NM1) [IS(85)] Cell mapping array in the conjugate-gradient solution of the pressure equation system. Filled in routine ELIM such that ICELL(n) is the number of the n^{th} fluid cell remaining in the equation system after cells having pressure boundary conditions have been eliminated.

ICORR (NFORCE) [IS(60)] Element number n is the friction factor correlation index number to be used for force structure number n . Input in NAMELIST DATA; used in routine FORCES.

IDODL#	(NM1)	[IS(8)]	Element n is a flag indicating whether fluid cell number n is to be considered in calculating the mass residual in routine DLCALC in the explicit-mode momentum calculation, which is not the recommended mode. Key values: 0: no; 1: yes. Array is nominally initialized to 1; element n is set to 0 when mass residual drops below $0.5 \cdot \text{DCONV}$ for fluid cell n. Space is allocated for this array on the basis of it containing real numbers (i.e. DOUBLE PRECISION on short-word machines). (Storage location S(IS(8)) is also used for array RMU in routine MOLOOP.)
IDUM1#	(NM1)	[IS(33)]	Temporary work space in routine OUTPUT. Space is allocated for this array on the basis of it containing real numbers (i.e. DOUBLE PRECISION on short-word machines). (Storage location S(IS(33)) is also used for array OARV in routines YMOM and MOMENT.)
IDUM2#	(NM1)	[IS(26)]	Temporary work space in routine OUTPUT. Space is allocated for this array on the basis of it containing real numbers (i.e. DOUBLE PRECISION on short-word machines). (Storage location S(IS(26)) is also used for array ARVL in routines YMOM and MOMENT and μ_{tot}^{n-1} in routine TIMSTP.)
IDUM3#	(NM1)	[IS(27)]	Temporary work space in routine OUTPUT. Space is allocated for this array on the basis of it containing real numbers (i.e. DOUBLE PRECISION on short-word machines). (Storage location S(IS(27)) is also used for array ARWL in routines ZMOM and MOMENT, RMU in routines TDLOOP and TKLOOP, and μ_{tot}^n in routine TIMSTP.)
IDUM4#	(NM1)	[IS(25)]	Temporary work space in routine OUTPUT. Space is allocated for this array on the basis of it containing real numbers (i.e. DOUBLE PRECISION on short-word machines). (Storage

location S(IS(25)) is also used for array ARUL in routines XMOM and MOMENT and SCHL in routine ENLOOP.

IFORCE	(NM1)	[IS(9)]	Element n is the force structure number(s) being used in fluid cell number n. Set in routine INFORC, based on the 'XFOR', 'YFOR', and 'ZFOR' records in the Force Structure Location input block, to be a 6-digit integer of the form "iijjkk", where "ii" is the force structure number used in the I direction (i.e. x or r), "jj" is the force structure number used in the J direction (i.e. y or θ), and "kk" is the force structure number used in the K direction (i.e. z). (This storage scheme imposes limits: (1) NFORCE $\leq$ 99 and (2) no more than one force structure per direction per cell.)
IICELw	(MTP1)	[IS(124)]	Cell numbering array in the conjugate-gradient solution of the pressure equation system on vector machines. Set in routine CGLOOP to IICEL(m)=m, for m=1,2,...,MTOT, after returning from routine RESORT; only used later in routine FACNCV.
Iiw	(MTP1)	[IS(113)]	Element MR is the first spatial location index (I) of fluid cell number MR ($=((J-1)*IMAX+(I-1))*KMAX+K$) in the diagonal-plane cell-numbering system in the conjugate-gradient solution method on vector machines. Set on first entry to routine RESORT.
IJK	(NM1)	[IS(7)]	Element n is the set of three spatial location indices for fluid cell number n. Set in routines BOXES, FULPIN, or QTRPIN and FILLM, based on input in NAMELIST GEOM and the Boundary Surface Identification block of the card-image input file, to a 6-digit integer of the form "iijjkk", where "ii" is the spatial location index in the I direction (i.e. x or r), "jj" is the spatial location index in the J direction (i.e. y or θ), and "kk" is the spatial location index in the K direction (i.e. z). (This storage scheme imposes limits: (1) IMAX $\leq$ 99, (2) JMAX $\leq$ 99, and (3) KMAX $\leq$ 99.)

INDHTX	(NM1)	[IS(78)]	Element n is the fluid number in cell number n. Set to default value of 1 in routine INITAL; overridden by 'HTEX' records in the Fluid Cell Location block of the card-image input file. Values must be in the range 1 to IFHTX (inclusive).
IREDD /	(NM1+1)	[IS(105)]	Element n identifies whether fluid cell number n is in the "red" or "black" system of variables in the vectorized successive overrelaxation solution method. Set in routine SOLVEV during first entry. Key values: 0: black; 1: red.
ISURF	(NL1)	[IS(43)]	Element n is the boundary surface number to which boundary surface element number n belongs. Set in routine BOXES, FULPIN, or QTRPIN. Values are in the range from 1 to NSURF (inclusive).
ITSCB	(NSTRUC*11)	[IS(52)]	Element number $(n-1)*11+s$ is information of type number s for thermal structure number n, where $1 \leq s \leq 11$ and $1 \leq n \leq NSTRUC$. Set in routines TSCAN and INPSTR based on the Thermal Structure Prototype and Location blocks of the card-image input file. Thermal structure number n is defined by the n^{th} occurrence of NAMELIST T in the Thermal Structure Prototype input block; it does not necessarily correspond to the value specified for N in NAMELISTs T (see s=9 below). The information stored for each s value is as follows. s=1: Number of fluid cells coupled to thermal structure number n; value stored is $10000*NAD1+NAD2$, where NAD1 is the number of fluid cells adjacent to the outside surface and NAD2 is the number of fluid cells adjacent to the inside surface; if both sides of a thermal structure interact with fluid then $NAD1=NAD2>0$; if only one side of a thermal structure interacts with fluid, then either (1) $NAD1>0$ and $NAD2=0$ or (2) $NAD1=0$ and $NAD2>0$.

- s=2:** Indicates which side(s) of thermal structure *n* interacts with fluid. Allowed values are: 01: inside surface only; 10: outside surface only; 11: both inside and outside surfaces.
- s=3:** Base offset in arrays ICEL and HSTREL, which store information by surface element, for thermal structure number *n*. Surface elements are defined by the order of the 'OUT' and 'IN' records for a given thermal structure; both outside and inside surface elements are counted; all outside surface elements are numbered before any inside surface elements for each thermal structure.
- s=4:** Surface heat transfer correlation numbers, stored as $1000 \cdot \text{IHT1} + \text{IHT2}$, where IHT1 is the correlation number used on the outside surface and IHT2 is the correlation number used on the inside surface; these correlation numbers are input as IHT in NAMELISTs F.
- s=5:** Region and partition counts for thermal structure number *n*; value stored is $1000 \cdot \text{NREG} + \text{NPRT}$, where NREG is the number of regions and NPRT is the number of partitions. For this purpose, the gap between regions is counted as a region but is not counted as a partition; therefore, NREG is twice the number of NAMELISTs M and NPRT is the sum of NP over the NAMELISTs M.
- s=6:** IPREG: Base offset in arrays MATERL, HEAT, and SIZE, which store information by region, for thermal structure number *n*.
- s=7:** IPTTS: Base offset in array TTS, which stores information by element and partition, for thermal structure number *n*.
- s=8:** IPPAR: Base offset in arrays STAREA and STVOL, which store information by partition, for thermal structure number *n*.
- s=9:** Index number for thermal structure number *n*. This is the value of *N* in NAMELISTs T. (This is usually the same value as *n* (but does not have to be); allows thermal structure prototype numbers to be used nonconsecutively.)
- s=10:** Geometry type and alignment direction of thermal structure number *n*. This is IXYZ in NAMELISTs T and is a 3-digit integer of the form "ttd",

where "tt" is the geometry type (00 is cylinder, 01 is slab, 10 is sphere)
and "d" is the alignment direction (1 is I, 2 is J, and 3 is K).

s=11: Transient function number used with heat source for thermal structure
number n. This is NT in NAMELISTs T.

JCELL+ (NM1) [IS(86)] Element n is the number of the
nth fluid cell which is coupled to cells which provide a pressure boundary
condition in the conjugate-gradient solution of the pressure equation system.
Filled in routine STORE. Used in routine UPDATE to include the effect of
pressure boundary conditions as a modified source term, so that the cells
providing the pressure boundary conditions can be eliminated from the equation
system.

JJw (MTP1) [IS(114)] Element MR is the second
spatial location index (J) of fluid cell number MR ($=((J-1)*IMAX+(I-1))*KMAX+K$) in the diagonal-plane cell-numbering system in the conjugate-
gradient solution method on vector machines. Set on first entry to routine
RESORT.

KKw (MTP1) [IS(115)] Element MR is the third spatial
location index (K) of fluid cell number MR ($=((J-1)*IMAX+(I-1))*KMAX+K$) in the diagonal-plane cell-numbering system in the conjugate-gradient solution
method on vector machines. Set on first entry to routine RESORT.

M0TOMRw (NM1+1) [IS(110)] Cell-mapping array in the
conjugate-gradient solution of the pressure equation system on vector machines.
Set in routine RESORT to $M0TOMR(ICELL(M))=((J-1)*IMAX+(I-1))*KMAX+K$, where I, J, and K are the spatial location indices for fluid cell
number ICELL(M) for each cell M in the pressure equation system.

MATERL (NREG) [IS(58)] Element ITSCB((n-1)*11+3)+2*r-1 is the structure material index number (input as MI in NAMELISTs M) and number of partitions (input as NP in NAMELISTs M) for region number r of thermal structure number n, stored as 1000*MI+NP. Set in routine INPSTR based on the stated input. (Array elements ITSCB((n-1)*11+3)+2*r are set to 0 in routine INPSTR but are, otherwise, not used.)

MB (NL1) [IS(42)] Element n is the fluid cell number which is adjacent to boundary surface element number n (and pointed to by the surface's unit-normal vector). Set in routine BOXES, FULPIN, or QTRPIN.

MDTOMRw (MTP1) [IS(116)] Cell/plane mapping for use in conjugate-gradient solution method on vector machines. Set using

```

      NSUM=0
      DO 50 N=1,NPLANS
      DO 50 L=1,NMAX(N)
      NSUM=NSUM+1
50    MDTOMR(NSUM)=MINDEX(L,N)

```

during first entry to routine RESORT. (The inverse of this mapping is array MRTOMD.)

MIM (NM1) [IS(2)] If MIM(n)>0, then MIM(n) is the number ($\leq$ NM1) of the fluid cell which is on the -I side of fluid cell number n. If MIM(n)<0, then the -I face lies on a boundary surface; if MIM(n)=-9999, this is an IREGular boundary surface and n is the boundary surface element number; for other MIM(n)<0 values, this is a REGular boundary surface and |MIM(n)| is the boundary surface element number. Set by routine BOXES, FULPIN, or QTRPIN based on input in NAMELIST GEOM and the Boundary Surface Identification input block. (This numbering scheme imposes a limit: NL1 $\leq$ 9998.)

MIMDw	(MTP1)	[IS(117)]	Element MD points to the fluid cell on the -I side of fluid cell number MD in the diagonal-plane cell-numbering system in conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT using
			IF (II(MR)-1.GT.0) MIMD(MD)=MRTOMD(MR-KMAX)
			IF (II(MR)-1.LE.0) MIMD(MD)=IMAX*JMAX*KMAX+1
			where MR=MDTOMR(MD) and MD=1,2,...,IMAX*JMAX*KMAX.

MIME	(NM1+1)	[IS(156)]	Similar to array MIM but used only in successive-overrelaxation solution method for the fluid energy equation system on vector machines. Set during first entry to routine SOLVEV from routine ENLOOP (IFROM=1 and IWAL99=IHTWAL(99)) as follows: (1) if the -I face of fluid cell number n is a boundary surface element but this cell is coupled to the cell on the -I side by a thermal structure and IWAL99=2, then MIME(n)=MIMTS(n); (2) if the -I face of fluid cell number n is a boundary surface element but (a) this cell is not coupled to the cell on the -I side by a thermal structure or (b) IWAL99 $\neq$ 2, then MIME(n)=NM1+1; (3) otherwise the -I face is not a boundary surface element and MIME(n)=MIM(n).
MIMNv	(NM1+1)	[IS(99)]	Similar to array MIM but used only in the conjugate-gradient solution method on vector machines. Set during first entry to routine OPERXD (and only used within this routine) as follows: (1) if the -I face of fluid cell number n is a boundary surface element, then MIMN(n)=NM1+1; (2) otherwise, MIMN(n)=MIM(n).
MIMTv	(NM1+1)	[IS(173)]	Similar to array MIM but used only in the successive-overrelaxation solution method for the fluid turbulence equation systems on vector machines. Set during first entry to routine SOLVEV from routine TKLOOP or TDLOOP (IFROM=2 and IWAL99=0) as follows: (1) if the -I face of fluid cell number n is a boundary surface element, then MIMT(n)=NM1+1; (2) otherwise, MIMT(n)=MIM(n).

MIMTS	(NM1+1)	[IS(144)]	If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the -I side by thermal structure number NIMTS(n) and that fluid cell's number is MIMTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.
MINDEXw	(MAXPTP,NPLANS)	[IS(126)]	Element (n,m) is the index pointing to the n^{th} cell in the m^{th} diagonal plane in the conjugate-gradient solution method on vector machines. Set on first entry to RESORT.
MIP	(NM1)	[IS(1)]	If $MIP(n) > 0$, then $MIP(n)$ is the number ($\leq NM1$) of the fluid cell which is on the +I side of fluid cell number n . If $MIP(n) < 0$, then the +I face lies on a boundary surface; if $MIP(n) = -9999$, this is an IREGular boundary surface and n is the boundary surface element number; for other $MIP(n) < 0$ values, this is a REGular boundary surface and $ MIP(n) $ is the boundary surface element number. Set by routine BOXES, FULPIN, or QTRPIN based on input in NAMELIST GEOM and the Boundary Surface Identification input block. (This numbering scheme imposes a limit: $NL1 \leq 9998$.)

MIPDw	(MTP1)	[IS(120)]	Element MD points to the fluid cell on the +I side of fluid cell number MD in the diagonal-plane cell-numbering system in conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT using
			IF (II(MR)+1.LE.IMAX) MIPD(MD)=MRTOMD(MR+KMAX)
			IF (II(MR)+1.GT.IMAX) MIPD(MD)=IMAX*JMAX*KMAX+1
			where $MR = MDTOMR(MD)$ and $MD = 1, 2, \dots, IMAX*JMAX*KMAX$.

MIPE	(NM1+1)	[IS(157)]	Similar to array MIP but used only in successive-overrelaxation solution method for the fluid energy equation system on vector machines. Set during first entry to routine SOLVEV from routine ENLOOP (IFROM=1 and IWAL99=IHTWAL(99)) as follows: (1) if the +I face of fluid cell number n is a boundary surface element but this cell is

coupled to the cell on the +I side by a thermal structure and IWAL99=2, then $MIPE(n)=MIPTS(n)$; (2) if the +I face of fluid cell number n is a boundary surface element but (a) this cell is not coupled to the cell on the +I side by a thermal structure or (b) $IWAL99 \neq 2$, then $MIPE(n)=NM1+1$; (3) otherwise the +I face is not a boundary surface element and $MIPE(n)=MIP(n)$.

MIPNv	(NM1+1)	[IS(100)]	Similar to array MIP but used only in the conjugate-gradient solution method on vector machines. Set during first entry to routine OPERXD (and only used within this routine) as follows: (1) if the +I face of fluid cell number n is a boundary surface element, then $MIPN(n)=NM1+1$; (2) otherwise, $MIPN(n)=MIP(n)$.
MIPTv	(NM1+1)	[IS(174)]	Similar to array MIP but used only in the successive-overrelaxation solution method for the fluid turbulence equation systems on vector machines. Set during first entry to routine SOLVEV from routine TKLOOP or TDLOOP (IFROM=2 and IWAL99=0) as follows: (1) if the +I face of fluid cell number n is a boundary surface element, then $MIPT(n)=NM1+1$; (2) otherwise, $MIPT(n)=MIP(n)$.
MIPTS	(NM1+1)	[IS(145)]	If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the +I side by thermal structure number NIPTS(n) and that fluid cell's number is MIPTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.
MJM	(NM1)	[IS(4)]	If $MJM(n) > 0$, then $MJM(n)$ is the number ($\leq NM1$) of the fluid cell which is on the -J side of fluid cell number n. If $MJM(n) < 0$, then the -J face lies on a boundary surface; if $MJM(n) = -9999$, this is an IREGular boundary surface and n is the boundary surface element number; for other $MJM(n) < 0$ values, this is a REGular boundary surface and $ MJM(n) $ is the boundary surface element number. Set by routine BOXES, FULPIN, or QTRPIN based on input in NAMELIST GEOM and the

Boundary Surface Identification input block. (This numbering scheme imposes a limit: $NL1 \leq 9998$.)

MJMDw (MTP1) [IS(118)] Element MD points to the fluid cell on the -J side of fluid cell number MD in the diagonal-plane cell-numbering system in conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT using

IF (JJ(MR)-1.GT.0) MJMD(MD)=MRTOMD(MR-KMAX*IMAX)
IF (JJ(MR)-1.LE.0) MJMD(MD)=IMAX*JMAX*KMAX+1

where $MR = MDTOMR(MD)$ and $MD = 1, 2, \dots, IMAX*JMAX*KMAX$.

MJME (NM1+1) [IS(158)] Similar to array MJM but used only in successive-overrelaxation solution method for the fluid energy equation system on vector machines. Set during first entry to routine SOLVEV from routine ENLOOP (IFROM=1 and IWAL99=IHTWAL(99)) as follows: (1) if the -J face of fluid cell number n is a boundary surface element but this cell is coupled to the cell on the -J side by a thermal structure and IWAL99=2, then $MJME(n) = MJMTS(n)$; (2) if the -J face of fluid cell number n is a boundary surface element but (a) this cell is not coupled to the cell on the -J side by a thermal structure or (b) $IWAL99 \neq 2$, then $MJME(n) = NM1 + 1$; (3) otherwise the -J face is not a boundary surface element and $MJME(n) = MJM(n)$.

MJMNv (NM1+1) [IS(101)] Similar to array MJM but used only in the conjugate-gradient solution method on vector machines. Set during first entry to routine OPERXD (and only used within this routine) as follows: (1) if the -J face of fluid cell number n is a boundary surface element, then $MJMN(n) = NM1 + 1$; (2) otherwise, $MJMN(n) = MJM(n)$.

MJMTv (NM1+1) [IS(175)] Similar to array MJM but used only in the successive-overrelaxation solution method for the fluid turbulence equation systems on vector machines. Set during first entry to routine SOLVEV

from routine TKLOOP or TDLOOP (IFROM=2 and IWAL99=0) as follows: (1) if the -J face of fluid cell number n is a boundary surface element, then MJMT(n)=NM1+1; (2) otherwise, MJMT(n)=MJM(n).

MJMTS (NM1+1) [IS(146)] If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the -J side by thermal structure number NJMTS(n) and that fluid cell's number is MJMTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.

MJP (NM1) [IS(3)] If MJP(n) > 0, then MJP(n) is the number ($\leq$ NM1) of the fluid cell which is on the +J side of fluid cell number n. If MJP(n) < 0, then the +J face lies on a boundary surface; if MJP(n) = -9999, this is an IREGular boundary surface and n is the boundary surface element number; for other MJP(n) < 0 values, this is a REGular boundary surface and |MJP(n)| is the boundary surface element number. Set by routine BOXES, FULPIN, or QTRPIN based on input in NAMELIST GEOM and the Boundary Surface Identification input block. (This numbering scheme imposes a limit: $NL1 \leq 9998$.)

MJPDw (MTP1) [IS(121)] Element MD points to the fluid cell on the +J side of fluid cell number MD in the diagonal-plane cell-numbering system in conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT using

IF (JJ(MR)+1.LE.JMAX) MJPD(MD)=MRTOMD(MR+KMAX*IMAX)
IF (JJ(MR)+1.GT.JMAX) MJPD(MD)=IMAX*JMAX*KMAX+1

where $MR = MDTOMR(MD)$ and $MD = 1, 2, \dots, IMAX*JMAX*KMAX$.

MJPE (NM1+1) [IS(159)] Similar to array MJP but used only in successive-overrelaxation solution method for the fluid energy equation system on vector machines. Set during first entry to routine SOLVEV from routine ENLOOP (IFROM=1 and IWAL99=IHTWAL(99)) as follows: (1) if the

+J face of fluid cell number n is a boundary surface element but this cell is coupled to the cell on the +J side by a thermal structure and IWAL99=2, then MJPE(n)=MJPTS(n); (2) if the +J face of fluid cell number n is a boundary surface element but (a) this cell is not coupled to the cell on the +J side by a thermal structure or (b) IWAL99 $\neq$ 2, then MJPE(n)=NM1+1; (3) otherwise the +J face is not a boundary surface element and MJPE(n)=MJP(n).

MJPNv	(NM1+1)	[IS(102)]	Similar to array MJP but used only in the conjugate-gradient solution method on vector machines. Set during first entry to routine OPERXD (and only used within this routine) as follows: (1) if the +J face of fluid cell number n is a boundary surface element, then MJPN(n)=NM1+1; (2) otherwise, MJPN(n)=MJP(n).
MJPTv	(NM1+1)	[IS(176)]	Similar to array MJP but used only in the successive-overrelaxation solution method for the fluid turbulence equation systems on vector machines. Set during first entry to routine SOLVEV from routine TKLOOP or TDLOOP (IFROM=2 and IWAL99=0) as follows: (1) if the +J face of fluid cell number n is a boundary surface element, then MJPT(n)=NM1+1; (2) otherwise, MJPT(n)=MJP(n).
MJPTS	(NM1+1)	[IS(147)]	If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the +J side by thermal structure number NJPTS(n) and that fluid cell's number is MJPTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.
MKM	(NM1)	[IS(6)]	If MKM(n)>0, then MKM(n) is the number ($\leq$ NM1) of the fluid cell which is on the -K side of fluid cell number n. If MKM(n)<0, then the -K face lies on a boundary surface; if MKM(n)=-9999, this is an IREGular boundary surface and n is the boundary surface element number; for other MKM(n)<0 values, this is a REGular boundary surface and MKM(n) is the boundary surface element number. Set

by routine BOXES, FULPIN, or QTRPIN based on input in NAMELIST GEOM and the Boundary Surface Identification input block. (This numbering scheme imposes a limit: $NL1 \leq 9998$.)

MKMDw (MTP1) [IS(119)] Element MD points to the fluid cell on the -K side of fluid cell number MD in the diagonal-plane cell-numbering system in conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT using

IF (KK(MR)-1.GT.0) MKMD(MD)=MRTOMD(MR-1)
IF (KK(MR)-1.LE.0) MKMD(MD)=IMAX*JMAX*KMAX+1

where $MR = MDTOMR(MD)$ and $MD = 1, 2, \dots, IMAX*JMAX*KMAX$.

MKME (NM1+1) [IS(160)] Similar to array MKM but used only in successive-overrelaxation solution method for the fluid energy equation system on vector machines. Set during first entry to routine SOLVEV from routine ENLOOP (IFROM=1 and IWAL99=IHTWAL(99)) as follows: (1) if the -K face of fluid cell number n is a boundary surface element but this cell is coupled to the cell on the -K side by a thermal structure and IWAL99=2, then $MKME(n) = MKMTS(n)$; (2) if the -K face of fluid cell number n is a boundary surface element but (a) this cell is not coupled to the cell on the -K side by a thermal structure or (b) $IWAL99 \neq 2$, then $MKME(n) = NM1 + 1$; (3) otherwise the -K face is not a boundary surface element and $MKME(n) = MKM(n)$.

MKMNv (NM1+1) [IS(103)] Similar to array MKM but used only in the conjugate-gradient solution method on vector machines. Set during first entry to routine OPERXD (and only used within this routine) as follows: (1) if the -K face of fluid cell number n is a boundary surface element, then $MKMN(n) = NM1 + 1$; (2) otherwise, $MKMN(n) = MKM(n)$.

MKMTv (NM1+1) [IS(177)] Similar to array MKM but used only in the successive-overrelaxation solution method for the fluid turbulence equation systems on vector machines. Set during first entry to routine SOLVEV

from routine TKLOOP or TDLOOP (IFROM=2 and IWAL99=0) as follows: (1) if the -K face of fluid cell number n is a boundary surface element, then $MKMT(n) = NM1 + 1$; (2) otherwise, $MKMT(n) = MKM(n)$.

MKMTS (NM1 + 1) [IS(148)] If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the -K side by thermal structure number NKMTS(n) and that fluid cell's number is MKMTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.

MKP (NM1) [IS(5)] If $MKP(n) > 0$, then $MKP(n)$ is the number ($\leq NM1$) of the fluid cell which is on the +K side of fluid cell number n. If $MKP(n) < 0$, then the +K face lies on a boundary surface; if $MKP(n) = -9999$, this is an IREGular boundary surface and n is the boundary surface element number; for other $MKP(n) < 0$ values, this is a REGular boundary surface and $|MKP(n)|$ is the boundary surface element number. Set by routine BOXES, FULPIN, or QTRPIN based on input in NAMELIST GEOM and the Boundary Surface Identification input block. (This numbering scheme imposes a limit: $NL1 \leq 9998$.)

MKPDw (MTP1) [IS(122)] Element MD points to the fluid cell on the +K side of fluid cell number MD in the diagonal-plane cell-numbering system in conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT using

IF (KK(MR)+1.LE.KMAX) MKPD(MD)=MRTOMD(MR+1)
IF (KK(MR)+1.GT.KMAX) MKPD(MD)=IMAX*JMAX*KMAX+1

where $MR = MDTOMR(MD)$ and $MD = 1, 2, \dots, IMAX*JMAX*KMAX$.

MKPE (NM1 + 1) [IS(161)] Similar to array MKP but used only in successive-overrelaxation solution method for the fluid energy equation system on vector machines. Set during first entry to routine SOLVEV from routine ENLOOP (IFROM=1 and IWAL99=IHTWAL(99)) as follows: (1) if the +K face of fluid cell number n is a boundary surface element but this cell is

coupled to the cell on the +K side by a thermal structure and $IWAL99=2$, then $MKPE(n)=MKPTS(n)$; (2) if the +K face of fluid cell number n is a boundary surface element but (a) this cell is not coupled to the cell on the +K side by a thermal structure or (b) $IWAL99 \neq 2$, then $MKPE(n)=NM1+1$; (3) otherwise the +K face is not a boundary surface element and $MKPE(n)=MKP(n)$.

MKPNv	(NM1+1)	[IS(104)]	Similar to array MKP but used only in the conjugate-gradient solution method on vector machines. Set during first entry to routine OPERXD (and only used within this routine) as follows: (1) if the +K face of fluid cell number n is a boundary surface element, then $MKPN(n)=NM1+1$; (2) otherwise, $MKPN(n)=MKP(n)$.
MKPTv	(NM1+1)	[IS(178)]	Similar to array MKP but used only in the successive-overrelaxation solution method for the fluid turbulence equation systems on vector machines. Set during first entry to routine SOLVEV from routine TKLOOP or TDLOOP ($IFROM=2$ and $IWAL99=0$) as follows: (1) if the +K face of fluid cell number n is a boundary surface element, then $MKPT(n)=NM1+1$; (2) otherwise, $MKPT(n)=MKP(n)$.
MKPTS	(NM1+1)	[IS(149)]	If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the +K side by thermal structure number $NKPTS(n)$ and that fluid cell's number is $MKPTS(n)$. Set in routine GETMTS at beginning of job when $IHTWAL(99)=2$.
MREB	(IFREB)	[IS(11)]	List of cells which form regions and cells whose faces form surfaces in the user-specified mass rebalancing model. Set in routine IREBAL at beginning of a run having $IFREB>0$ and $NEWREB=1$ based on the values input for arrays NREBM, NREBX, NREBY, and NREBZ in NAMELIST DATA and the records in the Rebalancing Region Location input block. The first NREBM(1) entries are the fluid cell numbers which form rebalancing region number 1; the next NREBX(1) entries are the fluid

cell numbers whose +I faces are part of rebalancing surface number 1; the next NREBY(1) entries are the fluid cell numbers whose +J faces are part of rebalancing surface number 1; the next NREBZ(1) entries are the fluid cell numbers whose +K faces are part of rebalancing surface number 1; the next NREBM(2), NREBX(2), NREBY(2), and NREBZ(2) entries are the corresponding fluid cell numbers for rebalancing region and surface number 2; this storage pattern continues for rebalancing region and surface numbers 3,4,...,NREBRT. Array IMREB in COMMON BLOCK /I4ARY/ contains the indexing offsets needed to access the cell-number information in array MREB.

MRTOMDw (MTP1) [IS(123)] Cell/plane mapping for use in conjugate-gradient solution method on vector machines. Set using

```

      NSUM=0
      DO 50 N=1,NPLANS
      DO 50 L=1,NMAX(N)
      NSUM=NSUM+1
50    MRTOMD(MINDEX(L,N))=NSUM

```

during first entry to routine RESORT. (The inverse of this mapping is array MDTOMR.)

MSWEEP# (NM1) [IS(10)] Not currently used (although appears in the argument lists for routines INITAL, TIMSTP, MALOOP, DLCALC, and REBAL). Storage allocation for this array is based on it containing real numbers (i.e. DOUBLE PRECISION on short-word machines) rather than integers as one might infer from the variable name. (Storage location S(IS(10)) is also used for array HOLD.)

MTOMDw (NM1+1) [IS(112)] Cell mapping array used in conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT using

```
MTOMD(M)=MRTOMD(MDTOMR(ICELL(M)))
```

for M=1,2,...,NX (= number of cells in pressure equation system ≤ NM1).

MTOMRw (NM1+1) [IS(111)] Cell mapping used in conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT using

$$MTOMR(M) = ((J-1)*IMAX + (I-1))*KMAX + K$$

where I, J, and K are the spatial location indices of fluid cell number ICELL(M) and M=1,2,...,NX (= number of cells in pressure equation system ≤ NM1).

MTSODD (NM1+1,NTSCUP) [IS(162)] If nonzero, then fluid cell number n is coupled to the mth nonadjacent fluid cell by thermal structure number MTSODD(n,m) and that fluid cell's number is MTSODD(n,m). Set in routine LODODD (as called from routine GETMTS) at the beginning of a job when IHTWAL(99)=2.

NA+ (7,NM1) [IS(88)] Index array in the conjugate-gradient solution of the pressure equation system. Set in routine SORTC such that element (n,i) holds the n-position which the term NM(n,i) occupied in the NM array before it was shuffled for cell number i. Used in routines FACINC and OPERXC. (See array NM in this section for additional information.)

NAAw (7,MTP1) [IS(131)] Analogous to array NA but used on vector machines, for which cell numbers (second array index) conform to the regular geometric ordering. Initially filled using array NA in routine RESORT; used in routine FACNCV.

NDGw (MTP1) [IS(125)] Cell/plane mapping array, holding the diagonal plane number to which each cell belongs, in conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT using

$$NDG(((J-1)*IMAX + (I-1))*KMAX + K) = I + J + K - 2$$

where I, J, and K are the spatial cell location indices.

NIMTS   (NM1+1)   [IS(150)]   If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the -I side by thermal structure number NIMTS(n) and that fluid cell's number is MIMTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.

NIPTS   (NM1+1)   [IS(151)]   If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the +I side by thermal structure number NIPTS(n) and that fluid cell's number is MIPTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.

NJMTS   (NM1+1)   [IS(152)]   If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the -J side by thermal structure number NJMTS(n) and that fluid cell's number is MJMTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.

NJPTS   (NM1+1)   [IS(153)]   If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the +J side by thermal structure number NJPTS(n) and that fluid cell's number is MJPTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.

NKMTS   (NM1+1)   [IS(154)]   If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the -K side by thermal structure number NKMTS(n) and that fluid cell's number is MKMTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.

NKPTS   (NM1+1)   [IS(155)]   If nonzero, then fluid cell number n is coupled to the adjacent fluid cell on the +K side by thermal structure number NKPTS(n) and that fluid cell's number is MKPTS(n). Set in routine GETMTS at beginning of job when IHTWAL(99)=2.

NLw	(NPLANS)	[IS(128)]	Element n is the first cell number (in the regular geometric cell-numbering pattern) in diagonal plane number n in the conjugate-gradient solution of the pressure equation system on vector machines. Set during first call to RESORT; used in LOWFCV.
NM+	(9,NM1)	[IS(89)]	Fluid cell number index array used in conjunction with array A in conjugate-gradient solution method. Array is initially constructed in routine COMMAT, such that element (1,n) is the fluid cell number and elements (2,n) through (7,n) are the fluid cell numbers which are adjacent to cell n in the -J, -I, -K, +K, +I, and +J directions, respectively. The ordering is shuffled in routine SORTC after zeroing entries where there is no coupling, such that (1) elements (m,n), for m=1,2,...,7, form an ascending sequence of cell numbers; (2) element (8,n) is the value of m corresponding to the cell number (i.e. element (8,n) is n); and (3) element (9,n) is how many of elements (m,n), m=1,2,...,7, are nonzero.
NMAXw	(NPLANS)	[IS(127)]	Element n is the number of fluid cells in diagonal plane number n in conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT.
NMMw	(9,MTP1)	[IS(130)]	Similar to array NM but information is stored by cell number in the diagonal-plane system for the conjugate-gradient solution method on vector machines. Set during first entry to routine RESORT; used in routines FACNCV and COFSRT.
NMNP+	(6,NM1)	[IS(87)]	If nonzero, then the pressure in fluid cell number NMNP(m,n) provides a boundary condition on side m (where m=1 through 6 correspond to the -I, +I, -J, +J, -K, and +K sides, respectively) of fluid cell number n in the conjugate-gradient solution of the pressure equation system. Set in routine STORE; used in routine UPDATE.

NTSODD (NM1+1,NTSCUP) [IS(163)] If nonzero, then fluid cell number n is coupled to the m^{th} nonadjacent fluid cell by thermal structure number NTSODD(n,m) and that fluid cell's number is MTSODD(n,m). Set in routine LODODD (as called from routine GETMTS) at the beginning of a job when IHTWAL(99)=2.

NUw (NPLANS) [IS(129)] Element n is the last cell number (in regular geometric cell-numbering pattern) in diagonal plane number n in conjugate-gradient solution of pressure equation system on vector machines. Set during first entry to routine RESORT; used in routine FACNCV.

OARU (NM1) [IS(32)] Originally used in explicit formulation of the I-direction momentum equation, which is not the recommended solution method; set in routine XMOM; values need to stay intact through their use in routine MOMENT. (Storage location S(IS(32)) is also used for the following temporary arrays: RDUM1 in routine OUTPUT, SPHL in routine ENLOOP, and SCHL in routines TDLOOP and TKLOOP.)

OARV (NM1) [IS(33)] Originally used in explicit formulation of the J-direction momentum equation, which is not the recommended solution method; set in routine YMOM; values must stay intact through their use in routine MOMENT. (Storage location S(IS(33)) is also used for temporary array IDUM1 in routine OUTPUT.)

OARW (NM1) [IS(34)] Originally used in explicit formulation of the K-direction momentum equation, which is not the recommended solution method; set in routine ZMOM; values need to stay intact through their use in routine MOMENT. (Storage location S(IS(34)) is a candidate for use as a temporary array in other routines or for deletion.)

P	(NM1)	[IS(41)]	P: Element n is the pressure [Pa] in fluid cell number n relative to the value in array element PSTAT0(n). (The current total pressure is $P(n)+PSTAT0(n)$.) Set in routine CNGRIC or SOLVIT depending on method used to solve the pressure equation system.
P+	(NM1)	[IS(91)]	Intermediate result (used in computing the initial residual) in the conjugate-gradient solution of the pressure equation system. Set by calling routine OPERXC from routine CNGRIC to $P=A*X$, where A is the coefficient matrix and X is the initial value of the solution vector (i.e. pressure).
PB	(NL1)	[IS(50)]	P_b : Element n is the total pressure [Pa] at boundary surface element number n. Value is always set to $P(MB(N))+PSTAT0(MB(N))$. Initialized in routine ICTEMP; reset in routines BCTEMP, BCTEMT, BCTEMO, and DUCTWA as case progresses. (Not clear that this array is really used effectively, since pressure is really not defined on boundary surfaces -- any specified boundary pressure is immediately transferred to the center of the neighboring fluid cell.)
POLD	(NM1)	[IS(82)]	Identical to array P but values are for the end of the previous time step. Set in routine TIMSTP at the beginning of the time step.
PSTAT0	(NM1)	[IS(35)]	P_0 : Element n is the reference pressure [Pa] in fluid cell number n. (The current total pressure is $P(n)+PSTAT0(n)$.) Set in routine INITAL to the initial gravity head (using values input in arrays TEMP0, PRES0, XPRES0, YPRES0, and ZPRES0 in NAMELIST DATA and the cell's position in Cartesian coordinates).
QBN	(NL1)	[IS(47)]	q_b : Element n is the heat flux [W/m^2] for boundary surface element number n. For "specified heat flux" fluid

energy boundary conditions, this is set to user-specified input values (using array TEMP in NAMELIST DATA or 'QBN' records in the Boundary Value Initialization block of the card-image input file) and updated in routine BCTEMP as needed during the case. For other types of fluid energy boundary conditions, this is computed in routine BCTEMP, BCTEM0, or QDUCTW (using TLB(n), TL(MB(n)), and other quantities).

QNOGHT (NM1+1,6+NTSCUP) [IS(165)] Element (n,m) is the net volumetric heat transfer rate [W/m^3] to fluid cell number n from the thermal structure which connects this fluid cell to the fluid cell indicated by index m when $\text{IHTWAL}(99) \geq 1$. Index m values of 1 through 6 refer to the cells immediately adjacent to cell n on the -I, +I, -J, +J, -K, and +K sides, respectively; higher values of index m refer to the cells which are not immediately adjacent to cell n. Set in routine QSTRUC.

QPRIME (NM1+1,6+NTSCUP) [IS(166)] Element (n,m) is the derivative [$\text{kg}/\text{m}^3 \cdot \text{s}$] of the net volumetric heat transfer rate to fluid cell number n from the thermal structure which connects this fluid cell to the fluid cell indicated by index m with respect to the enthalpy in the fluid cell indicated by index m when $\text{IHTWAL}(99)=2$. Index m values of 1 through 6 refer to the cells immediately adjacent to cell n on the -I, +I, -J, +J, -K, and +K sides, respectively; higher values of index m refer to the cells which are not immediately adjacent to cell n. Set in routine QSTRDS.

QSOUR (NM1) [IS(29)] q''' : Element n is the net volumetric heat source rate [W/m^3] to fluid cell number n. When thermal structures are used, this is computed in routine QSTRUC; when thermal structures are not used, this is input using 'QSOU' records in the Internal Cell Initialization block of the card-image input file.

R+	(NM1)	[IS(90)]	Mass residual in the conjugate-gradient solution of the pressure equation system. Computed in routine CNGRIC.
RDUM1	(NM1)	[IS(32)]	Temporary work space in routine OUTPUT. (Storage location S(IS(32)) is also used for the following arrays: OARU in routines XMOM and MOMENT, SPHL in routine ENLOOP, and SCHL in routines TDLOOP and TKLOOP.)
REALB	(NM1)	[IS(28)]	Not currently used. (Storage location S(IS(28)) is currently used for array ULOLD.)
REYLEN	(NFORCE)	[IS(62)]	D_{h2n} : Element n is the characteristic length [m] used in computing the Reynolds number for use in computing the friction factor for force structure number n. Input in NAMELIST DATA.
RL	(NM1)	[IS(17)]	ρ : Element n is the fluid density [kg/m ³] for fluid cell number n. Computed in routine TIMSTP (using h, P, and the equation-of-state information) near the end of each outer iteration.
RLB	(NL1)	[IS(45)]	ρ_b : Element n is the fluid density [kg/m ³] for boundary surface element number n. Set by routines which set array TLB.
RLOLD	(NM1)	[IS(83)]	Same as array RL except values are for the end of the previous time step. Set in routine TIMSTP at the beginning of a time step.
RMU	(NM1)	[IS(8)]	μ : Element n is the total (laminar plus turbulent) viscosity [Pa·s] for fluid cell number n. Defined in routine MOLOOP for temporary use in routines XMOMI, YMOMI, and

ZMOMI. (Storage location S(IS(8)) is also used for array IDODL in routine DLCALC.)

RMU (NM1) [IS(27)] μ : Element n is the total (laminar plus turbulent) viscosity [Pa·s] for fluid cell number n when ITURKE ≥ 11 . Defined in routines (1) TKLOOP for temporary use in routines TKSORC and TKENER and (2) TDLOOP for temporary use in routine TDNER. (Storage location S(IS(27)) is also used for array ARWL in routines ZMOM and MOMENT and array IDUM3 in routine OUTPUT.)

RODFR (NSTRUC) [IS(55)] Element n is the geometry multiplicity factor for thermal structure number n. Set in routine INPSTR to value input for RODFR in NAMELISTs T. Exact meaning depends its sign and on IXYZ as described in the Input Guide.

S (sdim) [special] See beginning of this section.

SCHL (NM1) [IS(25)] Similar to array QSOUR but is heat source rate per "cell volume" rather than per "cell fluid volume". Used in routine ENLOOP (and routines it calls). (Storage location S(IS(25)) is also used for array ARUL in routines XMOM and MOMENT and array IDUM4 in routine OUTPUT.)

SCHL (NM1) [IS(32)] (1) Part of source term (i.e. $P_k + G_k - \rho \varepsilon$, cf. Eq. 7.7 of Ref. 1) in turbulent kinetic energy and turbulent kinetic energy dissipation rate equation systems when ITURKE ≥ 11 ; defined in routine TKSORC; used in routines TKENER and TDNER. (2) Velocity gradient term (i.e. $\{(\partial u_i / \partial x_j)[(\partial u_i / \partial x_j) + (\partial u_j / \partial x_i)]\}^{1/2}$ in Eq. 7.32 of Ref. 1) in turbulent viscosity expression when ITURKE = 10; defined in routine VELOG; used in routine VISFIX. (Storage location S(IS(32)) is also used for array OARU in routines XMOM and MOMENT, array SPHL in routine ENLOOP, and array RDUM1 in routine OUTPUT.)

SIZE	(NREGTS)	[IS(64)]	Thermal structure thicknesses: (1) Element $ITSCB((n-1)*11+3)+2*r-1$ is the partition thickness (input as DR in NAMELISTs M) for region number r of thermal structure number n. (2) Element $ITSCB((n-1)*11+3)+2*r$ is the gap thickness (input as SGAP in NAMELISTs M) between region numbers r and r+1 for thermal structure number n. Array is filled in routine INPSTR based on the stated input.
SPAEND		[special]	Last variable in COMMON BLOCK /SPACE/. Value is irrelevant. Storage location is only referenced in connection with calculating the length of the common block.
SPHL	(NM1)	[IS(32)]	dq'''/dh : Element n is the derivative of the net heat source rate with respect to enthalpy for fluid cell n; contributions are computed in routines BCTEM0, QDUCTW, and QSTRUC; used in routine ENERGI. (Storage location S(IS(32)) is also used for array OARU in routines XMOM and MOMENT, array SCHL in routines TDLOOP and TKLOOP, and array RDUM1 in routine OUTPUT.)
SPHODL	(NM1+1,NTSCUP)	[IS(164)]	Element (n,m) is the derivative of the net heat transfer rate to fluid cell n from the thermal structure which couples this fluid cell to the m th nonadjacent fluid cell with respect to the enthalpy in the m th nonadjacent fluid cell when IHTWAL(99)=2. Set in routine ENERGI (to QPRIME(n,6+m) times the fluid volume in cell n).
STAREA	(NPARTS)	[IS(56)]	Element $ITSCB((n-1)*11+8)+p$ is the surface area between partition numbers p and p-1 for thermal structure number n. If the corresponding value of RODFR is negative, then this is an area factor rather than an absolute area. Set in routine INPSTR based on input in the Thermal Structure Prototype and Location blocks of the card-image input file.

STVOL	(NPARTS)	[IS(57)]	Element ITS CB((n-1)*11+8)+p is the volume of partition number p for thermal structure number n. If the corresponding value of RODFR is negative, then this is a volume factor rather than an absolute volume. Set in routine INPSTR based on input in the Thermal Structure Prototype and Location blocks of the card-image input file.
TEMBT0	(NM1+1)	[IS(106)]	See array TEMP01.
TEMDEL	(NM1+1)	[IS(109)]	See array TEMP04.
TEMP01v	(NM1+1)	[IS(106)]	Element n holds the constant (source plus boundary value) term for fluid cell n in the successive-overrelaxation solution method for nonmomentum equation systems on vector machines. Set and used in routine SOLVEV, in which it is identified by the name TEMBT0. (Storage location S(IS(106)) is also used for array TEMPV in routine OPERXD.)
TEMP02v	(NM1+1)	[IS(107)]	Element n is the new variable (either h, k, or ϵ) value for fluid cell number n in the successive-overrelaxation solution method for nonmomentum equation systems on vector machines. Computed during each inner iteration in routine SOLVEV, in which it is identified by the name TEMPV1. (Storage location S(IS(107)) is also used for array TEMPY in routine OPERXD.)
TEMP03v	(NM1+1)	[IS(108)]	Values of the solution variable (either h, k, or ϵ) being held constant during the successive-overrelaxation solution method for nonmomentum equation systems on vector machines; these are the values for the "red" cells when the "black" cells' values are being updated and the values for the "black" cells when the "red" cells' values are being updated. Array is filled from array TEMP02 after the "red" and "black" cell loops during each inner iteration in routine SOLVEV, in which the array is identified by the name TEMPV2. (Storage location S(IS(108)) is also used for array XR in routine CNGRIC.)

TEMP04v	(NM1+1)	[IS(109)]	Element n is the fractional change in the solution variable (either h, k, or ϵ) for fluid cell number n during this inner iteration in the successive-overrelaxation solution method for nonmomentum equation systems on vector machines. Computed at the end of each inner iteration in routine SOLVEV, in which it is identified by the name TEMDEL.
TEMPVw	(NM1+1)	[IS(106)]	Temporary work space array holding copy of array X in routine OPERXD which computes $F=A*X$ as part of the conjugate-gradient solution of the pressure equation system on vector machines. (Storage location S(IS(106)) is also used for array TEMBT0 in routine SOLVEV.)
TEMPV1v	(NM1+1)	[IS(107)]	See array TEMP02.
TEMPV2v	(NM1+1)	[IS(108)]	See array TEMP03.
TEMPYw	(NM1+1)	[IS(107)]	Temporary work space array holding copy of array F in routine OPERXD which computes $F=A*X$ as part of the conjugate-gradient solution of the pressure equation system on vector machines. (Storage location S(IS(107)) is also used for array TEMPV1 in routine SOLVEV.)
TKED	(NM1)	[IS(168)]	ϵ : Element n is the turbulent kinetic energy dissipation rate [m^2/s^3] for fluid cell number n when ITURKE ≥ 11 . Computed in routine TDLOOP (possibly by calling routine SOLVEN or SOLVEV).
TKEDB	(NL1)	[IS(170)]	ϵ_b : Element n is the turbulent kinetic energy dissipation rate (ϵ) [m^2/s^3] for boundary surface element number n when ITURKE ≥ 11 . Initialized in routine INITUR; updated in routine BCTURB during each outer iteration.

TKEDO	(NM1)	[IS(169)]	Same as array TKED except that the values are for the end of the previous time step. Set in routine TIMSTP at the beginning of each time step.
TL	(NM1)	[IS(23)]	T: Element n is the fluid temperature [$^{\circ}\text{C}$] for fluid cell number n. Computed in routine TIMSTP (using h, P and the equation-of-state information) near the end of each outer iteration.
TLB	(NL1)	[IS(49)]	T_b : Element n is the temperature [$^{\circ}\text{C}$] of boundary surface element number n. For specified-temperature fluid energy equation boundary conditions, this is initialized in routine ICTEMP (using input from array TEMP in NAMELIST DATA and 'TLB' records in the Boundary Value Initialization block of the card-image input file) and updated in routine BCTEMP0 as needed during the case. For other boundary conditions, this is computed in routine BCTEMP, BCTEMT, or QDUCTW (using QBN(n), TL(MB(n), and other quantities).
TLOLD	(NM1)	[IS(81)]	Same as array TL except that the values are for the end of the previous time step. Set in routine TIMSTP at the beginning of each time step.
TTS	(NTTS)	[IS(77)]	Element ITSCB((n-1)*11+7)+(e-1)*NPRT+p is the temperature [$^{\circ}\text{C}$] (at the center) of partition number p of element number e of thermal structure number n, where NPRT=MOD(ITSCB((n-1)*11+5),1000). Computed in routine TSTRUC.
TURCON	(NM1)	[IS(76)]	λ_t : Element n is the turbulent thermal conductivity [$\text{W}/\text{m}\cdot^{\circ}\text{C}$] for fluid cell number n when ITURKE>0. When ITURKE=1, this array is initially filled using the value of input variable TURBC in NAMELIST DATA and overridden on a cell-by-cell basis using the values specified using 'TURC' records in the Internal Cell Initialization block of

the card-image input file. When $ITURKE \geq 10$, these array values are computed in routine VISFIX ($ITURKE=10$) or TURV12 ($ITURKE \geq 11$) during each outer iteration (between the solutions of the fluid momentum and energy equation systems).

TURK	(NM1)	[IS(36)]	k: Element n is the turbulent kinetic energy [m^2/s^2] for fluid cell number n when $ITURKE \geq 11$. Computed by routine SOLVEN or SOLVEV (as called from routine TKLOOP).
TURKB	(NL1)	[IS(51)]	k_b : Element n is the turbulent kinetic energy [m^2/s^2] for boundary surface element number n when $ITURKE \geq 11$. Initialized by routine INTURK and updated by routine BCTURB during each outer iteration.
TURKO	(NM1)	[IS(12)]	Same as array TURK except that values are for the end of the previous time step. Set in routine TIMSTP at the beginning of each time step.
TURVIO	(NM1)	[IS(179)]	Same as array TURVIS except that values are for the end of the previous time step. Set in routine TIMSTP at the beginning of each time step.
TURVIS	(NM1)	[IS(37)]	μ_t : Element n is the turbulent viscosity for [$Pa \cdot s$] fluid cell number n when $ITURKE > 0$. When $ITURKE=1$, this array is initially filled using the value of input variable TURBV in NAMELIST DATA and overridden on a cell-by-cell basis using the values specified using 'TURV' records in the Internal Cell Initialization block of the card-image input file. When $ITURKE \geq 10$, these array values are computed in routine VISFIX ($ITURKE=10$) or TURV12 ($ITURKE \geq 11$) during each outer iteration (between the solutions of the fluid momentum and energy equation systems).

UL (NM1) [IS(18)] u : Element n is the x - (or r -) direction velocity [m/s] on the $+I$ face of fluid cell number n . (If $MIP(n) < 0$, then the $+I$ face lies on a boundary surface and the velocity on this cell face is not stored in array **UL**; for $MIP(n) = -9999$, this is an IREGular boundary surface and the velocity is implicitly 0; for other $MIP(n) < 0$ values, this is a REGular boundary surface and the velocity is $-VELBN(-MIP(n))$.) Computed in routine **MOMENI** (after solving the pressure equation system) during each outer iteration.

ULOLD (NM1) [IS(28)] Same as array **UL** except that values are for the end of the previous time step. Set in routine **TIMSTP** at the beginning of each time step. (Storage location $S(IS(28))$ is also used for array **REALB**.)

UWIRE (NM1) [IS(38)] Element n is the geometry coefficient of the x -direction component of the wire-wrap force vector (i.e. $f_x/(\rho w |w|)$) for fluid cell number n when $IGEOM > 0$ and $IWIRE = 2$. Computed in routine **GETWIR** at the beginning of a run.

VELBN (NL1) [IS(46)] u_n : Element m is the velocity [m/s] in the direction of the unit surface-normal vector (i.e. $VELBN(m) > 0$ is flow from the boundary toward the adjacent fluid cell) for boundary surface element number m . For specified-value velocity boundary conditions, this array is initially filled in routine **ICTEMP** (using values input for array **VELOC** in **NAMELIST DATA**), may be overridden by 'VELB' records in the Boundary Value Initialization block of the card-image input file, and is updated during every time step by routine **BCFLOT** for transient boundary conditions. For continuative velocity boundary conditions, the array values are computed in routine **BCFLOW** (using values from arrays **UL**, **VL**, **WL**, and other quantities) during every time step.

VL	(NM1)	[IS(19)]	v: Element n is the y- (or θ -) direction velocity [m/s] on the +J face of fluid cell number n. (If $MJP(n) < 0$, then the +J face lies on a boundary surface and the velocity on this cell face is not stored in array VL; for $MJP(n) = -9999$, this is an IREGular boundary surface and the velocity is implicitly 0; for other $MJP(n) < 0$ values, this is a REGular boundary surface and the velocity is $-VELBN(-MJP(n))$.) Computed in routine MOMENI (after solving the pressure equation system) during each outer iteration.
VLOLD	(NM1)	[IS(30)]	Same as array VL except that values are for the end of the previous time step. Set in routine TIMSTP at the beginning of each time step. (Storage location S(IS(30)) is also used for array DDDPOT(NM1).)
VOL+	(NM1)	[IS(95)]	V_f : Element n is the volume [m ³] of fluid in fluid cell number n as used in the conjugate-gradient solution method. Computed in routine VOLCEL at the beginning of a run. (This array could be used in more places in the program if it were defined for all cells, rather than just being defined for those cells in which the pressure is being computed.)
VWIRE	(NM1)	[IS(39)]	Element n is the geometry coefficient of the y-direction component of the wire-wrap force vector (i.e. $f_y/(\rho w w)$) for fluid cell number n when $IGEOM > 0$ and $IWIRE = 2$. Computed in routine GETWIR at the beginning of a run.
WL	(NM1)	[IS(20)]	w: Element n is the z-direction velocity [m/s] on the +K face of fluid cell number n. (If $MKP(n) < 0$, then the +K face lies on a boundary surface and the velocity on this cell face is not stored in array WL; for $MKP(n) = -9999$, this is an IREGular boundary surface and the velocity is implicitly 0; for other $MKP(n) < 0$ values, this is a REGular boundary surface and the velocity is $-VELBN(-MKP(n))$.) Computed in routine MOMENI (after solving the pressure equation system) during each outer iteration.

WLOLD	(NM1)	[IS(31)]	Same as array WL except that values are for the end of the previous time step. Set in routine TIMSTP at the beginning of each time step. (Storage location S(IS(31)) is also used for array DDDH(NM1).)
WWIRE	(NM1)	[IS(40)]	Element n is the geometry coefficient of the z-direction component of the wire-wrap force vector (i.e. $f_z/(\rho w w)$) for fluid cell number n when IGEOM > 0 and IWIRE=2. Computed in routine GETWIR at the beginning of a run.
XRw	(NM1 + 1)	[IS(108)]	Temporary work space array holding absolute value of array DL (which is the mass residual) in routine CNGRIC as part of the conjugate-gradient solution of the pressure equation system on vector machines. (Storage location S(IS(108)) is also used for array TEMPV2 in routine SOLVEV.)
XXXw	(MTP1)	[IS(133)]	Solution vector for upper- and lower- triangular matrix system (i.e. $AAL*AAU*XXX=FFF$) in the conjugate-gradient solution of the pressure equation system on vector machines. Computed and used in routine LOWFCV.

4.8 COMMON BLOCK /MACHIN/

This common block contains three INTEGERS used in connection with the storage allocation scheme (i.e. arrays IS in COMMON BLOCK /ADDCON/ and S in COMMON BLOCK /SPACE/). The values of all three variables are set in the BLOCK DATA routine and are constant for a given type of computer. The declaration statement defining the storage order is given by:

```
COMMON /MACHIN/ NOBPI,NOWPD,NOWPS
```

This common block generally occurs in routines where routine LOCF is used. The definitions

of these variables are as follows.

NOBPI Amount of storage, in units of the results returned by routine LOCF, occupied by one integer variable. Key values: for IBM mainframes (and many short-word workstations), the value should be 4 bytes per integer variable (thus giving rise to the name of the variable "number of bytes per integer"); for Cray machines, the value should be 1 word per integer variable.

NOWPD Number of words of storage for one double-precision real variable. Key values: for short-word machines, the value should be 2; for long-word machines, the value should be 1 (since there are no DOUBLE PRECISION variables). (This variable was introduced in an earlier IBM version of COMMIX in which most real variables were declared REAL and only a few were declared DOUBLE PRECISION.)

NOWPS Number of words of storage for one single-precision real variable. Key values: for short-word machines, the value should be 2 (since all real variables are DOUBLE PRECISION); for long-word machines, the value should be 1. (This variable was introduced in an earlier IBM version of COMMIX in which most real variables were declared REAL and only a few were declared DOUBLE PRECISION.)

4.9 COMMON BLOCK /REBALS/

The primary use of this common block is for storage of the equation system to be solved for mass rebalancing in routines REBAZ and REBAZG. The equation system to be solved for the pressure-correction factors (ΔP_n) is given by

$$c_n * \Delta P_{n-1} + a_n * \Delta P_n + b_n * \Delta P_{n+1} = d_n$$

where n ranges from 1 up to the number of rebalancing regions (=M below); the coefficients for this tridiagonal matrix system are set in routine REBAZ or REBAXG and the system is solved in routine TDMA; after the solution is unpacked, the coefficient arrays are no longer needed. The declaration statement defining the storage order in these routines is given by:

COMMON /REBALS/ A(99),B(99),C(99),D(99),DP(99)

The definitions of these variables are as follows.

A (99) a_n : Vector holding the main diagonal, where element $n+1$ corresponds to the coefficient for rebalancing region n , for $n=1,2,\dots,M$. (Element A(1) is not used.)

B (99) $-b_n$: Vector holding the negative of the upper diagonal, where element $n+1$ corresponds to the coefficient for rebalancing region n , for $n=1,2,\dots,M-1$. (Element B(1) is not used and element B(M) is zero.)

C (99) $-c_n$: Vector holding the negative of the lower diagonal, where element $n+1$ corresponds to the coefficient for rebalancing region n , for $n=2,3,\dots,M$. (Element C(1) is not used and element C(2) is zero.)

D (99) d_n : Vector holding the right hand side, where element $n+1$ corresponds to the term for rebalancing region n , for $n=1,2,\dots,M$. (Element D(1) is not used.)

DP (99) ΔP_n : Vector holding the solution, where element $n+1$ is the pressure correction for rebalancing region n , for $n=1,2,\dots,M$. (Element DP(1) is not used.)

Since the arrays in this common block are not needed after leaving routine REBAZ or REBAZG, their storage space is used for temporary arrays in other routines (COMMIX, INITAL, INITZ1, QGENER, IREBAL, REBAL, REBALX, REBALY, REBALZ, INPSTR, QSTRUC, QSTRDS, TSTRUC, and FITIT).

4.10 COMMON BLOCK /IMPL/

This common block contains one integer variable and is used to pass the value of NTSCUP (which is set by a PARAMETER statement) to certain routines where it was not permissible (or not convenient) to pass the value through the argument list. The declaration statement defining the storage order is given by:

COMMON /IMPL/ NODD

The definition of this variable is as follows.

NODD   The maximum number of nonadjacent fluid cells to which a fluid cell may be coupled by thermal structures. (This variable has the same value as variable NTSCUP.)

4.11 COMMON BLOCK /CSCAN/

This common block is used to pass information about the contents of the Thermal Structure Prototype block of the card-image input file from routine TSCAN to routine INPSTR. The declaration statement defining the storage order is given by

COMMON /CSCAN/ LOOK(PNSTRU+1)

where PNSTRU is the maximum number of thermal structure prototypes allowed in any run (and is set by a PARAMETER statement in the source coding). The definition of this array is as follows.

LOOK (PNSTRU+1)   Element n contains the value $100 \times \text{NMS} + \text{NOS}$ for the n^{th} thermal structure prototype in the Thermal Structure Prototype input block, where NMS is the number of material regions (i.e. the number of NAMELISTs M) and NOS indicates whether the inner (NOS=01), outer (NOS=10), or both (NOS=11)

surface(s) of the thermal structure prototype interact with fluid (i.e. the occurrence(s) of NAMELIST F). A zero is used to indicate the end of this array (i.e. if LOOK(9)=0, then there are 8 thermal structure prototypes). Filled by routine TSCAN during first reading of the Thermal Structure Prototype input block; used by routine INPSTR in second reading of the Thermal Structure Prototype input block in determining the order of the NAMELISTs; not needed after returning from INPSTR.

4.12 COMMON BLOCK /TIMING/

The real number variables in this common block are used to collect central-processor-unit (CPU) time usage information during the running of a case. This information is used primarily by the code developers. The "DTxxxx" values are summations of elapsed time, in units of CPU seconds, for various coding segments and the "Txxxxx" values are intermediate times used in computing the elapsed times. Timing information is obtained by calling system routine SECOND on Cray machines and COMMIX-1AR/P routine TLEFTS (which calls an appropriate system routine) on all other machines. The declaration statement defining the storage order is given by:

```
COMMON /TIMING/ DTMOEQ,DTMOSO,DTENEQ,DTENSO,DSTRUC,DTRAD,
+DTSTP,TMOEQ,TENEQ,DTTEEQ,DTTESO,TTEEQ,DTTDEQ,DTTDSO,TTDEQ,
+ CRATIM(26)
```

This declaration statement appears in routines AMAIN, ENLOOP, MOLOOP, TDLOOP, TKLOOP, and TIMSTP. The definitions of these variables are as follows.

CRATIM (26)   Reserved for future timing information.

DSTRUC   CPU time spent solving the thermal structure energy equations for new temperatures; more specifically, the time spent in routine TSTRUC (and routines called by it) as called from routine TIMSTP. (A significant block of time associated with thermal structures is due to calling routine QSTRUC; the

time spent in QSTRUC is currently included as part of DTENEQ.)

DTENEQ CPU time spent constructing the fluid energy equation system; more specifically, the time elapsed between calling routine ENLOOP from routine TIMSTP and calling routine SOLVEN or SOLVEV from routine ENLOOP and, thus, includes the time spent in routines BCTEMT, HSTRUC, ESORCE, and ENERGI (and routines called by them).

DTENSO CPU time spent solving the fluid energy equation system; more specifically, the time elapsed between calling routine SOLVEN or SOLVEV from routine ENLOOP and the return from routine ENLOOP to routine TIMSTP and, thus, includes the time spent in routines SOLVEN or SOLVEV and ENRBAL (and routines called by them).

DTMOEQ CPU time spent constructing the pressure (combined mass and momentum) equation system; more specifically, the time elapsed between calling routine MOLOOP from routine TIMSTP and calling routine SOLVIT or CGLOOP from routine MOLOOP and, thus includes the time spent in routines BCFLOT, XMOMI, YMOMI, ZMOMI, PEQN, GETDL, REBAZ, and REBAZG (and routines called by them).

DTMOSO CPU time spent solving the pressure (combined mass and momentum) equation system; more specifically, the time elapsed between calling routine SOLVIT or CGLOOP from routine MOLOOP and the return from routine MOLOOP to routine TIMSTP and, thus, includes the time spent in routines SOLVIT or CGLOOP, GETDL, MOMENI, and BCFLOW (and the routines called by them).

DTRAD CPU time spent constructing and solving the radiation heat transfer equation system; more specifically, the time spent in routine QSRAD (and routines it calls) as called from routine TIMSTP.

DTSTP CPU time spent doing computations; more specifically, the time spent in routine TIMSTP (and routines it calls) as called from routine AMAIN. (This is essentially everything but input and output processing time and includes the times subtotalled in the other "DTxxxx" variables.)

DTTDEQ CPU time spent constructing the turbulent kinetic energy dissipation rate equation system; more specifically, the time elapsed between calling routine TDLOOP from routine TIMSTP and calling routine SOLVEN or SOLVEV from routine TDLOOP and, thus, includes the time spent in routine TDNER (and routines called by it).

DTTDSO CPU time spent solving the turbulent kinetic energy dissipation rate equation system; more specifically, the time elapsed between calling routine SOLVEN or SOLVEV from routine TDLOOP and the return from routine TDLOOP to routine TIMSTP and, thus, includes the time spent in routine SOLVEN or SOLVEV.

DTTEEQ CPU time spent constructing the turbulent kinetic energy equation system; more specifically, the time elapsed between calling routine TKLOOP from routine TIMSTP and calling routine SOLVEN or SOLVEV from routine TKLOOP and, thus, includes the time spent in routines TKSORC and TKENER (and routines called by them).

DTTESO CPU time spent solving the turbulent kinetic energy equation system; more specifically, the time elapsed between calling routine SOLVEN or SOLVEV from routine TKLOOP and the return from routine TKLOOP to routine TIMSTP and, thus, includes the time spent in routine SOLVEN or SOLVEV.

TENEQ CPU time at which routine SOLVEN or SOLVEV was last called from routine ENLOOP; used to calculate values for variables DTENEQ and DTENSO.

TMOEQ CPU time at which routine SOLVIT or CGLOOP was last called from routine MOLOOP; used to calculate values for variables DTMOEQ and DTMOSO.

TTDEQ CPU time at which routine SOLVEN or SOLVEV was last called from routine TDLOOP; used to calculate values for variables DTTDEQ and DTTDSO.

TTEEQ CPU time at which routine SOLVEN or SOLVEV was last called from routine TKLOOP; used to calculate values for variables DTTEEQ and DTTESO.

4.13 COMMON BLOCK /TEMPRY/

This common block is used to pass time-step-size control information between routines AMAIN and TIMSTP when IDTIME=2. The declaration statement defining the storage order is given by

```
COMMON /TEMPRY/ IFIRST,NSTEPS
```

The definitions of these variables are as follows.

IFIRST The value of this variable is set to 1 (in routine AMAIN) at the beginning of the first time step taken after a time step size increase due to step-to-step changes being less than CHGMIN for NSTEPS consecutive time steps. If routine TIMSTP later finds that the time step size must be reduced during this step in order to keep step-to-step changes below CHGMAX, then the value of NSTEPS is doubled. During all other time steps, the value is 0.

NSTEPS N_0 : The number of consecutive time steps which must be completed using the same time step size with step-to-step changes less than

CHGMIN in order for the time step size to be increased when IDTIME=2. (The test of IFSHRT versus NSTEPS is made in routine AMAIN.) Initialized to 5 in routine AMAIN at beginning of job. The value is doubled in routine TIMSTP if the time step size must be decreased (in order to keep step-to-step changes less than CHGMAX) during a step for which the time step size was just increased. (This doubling of NSTEPS helps avoid useless time step size increases in ill-behaved cases. There is no corresponding logic to decrease the value of NSTEPS if things are going smoothly, although the value is reset to 5 at the beginning of each job.)

4.14 COMMON BLOCK /ARINC/

This common block contains CHARACTER-type variables for use by routines BARIN and INFORC in identifying records in several of the fixed-format blocks of the card-image input file. The declaration statements defining the storage order are given by

```
CHARACTER*4 LABEL,IEND,IFORC,IXFOR,IYFOR,IZFOR  
COMMON /ARINC/ LABEL(20),IEND,IFORC,IXFOR,IYFOR,IZFOR
```

These declaration statements are part of code module ARIN at ANL and are used in conjunction with COMMON BLOCK /ARINI/. The values of these variables are all initialized in the BLOCK DATA routine. All values are left justified with blank fill. The definitions of these variables are as follows.

IEND   Character string 'END'; used in identifying the end of the Force Structure Location, Boundary Value Initialization, and Internal Cell Initialization input blocks in routines INFORC and BARIN.

IFORC   Character string 'FORC'; not currently used.

IXFOR   Character string 'XFOR'; used in identifying records in the Force Structure Location input block in routine INFORC.

IYFOR Character string 'YFOR'; used in identifying records in the Force Structure Location input block in routine INFORC.

IZFOR Character string 'ZFOR'; used in identifying records in the Force Structure Location input block in routine INFORC.

LABEL (20) The following listing shows which character string is stored in each of the n elements of this array:

n=1: 'AREA'	n=2: 'RLB '	n=3: 'VELB'
n=4: 'QBN '	n=5: 'HLB '	n=6: 'TLB '
n=7: 'PB '	n=8: 'ALX '	n=9: 'ALY '
n=10: 'ALZ '	n=11: 'AL '	n=12: 'UL '
n=13: 'VL '	n=14: 'WL '	n=15: 'HL '
n=16: 'TL '	n=17: 'QSOU'	n=18: 'P '
n=19: 'TURV'	n=20: 'TURC'	

The first 7 elements are used in identifying records in the Boundary Value Initialization input block and the last 13 elements are used in identifying records in the Internal Cell Initialization input block, all within routine BARIN.

4.15 COMMON BLOCK /ARINI/

This common block contains INTEGER-type variables for use in processing records in the Boundary Value Initialization and Internal Cell Initialization blocks of the card-image input file. The declaration statement defining the storage order is given by

```
COMMON /ARINI/ KOM(20),KOF(20),NVAR
```

This declaration statement is part of code module ARIN at ANL and is used in conjunction with COMMON BLOCK /ARINC/. The definitions of these variables are as follows.

KOF (20) Element n is the beginning location in array S (in COMMON BLOCK /SPACE/) of the array associated with element LABEL(n). This array is filled (and later used) in routine BARIN as follows:

KOF(1)=IS(44) (array AREA)	KOF(2)=IS(45) (array RLB)
KOF(3)=IS(46) (array VELBN)	KOF(4)=IS(47) (array QBN)
KOF(5)=IS(48) (array HLB)	KOF(6)=IS(49) (array TLB)
KOF(7)=IS(50) (array PB)	KOF(8)=IS(13) (array ALX)
KOF(9)=IS(14) (array ALY)	KOF(10)=IS(15) (array ALZ)
KOF(11)=IS(16) (array AL)	KOF(12)=IS(18) (array UL)
KOF(13)=IS(19) (array VL)	KOF(14)=IS(20) (array WL)
KOF(15)=IS(22) (array HJ.)	KOF(16)=IS(23) (array TL)
KOF(17)=IS(29) (array QSOUR)	KOF(18)=IS(41) (array P)
KOF(19)=IS(37) (array TURVIS)	KOF(20)=IS(76) (array TURCON)

KOM (20)   Element n indicates the type of the array associated with element LABEL(n), where a value of 1 indicates DOUBLE PRECISION, 2 indicates REAL, and 3 indicates INTEGER. The array is filled with the value 2, except KOM(18)=1, in the BLOCK DATA routine and used in routine BARIN. (This array is somewhat superfluous at this point since (a) all real number variables are DOUBLE PRECISION on short-word machines, (b) all real number variables are REAL on long-word machines, and (c) no INTEGER arrays are fillable using the Boundary Value Initialization and Internal Cell Initialization input blocks.)

NVAR   The number of useful entries in array LABEL in COMMON BLOCK /ARINC/. This is set to 20 (i.e. the current dimension of array LABEL, since all elements are used) in the BLOCK DATA routine and used in routine BARIN.

4.16 COMMON BLOCK /INDLIM/

This common block is used to pass values from routine BARIN to routine RSET2 or RSET3 when processing records in the Boundary Value Initialization and Internal Cell Initialization blocks of the card-image input file. The declaration statement defining the storage order is given by

```
COMMON /INDLIM/ RVAL,IVAL,IB,IE,JB,JE,KB,KE,LB,LE
```

The values of these variables, except for LB and LE, are the values read from the input record.

The definitions of these variables are as follows.

IB	Beginning value of range for spatial location index I.
IE	Ending value of range for spatial location index I.
IVAL	An INTEGER value to be assigned to array elements corresponding to fluid cells (or cell faces) having spatial location indices (I,J,K) or to boundary surface element numbers L having spatial location indices (I,J,K), where $IB \leq I \leq IE$, $JB \leq J \leq JE$, $KB \leq K \leq KE$, and $LB \leq L \leq LE$. (Not currently used since no INTEGER arrays are filled using these input blocks.)
JB	Beginning value of range for spatial location index J.
JE	Ending value of range for spatial location index J.
KB	Beginning value of range for spatial location index K.
KE	Ending value of range for spatial location index K.
LB	The first boundary surface element number for boundary surface number N. Set in BARIN based on the value read for N; used in routine RSET3 (but not in routine RSET2).
LE	The last boundary surface element number for boundary surface number N. Set in BARIN based on the value read for N; used in routine RSET3 (but not in routine RSET2).
RVAL	A real number value (type REAL on long-word machines and type DOUBLE PRECISION on short-word machines) to be assigned to array elements corresponding to fluid cells (or cell faces) having spatial location indices (I,J,K)

or to boundary surface element numbers L having spatial location indices (I,J,K), where $IB \leq I \leq IE$, $JB \leq J \leq JE$, $KB \leq K \leq KE$, and $LB \leq L \leq LE$.

4.17 COMMON BLOCK /CCORR/

This common block contains the constants used in the basic form allowed for the friction factor correlations for the force structure model. The declaration statement defining the storage order is given by

```
COMMON /CCORR / ACORRL(20),BCORRL(20),CCORRL(20),
+ ACORRT(20),BCORRT(20),CCORRT(20),REYTRN(20),CCOEND
```

This declaration statement is identified as module CCORR in the code at ANL. The friction factor, F, from correlation number M (set by $M = ICORR(NF)$, where NF is the force structure number) is computed in routine FORCES when $1 \leq M \leq NCORR \leq 20$ using coding equivalent to

```
IF (RE.LE.REYTRN(M)) THEN
  F=ACORRL(M)*RE**BCORRL(M)+CCORRL(M)
ELSE
  F=ACORRT(M)*RE**BCORRT(M)+CCORRT(M)
ENDIF
```

where RE is the Reynolds number; this coding may be viewed as allowing for a laminar and a turbulent range within each correlation. (The dimension of these arrays could be increased (up to a limit of 99) but changes would be needed in routine FORCES. Currently, friction factor correlation numbers 81-87 and 90-95 are special forms coded directly in routine FORCES.) The seven arrays in this common block are input in NAMELIST DATA. These arrays are currently passed to routine FORCES from the calling routine through the parameter list, rather than the common block statement appearing in routine FORCES. The definitions of these variables are as follows.

ACORRL(20) C_{aFtm} : Element m is the Reynolds number multiplier in friction factor correlation number m for $RE \leq REYTRN(m)$ (e.g. laminar). Other logic in the program requires this to be the first item in COMMON BLOCK /CCORR/.

- ACORRT(20)** C_{aFtm} : Element m is the Reynolds number multiplier in friction factor correlation number m for $RE > REYTRN(m)$ (e.g. turbulent).
- BCORRL(20)** C_{bFtm} : Element m is the Reynolds number exponent in friction factor correlation number m for $RE \leq REYTRN(m)$ (e.g. laminar).
- BCORRT(20)** C_{bFtm} : Element m is the Reynolds number exponent in friction factor correlation number m for $RE > REYTRN(m)$ (e.g. turbulent).
- CCOEND** Last variable in **COMMON BLOCK /CCORR/**. Value is irrelevant. Storage Location is only referenced in connection with calculating the length of the common block.
- CCORRL(20)** C_{cFtm} : Element m is the additive constant in friction factor correlation number m for $RE \leq REYTRN(m)$ (e.g. laminar).
- CCORRT(20)** C_{cFtm} : Element m is the additive constant in friction factor correlation number m for $RE > REYTRN(m)$ (e.g. turbulent).
- REYTRN(20)** Re_{tm} : Element m is the transition Reynolds number for friction factor correlation number m . Array elements **ACORRL(m)**, **BCORRL(m)**, and **CCORRL(m)** are used for $RE \leq REYTRN(m)$ (e.g. laminar), and array elements **ACORRT(m)**, **BCORRT(m)**, and **CCORRT(m)** are used for $RE > REYTRN(m)$.

4.18 COMMON BLOCK /CHEATC/

This common block contains the constants used in the basic structure/fluid heat transfer correlations. The declaration statement defining the storage order is given by

```
COMMON /CHEATC/ HEATC1(20),HEATC2(20),HEATC3(20),HEATC4(20),
+ CHEEND
```

This declaration statement is identified as module CHEATC at ANL. When the heat transfer correlation index number, n , is in the range $1 \leq n \leq NHEATC \leq 20$, the heat transfer coefficient, U , is computed in routine HEATCF from $U = (\lambda_l / D_h) * Nu_n$, where λ_l is the laminar thermal conductivity, D_h is the characteristic length, Nu_n is the Nusselt number calculated from $HEATC1(n) + HEATC2(n) * Re^{HEATC3(n)} * Pr^{HEATC4(n)}$, Re is the Reynolds number, and Pr is the Prandtl number. (The dimension of these arrays could be increased (up to a limit of 50) but some error traps would need to be changed in the program. Heat transfer coefficients indexed by correlation numbers 51 through 99 are computed in routine HEATCU, which must be supplied by the user in order to use correlation number in this range.) The four arrays in this common block are input in NAMELIST DATA. The definitions of these variables are as follows.

CHEEND Last variable in COMMON BLOCK /CHEATC/. Value is irrelevant. Storage location is only referenced in connection with calculating the length of the common block.

HEATC1(20) C_{1Nn} : Element n is the additive constant in the expression used to compute the Nusselt number from heat transfer correlation number n . Other logic in the program requires this to be the first item in COMMON BLOCK /CHEATC/.

HEATC2(20) C_{2Nn} : Element n is the multiplicative constant in the expression used to compute the Nusselt number from heat transfer correlation number n .

HEATC3(20) C_{3Nn} : Element n is the Reynolds number exponent in the expression used to compute the Nusselt number from heat transfer correlation number n .

HEATC4(20) C_{4Nn} : Element n is the Prandtl number exponent in the expression used to compute the Nusselt number from heat transfer correlation number n .

4.19 COMMON BLOCK /CPUMP/

This common block contains variables associated with pump modeling and are, thus, only used when IFPUMP > 0 in NAMELIST DATA. The declaration statements defining the storage order are given by

```
DOUBLE PRECISION NCUT      <-- short-word machines only
REAL NCUT                  <-- long-word machines only
INTEGER PUMEND
COMMON /CPUMP/ CORPH8(9), CORPT8(18),
+ REYTRP(5), ACORP(5), BCORP(5), CCORP(5), DPSS(5), PSSO(5),
+ ALPHAL(5), ALPHAT(5), PUMLEN(5), QFLOW(5), QFLOWR(5),
+ PUMPS(5), PUMPSR(5), PUMPH(5), PUMPHR(5), TORQ(5), TORQR(5),
+ TORQF(5), TORQFR(5), TORQM(5), CUTPH(3), CUTPT(3), CUTPF(3),
+ PINER(5), CORPH(15), CORPT(8), CORPF(9),
+ QCUT, QCUTC, DENRO, NCUT,
+ ICORP(5), IDIRP(5), NTPUMP(5), IJKPP(5), NTORQM(5),
+ NCORRP, NPUMP, IFQCUT, IPUBUG, IPTRAN, PUMEND
```

These declaration statements are identified as code module CPUMP at ANL. The definitions of these variables are as follows.

ACORP(5) a_n : Element n is the overall multiplicative coefficient [Pa] in the pressure-increase expression for pump number n when IFPUMP=1. Input in NAMELIST PUMP. Used in routine PUMPQ.

ALPHAL(5) d_{ln} : Element n is the exponent [-] of $|\tilde{Q}|$ when the Reynolds number is less than or equal to REYTRP(n) in the pressure-increase expression for pump number n when IFPUMP=1. Input in NAMELIST PUMP. Used in routine PUMPQ.

ALPHAT(5) d_{ln} : Element n is the exponent [-] of $|\tilde{Q}|$ when the Reynolds number is greater than REYTRP(n) in the pressure-increase expression for pump number n when IFPUMP=1. Input in NAMELIST PUMP. Used in routine PUMPQ.

- BCORP(5)** b_n : Element n is the multiplicative coefficient [-] of $\tilde{N} \cdot \tilde{Q}$ in the pressure-increase expression for pump number n when IFPUMP=1. Input in NAMELIST PUMP. Used in routine PUMPQ.
- CCORP(5)** c_n : Element n is the multiplicative coefficient [-] of $|\tilde{Q}|^d$ in the pressure-increase expression for pump number n when IFPUMP=1. Input in NAMELIST PUMP. Used in routine PUMPQ.
- CORPF(9)** $C_{f,i}$: Element i is the i^{th} coefficient in the frictional torque function (WF) when IFPUMP=3 or 4 and ICORP(n)=1 for pump number n. Input in NAMELIST PUMP. Used in routine PUMPQ.
- CORPH(15)**   Not currently used (although appears in NAMELIST PUMP).
- CORPH8(9)** $C_{h,i}$: Element i is the i^{th} coefficient in the head function (WH) when IFPUMP=3 or 4 and ICORRP(n)=1 for pump number n. Input in NAMELIST PUMP. Used in routine PUMPQ. Other logic in the program requires this to be the first item in COMMON BLOCK /CPUMP/.
- CORPT(8)** $C_{r,i}$: Element i ($2 \leq i \leq 6$) is the i^{th} coefficient in the hydraulic torque function (WT) when IFPUMP=3 or 4 and ICORP(n)=50 for pump number n. Input in NAMELIST PUMP. Used in routine PUMPQ. (Element numbers 1, 7, and 8 are not currently used.)
- CORPT8(18)** $C_{r,i}$: Element i is the i^{th} coefficient in the hydraulic torque function (WT) when IFPUMP=3 or 4 and ICORP(n)=1 for pump number n. Element numbers 1 through 9 are used when IFPUMP=3, and element numbers 10 through 18 are used when IFPUMP=4. Input in NAMELIST PUMP. Used in routine PUMPQ.

- CUTPF(3)** $C_{f, cut, i}$: Element i ($1 \leq i \leq 2$) is the relative speed at which to switch from range i to range $i+1$ in the frictional torque function (WF) when IFPUMP=3 or 4 and ICORP(n)=1 for pump number n . Input in NAMELIST PUMP. Used in routine PUMPQ. (Element number 3 is not currently used.)
- CUTPH(3)** Not currently used (although CUTPH(1)=2.053 is set in routine INPUMP.)
- CUTPT(3)** Not currently used (although appears in NAMELIST PUMP).
- DENRO** $\rho * g$: Product of fluid density and gravitational acceleration [$\text{kg}/\text{m}^3/\text{s}^2$] used in converting from head [m] to pressure [Pa] when IFPUMP=3 or 4. Input in NAMELIST PUMP. Used in routine PUMPQ.
- DPSS(5)** $\Delta P_{p, ss}$: Element n is the pressure increase supplied by pump number n at steady state. Set to value of ΔP_p in routine PUMPQ when IFPUMP=1, 3, or 4 and ISTATE ≤ 1 (i.e. steady-state calculation). Used to compute ΔP_p in routine PUMPQ when IFPUMP=2 and ISTATE ≥ 2 (i.e. transient calculation).
- ICORP(5)** Element n is the correlation number to use for pump number n when IFPUMP=1, 3, or 4. Input in NAMELIST DATA. Used in routine PUMPQ. Allowed values: IFPUMP=1: must be 1; IFPUMP=3 or 4: 1 is general homologous model and 50 is CRBR pump.
- IDIRP(5)** Element n indicates the orientation (i.e. flow direction) for pump number n . Set in routine INPUMP based on records in the Pump Location block of the card-image input file. Used in routines XMOMI, YMOMI, and ZMOMI (in conjunction with array IJKPP) to determine whether routine PUMPQ is to be called when constructing the momentum equation for a specific momentum control volume. Key values: 1: x (or r) direction (set by reading a 'PUMX' record); 2 = y (or θ) direction (set by reading a 'PUMY' record); 3: z direction (set by reading a 'PUMZ' record).

IFQCUT Flag indicating whether variable QCUTC has been set when IFPUMP=3 or 4, ICORP(n)=1, and ISTATE $\geq$ 2. Set and used in routine PUMPQ. Key values: 0: no; 1: yes.

IJKPP(5) Element n contains the spatial location indices of the fluid cell in which pump number n is located. Set in routine INPUMP to 10000*IB+100*JB+KB, where IB, JB, and KB are the spatial location indices specified in the record for pump number n in the Pump Location block of the card-image input file. Used in routines XMOMI, YMOMI, and ZMOMI (in conjunction with array IDIRP) to determine whether routine PUMPQ is to be called when constructing the momentum equation for a specific momentum control volume. (This storage scheme imposes limits: IMAX $\leq$ 99, JMAX $\leq$ 99, and KMAX $\leq$ 99.)

IPTRAN Flag indicating method to be used in integrating the pump motor torque (τ_m) when IFPUMP=3 or 4, NTORQM(n)>0 for pump number n, and ISTATE $\geq$ 2. Input in NAMELIST PUMP. Used in routine PUMPQ. Key values: 0: approximate; 1: exact.

IPUBUG Flag activating printing associated with pumps in routine PUMPQ. Input in NAMELIST PUMP. Key values: 0: off; >0: on. (This generally should be >0, else the user will be provided with too little information regarding the pumps; the appropriate nonzero value currently depends on IFPUMP; code needs to be restructured to add pump output to the Global Balances page (printed by routine OUTPUT), unify the hierarchy of IPUBUG, and allow input of IPUBUG in NAMELIST DATA.)

NCORRP Number of different pump correlation sets when IFPUMP=1. Input in NAMELIST PUMP. Used in routine INPUMP. Key value: Must be 1. (Current logic in routine PUMPQ does not allow for multiple correlation sets.)

- NCUT** $\tilde{N}_{cut}$: Relative speed below which to use a linear head versus flow relationship when IFPUMP=3 or 4, ICORP(n)=1 for pump number n, and ISTATE $\geq$ 2. In contrast to the normal typing declarations in FORTRAN, this is a real number variable. Input in NAMELIST PUMP. Used in routine PUMPQ (in conjunction with variable QCUT) in setting the value of QCUTC. (Further details are given under the entry for variable QCUTC.)
- NPUMP** The number of pumps in the calculation when IFPUMP>0. Input in NAMELIST PUMP. Used in numerous routines (e.g. TIMSTP, PUMPQ, XMOMI, YMOMI, and ZMOMI). Restriction: NPUMP $\leq$ 5.
- NTORQM(5)** Element n is the number of the transient function used in setting the relative motor torque for pump number n when IFPUMP=3 or 4 and ISTATE $\geq$ 2. Input in NAMELIST PUMP. Used in routine PUMPQ. Restrictions: (1) NTORQM(n) $\leq$ 25; (2) if NTPUMP(n)>0 then NTORQM(n)=0 and vice versa.
- NTPUMP(5)** Element n is the number of the transient function used in setting (1) the relative speed for pump number n when IFPUMP=1, 3, or 4 and ISTATE $\geq$ 2 and (2) the relative pressure increase for pump number n when IFPUMP=2 and ISTATE $\geq$ 2. Input in NAMELIST PUMP. Used in routine PUMPQ. Restrictions: (1) IFPUMP=1 or 2: 1 $\leq$ NTPUMP(n) $\leq$ 25; (2) IFPUMP=3 or 4: (a) 0 $\leq$ NTPUMP(n) $\leq$ 25; (b) if NTORQM(n)>0 then NTPUMP(n)=0 and vice versa.
- PINER(5)** I_p : Element n is the moment of inertia [kg $\cdot$ m²] for the rotating elements of pump number n when IFPUMP=3 or 4, NTORQM(n)>0, and ISTATE $\geq$ 2. Input in NAMELIST PUMP. Used in routine PUMPQ.
- PSSO(5)** Same as array PUMPS except that values are for the end of the previous time step. Set in routine TIMSTP at the beginning of each time step.

- PUMEND** Last variable in COMMON BLOCK /CPUMP/. Value is irrelevant. Storage location is only referenced in connection with calculating the length of the common block.
- PUMLEN(5)** L: Element n is the characteristic length [m] used in computing the Reynolds number for pump number n when IFPUMP=1. Input in NAMELIST PUMP. The Reynolds number is computed in routine PUMPQ and is compared with array element REYTRP(n) to decide whether to use array element ALPHAL(n) or ALPHAT(n) as the exponent in the pressure increase correlation.
- PUMPH(5)** H: Element n is the head [m] supplied by pump number n for IFPUMP=3 or 4. Computed in routine PUMPQ. (Although it appears in NAMELIST PUMP, values should not be input.)
- PUMPHR(5)** H_R : Element n is the reference head [m] for pump number n when IFPUMP=3 or 4. Input in NAMELIST PUMP. Used in routine PUMPQ.
- PUMPS(5)** N: Element n is the speed [revolution/minute] for pump number n when IFPUMP=1, 3, or 4. Input in NAMELIST PUMP at ISTATE=0; computed in routine PUMPQ for ISTATE $\geq$ 2. Used in routines TIMSTP and PUMPQ.
- PUMPSR(5)** N_R : Element n is the reference speed [revolution/minute] for pump number n when IFPUMP=1, 3, or 4. Input in NAMELIST PUMP. Used in routines TIMSTP and PUMPQ.
- QCUT** $\tilde{Q}_{cut}$: Relative volumetric flow rate below which to use a linear head versus flow relationship when IFPUMP=3 or 4, ICORP(n)=1 for pump number n, and ISTATE $\geq$ 2. Input in NAMELIST PUMP. Used in routine PUMPQ (in conjunction with variable NCUT) in setting the value of QCUTC. (Further details are given under the entry for variable QCUTC.)

- QCUTC** $\tilde{H}_{tcat}/\tilde{Q}_{tcat}$: Relative head to relative flow ratio used in computing pump head in low-head/low-flow regime when IFPUMP=3 or 4, ICORP(n)=1, and ISTATE $\geq$ 2. Value is set to (PUMPH(n)/PUMPHR(n))/(QFLOW(n)/QFLOWR(n)) in routine PUMPQ when the following two relationships are first satisfied for any pump number n: (1) relative pump speed (PUMPS(n)/PUMPSR(n)) is less than NCUT and (2) relative volumetric flow rate (QFLOW(n)/QFLOWR(n)) is less than QCUT. After these relationships are satisfied for any pump, the low-head/low-flow regime linear head versus flow relationship will be used for all pumps which satisfy the above two relationships (and the same value of QCUTC is used for all pumps). (Although QCUTC appears in NAMELIST PUMP, a value should not be input.)
- QFLOW(5)** Q: Element n is the volumetric flow rate [m³/s] for pump number n when IFPUMP=1, 3, or 4. Computed in routine PUMPQ based on current velocity in pump. Used in routines TIMSTP and PUMPQ. (BUG: For IFPUMP=1, the equations behave as if QFLOW(n)=QFLOWR(n) for all values of ISTATE.)
- QFLOWR(5)** Q_R: Element n is the reference volumetric flow rate [m³/s] for pump number n when IFPUMP=1, 3, or 4. Input in NAMELIST PUMP. Used in routines TIMSTP and PUMPQ.
- REYTRP(5)** Re_r: Element n is the transition Reynolds number used in deciding whether to use array element ALPHAL(n) or ALPHAT(n) as the exponent in the pressure increase correlation for pump number n when IFPUMP=1. Input in NAMELIST PUMP. Used in routine PUMPQ.
- TORQ(5)** τ_h : Element n is the hydraulic torque [N·m] for pump number n when IFPUMP=3 or 4. Computed in routine PUMPQ. (Although this array appears in NAMELIST PUMP, values should not be input.)

TORQF(5) τ_f : Element n is the frictional torque [N·m] for pump number n when IFPUMP=3 or 4. Computed and used in routine PUMPQ.

TORQFR(5) τ_{fr} : Element n is the reference frictional torque [N·m] for pump number n when IFPUMP=3 or 4 and ICORP(n)=50. Input in NAMELIST PUMP. Used in routine PUMPQ.

TORQM(5) τ_{mR} : Element n is the reference motor torque [N·m] for pump number n when IFPUMP=3 or 4, NTORQM(n)>0, and ISTATE $\geq$ 2. Set in routine PUMPQ to be the sum of the hydraulic and frictional torques when ISTATE $\leq$ 1. (This array appears in NAMELIST PUMP; any values input at ISTATE=0 will be ignored; if any values are input in the card-image input file at ISTATE=2, the corresponding internally calculated value will be overridden.)

TORQR(5) τ_{hR} : Element n is the reference hydraulic torque [N·m] for pump number n when IFPUMP=3 or 4. Input in NAMELIST PUMP. Used in routine PUMPQ.

4.20 COMMON BLOCK /CR/

This common block is used in routine SMOOTH for temporary storage during the cubic-spline fitting of the transient functions. The declaration statement defining the storage order is given by

```
COMMON /CR/ R(200),R1(200),R2(200),T(200),T1(200),U(200),V(200)
```

Since this common block only appears in one routine, the variables in the common block are local to routine SMOOTH and their definitions are given as part of the discussion of that routine. (CLEANUP: These variables should probably just be allocated to normal local storage or possibly within COMMON BLOCK /REBALS/.)

4.21 Index of Global Variables

This section is an alphabetized listing of all global variables shown in Sections 4.1 through 4.20 as an aid to locating the definition of a particular variable. Shown for each variable are its name (followed by its dimensions in parentheses if the variable is an array) and the name of the common block (e.g. /SPACE/) in which the variable is stored, which, thus, identifies the text section in which the variable is defined. For the few variables in these sections which are not in a common block, the text section (e.g. §4.0) in which the variable is defined is shown instead of a common block name.

A(99)	/REBALS/	AREAW	/R4VAR/
A(7,NM1)	/SPACE/	ARUL(NM1)	/SPACE/
AA(7,MTP1)	/SPACE/	ARVL(NM1)	/SPACE/
AAL(6,MTP1)	/SPACE/	ARWL(NM1)	/SPACE/
AAU(7,MTP1)	/SPACE/	AT0(NM1)	/SPACE/
AC0(NM1)	/SPACE/	AT1(NM1)	/SPACE/
AC1(NM1)	/SPACE/	AT2(NM1)	/SPACE/
AC2(NM1)	/SPACE/	AT3(NM1)	/SPACE/
AC3(NM1)	/SPACE/	AT4(NM1)	/SPACE/
AC4(NM1)	/SPACE/	AT5(NM1)	/SPACE/
AC5(NM1)	/SPACE/	AT6(NM1)	/SPACE/
AC6(NM1)	/SPACE/	AU(7,NM1)	/SPACE/
ACOF0(NM1)	/SPACE/	B(99)	/REBALS/
ACOF1(NM1)	/SPACE/	BC0(NM1)	/SPACE/
ACOF2(NM1)	/SPACE/	BCFSIN(10,4)	/R4ARY/
ACOF3(NM1)	/SPACE/	BCOF0(NM1)	/SPACE/
ACOF4(NM1)	/SPACE/	BCORP(5)	/CPUMP/
ACOF5(NM1)	/SPACE/	BCORRL(20)	/CCORR/
ACOF6(NM1)	/SPACE/	BCORRT(20)	/CCORR/
ACORP(5)	/CPUMP/	BDOLD(NM1)	/SPACE/
ACORRL(20)	/CCORR/	BKOLD(NM1)	/SPACE/
ACORRT(20)	/CCORR/	BO	/R4VAR/
AKAPPA	/R4VAR/	BP0(NM1)	/SPACE/
AL(NM1)	/SPACE/	BT0(NM1)	/SPACE/
AL(6,NM1)	/SPACE/	C(99)	/REBALS/
AL0(NM1)	/SPACE/	C0CP(20)	/R4ARY/
ALNG(NM1)	/SPACE/	C0K(20)	/R4ARY/
ALPHA	/R4VAR/	C0RO(20)	/R4ARY/
ALPHAL(5)	/CPUMP/	C1(MTP1)	/SPACE/
ALPHAT(5)	/CPUMP/	C1CP(20)	/R4ARY/
ALX(NM1)	/SPACE/	C1K(20)	/R4ARY/
ALXN(10,10)	/R4ARY/	C1RO(20)	/R4ARY/
ALY(NM1)	/SPACE/	C1U(MTP1)	/SPACE/
ALYN(10,10)	/R4ARY/	C2(MTP1)	/SPACE/
ALZ(NM1)	/SPACE/	C2CP(20)	/R4ARY/
ALZN(10,10)	/R4ARY/	C2K(20)	/R4ARY/
AO	/R4VAR/	C2RO(20)	/R4ARY/
AREA(NL1)	/SPACE/	C2U(MTP1)	/SPACE/
AREATI(PNSTRU)	/R4ARY/	C3(MTP1)	/SPACE/
AREATO(PNSTRU)	/R4ARY/	C3U(MTP1)	/SPACE/
AREATR(PNRAD)	/R4ARY/	CCOEF(100,3)	/R4ARY/

CCOEND	/CCORR/	DTFACT	/R4VAR/
CCORP(5)	/CPUMP/	DTFUEL	/R4VAR/
CCORRL(20)	/CCORR/	DTIME	/R4VAR/
CCORRT(20)	/CCORR/	DTIME8	/R8ARY/
CDQTR	/R4VAR/	DTMOEQ	/TIMING/
CDRAGX	/R4VAR/	DTMOSO	/TIMING/
CDRAGY	/R4VAR/	DTRAD	/TIMING/
CDRAGZ	/R4VAR/	DTSTP	/TIMING/
CDTURB	/R4VAR/	DTTDEQ	/TIMING/
CHARRE	/R4VAR/	DTTDSO	/TIMING/
CHART	/RAVAR/	DTTEEQ	/TIMING/
CHEEND	/CHEATC/	DTTESO	/TIMING/
CHGMAX	/R4VAR/	DTWALL	/R4VAR/
CHGMIN	/R4VAR/	DUMAX	/R4VAR/
CLADOD	/R4VAR/	DUMAXT	/R4VAR/
CLENTH(NFORCE)	/SPACE/	DUMMY1(MIJK)	/SPACE/
CLOD	/R4VAR/	DVMAX	/R4VAR/
CORPF(9)	/CPUMP/	DVMAXT	/R4VAR/
CORPH(15)	/CPUMP/	DWMAX	/R4VAR/
CORPH8(9)	/CPUMP/	DWMAXT	/R4VAR/
CORPT(8)	/CPUMP/	DX(99)	/R8ARY/
CORPT8(18)	/CPUMP/	DY(99)	/R8ARY/
COURDT	/R4VAR/	DZ(99)	/R8ARY/
CRATIM(26)	/TIMING/	ECMAX	/R4VAR/
CT1	/R4VAR/	EE	/R4VAR/
CT2	/R4VAR/	EG	/R4VAR/
CUTPF(3)	/CPUMP/	EKL(NM1)	/SPACE/
CUTPH(3)	/CPUMP/	EKLOLD(NM1)	/SPACE/
CUTPT(3)	/CPUMP/	EMITS(PNRAD)	/R4ARY/
CWIREI	/R4VAR/	EMIW	/R4VAR/
CWIREO	/R4VAR/	EPS1	/R4VAR/
CWIREX	/R4VAR/	EPS2	/R4VAR/
CWIREY	/R4VAR/	EPS3	/R4VAR/
CWIREZ	/R4VAR/	EPS5	/R4VAR/
D(99)	/REBALS/	EPS6	/R4VAR/
DCONV	/R4VAR/	F(NM1)	/SPACE/
DCONV1	/R4VAR/	FC0H(PIFHTX)	/R4ARY/
DDDH(NM1)	/SPACE/	FC0HR(PIFHTX)	/R4ARY/
DDDHMX	/R4VAR/	FC0K(PIFHTX)	/R4ARY/
DDDP	/R4VAR/	FC0MU(PIFHTX)	/R4ARY/
DDDPOT(NM1)	/SPACE/	FC0RO(PIFHTX)	/R4ARY/
DDINV(MTP1)	/SPACE/	FC0T(PIFHTX)	/R4ARY/
DDPOT	/R4VAR/	FC1H(PIFHTX)	/R4ARY/
DENRO	/CPUMP/	FC1K(PIFHTX)	/R4ARY/
DENSE0(PIFHTX)	/R4ARY/	FC1MU(PIFHTX)	/R4ARY/
DHOH	/R4VAR/	FC1RO(PIFHTX)	/R4ARY/
DHOHT	/R4VAR/	FC1T(PIFHTX)	/R4ARY/
DL(NM1)	/SPACE/	FCX1	/R4VAR/
DLCUT	/R4VAR/	FCX2	/R4VAR/
DLMAX	/R4VAR/	FCX3	/R4VAR/
DLSUM	/R4VAR/	FCX4	/R4VAR/
DP(99)	/REBALS/	FCX5	/R4VAR/
DPSS(5)	/CPUMP/	FCY1	/R4VAR/
DRDT(NM1)	/SPACE/	FCY2	/R4VAR/
DRDTOL(NM1)	/SPACE/	FCY3	/R4VAR/
DSTRUC	/TIMING/	FCY4	/R4VAR/
DT(4)	/R8ARY/	FCY5	/R4VAR/
DTENEQ	/TIMING/	FF(NM1)	/SPACE/
DTENER	/R4VAR/	FFF(MTP1)	/SPACE/
DTENSO	/TIMING/	FINM	/R4VAR/

FORCEF(NFORCE)	/SPACE/	IFORC	/ARINC/
FVAL(100)	/R4ARY/	IFORCE(NM1)	/SPACE/
FVIEW(PNRAD,PNRAD)	/R4ARY/	IFPROP	/I4VAR/
GASMW(PIFHTX)	/R4ARY/	IFPUMP	/I4VAR/
GRAVR(99)	/R4ARY/	IFQCUT	/CPUMP/
GRAVTH(99)	/R4ARY/	IFRAD	/I4VAR/
GRAVX	/R4VAR/	IFREB	/I4VAR/
GRAVY	/R4VAR/	IFRES	/I4VAR/
GRAVZ	/R4VAR/	IFROD	/I4VAR/
HEAT(NREGTS)	/SPACE/	IFSHRT	/I4VAR/
HEATC1(20)	/CHEATC/	IGEOM	/I4VAR/
HEATC2(20)	/CHEATC/	IGETCN	/I4VAR/
HEATC3(20)	/CHEATC/	IHTOUT	/I4VAR/
HEATC4(20)	/CHEATC/	IHTWAL(99)	/I4ARY/
HL(NM1)	/SPACE/	II(MTP1)	/SPACE/
HLB(NL1)	/SPACE/	IICEL(MTP1)	/SPACE/
HOLD(NM1)	/SPACE/	IINBUG	/I4VAR/
HSINK(99)	/R4ARY/	IJK(NM1)	/SPACE/
HSTREL(NSURTS)	/SPACE/	IJKPP(5)	/CPUMP/
HYDALL	/R4VAR/	IMAX	/I4VAR/
HYDIN	/R4VAR/	IMOBUG	/I4VAR/
HYDOUT	/R4VAR/	IMREB(99,4)	/I4ARY/
HYDRA1(NSTRUC)	/SPACE/	INDHTX(NM1)	/SPACE/
HYDRA2(NSTRUC)	/SPACE/	INDTRI(PNSTRU)	/I4ARY/
HYDWAL(99)	/R4ARY/	INDTRO(PNSTRU)	/I4ARY/
I4AEND	/I4ARY/	IOUT01	/I4VAR/
I4VEND	/I4VAR/	IOUT02	/I4VAR/
IB	/INDLIM/	IOUT03	/I4VAR/
IBCFS(10)	/I4ARY/	IOUT04	/I4VAR/
IBOIL	/I4VAR/	IOUT05	/I4VAR/
IBSBUG	/I4VAR/	IOUT06	/I4VAR/
ICALL	/I4VAR/	IOUT08	/I4VAR/
ICEL(NSURTS)	/SPACE/	IOUT09	/I4VAR/
ICELL(NM1)	/SPACE/	IPART	/I4VAR/
ICHANG	/I4VAR/	IPTRAN	/CPUMP/
ICONV	/I4VAR/	IPUBUG	/CPUMP/
ICONVE	/I4VAR/	IREBIT	/I4VAR/
ICORP(5)	/CPUMP/	IRED(NM1+1)	/SPACE/
ICORR(NFORCE)	/SPACE/	IS(250)	/ADDCON/
IDDDP	/I4VAR/	ISETEN	/I4VAR/
IDIRP(5)	/CPUMP/	ISETMO	/I4VAR/
IDLBUG	/I4VAR/	ISTATE	/I4VAR/
IDODL(NM1)	/SPACE/	ISTOP1	/I4VAR/
IDRAG	/I4VAR/	ISTPR(50)	/I4ARY/
IDTIME	/I4VAR/	ISTRUC	/I4VAR/
IDUM1(NM1)	/SPACE/	ISURF(NL1)	/SPACE/
IDUM2(NM1)	/SPACE/	ISYMCH	/I4VAR/
IDUM3(NM1)	/SPACE/	IT(2)	/I4ARY/
IDUM4(NM1)	/SPACE/	ITAUTO	/I4VAR/
IE	/INDLIM/	ITDEBUG	/I4VAR/
IENBUG	/I4VAR/	ITENER	/I4VAR/
IEND	/ARINC/	ITENMX	/I4VAR/
IFACTR	/I4VAR/	ITER	/I4VAR/
IFENER	/I4VAR/	ITERMX	/I4VAR/
IFFLOT	/I4VAR/	ITIBUG	/I4VAR/
IFHTX	/I4VAR/	ITKBUG	/I4VAR/
IFIRST	/TEMPRY/	ITKMX	/I4VAR/
IFITEN	/I4VAR/	ITLAST	/I4VAR/
IFLONG	/I4VAR/	ITMASX	/I4VAR/
IFMAX	/I4VAR/	ITMAXE	/I4VAR/

ITMAXK	/I4VAR/	MATWAL(99)	/I4ARY/
ITMAXP	/I4VAR/	MAXPTP	\$4.7
ITMOMX	/I4VAR/	MB(NL1)	/SPACE/
ITSCB(NSTRUC*11)	/SPACE/	MDTOMR(MTP1)	/SPACE/
ITURK	/I4VAR/	MIJK	\$4.7
ITURKE	/I4VAR/	MIM(NM1)	/SPACE/
IUPDAT	/I4VAR/	MIMD(MTP1)	/SPACE/
IVAL	/INDLIM/	MIME(NM1+1)	/SPACE/
IWASEN	/I4VAR/	MIMN(NM1+1)	/SPACE/
IWASMO	/I4VAR/	MIMT(NM1+1)	/SPACE/
IWIRE	/I4VAR/	MIMTS(NM1+1)	/SPACE/
IXFOR	/ARINC/	MINDEX(MAXPTP,NPLANS)	/SPACE/
IXMBUG	/I4VAR/	MIP(NM1)	/SPACE/
IXREB	/I4VAR/	MIPD(MTP1)	/SPACE/
IYFOR	/ARINC/	MIPE(NM1+1)	/SPACE/
IYMBUG	/I4VAR/	MIPN(NM1+1)	/SPACE/
IYREB	/I4VAR/	MIPT(NM1+1)	/SPACE/
IZFOR	/ARINC/	MIPTS(NM1+1)	/SPACE/
IZMBUG	/I4VAR/	MJM(NM1)	/SPACE/
IZREB	/I4VAR/	MJMD(MTP1)	/SPACE/
JB	/INDLIM/	MJME(NM1+1)	/SPACE/
JCELL(NM1)	/SPACE/	MJMN(NM1+1)	/SPACE/
JE	/INDLIM/	MJMT(NM1+1)	/SPACE/
JJ(MTP1)	/SPACE/	MJMTS(NM1+1)	/SPACE/
JMAX	/I4VAR/	MJP(NM1)	/SPACE/
KB	/INDLIM/	MJPD(MTP1)	/SPACE/
KE	/INDLIM/	MJPE(NM1+1)	/SPACE/
KFLOW(99)	/I4ARY/	MJPN(NM1+1)	/SPACE/
KK(MTP1)	/SPACE/	MJPT(NM1+1)	/SPACE/
KMAX	/I4VAR/	MJPTS(NM1+1)	/SPACE/
KOF(20)	/ARINI/	MKM(NM1)	/SPACE/
KOM(20)	/ARINI/	MKMD(MTP1)	/SPACE/
KPRES(99)	/I4ARY/	MKME(NM1+1)	/SPACE/
KPROP(99)	/I4ARY/	MKMN(NM1+1)	/SPACE/
KRADTS(1)	/I4ARY/	MKMT(NM1+1)	/SPACE/
KTEMP(99)	/I4ARY/	MKMTS(NM1+1)	/SPACE/
LABEL(20)	/ARINC/	MKP(NM1)	/SPACE/
LASTDT	/I4VAR/	MKPD(MTP1)	/SPACE/
LASTIT	/I4VAR/	MKPE(NM1+1)	/SPACE/
LB	/INDLIM/	MKPN(NM1+1)	/SPACE/
LBL1	/ADDCON/	MKPT(NM1+1)	/SPACE/
LBL2	/ADDCON/	MKPTS(NM1+1)	/SPACE/
LBL3	/ADDCON/	MPIN(19)	/I4ARY/
LBL4	/ADDCON/	MREB(IFREB)	/SPACE/
LBL5	/ADDCON/	MRTOMD(MTP1)	/SPACE/
LBL6	/ADDCON/	MSWEEP(NM1)	/SPACE/
LBL7	/ADDCON/	MTOMD(NM1+1)	/SPACE/
LBS(99)	/I4ARY/	MTOMR(NM1+1)	/SPACE/
LCI (99)	/I4ARY/	MTP1	\$4.7
LCONV	/I4VAR/	MTSODD(NM1+1,NTSCUP)	/SPACE/
LCX(99)	/I4ARY/	MWIRE(50,19)	/I4ARY/
LCY(99)	/I4ARY/	NA(7,NM1)	/SPACE/
LCZ(99)	/I4ARY/	NAA(7,MTP1)	/SPACE/
LE	/INDLIM/	NCORR	/I4VAR/
LES(99)	/I4ARY/	NCORRP	/CPUMP/
LHEAD	/I4VAR/	NCUT	/CPUMP/
LMPRNT	/I4VAR/	NDG(MTP1)	/SPACE/
LOOK(PNSTRU+1)	/CSCAN/	NEND(25)	/I4ARY/
M0TOMR(NM1+1)	/SPACE/	NEWTS	/I4VAR/
MATERL(NREG)	/SPACE/	NFCN	/I4VAR/

NFORCE	/I4VAR/	OARV(NM1)	/SPACE/
NHEATC	/I4VAR/	OARW(NM1)	/SPACE/
NIMTS(NM1+1)	/SPACE/	OMEGA	/R4VAR/
NIPTS(NM1+1)	/SPACE/	OMEGAD	/R4VAR/
NJMTS(NM1+1)	/SPACE/	OMEGAE	/R4VAR/
NJPTS(NM1+1)	/SPACE/	OMEGAK	/R4VAR/
NKMTS(NM1+1)	/SPACE/	OMEGAR	/R4VAR/
NKPTS(NM1+1)	/SPACE/	OMEGAT	/R4VAR/
NL	/I4VAR/	OMEGAV	/R4VAR/
NL(NPLANS)	/SPACE/	OMR	/R4VAR/
NL1	/I4VAR/	P(NM1)	/SPACE/
NLAST(25)	/I4ARY/	P(NM1)	/SPACE/
NM	/I4VAR/	PB(NL1)	/SPACE/
NM(9,NM1)	/SPACE/	PI	/R4VAR/
NM1	/I4VAR/	PIFHTX	\$4.0
NMATER	/I4VAR/	PINER(5)	/CPUMP/
NMAX(NPLANS)	/SPACE/	PINPOW(1)	/R4ARY/
NMM(9,MTP1)	/SPACE/	PITCH	/R4VAR/
NMNP(6,NM1)	/SPACE/	PITCHX	/R4VAR/
NOBPI	/MACHIN/	PITCHY	/R4VAR/
NODD	/IMPL/	PNRAD	\$4.0
NOFQT	/I4VAR/	PNSTRU	\$4.0
NOHTX(PIFHTX)	/I4ARY/	POLD(NM1)	/SPACE/
NOWPD	/MACHIN/	PRES(99)	/R4ARY/
NOWPS	/MACHIN/	PRES0(PIFHTX)	/R4ARY/
NPARTS	/I4VAR/	PRNDLD	/R4VAR/
NPINS	/I4VAR/	PRNDLH	/R4VAR/
NPL	/I4VAR/	PRNDLK	/R4VAR/
NPLANS	\$4.7	PSSO(5)	/CPUMP/
NPR	/I4VAR/	PSTAT0(NM1)	/SPACE/
NPUMP	/CPUMP/	PUMEND	/CPUMP/
NRAD	/I4VAR/	PUMLEN(5)	/CPUMP/
NREBM(99)	/I4ARY/	PUMPH(5)	/CPUMP/
NREBP	/I4VAR/	PUMPHR(5)	/CPUMP/
NREBRS(5)	/I4ARY/	PUMPS(5)	/CPUMP/
NREBRT	/I4VAR/	PUMPSR(5)	/CPUMP/
NREBX(99)	/I4ARY/	QBN(NL1)	/SPACE/
NREBY(99)	/I4ARY/	QCUT	/CPUMP/
NREBZ(99)	/I4ARY/	QCUTC	/CPUMP/
NREGTS	/I4VAR/	QFLOW(5)	/CPUMP/
NSTEPS	/TEMPRY/	QFLOWR(5)	/CPUMP/
NSTREL	/I4VAR/	QFLUID(2*PNSTRU)	/R4ARY/
NSTRUC	/I4VAR/	QFLUX	/R4VAR/
NSURF	/I4VAR/	QIJ(10,10)	/R4ARY/
NSURTS	/I4VAR/	QK(99)	/R4ARY/
NTHCON(11)	/I4ARY/	QNOGHT(NM1+1,6+NTSCUP)	/SPACE/
NTHPR(50)	/I4ARY/	QPRIME(NM1+1,6+NTSCUP)	/SPACE/
NTIME	/I4VAR/	QRADTW	/R4VAR/
NTJUMP	/I4VAR/	QRNET(PNRAD)	/R4ARY/
NTMAX	/I4VAR/	QROLD(PNRAD)	/R4ARY/
NTORQM(5)	/CPUMP/	QSCOO	/R4VAR/
NTPLOT(26)	/I4ARY/	QSOLID(PNSTRU)	/R4ARY/
NTPRNT(51)	/I4ARY/	QSOUR(NM1)	/SPACE/
NTPUMP(5)	/CPUMP/	R(NM1)	/SPACE/
NTSCUP	\$4.7	R(200)	/CR/
NTSODD(NM1+1,NTSCUP)	/SPACE/	R1(200)	/CR/
NTTS	/I4VAR/	R2(200)	/CR/
NU(NPLANS)	/SPACE/	R4AEND	/R4ARY/
NVAR	/ARINI/	R4VEND	/R4VAR/
OARU(NM1)	/SPACE/	R8AEND	/R8ARY/

RDTIME	/R4VAR/	TREST	/R4VAR/
RDUM1(NM1)	/SPACE/	TROD(PNRAD)	/R4ARY/
REALB(NM1)	/SPACE/	TSINK(99)	/R4ARY/
RELAXE	/R4VAR/	TSTART	/R4VAR/
RELAXK	/R4VAR/	TTDEQ	/TIMING/
REYLEN(NFORCE)	/SPACE/	TTEEQ	/TIMING/
REYTRN(20)	/CCORR/	TTS(NTTS)	/SPACE/
REYTRP(5)	/CPUMP/	TURBC	/R4VAR/
RL(NM1)	/SPACE/	TURBCO	/R4VAR/
RLB(NL1)	/SPACE/	TURBV	/R4VAR/
RLOLD(NM1)	/SPACE/	TURCON(NM1)	/SPACE/
RMU(NM1)	/SPACE/	TURK(NM1)	/SPACE/
RMU(NM1)	/SPACE/	TURKB(NL1)	/SPACE/
RODFR(NSTRUC)	/SPACE/	TURKO(NM1)	/SPACE/
ROUT01	/R4VAR/	TURVIO(NM1)	/SPACE/
ROUT02	/R4VAR/	TURVIS(NM1)	/SPACE/
RVAL	/INDLIM/	TVAL(100)	/R4ARY/
S(sdim)	/SPACE/	U(200)	/CR/
SCHL(NM1)	/SPACE/	UL(NM1)	/SPACE/
SCHL(NM1)	/SPACE/	ULOLD(NM1)	/SPACE/
SIZE(NREGTS)	/SPACE/	UWIRE(NM1)	/SPACE/
SPAEND	/SPACE/	V(200)	/CR/
SPHL(NM1)	/SPACE/	VELBN(NL1)	/SPACE/
SPHODL(NM1+1,NTSCUP)	/SPACE/	VELMAX	/R4VAR/
SQRT3	/R4VAR/	VELOC(99)	/R4ARY/
STAREA(NPARTS)	/SPACE/	VL(NM1)	/SPACE/
STVOL(NPARTS)	/SPACE/	VLOLD(NM1)	/SPACE/
T(200)	/CR/	VOL(NM1)	/SPACE/
T1(200)	/CR/	VWIRE(NM1)	/SPACE/
TDIN	/R4VAR/	WALLCL	/R4VAR/
TEMBT0(NM1+1)	/SPACE/	WALLDX(99)	/R4ARY/
TEMDEL(NM1+1)	/SPACE/	WALLQS(99)	/R4ARY/
TEMP(99)	/R4ARY/	WETLEN(10,10)	/R4ARY/
TEMP0(PIFHTX)	/R4ARY/	WIREP	/R4VAR/
TEMP01(NM1+1)	/SPACE/	WL(NM1)	/SPACE/
TEMP02(NM1+1)	/SPACE/	WLOLD(NM1)	/SPACE/
TEMP03(NM1+1)	/SPACE/	WODIN	/R4VAR/
TEMP04(NM1+1)	/SPACE/	WODOUT	/R4VAR/
TEMPV(NM1+1)	/SPACE/	WWIRE(NM1)	/SPACE/
TEMPV1(NM1+1)	/SPACE/	X(99)	/R8ARY/
TEMPV2(NM1+1)	/SPACE/	XMAXX	/R4VAR/
TEMPY(NM1+1)	/SPACE/	XNORML(99)	/R4ARY/
TENEQ	/TIMING/	XPRES0(PIFHTX)	/R4ARY/
TIMAX	/R4VAR/	XR(NM1+1)	/SPACE/
TIME	/R4VAR/	XXX(MTP1)	/SPACE/
TIME8	/R8ARY/	Y(99)	/R8ARY/
TKED(NM1)	/SPACE/	YCOEF(100)	/R4ARY/
TKEDB(NL1)	/SPACE/	YMAXX	/R4VAR/
TKEDO(NM1)	/SPACE/	YNORML(99)	/R4ARY/
TKIN	/R4VAR/	YPRES0(PIFHTX)	/R4ARY/
TL(NM1)	/SPACE/	Z(99)	/R8ARY/
TLB(NL1)	/SPACE/	ZAT0	/R4VAR/
TLOLD(NM1)	/SPACE/	ZMAXX	/R4VAR/
TMOEQ	/TIMING/	ZNORML(99)	/R4ARY/
TORQ(5)	/CPUMP/	ZPRES0(PIFHTX)	/R4ARY/
TORQF(5)	/CPUMP/		
TORQFR(5)	/CPUMP/		
TORQM(5)	/CPUMP/		
TORQR(5)	/CPUMP/		
TPRNT(51)	/R4ARY/		

5. DESCRIPTION OF ROUTINES

This section presents a description of each routine which is part of the program. The routines are presented in alphabetical order. (The order in which routines are called is discussed in Sec. 2.3. of this report.) Noted for each routine are the following: (1) the type of routine (e.g. PROGRAM, SUBROUTINE, or FUNCTION), (2) what it does (i.e. key equations used and variable values altered), (3) what portion(s) of what file(s) it reads or writes (with exception of the printable output file), (4) what routines call it, and (5) what routines it calls (with exception of standard FORTRAN library routines). Descriptions are also included for the six statement functions used for "simplified" fluid properties; however, references to these statement functions are not shown in the "calls" list for the other routines.

AAMAIN   This program prints the code identification banner, reads the card-image input file and echoes it to the printer, reads NAMELIST GEOM from the card-image input file, reads the first record of input restart file, performs a quasi-dynamic allocation of variable storage within COMMON BLOCK /SPACE/ and prints a summary of this, writes the first record of the output restart file, zeroes (most) common blocks, and transfers control to AMAIN.

Called by operating system.

Calls LOCF, TSCAN, MXPLNS, ALTER, ERRCHK, CLEAR, AMAIN.

ALTER   The dimension of array S in this subroutine sets the size of COMMON BLOCK /SPACE/, which is where most arrays are stored. (This routine is typically compiled during every COMMIX-1AR/P run and linked with the object code from all other routines to form an executable code.) When called, this routine returns (through variable NAVAIL in the argument list) the length (in units of computer words) of COMMON BLOCK /SPACE/.

Called by AAMAIN.

Calls LOCF.

AMAIN   This subroutine is effectively the main controller for the calculation; it

does most of its work by calling other routines. These other routines read the problem input, set up geometry connections, and initialize variables. Then control is passed to TIMSTP to advance variables over a single time step. Upon return from TIMSTP, checks are made for whether results are to be printed and for case termination (e.g. steady state, too little CPU time left, etc.); if it is not time to terminate, then the routine loops back and calls TIMSTP to advance variables across the next step.

Called by AAMAIN (but does not return).

Calls GEOM3D, INITAL, HSTRUC, TSTRUC, QSTRUC, GETMTS, INITZ1, INITUR, OUTPUT, GDCONV, GDDDH, PLTAPE, ERRCHK, WATSTP, WATTIM, TIMSTP, BOIL, GETEKL, RESTAR, TLEFTS; TLIQ, ROLIQ, DRODHL, CPLIQ.

AXHEF   This subroutine initializes an axial heat flux distribution, QK(k), if IQ > 0 (primarily used for rod bundle geometry).

Called by QGENER.

Calls nothing.

BARIN   This subroutine reads the boundary value initialization and internal cell initialization blocks of the card-image input file and uses this information to set the indicated boundary surface and cell variable values. These input blocks are readable in any run (not just at beginning of a case). The values are read after doing the uniform initialization indicated in NAMELIST DATA. The arrays are filled using routines xSET3 and xSET2 (where "x" is "R", "D", or "I"), which receive some of the information they need through COMMON BLOCK /INDLIM/. A record with 'END' in positions 1 through 4 terminates each of these two input blocks. Routine REDEF is called to adjust porosities to proper internal form if cylindrical geometry is being used.

Called by INITAL.

Calls ERRCHK, RSET3, DSET3, ISET3, RSET2, DSET2, ISET2, REDEF, REDEF2.

BCFLOF This subroutine looks at all boundary surfaces (N). If an expansion-cell velocity boundary condition ($KFLOW(N) = -6$) was specified, then the volume porosity (AL) of the associated cell is adjusted to compensate for the amount of mass which appeared to cross the boundary surface during the time step. This adjustment is performed at the end of a totally converged time step. A warning is issued if cell volume porosity drops below 0.07; a flag is set to stop the calculation if cell volume porosity drops below 0.02.

Called by TIMSTP.

Calls LBLE.

BCFLOT This subroutine looks at all boundary surfaces (N). If a specified-value transient velocity boundary condition was specified, then the velocity of all surface elements (L) of the boundary surface are set using:

<u>KFLOW(N)</u>	<u>VELBN(L)</u>
100+NTF	$f(NTF,t)*VELOC(N)$
200+NTF	$f(NTF,TROD(NTF))*VELOC(N)$

where $f(NTF,...)$ is transient function number NTF.

Called by INITAL, INITZ1, MOLOOP (MALOOP if explicit).

Calls GETF.

BCFLOW This subroutine looks at all boundary surfaces (N). If a continuative velocity boundary condition was specified, then the velocity of all surface elements (L) of the boundary surface are set using some function of the velocity at the nextmost interior cell face in the same direction as the boundary surface normal vector:

<u>KFLOW(N)</u>	<u>VELBN(L)</u>
-1	continuative momentum
-2	continuative velocity
-4	average continuative mass
-5 or -6	continuative mass

Called by INITAL, TIMSTP, MOLOOP (MALOOP, REBAL, REBALX,

REBALY, REBALZ if explicit).

Calls nothing.

BCPRES This subroutine looks at all boundary surfaces (N). If a pressure boundary condition was specified, then the pressure (in array P) of all cells (M) having a face on this boundary surface are set using:

<u>KPRES(N)</u>	<u>P(M)</u>
1	$PRES(N) - PSTAT0(M)$
100+NTF	$f(NTF,t)*PRES(N) - PSTAT0(M)$

where $f(NTF,t)$ is transient function number NTF.

Called by INITAL, INITZ1, MOLOOP.

Calls GETF.

BCTEMP This subroutine looks at all boundary surfaces (N). If an adiabatic or duct wall energy boundary condition was specified, then various quantities are set for the surface elements (L) on the boundary surface:

<u>KTEMP(N)</u>	<u>Quantities</u>
400	Adiabatic: $QBN(L)=0.$; $TLB(L)=TL(M)$; $HLB(L)=HL(M)$; $RLB(L)=RL(M)$; $PB(L)=P(M)+PSTAT0(M)$.
500+NTF	Duct Wall: see DUCTWA.

where M is the number of the cell whose face is boundary surface element number L.

Called by INITAL, INITZ1, TIMSTP (ENERGY if explicit).

Calls DUCTWA.

BCTEMT This subroutine looks at all boundary surfaces (N). If a heat flux energy boundary condition was specified, then the heat flux of each boundary surface element (L) on the boundary surface is set:

<u>KTEMP(N)</u>	<u>QBN(L)</u>
200	TEMP(N)
300+NTF	f(NTF,t)*TEMP(N)

where f(NTF,t) is transient function number NTF. Various other boundary surface quantities are set:

$$TLB(L) = TL(M) + QBN(L) * 0.5 * \text{volume} / \text{area} / \text{conductivity}$$

$$PB(L) = P(M) + PSTAT0(M)$$

$$HLB(L) = \text{hliq}(PB(L), TLB(L))$$

$$RLB(L) = \text{rholiq}(TL(M), HLB(L), PB(L))$$

where M is the number of the cell whose face is boundary surface element number L; hliq and rholiq are fluid property functions for enthalpy and density.

Called by INITAL, ENLOOP (ENERGY if explicit).

Calls GETF; THCLIQ, HLIQ, ROLIQ.

BCTEM0

This subroutine looks at all boundary surfaces (N). If a temperature or duct wall energy boundary condition was specified, then the temperature of each boundary surface element (L) on the boundary surface is set:

<u>KTEMP(N)</u>	<u>TLB(L)</u>
1	TEMP(N)
100+NTF	f(NTF,t)*TEMP(N)
600+NSS	sum(area*TLB)/sum(area) for surface number NSS.
500+NTF	Calls QDUCTW.

where f(NTF,t) is transient function number NTF. Various other boundary surface quantities are set for the first three cases:

$$QBN(L) = (TLB(L) - TL(M)) * \text{function}(\text{geometry}, \text{properties})$$

$$PB(L) = P(M) + PSTAT0(M)$$

$$HLB(L) = \text{hliq}(PB(L), TLB(L))$$

$$RLB(L) = \text{rholiq}(TLB(L), HLB(L), PB(L))$$

$$SPHL(M) = SPHL(M) + QBN(L) * \text{area} / ((TLB(L) - TL(M)) * \text{cp} * \text{volume})$$

where M is the number of the cell whose face is boundary surface element number L; hliq, rholiq, cp are the fluid property functions for enthalpy, density, and specific heat capacity.

Called by INITAL, INTZ1, TIMSTP, ESORCE (ENERGY if explicit).
 Calls GETF, HEATCF, QDUCTW; CPLIQ, HLIQ, ROLI, THCLIQ,
 VISLIQ; XKSOL1.

BCTURB This subroutine looks at all boundary surfaces (N). If the flow boundary condition is not free slip (i.e. KFLOW(N) $\neq -3$), then set boundary values of turbulence quantities for every surface element (L) on the boundary surface:

$$\text{TURKB(L)} = \text{TKIN} * \text{VELBN(L)}^{**2}, \quad \text{if VELBN(L)} \neq 0$$

$$\text{TURKB(L)} = \text{TKIN} * (\text{UL}_{\text{avg}}^2 + \text{VL}_{\text{avg}}^2 + \text{WL}_{\text{avg}}^2), \quad \text{if VELBN(L)} = 0$$

(where UL_{avg} , VL_{avg} , WL_{avg} are for adjacent cell)

$$\text{TKEDB(L)} = \text{TDIN} * \text{TURKB(L)}^{**1.5}, \quad \text{all VELBN(L)}$$

These quantities are used later only at boundary surfaces where there is flow into the computational domain.

Called by TIMSTP.

Calls nothing.

BLKDTA This block data subprogram initializes COMMON BLOCKs /MACHIN/, /ARINC/, and /ARINI/.

Called by operating system.

Calls nothing.

BOIL This subroutine checks to see if boiling conditions have been attained in any cells. The check is only made if IBOIL > 0 and IFPROP = 0 and only checks cells containing fluid number 1. If boiling conditions are detected, the cell location(s) is printed and IBOIL is set to 2 to indicate a stop condition detectable by AMAIN.

Called by AMAIN.

Calls PSAT1.

BOUND This subroutine removes coupling to cells which provide pressure boundary conditions during initialization of the conjugate-gradient solution of the

pressure equation system. Called after COMMAT, which filled arrays A and NM. Using the fact that if fluid cell number I has its pressure set directly by a boundary condition then array element $A(1,I)=1.E40$, this routine performs the following actions. Sweep over all MX cells I and if $A(1,I)$ is greater than $1.E20$ then set all elements of $NM(L,J)$, where $2 \leq L \leq 7$ and $1 \leq J \leq MX$, which point to cell I to 0.

Called by CGLOOP

Calls nothing.

BOXES

This subroutine begins the establishment of the fluid cell computational geometry when x-y-z or r- θ -z coordinate systems are in use ($IGEOM=0$ or -1). (If $IGEOM > 0$, then FULPIN or QTRPIN is called instead.) The routine reads the boundary surface identification block of the card-image input file; assigns surface element numbers and cell numbers for cells on the boundary; fills arrays MB, ISURF, AREA, LCI, LCX, LCY, LCZ; begins filling arrays IJK, MIM, MIP, MJM, MJP, MKM, and MKP; counts irregular and regular surface elements and irregular cells (NL, NL1, and NM); begins counting regular cells (NM1). After all records in the boundary surface identification input block are processed, control is passed to FILLM to complete the geometry setup.

Called by GEOM3D.

Calls FILLM, ERRCHK.

CGLOOP

This subroutine solves an equation system of the form:

$$\begin{aligned} &ACOF0(M)*X(M) - ACOF1(M)*X(MIM(M)) - ACOF2(M)*X(MIP(M)) \\ &\quad - ACOF3(M)*X(MJM(M)) - ACOF4(M)*X(MJP(M)) \\ &\quad - ACOF5(M)*X(MKM(M)) - ACOF6(M)*X(MKP(M)) = B0(M) \end{aligned}$$

where M is the fluid cell number, X is the array of end of step values being solved for; $ACOF_i$ and B0 are coefficient arrays provided by other routines; and arrays M_{ij} are pointers to adjacent cells. The solution technique is conjugate-gradient with ILU preconditioning. This routine calls other routines to perform setup functions, then calls CNGRIC to perform the inner iteration loop; inner

iterations are continued until the maximum residual is less than DCONV or the number of iterations exceeds ITMAXP.

This routine is called to solve the fluid pressure equation system if ISYMCH=5. (If ISYMCH=3 or 4, then SOLVIT is called to solve the system.) Arrays ACOFi and B0 are filled by PEQN. The variable being solved for is the fluid pressure in array P. The residual is saved in array DL by cell and the maximum is in DLMAX.

Called by MOLOOP.

Calls STORE, UPDATE, COMMAT, BOUND, ELIM, WRPTST, SORTC, CNGRIC, TLEFTS; also MXPLNS, RESORT on vector machines.

CHKHTX

This subroutine sweeps through all cells to insure that if a neighboring cell contains a different fluid number that the two cells have been separated by (a pair of) boundary surfaces or by a zero-porosity cell face (using 'ALX ', 'ALY ', or 'ALZ ' records in the card-image input file). All improperly separated cells are noted in the output and the code stops if any were found.

Called by INITAL.

Calls ERRCHK.

CLEAR

This subroutine fills a contiguous block of core with zeroes.

Called by AAMAIN.

Calls LOCF.

CNGRIC

This subroutine contains the inner iteration loop for the conjugate- gradient solution of the pressure equation system. It is the last routine called by CGLOOP; when it returns, the pressure has converged (or the number of inner iterations has exceeded the maximum) and been updated to a new end-of-outer- iteration value. Most of the work is done by calling other routines.

NOTE: Array TEMP03, stored at S(IS(108)) in COMMON BLOCK /SPACE/, is in argument list for this routine on vector machines but not used; storage location S(IS(108)) is also used for array XR, which is in the argument

list and is used in this routine. (Need to fix this.)

Called by CGLOOP.

Calls DAXPYC, DAXPXC, DDTOC, TLEFTS; also FACINC, OPERXC, LOWFAC, UPPFAC on scalar machines; also FACNCV, OPERXD, LOWFCV, COFSRT on vector machines.

COFSRT

This subroutine initializes arrays before beginning the inner iteration loop in the conjugate-gradient solution of the pressure equation system on vector machines. Called after FACNCV. Defines the following arrays: C1, C2, and C3, which couple the pressure in a cell to the pressure in the cells in the preceding diagonal plane; C1U, C2U, and C3U, which couple the pressure in a cell to the pressure in the cells in the following diagonal plane; and DDINV. These arrays are later used by LOWFCV.

Called by CNGRIC.

Calls nothing.

COMMAT

This subroutine loads the coefficient and pointer arrays used in the conjugate-gradient solution of the pressure equation system. Called after UPDATE. Sweep over all MX fluid cells n, and define

$$\begin{aligned} F(n) &= BP0(n) * AL0(n), & A(1,n) &= ACOF0(n) * AL0(n), \\ A(2,n) &= -ACOF3(n) * AL0(n), & A(3,n) &= -ACOF1(n) * AL0(n), \\ A(4,n) &= -ACOF5(n) * AL0(n), & A(5,n) &= -ACOF6(n) * AL0(n), \\ A(6,n) &= -ACOF2(n) * AL0(n), & A(7,n) &= -ACOF4(n) * AL0(n), \\ NM(1,n) &= n, \\ NM(2,n) &= \max(0, MJM(n)), & NM(3,n) &= \max(0, MIM(n)), \\ NM(4,n) &= \max(0, MKM(n)), & NM(5,n) &= \max(0, MKP(n)), \\ NM(6,n) &= \max(0, MIP(n)), & NM(7,n) &= \max(0, MJP(n)), \\ & \text{(if } A(i,n)=0, \text{ then set } NM(i,n)=0) \end{aligned}$$

where ACOFi and BP0 are the revised coefficient matrices for the pressure equation, AL0 is the cell porosity, and Mij are the adjacent cell number indicators. This reorders the terms in the equation, eliminates coupling of a cell to a boundary ($Mij < 0$), and multiplies each equation by the porosity (for

consistency in calculating the mass residual).

Called by CGLOOP.

Calls nothing.

CPLIQ

This function returns the specific heat capacity (CPLIQ) of fluid number 1 when IFPROP=0 as a function of temperature (T0), enthalpy (H), and/or pressure (P). (For IFPROP=1 or fluids other than number 1, the specific heat capacity is obtained from array element FC1H(n), where n is the fluid number, rather than by calling CPLIQ.)

Versions of this function exist for sodium, normal water, heavy water, and helium; the user must select which one of these fluid property packages to include at linkedit time. Of the arguments passed, those actually used depend on which fluid package is being used. If this function is changed, other functions in the property package may need to be changed in order to maintain a consistent description of the fluid.

Called by (potentially, depending on fluid) other property routines and TIMSTP, BCTEM0, DUCTWA, QDUCTW, ENERGI, ENRBAL, INITAL, NITA3, QSTRUC, HSTRUC, TURV12, VISFIX (GDDDH if explicit).

Calls (potentially, depending on fluid) other property routines.

CPSOL1

This function returns the specific heat capacity of solid material number IRM at temperature T0. Nominally this is computed using a second order polynomial in temperature having user-supplied coefficients CiCP(IRM), $i=0,1,2$, but the user may supply coding in this routine for other functional forms.

Called by DUCTWA, QDUCTW, PSTRU1, TSTRUC, QSTRUC, INPSTR, QSTRDS.

Calls nothing.

DAXPXC

This subroutine multiplies a vector X by a constant (VALUE) and adds the result to vector Y leaving the result in vector X (or $X=VALUE*X+Y$) as part of the conjugate-gradient solution of the pressure equation system. The coding

uses indices in ICELL as follows:

```
      DO 10 II=1,NX  
10    X(ICELL(II))=VALUE*X(ICELL(II))+Y(ICELL(II))
```

Called by CNGRIC.

Calls nothing.

DAXPYC   This subroutine multiplies a vector X by a constant (VALUE) and adds the result to vector Y leaving the result in vector Y (or $Y = \text{VALUE} * X + Y$) as part of the conjugate-gradient solution of the pressure equation system. The coding uses indices in array ICELL as follows:

```
      DO 10 II=1,NX  
10    Y(ICELL(II))=VALUE*X(ICELL(II))+Y(ICELL(II))
```

Called by CNGRIC.

Calls nothing.

DDOTC   This function forms the inner product of vectors X and Y, or

```
      DDOTC=0.0  
      DO 10 II=1,NX  
10    DDOTC=DDOTC+X(ICELL(II))*Y(ICELL(II))
```

as part of the conjugate-gradient solution of the pressure equation system.

Called by CNGRIC.

Calls nothing.

DGEFA   DOUBLE PRECISION version of SGEFA; only used on short-word machines. See description under SGEFA.

DGESL   DOUBLE PRECISION version of SGESL; only used on short-word machines. See description under SGESL.

DLCALC   This subroutine sweeps through all fluid cells and calculates the mass residual (DL) by performing a full mass flow summation, estimates the amount of pressure change needed to zero the residual, adjusts the pressure (P) by this amount, and adjusts the velocities (UL, VL, and WL) to be consistent with the

pressure adjustment.

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by TIMSTP, MALOOP, REBAL.

Calls nothing.

DRODHL

This function returns the derivative of density with respect to enthalpy (DRODHL) of fluid number 1 when IFPROP=0 as a function of temperature (T0), enthalpy (H0), and/or pressure (P0). (For IFPROP=1 or fluids other than number 1, this derivative is computed by dividing the derivative of the density (from statement function FDENSE(n,T0) or GDENSE(n,T0,P0)) with respect to temperature by array element FC1H(n), where n is the fluid number, rather than calling DRODHL.)

Versions of this function exist for sodium, normal water, heavy water, and helium; the user must select which one of these fluid property packages to include at linkedit time. Of the arguments passed, those actually used depend on which fluid package is being used. If this function is changed, other functions in the property package may need to be changed in order to maintain a consistent description of the fluid.

Called by (potentially, depending on fluid) other property routines and TIMSTP, OUTPUT, TKSORC (ENERGY if explicit).

Calls (potentially, depending on fluid) other property routines.

DSDH

This function returns the "derivative of f(y) with respect to y" (DSDH) when fluid number 1 is normal water and IFPROP=0 as a function of "y" (X) needed for the derivative of density with respect to enthalpy function. See equations B.19 and B.20 (inter alia) in Ref. 2. This function is part of, and only used within, the normal water fluid property package.

Called by DRODHL.

Calls nothing.

DSET2   Alternate entry point for RSET2 to store type DOUBLE PRECISION variables. See RSET2 for additional information.

Called by BARIN.

Calls nothing.

DSET3   Alternate entry point for RSET3 to store type DOUBLE PRECISION variables. See RSET3 for additional information.

Called by BARIN.

Calls nothing.

DUCTWA   This subroutine looks at a single boundary surface having a duct wall energy boundary condition ($KTEMP=500+NTF$). For each surface element (L), compute a new value for temperature $TLB(L)$; then set:

$$PB(L)=P(M)+PSTAT0(M)$$

$$HLB(L)=hliq(PB(L),TLB(L))$$

$$RLB(L)=rholiq(TLB(L),HLB(L),PB(L))$$

where M is the number of the adjacent cell; hliq and rholiq are the fluid property functions for enthalpy and density.

The method used to calculate $TLB(L)$ in DUCTWA is identical to that coded in QDUCTW to calculate $QBN(L)$; any changes to the method must be incorporated in both routines for consistency.

Called by BCTEMP

Calls GETF, HEATCF; CPLIQ, HLIQ, ROLIQ, THCLIQ, VISLIQ; CPSOL1, XKSOL1.

ELIM   This subroutine removes equations from the pressure equation system for cells whose pressure is set by a boundary condition during initialization of the conjugate-gradient solution of the pressure equation system. Called after BOUND. Using the fact that if fluid cell number I has its pressure set directly by a pressure boundary condition then array element $A(1,I)=1.E40$, this routine performs the following actions. Sweep over all MX cells I. If $NM(1,I)=0$ or

$A(1,I) \geq 1.E20$ then this cell is skipped (i.e. its equation is eliminated). For all other cells, increment a cell counter NX, set ICELL(NX)=I, and if NM(L,I) is nonzero and $A(1,NM(L,I)) \geq 1.E20$ then set NM(L,I)=0 for $L=1,2,\dots,7$.

Called by CGLOOP.

Calls nothing.

ENERGI

This subroutine constructs the coefficients ATi(M) and BT0(M) in the energy equation system:

$$\begin{aligned} &AT0(M)*HL(M) - AT1(-I)*HL(-I) - AT2(+I)*HL(+I) \\ &\quad - AT3(-J)*HL(-J) - AT4(+J)*HL(+J) \\ &\quad - AT5(-K)*HL(-K) - AT6(+K)*HL(+K) \\ &\quad \pm SPHODL(M,n)*HL(n) = BT0(M) \end{aligned}$$

for each fluid cell M; cells -I, +I, -J, +J, -K, +K are the six neighboring cells in the indicated directions. The ATi contain contributions from cell-to-cell fluid convection (donor cell) and conduction; BT0 contains all source terms (including conduction to boundary surfaces); SPHODL contains coupling through thermal structures to non-adjacent fluid cells. The HL in the energy equation are end-of-step values (an implicit in time formulation). These coefficients will be used in SOLVEN/SOLVEV to actually solve for new enthalpies.

Any changes made in the bulk of this coding must also be made in routine ENRBAL for consistency.

Called from ENLOOP.

Calls GETIJK; THCLIQ, CPLIQ.

ENERGY

This subroutine sweeps through all fluid cells, setting up and solving the energy equation, advancing the fluid enthalpy (HL) to end of step values. This routine is called after pressure (P) and velocities (UL, VL, and WL) have been advanced. There is an inner iteration loop for some solution options. This routine calls other routines to obtain interactions with and update quantities associated with boundary and thermal structure temperatures (TLB and TTS).

This routine is only called when one of the explicit energy solution methods is selected, which is never the recommended mode of solution; this is

old coding and has not been kept up to date.

Called by TIMSTP.

Calls BCTEMT, HSTRUC, BCTEM0, QSTRUC, BCTEMP, TSTRUC;
THCLIQ; TLIQ, ROLIQ, DRODHL.

ENLOOP

This subroutine is effectively the driver for the fluid energy solution. It calls other routines to set boundary conditions, find heat sources from ducts and thermal structures, construct the terms in the energy equation, and solve the energy equation for new fluid enthalpy (HL) at the end of the current outer iteration. It then finds the maximum relative change in fluid enthalpy with respect to the previous outer iteration (DHOHT) and with respect to the beginning of step value (DHOH) for use in convergence checks.

Called by TIMSTP.

Calls BCTEMT, HSTRUC, ESORCE, ENERGI, SOLVEN/SOLVEV,
GETIJK, ENRBAL, TLEFTS.

ENRBAL

This subroutine computes cell-wise and global fluid energy balances. It is called after the fluid energy equations have been solved if IENBUG ≥ 99 or if IENBUG ≥ 98 and the inner iterations in SOLVEN/SOLVEV did not converge.

The bulk of the coding in this routine is identical to that in ENERGI; the two routines must be changed in a consistent manner.

Called by ENLOOP.

Calls THCLIQ, CPLIQ.

ERRCHK

This subroutine prints an error code number (IER) and text message (first NLINES values of M1, M2, ..., M5). If the error level is less than ISTOP and less than NCALLS errors have been processed, then execution continues; otherwise, execution terminates immediately.

Called by AAMAIN, AMAIN, BARIN, BOXES, ERRCHK, ERRTSC,
FILLM, FULPIN, GEOM3D, GETMTS, HEATCF, HEATCU, INFORC,
INITAL, INITA2, INITA3, INITZ1, INPUMP, INPSTR, IREBAL, LODODD,
OUTPUT, RESTAR, TSCAN; HLIQ, TLIQ.

Calls nothing.

ERRTSC   This subroutine prints errors detected by GETMTS (implies IHTWAL(99)=2) if two cells are coupled by more than one thermal structure.
                     Called by GETMTS.
                     Calls ERRCHK.

ESORCE   This subroutine constructs the source term for the fluid energy equations. This is done by first calling routines to get the source due to boundary surfaces and due to thermal structures. (Heat conduction at an irregular boundary surface is treated as a "source"). It then sweeps over all fluid cells M and combines these two sources with any volumetric heat generation directly in the fluid, leaving the result in SCHL(M) for use by ENERGI.
                     Called by ENLOOP.
                     Calls BCTEM0, QSTRUC, GETF.

FACINC   This subroutine performs the incomplete Cholesky factorization before beginning inner iterations of the conjugate-gradient solution of the pressure equation system on scalar machines. (FACNCV is used on vector machines.) Arrays AU and AL are modified; IFFAC=0 on exit.
                     Called by CNGRIC.
                     Calls nothing.

FACNCV   This subroutine serves the same purpose as subroutine FACINC, except that it is applied to matrix A in the regular geometric cell-numbering system and is used on vector machines. Prepares matrix factors AAU and AAL, which are the analogues of factors AU and AL in FACINC. Algorithm is the same as in FACINC, except that the banded structure is not utilized explicitly. IFFAC=0 on exit.
                     Called by CNGRIC.
                     Calls nothing.

FCOND This statement function returns the laminar thermal conductivity (FCOND) of fluid number III as a function of temperature TTT. (For fluid number 1 with IFPROP=0, the thermal conductivity is obtained from function THCLIQ rather than from FCOND.)

Used in BCTEMT, BCTEM0, DUCTWA, QDUCTWA, ENERGI, ENRBAL, INITAL, INITA3, HSTRUC, (ENERGY, GDDDH if explicit).

FDENSE This statement function returns the density (FDENSE) of fluid number III as a linear function of temperature TTT when array element GASMW(III)=0. (For GASMW(III)>0, the density is obtained from statement function GDENSE rather than from FDENSE. For fluid number 1 with IFPROP=0, the density is obtained from function ROLIQ rather than from FDENSE or GDENSE.)

Used in TIMSTP, BCTEMT, BCTEM0, DUCTWA, INITAL, INITA3, ICTEMP, INITZ1, MOLOOP, (ENERGY, MALOOP if explicit).

FENTH This statement function returns the enthalpy (FENTH) of fluid number III as a function of temperature TTT. (For fluid number 1 with IFPROP=0, the enthalpy is obtained from function HLIQ rather than from FENTH.) Statement functions FENTH and FTEMP must be rather exact inverses of each other.

Used in BCTEMT, BCTEM0, DUCTWA, INITAL, INITA3, ICTEMP, INITZ1, HSTRUC, QSTRDS.

FILLM This subroutine completes the establishment of fluid cell computational geometry which was started by BOXES, FULPIN, or QTRPIN. This routine first calls SHOME to print diagrams which show boundary surfaces, if selected. It then completes the tasks of counting fluid cells (NMI) and filling the index arrays IJK, MIM, MIP, MJM, MJP, MKM, and MKP which define cell locations and neighboring cells. Checks are made to insure that the system of fluid cells is completely enclosed by boundary surfaces.

The code will stop if less than 10 seconds of CPU time (as returned by TLEFTS) remain after completing the geometry setup.

Called by BOXES, FULPIN, QTRPIN.

Calls SHOME, ERRCHK, TLEFTS.

FITIT

This subroutine sets up all transient functions by converting user-supplied points (TVAL, FVAL, and NEND) to a set of third-order polynomial coefficients (YCOEF and CCOEF) for the range between each pair of adjacent points in each function. The spline-fit coefficients are generated by SMOOTH for each segment. These coefficients are later used by GETF. COMMON BLOCK /REBALS/ provides temporary workspace.

Called by INITAL.

Calls SMOOTH.

FLUDID

This function returns an alphanumeric description (FLUDID of type CHARACTER*8) of fluid number 1 when IFPROP=0 and sets the defaults for the low and high temperature limits (FCTLO and FCTHI) to be used in printing a property table summary. (For IFPROP=1 or fluids other than number 1, an equivalent function is not used.)

Versions of this function exist for sodium, normal water, heavy water, and helium; the user must select which one of these fluid property packages to include at linkedit time.

Called by INITAL.

Calls nothing.

FORCES

This subroutine calculates the friction force term between fluid and solid surfaces given a force structure number (NF) and local fluid conditions.

The first NCORR (≤ 20) correlations are of the form

$$\text{Re} \leq \text{REYTRN}(i): \quad f = \text{ACORRL}(i) * \text{Re}^{**} \text{BCORRL}(i) + \text{CCORRL}(i)$$

$$\text{Re} > \text{REYTRN}(i): \quad f = \text{ACORRT}(i) * \text{Re}^{**} \text{BCORRT}(i) + \text{CCORRT}(i)$$

where Re is the Reynolds number calculated using local fluid properties and length REYLEN(NF); REYLEN, REYTRN, jCORRk (j=A,B,C; k=L,T), and i=ICORR(NF) $\leq$ NCORR are user-input values.

For ICORR(NF) values between 51 and 99 (inclusive), the user must supply coding for the friction in this routine; examples are shown using numbers 81-87 and 90-95.

The final result when leaving this routine must be in variable ZFORCE in the form of a pressure gradient divided by velocity:

$$ZFORCE = -FORCEF(NF)*f*\rho*|velocity|/CLENTH(NF)$$

where FORCEF and CLENTH are user-input values, f is the friction factor, ρ is the fluid density, and velocity is the fluid velocity.

Called by XMOMI, YMOMI, ZMOMI (XMOM, YMOM, ZMOM if explicit).

Calls nothing.

FTEMP

This statement function returns the temperature (FTEMP) of fluid number III as a function of enthalpy HHH. (For fluid number 1 with IFPROP=0, the temperature is obtained from function TLIQ rather than from FTEMP.) Statement functions FTEMP and FENTH must be rather exact inverses of each other.

Used in TIMSTP, INITA3, INITZ1, OUTPUT, QSTRDS (ENERGY if explicit).

FULPIN

This subroutine automates the geometry specifications of hexagonal fuel assemblies using full-pin partitioning (IGEOM>0 and IPART=1). (If IGEOM>0 and IPART=0, then QTRPIN is called instead; if IGEOM≤0, then BOXES is called instead.)

The routine sets IMAX, JMAX, DX, DY, NSURF, XNORML, YNORML, ZNORML and the information normally provided by the boundary surface identification block of the card-image input file such that most coolant cells contact a "full" pin circumference (one half of one pin and one quarter of two other pins). The routine then assigns surface element numbers and cell numbers for cells on the boundary; fills arrays MB, ISURF, AREA, LCI, LCX, LCY, LCZ; begins filling arrays IJK, MIM, MIP, MJM, MJP, MKM, and MKP;

counts irregular and regular surface elements and irregular cells (NL, NL1, and NM); begins counting regular cells (NM1). The porosity arrays AL, ALX, ALY, and ALZ are filled to represent presence of pins; these arrays are modified if the smeared wire wrap option (IWIRE=1) is selected. After cells on boundary surfaces are processed, control is passed to FILLM to complete the geometry setup.

BUG: The maximum allowable value for IGEOM is limited by nondynamic dimensions of arrays.

Called by GEOM3D.

Calls FILLM, RARRAY, ERRCHK.

FVISC

This statement function returns the absolute laminar (molecular) viscosity (FVISC) of fluid number III as a function of temperature TTT. (For fluid number 1 with IFPROP=0, the viscosity is obtained from function VISLIQ rather than from FVISC.)

Used in BCTEM0, DUCTWA, QDUCTW, INITAL, INITA3, INITZ1, MOLOOP, HSTRUC, TDLOOP, TKLOOP, TURV12, XMOMI, YMOMI, ZMOMI (XMOM, YMOM, ZMOM if explicit).

GDCONV

This subroutine computes DCONV, which is part of the basis for the convergence of the mass residual (DL) during the solution of the pressure equation system. The routine sweeps over all cell faces of all fluid mesh cells to find:

$$UVWMAX = \max(\text{density} * \text{area} * \text{abs}(\text{velocity}) / \text{volume})$$

which is then used to compute

$$DCONV = EPS1 * (UVWMAX + EPS2)$$

where EPSi are user-input values. During the sweep, the routine also computes

$$VELMAX = \max((UL_{avg}^2 + VL_{avg}^2 + WL_{avg}^2)^{0.5})$$

which is used to set a Courant-based time step size if IDTIME=1. This routine is called before TIMSTP for time step numbers indicated by user-input array NTHCON.

Called by AMAIN.

Calls nothing.

GDDDH This subroutine sweeps through all fluid cells m , calculating $DDDH(m)$, which is later used in the fluid energy equation setup. This routine is called after pressure (P) and velocities (U_L , V_L , and W_L) have been advanced.

This routine is only called when one of the explicit energy solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by TIMSTP.

Calls THCLIQ, CPLIQ.

GDDDP This subroutine sweeps through all fluid cells m , calculating $DDDPOT(m)$, which is later used in $DLALC$ to adjust pressures if $IDDDP > 0$. This routine is called once per outer iteration after the momentum equation coefficient arrays ($ARiL$ and $OARi$, $i=U,V,W$) have been filled.

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by INITAL, MALOOP.

Calls nothing.

GDENSE This statement function returns the density ($GDENSE$) of fluid number III from the ideal gas law as a function of temperature TTT and pressure PPP when array element $GASMW(III) > 0$. (For $GASMW(III) = 0$, the density is obtained from statement function $FDENSE$ rather than from $GDENSE$. For fluid number 1 with $IFPROP = 0$, the density is obtained from function $ROLIQ$ rather than from $GDENSE$ or $FDENSE$.)

Used in TIMSTP, BCTEMT, BCTEM0, DUCTWA, INITAL, INITA3, ICTEMP, INITZ1, MOLOOP, (ENERGY, MALOOP if explicit).

GEOM3D

This subroutine is effectively the controlling routine for establishing the computational geometry of the fluid cells. It reads NAMELIST GEOM and then calls either BOXES (x-y-z or r-θ-z) or FULPIN/QTRPIN (hexagonal fuel assembly) to do the actual work. Some summary information is printed before exit.

Called by AMAIN.

Calls BOXES, FULPIN, QTRPIN, IARRAY, MARRAY, RARRAY, ERRCHK, TLEFTS.

GETDL

This subroutine sweeps through all fluid cells (m) and computes the mass residual DL(m) from the pressure equation using:

$$\begin{aligned} DL(m) = & (A0(m)*P(m) - A1(m)*P(MIM(m)) - A2(m)*P(MIP(m)) \\ & - A3(m)*P(MJM(m)) - A4(m)*P(MJP(m)) \\ & - A5(m)*P(MKM(m)) - A6(m)*P(MKP(m)) \\ & - B0(m)) / (DX(i)*DY(j)*DZ(k)) \end{aligned}$$

where A_i ($i=0,1,\dots,6$) and $B0$ are the coefficients matrices in the pressure equation system (from PEQN). The maximum absolute value of DL(m) and its cell location are saved in DLMAX and MDMAX, respectively.

This routine is primarily used when various momentum debug toggles have been activated to provide prints of how well the solution is converging.

Called by MOLOOP, REBAZ, REBAZG, SOLVIT.

Calls nothing.

GETEKL

This subroutine computes the kinetic energy (EKL) of each fluid cell using the current cell density and an average velocity in each direction (plus geometry):

$$EKL = \text{density} * \text{volume} * (UL_{\text{avg}}^2 + VL_{\text{avg}}^2 + WL_{\text{avg}}^2).$$

The result is only used in connection with IDTIME=2.

Called by AMAIN, TIMSTP.

Calls nothing.

GETF

This function evaluates transient function number NF at time (or temperature) TI. Transient functions are used in connection with velocity,

temperature, and pressure boundary conditions ($KFLOW=100+NT$, $200+NT$; $KTEMP=100+NT$, $300+NT$, $500+NT$; $KPRES=100+NT$), heat sources (NOFQT and IHT), and pumps (NTPUMP and NTORQM). The coefficients $CCOEF(n,i)$ and $YCOEF(n)$ needed by this routine are generated by FITIT.

Called by BCFLOT, BCPRES, BCTEMT, BCTEM0, DUCTWA, ESORCE, PUMPQ, QDUCTW, QSTRDS, QSTRUC, TSTRUC.

Calls nothing.

GETIJK   This subroutine takes the cell indices packed in variable IJKT and unpacks them into the three variables I, J, and K using:

$$I = IJKT/10000$$

$$J = (IJKT-10000*I)/100$$

$$K = (IJKT-10000*I)-100*J$$

(NOTE: This routine was introduced when the IHTWAL(99)=2 fully implicit thermal structure coupling was introduced; it could be called from many more places than from which it is currently called.)

Called by ENLOOP, ENERGI, SOLVEV, GETMTS, QSTRDS.

Calls nothing.

GETMTS   This subroutine loads the index arrays (ijkTS where $i=M,N$, $j=I,J,K$ and $k=M,P$) which show whether a fluid cell is coupled to an adjacent fluid cell by a thermal structure. Called at the beginning of each run; arrays are loaded with nonzero entries only if IHTWAL(99)=2 (i.e. if fully implicit thermal structure formulation is used).

Called by AMAIN.

Calls GETIJK, LODODD, ERRTSC.

GETWIR   This subroutine initializes arrays for the cell-integrated wire wrap model (IWIRE=2). For a given cell M, the routine calculates the wire wrap force coefficient arrays (UWIRE, VWIRE, and WWIRE) as a function of geometry. Variable CW may be either CWIREI or CWIREO depending on cell location.

These arrays will be used in the momentum equation setup in XMOMI, YMOMI, and ZMOMI.

Called by INTWIR.

Calls nothing.

HEATCF

This function returns a convective heat transfer coefficient between fluid and a solid surface given a heat transfer correlation index number (IHTWAL for duct walls at boundary surfaces and IHT for thermal structures) and the local fluid conditions. For $1 \leq i \leq NHEATC \leq 20$, the correlations are of the general form

$$U = Nu * \lambda_f / D_h$$

where

$$Nu = HEATC1(i) + HEATC2(i) * Re^{HEATC3(i)} * Pr^{HEATC4(i)}$$

λ_f is fluid laminar thermal conductivity, D_h is characteristic length, Re is Reynolds number, Pr is Prandtl number, and HEATCj(i) are user input coefficients. (If the correlation number is between 51 and 99 (inclusive) then the heat transfer coefficient is obtained from user-supplied function HEATCU.)

Called by BCTEM0, DUCTWA, QDUCTW, HSTRUC.

Calls HEATCU, ERRCHK.

HEATCU

This function returns a convective heat transfer coefficient between fluid and a solid surface given a heat transfer correlation index number (IHTWAL for duct walls at boundary surfaces and IHT for thermal structures) and the local fluid conditions. The user must supply the coding for this routine to provide a heat transfer coefficient for each correlation number used by the user in the range 51 through 99 (inclusive).

Called by HEATCF.

Calls ERRCHK and other routines determined by the user.

HLIQ

This function returns the enthalpy (HLIQ) of fluid number 1 when IFPROP=0 as a function of pressure (P) and/or temperature (TC). (For

IFPROP=1 or fluids other than number 1, the enthalpy is obtained from statement function FENTH(n,TC), where n is the fluid number, rather than from HLIQ.) Functions HLIQ and TLIQ must be fairly exact inverses of each other.

Versions of this function exist for sodium, normal water, heavy water, and helium; the user must select which one of these fluid property packages to include at linkedit time. Of the arguments passed, those actually used depend on which fluid package is being used. If this function is changed, other functions in the property package may need to be changed in order to maintain a consistent description of the fluid.

Called by (potentially, depending on fluid) other property routines and BCTEMT, BCTEM0, DUCTWA, INTAL, INITA3, ICTEMT, INITZ1, HSTRUC, QSTRDS.

Calls (potentially, depending on fluid) other property routines and ERRCHK.

HSTRUC

This subroutine is called during each outer iteration (after velocities are updated) at the beginning of the energy calculation to compute the solid/fluid heat transfer coefficient (HSTREL) at each surface element of each thermal structure. This routine passes the local conditions (velocity, temperature, and fluid properties) and the heat transfer correlation index (IHT) to HEATCF, which returns HSTREL.

Called by AMAIN, ENLOOP, INITZ1 (ENERGY if explicit).

Calls HEATCF; HLIQ, THCLIQ, VISLIQ, CPLIQ.

IARRAY

This subroutine prints values from INTEGER array INTVAR(m) for the two-dimensional K-plane number KK. Array IJK(m) is used to find the cell numbers (m) which are in the requested plane. Workspace of size IMAX*JMAX is assumed to have been allocated for passed array IWORK.

Called by GEOM3D.

Calls nothing.

ICTEMP   This subroutine sweeps over all surface elements (L) of all boundary surfaces (N), initializing

$TLB(L) = TEMP0(KPROP(N))$,   if $KTEMP(N) = 200$ or $300 + NTF$

$TLB(L) = TEMP(N)$,   other $KTEMP$

$QBN(L) = TEMP(N)$,   if $KTEMP(N) = 200$ or $300 + NTF$

$QBN(L) = 0.$,   other $KTEMP$

$VELBN(L) = VELOC(N)$

$PB(L) = P(MB(L)) + PSTAT0(MB(L))$

$HLB(L) = hliq(PB(L), TLB(L))$

$RLB(L) = rholiq(TLB(L), HLB(L), PB(L))$

where hliq and rholiq are the fluid property functions for enthalpy and density. For several boundary condition choices, these uniform initialization of TLB, QBN, and VELBN may be overridden on a pointwise basis by the user via records in the boundary value initialization block of the card-image input file.

          Called by INITIAL.

          Calls HLIQ, ROLIQ.

INFORC   This subroutine reads the force structure location block of the card-image input file and fills an index array (IFORCE) showing which cells have force structures specified and in what coordinate direction(s). Some summary information is printed.

          Called by INITIAL.

          Calls ERRCHK.

INHTX   This subroutine reads the fluid cell location block of the card-image input file, which specifies which cells contain something other than fluid number 1 in multifluid problems. The cell location indices (I,J,K) input are mapped to a cell number M ($\leq NM1$) and the fluid number overwrites the default (1) in array element INDHTX(M) for the indicated cells. The number of cells containing each fluid number are counted and stored in array NOHTX for use by INITIAL.

          Called by INITIAL.

          Calls nothing.

INITAL

This subroutine is the effective controlling routine for processing the card-image input file after geometry setup has been performed. This routine initializes defaults for variables in NAMELIST DATA, reads NAMELIST DATA, and processes this information directly or by calling other routines; other routines are called to read and/or process all other blocks in the card-image input file and to read the input restart file. Some additional initialization are performed (TURVIS, TURCON, DENSE0, GRAVR, GRAVTH, TL, PSTAT0, HL, and RL) and many summaries are printed. Many sections of the routine are skipped if this is a continuation run (ISTATE > 0).

Called by AMAIN.

Calls RESTAR, INITA3, INITA2, FITIT, QGENER, IREBAL, INHTX, INPUMP, INFORC, INPSTR, ICTEMP, BARIN, CHKHTX, BCFLOT, INTURK, BCTEMT, BCTEM0, BCTEMP, BCFLOW, BCPRES, ERRCHK, (GDDDP if explicit); HLIQ, CPLIQ, THCLIQ, VISLIQ, ROLIQ.

INITA2

This subroutine checks the validity of user input associated with the expansion-cell velocity boundary condition (KFLOW=-6). (Caution: One item that can not be checked is whether the associated cell is properly blocked by zero-porosity cell faces if it is not blocked by boundary surfaces -- porosities have not been read at the time this routine is called.)

Called by INITAL.

Calls LBLE, ERRCHK.

INITA3

This subroutine checks the sufficiency of property input and prints a properties table for each fluid being used in the calculation. LOGICAL-type array element LPROP(m) is set to .TRUE. if sufficient properties were input for fluid number m and passed back to INITAL for further checks.

Called by INITAL.

Calls ERRCHK; HLIQ, ROLIQ, THCLIQ, VISLIQ, CPLIQ, TLIQ.

INITUR   This subroutine controls initialization of most of the arrays associated with turbulence modeling. It specifically initializes the turbulent kinetic energy dissipation rate (TKED and TKEDB). It calls other routines to perform other initialization.

Called by AMAIN.

Calls TLFIX, INTURK, VISFIX, TURV12.

INITZ1   This subroutine performs a one-dimensional initialization for hexagonal fuel assembly problems if IFROD=2. Variables set are WL, P, HL, TL, and RL for fluid cells and VELBN for elements on the exit boundary surface, which override the uniform initialization done by INITIAL.

BUG: The IFROD=2 option must not be used for problems which use multiple fluids.

Called by INITIAL.

Calls BCPRES, BCTEM0, BCTEMP, BCFLOT, HSTRUC, TSTRUC, QSTRUC, ERRCHK; TLIQ, ROLI, HLIQ, VISLIQ.

INPSTR   This subroutine reads the card-image input file blocks associated with thermal structures (NAMELIST STRUCT, the thermal structure prototype input block (NAMELISTs T, F, and M), and the thermal structure location input block) and stores this information in ITSCB, HYDRA1, HYDRA2, RODF, MATERL, HEAT, SIZE, STAREA, STVOL, ICEL, INDTRI, and INDTRO. The order of the records in the input file is passed to this routine from TSCAN through COMMON BLOCK /CSCAN/. COMMON BLOCK /REBALS/ provides temporary workspace. Summaries for each thermal structure are printed.

Called by INITIAL.

Calls ERRCHK; CPSOL1.

INPUMP   This subroutine initializes data for the pump model (activated by IFPUMP>0). The routine sets defaults and then reads NAMELIST PUMP; it also reads the pump location block of the card-image input file, which results in

setting IJKPP(n) and IDIRP(n) for the cell location and pumping direction for each pump (n).

Called by INITAL.

Calls ERRCHK.

INTURK

This subroutine initializes the turbulent kinetic energy arrays (TURK and TURKB). Uses the (initial) values of velocity (UL, VL, WL, and VELBN) and a user-supplied constant (TKIN). The turbulent kinetic energy is forced to be above a minimum (1.E-15), since a zero value is not allowed.

Called by INITAL, INITUR.

Calls nothing.

INTWIR

This subroutine initializes arrays associated with the cell-integrated wire wrap model (IWIRE=2) when IGEOM>0 and IPART=0. Arrays initialized or modified directly are AL, ALX, ALY, ALZ, AREA, and MWIRE. Calls other routines to initialize other arrays.

Called by QTRPIN.

Calls THETAS, WIRE, WIRVOL, GETWIR, RARRAY.

IREBAL

This subroutine initializes variables associated with the user-specified region-by-region rebalancing option (IFREB>0). The routine reads the rebalancing region location block of the card-image input file and sets up indexing variables NREBP, NREBRS(p), NREBRT(n), IMREB(n,q), INDS(n,q), NFREB, and MREB(n) which define the rebalancing regions and the planes of separation. Allocates temporary storage in COMMON BLOCK /REBALS/.

Called by INITAL.

Calls ERRCHK.

ISSET2

Alternate entry point for RSET2 to store type INTEGER variables. See RSET2 for additional information.

Called by BARIN.

Calls nothing.

ISSET3   Alternate entry point for RSET3 to store type INTEGER variables. See RSET3 for additional information.
                                  Called by BARIN.
                                  Calls nothing.

ISURFO   This subroutine prints values from INTEGER-type surface-element array IVAR for boundary surface number NSUR.
                                  Called by OUTPUT.
                                  Calls nothing.

LBLF   This subroutine returns the beginning (LB) and ending (LE) surface element numbers for a given boundary surface number (NSURF). (NOTE: This routine should be used a lot more than it is to replace in-stream coding, primarily in routines BCxxxx.)
                                  Called by INITIAL, OUTPUT, BCFLOF.
                                  Calls nothing.

LOCF   This function returns the core storage address (LOCF) of a variable(X); the result returned must be divided by NOBPI to be in units of "computer words". On the IBM mainframe machine at ANL, this is a locally written system function. For other machines, source coding (in FORTRAN) is supplied with COMMIX-1AR/P which calls an appropriate system routine (e.g. LOC or %LOC),
                                  Called by AAMAIN, ALTER, CLEAR, RESTAR.
                                  Routines called depend on computer system (as noted).

LODODD   This subroutine loads the index arrays (MTSODD and NTSODD) which show whether a fluid cell is coupled to a nonadjacent fluid cell by a thermal structure. Only called if IHTWAL(99)=2 (i.e. if fully implicit thermal structure formulation is used).
                                  Called by GETMTS.
                                  Calls ERRCHK.

LOWFAC

This subroutine solves the lower triangular matrix system, $AL \cdot X = F$, as part of the conjugate-gradient solution of the pressure equation system on scalar machines. (LOWFCV is used on vector machines.) AL is the lower triangular matrix, F is the source vector, NX is the order of system, NM and ICELL show cell coupling; solution vector is returned in X.

Called by CNGRIC.

Calls nothing.

LOWFCV

This subroutine solves the upper and lower triangular matrix systems, $AAL \cdot AAU \cdot XXX = FFF$, as part of the conjugate-gradient solution of the pressure equation system on vector machines. (LOWFAC and UPPFAC are used on scalar machines.) The AAL and AAU matrices are prepared by COFSRT and passed to this routine as arrays C1, C2, C3, C1U, C2U, and C3U; solution vector is mapped from array XXX to X before exiting. This is the ILU factorized form of the pressure equation system in the regular geometric cell-numbering system. System is solved along diagonal planes using a vectorizable algorithm.

BUG: This algorithm is not quite correct for the case where the fluid system closes on itself in the θ direction (i.e., $IGEOM = -1$, $\sum(DY(J)) = 2\pi$ for $J=1,2,\dots,JMAX$, and cells at spatial location $J=JMAX$ are coupled on the $+J$ side to the $-J$ side of cells at spatial location $J=1$). Matrix elements outside of the normal 7 bands are ignored.

Called by CNGRIC.

Calls nothing.

MALoop

This subroutine is effectively the driver for the fluid momentum solution. It calls other routines to set boundary conditions, construct the terms in the three momentum equations, combine the three momentum equations to form a pressure equation, solve the pressure equation for the new pressure P, and use these pressures to advance the velocities UL, VL, and WL to the end of the current outer iteration. There is an inner iteration loop around the solver section.

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by TIMSTP.

Calls DLCALC, XMOM, YMOM, ZMOM, GDDDP, MOMENT, BCFLOT, BCFLOW, REBALX, REBALY, REBALZ, REBAL, BCPRES, TLEFTS; ROLIQ.

MARRAY This subroutine prints values from array IJK(m) for the two-dimensional K-plane number KK, thus showing the cell numbers (m) which are in the requested plane. Workspace of size IMAX*JMAX is assumed to have been allocated for passed array IWORK.

Called by GEOM3D.

Calls nothing.

MOLOOP This subroutine is effectively the driver for the fluid momentum solution. It calls other routines to set boundary conditions, construct the terms in the three momentum equations, combine the three momentum equations to form a pressure equation, solve the pressure equation for the new pressure P, and use these pressures to advance the velocities UL, VL, and WL to the end of the current outer iteration. It then finds the maximum change of the velocity components across the time step and normalizes these (DUMAX, DVMAX, and DWMAX) with respect to VELMAX for use in convergence checks.

Called by TIMSTP.

Calls BCFLOT, XMOMI, YMOMI, ZMOMI, PEQN, SOLVIT, CGLOOP, MOMENI, GETDL, REBAZG, REBAZ, TLEFTS; ROLIQ, VISLIQ.

MOMENI This subroutine uses the current value of the end-of-step pressure (array P from SOLVIT or CGLOOP) and the momentum equation coefficients (Di0L and iHATL, i=U,V,W, from XMOMI, YMOMI, and ZMOMI) to compute the new velocity field at the end of the current outer iteration:

$$UL(m) = UHATL(m) - DU0L(m)*(P(MIP(m)) - P(m))$$

$$VL(m) = VHATL(m) - DV0L(m)*(P(MJP(m)) - P(m))$$

$$WL(m) = WHATL(m) - DW0L(m)*(P(MKP(m)) - P(m))$$

The maximum changes since the last outer iteration are saved in DULMAX, DVLMAX, and DWLMAX for convergence checks. This is the last part of the implicit momentum calculation technique.

Called by MOLOOP.

Calls nothing.

MOMENT

This subroutine uses the current value of the end-of-step pressure (P from DLCALC, REBAL, REBALX, REBALY, or REBALZ) and the momentum equation coefficients (ARiL and OARi, i=U,V,W, from XMOM, YMOM, and ZMOM) to compute the new velocity field at the end of the current inner iteration:

$$UL(m) = (ARUL(m) - (P(MIP(m)) - P(m)) * DTIME * AL / DX) * OARU(m)$$

$$VL(m) = (ARVL(m) - (P(MJP(m)) - P(m)) * DTIME * AL / DY) * OARV(m)$$

$$WL(m) = (ARWL(m) - (P(MKP(m)) - P(m)) * DTIME * AL / DZ) * OARW(m)$$

This is called during each inner iteration of the explicit momentum calculation technique.

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by MALOOP, REBALX, REBALY, REBALZ, REBAL.

Calls nothing.

MXPLNS

This subroutine finds out how many mesh cells (MAXPTP) are in the largest fully diagonal plane. The result is used for allocating storage associated with the conjugate-gradient solution of the pressure equation system on vector machines.

Called by AAMAIN, CGLOOP.

Calls nothing.

OPERXC

This subroutine multiplies a matrix A times a column vector X leaving the result in column vector F (or $F=A*X$) as part of the conjugate-gradient solution of the pressure equation system on scalar machines. (OPERXD is used on vector machines.) The coding uses indices in NM, NA, and ICELL as follows:

```
DO 10 II=1,NX
  I=ICELL(II)
  F(I)=0.0
  DO 10 L=1,NM(9,I)
10  F(I)=F(I)+A(NA(L,I),I)*X(NM(L,I))
```

Called by CNGRIC.

Calls nothing.

OPERXD

This subroutine performs multiplication of a matrix times a column vector as part of the conjugate-gradient solution of the pressure equation system on vector machines. (OPERXC is used on scalar machines.) Matrix is defined in stripe form by arrays AC0, AC1, AC2, AC3, AC4, AC5, and AC6; cell couplings are given by MijN arrays; NX is the size of the system; array X is the column vector. The solution vector is returned in array F. Algorithm is fully vectorized using indirect addressing.

Called by CNGRIC.

Calls nothing.

OUTPUT

This subroutine provides printed output of the calculated results. The routine is called at the time step numbers (NTPRNT) or times (TPRNT) specified by the user. First printed is a block of summary information covering boundary surfaces, mass balance, energy balance, thermal structures, and radiation surfaces. The routine then calls other routines to print the remainder of the output, which consists of various variables at various planes or various thermal structures, as specified by the user in ISTPR (for first call in run having ISTATE=0 or 2) or NTHPR (for all other calls).

Called by AMAIN.

Calls RARRAY, RSURFO, ISURFO, LBLE, PSTRUC, PSTRU1, ERRCHK; DRODHL, TLIQ.

PEQN

This subroutine constructs the coefficient arrays in the pressure equation system (ACOFi, $i=0,1,\dots,6$, and BCOF0) using the momentum equation coefficient arrays (Di0L and iHATL, $i=U,V,W$) generated by XMOMI, YMOMI, and ZMOMI. This is an implicit-in-time formulation. The coefficients generated will ultimately be used in SOLVIT or CGLOOP to solve for the new pressure field.

Called by MOLOOP.

Calls nothing.

PLTAPE

This subroutine writes velocities and temperatures on a file on unit number IPL in the unformatted record structure expected by the graphics postprocessing programs VECT, TEMP, and TDSC. There are two values for IPL: 76 and 10. If IPL=76, the plot file is being written with results at the time step numbers specified by the user in array NTPLOT; on the first call with IPL=76, the file is opened and three header records and four records of information for this time step are written; on later calls with IPL=76, only the four records of time step information are written. If IPL=10, then the three header records plus the four records of information for the current time step are appended to the output restart file, which completes this file.

Called by AMAIN, RESTAR.

Calls nothing.

POLY

This function evaluates a polynomial, of order $N-1$ in X , whose coefficients are in array A, as

$$\text{POLY} = A(N)*X^{(N-1)} + A(N-1)*X^{(N-2)} + \dots + A(2)*X + A(1)$$

when fluid number 1 is normal water and IFPROP=0 as needed for the saturation temperature function. This function is part of, and only used within, the normal water fluid property package.

Called by TSAT11.

Calls nothing.

PSAT1   This function returns the saturation pressure (PSAT1) of fluid number 1 when IFPROP=0 as a function of temperature (TC). (For IFPROP=1 or fluids other than number 1, an equivalent function is not used.)

     Versions of this function exist for sodium, normal water, heavy water, and helium; the user must select which one of these fluid property packages to include at linkedit time. If this function is changed, other functions in the property package may need to be changed in order to maintain a consistent description of the fluid.

     Called by (potentially, depending on fluid) other property routines and BOIL.

     Calls (potentially, depending on fluid) other property routines.

PSTRUC   This subroutine prints value (fluid cell number, fluid temperature, and surface heat transfer coefficient for both surfaces and all intervening structure temperatures) for thermal structure number NNN.

     Called by OUTPUT.

     Calls nothing.

PSTRU1   This subroutine computes an estimate of the stored energy and average temperature for thermal structure number N. (This information is printed by OUTPUT but is not used otherwise in the calculation.)

     Called by OUTPUT.

     Calls CPSOL1.

PUMPQ   This subroutine performs calculations for pump number NP. The main item to be returned is the pressure increase, DPPUMP, due to the pump under the current operating conditions. The details of what else is done and how depends on which pump model is being used (IFPUMP) and whether this is a steady-state or a transient calculation (ISTATE).

     Called by XMOMI, YMOMI, ZMOMI.

     Calls GETF.

QDUCTW

This subroutine looks at a single boundary surface having a duct wall energy boundary condition ($KTEMP=500+NTF$). For each surface element (L), compute a new value for boundary heat flux $QBN(L)$; then convert this to an equivalent volumetric heat source rate

$$SPHL(M) = SPHL(M) + QBN(L) * area / ((TLB(L) - TL(M)) * cp * volume),$$

where M is the number of the adjacent fluid cell; cp is the fluid property function for specific heat capacity.

The method used to calculate $QBN(L)$ in QDUCTW is identical to that coded in DUCTWA to calculate $TLB(L)$; any changes to the method must be incorporated in both routines for consistency.

Called by BCTEM0.

Calls GETF, HEATCF; CPLIQ, THCLIQ, VISLIQ; CPSOL1, XKSOL1.

QGENER

This subroutine establishes heat source data if $IFROD > 0$ (primarily used for hexagonal fuel assembly geometry). This routine reads NAMELIST INPUTQ and results in setting $QK(k)$, $QU(i,j)$, $WETLEN(i,j)$, $QSOUR(m)$, $PINF(ind)$. Also sets constants $FCXn$ and $FCYn$ ($n=1,2,...,5$) used in x- and y-direction drag force.

BUG: The maximum allowed values for IMAX, JMAX, and KMAX are limited below their normal maximum values by nondynamic array dimensions.

Called by INITAL.

Calls AXHEF, RARRAY.

QSRAD

This subroutine sweeps over all radiation surfaces computing the net radiation heat transfer rate (QRNET). This routine is called after TSTRUC has updated the radiation surface temperatures (after the outer iteration process has converged). The net heat transfer rate calculated by this routine at the end of a time step will be used throughout the entire next time step. The rate is partitioned by area fraction to get a heat transfer rate for each thermal structure element which is part of a radiation surface.

Called by TIMSTP.

Calls LINPACK routines: SGEFA (or DGEFA), SGESL (or DGESL).

QSTRDS

This subroutine sweeps over all thermal structures calculating the derivative of the solid-to-fluid heat transfer rate for fluid cell number m with respect to the enthalpy in fluid cell number n (i.e. $d(QSOUR(m))/d(HL(n))$) if $IHTWAL(99) > 0$. This is done by numerical differentiation; the results are stored in array $SPHL$ for $n=m$ and, if $IHTWAL(99)=2$, in array $QPRIME$ for $n \neq m$.

The majority of the coding in this routine is identical to the coding used in **TSTRUC** and **QSTRUC**; any changes to the method must be implemented consistently in all three routines.

Called by **QSTRUC**.

Calls **GETF**, **GETIJK**; **HLIQ**, **TLIQ**; **CPSOL1**, **XKSOL1**.

QSTRUC

This subroutine is called during every outer iteration to set the solid-to-fluid source term for the fluid energy equation. The routine sweeps over all thermal structures calculating the heat transfer rate to each associated fluid cell (**QSOUR**), its derivative with respect to fluid enthalpy (**SPHL**), and the total heat transfer rate to all fluid cells (**QFLUID**). If $IHTWAL(99) > 0$, then the heat transfer rate by cell is also stored in **QNOGHT** and control is passed to **QSTRDS** to calculate the derivative of heat transfer rate with respect to fluid enthalpy.

The majority of the coding in this routine is identical to the coding used in **TSTRUC** and **QSTRDS**; any changes to the method must be implemented consistently in all three routines.

Called by **AMAIN**, **INITZ1**, **ESORCE** (**ENERGY** if explicit).

Calls **GETF**, **QSTRDS**; **CPLIQ**; **CPSOL1**, **XKSOL1**.

QTRPIN

This subroutine automates the geometry specifications of hexagonal fuel assemblies using quarter-pin partitioning ($IGEOM > 0$ and $IPART=0$). (If $IGEOM > 0$ and $IPART=1$, then **FULPIN** is called instead; if $IGEOM \leq 0$, then **BOXES** is called instead.)

The routine sets **IMAX**, **JMAX**, **DX**, **DY**, **NSURF**, **XNORML**, **YNORML**, **ZNORML** and the information normally provided by the boundary surface identification block of the card-image input file such that most coolant

cells contact a "quarter" pin circumference (all from one pin). The routine then assigns surface element numbers and cell numbers for cells on the boundary; fills arrays MB, ISURF, AREA, LCI, LCX, LCY, LCZ; begins filling arrays IJK, MIM, MIP, MJM, MJP, MKM, and MKP; counts irregular and regular surface elements and irregular cells (NL, NL1, and NM); begins counting regular cells (NM1). The porosity arrays AL, ALX, ALY, and ALZ are filled to represent presence of pins; these arrays are modified by this routine if the smeared wire wrap option (IWIRE=1) is selected (and by INTWIR if the cell-integrated wire wrap option (IWIRE=2) is selected). After cells on boundary surfaces are processed, control is passed to FILLM to complete the geometry setup.

BUG: The maximum allowed value for IGEOM is limited by nondynamic array dimensions.

Called by GEOM3D.

Calls FILLM, INTWIR, RARRAY, ERRCHK.

RARRAY

This subroutine prints values from real number array $\text{PEALA}(m)$ for the two-dimensional plane defined by whichever one of the following is nonzero: $I=II$, $J=JJ$, or $K=KK$. Array $IJK(m)$ is used to find the cell numbers (m) which are in the requested plane. Workspace of size $\max(IMAX*JMAX, JMAX*KMAX, KMAX*IMAX)$ is assumed to have been allocated beginning at location $S(IS(75))$ in COMMON BLOCK /SPACE/.

Called by GEOM3D, FULPIN, QTRPIN, QGENER, INTWIR, OUTPUT.

Calls nothing.

REBAL

This subroutine performs region-by-region rebalancing selected by $IFREB > 0$ for user-defined rebalancing regions. (Rebalancing may also be performed on a plane-by-plane basis by REBALX, REBALY, or REBALZ.) The rebalancing is performed by adjusting pressures, P , such that the total mass residual for all cells in a region is zero for all regions. This routine is called from MALOOP (after initial call to MOMENT and before every IREBIT-th inner iteration). The current coefficients for the momentum equations ($ARiL$ and

OAR_i, $i=U,V,W$) as computed by XMOM, YMOM, and ZMOM are used. Velocities (UL, VL, and WL) are updated after pressures are adjusted. COMMON BLOCK /REBALS/ provides temporary workspace.

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by MALOOP.

Calls DLCALC, MOMENT, BCFLOW.

REBALX

This subroutine performs plane-by-plane rebalancing in the I direction if selected by IXREB>0. (Rebalancing is performed in other planar directions or on a region-by-region basis by REBALY, REBALZ, or REBAL.) The rebalancing is performed by adjusting pressures, P, such that the total mass residual for all cells in a plane is zero for all planes. This routine is called from MALOOP (after initial call to MOMENT). The current I-direction velocities (UL) are used. Velocities are updated after pressures are adjusted. COMMON BLOCK /REBALS/ provides temporary workspace.

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by MALOOP.

Calls MOMENT, BCFLOW.

REBALY

This subroutine performs plane-by-plane rebalancing in the J direction if selected by IYREB>0. (Rebalancing is performed in other planar directions or on a region-by-region basis by REBALX, REBALZ, or REBAL.) The rebalancing is performed by adjusting pressures, P, such that the total mass residual for all cells in a plane is zero for all planes. This routine is called from MALOOP (after initial call to MOMENT). The current J-direction velocities (VL) are used. Velocities are updated after pressures are adjusted. COMMON BLOCK /REBALS/ provides temporary workspace.

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by MALOOP.

Calls MOMENT, BCFLOW.

REBALZ

This subroutine performs plane-by-plane rebalancing in the K direction if selected by $IZREB > 0$. (Rebalancing is performed in other planar directions or on a region-by-region basis by REBALX, REBALY, or REBAL.) The rebalancing is performed by adjusting pressures, P, such that the total mass residual for all cells in a plane is zero for all planes. This routine is called from MALOOP (after initial call to MOMENT). The current K-direction velocities (WL) are used. Velocities are updated after pressures are adjusted. COMMON BLOCK /REBALS/ provides temporary workspace.

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by MALOOP.

Calls MOMENT, BCFLOW.

REBAZ

This subroutine performs plane-by-plane rebalancing selected by whichever one of IXREB, IYREB, or IZREB is nonzero. (Rebalancing may also be performed on a region-by-region basis by REBAZG.) The rebalancing is performed by adjusting pressures, P, such that the total mass residual for all cells in a plane is zero for all planes. This routine is called from MOLOOP (between PEQN and SOLVIT/CGLOOP) and SOLVIT (before every IREBIT-th inner iteration). The current coefficients for the pressure equation (ACOFi, $i=0,1,\dots,6$, and BCOF0, as computed by PEQN) are used. COMMON BLOCK /REBALS/ provides temporary workspace.

Called by MOLOOP, SOLVIT.

Calls GETDL, TDMA.

REBAZG

This subroutine performs region-by-region rebalancing selected by $IFREB > 0$ for user-defined rebalancing regions. (Rebalancing may also be performed on a plane-by-plane basis by REBAZ.) The rebalancing is performed by adjusting pressures, P , such that the total mass residual for all cells in a region is zero for all regions. This routine is called from MOLOOP (between PEQN and SOLVIT/CGLOOP) and SOLVIT (before every IREBIT-th inner iteration). The current coefficients for the pressure equation ($ACOF_i$, $i=0,1,\dots,6$, and $BCOF_0$, as computed by PEQN) are used. COMMON BLOCK /REBALS/ provides temporary workspace.

Called by MOLOOP, SOLVIT.

Calls GETDL, TDMA.

REDEF

When cylindrical geometry is used, this subroutine modifies the stored value of volume and surface porosities to include a radius multiplier; i.e.

AL, ALY, and ALZ: (cell center radius)*(actual porosity)

ALX: (radius at +I cell face)*(actual porosity)

This modification is performed after completely reading the internal cell initialization block from the card-image input file. This is part of the technique used which allows the x-y-z conservation equations to also be used for r- θ -z geometry. The entry point REDEF2 undoes this modification, which is necessary if porosity values are read at $ISTATE > 0$. This routine also sets the velocity to zero at cell faces where the surface porosity is zero.

Called by BARIN.

Calls nothing.

REDEF2

Alternate entry point for routine REDEF. Called once if (i.e. before) porosity values are read from the card-image input file at $ISTATE > 0$ when $IGEOM = -1$ and removes the radius factor from arrays AL, ALX, ALY, and ALZ. (Routine REDEF will be called after all porosity values have been read from the card-image input file to restore the radius factor.) See routine REDEF for additional information.

Called by BARIN.

Calls nothing.

RESORT

This subroutine completely reorders the fluid cells during initialization of the conjugate-gradient solution of the pressure equation system on vector machines. Called after SORTC (just before CNGRIC). Cell numbering becomes purely geometric (i.e. regular):

(1,1,1),	(1,1,2),	..., (1,1,KMAX),
(2,1,1),	(2,1,2),	..., (2,1,KMAX), ...,
(IMAX,1,1),	(IMAX,1,2),	..., (IMAX,1,KMAX),
(1,2,1),	(1,2,2),	..., (1,2,KMAX), ...,
(IMAX,2,1),	(IMAX,2,2),	..., (IMAX,2,KMAX), ...,
(1,JMAX,1),	(1,JMAX,2),	..., (1,JMAX,KMAX), ...,
(IMAX,JMAX,1),	(IMAX,JMAX,2),	..., (IMAX,JMAX,KMAX)

which may allocate space for cells which do not actually exist but allows vectorization of the solution coding. Fills arrays II, JJ, KK, NDG, MINDEX, NMAX, MDTOMR, MRTOMD, MIMD, MIPD, MJMD, MJPD, MKMD, MKPD, NL, NU, AA, NMM, NAA, M0TOMR, and MTOMR.

Called by CGLOOP.

Calls ORDERS(system).

RESTAR

This subroutine reads and writes the majority of the (binary) restart file, depending on the setting of variable IR, which is set based on the value of input variable IFRES.

If IR=1, the routine was called from AMAIN at the end of a run. Records 2 through 5 and optional records 6 through 10 are written to unit 10. (Record 1 was written by COMMIX.) Then PLTAPE is called to append plot-file-type records to the restart file.

If IR=2, the routine was called from INITAL before reading NAMELIST DATA. Records 2 through 5 and optional records 6 through 10 are read from unit 9. (Record 1 is skipped since it was read by COMMIX and the file was rewound.) This restores calculational variables to values from a prior run.

If IR=4, the routine was called from INITAL after reading all of the card-

image input file except the boundary value and internal cell initialization input blocks. Record 1 is read from unit 9; if certain consistency checks are met, then records 2 through 4 are skipped and (part of) record 5 is read. This initializes the fluid velocities, temperatures, and pressures (UL, VL, WL, TL, and P) to values from a prior run. The rest of the input restart file is not read.

Called by AMAIN, INITAL.

Calls LOCF, PLTAPE, ERRCHK.

ROLIQ

This function returns the density (ROLIQ) of fluid number 1 when IFPROP=0 as a function of temperature (TC), enthalpy (H), and/or pressure (P). (For IFPROP=1 or fluids other than number 1, the density is obtained from statement function FDENSE(n,TC) or GDENSE(n,TC,P), where n is the fluid number, rather than from ROLIQ.)

Versions of this function exist for sodium, normal water, heavy water, and helium; the user must select which one of these fluid property packages to include at linkedit time. Of the arguments passed, those actually used depend on which fluid package is being used. If this function is changed, other functions in the property package may need to be changed in order to maintain a consistent description of the fluid.

Called by (potentially, depending on fluid) other property routines and TIMSTP, BCTEMT, BCTEM0, DUCTWA, INITAL, INITA3, ICTEMP, INITZ1, MOLOOP (ENERGY, MALOOP if explicit).

Calls (potentially, depending on fluid) other property routines.

RSET2

This subroutine assigns the values read from records in the internal cell initialization block of the card-image input file to the proper array locations for type REAL variables. This involves mapping from physical location indices (I,J,K) to a cell number ($\leq NM1$). Some of the needed information is passed to this routine through COMMON BLOCK /INDLIM/. Alternate entry points DSET2 and ISET2 are called to store type DOUBLE PRECISION and INTEGER

variables, respectively.

Called by BARIN.

Calls nothing.

RSET3

This subroutine assigns the values read from records in the boundary value initialization block of the card-image input file to the proper array locations for type REAL variables. This involves mapping from physical location indices (I,J,K) on surface L to a surface element number ($\leq NL1$). Some of the needed information is passed to this routine through COMMON BLOCK /INDLIM/. Alternate entry points DSET3 and ISET3 are called to store type DOUBLE PRECISION and INTEGER variables, respectively.

Called by BARIN.

Calls nothing.

RSURFO

This subroutine prints values from real-number type surface element array VAR for boundary surface number NSUR.

Called by OUTPUT.

Calls nothing.

S

This function returns the 'f(y)' (S) when fluid number 1 is normal water and IFPROP=0 as a function of 'y' (X) needed for the density, specific heat capacity, and saturation temperature functions. See Eqs. B.19 and B.20 (inter alia) in Ref. 2. This function is part of, and only used within, the normal water fluid property package.

Called by ROLIQU, DRODHL, TLIQU, CPLIQU, SNDS.

Calls nothing.

SGEFA

This subroutine from the LINPACK package prepares the matrix system for routine SGESL for variables of type REAL. See description of routine SGESL for additional information.

Called by QSRAD.

Calls other LINPACK (and system) routines.

SGESL

This subroutine, in conjunction with routine SGEFA, solves the system of linear equations $A \cdot X = B$ for the column vector X when the A matrix has a general form. Arrays A , B , and X are all of type REAL. (Routines DGEFA and DGESL are used when the arrays are of type DOUBLE PRECISION (i.e. on short-word machines).) The calling sequence is

```
      REAL A(LDA,MX),B(MX),IPVT(LDA)
      DO 2 I=1,MX
      DO 1 J=1,MX
1     A(I,J)=...
2     B(I)=...
      CALL SGEFA(A,LDA,MX,IPVT,INFO)
      CALL SGESL(A,LDA,MX,IPVT,B,0)
```

where MX is the number of equations, LDA is at least as big as MX , $IPVT$ is a pointer array created by SGEFA and used by SGESL, and $INFO$ will be set nonzero by SGEFA if the system is (nearly) singular. The original structure of matrix A is destroyed by calling SGEFA. Array B contains the solution vector (X) upon return from SGESL.

SGESL and SGEFA (and their counterparts DGESL and DGEFA) are part of LINPACK (Ref. 12), which is a collection of routines for linear algebra available on many computer systems. The LINPACK routines are categorized as system routines; they are not supplied with the COMMIX-1AR/P program package.

Called by QSRAD.

Calls other LINPACK (and system) routines.

SHOME

This subroutine prints diagrams showing locations of all boundary surfaces if $IBSBUG > 0$. This diagram is useful in debugging input errors in the boundary surface identification block of the card-image input file for complicated geometries.

Called by FILLM.

Calls nothing.

SMOOTH

This subroutine performs smoothing by spline functions. It is called in connection with creating polynomial fits to the data the user provides in arrays TVAL and FVAL for the transient functions. COMMON BLOCK /CR/ provides temporary workspace.

Called by FITIT.

Calls nothing.

SNDS

This subroutine returns

$$X1 = S(X)$$

$$XN1 = 1.0 - S(X)$$

when fluid number 1 is normal water and IFPROP=0 as needed for the saturation temperature function. This routine is part of, and only used within, the normal water fluid property package.

Called by TSAT11.

Calls S.

SOLVEN

This subroutine solves an equation system of the form:

$$\begin{aligned} &AT0(M)*V(M) - AT1(M)*V(MIM(M)) - AT2(M)*V(MIP(M)) \\ &\quad - AT3(M)*V(MJM(M)) - AT4(M)*V(MJP(M)) \\ &\quad - AT5(M)*V(MKM(M)) - AT6(M)*V(MKP(M)) \\ &\quad - SPHODL(M,k)*V(MTSODD(M,k)) = BT0(M) \end{aligned}$$

where M is the fluid cell number, V is the array of end-of-step values being solved for, AT_i, BT₀, and SPHODL are coefficient arrays provided by other routines, and arrays Mij and MTSODD are pointers to adjacent and nonadjacent cells. The solution technique is "successive overrelaxation". (More precisely, this is successive overrelaxation if OMEGA > 1, successive underrelaxation if OMEGA < 1, and Gauss Seidel if OMEGA = 1.) One pass through the main part of this routine is an inner iteration; inner iterations are continued until the maximum relative change between successive iterations is less than HCONV or the number of iterations exceeds ITMAX.

This routine is called to solve the fluid energy (coefficient arrays from ENERGI), fluid turbulent kinetic energy (coefficient arrays from TKENER), and

fluid turbulent kinetic energy dissipation rate (coefficient arrays from TDNER) equation systems on scalar machines. (SOLVEV is called on vector machines.) The term involving SPHODL is not used for the two turbulence equation systems.

Called by ENLOOP, TKLOOP, TDLOOP.

Calls nothing.

SOLVEV

This subroutine is used instead of SOLVEN on vector machines. The technique is a red/black-type implementation of the "successive overrelaxation" technique, which is amenable to vectorization. See routine SOLVEN for additional information.

Called by ENLOOP, TKLOOP, TDLOOP.

Calls GETIJK.

SOLVIT

This subroutine solves an equation system of the form:

$$\begin{aligned} &AT0(M)*V(M)-AT1(M)*V(MIM(M))-AT2(M)*V(MIP(M)) \\ &\quad -AT3(M)*V(MJM(M))-AT4(M)*V(MJP(M)) \\ &\quad -AT5(M)*V(MKM(M))-AT6(M)*V(MKP(M))=BT0(M) \end{aligned}$$

where M is the fluid cell number, V is the array of end-of-step values being solved for, AT_i and BT₀ are coefficient arrays provided by other routines, and arrays M_{ij} are pointers to adjacent cells. The solution technique is "successive overrelaxation". (More precisely, this is successive overrelaxation if OMEGA > 1, successive underrelaxation if OMEGA < 1, and Gauss Seidel if OMEGA = 1.) One pass through the main part of this routine is an inner iteration; inner iterations are continued until the maximum residual is less than DCONV or the number of iterations exceeds ITMAXP.

This routine is called to solve the fluid pressure equation if ISYMCH=3 ("successive overrelaxation") or 4 (Jacobi). (If ISYMCH=5, then CGLOOP is called to solve system.) Mass rebalancing is performed every IREBIT-th inner iteration. The coefficient arrays come from PEQN. The variable being solved for is the fluid pressure (relative to the reference pressure) in array P. The mass residual is saved in array DL by cell and the maximum is in DLMAX.

Called by MOLOOP.

Calls REBAZ, REBAZG, GETDL.

SORTC

This subroutine reorders the coefficients during initialization of the conjugate-gradient solution of the pressure equation system. Called after WRPTST. Sweep through all MX remaining cells ii, getting cell numbers, i, from ICELL(ii). Find the number of nonzero entries in NM(n,i) ($n=1,2,\dots,7$); store this in NM(9,i). Rearrange the entries in NM(n,i) ($n=1,2,\dots,7$) so they are in ascending order in NM(n,i) ($n=1,2,\dots,\text{NM}(9,i)$). Store in NM(8,i) the n-position which the term NM(1,i) in the unshuffled array (the "diagonal" term) now occupies in the NM array. Store in NA(n,i) the n-position which the term NM(n,i) occupied in the NM array before it was shuffled.

Called by CGLOOP.

Calls nothing.

STORE

This subroutine defines indices associated with boundary condition cells for the conjugate-gradient solution of the pressure equation system. The routine sweeps over all cells m. Using the fact that if fluid cell number m has its pressure set directly by a boundary condition then array element AC0(m)=1.E40, this routine performs the following actions. If AC0(m) is greater than 1.E20, no action is taken. Otherwise, if any of the six neighboring cells j ($j: 1=-I, 2=+I, 3=-J, 4=+J, 5=-K, 6=+K$) has AC0 greater than 1.E20, then array element NMNP(j,m) is set to the neighboring cell's number; JCELL(n) is set to the cell number of the n-th cell having such neighboring cells. If the neighboring cell has AC0 less than 1.E20, then NMNP(j,m) is set to zero. Variable NCP counts the number of entries made in array JCELL.

Called by CGLOOP.

Calls nothing.

TDLOOP

This subroutine controls the advancement of the turbulent kinetic energy dissipation rate (TKED) across a time step when ITURKE ≥ 11 . This calculation is performed after advancing the turbulent kinetic energy. For ITURKE=11, the routine calculates TKED from arrays TURK and ALNG and constants CDTURB and AKAPPA. For ITURKE=12, the routine puts the current laminar viscosity

into array RMU and calls other routines to setup and solve the transport equation system. The final values of TKED are forced to be positive (using $|TKED|$), since negative values are not allowed. The maximum relative change and cell number in which it occurs are computed and passed back through DDOHT and MDDOHT (between successive outers) and DDOH and MDDOH (since beginning of step).

Called by TIMSTP.

Calls TDNER, SOLVEN/SOLVEV, TLEFTS; VISLIQ.

TDMA

This subroutine solves a tridiagonal matrix system. Basic set of equations are of form:

$$-c(i)*f(i-1) + a(i)*f(i) - b(i)*f(i+1) = d(i)$$

for $i=1,2,\dots,M$ ($M < 100$) with $c(1)=b(M)=0$. Supplied to routine are the simple variable

N: $M+1$ (i.e. number of equations plus one)

and values in the following array locations

A(1,2,...,N-1,N): 0, a(1), a(2), ..., a(M-1), a(M)

B(1,2,...,N-1,N): 0, b(1), b(2), ..., b(M-1), 0

C(1,2,...,N-1,N): 0, 0, c(2), ..., c(M-1), c(M)

D(1,2,...,N-1,N): 0, d(1), d(2), ..., d(M-1), d(M)

PHI(1) = PHI(N+1) = 0

These input values are not altered by the call. The routine does a noniterative forward elimination followed by backward substitution to return the solution in the following array locations:

PHI(2,3,...,N-1,N): f(1), f(2), ..., f(M-1), f(M)

Called by REBAZ, REBAZG.

Calls nothing.

TDNER

This subroutine sets up the transport equation system for turbulent kinetic energy dissipation rate (TKED). This results in a set of coefficient arrays (ATi, $i=0,1,\dots,6$, and BT0) which are passed to a solver routine. Part of the source

term needed in this equation system is passed to this routine from TKSORC in array SCHL.

Called by TDLOOP.

Calls nothing.

THCLIQ

This function returns the laminar (molecular) thermal conductivity (THLIQ) of fluid number 1 when IFPROP=0 as a function of temperature (TC) and/or enthalpy (H). (For IFPROP=1 or fluids other than number 1, the thermal conductivity is obtained from statement function FCOND(n,TC), where n is the fluid number, rather than from THCLIQ.)

Versions of this function exist for sodium, normal water, heavy water, and helium; the user must select which one of these fluid property packages to include at linkedit time. Of the arguments passed, those actually used depend on which fluid package is being used. If this function is changed, other functions in the property package may need to be changed in order to maintain a consistent description of the fluid.

Called by (potentially, depending on fluid) other property routines and BCTEMT, BCTEM0, DUCTWA, QDUCTW, ENERGI, ENRBAL, INITAL, INITA3, HSTRUC (ENERGY, GDDDH if explicit).

Calls (potentially, depending on fluid) other property routines.

THETAS

This function returns the angular position of the wire wrap (THETAS) given an axial location Z1. The angular position, in units of radians, is in the range 0 to 2π ; ZAT0 is a reference axial position where the wrap's angular position is 0; WIREP is the pitch of the wrap winding and its sign indicates the direction of the winding.

Called by INTWIR.

Calls nothing.

TIMSTP

This subroutine controls the advancement of variables across a single time step. This routine calls other routines to solve the pressure (combined mass and

momentum), turbulent kinetic energy, turbulent kinetic energy dissipation rate, and energy equation systems; one pass through this set of routines is an outer iteration. This outer iteration loop is repeated until (1) the relative changes between successive iterates are less than EPS3, (2) the number of outer iterations exceeds IT, or (3) the amount of CPU time remaining is less than TREST. If IDTIME=2 and (1) the outers did not reach convergence or (2) the outers converged but the change in certain variables across the step exceeds CHGMAX, the time step size is reduced and the step is repeated. (There are two alternate paths in the outer iteration: the implicit path should always be used (ISYMCH $\geq$ 3 and IFITEN=3); the explicit path is older coding and has not been kept up to date.)

Called by AMAIN.

Calls BCPRES, MOLOOP, VISFIX, BCTURB, TKLOOP, TDLOOP, TURV12, ENLOOP, TLEFTS, GETEKL, BCFLOW, BCTEMP, TSTRUC, QSRAD, BCFLOF; CPLIQ, DRODHL, ROLIQ, TLIQ. (If explicit: MALOOP, BCTEM0, DLCALC, GDDDH, ENERGY.)

TKENER

This subroutine sets up the transport equation system for turbulent kinetic energy (TURK). This results in a set of coefficient arrays (AT_i, $i=0,1,\dots,6$, and BT₀) which are passed to a solver routine. Part of the source term needed in this equation system is passed to this routine from TKSORC in array SCHL.

Called by TKLOOP.

Calls WLFNCK.

TKLOOP

This subroutine controls the advancement of the turbulent kinetic energy (TURK) across a time step when ITURKE $\geq$ 11. This calculation is performed after advancing the pressure and velocities. The routine puts the current laminar viscosity into array RMU and calls other routines to setup and solve the transport equation system. The final values of TURK are forced to be positive (using |TURK|), since negative values are not allowed. The maximum relative change and cell number in which it occurs are computed and passed back through

DKOHT and MDKOHT (between successive outers) and DKOH and MDKOH (since beginning of step).

Called by TIMSTP.

Calls TKSORC, TKENER, SOLVEN/SOLVEV, TLEFTS; VISLIQ.

TKSORC

This subroutine sets up the source term array (SCHL) for use in building the transport equation systems for turbulent kinetic energy and turbulent kinetic energy dissipation rate when $ITURKE \geq 11$. This term includes the velocity and thermal gradient terms (i.e. P_k and G_k as defined by Eqs. 7.6 and 7.7 of Ref. 1). (The coding in this routine is identical to that used to calculate SCHL in VELOG except that the thermal gradient term is not included in VELOG.)

Called by TKLOOP.

Calls VELCEN; DRODHL.

TLEFTS

This function returns the amount of CPU time (seconds) remaining before job time limit will be exceeded. This is accomplished by calling a system routine which is not supplied as part of the COMMIX-1AR/P program package. (To run in interactive mode or on systems that can not simulate this function, include a replacement function which returns a result which is greater than 10.0.)

Called by AMAIN, CGLOOP, CNGRIC, ENLOOP, FILLM, GEOM3D, MOLOOP, TDLOOP, TIMSTP, TKLOOP (MALOOP if explicit).

Calls TLEFT (ANL system routine).

TLFIX

This subroutine calculates the turbulence length scale (ALNG) when $ITURKE=10$. The length scale is the distance from the center of a fluid cell to the closest boundary surface having $KFLOW=1$ and $VELBN=0$ but is limited to being less than $0.175*HYDIN$.

Called by INITUR.

Calls nothing.

TLIQ

This function returns the temperature (TLIQ) of fluid number 1 when IFPROP=0 as a function of enthalpy (H1) and/or pressure (P1) by inverting the HLIQ function. If this must be done numerically, T0 is a starting guess temperature for the iteration. (For IFPROP=1 or fluids other than number 1, the temperature is obtained from statement function FTEMP(n,H1), where n is the fluid number, rather than from TLIQ.) Functions TLIQ and HLIQ must be fairly exact inverses of each other.

Versions of this function exist for sodium, normal water, heavy water, and helium; the user must select which one of these fluid property packages to include at linkedit time. Of the arguments passed, those actually used depend on which fluid package is being used. If this function is changed, other functions in the property package may need to be changed in order to maintain a consistent description of the fluid.

Called by (potentially, depending on fluid) other property routines and TIMSTP, INITA3, INITZ1, OUTPUT, QSTRDS (ENERGY if explicit).

Calls (potentially, depending on fluid) other property routines and ERRCHK.

TSAT11

This function returns the saturation temperature (TSAT11) when fluid number 1 is normal water and IFPROP=0 as a function of pressure (P) as needed for the saturation pressure function (which performs an iterative numerical inversion). This function is part of, and only used within, the normal water fluid property package.

Called by PSAT1.

Calls POLY, SNDS.

TSCAN

This subroutine does an initial screening of the blocks in the card-image input file which are associated with thermal structures in order to allocate storage. Reads NAMELIST STRUCT, the thermal structure prototype input block (which consists of NAMELISTs T, F, and M), and the thermal structure location input block. Fills part of array ITSCB, passes allocation information back to AAMAIN

through the argument list, and passes record-order information to INPSTR through COMMON BLOCK /CSCAN/.

Called by AAMAIN.

Calls ERRCHK.

TSTRUC

This subroutine sweeps over all thermal structures updating the temperatures, TTS, of all partitions. During this process, the temperatures, TROD, of all radiation surfaces are updated (using an average of TTS over the surface) and the total heat generation rate in the solid is summed into QSOLID. When called from TIMSTP, the outer iterations have converged and this routine advances TTS from beginning-of-step to end-of-step values.

The majority of the coding in this routine is identical to the coding used in QSTRUC and QSTRDS; any changes to the method must be implemented consistently in all three routines.

Called by AMAIN, INITZ1, TIMSTP (ENERGY if explicit).

Calls GETF; CPSOL1, XKSOL1.

TURV12

This subroutine calculates the turbulent viscosity (TURVIS) and turbulent thermal conductivity (TURCON) when ITURKE ≥ 11 . The routine is called after the turbulent kinetic energy (TURK) and turbulent kinetic energy dissipation rate (TKED) have been advanced to end of step values. The turbulent viscosity is a function of TURK, TKED, CDTURB, and fluid properties (cf. Eq. 7.12 of Ref. 1); new values are relaxed by OMEGAT from prior values. The turbulent thermal conductivity is a function TURVIS, PRNDLH, and fluid properties (cf. Eq. 7.14 of Ref. 1); it is only computed when IFENER > 0.

Called by INITUR, TIMSTP.

Calls CPLIQ, VISLIQ.

UPDATE

This subroutine performs an initialization adjustment of the source term vector, BP, to include boundary conditions in the conjugate-gradient solution of the pressure equation system. Called after STORE. For each of the NCP

boundary cells jj look at all six neighbor cells ($n=1,2,\dots,6$); if NMNP(n,i) is nonzero, then set

$$BP(i) = BP(i) + ACn(i)*P(NMNP(n,i))$$

where $i=JCELL(jj)$, ACn and BP are the pressure equation coefficient arrays, and P is the pressure array.

Called by CGLOOP.

Calls nothing.

UPPFAC

This subroutine solves an upper triangular matrix system, $AU*X=F$, as part of the conjugate-gradient solution of the pressure equation system on scalar machines. (LOWFCV is used on vector machines.) AU is the upper triangular matrix, F is the source vector, NX is the order of system, arrays NM and ICELL show cell coupling; solution vector is returned in array X.

Called by CNGRIC.

Calls nothing.

VELCEN

This subroutine calculates the velocity component (VEL) at the center of cell M0 by averaging the velocity components (from VL or VELBN) at two opposite faces (M3 and M4). Argument meanings depend on direction:

<u>Dir.</u>	<u>VL</u>	<u>M3</u>	<u>M4</u>
I	UL	MIM(M0)	MIP(M0)
J	VL	MJM(M0)	MJP(M0)
K	WL	MKM(M0)	MKP(M0)

Called by TKSORC, VELOG.

Calls nothing.

VELOG

This subroutine calculates the velocity gradient term (SCHL) for each cell when ITURKE=10. This term is used in VISFIX to calculate TURVIS. (The coding in this routine is identical to that used to calculate SCHL in TKSORC except that the thermal gradient term is not included in VELOG.)

Called by VISFIX.

Calls VELCEN.

VISFIX

This subroutine calculates the turbulent viscosity (TURVIS) and turbulent thermal conductivity (TURCON) when ITURKE=10. The routine is called after the pressure (P) and velocities (UL, VL, and WL) have been advanced to end-of-step values. The turbulent viscosity is a function of SCHL, ALNG, AKAPPA, and fluid properties (cf. Eq. 7.32 of Ref. 1); new values are relaxed by OMEGAT from prior values. The turbulent thermal conductivity is a function TURVIS, PRNDLH, and fluid properties (cf. Eq. 7.14 of Ref. 1); it is only computed when IFENER>0.

Called by INITUR, TIMSTP.

Calls VELOG; CPLIQ.

VISLIQ

This function returns the absolute laminar (molecular) viscosity (VISLIQ) of fluid number 1 when IFPROP=0 as a function of temperature (TC), enthalpy (H), and/or pressure (P). (For IFPROP=1 or fluids other than number 1, the viscosity is obtained from statement function FVISC(n,TC), where n is the fluid number, rather than from VISLIQ.)

Versions of this function exist for sodium, normal water, heavy water, and helium; the user must select which one of these fluid property packages to include at linkedit time. Of the arguments passed, those actually used depend on which fluid package is being used. If this function is changed, other functions in the property package may need to be changed in order to maintain a consistent description of the fluid.

Called by (potentially, depending on fluid) other property routines and BCTEM0, DUCTWA, QDUCTW, INITAL, INITA3, INITZ1, MOLOOP, HSTRUC, TDLOOP, TKLOOP, TURV12, XMOMI, YMOMI, ZMOMI (XMOM, YMOM, ZMOM if explicit).

Calls (potentially, depending on fluid) other property routines.

VOLCEL

This subroutine initializes a fluid volume array (VOL) during initialization of the conjugate-gradient solution of the pressure equation system. Called after ELIM. Sweep over all NX cells, jj, still remaining in the equation set and define

VOL(m) to be the fluid volume ($AL0(m)*DX(i)*DY(j)*DZ(k)$), where $m=ICELL(jj)$ and i, j, and k are cell spatial location indices unpacked from IJK(m).

Called by CGLOOP.

Calls nothing.

WATSTP

This subroutine is used to see if the current time step number (NTIME) is one specified by the user (in array NTIMES) at which results are to be printed or written to the plot file or at which GDCONV is to be called to revise DCONV. If so, set IFCALL=1; otherwise, set IFCALL=0. Variable INDEX keeps track of the index of the value in array NTIMES which is currently controlling the setting of IFCALL and is advanced by WATSTP as needed to step through the array. The correspondence between formal and actual arguments depends on the type of call:

<u>Type of Call</u>	<u>NTIMES</u>	<u>INDEX</u>
print	NTPRNT	NPR
plot	NTPLOT	NPL
revise DCONV	NTHCON	ITCN

Called by AMAIN.

Calls nothing.

WATTIM

This subroutine is used to see if the current time step time (TIME) is one specified by the user (in array TIMES, which is user-input array TPRNT) at which results are to be printed. If so, set IFCALL=1; otherwise, set IFCALL=0. Variable INDEX (which passes the value of NTPR) keeps track of the index of the value in array TIMES which is currently controlling the setting of IFCALL and is advanced as needed by WATTIM to step through the array.

Called by AMAIN.

Calls nothing.

WIRE   This subroutine calculates quantities needed during initialization of arrays for the cell-integrated wire wrap model (IWIRE=2). For a given cell having spatial location indices $I=IC$ and $J=JC$ and axial position $Z=ZEE$, the routine calculates the axial cell flow area occupied by the wrap (AREAW) and the +X and +Y cell face lengths blocked by the wrap (XLENTH and YLENTH, respectively).

Called by INTWIR, WIRVOL.

Calls nothing.

WIRVOL   This subroutine calculates quantities needed during initialization of arrays for the cell-integrated wire wrap model (IWIRE=2). For a given cell having spatial location indices I and J and between axial positions $Z=Z1$ and $Z=Z2$, the routine calculates the cell volume occupied by the wrap (VOL) and the +X and +Y cell face areas blocked by the wrap (XAREA and YAREA). Routine does numerical integration.

Called by INTWIR.

Calls nothing.

WLFNCK   This subroutine calculates the modified source term P_k (PKTERM) for the turbulent kinetic energy transport equation for a cell adjacent to a boundary surface having $KFLOW=1$ and $VELBN=0$ when $ITURKE \geq 11$ (cf. Eq. 7.25 of Ref. 1).

Should maintain consistency with coding in WLFNCV.

Called from TKENER.

Calls YOFRE.

WLFNCV   This subroutine calculates the wall shear stress τ_w (TAUWAL) for the momentum transport equation for a cell adjacent to a boundary surface having $KFLOW=1$ and $VELBN=0$ when $ITURKE \geq 11$ (cf. Eq. 7.18 of Ref. 1).

Should maintain consistency with coding in WLFNCK.

Called from XMOMI, YMOMI, ZMOMI.

Calls YOFRE.

WRPTST

This subroutine checks for cylindrical wrap around during initialization of the conjugate-gradient solution of the pressure equation. Called after VOLCEL only if IGEOM=-1 and JMAX=3. (An error stop is performed during the input stage by routine AMAIN if the following four conditions are all true: IGEOM=-1, $\text{sum}(\text{DY}(j))=2\pi$ (for $J=1,2,\dots,J\text{MAX}$), ISYMCH=5, and $J\text{MAX}<3$.) KSRCH is initialized to 0 before calling this routine. The routine sweeps over all NX remaining cells ii. If the routine finds that

$$\text{MJP}(\text{MJP}(\text{MJP}(\text{ICELL}(\text{ii})))) = \text{ICELL}(\text{ii})$$

where ICELL(ii) are the cell numbers and MJP(i) is the cell number on the +J side of cell i (and is negative if the +J side is a boundary surface element), then KSRCH is set to 1. This means that all three cells in the plane are coupled circularly in the pressure equation which means the factorization technique must be altered. (If encounter $\text{MJP}<0$ at any point in evaluating the above check, then terminate check for this cell without altering KSRCH.)

Called by CGLOOP.

Calls nothing.

XKSOL1

This function returns the thermal conductivity of solid material number IRM at temperature T0. Nominally this is computed using a second-order polynomial in temperature having user-supplied coefficients CiK(IRM), $i=0,1,2$, but the user may supply coding in this routine for other functional forms.

Called by BCTEM0, DUCTWA, QDUCTW, TSTRUC, QSTRUC, QSTRDS.

Calls nothing.

XMOM

This subroutine sweeps over all fluid cells m to set up the I-direction (x or r) momentum equation for an outer iteration. The formulation of the momentum equation is explicit in time. The time-dependent, convective, diffusive, gravity, and wire-wrap terms are formed in this routine. Another routine is called for the force structure contribution. The result of this routine fills arrays ARUL and OARU, which will be passed to MOMENT to solve for

velocities after the pressure solution is obtained:

$$UL(m) = (ARUL(m) - (P(MIP(m)) - P(m)) * DTIME * AL / DX) * OARU(m)$$

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by MALOOP.

Calls FORCES; VISLIQ.

XMOMI

This subroutine sweeps over all fluid cells m to set up the I-direction (x or r) momentum equation for an outer iteration. The formulation of the momentum equation is implicit in time. The time-dependent, convective, diffusive, gravity, and wire-wrap terms are formed in this routine. Other routines are called for wall shear ($ITURKE \geq 11$), force structure, and pump contributions. The result of this routine fills arrays UHATL and DU0L, which will be passed to PEQN to form the pressure equation system. After the pressure solution is obtained, the velocity is computed from

$$UL(m) = UHATL(m) - DU0L(m) * (P(MIP(m)) - P(m))$$

in MOMENI.

Called by MOLOOP.

Calls WLFNCV, FORCES, PUMPQ; VISLIQ.

YMOM

This subroutine sweeps over all fluid cells m to set up the J-direction (y or θ) momentum equation for an outer iteration. The formulation of the momentum equation is explicit in time. The time-dependent, convective, diffusive, gravity, and wire-wrap terms are formed in this routine. Another routine is called for the force structure contribution. The result of this routine fills arrays ARVL and OARV, which will be passed to MOMENT to solve for velocities after the pressure solution is obtained:

$$VL(m) = (ARVL(m) - (P(MJP(m)) - P(m)) * DTIME * AL / DY) * OARV(m)$$

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is

old coding and has not been kept up to date.

Called by MALOOP.

Calls FORCES; VISLIQ.

YMOMI

This subroutine sweeps over all fluid cells m to set up the J -direction (y or θ) momentum equation for an outer iteration. The formulation of the momentum equation is implicit in time. The time-dependent, convective, diffusive, gravity, and wire-wrap terms are formed in this routine. Other routines are called for wall shear ($ITURKE \geq 11$), force structure, and pump contributions. The result of this routine fills arrays $VHATL$ and $DVOL$, which will be passed to $PEQN$ to form the pressure equation system. After the pressure solution is obtained, the velocity is computed from

$$VL(m) = VHATL(m) - DVOL(m) * (P(MJP(m)) - P(m))$$

in MOMENI.

Called by MOLOOP.

Calls WLFNCV, FORCES, PUMPQ; VISLIQ.

YOFRE

This function solves the following equation for y (YOFRE) given a Reynolds number (RE):

$$RE = (y/AKAPPA) * \log_e(1 + AKAPPA * y * f(y))$$

where

$$f(y) = (1 + (EE * AKAPPA) * (a * y)^b) / (1 + (a * y)^b)$$

and $AKAPPA$, EE , a , and b are constants (cf. Eqs. 7.22a and 7.23 of Ref. 1). Only used when $ITURKE \geq 11$. Solution is via a Newton iteration. The y and $d(RE/y)/d(y)$ (DUDY) are returned for use in defining the wall shear stress (τ_w). The basic form of the equation has proper limits for very low and very high flow rates and provides a blending between these two limits over a narrow transition region.

Called by WLFCNV, WLFNCK.

Calls nothing.

ZMOM

This subroutine sweeps over all fluid cells m to set up the K-direction (z) momentum equation for an outer iteration. The formulation of the momentum equation is explicit in time. The time-dependent, convective, diffusive, gravity, and wire-wrap terms are formed in this routine. Another routine is called for the force structure contribution. The result of this routine fills arrays ARWL and OARW, which will be passed to MOMENT to solve for velocities after the pressure solution is obtained:

$$WL(m) = (ARWL(m) - (P(MKP(m)) - P(m)) * \Delta TIME * AL/DZ) * OARW(m)$$

This routine is only called when one of the explicit momentum solution methods is selected, which is never the recommended mode of solution; this is old coding and has not been kept up to date.

Called by MALOOP.

Calls FORCES; VISLIQ.

ZMOMI

This subroutine sweeps over all fluid cells m to set up the K-direction (z) momentum equation for an outer iteration. The formulation of the momentum equation is implicit in time. The time-dependent, convective, diffusive, gravity, and wire-wrap terms are formed in this routine. Other routines are called for wall shear ($ITURKE \geq 11$), force structure, and pump contributions. The result of this routine fills arrays WHATL and DW0L, which will be passed to PEQN to form the pressure equation system. After the pressure solution is obtained, the velocity is computed from

$$WL(m) = WHATL(m) - DW0L(m) * (P(MKP(m)) - P(m))$$

in MOMENI.

Called by MOLOOP.

Calls WLFNCV, FORCES, PUMPQ; VISLIQ.

ACKNOWLEDGMENTS

As COMMIX-1AR/P is an extension to earlier versions of COMMIX, we acknowledge the liberal use of the prior COMMIX documentation in preparing this report and thank the developers of the prior COMMIX versions for their time in discussing the implementation of the new modeling described herein.

We deeply appreciate the diligent work of Betty Kinney and Jill McGregor in typing the manuscript.

This work was supported by the United States Department of Energy.

REFERENCES

1. R. N. Blomquist, P. L. Garner, and E. M. Gelbard, "COMMIX-1AR/P: A Three-Dimensional Transient Single-Phase Computer Program for Thermal Hydraulic Analysis of Single and Multicomponent Systems; Volume 1: Equations and Numerics", ANL-90/45, Argonne National Laboratory, Argonne, IL (July 1991).
2. P. L. Garner, R. N. Blomquist, and E. M. Gelbard, "COMMIX-1AR/P: A Three-Dimensional Transient Single-Phase Computer Program for Thermal Hydraulic Analysis of Single and Multicomponent Systems; Volume 2: User's Guide", ANL-92/33, Argonne National Laboratory, Argonne, IL (September 1992).
3. W. T. Sha, H. M. Domanus, R. C. Schmitt, J. J. Oras, and E. I. H. Lin, "COMMIX-1: A Three-Dimensional Transient Single-Phase Component Computer Program for Thermal-Hydraulic Analysis", NUREG/CR-0785 (or ANL-77-96), Argonne National Laboratory, Argonne, IL (September 1978).
4. H. M. Domanus, R. C. Schmitt, W. T. Sha, and V. L. Shah, "COMMIX-1A: A Three-Dimensional Transient Single-Phase Computer Program for Thermal Hydraulic Analysis of Single and Multicomponent Systems; Volume I: Users Manual", NUREG/CR-2896 (or ANL-82-25), Vol. I, Argonne National Laboratory, Argonne, IL (December 1983).
5. H. M. Domanus, R. C. Schmitt, W. T. Sha, and V. L. Shah, "COMMIX-1A: A Three-Dimensional Transient Single-Phase Computer Program for Thermal Hydraulic Analysis of Single and Multicomponent Systems; Volume II: Assessment and Verification", NUREG/CR-2896 (or ANL-82-25), Vol. II, Argonne National Laboratory, Argonne, IL (December 1983).
6. "COMMIX-1B: A Three-Dimensional Transient Single-Phase Computer Program for Thermal Hydraulic Analysis of Single and Multicomponent Systems; Volume I: Equations and Numerics", NUREG/CR-4348 (or ANL-85-42), Vol. I, Argonne National Laboratory, Argonne, IL (September 1985).

7. "COMMIX-1B: A Three-Dimensional Transient Single-Phase Computer Program for Thermal Hydraulic Analysis of Single and Multicomponent Systems; Volume II: User's Manual", NUREG/CR-4348 (or ANL-85-42), Vol. II, Argonne National Laboratory, Argonne, IL (September 1985).
8. "American National Standard: Programming Language FORTRAN", ANSI X3.9-1978, American National Standards Institute, Inc., New York, NY (1978).
9. "ADR/The LITERARIAN: User Reference Manual", Applied Data Research, Inc., Princeton, NJ (1985).
10. C. H. Adams, K. L. Derstine, H. Henryson II, R. P. Hosteny, and B. J. Toppel, "The Utility Subroutine Package Used by Applied Physics Division Export Codes", ANL-83-3, Argonne National Laboratory, Argonne, IL, 25-33 (1983).
11. "Standard for Metric Practice", ANSI/ASTM E 380-76, American Society for Testing and Materials, Philadelphia, PA (1976).
12. J. J. Dongarra, C. B. Moler, J. R. Bunch, and G. W. Stewart, LINPACK User's Guide, Soc. for Ind. and Appl. Math., Philadelphia, PA (1979).

COMMIX-1AR/P Computer Program Problem or Suggestion Report (9/23/91)

Complete the top part of this form and submit to one of the persons whose name is shown on the banner page of the Input Guide or of your output file.

Submitted by: Name: _____ Date: ____/____/____

Mailing Address: _____

Telephone Number: ____ - ____ - ____ E-mail Address: _____

Type of Problem: Execution: ____ Documentation: ____ Suggestion: ____ Other: _____

Code Version (from banner page): Name: _____ Date: ____/____/____

Machine: Brand: _____ Model: _____ Operating System: _____

Description of Problem or Suggestion (be as specific as possible):

_____
To be completed by COMMIX-1AR/P Code Maintenance Staff

Received: ____/____/____ Source: phone: ____ mail: ____ E-mail: ____ FAX: ____ other: _____

Log Number: _____ Priority: _____ Assigned to: _____

Action(s) (with date and by whom):

Distribution for ANL-92/34

Internal:

C. H. Adams	P. L. Garner (25)	R. M. Singer
R. N. Blomquist	E. M. Gelbard	M. J. Tan
M. Bottoni	K. C. Gross	A. M. Tentner
L. L. Briggs	D. J. Hill	C. E. Till
F. B. Brown	Kalimullah	C. P. Tzanos
J. E. Cahalan	H. S. Khalil	R. A. Valentin
T. R. Canfield	M. Minkoff	R. B. Vilim
Y. S. Cha	D. Mohr	D. C. Wade
Y. I. Chang	E. E. Morris	D. P. Weber
T. H. Chien	H. M. Park	T. Y. Wei
D. H. Cho	P. A. Pizzica	R. A. Wigeland
H. M. Domanus	H. P. Planchon	B. S. Yarlagadda
F. E. Dunn	R. C. Schmitt	ANL Patent Department
E. E. Feldman	W. T. Sha	ANL Contract File
P. J. Finck	Y. W. Shin	TIS Files (3)
E. K. Fujita	J. J. Sienicki	

External:

DOE-OSTI for distribution per UC-542 (68)

ANL-TIS Libraries

Chicago Operations Office, DOE:

A. L. Taboas

J. L. Hooper

DOE Headquarters, Washington, DC:

H. Alter

P. B. Hemmig

J. W. Herczeg

J. M. Berkoe, Bechtel Power Corporation, San Francisco, CA

P. Kroeger, Brookhaven National Laboratory

G. Van Tyle, Brookhaven National Laboratory

D. Grand, CEA-Centre d'Etudes Nucleaires de Grenoble, France

M. Parent, CEA-Centre d'Etudes Nucleaires de Grenoble, France

T. Charlton, EG&G Idaho Inc., Idaho Falls

S. Z. Rouhani, EG&G Idaho Inc., Idaho Falls

E. Brega, ENEL-Thermal and Nuclear Research Center, Milan, Italy

M. McDowell, Energy Technology Engineering Center

A. Shenoy, General Atomics, San Diego, CA

P. MaGee, General Electric Company, San Jose, CA

J. A. Turner, Los Alamos National Laboratory

N. E. Todreas, Massachusetts Institute of Technology, Cambridge

M. Oszewski, Oak Ridge National Laboratory

S. Aslam, University of Illinois, Urbana

S. Gallopoulos, University of Illinois, Urbana

M. Berzins, University of Leeds, England

N. Aslam, University of Michigan, Ann Arbor

J. Dorning, University of Virginia, Charlottesville

Rizwan-uddin, University of Virginia, Charlottesville

**DATE
FILMED**

3 / 17 / 93