LA-SUB--94-149

*Low-Level RF LabVIEW[®] Control Software
User's Manual*

Los Alamos

*Los Alamos National Laboratory is operated by the University of California for
the United States Department of Energy under contract W-7405-ENG-36.*

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

*This work was supported by the US Department of Defense,
Army Strategic Defense Command.*

An Affirmative Action/Equal Opportunity Employer

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither The Regents of the University of California, the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by The Regents of the University of California, the United States Government, or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of The Regents of the University of California, the United States Government, or any agency thereof.

DISCLAIMER

Portions of this document may be illegible in electronic image products. Images are produced from the best available original document.

Los Alamos
NATIONAL LABORATORY
Los Alamos, New Mexico 87545

**LOW-LEVEL RF LabVIEW®
CONTROL SOFTWARE
User's Manual**

Specifically developed for the University of Twente

Version 1.0

**ACCELERATOR TECHNOLOGY DIVISION
AT-5, LOW-LEVEL RF SECTION**

MASTER

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

87B ✓

LOW-LEVEL RF LABVIEW CONTROL SOFTWARE USER'S MANUAL

For further information on the subject matter covered herein, contact:

Low-level RF Section Leader
AT-5 RF & Microwave Group
Accelerator Technology Division
Los Alamos National Laboratory
Los Alamos, NM 87545
The United States of America
(505) 667-1200

Los Alamos National Laboratory is operated by the University of California for the United States Department of Energy under contract W-7405-ENG-36.

Contents

1. LLRF Control Software Overview	1-1
1.1 Document Introduction	1-1
1.2 Chapter Introduction	1-2
1.3 Software Background	1-3
1.4 Running the LLRF Control Software	1-6
1.5 Shutting Down the LLRF Control Software	1-7
1.6 Operating the Mouse	1-7
1.7 Operating the Controls	1-8
1.7.1 Buttons	1-8
1.7.2 Alterable Data Fields	1-8
1.7.3 Switches	1-9
1.7.4 Selectable Data Fields	1-9
1.7.5 Scroll Bars	1-10
1.8 System-Level Control Panels	1-10
1.8.1 Disclaimer Panel	1-11
1.8.2 Hierarchy Panel	1-11
1.8.3 LLRF Control System Menu Panel	1-12
1.8.4 Accelerator Operational Modes Panel	1-13
1.8.5 Control System Setup Modes Panel	1-14
1.8.6 Exit Panel	1-15
1.8.7 Pop-Up Windows	1-16
2. LLRF Operational Modes	2-1
2.1 Chapter Overview	2-1
2.2 Normal Operations Panel	2-1
2.3 Cavity Conditioning Panel	2-6
2.4 Status Panel	2-11
3. RESONANCE Detection	3-1
3.1 Chapter Overview	3-1
3.2 Resonance Detection Status Panel	3-1
3.3 Resonance Detection Setup Panel	3-3
3.4 Calibrate Reflectometer Panel	3-8
3.5 Calibration Standards Panel	3-12
4. Field CONTROL Subsystem	4-1
4.1 Chapter Overview	4-1
4.2 Field Control Status	4-1
4.3 Field Control Setup Panel	4-4
4.4 Gain Schedule Identification Panel	4-10
4.5 Gain Schedule Data Table Panel	4-15
4.6 Adaptive Feedforward Panel	4-19
5. Diagnostic Monitor Subsystem	5-1
5.1 Chapter Overview	5-1
5.2 Diagnostic Monitor Status Panel	5-1
5.3 Diagnostic Monitor Setup Panel	5-3
6. Timing Subsystem	6-1
6.1 Chapter Overview	6-1

6.2 Timing Status	6-1
6.3 Timing Pulse Descriptions	6-4
6.4 Timing Setup Panel	6-7
7. Alarm & Limit Subsystem	7-1
7.1 Chapter Overview	7-1
7.2 Alarm & Limit Status Panel	7-1
7.3 Alarm & Limit Setup Panel	7-5

Figures

Figure 1-1. Software file hierarchy.	1-5
Figure 1-2. LLRF control panel hierarchy.	1-6
Figure 1-3. Button.	1-8
Figure 1-4. Alterable data field.	1-8
Figure 1-5. Switches.	1-9
Figure 1-6. Selectable data field.	1-9
Figure 1-8. Scroll Bars.	1-10
Figure 1-9. Disclaimer panel.	1-11
Figure 1-10. Hierarchy panel.	1-12
Figure 1-11. LLRF control system menu panel.	1-13
Figure 1-12. Accelerator operational modes panel.	1-14
Figure 1-13. Control system setup modes panel.	1-15
Figure 1-14. Exit panel.	1-16
Figure 1-15. Pop-up menu panel.	1-17
Figure 2-1. Normal operations panel.	2-2
Figure 2-2. Cavity conditioning panel.	2-7
Figure 2-3. Status panel.	2-12
Figure 3-1. Resonance detection status panel.	3-2
Figure 3-2. Resonance detection setup panel.	3-4
Figure 3-3. Calibrate reflectometer panel.	3-9
Figure 3-4. Calibration standards panel.	3-13
Figure 4-1. Field control status panel.	4-2
Figure 4-2. Field control setup panel.	4-5
Figure 4-3. Gain schedule identification panel.	4-10
Figure 4-4. Gain schedule data table panel.	4-15
Figure 4-5. Adaptive feedforward panel.	4-20
Figure 5-1. Diagnostic monitor status panel.	5-2
Figure 5-2. Diagnostic monitor setup panel.	5-4
Figure 6-1. Timing status panel.	6-2
Figure 6-2. Timing pulse examples.	6-4
Figure 6-3. Timing setup panel.	6-8
Figure 7-1. Alarm & limit status panel.	7-2
Figure 7-2. Alarm & limit setup panel.	7-6

Tables

Table 1-1. AT-5 LLRF module logical addresses.	1-4
---	-----

ABBREVIATIONS

*	Indicates an active-low signal
n	Indicates signal/device number 'n'
AFF	Adaptive feedforward
ARB	Cavity amplitude readback
ASP	Cavity amplitude setpoint
ASPSF	Cavity amplitude setpoint scale factor
CAL	Calibration
CDA	Cavity drive adjustment
CDSF	Cavity drive adjustment scale factor
CH	Channel number 'n'
CLK	Clock
CPLR	Coupler
DIFF	Differential
DRV	Cavity drive
DS	Delay skew
DSTRB	Disturbance signal
ENV	Envelope
ERR	Error
FFWD I	Adaptive feedforward signal, in-phase component
FFWD Q	Adaptive feedforward signal, quadrature component
FLD	Cavity RF field
FLD I	Cavity RF field, in-phase component
FLD Q	Cavity RF field, quadrature component
FP	Fast-protection
FWD	Forward
FWDP	Forward drive power
GND	Ground
HPD	High-power drive
HPRF	High-power radio frequency
I	In-phase
ICM	I Controller Module
IDM	Initial drive magnitude
INT	Integral
IVAL	Initial value
LANL	Los Alamos National Laboratory
LLRF	Low-level radio-frequency
LORD	LLRF output, raw data
LOSF	LLRF output, scale factor
LPO	Loop phase offset
MAG	Magnitude
OL	Open-loop
OLDRV	Open-loop drive
OLSF	Open-loop drive scale factor
PHS	Phase
PID	Proportional, integral, differential

PRB Cavity RF field phase readback
 PROP Proportional
 PSP Cavity phase setpoint
 Q Quadrature
 QCM Q Controller Module
 RASF Reflectometer 'a' scale factor
 RBSF Reflectometer 'b' scale factor
 REFL A Reflectometer 'a' signal
 REFL B Reflectometer 'b' signal
 REFL A+B .. Reflectometer 'a + b' channel
 REFL A+jB .. Reflectometer 'a + jb' channel
 RF Radio-frequency
 RFD RF timing-pulse delay
 RFGD RF gate delay
 RFGW RF gate width
 RFW RF timing-pulse width
 RVS Reverse
 RVSP Reverse drive power
 SFI Cavity RF field scale factor, in-phase component
 SFQ Cavity RF field scale factor, quadrature component
 SMPL Sampling signal
 SPR Spare
 THRESHn ... Threshold signal 'n'
 VDM Vector Detector Module
 VI Virtual instrument
 VXibus VMEbus extension for instrumentation
 WS Width skew

This page has been left blank intentionally.

1. LLRF CONTROL SOFTWARE OVERVIEW

1.1 Document Introduction

This document details information on the low-level radio frequency (LLRF) software control package. The software is associated with the control system developed by the Los Alamos National Laboratory (LANL) for use at the University of Twente. It is based on the LabVIEW® development software created by National Instruments Corporation. The software is contained on the disk drive in the embedded processor module, and accessed through the keyboard and monitor associated with the module. This manual describes how the software is accessed and operated, and for what each portion is generally used.

The manual is divided into several chapters, each presenting a group of panels that are functionally related. The chapters are further divided into sections, every section covering one of the individual control panels. The descriptions of the individual control panels each contain a view of the panel, and a comprehensive summary of all control functions and data displays on that panel.

For the convenience of the readers, the overall structure of this document is the same as that used in the system description document¹. As in that document, the control system hardware components have been combined to create several conceptual subsystems. Each of the subsystems has a separate chapter dedicated to it. The chapters appear in the same order as the related chapters in the system description, and have corresponding chapter numbers.

The chapters in this manual cover the following topics:

- Chapter one describes the general operating principles of the LabVIEW® software package, and also discusses the high-level menu panels which allow access to the individual control panels.
- Chapter two covers the control panels used for conditioning the cavity, and for controlling the accelerator under normal operating conditions.
- Chapter three provides information on the resonance detection and reflectometer calibration functions, including the setup and status panels for each. The cavity resonance detection subsystem monitors the RF frequency of the cavity to find out if the temperature regulator is maintaining the cavity resonance properly. The operator is notified if the cavity drifts too far from resonance.

1. *University of Twente RF System Description*, under development.

- Chapter four contains instructions on the use of those panels dedicated to controlling the cavity RF field; the field control panels, the gain scheduling panels, and the adaptive feedforward panels. The cavity field control subsystem regulates the phase and amplitude of the cavity RF field. The field is kept at a user-defined setpoint using a PID-based feedback control system, while filters are implemented to eliminate noise and disturbances. The combination effectively maintains operational stability over changes in the electrical structure of the accelerator.
- Chapter five discusses the control panels that provide setup and status information on the diagnostic monitor subsystem. The subsystem gathers information about the accelerator system, both as a set of real-time diagnostic signals and as sampled/held RF magnitude levels which are converted into digital bit-sets.
- Chapter six outlines those panels used to control the timing functions provided by the LLRF system. The timing subsystem provides the precision timing signals used to synchronize the various systems of the pulsed particle accelerator. The 40 MHz reference clock and the precursory trigger are the basis of all timing signals.
- Finally, chapter seven describes the control panels used to monitor and adjust the alarm & limit functions of the system. The alarm & limit subsystem monitors several signals in the LLRF system, and alerts the user when any of these signals are outside of their normal bounds. Additionally, it enforces limits on the LLRF output signal, thus restricting the level at which the cavity is driven.

Throughout the document, it is assumed that the reader has a general working knowledge of accelerators, high-power amplifier equipment, and low-level RF (LLRF) control systems. References are listed as footnotes as they occur in the text.

1.2 Chapter Introduction

This chapter has been included to provide an overall view of the control software package. It provides some general background information about the software, instructions for using it, and details on the control panels which do not correspond to any specific subsystem. Specifically, the chapter includes:

- Addressing data about the control system designed for the University of Twente,
- A description of the software file hierarchy,
- How to start up the software package,
- How to shut down the software package,
- How to use each of the various types of controls contained on the panels.
- Data on the password panel, which asks the user for a valid user name and password combination,

- Details on the LLRF control system menu panel, which provides the operator with access to the main control panels of the software package,
- Facts about the accelerator operational modes panel, which provides the operator with access to the control and monitor panels associated with the normal operation of the accelerator,
- Information on the control system setup modes panel, which allows the user access to the sets of subsystem setup panels,
- Data about the hierarchy panel, which provides the user with a hierarchical view of the control panels,
- How the various exit options will affect the control system,
- And finally, some information about the pop-up windows that will appear at different times during the operating session.

1.3 Software Background

The LLRF module set has been designed with the idea of complete computer control and automation in mind. Accordingly, an embedded processor module has been incorporated into the system to provide this control. The embedded processor module used in the LLRF control rack is a VXIbus-based version of the Apple® SE-30 computer, and is manufactured by National Instruments Corporation. This module comes complete with a keyboard and terminal (viewscreen) for user-interface, and serial and parallel data ports allowing the implementation of additional peripheral devices. In short, it is a complete computer on a VXIbus module.

All software necessary for complete and accurate control of the LLRF equipment has been installed by LANL AT-5 personnel. The control software provided by AT-5 is based on LabVIEW® 2.2, a high-level graphical programming environment used to define and create sets of viewscreen control panels. Each set of panels controls one of the LLRF subsystems, and all control panels relevant to a given subsystem are summarized in the chapter dedicated to that subsystem.

This section contains some general background on the control system software as a whole. This includes things such as: the logical addresses of each individual VXIbus module in the system, and the file/folder hierarchy of the control system program and files.

1.3.1 VXIbus Backplane Logical Addresses

In the LLRF control system developed for the University of Twente, each of the internal VXIbus modules has been assigned a logical address. These are illustrated in table 1-1.

There are several empty slots in chassis 2. If additional modules are installed in these, their logical addresses must be within the window established by the MXI master module (also located in chassis 2). Specifically, this range is defined to be 1 through 14. Each device in this space is required to have a unique logical address, so a maximum of 14 additional devices may be incorporated into chassis 2.

Table 1-1. AT-5 LLRF module logical addresses.

Module address	Module name	Module address	Module name
41	Adaptive Feedforward Module	37	Q Controller Module
34	Downconverter Module	43	Timing Distribution Module
40	Envelope Detector Module	42	Timing Receiver Module
00	Embedded Processor Module	39	Upconverter Module
36	I Controller Module	35	Vector Detector Module
33	Coax Monitor Transmitter Module	38	Vector Modulator Module
32	MXI Module (chassis 1)	15	MXI Module (chassis 2)

1.3.2 File Hierarchy

Figure 1-1 illustrates the folder and file divisions of the control software installed on the embedded processor module by LANL AT-5 personnel. Note that the LLRF control system software makes up only a portion of the files stored on the embedded processor module. This hierarchy tree covers only those files used by the LabVIEW® control software package, i.e. the files contained in the system states folder and the LLRF control system folder.

The system states folder contains the data files specific to each LLRF system state, the global hardware data files, and the configuration data files. The file and folder names appearing in the diagram are the specific file names accessed by the LabVIEW® software. The operator may specify alternate filenames when saving system-state data. If this is done, the software will not load the alternate files automatically, but can access them if specifically instructed to do so.

The LLRF control system folder contains the LLRF control system executable application, the sub-VIs (virtual instruments) called by the application, and the executable resource manager files. When selected, the executable LLRF control system application runs the accelerator control software. Because the 'init resource manager' initializes the VXIbus hardware, it is executed immediately upon system power-on. It provides the resource manager functionality (as defined by the VXIbus specification) for the control system, while suppressing its output to the viewscreen. The software operates by calling a series of VIs, which are executable graphical subroutines. The 'resource manager' operates in the same manner as the 'init resource manager,' except that its output is displayed on the panel. For this reason, the 'resource manager' is unused unless it is specifically activated by the operator.

Figure 1-1. Software file hierarchy.

1.3.3 Control Panel Hierarchy

Figure 1-2 illustrates the control panel hierarchy of the LLRF software package. The upper-level panels are at the left of the diagram, and the lower-level panels are at the right. When the software is run, the first panel presented to the user is the password panel. From there, the user may proceed as far down the structure as is deemed necessary. Note that the structure may be fully traversed in both directions, preventing isolation from being a problem.

The password panel and the hierarchy panel are not connected to any of the other panels in the diagram. This is because they reside outside of the normal panel hierarchy. The hierarchy panel can be accessed by any panel in the top two levels, and the password panel can be accessed from the LLRF control system menu panel.

Figure 1-2. LLRF control panel hierarchy.

Several of the panels are inactive and/or undefined at the present time: accelerator diagnostic modes, control system test modes, phase scan, beam loading measurement, cavity Q measurement, resonance control test, and resource manager. In the figure, these are distinguished from the active panels by dark shading. The inactive panels can be accessed but will not perform any control functions.

1.4 Running the LLRF Control Software

At power-on or when rebooted, the embedded processor module automatically loads and runs the LLRF control software package. This process takes several minutes. The software will present a LabVIEW® copyright notice for a short while, then continue with its loading procedure. Finally, when the software has been completely loaded, the password panel (section 1.8.1) is presented to the user.

1.5 Shutting Down the LLRF Control Software

The embedded processor should never be turned off when not shut down, especially if in the middle of running a program (such as the LLRF control software). If shut off without being shut down, the disk drive may be damaged physically. Additionally, if the processor is shut off in the middle of running a program, damage to the data structure of the files in use could occur, perhaps making them unreadable and unrecoverable.

Because the processor must be shut down every time it is turned off, the shutdown procedure has been made very simple. In order to end a session with the control software, one must do the following:

- First, the control panel structure must be traversed until the LLRF control system menu is the active panel.
- Next, the shutdown button must be pressed. Pop-up windows may appear with warning messages, asking permission to continue the shutdown procedure and offering the user the opportunity to make some adjustments before the current states have been erased.
- Finally, a message will be displayed when the embedded processor module has been completely shut down.

1.6 Operating the Mouse

This section has been included for those who are not familiar with the standard terminology and control methods of the Apple® mouse-driven user-interface. Before describing each of the individual control types used by the LLRF control software, the general control procedures need to be covered. Contained herein are the definitions of several terms that may be confusing to the novice operator, and should be read over before proceeding on to the following sections.

The mouse is the main user input device for the embedded processor module, and is used to operate all types of controls existing on the various control panels. On the screen, there is a small mouse-pointer in the shape of a hand with a pointing finger. The mouse-pointer moves about the screen in concert with the movement of the mouse on its mouse pad, and is used to point to items on the panel.

- To 'point' to something on a control panel move the mouse until the mouse pointer is on top of the desired item.

When pointed to, an item may be selected or activated. This is done by clicking on the item with the mouse button.

- To 'click' an item on a control panel: point to the item with the mouse pointer, then quickly press and release the mouse button.
- To 'double-click' an item on a control panel: point to the item with the mouse pointer, then quickly press and release the mouse button twice in rapid succession.

Certain items may be moved to different locations on the screen. When this is done, it is called dragging.

- To 'drag' an item: point to the item with the mouse pointer, then hold down the mouse button while moving the mouse (and the item) until the item is at its new location.

1.7 Operating the Controls

There are several different types of controls used on the control panels: buttons, alterable data fields, switches, selectable data fields, and dials. Each of these is operated in some part with the mouse, but in some cases use of the keyboard is also required, or at least advised. Many of the control panels contain at least one of every type of control, but some contain only one type. Additionally, there are often data fields present on a panel. These are read-only fields; they are read by the user, but can not be altered. On a control panel, any type of field that is not described in the following subsections is a data field.

1.7.1 Buttons

Because the buttons are used to traverse the panel structure, every control panel contains at least one button. The buttons have been given a slight three-dimensional appearance, and contain some words describing the function performed when the button is pressed. An example button is pictured in figure 1-3.

Figure 1-3. Button.

In order to press a control panel button, the following must be done:

- Point to the button in question.
- Click on the button. The button will appear to depress for a moment, then the action(s) dictated by the button will be taken.

1.7.2 Alterable Data Fields

Most of the control panels contain alterable data fields in which data is read and written numerically. In addition to a numerical display of its value, each alterable data field contains up and down arrows that will increment and decrement the value in the field by its finest resolution. To the left of the field a word or two describes the meaning of the value within the field, while to the right of the field scaled units qualify the numerical value. The units change automatically to keep the value in a standard notational form. An example of an alterable data field is shown in figure 1-4 below.

Figure 1-4. Alterable data field.

In order to change the value in one of the alterable data fields, either of the following procedures must be performed:

- Point to the numerical field in question.
- Double-click on the data field, and it will change color.
- Use the keyboard to type in the new value of the data field. The new value will replace the old one completely.

or:

- Point to the up arrow for an increase, or the down arrow for a decrease.
- Click the chosen arrow repeatedly to cause incremental increases/decreases to the value shown in the display. Continue to do so until the desired value appears therein.

1.7.3 Switches

Many of the control panels contain switches which allow the operator to select between two possible states. The switches can be oriented horizontally or vertically, and contain a word at each switch position to describe what state the system will be in if the switch is in that position. Examples of the types of switches used on the control panels are shown in figure 1-5 below.

Figure 1-5. Switches.

In order to change the setting of a switch on one of the control panels the operator must do the following:

- Point to the switch in question.
- Click on the switch. The switch will move to indicate its new state, the opposite of that at which it was originally located.

1.7.4 Selectable Data Fields

Some of the control panels contain selectable data fields which are used for things such as signal selection. Beneath the data display are left and right arrows which allow the operator to alter the value in the display. Also, pop-up menus can be used to change the data. At the left of the display, a word or two is included to indicate what the selection will affect. An example of a selectable data field can be seen in figure 1-6 below.

Figure 1-6. Selectable data field.

In order to alter a selectable data field, either of the following procedures must be performed:

- Point to the data field display.
- Press and hold the mouse button. A pop-up menu with a complete list of possibilities for that field.
- Keeping the mouse button held down, point to the desired selection.
- Release the mouse button and the menu will disappear, leaving the new selection displayed in the data field.

or:

- Point to the left or right arrow of the data field.
- Click on the chosen arrow and the data field will display a new selection. Click repeatedly until the desired value appears in the data field.

1.7.5 Scroll Bars

In some instances, there is not enough space on the viewscreen to look at the entire set of information provided by a panel or menu. In these cases, the window may be scrolled up or down, left or right to display more of the available information. This is done with scroll bars, pictured in figure 1-7.

Figure 1-8. Scroll Bars.

In order to change the view displayed by a window, one of the following procedures must be performed:

- Point to the arrow corresponding to the direction the window should be moved.
- Click on the arrow until the window displays the correct view.

or:

- Point to the window position box (somewhere on the scroll bar).
- Drag the box along the scroll bar to the appropriate position.

1.8 System-Level Control Panels

This section describes those control panels that are unrelated to any of the individual control subsystems. In general, they are organizational panels that allow the user to perform those tasks which are necessary, but which do not affect accelerator operation directly. This includes things such as entering and exiting the control software, performing administrative tasks, and accessing the control panels that do directly affect

the control system. The panels include the: password panel, hierarchy panel, LLRF control system menu panel, accelerator operational modes panel, control system setup modes panel, exit panel, and general pop-up panels. Each of these is discussed in a subsection below.

1.8.1 Disclaimer Panel

Upon entering the software environment, the user is presented with a Disclaimer Panel, as shown in figure 1-9. Read the copyright notice, the disclaimer, and the restrictions that apply to the dissemination of the software. When you have done this, press the CONTINUE button.

Figure 1-9. Disclaimer panel.

1.8.2 Hierarchy Panel

The hierarchy panel, shown in figure 1-10, presents the user with a hierarchical representation of the control panels in the software package. The panel can be used to see exactly where in the software a given panel resides, allowing the user to find the correct path to that panel.

Figure 1-10. Hierarchy panel.

When pushed, the OK button returns the user to the panel from which this panel was called. This is the only active control.

1.8.3 LLRF Control System Menu Panel

The LLRF control system menu panel, pictured in figure 1-11 below, is the overall menu of the software package. It provides the user with access to several other control panel menus, and provides a shutdown option which allows the user to exit the software.

Figure 1-11. LLRF control system menu panel.

To call up a given sub-menu, simply press the button containing the name of the desired sub-menu. The panels that can be called up are the accelerator operational modes panel, and control system setup modes panel. The shutdown button is also active, but does not call up a panel (excepting the possibility of a pop-up menu, see section 1.8.7). The shutdown button simply exits the control software package as described in section 1.5.

Additionally, there is one small button in the bottom-left corner of the panel: the hierarchy button. This button brings up the hierarchy panel.

1.8.4 Accelerator Operational Modes Panel

The accelerator operational modes panel, pictured in figure 1-12, is called up from the LLRF control system menu panel. This panel allows the user to select a mode of operation from which to observe and adjust the control system. Specifically, it allows the user to enter either the normal operations panel, or the cavity conditioning panel.

Figure 1-12. Accelerator operational modes panel.

Selecting the normal operations button brings up the normal operations panel, providing the user with access to the controls and monitors of the accelerator control system. The normal operations panel is discussed in section 2.2.

If the cavity conditioning button is pressed, then the software brings up the cavity conditioning panel, described in section 2.3. This provides the user with the functions necessary to perform the conditioning process on the cavity.

If the exit button is pressed then the user is returned to the LLRF control system menu panel. From there, the user may enter the setup mode or shut down the software.

Additionally, there is one small button in the bottom-left corner of the panel: the hierarchy button. This button brings up the hierarchy panel.

1.8.5 Control System Setup Modes Panel

The control system setup modes panel, pictured in figure 1-13, is brought up by the LLRF control system menu panel. The panel is presented as an extremely simplified block diagram of the control system, with each block representing one of the setup panels. Thus, the user is allowed to select from a variety of setup panels in which all setup functions may be performed.

Figure 1-13. Control system setup modes panel.

To call up a given setup panel, simply press the button that contains the name of the desired panel. Note that several of the buttons are shaded darkly. These buttons are inactive in the software, so pushing them will have no effect: RF reference, HPRF amplifier, and RF cavity. The panels that can be called up are: field control, diagnostic monitor, timing, alarms and limits, and resonance detection. The exit button returns the user to the LLRF control system menu panel.

Additionally, there is one small button in the bottom-left corner of the panel: the hierarchy button. This button brings up the hierarchy panel.

1.8.6 Exit Panel

The exit panel, seen in figure 1-14, is called up when the exit button is pressed on the normal operations panel, the cavity conditioning panel, or any of the system setup panels. It offers the user several exit options: saving the system state before exiting, loading a new system state, canceling the exit, and exiting the setup without saving the new system state.

Figure 1-14. Exit panel.

The 'save system state' button saves the current state of the system in a file, so that it can be accessed by the operator at a later date. The system state can be saved under most any name that the operator wishes to give it. However, only the default state is loaded into the software upon start-up, so if the file is to be the default file it should be given the default file name.

The 'load system state' button causes the processor to load data from any file specified by the operator. If this is done before saving newly generated data to a file, the software will prompt the user with a cautionary pop-up menu. (See section 1.8.7 below.)

The 'return - cancel exit' button will cancel the exit procedure, and return the operator to the panel from which the exit panel was called.

The exit button will cause the software to exit the current section, returning the operator to the control system setup modes panel or the accelerator operation modes panel. If this is done before saving the data to a file, the software will prompt the user with a cautionary pop-up menu. (See section 1.8.7 below.)

1.8.7 Pop-Up Windows

Under many different sets of circumstances, a pop-up window may appear (an example of which is seen in figure 1-15). The window may contain different messages at different times, depending upon the specific circumstances of its appearance. In general, it offers the user the opportunity of either continuing

with, or canceling, the current operation. Whichever is chosen, the software continues as instructed.

Figure 1-15. Pop-up menu panel.

This page has been left blank intentionally.

2. LLRF OPERATIONAL MODES

2.1 Chapter Overview

This chapter describes the LabVIEW® control panels used during the normal operations of the accelerator cavity: the normal operations panel and the cavity conditioning panel. Both of these panels are in the control hierarchy underneath accelerator operational modes. The panels contain sets of controls that can be used to operate and monitor the control system as a whole, without specifically altering any of the subsystems. (Although, as the various controls are altered, the corresponding items are altered in the relevant subsystems.) Illustrations of the panels are provided along with information on how they operate, and what function each control provides.

The panels discussed in this chapter are as follows:

- The normal operations panel provides the operator with the control and monitor points for the functions used during the normal operation of the accelerator.
- The cavity conditioning panel provides the operator with the control and monitor points allowing control over the accelerator cavity conditioning process.

2.2 Normal Operations Panel

The normal operations panel is illustrated in figure 2-1. The panel allows contains the controls used in governing the normal operations of the accelerator. Much of the operation is automated, running in the background transparent to the user.

The normal operations panel is entered from the accelerator operational modes panel. Upon entering the normal operations panel, several configuration files are loaded into the control software. First, the resonance control, field control, diagnostic monitor, timing, and alarm & limit configuration files are loaded. They provide the hardware configuration data which is needed to define the normal mode of operation. Next, the global files for the reflectometer calibration, gain schedule, and diagnostic signal list are also loaded. This is done to provide the hardware-specific setup data common to all modes of operation. Finally, the operator is asked if the default file for the normal mode of operation is to be used. If it is not, the user is asked to provide the name of the file that will be used. The data in this file is displayed on, and is adjustable from, the normal operations panel.

The remainder of this section is dedicated to describing the control and monitor points on the normal operations panel. Generally, the control descriptions are listed as the controls appear on the panel, from the upper-left to the lower-right. Where the controls are grouped, each control in the group is discussed before proceeding on to the next group.

Figure 2-1. Normal operations panel.

LLRF ENABLE/DISABLE: This switch allows the operator to enable and disable the LLRF output. When in the disabled position, the LLRF output will not be allowed to leave the LLRF control rack. When in the enabled position, the LLRF control system will provide the LLRF output signal to the HPRF control rack if all other conditions are satisfied (i.e. the fast-protection signal has not been triggered, the RF gate timing pulse is active, etc.). When enabled, the RF gate enable bit is set high on the *Upconverter Module*, and when disabled this bit is cleared low. In other words, the switch reflects and controls the status of the RF gate enable bit. Note that when an alarm occurs, the switch will be moved to the 'disable' state automatically by the software.

LLRF OFF: When this button is pressed, the LLRF output is tied to ground, effectively disabling the output to the HPRF control rack. As with the LLRF disable switch, this button clears the RF gate enable bit on the *Upconverter Module*, forcing it low to prevent any output signal.

WARNING: This is a yellow status display light which provides the warning status for the system. When lit, one or more warnings have been activated. When not lit, no warnings are active in the system. The various warnings are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

ALARM: This is a red status display light which provides the alarm status for the system. When lit, one or more alarms have been activated. When not lit, no alarms are active in the system. The various alarms are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

CAVITY AMPLITUDE SETPOINT: The cavity amplitude setpoint control provides the method of adjusting the magnitude of the cavity RF field. The control system uses a PID-based feedback algorithm to maintain the amplitude of the cavity RF field at the value of the cavity amplitude setpoint. The value residing in this field is scaled to reflect the actual cavity field voltage.

Since the control system performs its operations on the in-phase and quadrature components of the system signals, the setpoints must also be divided into in-phase and quadrature components ($SETPOINT_{ICM}$ and $SETPOINT_{QCM}$). To do this the following equations are used:

$$SETPOINT_{ICM} = \frac{ASP}{ASPSF} \cos(PSP)$$

$$SETPOINT_{QCM} = \frac{ASP}{ASPSF} \sin(PSP)$$

Where ASP is the cavity amplitude setpoint, ASPSF is the cavity amplitude setpoint scale factor, and PSP is the cavity phase setpoint.

In the gain-scheduling algorithm, the ASP provides the key parameter from which all other data parameters are derived. Because of this, the interpolation algorithms must re-evaluate the other parameters each time the ASP is altered. This is explained further in section 4.4, covering the creation of the gain schedule table.

CAVITY AMPLITUDE READBACK: The cavity amplitude readback display contains the amplitude of the cavity RF field as detected by the control system. The value in this field is scaled to reflect the actual cavity field voltage, and appears in a box to the left of a vertical bar graph.

The bar graph displays the relative values of the current field amplitude, the minimum warning level, and the minimum alarm level. The graph also contains their numerical values: The red-to-yellow (upper) transition point is labelled with the value of the alarm limit in the alarm & limit configuration file. The yellow-to-green (lower) transition point is labelled with the value of the warning limit in the alarm & limit configuration file.

To determine the value of the cavity amplitude readback (ARB) the software uses the following equation:

$$ARB = \sqrt{(FLDI \cdot SFT)^2 + (FLDQ \cdot SFQ)^2}$$

Where FLD I is the in-phase component of the RF field, FLD Q is the quadrature component of the RF field, SFI is the scale factor of the in-phase component of the RF field, and SFQ is the scale factor of the quadrature component of the RF field.

CAVITY PHASE SETPOINT: The phase setpoint control provides a method for adjusting the phase of the cavity RF field. The control system uses a PID-based feedback algorithm to maintain the cavity phase at its setpoint value.

Since the control system performs its operations on the in-phase and quadrature components of the system signals, the setpoints must also be divided into in-phase and quadrature components ($SETPOINT_{ICM}$ and $SETPOINT_{QCM}$). To do this the following equations are used:

$$SETPOINT_{ICM} = \frac{ASP}{ASPSF} \cos(PSP)$$

$$SETPOINT_{QCM} = \frac{ASP}{ASPSF} \sin(PSP)$$

Where ASP is the cavity amplitude setpoint, ASPSF is the cavity amplitude setpoint scale factor, and PSP is the cavity phase setpoint.

CAVITY PHASE READBACK: The readback display of the cavity phase contains the phase (in degrees) of the cavity RF field. It appears as a vector in a circle, giving an approximate visual representation of the phase. The $0^\circ/360^\circ$ position is along the positive x-axis, or horizontally to the right. Its numerical value (in degrees) appears beneath the circle. The value of the phase readback (PRB) is determined from the following equation:

$$PRB = \tan^{-1}\left(\frac{FLDQ}{FLDI}\right)$$

Where FLD I is the in-phase component of the RF field, and FLD Q is the quadrature component of the RF field.

RF TIMING DELAY: The RF timing delay is used to adjust the time-position of the cavity RF field in the RF cycle. Since the precursory trigger (T0) indicates the beginning of an RF cycle, the RF timing delay is defined as the length of time between the leading edge of T0 and the leading edge of the RF gate. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. Thus the number of clock cycles in the delay period is determined as follows:

$$delay_{cycles} = \frac{RFGD}{200ns}$$

Where RFGD is the RF gate delay.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The delays of all other timing pulses are derived from the RF gate delay. Consequently, as the RFGD is adjusted, all other timing signals track the change. This is explained further in section 6.4, which is about the timing setup.

RF TIMING WIDTH: The RF timing width is used to adjust the length of time that the RF field exists in the cavity. This is done by altering the width of the RF gate pulse, which is displayed as the RF timing width. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. The number of clock cycles that pass while the RF gate is active is determined as follows:

$$width_{cycles} = \frac{RFGW}{200ns}$$

Where RFGW is the RF gate width.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The widths of all dependent-type timing pulses are derived from the width of the RF gate. Consequently, as RFGW is adjusted, all dependent pulses track the change. This is explained further in section 6.4, which is about the timing setup.

FORWARD DRIVE POWER: The forward drive power status display contains the value of the voltage magnitude at which the cavity is currently being driven. The value is taken from a readback of the klystron amplifier output. It is displayed numerically, and is scaled to reflect the actual voltage level of the forward power signal.

The forward drive power (FWDP) is determined from the following equation:

$$FWDP = (REFLA)^2 \cdot RASF$$

Where REFL A is the reflectometer 'a' signal, and RASF is the reflectometer 'a' scale factor.

REVERSE DRIVE POWER: The reverse drive power status display contains the value of the voltage magnitude at which drive power is being reflected from the cavity. It is displayed numerically, and is scaled to reflect the actual voltage level of the reflected power signal.

The reverse drive power (RVSP) is determined from the following equation:

$$RVSP = (REFLB)^2 \cdot RBSF$$

Where REFL B is the reflectometer 'b' signal, and RBSF is the reflectometer 'b' scale factor.

ADAPTIVE FEEDFORWARD ON/OFF: The adaptive feedforward on/off switch determines whether or not the adaptive feedforward functionality is currently active. When in the off position, the current feedforward data is maintained and used until it is cleared with the reset button or additional adaption is enabled by turning the switch on. When this switch is in the on position, the enable FFWD I and enable FFWD Q bits are set high on the *Adaptive Feedforward Module*. This causes the module to continue (or begin) gathering data for use in its adaptive feedforward algorithm. When the switch is in the off position, both bits are cleared to low.

ADAPTIVE FEEDFORWARD RESET: When the adaptive feedforward reset button is pressed, the adaptive feedforward data is cleared. The software executed by this button sets both the reset I data and reset Q data bits high on the *Adaptive Feedforward Module*.

DIAGNOSTIC MONITOR CH 1: The diagnostic monitor channel 1 control allows the selection of which diagnostic signal is to drive channel one of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 1, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

DIAGNOSTIC MONITOR CH 2: The diagnostic monitor channel 2 control allows the selection of which diagnostic signal is to drive channel two of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 2, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

REFLECTION COEFFICIENT: The reflection coefficient data is displayed on a Smith chart. The chart illustrates the complex reflection coefficient points plotted in polar coordinates, with the standard Smith chart admittance curves superimposed upon it. An ongoing history of 25 points is displayed on the panel as the system continuously updates the reflection coefficient measurement.

The normalized load admittance for the RF cavity can be observed directly from this plot. A vector error correction algorithm is used to calculate the complex reflection coefficient from the *Envelope Detector Module* registers: REFL A, REFL B, REFL A + B, and REFL A + jB.

REFRESH CHART: When the refresh chart button is pressed, the Smith chart is cleared of all previous data points. This is useful in preventing the chart from becoming cluttered with outdated data.

EXIT: When the exit button is pressed, the normal operations panel is closed and replaced with the accelerator operational modes panel. The operator is prompted to choose one of the following exit functions: save, load, return, or exit. (See section 1.8.6.) Note that when the operator leaves this panel, the current machine state remains active until another mode of operations is entered or the shutdown function is selected.

2.3 Cavity Conditioning Panel

The cavity conditioning panel, illustrated in figure 2-2, provides the operator with control over the accelerator cavity conditioning process. Many of the conditioning operations are automated and run in the background, transparent to the user.

The cavity conditioning panel is entered from the accelerator operational modes panel. Upon entering the cavity conditioning panel, several configuration files are automatically loaded into the control software. First, the resonance detection, field control, diagnostic monitor, timing, and alarm & limit configuration files are loaded. They provide the hardware configuration data which is needed to define the normal mode of operation. Next, the global files for the reflectometer calibration, gain schedule, and diagnostic signal list are also loaded. This is done to provide the hardware-specific setup data common to all modes of operation. Finally, the operator is asked if the default file for cavity conditioning is to be used. If it is not, the user is asked to provide the name of the file that will be used. The data in this file is displayed on, and is adjustable from, the cavity conditioning panel.

Figure 2-2. Cavity conditioning panel.

The remainder of this section is dedicated to describing the control and monitor points on the cavity conditioning panel. Generally, the control descriptions are listed as the controls appear on the panel, from the upper-left to the lower-right. Where the controls are grouped, each control in the group is discussed before proceeding on to the next group.

LLRF ENABLE/DISABLE: This switch allows the operator to enable and disable the LLRF output. When in the disabled position, the LLRF output will not be allowed to leave the LLRF control rack. When in the enabled position, the LLRF control system will provide the LLRF output signal to the HPRF control rack if all other conditions are satisfied (i.e. the fast-protection signal has not been triggered, the RF gate timing pulse is active, etc.). When enabled, the RF gate enable bit is set high on the *Upconverter Module*, and when disabled this bit is cleared low. In other words, the switch reflects and controls the status of the RF gate enable bit.

LLRF OFF: When this button is pressed, the LLRF output is tied to ground, effectively disabling the output to the HPRF control rack. As with the LLRF disable switch, this button clears the RF gate enable bit on the *Upconverter Module*, forcing it low to prevent any output signal.

WARNING: This is a yellow status display light which provides the warning status for the system. When lit, one or more warnings have been activated. When not lit, no warnings are active in the system. The various warnings are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

ALARM: This is a red status display light which provides the alarm status for the system. When lit, one or more alarms have been activated. When not lit, no alarms are active in the system. The various alarms are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

CAVITY DRIVE ADJUSTMENT: The cavity drive adjustment control provides a direct adjustment to the drive level of the RF cavity. The value is scaled to reflect the actual voltage of the cavity drive signal. The cavity drive adjustment is used to determine the value of the open-loop drive on the *I and Q Controller Modules* ($OLDRV_{ICM}$ and $OLDRV_{QCM}$), as seen in the following equations:

$$OLDRV_{ICM} = \frac{CDA}{CDSF} \sin(CDP)$$

$$OLDRV_{QCM} = \frac{CDA}{CDSF} \sin(CDP)$$

Where CDA is the cavity drive adjustment, CDSF is the cavity drive scale factor, and CDP is the cavity drive phase.

There is no gain-scheduling required for cavity conditioning. The remaining field control parameters should remain unchanged from their original values (as taken from the field control configuration file).

CAVITY AMPLITUDE READBACK: The cavity amplitude readback display contains the amplitude of the cavity RF field as detected by the control system. The value in this field is scaled to reflect the actual cavity field voltage, and appears in a box to the left of a vertical bar graph.

The bar graph displays the relative values of the current field amplitude, the minimum warning level, and the minimum alarm level. The graph also contains their numerical values: The red-to-yellow (upper) transition point is labelled with the value of the alarm limit in the alarm & limit configura-

tion file. The yellow-to-green (lower) transition point is labelled with the value of the warning limit in the alarm & limit configuration file.

To determine the value of the cavity amplitude readback (ARB) the software uses the following equation:

$$ARB = \sqrt{(FLDI \cdot SFI)^2 + (FLDQ \cdot SFQ)^2}$$

Where FLD I is the in-phase component of the RF field, FLD Q is the quadrature component of the RF field, SFI is the scale factor of the in-phase component of the RF field, and SFQ is the scale factor of the quadrature component of the RF field.

RF TIMING DELAY: The RF timing delay is used to adjust the time-position of the cavity RF field in the RF cycle. Since the precursory trigger (T0) indicates the beginning of an RF cycle, the RF timing delay is defined as the length of time between the leading edge of T0 and the leading edge of the RF gate. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. Thus the number of clock cycles in the delay period is determined as follows:

$$delaycycles = \frac{RFGD}{200ns}$$

Where RFGD is the RF gate delay.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The delays of all other timing pulses are derived from the RF gate delay. Consequently, as the RFGD is adjusted, all other timing signals track the change. This is explained further in section 6.4, which is about the timing setup.

RF TIMING WIDTH: The RF timing width is used to adjust the length of time that the RF field exists in the cavity. This is done by altering the width of the RF gate pulse, which is displayed as the RF timing width. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. The number of clock cycles that pass while the RF gate is active is determined as follows:

$$widthcycles = \frac{RFGW}{200ns}$$

Where RFGW is the RF gate width.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The widths of all dependent-type timing pulses are derived from the width of the RF gate. Consequently, as RFGW is adjusted, all dependent pulses track the change. This is explained further in section 6.4, which is about the timing setup.

FORWARD DRIVE POWER: The forward drive power status display contains the value of the voltage magnitude at which the cavity is currently being driven. The value is taken from a readback of the klystron amplifier output. It is displayed numerically, and is scaled to reflect the actual voltage level of the forward power signal.

The forward drive power (FWDP) is determined from the following equation:

$$FWDP = (REFLA)^2 \cdot RASF$$

Where REFL A is the reflectometer 'a' signal, and RASF is the reflectometer 'a' scale factor.

REVERSE DRIVE POWER: The reverse drive power status display contains the value of the voltage magnitude at which drive power is being reflected from the cavity. It is displayed numerically, and is scaled to reflect the actual voltage level of the reflected power signal.

The reverse drive power (RVSP) is determined from the following equation:

$$RVSP = (REFLB)^2 \cdot RBSF$$

Where REFL B is the reflectometer 'b' signal, and RBSF is the reflectometer 'b' scale factor.

DIAGNOSTIC MONITOR CH 1: The diagnostic monitor channel 1 control allows the selection of which diagnostic signal is to drive channel one of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 1, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

DIAGNOSTIC MONITOR CH 2: The diagnostic monitor channel 2 control allows the selection of which diagnostic signal is to drive channel two of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 2, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

REFLECTION COEFFICIENT: The reflection coefficient data is displayed on a Smith chart. The chart illustrates the complex reflection coefficient points plotted in polar coordinates, with the standard Smith chart admittance curves superimposed upon it. An ongoing history of 25 points is displayed on the panel as the system continuously updates the reflection coefficient measurement.

The normalized load admittance for the RF cavity can be observed directly from this plot. A vector error correction algorithm is used to calculate the complex reflection coefficient from the *Envelope Detector Module* registers: REFL A, REFL B, REFL A + B, and REFL A + jB.

REFRESH CHART: When the refresh chart button is pressed, the Smith chart is cleared of all previous data points. This is useful in preventing the chart from becoming cluttered with outdated data.

EXIT: When the exit button is pressed, the cavity conditioning panel is closed and replaced with the accelerator operational modes panel. The operator is prompted to choose one of the following exit functions: save, load, return, or exit. (See section 1.8.6.) Note that when the operator leaves this panel, the current machine state remains active until another mode of operations is entered or the shutdown function is selected.

2.4 Status Panel

The status panel, illustrated in figure 2-2, provides the operator with the ability to access each of the individual subsystem status panels. The individual status panels contain no operational controls, instead, they supply a summary of the information being generated or used by the corresponding subsystem. Control over a given subsystem is provided via the setup panel for that subsystem.

The panel is presented as an extremely simplified block diagram of the control system, with each block presenting access to one of the status panels. To call up a given status panel, simply press the button that contains the name of the desired panel. Note that several of the buttons are shaded darkly. These buttons are inactive in the software, and will perform no functions: RF reference, HPRF amplifier, and RF cavity. The status panels that can be called up are: field control, diagnostic monitor, timing, alarms & limits, and resonance detection.

3. RESONANCE DETECTION

3.1 Chapter Overview

This chapter describes the LabVIEW® control panels used to detect the resonance condition of the RF cavity, and calibrate the reflectometer assembly. These panels are in the control hierarchy under the control system setup modes panel. Illustrations of the panels are provided along with information on how they operate, and what function each control provides.

The cavity resonance detection subsystem monitors the resonant frequency of the RF cavity. The RF cavity must remain close to its designated resonance so that the proper RF field may be generated, and so that proper feedback regulation of the cavity field is possible. If the cavity is driven far from resonance: it may not accept RF power, a parasitic mode may be excited, or the feedback loop margins might be exceeded.

The panels discussed in this chapter are as follows:

- The resonance detection status panel provides the complete set of status information on the resonance detection subsystem.
- The resonance detection setup panel provides control and monitor points which allow the resonance detection subsystem to be set up for operation.
- The calibrate reflectometer panel provides the control and monitor points used to help guide the automated reflectometer calibration process.
- The calibration standards panel provides direct access to the data in the calibration standards table.

3.2 Resonance Detection Status Panel

The resonance detection status panel contains a complete set of status information on the resonance detection subsystem. (See figure 3-1.) The panel is accessed from the status panel, and appears in its place at the top of the screen. The display shows the current status of all data channels in the subsystem. Specifically, the panel provides the following:

SMITH CHART: The reflection coefficient data is displayed on a Smith chart. The chart illustrates the complex reflection coefficient points plotted in polar coordinates, with the standard Smith chart admittance curves superimposed upon it. An ongoing history of 25 points is displayed on the panel as the system continuously updates the reflection coefficient measurement.

The normalized load admittance for the RF cavity can be observed directly from this plot. A vector error correction algorithm is used to calculate the complex reflection coefficient from the *Envelope Detector Module* registers: REFL A, REFL B, REFL A+B, and REFL A+jB.

REFLECTOMETER DATA B: This numeric display shows the value of the reflectometer 'b' data channel, as stored in the REFL B register on the *Envelope Detector Module*.

REFLECTOMETER DATA A + B: This numeric display shows the value of the reflectometer 'a + b' data channel, as stored in the REFL A + B register on the *Envelope Detector Module*.

REFLECTOMETER DATA A + jB: This numeric display shows the value of the reflectometer 'a + jb' data channel, as stored in the REFL A + jB register on the *Envelope Detector Module*.

EXIT: When the exit button is pressed, the resonance detection status panel is closed and replaced with the status panel, which is covered in section 2.4.

3.3 Resonance Detection Setup Panel

The resonance detection setup panel, illustrated in figure 3-2, provides the control and monitor points used in the setup of the cavity resonance detection subsystem. Much of the setup operations are automated and run in the background, transparent to the user.

The resonance detection setup panel is entered from the control system setup modes panel. Upon entering the panel, several configuration files are automatically loaded into the control software. First, the resonance detection, field control, diagnostic monitor, timing, and alarm & limit configuration files are loaded. They provide the hardware configuration data which is needed to define the normal mode of operation. Next, the global files for the reflectometer calibration, gain schedule, and diagnostic signal list are also loaded. This is done to provide the hardware-specific setup data common to all modes of operation. Finally, the operator is asked if the default file for the resonance detection setup mode will be used. If it is not, the user is asked to provide the name of the file that will be used. The data in this file is displayed on, and is adjustable from, the resonance detection setup panel.

The remainder of this section is dedicated to describing the control and monitor points on the resonance detection setup panel. Generally, the control descriptions are listed as the controls appear on the panel, from the upper-left to the lower-right. Where the controls are grouped, each control in the group is discussed before proceeding on to the next group.

LLRF ENABLE/DISABLE: This switch allows the operator to enable and disable the LLRF output. When in the disabled position, the LLRF output will not be allowed to leave the LLRF control rack. When in the enabled position, the LLRF control system will provide the LLRF output signal to the HPRF control rack if all other conditions are satisfied (i.e. the fast-protection signal has not been triggered, the RF gate timing pulse is active, etc.). When enabled, the RF gate enable bit is set high on the *Upconverter Module*, and when disabled this bit is cleared low. In other words, the switch reflects and controls the status of the RF gate enable bit. Note that when an alarm occurs, the switch will be moved to the 'disable' state automatically by the software.

Figure 3-2. Resonance detection setup panel.

LLRF OFF: When this button is pressed, the LLRF output is tied to ground, effectively disabling the output to the HPRF control rack. As with the LLRF disable switch, this button clears the RF gate enable bit on the *Upconverter Module*, forcing it low to prevent any output signal.

WARNING: This is a yellow status display light which provides the warning status for the system. When lit, one or more warnings have been activated. When not lit, no warnings are active in the system. The various warnings are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

ALARM: This is a red status display light which provides the alarm status for the system. When lit, one or more alarms have been activated. When not lit, no alarms are active in the system. The various alarms are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

CAVITY DRIVE ADJUSTMENT: The cavity drive adjustment control provides a direct adjustment to the drive level of the RF cavity. The value is scaled to reflect the actual voltage of the cavity drive signal. The cavity drive adjustment is used to determine the value of the open-loop drive on the *I* and *Q* *Controller Modules* (OLDRV_{ICM} and OLDRV_{QCM}), as seen in the following equations:

$$OLDRV_{ICM} = \frac{CDA}{CDSF} \sin(CDP)$$

$$OLDRV_{QCM} = \frac{CDA}{CDSF} \sin(CDP)$$

Where CDA is the cavity drive adjustment, CDSF is the cavity drive scale factor, and CDP is the cavity drive phase.

There is no gain-scheduling required for cavity conditioning. The remaining field control parameters should remain unchanged from their original values (as taken from the field control configuration file).

CAVITY AMPLITUDE READBACK: The cavity amplitude readback display contains the amplitude of the cavity RF field as detected by the control system. The value in this field is scaled to reflect the actual cavity field voltage, and appears in a box to the left of a vertical bar graph.

The bar graph displays the relative values of the current field amplitude, the minimum warning level, and the minimum alarm level. The graph also contains their numerical values: The red-to-yellow (upper) transition point is labelled with the value of the alarm limit in the alarm & limit configuration file. The yellow-to-green (lower) transition point is labelled with the value of the warning limit in the alarm & limit configuration file.

To determine the value of the cavity amplitude readback (ARB) the software uses the following equation:

$$ARB = \sqrt{(FLDI \cdot SFI)^2 + (FLDQ \cdot SFQ)^2}$$

Where FLD I is the in-phase component of the RF field, FLD Q is the quadrature component of the RF field, SFI is the scale factor of the in-phase component of the RF field, and SFQ is the scale factor of the quadrature component of the RF field.

RF TIMING DELAY: The RF timing delay is used to adjust the time-position of the cavity RF field in the RF cycle. Since the precursory trigger (T0) indicates the beginning of an RF cycle, the RF timing delay is defined as the length of time between the leading edge of T0 and the leading edge of the RF gate. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. Thus the number of clock cycles in the delay period is determined as follows:

$$delay_{cycles} = \frac{RFGD}{200ns}$$

Where RFGD is the RF gate delay.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The delays of all other timing pulses are derived from the RF gate delay. Consequently, as the RFGD is adjusted, all other timing signals track the change. This is explained further in section 6.4, which is about the timing setup.

RF TIMING WIDTH: The RF timing width is used to adjust the length of time that the RF field exists in the cavity. This is done by altering the width of the RF gate pulse, which is displayed as the RF timing width. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. The number of clock cycles that pass while the RF gate is active is determined as follows:

$$widthcycles = \frac{RFGW}{200ns}$$

Where RFGW is the RF gate width.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The widths of all dependent-type timing pulses are derived from the width of the RF gate. Consequently, as RFGW is adjusted, all dependent pulses track the change. This is explained further in section 6.4, which is about the timing setup.

FORWARD DRIVE POWER: The forward drive power status display contains the value of the voltage magnitude at which the cavity is currently being driven. The value is taken from a readback of the klystron amplifier output. It is displayed numerically, and is scaled to reflect the actual voltage level of the forward power signal.

The forward drive power (FWDP) is determined from the following equation:

$$FWDP = (REFLA)^2 \cdot RASF$$

Where REFL A is the reflectometer 'a' signal, and RASF is the reflectometer 'a' scale factor.

REVERSE DRIVE POWER: The reverse drive power status display contains the value of the voltage magnitude at which drive power is being reflected from the cavity. It is displayed numerically, and is scaled to reflect the actual voltage level of the reflected power signal.

The reverse drive power (RVSP) is determined from the following equation:

$$RVSP = (REFLB)^2 \cdot RBSF$$

Where REFL B is the reflectometer 'b' signal, and RBSF is the reflectometer 'b' scale factor.

DIAGNOSTIC MONITOR CH 1: The diagnostic monitor channel 1 control allows the selection of which diagnostic signal is to drive channel one of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all appli-

cable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 1, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

DIAGNOSTIC MONITOR CH 2: The diagnostic monitor channel 2 control allows the selection of which diagnostic signal is to drive channel two of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 2, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

CALIBRATE REFLECTOMETER: When this button is pressed, the calibrate reflectometer panel is opened and displayed on the screen. The panel contains all control and monitor fields necessary to perform the calibration procedure.

REFLECTOMETER DATA A: This numeric display shows the value of the reflectometer 'a' data channel, as stored in the REFL A register on the *Envelope Detector Module*.

REFLECTOMETER DATA B: This numeric display shows the value of the reflectometer 'b' data channel, as stored in the REFL B register on the *Envelope Detector Module*.

REFLECTOMETER DATA A + B: This numeric display shows the value of the reflectometer 'a + b' data channel, as stored in the REFL A + B register on the *Envelope Detector Module*.

REFLECTOMETER DATA A + jB: This numeric display shows the value of the reflectometer 'a + jb' data channel, as stored in the REFL A + jB register on the *Envelope Detector Module*.

ROTATION ANGLE: This control field contains the user-defined rotation angle that is used in calculating the reflection coefficient and Smith chart plot. The rotation angle is stored in the resonance detection configuration file.

REFLECTION COEFFICIENT: This numeric display contains the value of the computed complex reflection coefficient as an instantaneous reading of its current value. The coefficient is calculated with a vector error correction algorithm using the values in registers REFL A, REFL B, REFL A + B, and REFL A + jB (located on the *Envelope Detector Module*).

Additionally, the reflection coefficient data is displayed on a Smith chart. The chart illustrates the complex reflection coefficient points plotted in polar coordinates, with the standard Smith chart admittance curves superimposed upon it. An ongoing history of 25 points is displayed on the panel as the system continuously updates the reflection coefficient measurement.

The normalized load admittance for the RF cavity can be observed directly from this plot. A vector error correction algorithm is used to calculate the complex reflection coefficient from the *Envelope Detector Module* registers: REFL A, REFL B, REFL A + B, and REFL A + jB.

REFRESH CHART: When the refresh chart button is pressed, the Smith chart is cleared of all previous data points. This is useful in preventing the chart from becoming cluttered with outdated data.

EXIT: When the exit button is pressed, the resonance detection setup panel is closed and replaced with the control system setup modes panel. The operator is prompted to choose one of the following exit functions: save, load, return, or exit. (See section 1.8.6.) Note that when the operator leaves this panel, the current machine state remains active until another mode of operations is entered or the shutdown function is selected.

3.4 Calibrate Reflectometer Panel

The calibrate reflectometer panel, illustrated in figure 3-3, provides the controls necessary to perform the reflectometer assembly calibration procedure. Much of the calibration functions are automated and run in the background, transparent to the user.

The calibrate reflectometer panel is brought up with a button on the resonance detection setup panel. When the calibrate reflectometer panel is entered, the configuration and state of the resonance control setup mode remain intact. This is because the resonance control setup panel remains active in the background. However, a single change in the system state may occur: if the LLRF output is enabled when this panel is entered, it will be automatically disabled.

Note that the calibration process includes many automated functions which take a great deal of time and require operating the RF cavity. The calibration data will remain valid until alterations are made to the accelerator hardware. Therefore, once the cavity has been properly calibrated it should not be calibrated again unless hardware changes are made.

The following information provides the definitions of each control and data display on the calibrate reflectometer panel:

BEGIN CALIBRATION: When the begin calibration button is pressed, the reflectometer calibration process is initiated. A file is opened to provide a place to store the calibration data generated by the processes on this panel.

READ STANDARD: When the read standard button is pressed, the current set of data for the existing calibration standard is entered into the data table. The reflectometer calibration process must have been started (with the begin calibration button) in order to use the read standard button.

Calibrate Reflectometer Panel														
REFLECTOMETER CALIBRATION CONTROLS														
BEGIN CALIBRATION	READ STANDARD	REMEASURE STANDARD	END CALIBRATION											
RECALCULATE CONSTANTS														
<p style="text-align: center;">CALIBRATION DATA</p> <p style="text-align: center;">REFLECTOMETER DATA</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">A</td> <td style="width: 40%; text-align: center;">0.000</td> <td style="width: 30%; text-align: right;">V</td> </tr> <tr> <td>B</td> <td style="text-align: center;">0.000</td> <td style="text-align: right;">V</td> </tr> <tr> <td>A+B</td> <td style="text-align: center;">0.000</td> <td style="text-align: right;">V</td> </tr> <tr> <td>A+jB</td> <td style="text-align: center;">0.000</td> <td style="text-align: right;">V</td> </tr> </table> <p style="text-align: center;">MEASURED REFLECTION COEFFICIENT</p> <div style="border: 1px solid black; height: 20px; width: 100%;"></div> <p style="text-align: center;">STANDARD/MEASURED DIFFERENCE</p> <div style="border: 1px solid black; height: 20px; width: 100%;"></div>	A	0.000	V	B	0.000	V	A+B	0.000	V	A+jB	0.000	V	<p style="text-align: center;">CALIBRATION STATUS</p> <p style="text-align: center;">NO. OF STDS ENTERED</p> <div style="border: 1px solid black; text-align: center; width: 50px; margin: 0 auto;">0</div> <p style="text-align: center;">MINIMUM NUMBER OF STANDARDS MEASURED</p> <div style="text-align: center; margin: 10px 0;">○</div> <p style="text-align: center;">ERROR (ε) =</p> <div style="border: 1px solid black; text-align: center; width: 80px; margin: 0 auto;">0.000</div> <p style="text-align: center;">CAVITY DRIVE ADJUSTMENT</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; width: 40px; height: 20px; position: relative;"> <div style="position: absolute; top: 0; left: 0; right: 0; height: 2px;"></div> </div> <div style="margin: 0 5px;">50.00</div> <div style="font-size: 20px; margin: 0 5px;">%</div> </div> <p style="text-align: center;">LLRF ACTIVE</p> <div style="text-align: center; margin: 0 10px;">○</div>	<p style="text-align: center;">CALIBRATION STANDARDS</p> <p style="text-align: center; border: 1px solid black; padding: 2px; margin: 5px auto; width: 150px;">MODIFY STANDARDS TABLE</p> <p style="text-align: center; margin-top: 10px;">STANDARD TYPE</p> <div style="border: 1px solid black; text-align: center; padding: 2px; margin: 0 auto; width: 150px;">0 DEGREE SHORT</div> <p style="text-align: center; margin-top: 10px;">STANDARD REFLECTION COEFFICIENT</p> <div style="border: 1px solid black; height: 20px; width: 100%;"></div>
A	0.000	V												
B	0.000	V												
A+B	0.000	V												
A+jB	0.000	V												
CAVITY DRIVE ADJUSTMENT 50.00 %			EXIT											

Figure 3-3. Calibrate reflectometer panel.

The data set is collected with the following procedure: The LLRF output is enabled by setting the RF gate enable bit on the *Upconverter Module* to high. With the RF enabled, the reflectometer data channels (A, B, A + B, and A + jB) are read from the *Envelope Detector Module*, entered into the data table, and displayed upon the screen. Finally, once the data is read, the LLRF output is disabled by clearing the RF gate enable bit on the *Upconverter Module*.

During the period for which the RF gate enable bit is high, the yellow LLRF active light is lit to warn the user that the system is generating output. Each time a set of data is entered into the data table, the number of standards entered is incremented. When the number of data sets in the table surpasses a minimum number required for calculating the reflection coefficient (typically six), the minimum number of standards measured indicator changes from red to green. The reflectometer calibration process is terminated by selecting the end calibration button.

REMEASURE STANDARD: When the remeasure standard button is activated, the last set of data that was entered into the data table is deleted, and replaced with a new (remeasured) set. This provides the means to replace erroneous data. The reflectometer calibration process must have been started (with the begin calibration button) in order to use the remeasure standard button.

The data is collected as it is with the read standard button: The LLRF output is enabled by setting the RF gate enable bit on the *Upconverter Module* to high. With the RF enabled, the reflectometer data channels (A, B, A + B, and A + jB) are read from the *Envelope Detector Module*, entered into the data table, and displayed upon the screen. Finally, once the data is read, the LLRF output is disabled by clearing the RF gate enable bit on the *Upconverter Module*.

During the period for which the RF gate enable bit is high, the yellow LLRF active light is lit to inform the user that the system is generating output. The number of standards entered is not incremented because this new data replaces old data. It does not actually add to the data file.

END CALIBRATION: When the end calibration button is pressed, the reflectometer calibration process is stopped. This causes the constants used for computing the measured reflection coefficient to be calculated from the data in the table that was just created (containing the measurements for the calibration standards). These constants provide a calibrated description of the hardware which is used for all modes of operation. Consequently, the data is saved as the global reflectometer calibration file. In addition, the measurement error and reflection coefficient are generated and displayed in their respective data display fields when the button is pushed.

RECALCULATE CONSTANTS: When the recalculate constants button is pushed, the constants used for computing the reflection coefficient are recalculated. It is done using the data from a completed calibration process with a new set of weighting factors for the standards. When completed, the new set of constants is saved as the global reflectometer calibration file. In addition, the button causes the measurement error and reflection coefficient to be generated and displayed in their respective data display fields when the button is pushed.

REFLECTOMETER DATA A: This is a numeric display showing the value of the reflectometer 'a' data channel, as stored in the REFL A register on the *Envelope Detector Module*. It is entered into the currently active data table when the read standard button is pushed. The data displayed here is updated whenever the remeasure standard button is pushed.

REFLECTOMETER DATA B: This is a numeric display showing the value of the reflectometer 'b' data channel, as stored in the REFL B register on the *Envelope Detector Module*. It is entered into the currently active data table when the read standard button is pushed. The data displayed here is updated whenever the remeasure standard button is pushed.

REFLECTOMETER DATA A + B: This is a numeric display showing the value of the reflectometer 'a + b' data channel, as stored in the REFL A + B register on the *Envelope Detector Module*. It is entered into the currently active data table when the read standard button is pushed. The data displayed here is updated whenever the remeasure standard button is pushed.

REFLECTOMETER DATA $A + jB$: This is a numeric display showing the value of the reflectometer ' $a + jb$ ' data channel, as stored in the REFL $A + jB$ register on the *Envelope Detector Module*. It is entered into the currently active data table when the read standard button is pushed. The data displayed here is updated whenever the remeasure standard button is pushed.

MEASURED REFLECTION COEFFICIENT: The measured reflection coefficient display contains the value of the complex reflection coefficient that was measured by the system for the selected standard.

STANDARD/MEASURED DIFFERENCE: This is a numerical display showing the difference between two complex reflection coefficients: that defined for the selected standard, and that computed for the current values in the reflectometer registers the *Envelope Detector Module*. It provides a measure of the precision of the complex reflection coefficient calculation operating on a known standard.

NUMBER OF STANDARDS ENTERED: The number of standards entered is incremented each time a set of data is entered into the data table with the read standard button during the reflectometer calibration procedure. This allows the operator to keep track of how far along the calibration procedure is.

MINIMUM NUMBER OF STANDARDS MEASURED: This is a cautionary light that indicates whether or not the number of data sets that have been entered into the data table is less than the minimum required for an accurate calculation of the reflection coefficient. The light is red until the minimum number has been reached, at which time it turns green.

ERROR (ϵ): Once the reflectometer calibration process has been completed, the measurement error associated with the computed calibration constant is calculated and displayed in the error field. If the current calibration constants result in an error that is not zero, the weighting factors for the standards can be adjusted, then used to recalculate the calibration constants. With patience, the error can be reduced to zero. The error value is updated when either the end calibration button or the recalculate constants button is selected.

MODIFY STANDARDS TABLE: When the modify standards table button is pushed, the display used to review and modify the values in the standards table is opened.

STANDARD TYPE: The standard type control displays the type of standard, selected by the user, that is being used in the calibration procedure.

STANDARD REFLECTION COEFFICIENT: This is a numerical display containing the value of the complex reflection coefficient that is contained in the standards table for the currently active standard type. The display is updated whenever the selected standard is altered.

LLRF ACTIVE: This yellow (cautionary) light is lit whenever the low-level control system is generating its LLRF output. It has been included to make the user aware of the RF generation.

CAVITY DRIVE ADJUSTMENT: The cavity drive adjustment control provides a direct adjustment to the drive level of the RF cavity. The value is scaled to reflect the actual voltage of the cavity drive signal. The cavity drive adjustment is used to determine the value of the open-loop drive on the *I* and *Q* Controller Modules ($OLDRV_{ICM}$ and $OLDRV_{QCM}$), as seen in the following equations:

$$OLDRV_{ICM} = \frac{CDA}{CDSF} \sin(CDP)$$

$$OLDRV_{QCM} = \frac{CDA}{CDSF} \sin(CDP)$$

Where CDA is the cavity drive adjustment, CDSF is the cavity drive scale factor, and CDP is the cavity drive phase. There is no gain-scheduling required for cavity conditioning. The remaining field control parameters should remain unchanged from their original values (as taken from the field control configuration file).

EXIT: When the exit button is pressed, the calibrate reflectometer panel is closed and replaced with the resonance detection setup panel. The operator is prompted to choose one of the following exit functions: save, return, or exit. (See section 1.8.6.) The save option stores the current operational state to the hardware definition folder.

3.5 Calibration Standards Panel

The calibration standards panel, illustrated in figure 3-4, provides the user with individual adjustment functions for each of the calibration standard types. Much of this process is automated and runs in the background, transparent to the user.

Calibration Standards Panel			
REFLECTOMETER CALIBRATION STANDARDS TABLE			
CALIBRATION STANDARD TYPE	REFLECTION COEFFICIENT		WEIGHTING FACTOR
	REAL	IMAGINARY	
1. 0 Degree Short	0.656	0.760	1.000
2. 0 Degree Load	0.087	-0.002	1.000
3. 0 Degree Mismatch	0.541	0.116	1.000
4. 90 Degree Short	0.781	-0.634	1.000
5. 90 Degree Mismatch	0.057	-0.523	1.000
6. 180 Degree Short	-0.671	-0.739	1.000
7. 180 Degree Load	-0.048	0.047	1.000
8. 180 Degree Mismatch	-0.523	0.008	1.000
9. 270 Degree Short	-0.701	0.708	1.000
10. 270 Degree Mismatch	0.012	0.553	1.000

EXIT

Figure 3-4. Calibration standards panel.

The calibration standards panel is accessed through the calibrate reflectometer panel. Upon entering the calibration standards panel, the current configuration and state of the reflectometer remain intact. This is because the resonance detection setup panel remains active in the background. However, a single change in the system state may occur as the LLRF output is automatically disabled upon entering this panel.

The following information provides the definitions of each control and data display on the calibration standards:

CALIBRATION STANDARD TYPE: The calibration standard type names are inactive fields that cannot be changed without modifying the actual LabVIEW® programming. They comprise the list of calibration standards that currently exist, and will likely remain unchanged. The name boxes become darkly shaded when a standard has been measured for the corresponding standard type in the calibrate reflectometer panel.

REFLECTION COEFFICIENT (REAL & IMAGINARY): The reflection coefficient values are the complex values for each of the hardware calibration standards, as measured with a network analyzer.

WEIGHTING FACTOR: If the calibration constants result in a calibration error that is not zero, the weighting factors for the standards can be adjusted. The adjusted weighting factors are used in calculating the calibration constants.

With patience, the error can be reduced to zero. The weighting factors all default to 'one.' In addition, the small controls at the right of the panel allow the values to be scrolled through.

EXIT: When the exit button is pressed, the display of the calibration standards panel is closed. The reflectometer calibration panel then becomes the active panel. The operator is prompted to choose one of the following exit functions: save, return, or exit. (See section 1.8.6.) The save option stores the current standards table to the hardware definition folder.

4. FIELD CONTROL SUBSYSTEM

4.1 Chapter Overview

This chapter describes the LabVIEW® control panels that are used to control the phase and magnitude of the RF field in the accelerator cavity. This set of panels includes controls used to alter the adaptive feedforward settings as well as the phase and amplitude values. These panels are in the control hierarchy under the control system setup modes panel. Illustrations of the panels are provided along with information on how they operate, and what function each control provides.

The amplitude and phase of the RF field must be controlled precisely in order to confine and accelerate a charged particle beam. The cavity field control subsystem is designed to regulate the field in the RF cavity, maintaining it at user-defined amplitude and phase setpoints. To do this properly the subsystem must filter out noise and disturbances, and maintain operational stability over changes in the electrical structure of the plant. This control is provided by resolving the amplitude and phase quantities into in-phase and quadrature (I/Q) variables, and using these as control variables for the two-input/two-output control system.

The following panels are covered in this chapter:

- The field control status panel provides a complete set of status information on the field control subsystem.
- The field control setup panel contains the control and monitor points allowing the setup of the closed-loop cavity field control subsystem.
- The gain schedule identification panel aids the gain schedule identification process. This enables the automated adjustment of the field control parameters.
- The gain schedule data table panel displays the interpolation data table for the gain scheduling file specified by the user. This allows the entire set of data to be examined simultaneously.
- The adaptive feedforward panel has the control and monitor points allowing for the adjustment and control of the adaptive feedforward algorithm.

4.2 Field Control Status

The field control status panel contains a complete set of status information on the field control subsystem. (See figure 4-1.) The panel is accessed from the status panel, and appears in its place at the top of the screen. The display shows the current status of all data channels in the field control subsystem, grouped according to the modules on which the data channels are located. Specifically, the panel provides the following:

THRESH 1: The threshold 1 data display shows the data currently residing in the THLD 1 register on the *Vector Detector Module*. The three threshold registers provide the RF cavity field amplitudes at which the LLRF output changes states.

Field Control Status Panel			
VECTOR DETECTOR THRESH 1 <input type="text" value="0.00"/> V THRESH 2 <input type="text" value="0.00"/> V THRESH 3 <input type="text" value="0.00"/> V VECTOR MODULATOR FLD COS <input type="text" value="0.00"/> V FLD SIN <input type="text" value="0.00"/> V DRV COS <input type="text" value="0.00"/> V DRV SIN <input type="text" value="0.00"/> V	I CONTROLLER SCALE FCTR <input type="text" value="0.00"/> SETPOINT <input type="text" value="0.00"/> V PROP GAIN <input type="text" value="0.00"/> % INT GAIN <input type="text" value="0.00"/> % DIFF GAIN <input type="text" value="0.00"/> % DRIVE 0 <input type="text" value="0.00"/> V DRIVE 1 <input type="text" value="0.00"/> V DRIVE 2 <input type="text" value="0.00"/> V INITIAL DRIVE <input type="text" value="0.00"/> V OL DRIVE <input type="text" value="0.00"/> V LOOP <input type="text" value="CLOSED"/>	Q CONTROLLER SCALE FCTR <input type="text" value="0.00"/> SETPOINT <input type="text" value="0.00"/> V PROP GAIN <input type="text" value="0.00"/> % INT GAIN <input type="text" value="0.00"/> % DIFF GAIN <input type="text" value="0.00"/> % DRIVE 0 <input type="text" value="0.00"/> V DRIVE 1 <input type="text" value="0.00"/> V DRIVE 2 <input type="text" value="0.00"/> V INITIAL DRIVE <input type="text" value="0.00"/> V OL DRIVE <input type="text" value="0.00"/> V LOOP <input type="text" value="CLOSED"/>	ADAPTIVE FEEDFWD I FFWD GAIN <input type="text" value="0.00"/> % I ADVANCE <input type="text" value="0"/> ns I PRESET LEVEL <input type="text" value="0.00"/> V Q FFWD GAIN <input type="text" value="0.00"/> % Q ADVANCE <input type="text" value="0"/> ns Q PRESET LEVEL <input type="text" value="0.00"/> V FEEDFWD <input type="text" value="OFF"/> UPCONVERTER LLRF <input type="text" value="DISABLED"/> <input type="button" value="EXIT"/>
<div style="display: flex; justify-content: space-between;"> <div style="width: 30%;"> CAVITY AMPLITUDE SETPOINT <input type="text" value="11.0"/> MV READBACK(MV) <div style="border: 1px solid black; padding: 2px; display: inline-block;">5.00</div> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 10px;">8.52</div> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 10px;">6.36</div> </div> <div style="width: 30%;"> CAVITY PHASE SETPOINT <input type="text" value="0.00"/> <div style="text-align: center;"> </div> READBACK <input type="text" value="0.00"/> </div> <div style="width: 30%;"> DRIVE POWER FORWARD <input type="text" value="0.00"/> MW REVERSE <input type="text" value="0.00"/> MW DIAGNOSTIC MONITOR CH 1 <input type="text" value="DISABLE"/> CH 2 <input type="text" value="DISABLE"/> RESONANCE CONDITION <div style="border: 1px solid black; width: 100px; height: 20px; margin: 0 auto;"></div> </div> <div style="width: 30%;"> OPEN/CLOSED LOOP SCALE FACTOR <input type="text" value="0.000"/> DISTURBANCE OFF <input type="text" value="ON"/> <input type="button" value="IDENTIFY GAIN SCHEDULE"/> <input type="button" value="SETUP ADAPTIVE FEEDFORWARD"/> <input type="button" value="EXIT"/> </div> </div>			

Figure 4-1. Field control status panel.

THRESH 2: The threshold 2 data display shows the data currently residing in the THLD 2 register on the *Vector Detector Module*. The three threshold registers provide the RF cavity field amplitudes at which the LLRF output changes states.

THRESH 3: The threshold 3 data display shows the data currently residing in the THLD 3 register on the *Vector Detector Module*. The three threshold registers provide the RF cavity field amplitudes at which the LLRF output changes states.

FLD COS: The field cosine display contains the cosine of the field loop phase rotation angle, as contained in the field cosine register on the *Vector Modulator Module*. This rotation angle is the amount by which the field signal must be rotated to maintain phase synchronization with the RF reference signal.

FLD SIN: The field sine display contains the sine of the field loop phase rotation angle, as contained in the field sine register on the *Vector Modulator Module*. This rotation angle is the amount by which the field signal must be rotated to maintain phase synchronization with the RF reference signal.

- DRV COS:** The drive cosine display contains the cosine of the drive loop phase rotation angle, as contained in the drive cosine register on the *Vector Modulator Module*. This rotation angle is the amount by which the drive signal must be rotated to maintain phase synchronization with the RF reference signal.
- DRV SIN:** The drive sine display contains the sine of the drive loop phase rotation angle, as contained in the drive sine register on the *Vector Modulator Module*. This rotation angle is the amount by which the drive signal must be rotated to maintain phase synchronization with the RF reference signal.
- SCALE FCTR:** The two scale factor data displays contain the scale factors residing in the field control configuration file. They are used in conversions between the control outputs (CTL I and CTL Q) and the actual cavity field drive levels. When the LLRF system is operating in a closed-loop mode the scale factors displayed reflect the setpoint scale factors, and when operating in an open-loop mode the scale factors reflect the open-loop scale factors.
- SETPOINT:** The two setpoint data displays contain the values in the setpoint registers residing in the *I* and *Q Controller Modules*. The closed-loop control system maintains the cavity field at the setpoints.
- PROP GAIN:** The two proportional gain data displays contain the values in the proportional gain registers that reside in the *I* and *Q Controller Modules*. At present, these registers are calculated as a single value and, consequently, should be identical.
- INT GAIN:** The two integral gain data displays contain the values in the integral gain registers that reside in the *I* and *Q Controller Modules*. At present, these data channels are calculated as a single value and, consequently, should be identical.
- DIFF GAIN:** The two differential gain data displays contain the values in the differential gain registers that reside in the *I* and *Q Controller Modules*. At present, these data channels are calculated as a single value and, consequently, should be identical.
- DRIVE 0:** The two drive 0 displays show the values in the drive 0 registers, which reside in the *I* and *Q Controller Modules*. The three drive registers contain the values used to drive the cavity during the cavity charging period of an RF cycle.
- DRIVE 1:** The two drive 1 displays show the values in the drive 1 registers, which reside in the *I* and *Q Controller Modules*. The three drive registers contain the values used to drive the cavity during the cavity charging period of an RF cycle.
- DRIVE 2:** The two drive 2 displays show the values in the drive 2 registers, which reside in the *I* and *Q Controller Modules*. The three drive registers contain the values used to drive the cavity during the cavity charging period of an RF cycle.
- INITIAL DRIVE:** The two initial drive data displays show the values in the initial drive registers residing in the *I* and *Q Controller Modules*.
- OL DRIVE:** The two open-loop drive displays show the values in the two open-loop drive registers residing in the *I* and *Q Controller Module*.

- LOOP:** These two status displays show the status of the open/closed loop data bits residing in the *I* and *Q* *Controller Modules*. If the bit on a module is high the display for that module reads 'closed,' and if the bit is low the display for that module reads 'open.'
- I FFWD GAIN:** This data display shows the value of the in-phase feedforward gain register residing in the *Adaptive Feedforward Module*. The figure is given in percentage and can vary from -100% to +100%.
- I ADVANCE:** This data display shows the value of the in-phase advance register residing in the *Adaptive Feedforward Module*. Values can vary from 0 ns to 25 500 ns in increments of 100 ns.
- I PRESET LEVEL:** This data display shows the value of the preset voltage loaded in the in-phase preset level register of *Adaptive Feedforward Module*. Values can vary from +10 V to -10 V.
- Q FFWD GAIN:** This data display shows the value of the quadrature feedforward gain register residing in the *Adaptive Feedforward Module*. The figure is given in percentage and can vary from -100% to +100%.
- Q ADVANCE:** This data display shows the value of the quadrature advance register residing in the *Adaptive Feedforward Module*. Values can vary from 0 ns to 25 500 ns in increments of 100 ns.
- Q PRESET LEVEL:** This data display shows the value of the preset voltage loaded in the quadrature preset level register of *Adaptive Feedforward Module*. Values can vary from +10 V to -10 V.
- FEEDFWD:** This display provides the status of the feedforward enable data bit in the *Adaptive Feedforward Module*. If the bit is high the display reads 'on,' and if the bit is low the display reads 'off.'
- LLRF:** This display provides the status of the RF enable data bit residing on the *Upconverter Module*. If the bit is high, the display reads 'enabled,' and if the bit is low, the display reads 'off.'
- EXIT:** When the exit button is pressed, the field control status panel is closed and replaced with the status panel, which is covered in section 2.4.

4.3 Field Control Setup Panel

The field control setup panel, illustrated in figure 4-2, provides the operator with the ability to control and monitor the setup of the cavity field control subsystem. Much of the setup operations are automated and run in the background, transparent to the user.

The field control setup panel is entered from the control system setup modes panel. Upon entering the panel, several configuration files are automatically loaded into the control software. First, the resonance detection, field control, diagnostic monitor, timing, and alarm & limit configuration files are loaded. They provide the hardware configuration data which is needed to define the normal mode of operation. Next, the global files for the reflectometer calibration, gain schedule, and diagnostic signal list

are also loaded. This is done to provide the hardware-specific setup data common to all modes of operation. Finally, the operator is asked if the default file for the field control setup mode will be used. If it is not, the user is asked to provide the name of the file that will be used. The data in this file is displayed on, and is adjustable from, the field control setup panel.

Figure 4-2. Field control setup panel.

The remainder of this section is dedicated to describing the control and monitor points on the field control setup panel. Generally, the control descriptions are listed as the controls appear on the panel, from the upper-left to the lower-right. Where the controls are grouped, each control in the group is discussed before proceeding on to the next group.

LLRF ENABLE/DISABLE: This switch allows the operator to enable and disable the LLRF output. When in the disabled position, the LLRF output will not be allowed to leave the LLRF control rack. When in the enabled position, the LLRF control system will provide the LLRF output signal to the HPRF control rack if all other conditions are satisfied (i.e. the fast-protection signal has not been triggered, the RF gate timing pulse is active, etc.). When en-

abled, the RF gate enable bit is set high on the *Upconverter Module*, and when disabled this bit is cleared low. In other words, the switch reflects and controls the status of the RF gate enable bit. Note that when an alarm occurs, the switch will be moved to the 'disable' state automatically by the software.

LLRF OFF: When this button is pressed, the LLRF output is tied to ground, effectively disabling the output to the HPRF control rack. As with the LLRF disable switch, this button clears the RF gate enable bit on the *Upconverter Module*, forcing it low to prevent any output signal.

WARNING: This is a yellow status display light which provides the warning status for the system. When lit, one or more warnings have been activated. When not lit, no warnings are active in the system. The various warnings are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

ALARM: This is a red status display light which provides the alarm status for the system. When lit, one or more alarms have been activated. When not lit, no alarms are active in the system. The various alarms are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

CAVITY AMPLITUDE SETPOINT: The cavity amplitude setpoint control provides the method of adjusting the magnitude of the cavity RF field. The control system uses a PID-based feedback algorithm to maintain the amplitude of the cavity RF field at the value of the cavity amplitude setpoint. The value residing in this field is scaled to reflect the actual cavity field voltage.

Since the control system performs its operations on the in-phase and quadrature components of the system signals, the setpoints must also be divided into in-phase and quadrature components ($SETPOINT_{ICM}$ and $SETPOINT_{QCM}$). To do this the following equations are used:

$$SETPOINT_{ICM} = \frac{ASP}{ASPSF} \cos(PSP)$$

$$SETPOINT_{QCM} = \frac{ASP}{ASPSF} \sin(PSP)$$

Where ASP is the cavity amplitude setpoint, ASPSF is the cavity amplitude setpoint scale factor, and PSP is the cavity phase setpoint.

In the gain-scheduling algorithm, the ASP provides the key parameter from which all other data parameters are derived. Because of this, the interpolation algorithms must re-evaluate the other parameters each time the ASP is altered. This is explained further in section 4.4, covering the creation of the gain schedule table.

CAVITY AMPLITUDE READBACK: The cavity amplitude readback display contains the amplitude of the cavity RF field as detected by the control system. The value in this field is scaled to reflect the actual cavity field voltage, and appears in a box to the left of a vertical bar graph.

The bar graph displays the relative values of the current field amplitude, the minimum warning level, and the minimum alarm level. The graph also contains their numerical values: The red-to-yellow (upper) transition point is labelled with the value of the alarm limit in the alarm & limit configuration file. The yellow-to-green (lower) transition point is labelled with the value of the warning limit in the alarm & limit configuration file.

To determine the value of the cavity amplitude readback (ARB) the software uses the following equation:

$$ARB = \sqrt{(FLDI \cdot SFI)^2 + (FLDQ \cdot SFQ)^2}$$

Where FLD I is the in-phase component of the RF field, FLD Q is the quadrature component of the RF field, SFI is the scale factor of the in-phase component of the RF field, and SFQ is the scale factor of the quadrature component of the RF field.

CAVITY PHASE SETPOINT: The phase setpoint control provides a method for adjusting the phase of the cavity RF field. The control system uses a PID-based feedback algorithm to maintain the cavity phase at its setpoint value.

Since the control system performs its operations on the in-phase and quadrature components of the system signals, the setpoints must also be divided into in-phase and quadrature components (SETPOINT_{ICM} and SETPOINT_{QCM}). To do this the following equations are used:

$$SETPOINT_{ICM} = \frac{ASP}{ASPSF} \cos(PSP)$$

$$SETPOINT_{QCM} = \frac{ASP}{ASPSF} \sin(PSP)$$

Where ASP is the cavity amplitude setpoint, ASPSF is the cavity amplitude setpoint scale factor, and PSP is the cavity phase setpoint.

CAVITY PHASE READBACK: The readback display of the cavity phase contains the phase (in degrees) of the cavity RF field. It appears as a vector in a circle, giving an approximate visual representation of the phase. The 0°/360° position is along the positive x-axis, or horizontally to the right. Its numerical value (in degrees) appears beneath the circle. The value of the phase readback (PRB) is determined from the following equation:

$$PRB = \tan^{-1}\left(\frac{FLDQ}{FLDI}\right)$$

Where FLD I is the in-phase component of the RF field, and FLD Q is the quadrature component of the RF field.

RF TIMING DELAY: The RF timing delay is used to adjust the time-position of the cavity RF field in the RF cycle. Since the precursory trigger (T0) indicates the beginning of an RF cycle, the RF timing delay is defined as the length of time between the leading edge of T0 and the leading edge of the RF gate. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. Thus the number of clock cycles in the delay period is determined as follows:

$$\text{delaycycles} = \frac{\text{RFGD}}{200\text{ns}}$$

Where RFGD is the RF gate delay.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The delays of all other timing pulses are derived from the RF gate delay. Consequently, as the RFGD is adjusted, all other timing signals track the change. This is explained further in section 6.4, which is about the timing setup.

RF TIMING WIDTH: The RF timing width is used to adjust the length of time that the RF field exists in the cavity. This is done by altering the width of the RF gate pulse, which is displayed as the RF timing width. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. The number of clock cycles that pass while the RF gate is active is determined as follows:

$$\text{widthcycles} = \frac{\text{RFGW}}{200\text{ns}}$$

Where RFGW is the RF gate width.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The widths of all dependent-type timing pulses are derived from the width of the RF gate. Consequently, as RFGW is adjusted, all dependent pulses track the change. This is explained further in section 6.4, which is about the timing setup.

FORWARD DRIVE POWER: The forward drive power status display contains the value of the voltage magnitude at which the cavity is currently being driven. The value is taken from a readback of the klystron amplifier output. It is displayed numerically, and is scaled to reflect the actual voltage level of the forward power signal.

The forward drive power (FWDP) is determined from the following equation:

$$\text{FWDP} = (\text{REFL A})^2 \cdot \text{RAS F}$$

Where REFL A is the reflectometer 'a' signal, and RAS F is the reflectometer 'a' scale factor.

REVERSE DRIVE POWER: The reverse drive power status display contains the value of the voltage magnitude at which drive power is being reflected from the cavity. It is displayed numerically, and is scaled to reflect the actual voltage level of the reflected power signal.

The reverse drive power (RVSP) is determined from the following equation:

$$\text{RVSP} = (\text{REFL B})^2 \cdot \text{RBS F}$$

Where REFL B is the reflectometer 'b' signal, and RBS F is the reflectometer 'b' scale factor.

DIAGNOSTIC MONITOR CH 1: The diagnostic monitor channel 1 control allows the selection of which diagnostic signal is to drive channel one of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 1, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

DIAGNOSTIC MONITOR CH 2: The diagnostic monitor channel 2 control allows the selection of which diagnostic signal is to drive channel two of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 2, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

RESONANCE CONDITION: The resonance condition display provides a graphical representation of the resonance condition of the RF cavity, using a marker on a scale. An instantaneous reading, in the form of a complex coefficient, is taken of the resonance frequency error. The imaginary part of the reading is isolated, and used as the basis for positioning the marker. The complex reflection coefficient is calculated from the REFL A, REFL B REFL A + B, and REFL A + jB registers on the *Envelope Detector Module*.

LOOP CLOSED/OPEN: The loop closed/open switch controls the feedback status of the field control subsystem: specifying either a closed-loop or an open-loop configuration. When in open-loop mode, the subsystem disregards all feedback information and provides a constant LLRF output signal based on the OLDRV registers in the *I* and *Q Controller Modules*. When in the closed-loop position, the subsystem uses feedback to regulate the cavity field more accurately.

OPEN/CLOSED LOOP SCALE FACTOR: The open/closed loop scale factor allows the operator to adjust the scale factor being used by the control system. The scale factors provide the numeric constants for conversion between the control output and the actual value of the LLRF output signal.

DISTURBANCE OFF/ON: The disturbance on/off switch enables and disables the disturbance input. (Disturbances are used to evaluate the performance of the closed-loop control over the cavity RF field.) When in the 'on' position, the disturbance timing pulses in the *I* and *Q Controller Modules* are used as they appear in the timing configuration file. When in the 'off' position these timing pulses are disabled, and will remain low.

IDENTIFY GAIN SCHEDULE: When this button is pressed, the gain schedule identification panel is opened. It provides the means of entering the data for closed-loop gain scheduling. Using the gain scheduling algorithm, the control parameters can be calculated for any given operating setpoint, resulting in a look-up table of control parameters. See section 4.4.

SETUP ADAPTIVE FEEDFORWARD: When this button is pressed, the adaptive feed-forward panel is opened. It provides the means of adjusting, resetting, and enabling the functions of the *Adaptive Feedforward Module*.

EXIT: When the exit button is pressed, the field control setup panel is closed and replaced with the control system setup modes panel. The operator is prompted to choose one of the following exit functions: save, load, return, or exit. (See section 1.8.6.) Note that when the operator leaves this panel, the current machine state remains active until another mode of operations is entered or the shutdown function is selected.

4.4 Gain Schedule Identification Panel

The gain schedule identification panel, illustrated in figure 4-3, provides the controls needed in generating the gain schedule table. Much of the operations are automated and run in the background, transparent to the user.

The screenshot shows the 'Gain Schedule Identification Panel' with the following elements:

- AMPLITUDE SET POINT:** 0.00 MV
- GAINS ASSOCIATED WITH SET POINT:**
 - PROPORTIONAL GAIN: 0.00 %
 - INTEGRAL GAIN: 0.00 %
 - DERIVATIVE GAIN: 0.00 %
 - DRIVE 0 MAGNITUDE: 0.00 V
 - DRIVE 0 PHASE: 0.00 °
 - DRIVE 1 MAGNITUDE: 0.00 V
 - DRIVE 1 PHASE: 0.00 °
 - DRIVE 2 MAGNITUDE: 0.00 V
 - DRIVE 2 PHASE: 0.00 °
 - INITIAL DRIVE MAGNITUDE: 0.00 V
 - INITIAL DRIVE PHASE: 0.00 °
 - THRESHOLD 1: 0.00 V
 - THRESHOLD 2: 0.00 V
 - THRESHOLD 3: 0.00 V
 - LOOP PHASE OFFSET: 0.00 °
- Buttons:** ENTER CURRENT VALUES INTO GAIN SCHEDULE, EXAMINE GAIN SCHEDULE, EXIT (multiple locations).
- Other Controls:** LLRF ENABLE/DISABLE, CAVITY AMPLITUDE SETPOINT (11.0 MV), READBACK (10.8, 25.0, 20.0), LOOP CLOSED/OPEN, DISTURBANCE OFF/ON, ADAPTIVE FEEDFORWARD, etc.

Figure 4-3. Gain schedule identification panel.

The gain schedule identification panel is entered through the field control setup panel. Upon entering the gain schedule identification panel, the current configuration and state for the field control setup mode remain intact, as the field control setup panel remains active in the background. A single change in the software occurs when the panel is opened: the gain-scheduling algorithms for closed-loop operation are disabled automatically. This allows the field control parameters to be manually adjusted, and used to set up the interpolation table for gain-scheduling.

The control and monitor points on the gain schedule identification panel are defined and used as follows:

AMPLITUDE SETPOINT: The amplitude setpoint adjusts the magnitude of the cavity RF field. The setpoint value is valid for both open-loop and closed-loop LLRF output signals. In either case, the field control subsystem will maintain the cavity RF field at the setpoint value.

The gain-scheduling algorithms are disabled while the gain schedule identification panel is active. Consequently, the field control parameters are not affected by changes in the amplitude setpoint. The changes will occur only when this panel is exited.

The in-phase and quadrature open-loop drive levels ($OLDRV_{ICM}$ and $OLDRV_{QCM}$), are computed with the following equations:

$$OLDRV_{ICM} = \frac{ASP}{OLSF} \cos(PSP)$$

$$OLDRV_{QCM} = \frac{ASP}{OLSF} \sin(PSP)$$

Where ASP is the amplitude setpoint, PSP is the cavity field phase set point, and OLSF is the open-loop scale factor.

Similarly, the closed-loop setpoints are determined by the following equations:

$$SETPOINT_{ICM} = \frac{ASP}{ASPSF} \cos(PSP)$$

$$SETPOINT_{QCM} = \frac{ASP}{ASPSF} \sin(PSP)$$

Where ASP is again the amplitude setpoint, ASPSF is the amplitude setpoint scale factor, and PSP is the cavity field phase setpoint.

The gain scheduling algorithm automatically calculates the control parameters for any amplitude setpoint. A look-up table of control parameters used in the interpolation algorithm can be created by the operator. Additionally, each value can be determined empirically, and entered into the gain table. Once data values have been entered for each ASP over the operating range, the data table is saved to a file.

The data table must be determined as a part of the original system installation process. But unless the hardware changes significantly, the table need not be recalculated.

PROPORTIONAL GAIN: The proportional gain adjustment field contains the value of the control loop proportional gain (as stored in registers on the *I* and *Q Controller Modules*). The value is a percentage, defining what fraction of the output from the proportional gain circuit will be incorporated into the cavity drive signal.

INTEGRAL GAIN: The integral gain adjustment field contains the value of the control loop integral gain (as stored in registers on the *I* and *Q Controller Modules*). The value is a percentage, defining what fraction of the output from the integral gain circuit will be incorporated into the cavity drive signal.

DERIVATIVE GAIN: The derivative gain adjustment field contains the value of the control loop derivative gain (as stored in registers on the *I* and *Q Controller Modules*). The value is a percentage, defining what fraction of the output from the derivative gain circuit will be incorporated into the cavity drive signal.

DRIVE 0 MAGNITUDE: The drive 0 magnitude is the magnitude (in volts) of the initial LLRF output signal, used during the cavity charging process. During this process, it is typically desirable to apply an initial overdrive to the cavity. This helps to attain the shortest possible rise-time of the cavity field, providing a quick transition through the region where multipacting occurs. The drive 0 magnitudes are calculated with the following equations:

$$D0_{ICM} = D0MAG \cos(PSP + D0PHS)$$

$$D0_{QCM} = D0MAG \sin(PSP + D0PHS)$$

Where $D0_{ICM}$ and $D0_{QCM}$ are the individual *I* and *Q Controller Module* drive 0 outputs, $D0MAG$ is the drive 0 magnitude, PSP is the phase setpoint, and $D0PHS$ is the drive 0 phase.

DRIVE 0 PHASE: The drive 0 phase is the phase (in degrees) of the initial LLRF output signal, used during the cavity charging process. Due to phase variations in the klystron amplifier, the RF phase is usually different during this drive period than it is during closed-loop operations. The drive 0 phases are calculated with the following equations:

$$D0_{ICM} = D0MAG \cos(PSP + D0PHS)$$

$$D0_{QCM} = D0MAG \sin(PSP + D0PHS)$$

Where $D0_{ICM}$ and $D0_{QCM}$ are the individual *I* and *Q Controller Module* drive 0 outputs, $D0MAG$ is the drive 0 magnitude, PSP is the phase setpoint, and $D0PHS$ is the drive 0 phase.

DRIVE 1 MAGNITUDE: The drive 1 magnitude is the magnitude (in volts) of the initial LLRF output signal, used during the cavity charging process. Quite often, the cavity charging may work best when this value is close to zero. The drive 1 magnitudes are calculated with the following equations:

$$D1_{ICM} = D1MAG \cos(PSP + D1PHS)$$

$$D1_{QCM} = D1MAG \sin(PSP + D1PHS)$$

Where $D1_{ICM}$ and $D1_{QCM}$ are the individual *I* and *Q* Controller Module drive 1 outputs, $D0MAG$ is the drive 1 magnitude, PSP is the phase setpoint, and $D0PHS$ is the drive 1 phase.

DRIVE 1 PHASE: The drive 1 phase is the phase (in degrees) of the initial LLRF output signal, used during the cavity charging process. Due to phase variations in the klystron amplifier, the RF phase is usually different during this drive period than it is during closed-loop operations. The drive 1 phases are calculated from the following equations:

$$D1_{ICM} = D1MAG \cos(PSP + D1PHS)$$

$$D1_{QCM} = D1MAG \sin(PSP + D1PHS)$$

Where $D1_{ICM}$ and $D1_{QCM}$ are the individual *I* and *Q* Controller Module drive 1 outputs, $D0MAG$ is the drive 1 magnitude, PSP is the phase setpoint, and $D0PHS$ is the drive 1 phase.

DRIVE 2 MAGNITUDE: The drive 2 magnitude is the magnitude (in volts) of the initial LLRF output signal, used during the cavity charging process. This is done before the system enters closed-loop operations, and typically, $D2MAG$ is close to the final value of the cavity field. The drive 2 parameters are calculated with the following equations:

$$D2_{ICM} = D2MAG \cos(PSP + D2PHS)$$

$$D2_{QCM} = D2MAG \sin(PSP + D2PHS)$$

Where $D2_{ICM}$ and $D2_{QCM}$ are the individual *I* and *Q* Controller Module drive 2 outputs, $D2MAG$ is the drive 2 magnitude, PSP is the phase setpoint, and $D2PHS$ is the drive 2 phase.

DRIVE 2 PHASE: The drive 2 phase is the phase (in degrees) of the initial LLRF output signal, used during the cavity charging process. Due to phase variations in the klystron amplifier, the RF phase is usually different during this drive period than it is during closed-loop operations. The drive 2 phases are calculated from the following equations:

$$D2_{ICM} = D2MAG \cos(PSP + D2PHS)$$

$$D2_{QCM} = D2MAG \sin(PSP + D2PHS)$$

Where $D2_{ICM}$ and $D2_{QCM}$ are the individual *I* and *Q* Controller Module drive 2 outputs, $D2MAG$ is the drive 2 magnitude, PSP is the phase setpoint, and $D2PHS$ is the drive 2 phase.

INITIAL DRIVE MAGNITUDE: The initial drive magnitude signal is used to determine the cavity drive magnitude used when the system first enters closed-loop operations. Typically, the cavity is driven close to the final setpoint value of the cavity field. The initial value parameters in the *I* and *Q* Controller Modules ($IVAL_{ICM}$ and $IVAL_{QCM}$) are calculated in the following equation:

$$IVAL_{ICM} = IDM \cos(PSP)$$

$$IVAL_{QCM} = IDM \sin(PSP)$$

Where IDM is the initial drive magnitude, and PSP is the phase setpoint.

INITIAL DRIVE PHASE: The initial drive phase signal is used to determine the phase of the cavity drive when the system first enters closed-loop operation.

THRESHOLD 1: The threshold 1 field contains the value of the RF cavity amplitude at which there is a sufficient charge to allow drive 0 to be terminated, and drive 1 activated.

THRESHOLD 2: The threshold 2 field contains the value of the RF cavity amplitude at which there is a sufficient charge to allow drive 1 to be terminated, and drive 2 activated.

THRESHOLD 3: The threshold 3 field contains the value of the RF cavity amplitude at which there is a sufficient charge to allow drive 2 to be terminated, and the closed-loop control activated.

LOOP PHASE OFFSET: The loop phase offset contains the value of the phase offset being used to eliminate the arbitrary phase rotation of the control loop. The loop phase offset parameters in the *Vector Modulator Module* ($LPO_{\cos}$ and $LPO_{\sin}$) are calculated as follows:

$$LPO_{\cos} = 10 \cdot \cos(LPO_{\text{INTERPOLATED}})$$

$$LPO_{\sin} = 10 \cdot \sin(LPO_{\text{INTERPOLATED}})$$

Where $LPO_{\text{INTERPOLATED}}$ is the interpolated loop phase offset.

ENTER CURRENT VALUES INTO GAIN SCHEDULE: When this button is pressed, the data set contained in the fields on this panel is entered as a line in the selected gain schedule data table. The software sorts the data automatically so that the table will be listed with the amplitude setpoints in increasing order. This provides the means of compiling the gain schedule data table.

EXAMINE GAIN SCHEDULE: When this button is pressed, the gain schedule data table panel is opened and placed on the screen. It allows the current gain schedule data table to be examined.

LOOP CLOSED/OPEN: The loop closed/open switch controls the feedback status of the field control subsystem: specifying either a closed-loop or an open-loop configuration. When in open-loop mode, the subsystem disregards all feedback information and provides a constant LLRF output signal based on the OLDRV registers in the *I* and *Q Controller Modules*. When in the closed-loop position, the subsystem uses feedback to regulate the cavity field more accurately.

DISTURBANCE OFF/ON: The disturbance on/off switch enables and disables the disturbance input. (Disturbances are used to evaluate the performance of the closed-loop control over the cavity RF field.) When in the 'on' position, the disturbance timing pulses in the *I* and *Q Controller Modules* are used as they appear in the timing configuration file. When in the 'off' position these timing pulses are disabled, and will remain low.

EXIT: When the exit button is pressed, the gain schedule identification panel is closed and replaced with the field control setup panel. When the exit button is selected, the operator is prompted to choose one of the following exit functions: save, return, or exit. (See section 1.7.6.)

4.5 Gain Schedule Data Table Panel

The gain schedule data table panel, illustrated in figure 4-3, displays the interpolation data table for the selected gain schedule file. The values can not be altered from this panel, only viewed. Instead, alteration of the data is done from the gain schedule identification panel.

SETPOINT	PROP GAIN	INT GAIN	DIFF GAIN	D0 MAG	D0 PHS	D1 MAG	D1 PHS	D2 MAG	D2 PHS
0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
0.5000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
1.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
2.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
3.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
4.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
5.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
7.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
10.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

EXIT

10.8 20.0

LOOP CLOSED ☒ OPEN ☒ DISTRUBANCE OFF ☒ ON ☒ EXIT

READBACK 37.5 EXIT

PACTIVE RWARD

Figure 4-4. Gain schedule data table panel.

The gain schedule data table panel is entered through the gain schedule identification panel. Upon entering the gain schedule data table panel, the current configuration and state for the field control setup mode remain intact, as the field control setup panel remains active in the background.

The items in the table are kept in numerical order according to the setpoints. This is done automatically by the software, regardless of the order in which the data has been entered. The data categories are defined as follows:

SETPOINT: The amplitude setpoint adjusts the magnitude of the cavity RF field. The setpoint value is valid for both open-loop and closed-loop LLRF output signals. In either case, the field control subsystem will maintain the cavity RF field at the setpoint value.

The gain-scheduling algorithms are disabled while the gain schedule identification panel is active. Consequently, the field control parameters are not affected by changes in the amplitude setpoint. The changes will occur only when this panel is exited.

The in-phase and quadrature open-loop drive levels ($OLDRV_{ICM}$ and $OLDRV_{QCM}$), are computed with the following equations:

$$OLDRV_{ICM} = \frac{ASP}{OLSF} \cos(PSP)$$

$$OLDRV_{QCM} = \frac{ASP}{OLSF} \sin(PSP)$$

Where ASP is the amplitude setpoint, PSP is the cavity field phase set point, and OLSF is the open-loop scale factor.

Similarly, the closed-loop setpoints are determined by the following equations:

$$SETPOINT_{ICM} = \frac{ASP}{ASPSF} \cos(PSP)$$

$$SETPOINT_{QCM} = \frac{ASP}{ASPSF} \sin(PSP)$$

Where ASP is again the amplitude setpoint, ASPSF is the amplitude setpoint scale factor, and PSP is the cavity field phase setpoint.

The gain scheduling algorithm automatically calculates the control parameters for any amplitude setpoint. A look-up table of control parameters used in the interpolation algorithm can be created by the operator. Additionally, each value can be determined empirically, and entered into the gain table. Once data values have been entered for each ASP over the operating range, the data table is saved to a file.

The data table must be determined as a part of the original system installation process. But unless the hardware changes significantly, the table need not be recalculated.

PROP GAIN: The proportional gain adjustment field contains the value of the control loop proportional gain (as stored in registers on the *I* and *Q Controller Modules*). The value is a percentage, defining what fraction of the output from the proportional gain circuit will be incorporated into the cavity drive signal.

INT GAIN: The integral gain adjustment field contains the value of the control loop integral gain (as stored in registers on the *I* and *Q Controller Modules*). The value is a percentage, defining what fraction of the output from the integral gain circuit will be incorporated into the cavity drive signal.

DIFF GAIN: The derivative gain adjustment field contains the value of the control loop derivative gain (as stored in registers on the *I* and *Q Controller Modules*). The value is a percentage, defining what fraction of the output from the derivative gain circuit will be incorporated into the cavity drive signal.

D0 MAG: The drive 0 magnitude is the magnitude (in volts) of the initial LLRF output signal, used during the cavity charging process. During this process, it is typically desirable to apply an initial overdrive to the cavity. This helps to attain the shortest possible rise-time of the cavity field, providing a quick transition through the region where multipacting occurs. The drive 0 magnitudes are calculated with the following equations:

$$D0_{ICM} = D0MAG \cos(PSP + D0PHS)$$

$$D0_{QCM} = D0MAG \sin(PSP + D0PHS)$$

Where $D0_{ICM}$ and $D0_{QCM}$ are the individual *I* and *Q* Controller Module drive 0 outputs, $D0MAG$ is the drive 0 magnitude, PSP is the phase setpoint, and $D0PHS$ is the drive 0 phase.

D0 PHS: The drive 0 phase is the phase (in degrees) of the initial LLRF output signal, used during the cavity charging process. Due to phase variations in the klystron amplifier, the RF phase is usually different during this drive period than it is during closed-loop operations. The drive 0 phases are calculated with the following equations:

$$D0_{ICM} = D0MAG \cos(PSP + D0PHS)$$

$$D0_{QCM} = D0MAG \sin(PSP + D0PHS)$$

Where $D0_{ICM}$ and $D0_{QCM}$ are the individual *I* and *Q* Controller Module drive 0 outputs, $D0MAG$ is the drive 0 magnitude, PSP is the phase setpoint, and $D0PHS$ is the drive 0 phase.

D1 MAG: The drive 1 magnitude is the magnitude (in volts) of the initial LLRF output signal, used during the cavity charging process. Quite often, the cavity charging may work best when this value is close to zero. The drive 1 magnitudes are calculated with the following equations:

$$D1_{ICM} = D1MAG \cos(PSP + D1PHS)$$

$$D1_{QCM} = D1MAG \sin(PSP + D1PHS)$$

Where $D1_{ICM}$ and $D1_{QCM}$ are the individual *I* and *Q* Controller Module drive 1 outputs, $D0MAG$ is the drive 1 magnitude, PSP is the phase setpoint, and $D0PHS$ is the drive 1 phase.

D1 PHS: The drive 1 phase is the phase (in degrees) of the initial LLRF output signal, used during the cavity charging process. Due to phase variations in the klystron amplifier, the RF phase is usually different during this drive period than it is during closed-loop operations. The drive 1 phases are calculated from the following equations:

$$D1_{ICM} = D1MAG \cos(PSP + D1PHS)$$

$$D1_{QCM} = D1MAG \sin(PSP + D1PHS)$$

Where $D1_{ICM}$ and $D1_{QCM}$ are the individual *I* and *Q* Controller Module drive 1 outputs, $D0MAG$ is the drive 1 magnitude, PSP is the phase setpoint, and $D0PHS$ is the drive 1 phase.

D2 MAG: The drive 2 magnitude is the magnitude (in volts) of the initial LLRF output signal, used during the cavity charging process. This is done before the system enters closed-loop operations, and typically, D2MAG is close to the final value of the cavity field. The drive 2 parameters are calculated with the following equations:

$$\begin{aligned} D2_{ICM} &= D2MAG \cos(PSP + D2PHS) \\ D2_{QCM} &= D2MAG \sin(PSP + D2PHS) \end{aligned}$$

Where $D2_{ICM}$ and $D2_{QCM}$ are the individual *I* and *Q* Controller Module drive 2 outputs, D2MAG is the drive 2 magnitude, PSP is the phase setpoint, and D2PHS is the drive 2 phase.

D2 PHS: The drive 2 phase is the phase (in degrees) of the initial LLRF output signal, used during the cavity charging process. Due to phase variations in the klystron amplifier, the RF phase is usually different during this drive period than it is during closed-loop operations. The drive 2 phases are calculated from the following equations:

$$\begin{aligned} D2_{ICM} &= D2MAG \cos(PSP + D2PHS) \\ D2_{QCM} &= D2MAG \sin(PSP + D2PHS) \end{aligned}$$

Where $D2_{ICM}$ and $D2_{QCM}$ are the individual *I* and *Q* Controller Module drive 2 outputs, D2MAG is the drive 2 magnitude, PSP is the phase setpoint, and D2PHS is the drive 2 phase.

INIT MAG: The initial drive magnitude signal is used to determine the cavity drive magnitude used when the system first enters closed-loop operations. Typically, the cavity is driven close to the final setpoint value of the cavity field. The initial value parameters in the *I* and *Q* Controller Modules ($IVAL_{ICM}$ and $IVAL_{QCM}$) are calculated in the following equation:

$$\begin{aligned} IVAL_{ICM} &= IDM \cos(PSP) \\ IVAL_{QCM} &= IDM \sin(PSP) \end{aligned}$$

Where IDM is the initial drive magnitude, and PSP is the phase setpoint.

INIT PHS: The initial drive phase signal is used to determine the phase of the cavity drive when the system first enters closed-loop operation.

THR 1: The threshold 1 field contains the value of the RF cavity amplitude at which there is a sufficient charge to allow drive 0 to be terminated, and drive 1 activated.

THR 2: The threshold 2 field contains the value of the RF cavity amplitude at which there is a sufficient charge to allow drive 1 to be terminated, and drive 2 activated.

THR 3: The threshold 3 field contains the value of the RF cavity amplitude at which there is a sufficient charge to allow drive 2 to be terminated, and the closed-loop control activated.

LPO: The loop phase offset contains the value of the phase offset being used to eliminate the arbitrary phase rotation of the control loop. The loop phase offset parameters in the *Vector Modulator Module* ($LPO_{\cos}$ and $LPO_{\sin}$) are calculated as follows:

$$LPO_{\cos} = 10 \cdot \cos(LPO_{\text{INTERPOLATED}})$$

$$LPO_{\sin} = 10 \cdot \sin(LPO_{\text{INTERPOLATED}})$$

Where $LPO_{\text{INTERPOLATED}}$ is the interpolated loop phase offset.

EXIT: This control button closes the control display for the gain schedule data table and returns control to the gain schedule identification panel.

4.6 Adaptive Feedforward Panel

The adaptive feedforward panel, illustrated in figure 4-5, contains the control and monitor points that adjust the adaptive feedforward functions. Much of the operation is automated, running in the background transparent to the user.

The adaptive feedforward panel is accessible from the field control setup panel, and appears on top of the existing panels. Upon entering the adaptive feedforward panel, the current configuration and state for the field control setup mode remain intact as the field control setup panel remains active in the background.

The adaptive feedforward panel functions are defined and used as follows:

FFWD ON/OFF: The feedforward on/off switch turns the output of the *Adaptive Feedforward Module* off or on.

ADAPT ON/OFF: The adapt on/off switch essentially turns the adaptation function of the *Adaptive Feedforward Module* on or off.

RESET ON/OFF: The reset on/off switch causes data to be reset and the preset voltage (if enabled) to be applied to the *Adaptive Feedforward Module* output when the switch is on. When it is off, current data is held.

RESET: When the adaptive feedforward reset button is pressed, the adaptive feedforward data is cleared. The software executed by this button sets both the reset I data and reset Q data bits high on the *Adaptive Feedforward Module*.

These three toggle switches can be set together to configure the output of the *Adaptive Feedforward Module*. The following table indicates the on/off state of each switch and the resulting state of the module:

FFWD	Switch ADAPT	RESET	Operation
Off	Either	On	Reset data, no FFWD output.
Off	Off	Off	Hold current data, no FFWD output.
Off	On	Off	Adapt with input, no FFWD output.
On	Either	On	Reset data, FFWD output.
On	Off	Off	Hold current data, FFWD output.
On	On	Off	Adapt with input, FFWD output.

I FFWD GAIN: The in-phase feedforward output of the *Adaptive Feedforward Module* can be adjusted through this control. Output of the signal can be varied from -100% to +100%, including 0%.

Q FFWD GAIN: The quadrature feedforward output of the *Adaptive Feedforward Module* can be adjusted through this control. Output of the signal can be varied from -100% to +100%, including 0%.

I ADVANCE: The in-phase advance field controls the timing advance for the I component of the *Adaptive Feedforward Module*. The values entered in this field may vary from 0 ns to 25 500 ns in 100-ns increments. Generally, an advance of 1000 ns should be sufficient for most accelerator operations.

Q ADVANCE: The quadrature advance field controls the timing advance for the Q component of the *Adaptive Feedforward Module*. The values entered in this field may vary from 0 ns to 25 500 ns in 100-ns increments. Generally, an advance of 1000 ns should be sufficient for most accelerator operations.

Figure 4-5. Adaptive feedforward panel.

I PRESET LEVEL: The in-phase preset level field controls the preset (or reset) voltage level for the I component of the *Adaptive Feedforward Module*. In the event of an input signal interruption (or a test procedure) this voltage will be used by the module to generate a signal output. The voltage may vary from +10 V to -10 V.

Q PRESET LEVEL: The quadrature preset level field controls the preset (or reset) voltage level for the Q component of the *Adaptive Feedforward Module*. In the event of an input signal interruption (or a test procedure) this voltage will be used by the module to generate a signal output. The voltage level may vary from +10 V to -10 V.

OVERFLOW I: This is a warning light that indicates that the I component of the *Adaptive Feedforward Module* is generating data that is overflowing module RAM. Because the output of the *Adaptive Feedforward Module's* multiplier/accumulator chip can be as great as 16 bits while only 12 bits are used by the RAM that receives input from the device, it is possible that the module can generate values that will overflow the RAM. If the module has been configured through hardware to generate an overflow alarm signal, then the presence of the overflow state will be indicated by this warning light.

OVERFLOW Q: This is a warning light that indicates that the Q component of the *Adaptive Feedforward Module* is generating data that is overflowing module RAM. Because the output of the *Adaptive Feedforward Module's* multiplier/accumulator chip can be as great as 16 bits while only 12 bits are used by the RAM that receives input from the device, it is possible that the module can generate values that will overflow the RAM. If the module has been configured through hardware to generate an overflow alarm signal, then the presence of the overflow state will be indicated by this warning light.

EXIT: When the exit button is pressed, the adaptive feedforward panel is closed, and control is returned to the field control setup panel.

This page has been left blank intentionally.

5. DIAGNOSTIC MONITOR SUBSYSTEM

5.1 Chapter Overview

This chapter describes the LabVIEW® control panels that are used to control the diagnostic monitor subsystem. This set of panels includes monitors for both the real-time analog signals and the sampled/held digital signals.

The subsystem provides two types of monitor signals: sampled/held magnitude levels, and real-time waveforms. The sampled magnitude levels can be examined by accessing the appropriate sample/hold register in the module containing the desired monitor point. Each register provides the magnitude of a signal at a single sample point within the RF pulse. The timing of the sample points can be adjusted.

The panels discussed in this chapter are as follows:

- The diagnostic monitor status panel provides a complete set of status information on the diagnostic monitor subsystem.
- The diagnostic monitor setup panel contains controls which allow the diagnostic monitor subsystem to be set up for operation.

5.2 Diagnostic Monitor Status Panel

The diagnostic monitor status panel provides the operator with a complete set of status information on the diagnostic monitor subsystem. (See figure 5-1.) The panel is accessed from the status panel, and appears in its place at the top of the screen. The display contains the current amplitude measurements for the diagnostic data channels that are detected, sampled, and converted into digital bit-sets. Specifically, the panel provides the following:

SIGNAL NAME/DESCRIPTION: This area of the panel provides the user with a brief on-line description of the signal abbreviations and their meanings.

MEASUREMENT DATA: The data appearing in this box comes from several different VXibus modules. For each of the signals, the value shows the magnitude of the high-power RF signal, and the raw data represents the corresponding magnitude of the low-level RF signal.

FIELD I: Field I is the in-phase component of the cavity field sample as seen in the field I register on the *Vector Detector Module*. The raw data is converted into a scaled value with the following equation:

$$FIELDI_{SCALEDVALUE} = FIELDI_{RAWDATA} \cdot FIELDI_{SCALEFACTOR}$$

FIELD Q: Field Q is the in-phase component of the cavity field sample as seen in the field Q register on the *Vector Detector Module*. The raw data is converted into a scaled value with the following equation:

$$FIELDQ_{SCALEDVALUE} = FIELDQ_{RAWDATA} \cdot FIELDQ_{SCALEFACTOR}$$

Figure 5-1. Diagnostic monitor status panel.

DRIVE I: Drive I is the in-phase component of the cavity drive sample as seen in the drive I register on the *Vector Detector Module*. The raw data is converted into a scaled value with the following equation:

$$DRIVEI_{SCALEDVALUE} = DRIVEI_{RAWDATA} \cdot DRIVEI_{SCALEFACTOR}$$

DRIVE Q: Drive Q is the quadrature component of the cavity drive sample, as seen in the drive Q register on the *Vector Detector Module*. The raw data is converted into a scaled value with the following equation:

$$DRIVEQ_{SCALEDVALUE} = DRIVEQ_{RAWDATA} \cdot DRIVEQ_{SCALEFACTOR}$$

REFL A: This is the sampled value of the reflectometer 'a' channel, as seen in the REFL A register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$REFLA_{SCALEDVALUE} = (REFLA_{RAWDATA})^2 \cdot REFLA_{SCALEFACTOR}$$

REFL B: This is the sampled value of the reflectometer 'b' channel, as seen in the REFL B register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$REFLB_{SCALEDVALUE} = (REFLB_{RAWDATA})^2 \cdot REFLB_{SCALEFACTOR}$$

REFL A + B: This is the sampled value of the reflectometer 'a + b' channel, as seen in the REFL A + B register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$REFLA + B_{SCALEDVALUE} = (REFLA + B_{RAWDATA})^2 \cdot REFLA + B_{SCALEFACTOR}$$

REFL A + jB: This is the sampled value of the reflectometer 'a + jb' channel, as seen in the REFL A + jB register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$REFLA + jB_{SCALEDVALUE} = (REFLA + jB_{RAWDATA})^2 \cdot REFLA + jB_{SCALEFACTOR}$$

CPLR FWD: This display provides the user with the value of the forward sample from the directional coupler, as held in the coupler forward register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$CPLRFWD_{SCALEDVALUE} = (CPLRFWD_{RAWDATA})^2 \cdot CPLRFWD_{SCALEFACTOR}$$

CPLR RVS: This display provides the user with the value of the reverse sample from the directional coupler, as held in the coupler reverse register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$CPLRRVS_{SCALEDVALUE} = (CPLRRVS_{RAWDATA})^2 \cdot CPLRRVS_{SCALEFACTOR}$$

ENV SPARE 1: This provides the user with the value of the first spare input on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$ENVSPARE1_{SCALEDVALUE} = (ENVSPARE1_{RAWDATA})^2 \cdot ENVSPARE1_{SCALEFACTOR}$$

ENV SPARE 2: This provides the user with the value of the second spare input on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$ENVSPARE2_{SCALEDVALUE} = (ENVSPARE2_{RAWDATA})^2 \cdot ENVSPARE2_{SCALEFACTOR}$$

LLRF OUT: This display provides the operator with a sample of the low-level RF output signal from the register on the *Upconverter Module*. The raw data is converted into a scaled value with the following equation:

$$LLRFOUT_{SCALEDVALUE} = (LLRFOUT_{RAWDATA})^2 \cdot LLRFOUT_{SCALEFACTOR}$$

EXIT: When the exit button is pressed, the diagnostic monitor status panel is closed and replaced with the status panel, which is covered in section 2.4.

5.3 Diagnostic Monitor Setup Panel

The diagnostic monitor setup panel, illustrated in figure 5-2, provides the controls needed to set up the diagnostic monitor subsystem, including signal calibration functions. Much of the setup operations are automated and run in the background, transparent to the user.

Figure 5-2. Diagnostic monitor setup panel.

The diagnostic monitor setup panel is entered from the control system setup modes panel. Upon entering the panel, several configuration files are automatically loaded into the control software. First, the resonance detection, field control, diagnostic monitor, timing, and alarm & limit configuration files are loaded. They provide the hardware configuration data which is needed to define the normal mode of operation. Next, the global files for the reflectometer calibration, gain schedule, and diagnostic signal list are also loaded. This is done to provide the hardware-specific setup data common to all modes of operation. Finally, the operator is asked if the default file for the diagnostic monitor setup mode will be used. If it is not, the user is asked to provide the name of the file that will be used. The data in this file is displayed on, and is adjustable from, the diagnostic monitor setup panel.

Note that the scale factors given in figure 5-2 are not unitless; they are given in dB. This has been done to allow the user to input the attenuation of the transport path in order to derive the true value of the forward power. For example, the reflectometer has 10 dB of coupling in the directional coupler and ~6 dB of loss in the cable connecting the rack to the reflectometer assembly. So, for REFL A, put in 76 dB for

a scale factor ($60 \text{ dB} + 10 \text{ dB} + 6 \text{ dB} = 76 \text{ dB}$). This method of calculating the scale factor tells the user what the forward power really is.

The remainder of this section is dedicated to describing the control and monitor points on the diagnostic monitor setup panel. Generally, the control descriptions are listed as the controls appear on the panel, from the upper-left to the lower-right. Where the controls are grouped, each control in the group is discussed before proceeding on to the next group.

LLRF ENABLE/DISABLE: This switch allows the operator to enable and disable the LLRF output. When in the disabled position, the LLRF output will not be allowed to leave the LLRF control rack. When in the enabled position, the LLRF control system will provide the LLRF output signal to the HPRF control rack if all other conditions are satisfied (i.e. the fast-protection signal has not been triggered, the RF gate timing pulse is active, etc.). When enabled, the RF gate enable bit is set high on the *Upconverter Module*, and when disabled this bit is cleared low. In other words, the switch reflects and controls the status of the RF gate enable bit. Note that when an alarm occurs, the switch will be moved to the 'disable' state automatically by the software.

LLRF OFF: When this button is pressed, the LLRF output is tied to ground, effectively disabling the output to the HPRF control rack. As with the LLRF disable switch, this button clears the RF gate enable bit on the *Upconverter Module*, forcing it low to prevent any output signal.

WARNING: This is a yellow status display light which provides the warning status for the system. When lit, one or more warnings have been activated. When not lit, no warnings are active in the system. The various warnings are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

ALARM: This is a red status display light which provides the alarm status for the system. When lit, one or more alarms have been activated. When not lit, no alarms are active in the system. The various alarms are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

CAVITY DRIVE LEVEL ADJUSTMENT: The cavity drive adjustment control provides a direct adjustment to the drive level of the RF cavity. The value is scaled to reflect the actual voltage of the cavity drive signal. The cavity drive level adjustment is used to determine the value of the open-loop drive on the *I* and *Q* Controller Modules ($OLDRV_{ICM}$ and $OLDRV_{QCM}$), as seen in the following equations:

$$OLDRV_{ICM} = \frac{CDA}{CDSF} \sin(CDP)$$

$$OLDRV_{QCM} = \frac{CDA}{CDSF} \sin(CDP)$$

Where CDA is the cavity drive adjustment, CDSF is the cavity drive scale factor, and CDP is the cavity drive phase.

CAVITY DRIVE PHASE ADJUSTMENT: The cavity drive phase adjustment control allows the open-loop phase of the cavity RF field to be set. The cavity drive phase adjustment is used to determine the value of the open-loop drive on the *I* and *Q* Controller Modules ($OLDRV_{ICM}$ and $OLDRV_{QCM}$), as seen in the following equations:

$$OLDRV_{ICM} = \frac{CDA}{CDSF} \sin(CDP)$$

$$OLDRV_{QCM} = \frac{CDA}{CDSF} \sin(CDP)$$

Where CDA is the cavity drive adjustment, CDSF is the cavity drive scale factor, and CDP is the cavity drive phase.

CAVITY AMPLITUDE READBACK: The cavity amplitude readback display contains the amplitude of the cavity RF field as detected by the control system. The value in this field is scaled to reflect the actual cavity field voltage, and appears in a box to the left of a vertical bar graph.

The bar graph displays the relative values of the current field amplitude, the minimum warning level, and the minimum alarm level. The graph also contains their numerical values: The red-to-yellow (upper) transition point is labelled with the value of the alarm limit in the alarm & limit configuration file. The yellow-to-green (lower) transition point is labelled with the value of the warning limit in the alarm & limit configuration file.

To determine the value of the cavity amplitude readback (ARB) the software uses the following equation:

$$ARB = \sqrt{(FLDI \cdot SFI)^2 + (FLDQ \cdot SFQ)^2}$$

Where FLD I is the in-phase component of the RF field, FLD Q is the quadrature component of the RF field, SFI is the scale factor of the in-phase component of the RF field, and SFQ is the scale factor of the quadrature component of the RF field.

CAVITY PHASE READBACK: The readback display of the cavity phase contains the phase (in degrees) of the cavity RF field. It appears as a vector in a circle, giving an approximate visual representation of the phase. The $0^\circ/360^\circ$ position is along the positive x-axis, or horizontally to the right. Its numerical value (in degrees) appears beneath the circle. The value of the phase readback (PRB) is determined from the following equation:

$$PRB = \tan^{-1}\left(\frac{FLDQ}{FLDI}\right)$$

Where FLD I is the in-phase component of the RF field, and FLD Q is the quadrature component of the RF field.

RF TIMING DELAY: The RF timing delay is used to adjust the time-position of the cavity RF field in the RF cycle. Since the precursory trigger (T0) indicates the beginning of an RF cycle, the RF timing delay is defined as the length of

time between the leading edge of T0 and the leading edge of the RF gate. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. Thus the number of clock cycles in the delay period is determined as follows:

$$\text{delaycycles} = \frac{\text{RFGD}}{200\text{ns}}$$

Where RFGD is the RF gate delay.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The delays of all other timing pulses are derived from the RF gate delay. Consequently, as the RFGD is adjusted, all other timing signals track the change. This is explained further in section 6.4, which is about the timing setup.

RF TIMING WIDTH: The RF timing width is used to adjust the length of time that the RF field exists in the cavity. This is done by altering the width of the RF gate pulse, which is displayed as the RF timing width. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. The number of clock cycles that pass while the RF gate is active is determined as follows:

$$\text{widthcycles} = \frac{\text{RFGW}}{200\text{ns}}$$

Where RFGW is the RF gate width.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The widths of all dependent-type timing pulses are derived from the width of the RF gate. Consequently, as RFGW is adjusted, all dependent pulses track the change. This is explained further in section 6.4, which is about the timing setup.

DIAGNOSTIC MONITOR CH 1: The diagnostic monitor channel 1 control allows the selection of which diagnostic signal is to drive channel one of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 1, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

DIAGNOSTIC MONITOR CH 2: The diagnostic monitor channel 2 control allows the selection of which diagnostic signal is to drive channel two of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 2, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

DIAGNOSTIC MONITOR CALIBRATION: This control field provides the means of calibrating the offset, gain, and bandwidth of the two diagnostic monitor channels. The following options are available:

- **CAL SIGNALS OFF:** This option turns off all diagnostic monitor calibration processes, and enables normal operation for the two monitor channels. The signal source for the selected channel is chosen with the two diagnostic monitor selection controls described above.
- **ADJUST OFFSET - CHANNEL 1/2:** This option allows the user to calibrate and adjust the voltage offset for each of the monitor channels, one at a time. The signal source for the selected channel is grounded so that the operator can obtain a voltage offset of zero. The software transmits the following bit-combination to the transmitter calibration select channel on the *Monitor Transmitter Module*: set $\overline{\text{ON}}/\text{CAL}$ to high, select $\overline{1}/2$ high for channel two or low for channel one, clear $\overline{\text{REF}}/\text{CLK}$ low, and clear $\overline{\text{GND}}/+10\text{V}$ low. The system remains in the offset adjustment state until another option is selected.
- **ADJUST GAIN - CHANNEL 1/2:** This option allows the user to calibrate and adjust the gain for each of the monitor channels, one at a time. The signal source for the selected channel is connected to a +10 V signal so that the operator can obtain a gain of unity. The software transmits the following bit-combination to the transmitter calibration select channel on the *Monitor Transmitter Module*: set $\overline{\text{ON}}/\text{CAL}$ to high, select $\overline{1}/2$ high for channel two or low for channel one, clear $\overline{\text{REF}}/\text{CLK}$ low, and set $\overline{\text{GND}}/+10\text{V}$ high. The system remains in the gain adjustment state until another option is selected.
- **ADJUST BANDWIDTH - CHANNEL 1/2:** This option allows the user to calibrate and adjust the bandwidth for each of the monitor channels. The signal source for the selected channel is connected to a 1 kHz clock so the operator can adjust the bandwidth for the appropriate step response. The software transmits the following bit-combination to the transmitter calibration select channel on the *Monitor Transmitter Module*: set $\overline{\text{ON}}/\text{CAL}$ to high, select $\overline{1}/2$ high for channel two or low for channel one, set $\overline{\text{REF}}/\text{CLK}$ high, and clear $\overline{\text{GND}}/+10\text{V}$ low. The system remains in the bandwidth adjustment state until another option is selected.

MEASUREMENT DATA: The data appearing in this box comes from several different VXibus modules. For each of the signals, the value shows the magnitude of the high-power RF signal, and the raw data represents the corresponding magnitude of the low-level RF signal. In addition, each of the signals has an adjustable scale factor which controls the conversion between the raw data and the scaled value.

FIELD I: Field I is the in-phase component of the cavity field sample as seen in the field I register on the *Vector Detector Module*. The raw data is converted into a scaled value with the following equation:

$$\text{FIELDI}_{\text{SCALEDVALUE}} = \text{FIELDI}_{\text{RAWDATA}} \cdot \text{FIELDI}_{\text{SCALEFACTOR}}$$

FIELD Q: Field Q is the in-phase component of the cavity field sample as seen in the field Q register on the *Vector Detector Module*. The raw data is converted into a scaled value with the following equation:

$$FIELDQ_{SCALEDVALUE} = FIELDQ_{RAWDATA} \cdot FIELDQ_{SCALEFACTOR}$$

DRIVE I: Drive I is the in-phase component of the cavity drive sample as seen in the drive I register on the *Vector Detector Module*. The raw data is converted into a scaled value with the following equation:

$$DRIVEI_{SCALEDVALUE} = DRIVEI_{RAWDATA} \cdot DRIVEI_{SCALEFACTOR}$$

DRIVE Q: Drive Q is the quadrature component of the cavity drive sample, as seen in the drive Q register on the *Vector Detector Module*. The raw data is converted into a scaled value with the following equation:

$$DRIVEQ_{SCALEDVALUE} = DRIVEQ_{RAWDATA} \cdot DRIVEQ_{SCALEFACTOR}$$

REFL A: This is the sampled value of the reflectometer 'a' channel, as seen in the REFL A register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$REFLA_{SCALEDVALUE} = (REFLA_{RAWDATA})^2 \cdot REFLA_{SCALEFACTOR}$$

REFL B: This is the sampled value of the reflectometer 'b' channel, as seen in the REFL B register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$REFLB_{SCALEDVALUE} = (REFLB_{RAWDATA})^2 \cdot REFLB_{SCALEFACTOR}$$

REFL A + B: This is the sampled value of the reflectometer 'a + b' channel, as seen in the REFL A + B register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$REFLA + B_{SCALEDVALUE} = (REFLA + B_{RAWDATA})^2 \cdot REFLA + B_{SCALEFACTOR}$$

REFL A + jB: This is the sampled value of the reflectometer 'a + jb' channel, as seen in the REFL A + jB register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$REFLA + jB_{SCALEDVALUE} = (REFLA + jB_{RAWDATA})^2 \cdot REFLA + jB_{SCALEFACTOR}$$

CPLR FWD: This display provides the user with the value of the forward sample from the directional coupler, as held in the coupler forward register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$CPLRFWD_{SCALEDVALUE} = (CPLRFWD_{RAWDATA})^2 \cdot CPLRFWD_{SCALEFACTOR}$$

CPLR RVS: This display provides the user with the value of the reverse sample from the directional coupler, as held in the coupler reverse register on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$CPLRRVS_{SCALEDVALUE} = (CPLRRVS_{RAWDATA})^2 \cdot CPLRRVS_{SCALEFACTOR}$$

ENV SPARE 1: This provides the user with the value of the first spare input on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$ENVSPARE1_{SCALEDVALUE} = (ENVSPARE1_{RAWDATA})^2 \cdot ENVSPARE1_{SCALEFACTOR}$$

ENV SPARE 2: This provides the user with the value of the second spare input on the *Envelope Detector Module*. The raw data is converted into a scaled value with the following equation:

$$ENVSPARE2_{SCALEDVALUE} = (ENVSPARE2_{RAWDATA})^2 \cdot ENVSPARE2_{SCALEFACTOR}$$

LLRF OUT: This display provides the operator with a sample of the low-level RF output signal from the register on the *Upconverter Module*. The raw data is converted into a scaled value with the following equation:

$$LLRFOUT_{SCALEDVALUE} = (LLRFOUT_{RAWDATA})^2 \cdot LLRFOUT_{SCALEFACTOR}$$

RESONANCE CONDITION: The resonance condition display provides a graphical representation of the resonance condition of the RF cavity, using a marker on a scale. An instantaneous reading, in the form of a complex coefficient, is taken of the resonance frequency error. The imaginary part of the reading is isolated, and used as the basis for positioning the marker. The complex reflection coefficient is calculated from the REFL A, REFL B REFL A + B, and REFL A + jB registers on the *Envelope Detector Module*.

EXIT: When the exit button is pressed, the diagnostic monitor setup panel is closed and replaced with the control system setup modes panel. When the exit button is selected, the operator is prompted to choose one of the following exit functions: save, load, return, or exit. (See section 1.7.6.) Note that when the operator leaves this panel, the current machine state remains active until another mode of operations is entered or the shutdown function is selected.

6. TIMING SUBSYSTEM

6.1 Chapter Overview

This chapter describes the LabVIEW® control panels used to control the timing signals generated for the accelerator control system. Many of the timing signals depend on other timing signals, so automatic update functions have been included to maintain the relative values of the signals. This set of panels is in the control hierarchy under the control system setup modes panel. Illustrations of the panels are provided along with information on how they operate, and what function each control provides.

A distributed system of timing signal generation is used to synchronize the operations of the accelerator. The LLRF system provides timing for: all LLRF modules, the HPRF control rack, the klystron amplifier, the pulse-forming network (PFN), and all other accelerator subsystems (provided by the University of Twente).

The following panels are covered in this chapter:

- The timing status panel provides a complete set of status information on the timing subsystem.
- The timing setup panel contains the controls needed to set up the timing subsystem for all modes of operation.

6.2 Timing Status

The timing status panel provides a complete set of status information on the timing subsystem. (See figure 6-1.) The panel is accessed from the status panel, and appears in its place at the top of the screen. The display contains the current status of all data channels in the timing subsystem, both those providing the internal synchronization of the LLRF equipment, as well as those providing external synchronization of the remaining accelerator subsystems. The external timing signals consist of the ten provided by the *Timing Distribution Module*, and the HPD (high power driver) gate provided by the *Upconverter Module*. The remaining signals are internal signals.

TIMING GRAPH: The graph displays the waveforms of five timing pulses dictated by the user. The pulses to be displayed are chosen using the menu selection boxes to the right of the timing graph, and the time scale can be altered with the time scale and time delay controls. The edge locations are calculated from the delay and width parameters in the timing configuration file including: the RF timing delay, the RF timing width, the delay skew, and the width skew.

The LLRF control system generates two different types of timing signals: fixed width and dependent width. For the fixed width signals:

$$\begin{aligned} \text{leadingedge} &= \text{RFGD} + \text{DS} \\ \text{trailingedge} &= \text{RFGD} + \text{DS} + \text{WS} \end{aligned}$$

Where RFGD is the RF gate timing delay, DS is the delay skew, and WS is the width skew.

Figure 6-1. Timing status panel.

For dependent width signals, the trailing edge is dependent upon the trailing edge of the RF gate. The width skew then becomes the amount of time between the trailing edge of the RF gate and the trailing edge of the timing pulse. Mathematically, this translates to:

$$\begin{aligned} \text{leadingedge} &= \text{RFGD} + \text{DS} \\ \text{trailingedge} &= \text{RFGD} + \text{RFGW} + \text{WS} \end{aligned}$$

Where RFGD is the RF gate timing delay, DS is the delay skew, RFGW is the RF gate timing width, and WS is the width skew.

Additionally, the external signals have an external skew parameter. The external skew compensates for the propagation delays in transmitting the timing signal to a remote location. The effects of this skew are not included in the graph because they are meant to offset system limitations, and be otherwise transparent to the operator and the system.

TIME DELAY: The time delay control specifies the amount of time that passes after the occurrence of the precursory trigger (T0), and before the beginning of the graphical display.

TIME SCALE: The time scale control specifies the resolution of the graphical display by specifying the time span of the graph.

DELAY: Each of the values contained in the delay column is the amount of time elapsed between the occurrence of T0 and the leading edge of the corresponding timing pulse. The five delays correspond to the five pulse names on the left of the timing graph, and will change as the pulse names are changed. There are two types of signal delays used by the LLRF system: internal pulses and external pulses. Figure 6-2 provides examples of the various types of pulses that can be configured.

For the case of internal pulses, the delay is calculated using the following equation:

$$DELAY = RFD + DS$$

Where RFD is the RF timing delay, and DS is the delay skew.

For the case of external pulses, an additional skew term (external skew) is required to compensate for the propagation and circuitry delays caused by external distribution. Because the additional delay is used to compensate for transmission times, it is not apparent to the system, and therefore is not included in the display of the time delay, though it is included when storing data in the appropriate delay register.

WIDTH: Each of the values contained in the width column is the amount of time that the corresponding pulse remains in its active state. The five widths correspond to the five pulse names on the left of the timing graph, and will change as the pulse names are changed. There are two types of pulse-widths used by the LLRF system: those that are fixed, and those that are dependent. Figure 6-2 provides examples of the various types of pulses that can be configured, including both types of widths.

In the case of fixed-width pulses, the pulse width is simply the width skew. The value may only be positive. Thus we get the equation:

$$RFW = WS$$

Where RFW is the RF timing width, and WS is the width skew.

Figure 6-2. Timing pulse examples.

In the case of dependent pulse-widths, the pulse width is based upon the width of the RF gate. Thus the width skew becomes the difference in time between the trailing edge of the RF gate and the trailing edge of the timing pulse. In this case, the width skew may be either positive or negative. A positive width skew means that the timing pulse ends after the RF gate, and a negative width skew means that the timing pulse ends before the RF gate. Mathematically, this translates to:

$$RFW = RFGW - DS + WS$$

Where RFW is the RF timing width, RFGW is the width of the RF gate, DS is the delay skew, and WS is the width skew.

EXIT: When the exit button is pressed, the timing status panel is closed and replaced with the status panel, which is covered in section 2.4.

6.3 Timing Pulse Descriptions

On both of the panels having to do with the timing subsystem, a graph is provided to display several of the timing pulses. Several pulses can be selected for display on a timing graph, allowing them to be compared with each other. Because of limited space on the computer screen, only five can be displayed in the timing graph at any given time. Any of the timing pulses can be displayed in any of the five positions by using the pull-down menus or the left and right arrows to scroll through the list of available pulses. The complete list of the pulses and a brief description of each one follows:

RF GATE: The RF gate pulse is the internal synchronization gate used to pulse-modulate the LLRF output drive signal. The RF gate is an internal timing signal produced by the *Upconverter Module*.

TIMING SPARE 0: This spare timing signal provides an external synchronization signal which has not yet been defined. This is an external timing signal produced by the *Timing Distribution Module*.

- TIMING SPARE 1:** The first spare timing signal provides an external synchronization signal which has not yet been defined. This is an external timing signal produced by the *Timing Distribution Module*.
- TIMING SPARE 2:** The second spare timing signal provides an external synchronization signal which has not yet been defined. This is an external timing signal produced by the *Timing Distribution Module*.
- TIMING SPARE 3:** The third spare timing signal provides an external synchronization signal which has not yet been defined. This is an external timing signal produced by the *Timing Distribution Module*.
- TIMING SPARE 4:** The fourth spare timing signal provides an external synchronization signal which has not yet been defined. This is an external timing signal produced by the *Timing Distribution Module*.
- TIMING SPARE 5:** The fifth spare timing signal provides an external synchronization signal which has not yet been defined. This is an external timing signal produced by the *Timing Distribution Module*.
- TIMING SPARE 6:** The sixth spare timing signal provides an external synchronization signal which has not yet been defined. This is an external timing signal produced by the *Timing Distribution Module*.
- TIMING SPARE 7:** The seventh spare timing signal provides an external synchronization signal which has not yet been defined. This is an external timing signal produced by the *Timing Distribution Module*.
- TIMING SPARE 8:** The eighth spare timing signal provides an external synchronization signal which has not yet been defined. This is an external timing signal and is produced by the *Timing Distribution Module*.
- TIMING SPARE 9:** The ninth spare timing signal provides an external synchronization signal which has not yet been defined. This is an external timing signal and is produced by the *Timing Distribution Module*.
- HPD GATE:** The high power driver gate provides an external synchronization pulse for the high power RF amplifying system. This is an external timing signal produced by the *Upconverter Module*.
- TRIGGER RESET:** The trigger reset pulse causes the turn-on triggers (T1–T3) for the open-loop LLRF output signal to be reset. It is an internal timing signal produced by the *Vector Detector Module*.
- FP WINDOW* I:** The in-phase fast-protection window is a synchronizational window. When active (active-low) it prompts the fast-protection circuitry to turn off the LLRF output when the in-phase signal becomes too far from its setpoint value. This is an internal timing signal produced by the *I Controller Module*.
- DSTRB GATE I:** The in-phase disturbance gate provides a synchronizational gate which enables a disturbance signal to be added to the in-phase control signal. It is generally used as a diagnostic signal to determine how the system will react to a given signal fluctuation. This is an internal timing signal produced by the *I Controller Module*.

FP WINDOW* Q: The quadrature fast-protection window is a synchronizational window. When active (active-low) it prompts the fast-protection circuitry to turn off the LLRF output when the quadrature signal becomes too far from its setpoint value. This is an internal timing signal produced by the *Q Controller Module*.

DSTRB GATE Q: The quadrature disturbance gate provides a synchronizational gate which enables a disturbance signal to be added to the quadrature control signal. It is generally used as a diagnostic signal to determine how the system will react to a given signal fluctuation. This is an internal timing signal produced by the *Q Controller Module*.

AFF ERR GATE I: The adaptive feedforward in-phase error gate enables the adaptive feedforward process to occur on the in-phase error signal. This is an internal timing signal produced by the *Adaptive Feedforward Module*.

AFF ERR GATE Q: The adaptive feedforward quadrature error gate enables the adaptive feedforward process to occur on the quadrature error signal. This is an internal timing signal produced by the *Adaptive Feedforward Module*.

SMPL LLRF OUT: The LLRF output sample pulse is used to capture the HPRF amplifier drive signal, which is converted into a digital bit-set. It is an internal timing signal produced by the *Upconverter Module*.

SAMPLE FIELD: The field sampling pulse is used to capture the cavity field readback signal, which is converted into a digital bit-set. It is an internal timing signal produced by the *Vector Detector Module*.

SAMPLE DRIVE: The drive sampling pulse is used to capture the cavity drive readback signal, which is converted into a digital bit-set. It is an internal timing signal produced by the *Vector Detector Module*.

SAMPLE A: The 'a' sampling pulse is used to capture the reflectometer 'a' (forward drive) signal, which is converted into a digital bit-set. It is an internal timing signal produced by the *Envelope Detector Module*.

SAMPLE B: The 'b' sampling pulse is used to capture the reflectometer 'b' (reverse drive) signal, which is converted into a digital bit-set. It is an internal timing signal produced by the *Envelope Detector Module*.

SAMPLE A + B: The 'a + b' sampling pulse is used to capture the reflectometer 'a + b' (forward + reverse drive) signal, which is converted into a digital bit-set. It is an internal timing signal produced by the *Envelope Detector Module*.

SAMPLE A + jB: The 'a + jb' sampling pulse is used to capture the reflectometer 'a + jb' (forward + reverse drive) signal, which is converted into a digital bit-set. It is an internal timing signal produced by the *Envelope Detector Module*.

SMPL CPLR FWD: The coupler forward sampling pulse is used to capture the directional coupler forward-drive signal, which is then converted into a digital bit-set. It is an internal timing signal produced by the *Envelope Detector Module*.

SMPL CPLR RVS: The coupler reverse sampling pulse is used to capture the directional coupler reverse-drive signal, which is then converted into a digital bit-set. It is an internal timing signal produced by the *Envelope Detector Module*.

SMPL ENV SPR 1: The spare envelope channel 1 sampling pulse is used to capture the first spare envelope detector channel, which is then converted into a digital bit-set. It is an internal timing signal produced by the *Envelope Detector Module*.

SMPL ENV SPR 2: The spare envelope channel 2 sampling pulse is used to capture the second spare envelope detector channel, which is then converted into a digital bit-set. It is an internal timing signal produced by the *Envelope Detector Module*.

6.4 Timing Setup Panel

The timing setup panel, illustrated in figure 6-3, provides the control and monitor fields used in the setup of the timing subsystem. Much of the setup operation is automated and runs in the background, transparent to the user.

The timing setup panel is entered from the control system setup modes panel. Upon entering the panel, several configuration files are automatically loaded into the control software. First, the resonance detection, field control, diagnostic monitor, timing, and alarm & limit configuration files are loaded. They provide the hardware configuration data which is needed to define the normal mode of operation. Next, the global files for the reflectometer calibration, gain schedule, and diagnostic signal list are also loaded. This is done to provide the hardware-specific setup data common to all modes of operation. Finally, the operator is asked if the default file for the timing setup mode will be used. If it is not, the user is asked to provide the name of the file that will be used. The data in this file is displayed on, and is adjustable from, the timing setup panel. Each mode of operation requires a unique set of timing signals that will need to be determined and stored separately.

The remainder of this section is dedicated to describing the control and monitor points on the timing setup panel. Generally, the control descriptions are listed as the controls appear on the panel, from the upper-left to the lower-right. Where the controls are grouped, each control in the group is discussed before proceeding on to the next group.

CHANNEL SETUP SIGNAL NAME: The signal name control allows the user to select which one of the timing signals is to be configured. The name of a timing channel can be accessed with a pull-down menu, or by scrolling through the names with the left and right arrows. Note that the RF gate pulse can not be adjusted with the channel setup controls, because this functionality is provided by the controls in the RF timing box.

CHANNEL SETUP ACTIVE: This control displays the current active truth for the selected signal, and allows the user to alter it if desired.

Figure 6-3. Timing setup panel.

CHANNEL SETUP DELAY SKEW: The delay skew controls how much time will elapse between the RF gate going active and the selected timing pulse going active. The delay skew can be either positive or negative. If it is positive the timing pulse will start after the RF gate has started, if it is negative the timing pulse will start before the RF gate has started. There are two types of signal delays used by the LLRF system: internal pulse delays and external pulse delays. Figure 6-2 provides examples of the various types of pulses that can be configured.

In the case of internal pulses, the delay is calculated using the following equation:

$$RFD = RFGD + DS$$

Where RFD is the RF timing-pulse delay, RFGD is the RF gate delay, and DS is the delay skew.

In the case of external pulses, an additional skew term (external skew) is required to compensate for the propagation and circuitry delays caused by external distribution. Because the additional delay is used to compensate for transmission times, it is not apparent to the system, and therefore is not included in the display of the time delay, though it is included when storing data in the appropriate delay register.

Once the RF timing-pulse delay has been calculated, the number of clock cycles for the delay of that timing channel must be determined. The timing subsystem bases its signals on a 5 MHz clock, so the timing resolution is 200 ns. The RF timing delay is converted as shown in the following equation:

$$delaycycles_{RFG} = \frac{RFD}{200ns}$$

CHANNEL SETUP WIDTH TYPE: The width type control displays the current type of width used for the selected signal: off, fixed, or dependent. If desired, the user can change the type of width for the selected signal.

If the selected width type is off, then the pulse defaults to a fixed configuration. The width skew becomes the width of the active period of the timing pulse.

If the width type is fixed, then the width skew becomes the width of the active period of the timing pulse.

If the width type is dependent, then the width skew becomes the difference in time between the trailing edge of the RF gate and the trailing edge of the timing pulse.

CHANNEL SETUP WIDTH SKEW: The width skew of a timing pulse is used to determine the length of time that the pulse remains in its active state. There are two types of pulse-widths used by the LLRF system: those that are fixed, and those that are dependent. Figure 6-2 provides examples of the various types of pulses that can be configured, including both types of widths.

In the case of fixed-width pulses, the pulse width is simply the width skew. The value may only be positive. Thus we get the equation:

$$RFW = WS$$

Where RFW is the RF timing-pulse width, and WS is the width skew.

In the case of dependent pulse-widths, the pulse width is based upon the width of the RF gate. Thus the width skew (which is displayed on the panel as RF timing width) becomes the difference in time between the trailing edge of the RF gate and the trailing edge of the timing pulse. In this case, the width skew may be either positive or negative. A positive width skew means that the timing pulse ends after the RF gate, and a negative width skew means that the timing pulse ends before the RF gate. Mathematically, this translates to:

$$RFW = RFGW - DS + WS$$

Where RFW is the RF timing-pulse width, RFGW is the width of the RF gate, DS is the delay skew, and WS is the width skew.

Once the RF timing-pulse width has been calculated, the required number of clock cycles for the width of that timing channel must be determined. The timing subsystem bases its signals on a 5 MHz clock, so the timing resolution is 200 ns. The RF timing width is converted as shown in the following equation:

$$widthcycles_{RF} = \frac{RFW}{200ns}$$

TIMING GRAPH: The graph displays the waveforms of five timing pulses dictated by the user. The pulses to be displayed are chosen using the menu selection boxes to the right of the timing graph, and the time scale can be altered with the time scale and time delay controls. The edge locations are calculated from the delay and width parameters in the timing configuration file including: the RF timing delay, the RF timing width, the delay skew, and the width skew.

The LLRF control system generates two different types of timing signals: fixed width and dependent width. For the fixed width signals:

$$\begin{aligned} leadingedge &= RFGD + DS \\ trailingedge &= RFGD + DS + WS \end{aligned}$$

Where RFGD is the RF gate timing delay, DS is the delay skew, and WS is the width skew.

For dependent width signals, the trailing edge is dependent upon the trailing edge of the RF gate. The width skew then becomes the amount of time between the trailing edge of the RF gate and the trailing edge of the timing pulse. Mathematically, this translates to:

$$\begin{aligned} leadingedge &= RFGD + DS \\ trailingedge &= RFGD + RFGW + WS \end{aligned}$$

Where RFGD is the RF gate timing delay, DS is the delay skew, RFGW is the RF gate timing width, and WS is the width skew.

Additionally, the external signals have an external skew parameter. The external skew compensates for the propagation delays in transmitting the timing signal to a remote location. The effects of this skew are not included in the graph because they are meant to offset system limitations, and be otherwise transparent to the operator and the system.

TIME DELAY: The time delay control specifies the amount of time that passes after the occurrence of the precursory trigger (T0), and before the beginning of the graphical display.

TIME SCALE: The time scale control specifies the resolution of the graphical display by specifying the time span of the graph.

WARNING: This is a yellow status display light which provides the warning status for the system. When lit, one or more warnings have been activated. When not lit, no warnings are active in the system. The various warnings are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

ALARM: This is a red status display light which provides the alarm status for the system. When lit, one or more alarms have been activated. When not lit, no alarms are active in the system. The various alarms are discussed in chapter seven, which covers the control panels for the alarm & limit subsystem.

RF TIMING DELAY: The RF timing delay is used to adjust the time-position of the cavity RF field in the RF cycle. Since the precursory trigger (T0) indicates the beginning of an RF cycle, the RF timing delay is defined as the length of time between the leading edge of T0 and the leading edge of the RF gate. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. Thus the number of clock cycles in the delay period is determined as follows:

$$\text{delaycycles} = \frac{\text{RFGD}}{200\text{ns}}$$

Where RFGD is the RF gate delay.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The delays of all other timing pulses are derived from the RF gate delay. Consequently, as the RFGD is adjusted, all other timing signals track the change. This is explained further in section 6.4, which is about the timing setup.

RF TIMING WIDTH: The RF timing width is used to adjust the length of time that the RF field exists in the cavity. This is done by altering the width of the RF gate pulse, which is displayed as the RF timing width. The timing circuitry uses a 5 MHz clock, so is limited to a 200 ns resolution. The number of clock cycles that pass while the RF gate is active is determined as follows:

$$\text{widthcycles} = \frac{\text{RFGW}}{200\text{ns}}$$

Where RFGW is the RF gate width.

The RF gate timing signal is an internal synchronization gate used to pulse-modulate the LLRF output drive signal. This key timing signal controls when an RF field will exist in the cavity, and for how long. The widths of all dependent-type timing pulses are derived from the width of the RF gate. Consequently, as RFGW is adjusted, all dependent pulses track the change. This is explained further in section 6.4, which is about the timing setup.

EXT SKEW: The external skew control allows the operator to define the skew term used to compensate for the propagation and circuitry delays of those signals distributed externally. The external skew is used to adjust the number of delay cycles necessary for the proper synchronization of external timing signals.

DIAGNOSTIC MONITOR CH 1: The diagnostic monitor channel 1 control allows the selection of which diagnostic signal is to drive channel one of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first dis-

ables whatever signal was previously driving bus channel 1, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

DIAGNOSTIC MONITOR CH 2: The diagnostic monitor channel 2 control allows the selection of which diagnostic signal is to drive channel two of the diagnostic monitor bus. The selection is provided via a pull-down menu listing all applicable signals. When a new diagnostic signal is selected, the software first disables whatever signal was previously driving bus channel 2, then enables the newly selected signal. This prevents two separate signals from driving the same bus channel simultaneously. A list of the available diagnostic signals is found in section 5.1.

EXIT: When the exit button is pressed, the timing setup panel is closed and replaced with the control system setup modes panel. When the exit button is selected, the operator is prompted to choose one of the following exit functions: save, load, return, or exit. (See section 1.7.6.) Note that when this panel is left, the current machine state remains active until another mode of operations is entered or the shutdown function is selected.

7. ALARM & LIMIT SUBSYSTEM

7.1 Chapter Overview

This chapter describes the LabVIEW® software control panels used to control the alarm & limit subsystem. This set of panels is in the control hierarchy under the control system setup modes panel. Illustrations of the panels are provided along with information on how they operate, and what function each control provides.

The panels covered in this chapter include:

- The alarm & limit status panel contains a complete set of status information on the alarm & limit subsystem. The display identifies all alarms and warnings detected by the LLRF system.
- The alarm & limit setup panel provides the operator with the control and monitor points allowing the alarm & limit subsystem to be set up for operation.

7.2 Alarm & Limit Status Panel

The alarm and limit status panel contains a complete set of status information on the alarm and limit subsystem. (See figure 7-1.) The panel is accessed from the status panel, and appears in its place at the top of the screen. The display shows the current status of all data channels in the subsystem, some with a graphical representation as well as a numerical value. Specifically, the panel provides the following:

VDM TEMPERATURE, WARNING: The *Vector Detector Module* temperature warning is lit when components on that module are not operating within their nominal temperature range. The module informs the system by driving the temperature fault bit low.

RF PULSE WIDTH LONG, WARNING: This warning is lit if the width of the RF enable pulse exceeds that of the RF pulse warning trip threshold. This indicates that the width of the RF pulse in the cavity is too long for the current mode of operation.

FORWARD POWER HIGH, WARNING: This warning is lit if the forward drive power is in excess of the forward power warning trip threshold. This indicates that the forward power level is too high for the current mode of operation. The software obtains a reading of the forward drive power from the following equation:

$$FWDP = (REFLA)^2 \cdot RASF$$

Where FWDP is the forward drive power, REFL A is the reflectometer 'a' signal, and RASF is the reflectometer 'a' scale factor.

Figure 7-1. Alarm & limit status panel.

REVERSE POWER HIGH, WARNING: This warning is lit if the reverse drive power level is in excess of the reverse power warning trip threshold. This indicates that the reverse power level is too high for the current mode of operation. A reading of the reverse power is obtained from the following equation:

$$RVSP = (REFLB)^2 \cdot RBSF$$

Where RVSP is the reverse drive power, REFL B is the reflectometer 'b' signal, and RBSF is the reflectometer 'b' scale factor.

CAVITY AMPLITUDE HIGH, WARNING: This warning is lit if the cavity field amplitude exceeds the cavity amplitude warning trip threshold. This indicates that the cavity voltage level is too high for the current mode of operation. A reading of the cavity amplitude is determined from the following equation:

$$ARB = \sqrt{(FIELDI \cdot SFT)^2 + (FIELDQ \cdot SFQ)^2}$$

Where ARB is the cavity amplitude readback, FIELD I is the in-phase component of the cavity field, FIELD Q is the quadrature component of the cavity field, SFI is the in-phase scale factor, and SFQ is the quadrature scale factor.

LLRF OUTPUT HIGH, WARNING: This warning is lit if the LLRF output signal exceeds its warning trip threshold. This indicates that the LLRF output power to the HPRF amplifier is too high for the current mode of operation. The readback of the LLRF output is determined from the following equation:

$$LLRFOUT = (LORD)^2 \cdot LOSF$$

Where LLRF OUT is the LLRF output signal, LORD is the LLRF output raw data, and LOSF is the LLRF output scale factor.

REFERENCE FAULT, ALARM: The reference fault alarm is lit if the RF reference signal is somehow degraded. It is indicated by a low level in the reference fault bit on the *Downconverter Module*.

LOSS OF TRIGGER, ALARM: The loss of trigger alarm is lit if 10 seconds pass without the occurrence of the T0 precursory trigger. It is indicated by a low level in the trigger loss bit on the *Timing Receiver Module*.

LOSS OF CLOCK, ALARM: The loss of clock alarm is lit if the 10 MHz master clock signal is somehow degraded. It is indicated by a low level in the clock loss bit on the *Timing Receiver Module*.

RF PULSE WIDTH LONG, ALARM: The RF pulse width long alarm is lit if the length of the RF enable pulse exceeds its alarm trip threshold. It indicates that the width of the RF pulse in the cavity is too long for the current mode of operation.

FORWARD POWER HIGH, ALARM: The forward power high alarm is lit if the forward drive power is in excess of its alarm trip threshold. It indicates that the forward power level is excessive. A reading of the forward drive power is obtained from the following equation:

$$FWDP = (REFLA)^2 \cdot RASF$$

Where FWDP is the forward drive power, REFL A is the reflectometer 'a' signal, and RASF is the reflectometer 'a' scale factor.

REVERSE POWER HIGH, ALARM: The reverse power high alarm is lit if the reverse drive power is in excess of its alarm trip threshold. It indicates that the reverse power level is excessive. A reading of the reverse power is obtained from the following equation:

$$RVSP = (REFLB)^2 \cdot RBSF$$

Where RVSP is the reverse power, REFL B is the reflectometer 'b' signal, and RBSF is the reflectometer 'b' scale factor.

CAVITY AMPLITUDE HIGH, ALARM: The cavity amplitude high alarm is lit if the cavity field amplitude exceeds its trip threshold. This indicates that the cavity voltage level is too high for the current mode of operation. A reading of the cavity amplitude is obtained from the following equation:

$$ARB = \sqrt{(FIELDI \cdot SFI)^2 + (FIELDQ \cdot SFQ)^2}$$

Where ARB is the cavity amplitude readback, FIELD I is the in-phase component of the cavity field, FIELD Q is the quadrature component of the cavity field, SFI is the in-phase scale factor, and SFQ is the quadrature scale factor.

LLRF OUTPUT HIGH, ALARM: This alarm is lit if the LLRF output signal exceeds its alarm trip threshold. This indicates that the LLRF output power to the HPRF amplifier is too high for the current mode of operation. The LLRF output level is determined from the following equation:

$$LLRFOUT = (LORD)^2 \cdot LOSF$$

Where LLRF OUT is the LLRF output signal, LORD is the LLRF output raw data, and LOSF is the LLRF output scale factor.

RF PULSE WIDTH WARNING/ALARM TRIP THRESHOLDS: This display lists the warning and alarm thresholds of the RF pulse width. Should the RF pulse width exceed the warning value, the warning signal will become active. Similarly, if the RF pulse width exceeds the alarm value, the alarm signal will become active.

FWD POWER READBACK WARNING/ALARM TRIP THRESHOLDS: This display lists the warning and alarm thresholds of the forward power readback signal. Should the forward power readback level exceed the warning value, the warning signal will become active. Similarly, if the forward power readback level exceeds the alarm value, the alarm signal will become active.

RVS POWER READBACK WARNING/ALARM TRIP THRESHOLDS: This display lists the warning and alarm thresholds of the reverse power readback signal. Should the reverse power readback level exceed the warning value, the warning signal will become active. Similarly, if the reverse power readback level exceeds the alarm value, the alarm signal will become active.

CAV AMPLITUDE READBACK WARNING/ALARM TRIP THRESHOLDS: This display lists the warning and alarm thresholds of the cavity amplitude readback signal. Should the cavity amplitude readback level exceed the warning value, the warning signal will become active. Similarly, if the cavity amplitude readback level exceeds the alarm value, the alarm signal will become active.

LLRF OUTPUT READBACK WARNING/ALARM TRIP THRESHOLDS: This display lists the warning and alarm thresholds of the LLRF output readback signal. Should the LLRF output exceed the warning value, the warning signal will become active. Similarly, if the LLRF output exceeds the alarm value, the alarm signal will become active.

HARDWARE DRIVE I LIMIT (+): The positive hardware in-phase drive limit is displayed as a numerical value. The control system limits the in-phase output magnitude to this value or less. The limit is derived from the physical limitations of the accelerator hardware, and implemented to avoid damaging equipment and personnel.

HARDWARE DRIVE I LIMIT (-): The negative hardware in-phase drive limit is displayed as a numerical value. The control system limits the in-phase output magnitude to this value or more. The limit is derived from the physical limitations of the accelerator hardware, and implemented to avoid damaging equipment and personnel.

HARDWARE DRIVE Q LIMIT (+): The positive hardware quadrature drive limit is displayed as a numerical value. The control system limits the quadrature output magnitude to this value or less. The limit is derived from the physical limitations of the accelerator hardware, and implemented to avoid damaging equipment and personnel.

HARDWARE DRIVE Q LIMIT (-): The negative hardware quadrature drive limit is displayed as a numerical value. The control system limits the quadrature output magnitude to this value or more. The limit is derived from the physical limitations of the accelerator hardware, and implemented to avoid damaging equipment and personnel.

OPERATING REGION: This display provides a graphical representation of the hardware limits: positive and negative, in-phase and quadrature. Additionally, a vector representation of the current amplitude setpoint is overlaid upon it.

FAST PROTECTION TRIP THRESHOLD - I ERROR: This display provides the numeric value currently being used as the fast protection threshold of the in-phase error signal. If the value of the in-phase error ever exceeds this threshold, the LLRF output signal will be disabled immediately by the control system.

FAST PROTECTION TRIP THRESHOLD - Q ERROR: This display provides the numeric value currently being used as the fast protection threshold for the quadrature error signal. If the value of the quadrature error ever exceeds this threshold, the LLRF output signal will be disabled immediately by the control system.

CONFIGURATION FILE: The configuration file display lists the name of the currently active alarm & limit configuration file.

RESET ALARMS: When an alarm causes the system to be shut down, the alarm remains latched. This keeps the system shut down until the problem can be remedied, then reset manually. This button provides the manual alarm reset functionality.

EXIT: This control button closes the display for the alarm & limit status panel, replacing it with the status panel (covered in section 2.4).

7.3 Alarm & Limit Setup Panel

The alarm & limit setup panel, illustrated in figure 7-2, contains the capability of controlling and monitoring the setup of the alarm & limit subsystem. Much of the setup operations are automated and run in the background, transparent to the user.

Figure 7-2. Alarm & limit setup panel.

The alarm & limit setup panel is entered from the control system setup modes panel. Upon entering the panel, several configuration files are automatically loaded into the control software. First, the resonance detection, field control, diagnostic monitor, timing, and alarm & limit configuration files are loaded. They provide the hardware configuration data which is needed to define the normal mode of operation. Next, the global files for the reflectometer calibration, gain schedule, and diagnostic signal list are also loaded. This is done to provide the hardware-specific setup data common to all modes of operation. Finally, the operator is asked if the default file for the alarm & limit setup mode will be used. If it is not, the user is asked to provide the name of the file that will be used. The data in this file is displayed on, and is adjustable from, the alarm & limit setup panel.

The remainder of this section is dedicated to describing the control and monitor points on the alarm & limit setup panel. Generally, the control descriptions are listed as the controls appear on the panel, from the upper-left to the lower-right. Where the controls are grouped, each control in the group is discussed before proceeding on to the next group.

VDM TEMPERATURE, WARNING: The *Vector Detector Module* temperature warning is lit when components on that module are not operating within their nominal temperature range. The module informs the system by driving the temperature fault bit low.

RF PULSE WIDTH LONG, WARNING: This warning is lit if the width of the RF enable pulse exceeds that of the RF pulse warning trip threshold. This indicates that the width of the RF pulse in the cavity is too long for the current mode of operation.

FORWARD POWER HIGH, WARNING: This warning is lit if the forward drive power is in excess of the forward power warning trip threshold. This indicates that the forward power level is too high for the current mode of operation. The software obtains a reading of the forward drive power from the following equation:

$$FWDP = (REFLA)^2 \cdot RASF$$

Where FWDP is the forward drive power, REFL A is the reflectometer 'a' signal, and RASF is the reflectometer 'a' scale factor.

REVERSE POWER HIGH, WARNING: This warning is lit if the reverse drive power level is in excess of the reverse power warning trip threshold. This indicates that the reverse power level is too high for the current mode of operation. A reading of the reverse power is obtained from the following equation:

$$RVSP = (REFLB)^2 \cdot RBSF$$

Where RVSP is the reverse drive power, REFL B is the reflectometer 'b' signal, and RBSF is the reflectometer 'b' scale factor.

CAVITY AMPLITUDE HIGH, WARNING: This warning is lit if the cavity field amplitude exceeds the cavity amplitude warning trip threshold. This indicates that the cavity voltage level is too high for the current mode of operation. A reading of the cavity amplitude is determined from the following equation:

$$ARB = \sqrt{(FIELDI \cdot SFI)^2 + (FIELDQ \cdot SFQ)^2}$$

Where ARB is the cavity amplitude readback, FIELD I is the in-phase component of the cavity field, FIELD Q is the quadrature component of the cavity field, SFI is the in-phase scale factor, and SFQ is the quadrature scale factor.

LLRF OUTPUT HIGH, WARNING: This warning is lit if the LLRF output signal exceeds its warning trip threshold. This indicates that the LLRF output power to the HPRF amplifier is too high for the current mode of operation. The readback of the LLRF output is determined from the following equation:

$$LLRFOUT = (LORD)^2 \cdot LOSF$$

Where LLRF OUT is the LLRF output signal, LORD is the LLRF output raw data, and LOSF is the LLRF output scale factor.

REFERENCE FAULT, ALARM: The reference fault alarm is lit if the RF reference signal is somehow degraded. It is indicated by a low level in the reference fault bit on the *Downconverter Module*.

LOSS OF TRIGGER, ALARM: The loss of trigger alarm is lit if 10 seconds pass without the occurrence of the T0 precursory trigger. It is indicated by a low level in the trigger loss bit on the *Timing Receiver Module*.

LOSS OF CLOCK, ALARM: The loss of clock alarm is lit if the 10 MHz master clock signal is somehow degraded. It is indicated by a low level in the clock loss bit on the *Timing Receiver Module*.

RF PULSE WIDTH LONG, ALARM: The RF pulse width long alarm is lit if the length of the RF enable pulse exceeds its alarm trip threshold. It indicates that the width of the RF pulse in the cavity is too long for the current mode of operation.

FORWARD POWER HIGH, ALARM: The forward power high alarm is lit if the forward drive power is in excess of its alarm trip threshold. It indicates that the forward power level is excessive. A reading of the forward drive power is obtained from the following equation:

$$FWDP = (REFLA)^2 \cdot RASF$$

Where FWDP is the forward drive power, REFL A is the reflectometer 'a' signal, and RASF is the reflectometer 'a' scale factor.

REVERSE POWER HIGH, ALARM: The reverse power high alarm is lit if the reverse drive power is in excess of its alarm trip threshold. It indicates that the reverse power level is excessive. A reading of the reverse power is obtained from the following equation:

$$RVSP = (REFLB)^2 \cdot RBSF$$

Where RVSP is the reverse power, REFL B is the reflectometer 'b' signal, and RBSF is the reflectometer 'b' scale factor.

CAVITY AMPLITUDE HIGH, ALARM: The cavity amplitude high alarm is lit if the cavity field amplitude exceeds its trip threshold. This indicates that the cavity voltage level is too high for the current mode of operation. A reading of the cavity amplitude is obtained from the following equation:

$$ARB = \sqrt{(FIELDI \cdot SFI)^2 + (FIELDQ \cdot SFQ)^2}$$

Where ARB is the cavity amplitude readback, FIELD I is the in-phase component of the cavity field, FIELD Q is the quadrature component of the cavity field, SFI is the in-phase scale factor, and SFQ is the quadrature scale factor.

LLRF OUTPUT HIGH, ALARM: This alarm is lit if the LLRF output signal exceeds its alarm trip threshold. This indicates that the LLRF output power to the HPRF amplifier is too high for the current mode of operation. The LLRF output level is determined from the following equation:

$$LLRFOUT = (LORD)^2 \cdot LOSF$$

Where LLRF OUT is the LLRF output signal, LORD is the LLRF output raw data, and LOSF is the LLRF output scale factor.

RF PULSE WIDTH WARNING/ALARM TRIP THRESHOLDS: These controls list the warning and alarm thresholds of the RF pulse width. Should the RF pulse width exceed the warning value, the warning signal will become active. Similarly, if the RF pulse width exceeds the alarm value, the alarm signal will become active.

FWD POWER READBACK WARNING/ALARM TRIP THRESHOLDS: These controls list the warning and alarm thresholds of the forward power readback signal. Should the forward power readback level exceed the warning value, the warning signal will become active. Similarly, if the forward power readback level exceeds the alarm value, the alarm signal will become active.

RVS POWER READBACK WARNING/ALARM TRIP THRESHOLDS: These controls list the warning and alarm thresholds of the reverse power readback signal. Should the reverse power readback level exceed the warning value, the warning signal will become active. Similarly, if the reverse power readback level exceeds the alarm value, the alarm signal will become active.

CAV AMPLITUDE READBACK WARNING/ALARM TRIP THRESHOLDS: These controls list the warning and alarm thresholds of the cavity amplitude readback signal. Should the cavity amplitude readback level exceed the warning value, the warning signal will become active. Similarly, if the cavity amplitude readback level exceeds the alarm value, the alarm signal will become active.

LLRF OUTPUT READBACK WARNING/ALARM TRIP THRESHOLDS: These controls list the warning and alarm thresholds of the LLRF output readback signal. Should the LLRF output exceed the warning value, the warning signal will become active. Similarly, if the LLRF output exceeds the alarm value, the alarm signal will become active.

HARDWARE DRIVE I LIMIT (+): The positive hardware in-phase drive limit is displayed as a numerical value. The control system limits the in-phase output magnitude to this value or less. The limit is derived from the physical limitations of the accelerator hardware, and implemented to avoid damaging equipment and personnel.

HARDWARE DRIVE I LIMIT (-): The negative hardware in-phase drive limit is displayed as a numerical value. The control system limits the in-phase output magnitude to this value or more. The limit is derived from the physical limitations of the accelerator hardware, and implemented to avoid damaging equipment and personnel.

HARDWARE DRIVE Q LIMIT (+): The positive hardware quadrature drive limit is displayed as a numerical value. The control system limits the quadrature output magnitude to this value or less. The limit is derived from the physical limitations of the accelerator hardware, and implemented to avoid damaging equipment and personnel.

HARDWARE DRIVE Q LIMIT (-): The negative hardware quadrature drive limit is displayed as a numerical value. The control system limits the quadrature output magnitude to this value or more. The limit is derived from the physical limitations of the accelerator hardware, and implemented to avoid damaging equipment and personnel.

OPERATING REGION: This display provides a graphical representation of the hardware limits: positive and negative, in-phase and quadrature. Additionally, a vector representation of the current amplitude setpoint is overlaid upon it.

FAST PROTECTION TRIP THRESHOLD - I ERROR: This control sets the value of the fast protection threshold of the in-phase error signal. If the value of the in-phase error ever exceeds this threshold, the LLRF output signal will be disabled immediately by the control system. The value is entered as a percentage (with a full scale of 10%) that scales the output to the DAC register (i.e. 10% = 4095, 5% = 2048, 0% = 0).

FAST PROTECTION TRIP THRESHOLD - Q ERROR: This control sets the value of the fast protection threshold for the quadrature error signal. If the value of the quadrature error ever exceeds this threshold, the LLRF output signal will be disabled immediately by the control system. The value is entered as a percentage (with a full scale of 10%) that scales the output to the DAC register (i.e. 10% = 4095, 5% = 2048, 0% = 0).

EXIT: When the exit button is pressed, the timing setup panel is closed and replaced with the timing setup mode panel. When the exit button is selected, the operator is prompted to choose one of the following exit functions: save, load, return, or exit. (See section 1.7.6.) Note that when this panel is left, the current machine state remains active until another mode of operations is entered or the shutdown function is selected.

This report has been reproduced directly from the
best available copy.

It is available to DOE and DOE contractors from the
Office of Scientific and Technical Information,
P.O. Box 62,
Oak Ridge, TN 37831.
Prices are available from
(615) 576-8401, FTS 626-8401.

It is available to the public from the
National Technical Information Service,
U.S. Department of Commerce,
5285 Port Royal Rd.,
Springfield, VA 22161.