ENGINEERING CHANGE NOTICE

Page 1 of 21. ECN **636514**Proj.
ECN

2. ECN Category (mark one) Supplemental ☐ Direct Revision ☒ Change ECN ☐ Temporary ☐ Standby ☐ Supersedeure ☐ Cancel/Void ☐	3. Originator's Name, Organization, MSIN, and Telephone No. JD Robinson, 75230, S7-12, 376-4777 6. Project Title/No./Work Order No. Rotary Mode Core Sampling 9. Document Numbers Changed by this ECN (includes sheet no. and rev.) WHC-SD-WM-CSDD-020, Rev. 0	4. USQ Required? ☒ Yes ☐ No 7. Bldg./Sys./Fac. No. 241G 10. Related ECN No(s). N/A	5. Date September 19, 1996 8. Approval Designator Q 11. Related PO No. N/A
12a. Modification Work ☐ Yes (fill out Blk. 12b) ☒ No (NA Blks. 12b, 12c, 12d)	12b. Work Package No. N/A	12c. Modification Work Complete N/A Design Authority/Cog. Engineer Signature & Date	12d. Restored to Original Condition (Temp. or Standby ECN only) N/A Design Authority/Cog. Engineer Signature & Date
13a. Description of Change This Direct Revision describes software changes that will allow operators to differentiate between hydrogen rate of rise and hydrogen concentration alarms. Also described are the changes required to make separate alarms for flammable gas concentration and flammable gas rate of rise. Data collection intervals for background tank pressure have been reduced from six minutes to five minutes. 13b. Design Baseline Document? ☒ Yes ☐ No			
14a. Justification (mark one) Criteria Change ☒ Design Improvement ☐ Environmental ☐ Facility Deactivation ☐ As-Found ☐ Facilitate Const ☐ Const. Error/Omission ☐ Design Error/Omission ☐			
14b. Justification Details These changes will allow easier daily functional checks and help operators differentiate between alarm types.			
This ECN covered by USQ TF-96-226, Rev. 1 15. Distribution (include name, MSIN, and no. of copies) EJ Waldo S7-12 (1) Central Files A3-88 (1) JD Robinson S7-12 (1) ML McCloy S7-07 (1) TH Smith S7-12 (1) EE Salinas S7-12 (1)

636514

A-7900-013-3 (05/96) GEF096

FLAMMABLE GAS TANK EXHAUSTER INTERLOCK (FGTEI) COMPUTER SOFTWARE DESIGN DESCRIPTION

SO Smith/RW Truitt
Westinghouse Hanford Company, Richland, WA 99352
U.S. Department of Energy Contract DE-AC06-87RL10930

ECN: 636514 UC: 2070
Org Code: 75230 Charge Code: N4HBB
B&R Code: EW3120074 Total Pages: 7

Key Words: Flammable gas tank exhaust interlock, (FGTEI), software design.

Abstract: Modicon Compact Programmable Logic Controller (PLC). The device configuration integrates the isolation and current-carrying capacities of mechanical relays with the logic and programming sophistication of the PLC.

This revised document provides descriptions of components and tasks involved in the PLC system for controlling and monitoring the FGTEI. All control functions required by the PLC, and how they are implemented, are described in detail.

TRADEMARK DISCLAIMER. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof or its contractors or subcontractors.

Printed in the United States of America. To obtain copies of this document, contact: WHC/BCS Document Control Services, P.O. Box 1970, Mailstop H6-08, Richland WA 99352, Phone (509) 372-2420; Fax (509) 376-4989.

Kara J. Bro 9/20/96
Release Approval Date
Release Stamp

Approved for Public Release

FLAMMABLE GAS TANK EXHAUSTER INTERLOCK
(FGTEI)
COMPUTER SOFTWARE DESIGN DESCRIPTION

September 12, 1996

Samuel O. Smith
Ross W. Truitt

PLCs Plus
for
WESTINGHOUSE HANFORD COMPANY

TABLE OF CONTENTS

1.0 INTRODUCTION	2
2.0 HARDWARE CONFIGURATION	2
3.0 OPERATION	2
3.1 GENERAL	2
3.2 SEQUENCE OF OPERATION	3
4.0 PLC SOFTWARE DESCRIPTION	9
4.1 GENERAL	9
4.2 LADDER LOGIC NETWORK DESCRIPTIONS	9
APPENDIX A	23
I/O Channel List	23
APPENDIX B	27
Reference Symbol Table	27
APPENDIX C	32
PLC System Configuration	32
APPENDIX D	35
Ladder Logic Network Diagrams	36
APPENDIX E	54
Coil/Register Utilization Tables	55
APPENDIX F	67
ADU206 Control Register Reference	68

FLAMMABLE GAS TANK EXHAUSTER INTERLOCK (FGTEI) COMPUTER SOFTWARE DESIGN DESCRIPTION

1.0 INTRODUCTION

The Flammable Gas Tank Exhauster Interlock (FGTEI) is controlled by a Modicon Compact Programmable Logic Controller (PLC). The device configuration integrates the isolation and current-carrying capacities of mechanical relays with the logic and programming sophistication of the PLC.

This document provides descriptions of components and tasks involved in the PLC system for controlling and monitoring the FGTEI. All control functions required by the PLC, and how they are implemented, are described in detail.

2.0 HARDWARE CONFIGURATION

As shown on drawings H-14-100519 and H-14-100520, the FGTEI PLC system is comprised of the following:

- 2 backplane housings (HDTA-200 and HDTA 201)
- 1 controller module (A984-145)
- 2 power supplies (P120)
- 1 120 VAC 16-channel discrete input module (DEP218)
- 2 120 VAC 16-channel discrete output modules (DAP218)
- 2 4-20 mA 4-channel analog input modules (ADU206)

Appendix A lists the specific backplane I/O slots for each module.

Each component has been carefully chosen, based on its capabilities, to perform a specific task. The system is designed to collect data from external inputs and sensors, and perform programmed control tasks based on specified input criteria. The external FGTEI logic, using hard-wired relays, works in concert with the PLC ladder logic to provide safe operation of the portable exhauster.

3.0 OPERATION

3.1 GENERAL

The primary purpose of the FGTEI is to trip the interlock to the Rotary Mode Core Sampling (RMCS) truck if any abort limits have been exceeded. These

RMCS abort signals include the following:

- High hydrogen concentration
- High rate of change of hydrogen (dH/dT)
- High combustible gas concentration
- High rate of change of combustible gas (dCG/dT)
- 2" W.C. above baseline pressure alarm
- Emergency stop (E-STOP) switch activation
- Watch dog timer (WDT) expiration
- High tank pressure

In addition, the FGTEI will also shut down the portable exhauster should the pressure drop below -3" W.C., or if the tank pressure instrument fails.

The FGTEI samples gas from the respective tank from a spoolpiece installed between the tank exhaust header and the portable exhauster.

Continuity of the truck shut down circuit is interrupted by normally open relay contact located on the exhauster. Power to the exhauster is interrupted by a motor contactor located in each FGTEI unit. Two FGTEI units are provided for redundancy and are controlled independently by their respective PLCs.

The "RMCS truck enable" relay contact is closed when conditions are within specified tolerances. The portable exhauster is controlled with the use of a maintained arming circuit, energized by an electro-mechanical relay, enabled by the PLC. When a shutdown condition occurs, the PLC or operator (via the emergency stop button), can trip the circuit and de-energize the A.C. power to the portable exhauster.

3.2 SEQUENCE OF OPERATION

NOTE: For the following discussion, reference drawings H-14-100519 and H-14-100520 are necessary.

3.2.1 Analog Input Signals

Five 4-20 mA signals are connected to the FGTEI. The signals are:

- Inside cabinet temperature
- Combustible gas concentration
- Hydrogen concentration
- Exhaust header pressure
- Outside cabinet temperature

The first four signals are connected to the ADU206 module in slot 7, with the last signal connected to the ADU206 module in slot 8. Three channels are available for future use. These are the only analog input signals

provided to the PLC system.

3.2.2 Power Initialization

The system is started by the operator action of closing the disconnects, energizing the units. The LOSS OF POWER relay coil (K1) is initially energized, closing two normally-open (N.O.) relay contacts, energizing the conditioned control power circuit. The power initialization energizes all major components. This includes the following devices:

- Cabinet air conditioning (A/C) unit
- Inside and outside utility power receptacles
- Control power conditioning unit
- Transducer signal conditioning/transmitters
- Modicon PLC system

As soon as the PLC receives power, an automatic initialization sequence is started. However, if the cabinet temperature is below the operating temperature of the PLC, it will not function. The cabinet will be required to attain a minimum operating temperature, initiated by the EXH FAN START PERMISSIVE button, as described in the following section.

When the PLC starts operation at power-up it begins to control the cabinet temperature to the pre-determined temperature range by actuation of AIR CONDITIONER relay coil (K7) and HEATER relay coil (K8).

The actual temperature of the cabinet is being read by the PLC from a 4-20 mA INSIDE CABINET TEMPERATURE signal being generated from the temperature transmitter. The PLC then commands a heating or cooling action, as required, to maintain the programmed temperature.

If the FGWL (Flammable Gas Watch List) enable input (slot 4, input 7) is sensed, the WATCH DOG timer output is pulsed by the PLC every second. This input verifies that the correct jumper is in place in the external cable, ensuring correct system configuration (see reference drawings). The tank pressure instrument must also be connected and the PLC must measure greater than 2mA on the input to enable the watch dog timer. This causes the SYSTEM OK lamp to flash on and off continuously. A programmable time delay relay (VTP-HM-2205/6) requires a pulse to be sent at least every 2 seconds. If the PLC fails, this time delay relay will shut off power to the exhauster by de-energizing the ENABLE POWER TO EXHAUSTER relay coil (K3).

3.2.3 Start

NOTE: Previous shutdown conditions may be indicated on the operator's console. These lights are latched on, and will not extinguish until the KEYSWITCH is turned off and back on (see 3.2.4).

The sequence is initiated by the operators depressing the EXH FAN START PERMISSIVE(S3) button on each unit. The action energizes the HEATER BYPASS relay coil (K2) and energizes the cabinet heater. The CABINET TEMPERATURE OUT OF RANGE lamp is illuminated by a N.O. contact from the parallel HEATER BYPASS relay coil (K12). Since the disconnects have been previously closed, the PLC is on-line and running its ladder logic program. When the PLC senses the HEATER BYPASS N.O. relay contact closure (K2) on, signifying that the HEATER BYPASS relay coil (K2) has been energized, the PLC de-energizes the HEATER BYPASS relay coil (K2) by toggling the HEATER OFF relay coil (K4) on and off. If the PLC is below operating temperature, the HEATER OFF relay coil (K4) will not be toggled until the PLC has warmed sufficiently to begin operation.

If the FGWL Enable input is on (enabling the WDT contact) then the ENABLE POWER TO EXHAUSTER relay coil (K3) is energized and maintained (latched). The N.O. relay contact closure (K3) is closed, and if all required conditions are met in the PLC, the PLC energizes the MOTOR STARTER relay coil (K6), providing power to the exhauster by energizing the POWER CONTACTOR relay coil (MS). Additionally, the PLC will enable the RMCS truck interlock if the proper conditions have been satisfied.

The required conditions that need to be met in the PLC to enable the RMCS truck include the following:

- FGWL enable input ON
- KEYSWITCH in ON position
- Hydrogen concentration less than alarm value
- Rate of change of hydrogen (dH/dT) less than alarm value
- Combustible gas concentration less than alarm value
- Rate of change of combustible gas (dCG/dT) less than alarm value
- Pressure within range (no more than 2" W.C. above baseline, and less than the high pressure alarm setting of -0.1" W.C.)

The required conditions that need to be met in the PLC to enable the portable exhauster include the following:

- FGWL enable input ON
- Pressure above low limit (pressure above -3" W.C.)
- Pressure signal OK (measured input greater than 2mA)

When the PLC senses that the POWER CONTACTOR relay is energized, the "POWER CONTACTOR" lamp is then illuminated under program control.

3.2.4 Shutdown

The RMCS INTERLOCK relay (K10) can be de-energized by the conditions listed below:

- High hydrogen concentration
- High rate of change of hydrogen (dH/dT)
- 2" W.C. above baseline pressure alarm
- High combustible gas concentration
- High rate of change of combustible gas (dCG/dT)
- High tank pressure

The PLC will light an indicator light, on the operator's console, identifying the condition causing the shutdown for the above conditions. This light is latched on, and will not extinguish until the KEYSWITCH is turned off, which will reset any latched alarms. Two additional events will cause the RMCS INTERLOCK relay to de-energize:

- Loss of A.C. Power
- KEYSWITCH in OFF position

The portable exhauster can be shut down by the following condition:

- Tank Low Pressure Alarm (-3" W.C. or below)

Again, the PLC will light an indicator light on the operator's console, identifying a PRESSURE alarm. This light is latched on, and will not extinguish until the KEYSWITCH is turned off, which will reset any latched alarms. The portable exhauster enable must be manually restarted from the EXH FAN START PERMISSIVE(S3) button. Four additional events will cause the portable exhauster to shut down:

- Tank pressure signal less than 2mA (open circuit detection)
- Emergency stop (E-STOP) switch activation
- Loss of A.C. Power
- Watch dog timer expiration

3.2.4.1 High Hydrogen Concentration

If a high hydrogen concentration (above 5000 ppm) is detected, the HYDROGEN lamp will be energized, the STROBE LIGHT relay coil (K11) will energize, and the RMCS INTERLOCK relay coil (K10) will de-energize. This will cause the RMCS truck to shut down.

3.2.4.2 High Rate of Change of Hydrogen Concentration (dH/dT)

If a high rate of change of hydrogen concentration (above 100 ppm/sec for 10 seconds) is detected, the dH/dT lamp will be energized, the STROBE

LIGHT relay coil (K11) will energize, and the RMCS INTERLOCK relay coil (K10) will de-energize. This will cause the RMCS truck to shut down.

3.2.4.3 Cabinet Temperature Out of Range

If the cabinet temperature is sensed to be outside of the high alarm setpoint (95 degrees F.) by the PLC, the CABINET TEMPERATURE OUT OF RANGE lamp will be energized. This lamp will also be illuminated whenever the parallel HEATER BYPASS relay coil (K12) is energized, indicating the cabinet temperature is too low for PLC operation.

3.2.4.4 2" W.C. Above Baseline Pressure Alarm

If the pressure is observed to be 2" W.C. above the baseline pressure, the PRESSURE lamp will be energized, the STROBE LIGHT relay coil (K11) will energize, and the RMCS INTERLOCK relay coil (K10) will de-energize. This will cause the RMCS truck to shut down.

NOTE: At power-up, a tank pressure reading is taken, and the high pressure alarm is set to 2" W.C. above this background level. As soon as the exhauster begins operating, a drop in pressure will occur, and 3 minutes later the high pressure alarm is set to 2" W.C. above this new pressure. Every 5 minutes during exhauster operation, the high pressure alarm is updated to 2" W.C. above the current tank pressure reading. This allows for normal tank pressure fluctuations.

3.2.4.5 High Combustible Gas Concentration

If the combustible gas concentration reaches the alarm limit (above 5000 ppm), the COMBUSTIBLE GASSES lamp will be energized, the STROBE LIGHT relay coil (K11) will energize, and the RMCS INTERLOCK relay coil (K10) will de-energize. This will cause the RMCS truck to shut down.

3.2.4.6 High Rate of Change of Combustible Gas (dCG/dT)

If a high rate of change of combustible gas concentration (above 100 ppm/sec for 10 seconds) is detected, the dCG/dT lamp will be energized, the STROBE LIGHT relay coil (K11) will energize, and the RMCS INTERLOCK relay coil (K10) will de-energize. This will cause the RMCS truck to shut down.

3.2.4.7 Tank Pressure Alarm

If the pressure is observed to be below -3" W.C., the PRESSURE lamp will be energized, the MOTOR STARTER relay coil (K6) will be de-energized, and the E-STOP relay coil (K5) will be toggled. This de-energizes the ENABLE POWER TO EXHAUSTER relay coil (K3).

If the tank pressure is observed to be above -0.1" W.C., the STROBE LIGHT relay coil (K11) will energize, and the RMCS INTERLOCK relay coil (K10) will de-energize. This will cause the RMCS truck to shut down.

3.2.4.8 E-STOP

The depression of the EMER STOP (S2) button directly de-energizes the POWER CONTACTOR and is sensed by the PLC by the EMER STOP pushbutton switch pole. The PLC then actuates the E-STOP relay coil (K5), redundantly de-energizing the POWER CONTACTOR relay coil (MS), which shuts down the exhaustor.

3.2.4.9 Watch Dog Timer

A watch dog timer (WDT) must be periodically reset by the PLC any time the PLC is running. This is accomplished by energizing and de-energizing the WATCH DOG relay coil (K9) every second. The reset command will be evident to the operator by the flashing of the SYSTEM OK lamp (DS2) at the operator's console. Toggling a N.O. relay contact closure (K9) resets the WDT. The WDT maintains a N.O. relay contact closure in the arming circuit. When the PLC begins operating on power-up, the WDT N.O. relay contact is initially closed. If the WDT fails to get reset by the PLC, the timer will expire and open the N.O. contact, de-energizing the POWER CONTACTOR (MS). This will be evident on the operator's panel by the cessation of the flashing of the SYSTEM OK lamp, a shutdown of power to the exhaustor, and the loss of the POWER TO EXHAUSTER lamp (DS3). Additionally, if power fails, the N.O. contact closure will return to the N.O. state.

NOTE: If the FGWL ENABLE input (slot 4, input 7) is not sensed by the PLC, then the SYSTEM OK lamp will not flash and the watch dog timer will not be reset. The correct cables must be connected to the FGTEI carts at J5A (cart 2205) and J12A (cart 2206) to allow proper FGTEI operation.

Additionally, if the tank pressure signal input is less than 2mA, the SYSTEM OK lamp will not flash and the watch dog timer will not be reset. This indicates an open circuit from the tank pressure signal, or a failed pressure instrument.

3.2.4.10 Loss of A.C. Power

A loss of A.C. power will drop out all hard-wired relay coils, as well as de-energize the PLC. The start-up sequence must be performed to enable the RMCS truck and start the portable exhaustor again.

3.2.4.11 Keyswitch

The KEYSWITCH is used as a "Truck Enable" input, as well as a latched alarm reset. The portable exhaustor does not require the keyswitch to be in the ON position to start, but the RMCS truck DOES require it's use. The KEYSWITCH must be in the ON position for alarms to be latched. To reset latched alarms, simply turn the KEYSWITCH to the OFF position and then back to the ON position.

4.0 PLC SOFTWARE DESCRIPTION

4.1 GENERAL

Ladder logic for the FGTEI has been developed utilizing FGTEI elementary diagrams and operational design information.

Programming the PLC is accomplished with a MS-DOS based 486 PC running Modsoft, a software package provided by Modicon, Inc. The ladder logic is downloaded to the PLC via an RS-232 link, referred to by Modicon as Modbus. This RS-232 connection will also provide the communication path when the FGTEI is connected to a laptop PC in the field (or during testing). Cart 2205 utilizes J10A as the laptop interface connector, while cart 2206 uses J16A.

Included in the appendices of this document are:

- I/O channel list (Appendix A)
- Reference symbol table (Appendix B)
- PLC system configuration (Appendix C)
- Ladder logic network diagrams (Appendix D)
- Coil/register utilization tables (Appendix E)
- ADU206 control register reference (Appendix F)

4.2 LADDER LOGIC NETWORK DESCRIPTIONS

The following sections describe the individual networks that collectively make up the ladder logic of the FGTEI PLC system. Refer to Appendix D for the appropriate ladder logic network diagram.

4.2.1 Network 1 - Watch Dog / Powerup Delay Timers

This network has two functions -- to control the pulse train to the watch dog timer and to provide a 10-second power-up delay timer for use with alarms.

4.2.1.1 Watch Dog Timer

The watch dog timer (WDT) portion of this network uses an internal 0.1 second timer block, with a multiplier of 10, to provide a pulse every 1.0 seconds.

A N.C. contact 204 (WDTCOUNT) controls the reset of the timer. Output coil WDTCOUNT energizes after 1 second, which resets the timer by opening the N.C. contact on the reset input. The timer output then de-energizes WDTCOUNT, which starts the timer again. This process is repeated continually while the PLC is in operation.

A SUB block uses the timer register 41200 (WDTTIMR) to provide a square-wave output to coil 12 (WDTO). Whenever WDTTIMR is less than 5, the WDTO coil is energized, and remains energized for 0.5 seconds.

NOTE: A N.O. contact 10007 (FGWLEI) is in series before WDTO. This requires FGWLEI to be energized for the WDTO coil to toggle as described above. This input is the FGWL ENABLE input (slot 4, input 7). See section 3.2.4.9.

An additional N.C. contact 402 is in series before WDTO. This contact is controlled by the status bit for the tank pressure signal input (see Network 4 – section 4.2.4). If the signal is measured to be <2mA, then coil 402 is energized, and the N.C. contact 402 opens up, disabling WDTO.

The WDTO coil is hardware-mapped to the WATCH DOG output relay coil (K9). The pulse output will cause flashing of the SYSTEM OK lamp at the operator's console. The WDT maintains a normally open (N.O.) relay contact closure in the arming circuit. If the WDT fails to get reset by the PLC, the timer will expire and open the N.O. contact closure, de-energizing the POWER CONTACTOR (MS). This will be evident on the operator's panel by the cessation of the flashing of the SYSTEM OK lamp, a shutdown of power to the exhauster, and the loss of the POWER TO EXHAUSTER lamp.

4.2.1.2 Powerup Delay Timer

The purpose of this timer is to generate a contact closure for internal coil 205 (PWRUPTMR) 10 seconds after initial power up of the PLC. Using an internal 1.0 second timer block, with a multiplier of 10, coil PWRUPTMR goes high 10 seconds after initial power up via internal coil 101 (POWERUP). Coil POWERUP is discussed in section 4.2.2.

This 10-second delay is used for two purposes. The first is to load the high pressure alarm limit to 2" W.C. above the background pressure. This is discussed in section 4.2.3.

The second use for PWRUPTMR is to disable any alarm conditions for 10 seconds after power up, to ensure the instruments have stabilized. This is discussed in sections 4.2.10 and 4.2.11.

4.2.2 Network 2 - Toggle HEATOFF0 Relay (K4) / Set HIPRABVAL

This network has two functions -- to toggle the Heater Bypass relay (K2) allowing the PLC to take control of the HVAC of the FGTEI cart and to set the pressure alarm limit for the exhauster during its operation.

4.2.2.1 Toggle HEATOFF0 Relay (K4)

On power-up, internal coil 101 (POWERUP) is energized. Internal contacts from this coil are used throughout the FGTEI ladder logic, primarily to initialize values on power up of the PLC.

In this network, POWERUP, in series with a N.C. contact 10003 (HBYPASSI), controls the reset input for a 2 second timer. The 0.1 second timer block, with a multiplier of 20, holds the output of coil 7 (HEATOFF0) high for 2 seconds, then de-energizes it.

HEATOFF0 is hardware-mapped to the HEATER OFF output relay coil (K4), which will drop out relay coil K2 (and parallel relay coil K12), turning off the HEATER BYPASS.

A N.O. contact from K2 is hardware-mapped to coil 10003 (HBYPASSI). When HBYPASSI is closed, this also opens the N.C. contact from HBYPASSI and energizes HEATOFF0 for two seconds. Therefore, when the PLC is first powered up, a 2-second energization of HEATOFF0 occurs, as well as any time the EXH FAN START PERMISSIVE button is pressed (which causes HBYPASSI to energize K2).

4.2.2.2 Set HIPRABVAL

A 1.0 second timer block, with a multiplier of 180, is used to generate an output 180 seconds (3 minutes) after the exhauster is started. A pulse is generated by a positive-transition from internal coil 206 (BKGNDBMR1). The pulse is used to perform an addition function when the exhauster is running to establish a new high pressure alarm limit (register 41013 - HIPRABVAL) to 2" W.C. above the "running" baseline pressure level (register 30005 - PRESSVAL).

An additional positive-transition contact from coil 207 (BKGNDBMR2) also causes HIPRABVAL to be updated with PRESSVAL plus 2" W.C. This occurs every 5 minutes while the exhauster is running, and is discussed in network 6 (section 4.2.6.2).

If the result of the SUB block is determined to be above 0 "W.C., then the following BLKM block moves ZERO (41003) into 41013 (HIPRABVAL). This

ensures that the high pressure alarm limit never exceeds 0" W.C.

4.2.3 Network 3 - Alarm and Abort Initialization

During power-up, the positive-edge recognition of POWERUP causes the N.O. contact 101 (POWERUP) to close. This enables the ADD blocks to perform the addition shown, but only one time due to the nature of a positive-edge triggered contact. The result of the ADD is transferred to the designated register used for setpoints for alarms, aborts, and temperature control.

The ADD blocks use constants added to other constants to accomplish the respective setpoint value transfers. Two MUL (multiply) blocks are used to create constants above the limitation number of 999 for direct constant use. The first MUL block creates the number 2000 by placing (500×4) in the register pair at address 41300. This places the number 2000 into register 41301 (TWO THOUSAND). The remaining MUL block creates the number 3000 into register 41303 (THREE THOUSAND).

The first ADD block adds 2000 to zero (#0000), placing the result into register 41006 (HH2ABVAL). This initializes the HIGH HYDROGEN ABORT setpoint value one time, at start-up.

The remaining ADD blocks initialize the following:

- 41001 (TCLOVAL) TEMPERATURE CONTROL LOW = 1125 (45°F.)
- 41002 (TCHIVAL) TEMPERATURE CONTROL HIGH = 2125 (85°F.)
- 41004 (TAHIVAL) TEMPERATURE ALARM HIGH = 2375 (95°F.)
- 41005 (CGABVAL) COMBUSTIBLE GAS ABORT = 2000 (5000 ppm)
- 41006 (HH2ABVAL) HIGH HYDROGEN ABORT = 2000 (5000 ppm)
- 41008 (DHDTABVAL) dH/dT ABORT = 40 (100 ppm/sec.)
- 41012 (LOPRABVAL) LOW PRESSURE ABORT = 1200 (-3" W.C.)
- 41508 (DCGDTABVAL) dCG/dT ABORT = 40 (100 ppm/sec.)

All analog inputs are 4-20 mA. The ADU206 modules are configured to read 0 at 4 mA, and 4000 at 20 mA (see section 4.2.4). The calibrations used for all inputs are as follows:

Hydrogen:	0 - 4000 = 0 to 10,000 ppm (2.5 ppm/count)
Combustible Gas:	0 - 4000 = 0 to 10,000 ppm (2.5 ppm/count)
Pressure:	0 - 4000 = 0 to -10 "W.C. (.0025 "W.C./count)
Temperatures:	0 - 4000 = 0 to 160 degrees F. (.04°F/count)

4.2.4 Network 4 - ADU206 Initialization

The ADU206 modules require an initialization register to be loaded prior to use. This network initializes the ADU206 4-channel analog input modules in slots 7 and 8. One time only, upon power-up, a N.O. positive-edge triggered contact 101 (POWERUP) is closed.

The single closure of POWERUP enables the ADD blocks to perform the addition shown. This transfers the result to the designated registers used to set the mode of operation for the ADU206 modules. Register 40001 (MOD1MODE) is used for the module in slot 7, and register 40002 (MOD2MODE) is used for the module in slot 8.

ADD blocks are used to add constants to zero to accomplish this. For example, the first ADD block adds 112 (#0112) to zero (#0000), placing the result into register 40001 (MOD1MODE). This initializes the ADU206 module to unipolar mode with offset and extended resolution (see Appendix F). In this mode, all 4-20 mA inputs are read as 0000 when 4 mA is input, and 4000 at 20 mA.

This network also initializes the system constant ZERO to 0. This is accomplished by adding 0 to 0 (using an ADD block) with the result placed into register 41003 (ZERO). This constant is used in networks 2, 13, and 15.

Register 41401 (HITANKPRESSVAL) is initialized to 40 (-0.1 "W.C.") in this network by using an ADD block to add 0 to 40, storing the result into register 41401.

Testing of the pressure signal input is also performed in this network with the use of a SENS (sense) block. Bit 13 in register 30001 (the ADU206 status register) will be set to a "1" if the input is sensed to be less than 2 mA. Should this happen, internal coil 402 will energize and the N.C. contact 402 used in Network 1 will open, causing the WOTO coil to stop pulsing (see section 4.2.1.1).

4.2.5 Network 5 - Exhauster & RMCS Truck Shutdown

This network has three functions -- to control the power output to the portable exhauster (K6), to enable/disable the RMCS truck interlock (K10), and to control the ESTOP relay (K5).

4.2.5.1 Exhauster (Motor Starter) Enable Output

The MOTOR STARTER output relay (K6) is hardware-mapped to output coil 9 (MOTSTRTO). This coil is energized only when the tank pressure is above -3" W.C. (N.C. contact 300 - see section 4.2.11.1), the E-Stop switch is not pressed (N.O. but normally energized contact 10001), and the FGWL input is enabled (N.O. contact 10007), and the EXH FAN START PERMISSIVE switch is detected via the HEATER BYPASS (K2) N.O. contact, hardware-mapped to 10003 (HBYPASSI).

Once MOTSTRTO is energized, it is latched in place with a N.O. contact controlled by MOTSTRTO. The MOTSTRTO coil will de-energize only if the tank pressure drops below -3" W.C., the FGWL enable input is removed, or the E-STOP button coil 10001 (ESTOPI) is energized.

4.2.5.2 RMCS Interlock (K10)

The RMCS INTERLOCK output relay (K10) is hardware-mapped to output coil 13 (RMCSO). This coil is energized only when no abort conditions exist (with the N.O. contact 100), the FGWL input is enabled (N.O. contact 10007), and the KEYSWITCH is enabled (with the N.O. contact 10006).

The RMCSO coil will de-energize only if an abort condition occurs, the FGWL enable input is removed, or the KEYSWITCH is disabled.

The composite abort (coil 100) is made up with N.C. contacts from the following:

- 00001 (HIGHH2O) HIGH HYDROGEN CONCENTRATION
 - 00005 (DHDT0) dH/dT OUT
 - 00301 (DELTAPRESS) DELTA PRESSURE ALARM
 - 00004 (COMBGALO) COMBUSTIBLE GAS ALARM
 - 00006 (DCGDT0) dCG/dT OUT
- and a N.O. contact from:
- 10001 (ESTOPI) E-STOP BUTTON INPUT

Energizing any of the first five coils listed above (or de-energizing 10001 with the E-Stop button) will cause the composite coil 100 (COMPABORT) to de-energize. If RMCSO (which enables the RMCS truck interlock) is energized when this occurs, RMCSO will de-energize.

Additionally, the N.C. contacts from the first five coils above (00001, 00005, 00301, 00004, and 00006) energize coil 208 (NOTSTROBE). This is the inverted strobe control output, and will be discussed in the following network (network 6).

4.2.6 Network 6 - Strobe / Background Pressure

This network has two distinct functions - to control the strobe light output, and to update the high-pressure abort level (2" W.C. above baseline pressure).

4.2.6.1 Strobe Light Control

Output coil 14 (STROBE0) is hardware-mapped to external relay STROBE LIGHT (K11). This output goes on when the coil to N.C. contact 208 (NOTSTROBE) is de-energized. This occurs under RMCS abort conditions (see section 4.2.5.2).

4.2.6.2 Background Pressure Timer

Coil 207 (BKGNDTMR2) is used to update the 2" W.C. above baseline pressure abort (HIPRABVAL - as discussed in section 4.2.2.2) every five

minutes while the exhauster is running. The N.O. contact 206 (BKGNDTMR1) is used as an indicator that the exhauster is running - it also serves as the start time after the initial 3-minute update.

The N.C. contact 207 (in series with the N.O. contact 206) is used as a reset control for the 300 second timer block that controls coil 207. This timer block continually counts 300 seconds (five minutes), resets, and counts again while the exhauster is running. If the exhauster is stopped, then coil 206 will de-energize, causing the updates to discontinue (see section 4.2.2.2).

The SUB block is used to compare the real-time tank pressure (register 30001 - PRESSVAL) with the 2" W.C. above baseline pressure abort limit (register 41013 - HIPRABVAL). If the tank pressure is above the limit, then the alarm coil 301 (DELTAPRESS) is energized. However, the N.O. coil 206 (BKGNDTMR1) in series with coil 301 ensures that the alarm only occurs if the exhauster is running (coil 301 only aborts the portable exhauster, and since the 2" W.C. above baseline background pressure abort limit is updated only when the exhauster is running, HIPRABVAL will not have current information in it unless the exhauster is running).

The N.O. coil 10006 (KBYPASSI) is the keyswitch input. If it is energized (KEYSWITCH ON), then if coil 301 is energized, the coil is self-latching (with the use of the N.O. contact 301). The KEYSWITCH must be turned OFF to reset the alarm condition.

N.O. coil 401 (HITANKPRESS) will also energize coil 301. This coil is controlled by the high tank pressure alarm of -0.1 "W.C. (see Network 9 - section 4.2.9.4).

4.2.7 Network 7 - Low Temperature Control (HEAT)

Output coil 11 (HEATONO) is hardware-mapped to external relay HEATER (K8). When the HEATER relay is energized, the heater is on.

Register 30002 (ICBTEVAL) is the Inside Cabinet Temperature. It is compared to the low temperature control setpoint (TCLOVAL) using a SUB block to perform a subtraction. If ICBTEVAL is less than TCLOVAL, then power is applied to the adjacent ADD block and coil 200 (HEATCONT1) is energized. The function of the ADD block is to set the deadband for temperature control. The ADD block adds 125 (5 degrees F.) to the low temperature setpoint, TCLOVAL, and places it into register 41102 (HTCONDVAL), the heating control delta value.

When coil 200 (HEATCONT1) is energized, coil 201 (HEATCONT2) is also energized. This allows the N.O. contact from HEATCONT2 to pass power to the final SUB block, which performs the actual control to the heater. HTCONDVAL is subtracted from ICBTEVAL, and HEATONO is energized while ICBTEVAL is less

than HTCONDVAL.

As HEATONO is energized, the N.O. contact will latch HEATCONT2 on until the temperature rises 5 degrees F. above the low temperature setpoint.

4.2.8 Network 8 - High Temperature Control (COOL)

Output coil 10 (COOLONO) is hardware-mapped to external relay AIR CONDITIONER (K7). When relay AIR CONDITIONER is energized, the air conditioner is on.

Register 30002 (ICBTEVAL) is the Inside Cabinet Temperature. It is compared to the high temperature control setpoint (TCHIVAL) using a SUB block to perform a subtraction. If ICBTEVAL is greater than TCHIVAL, then power is applied to the adjacent SUB block and coil 202 (COOLCONT1) is energized. The function of this second SUB block is to set the deadband for temperature control. The SUB block subtracts 125 (5 degrees F.) from the high temperature setpoint, TCHIVAL, and places it into register 41103 (CTCONDVAL), the cooling control delta value.

When coil 202 (COOLCONT1) is energized, coil 203 (COOLCONT2) is also energized. This allows the N.O. contact from COOLCONT2 to pass power to the final SUB block, which performs the actual control to the air conditioner. CTCONDVAL is subtracted from ICBTEVAL, and COOLONO is energized while ICBTEVAL is greater than CTCONDVAL.

As COOLONO is energized, the N.O. contact will latch COOLCONT2 on until the temperature drops 5 degrees below the high temperature setpoint.

4.2.9 Network 9 - Temp. Out of Range/Power to Exhauster/E-STOP/High Tank Pressure

4.2.9.1 Temperature Out Of Range

Energizing internal coil 2 (CABTEMPO) indicates that the cabinet temperature is out of range (high) for operating the PLC. The high alarm point (95 degrees F.) is 10 degrees F. above the high temperature control setpoint (85 degrees F.).

NOTE: External relay coil K12 (HEATER BYPASS - in parallel with K2) also will illuminate the CABINET TEMPERATURE OUT OF RANGE lamp, indicating that the temperature is too low to operate the PLC.

This network continually checks for an out of range condition, through the use of a SUB block. Register 41004 (TAHIVAL) is subtracted from register 30002 (ICBTEVAL), and coil 2 (CABTEMPO) is energized if ICBTEVAL is above TAHIVAL.

CABTEMPO is hardware-mapped to the CABINET TEMPERATURE OUT OF RANGE lamp.

4.2.9.2 Power To Exhauster Lamp

Coil 15 (PWR2EXHSTRO) is hardware-mapped to the POWER TO EXHAUSTER lamp on the console (DS3). When the N.O. contact 10004 (MOTSTRTI) closes, coil 15 is energized, illuminating the POWER TO EXHAUSTER lamp. Coil 10004 is the input from the motor starter (MS) power contactor. When the power contactor is energized, a N.O. contact from the contactor closes, enabling input coil 10004.

4.2.9.3 E-STOP

Coil 8 is hardware-mapped to the E-STOP relay (K5). Under normal conditions, the N.C. contact 300 (PRESSABRT) and the N.O. contact 10001 (ESTOPI) keep coil 8 energized. Whenever the low pressure abort (-3" W.C.) is detected, the N.C. contact 300 will open, causing coil 8 to de-energize, which causes K5 to de-energize. This will remove the power to the exhauster, requiring the EXH FAN START PERMISSIVE switch to be pressed to restart the exhauster.

Similarly, the N.O. contact 10001 is closed when the E-STOP button is not pressed. If an operator presses the E-STOP button, this will cause the N.O. contact 10001 to open, removing power to the exhauster by de-energizing K5.

4.2.9.4 High Tank Pressure

A high tank pressure alarm setting of -0.1 "W.C. will cause the RMCS truck to shut down with the use of coil 401 (HITANKPRESS). Network 6 uses a N.O. contact from coil 401 to generate a pressure alarm (see section 4.2.6.2). The pressure signal in register 30005 is compared with the high tank pressure alarm value (register 41401 - HITANKPRESSVAL). If the pressure is above this value, AND N.O. contact 206 is closed (indicating that the exhauster is running), then coil 401 is energized.

4.2.10 Network 10 - Combustible Gas, Hydrogen Aborts

This network has two distinct functions - to generate an abort if a high combustible gas concentration level exists or a high-hydrogen level limit is detected.

4.2.10.1 Combustible Gas Abort

Output coil 4 (COMBGALO) is energized whenever the combustible gas concentration exceeds a preset setpoint. This is accomplished through the use of a SUB block, where register 41005 (CGABVAL), the combustible gas abort

value, is subtracted from register 30003 (COMBGVAL), the combustible gas concentration. If COMBGVAL is greater than CGABVAL, COMBGALO is energized, causing an abort (see 4.2.5.2). However, N.O. contact 205 (PWRUPTMR) must be closed, indicating that at least 10 seconds have elapsed since power up of the PLC (see section 4.2.1.2). COMBGALO is hardware-mapped to the COMBUSTIBLE GASSES lamp.

A N.O. contact from COMBGALO is used in series with a N.O. contact from coil 10006 (KBYPASSI) to latch the alarm. Whenever the KEYSWITCH is turned OFF, de-energizing KBYPASSI, the alarm is reset.

4.2.10.2 Hydrogen Abort

Output coil 1 (HIGHH2O) energizes whenever a hydrogen concentration level exceeds the alarm setpoint. This is accomplished through the use of a SUB block, where register 41006 (HH2ABVAL), the high hydrogen abort value, is subtracted from register 30004 (H2VAL), the hydrogen concentration. If H2VAL is greater than HH2ABVAL, HIGHH2O is energized, causing an abort (see 4.2.5.2). However, N.O. contact 205 (PWRUPTMR) must be closed, indicating that at least 10 seconds have elapsed since power up of the PLC (see section 4.2.1.2). HIGHH2O is hardware-mapped to the HYDROGEN lamp.

A N.O. contact from HIGHH2O is used in series with a N.O. contact from coil 10006 (KBYPASSI) to latch the alarm. Whenever the KEYSWITCH is turned OFF, de-energizing KBYPASSI, the alarm is reset.

4.2.11 Network 11 - Low Pressure Abort / Pressure Alarm Lamp

This network has two purposes - to generate the low pressure (-3" W.C.) abort of the portable exhaustor, and to illuminate the PRESSURE lamp on the console.

4.2.11.1 Low Pressure Abort

To handle the low pressure abort, register 41012 (LOPRABVAL), the low pressure abort value, is subtracted from register 30005 (PRESSVAL), the pressure signal. If PRESSVAL is less than LOPRABVAL, coil 300 (PRESSABRT) is energized, causing an abort (see 4.2.5.1). However, N.O. contact 205 (PWRUPTMR) must be closed, indicating that at least 10 seconds have elapsed since power up of the PLC (see section 4.2.1.2).

A N.O. contact from PRESSABRT is used in series with a N.O. contact from coil 10006 (KBYPASSI) to latch the alarm. Whenever the KEYSWITCH is turned OFF, de-energizing KBYPASSI, the alarm is reset.

4.2.11.2 Pressure Alarm Lamp

Output coil 3 (PRESSALO) energizes whenever the 2" W.C. above baseline

condition occurs (N.O. contact 301 - see 4.2.6.2), the high tank pressure alarm value is exceeded (coil 401 controlling coil 301 - see 4.2.9.4), or the low pressure abort exists (N.O. contact 300 - see 4.2.11.1). PRESSALO is hardware-mapped to the PRESSURE lamp.

4.2.12 Network 12 - dH/dT Data Capture

The purpose of the dH/dT data capture network is to provide two registers containing real-time hydrogen concentration data, separated by a preset time delay. This allows the hydrogen rate of change to be determined in network 13 (see 4.2.13).

A 0.01 second timer block, with a multiplier of 200, counts to 200 in register 41201 (DHDTTIMR) and outputs a pulse to coil 102 (DHDTTIMER), which resets itself and counts to 200 again, providing a pulse every 2 seconds.

The first SUB block is used to subtract 100 from DHDTTIMR. If DHDTTIMR is greater than 100, coil 103 (DHDTCAP), the dH/dT capture control coil, is energized. This provides a square wave with a period of 2 seconds. Any rising edge is always 1 second from the next falling edge, and vice-versa. Therefore, a positive edge triggering one data capture register and a negative edge triggering another data capture register results in the two registers containing data points 1 second apart.

Precision data capture is accomplished by using registers 41009 (DHDTVAL1) and 41010 (DHDTVAL2). Zero is subtracted from register 30004 (H2VAL) and placed in these registers, controlled by a positive edge of DHDTCAP (into DHDTVAL1) and a negative edge of DHDTCAP (into DHDTVAL2), as explained above.

These two registers, DHDTVAL1 and DHDTVAL2, are continually updated while the PLC is operating. Network 13 (see 4.2.13) uses these registers to determine the dH/dT (rate of change of hydrogen concentration) and to test for an abort condition.

4.2.13 Network 13 - dH/dT Alarm and Abort

A rising edge of coil 103 (DHDTCAP) is used to control a SUB block that subtracts register 41010 (DHDTVAL2) from register 41009 (DHDTVAL1). The result is placed into register 41007 (DHDTRAW), the dH/dT rate raw value. This positive-edge triggering is required to ensure that every time the subtract occurs, DHDTVAL1 is captured 1 second after DHDTVAL2.

If DHDTVAL1 is greater than DHDTVAL2 (implying the rate of change is positive), then the value in register 41007 (DHDTRAW) is placed into register 41011 (DHDTREAL) via a BLKM block.

When DHDTVAL1 is less than or equal to DHDTVAL2 (implying the dH/dT rate is non-positive), then register 41003 (ZERO) is placed into register DHOTRVAL with another BLKM block.

Register 41008 (DHDTABVAL), the dH/dT abort value, is subtracted from DHOTRVAL in the following SUB block. If DHOTRVAL is greater than DHDTABVAL, then coil 104 (DHDTALARM) is energized, indicating the rate of change is greater than the abort setpoint.

The 0.1 second timer block, with a multiplier of 100, is used to filter the dH/dT value. DHDTALARM must be energized for a minimum of 10 seconds to cause a dH/dT abort condition. When DHDTALARM is high, the N.O. contact from DHDTALARM closes and the timer starts to count. If DHDTALARM remains high for 10 seconds, the timer output energizes coil 105 (DHDTABORT), the abort coil for the dH/dT hydrogen rate. If DHDTABORT is energized an abort occurs (see 4.2.5.2). If at any time DHDTALARM is de-energized, the timer resets and DHDTABORT is also de-energized.

4.2.14 Network 14 - dCG/dT Data Capture

The purpose of the dCG/dT data capture network is to provide two registers containing real-time combustible gas (CG) concentration data, separated by a preset time delay. This allows the CG rate of change to be determined in network 15 (see 4.2.15).

A 0.01 second timer block, with a multiplier of 200, counts to 200 in register 41501 (DCGDTTMR) and outputs a pulse to coil 502 (DCGDTTIMER), which resets itself and counts to 200 again, providing a pulse every 2 seconds.

The first SUB block is used to subtract 100 from DCGDTTMR. If DCGDTTMR is greater than 100, coil 503 (DCGDTCAP), the dCG/dT capture control coil, is energized. This provides a square wave with a period of 2 seconds. Any rising edge is always 1 second from the next falling edge, and vice-versa. Therefore, a positive edge triggering one data capture register and a negative edge triggering another data capture register results in the two registers containing data points 1 second apart.

Precision data capture is accomplished by using registers 41509 (DCGDTVAL1) and 41510 (DCGDTVAL2). Zero is subtracted from register 30003 (COMBGVAL) and placed in these registers, controlled by a positive edge of DCGDTCAP (into DCGDTVAL1) and a negative edge of DCGDTCAP (into DCGDTVAL2), as explained above.

These two registers, DCGDTVAL1 and DCGDTVAL2, are continually updated while the PLC is operating. Network 15 (see 4.2.15) uses these registers to determine the dCG/dT (rate of change of combustible gas concentration) and to test for an abort condition.

4.2.15 Network 15 - dCG/dT Alarm and Abort

A rising edge of coil 503 (DCGDTCAP) is used to control a SUB block that subtracts register 41510 (DCGDTVAL2) from register 41509 (DCGDTVAL1). The result is placed into register 41507 (DCGDTRAW), the dCG/dT rate raw value. This positive-edge triggering is required to ensure that every time the subtract occurs, DCGDTVAL1 is captured 1 second after DCGDTVAL2.

If DCGDTVAL1 is greater than DCGDTVAL2 (implying the rate of change is positive), then the value in register 41507 (DCGDTRAW) is placed into register 41511 (DCGDTRVAL) via a BLKM block.

When DCGDTVAL1 is less than or equal to DCGDTVAL2 (implying the dCG/dT rate is non-positive), then register 41003 (ZERO) is placed into register DCGDTRVAL with another BLKM block.

Register 41508 (DCGDTABVAL), the dCG/dT abort value, is subtracted from DCGDTRVAL in the following SUB block. If DCGDTRVAL is greater than DCGDTABVAL, then coil 504 (DCGDTALARM) is energized, indicating the rate of change is greater than the abort setpoint.

The 0.1 second timer block, with a multiplier of 100, is used to filter the dCG/dT value. DCGDTALARM must be energized for a minimum of 10 seconds to cause a dCG/dT abort condition. When DCGDTALARM is high, the N.O. contact from DCGDTALARM closes and the timer starts to count. If DCGDTALARM remains high for 10 seconds, the timer output energizes coil 505 (DCGDTABORT), the abort coil for the dCG/dT combustible gas rate. If DCGDTABORT is energized an abort occurs (see 4.2.5.2). If at any time DCGDTALARM is de-energized, the timer resets and DCGDTABORT is also de-energized.

4.2.16 Network 16 - dH/dT and dCG/dT Alarm Outputs

This network has two functions - to generate an abort if a high hydrogen concentration rate of rise (dH/dT) exists, or a high combustible gas concentration rate of rise is detected.

4.2.16.1 dH/dT Alarm Output

Output coil 5 (DHDTO) energizes whenever a dH/dT hydrogen rate abort occurs. This is accomplished through the use of a N.O. contact 105 (see 4.2.13), which will close when a dH/dT alarm occurs. When the N.O. contact 105 closes, coil 5 (DHDTO) will energize, causing an abort (see 4.2.5.2). However, N.O. contact 205 (PWRUPTMR) must be closed, indicating that at least 10 seconds have elapsed since power up of the PLC (see section 4.2.1.2). DHDTO is hardware-mapped to the dH/dT lamp.

A N.O. contact from DHDTO is used in series with a N.O. contact from coil 10006 (KBYPASSI) to latch the alarm. Whenever the KEYSWITCH is turned OFF, de-energizing KBYPASSI, the alarm is reset.

4.2.16.2 dCG/dT Alarm Output

Output coil 6 (DCGDTO) energizes whenever a dCG/dT hydrogen rate abort occurs. This is accomplished through the use of a N.O. contact 505 (see 4.2.15), which will close when a dCG/dT alarm occurs. When the N.O. contact 505 closes, coil 6 (DCGDTO) will energize, causing an abort (see 4.2.5.2). However, N.O. contact 205 (PWRUPTMR) must be closed, indicating that at least 10 seconds have elapsed since power up of the PLC (see section 4.2.1.2). DCGDTO is hardware-mapped to the dCG/dT lamp.

A N.O. contact from DCGDTO is used in series with a N.O. contact from coil 10006 (KBYPASSI) to latch the alarm. Whenever the KEYSWITCH is turned OFF, de-energizing KBYPASSI, the alarm is reset.

APPENDIX A

I/O Channel List

DROP	RACK	SLOT	CHANNEL	REGISTER	TAGNAME	DESCRIPTION
1	1	1	N/A	N/A		PC-A984-145
1	1	2	N/A	N/A		
1	1	3	N/A	N/A		AS-P120-000
1	1	4	N/A	100XX		AS-BDEP-218
1	1	4	1	10001	ESTOPI	Exhauster ESTOP In
1	1	4	2	10002	EXHSTRI	Exh. (CT) Running In
1	1	4	3	10003	HBYPASSI	Heater Bypass In
1	1	4	4	10004	MOTSTRTI	Motor Starter In
1	1	4	5	10005	ESTOPFI	ESTOP Feedback In
1	1	4	6	10006	KBYPASSI	Keyswitch Bypass In
1	1	4	7	10007	FGWLEI	FGWL Enable In
1	1	4	8	10008	EXFANRUNI	Exh. Fan Running In
1	1	4	9	10009		Spare
1	1	4	10	10010		Spare
1	1	4	11	10011		Spare
1	1	4	12	10012		Spare
1	1	4	13	10013		Spare
1	1	4	14	10014		Spare
1	1	4	15	10015		Spare
1	1	4	16	10016		Spare
1	1	5	N/A	000XX		AS-BDAP-218
1	1	5	1	00001	HIGHH2O	High Hydrogen Out
1	1	5	2	00002	CABTEMPO	Cab. Temp. OOR Out
1	1	5	3	00003	PRESSALO	Pressure Alarm Out
1	1	5	4	00004	COMBGALO	Comb. Gas Alarm Out
1	1	5	5	00005	DHDTO	dH/dT Out
1	1	5	6	00006	DCGDTO	dCG/dT Out
1	1	5	7	00007	HEATOFFO	Heater Off Out

1	1	5	8	00008	ESTOPO	Exhauster ESTOP Out
1	1	5	9	00009	MOTSTRTO	Motor Starter Out
DROP	RACK	SLOT	CHANNEL	REGISTER	TAGNAME	DESCRIPTION
1	1	5	10	00010	COOLONO	Air Cond. On Out
1	1	5	11	00011	HEATONO	Heater On Out
1	1	5	12	00012	WDTO	Watch Dog Timer Out
1	1	5	13	00013	RMCSO	RMCS Interlock Out
1	1	5	14	00014	STROBEO	Strobe Light Out
1	1	5	15	00015	PWR2EXHSTRO	Pwr. to Ex. Lamp Out
1	1	5	16	00016		Spare
1	2	1	N/A	000XX		AS-BDAP-218
1	2	1	1	00017		Spare
1	2	1	2	00018		Spare
1	2	1	3	00019		Spare
1	2	1	4	00020		Spare
1	2	1	5	00021		Spare
1	2	1	6	00022		Spare
1	2	1	7	00023		Spare
1	2	1	8	00024		Spare
1	2	1	9	00025		Spare
1	2	1	10	00026		Spare
1	2	1	11	00027		Spare
1	2	1	12	00028		Spare
1	2	1	13	00029		Spare
1	2	1	14	00030		Spare
1	2	1	15	00031		Spare
1	2	1	16	00032		Spare
1	2	2	N/A	3X/4X		AS-BADU-206
1	2	2	N/A	30001	MOD1STAT	ADU206 Op. Status

1	2	2	1	30002	ICBTEVAL	Inside Cab. Temp.
1	2	2	2	30003	COMBGVAL	Combust. Gasses
1	2	2	3	30004	H2VAL	Whittaker H2 Signal
1	2	2	4	30005	PRESSVAL	Pressure
DROP	RACK	SLOT	CHANNEL	REGISTER	TAGNAME	DESCRIPTION
1	2	2	N/A	40001	MOD1MODE	ADU206 Mode/Range
1	2	3	N/A	3X/4X		AS-BADU-206
1	2	3	N/A	30006	MOD2STAT	ADU206 Op. Status
1	2	3	1	30007	OCBTEVAL	Outside Cab. Temp.
1	2	3	2	30008		Spare
1	2	3	3	30009		Spare
1	2	3	4	30010		Spare
1	2	3	N/A	40002	MOD2MODE	ADU206 Mode/Range
1	2	4	N/A	N/A		AS-P120-000

APPENDIX B

Reference Symbol Table

Discrete Output Coils

00001	HIGHH2O	1.1.5.1	High Hydrogen Out
00002	CABTEMPO	1.1.5.2	Cabinet Temp. Out Of Range Out
00003	PRESSALO	1.1.5.3	Pressure Alarm Out
00004	COMBGALO	1.1.5.4	Combustible Gas Alarm Out
00005	DHDTO	1.1.5.5	dH/dT Out
00006	DCGDTO	1.1.5.6	dCG/dT Out
00007	HEATOFFO	1.1.5.7	Heater Off Out
00008	ESTOPO	1.1.5.8	Exhauster ESTOP Out
00009	MOTSTRTO	1.1.5.9	Motor Starter Out
00010	COOLONO	1.1.5.10	Air Conditioning On Out
00011	HEATONO	1.1.5.11	Heater On Out
00012	WDTO	1.1.5.12	Watch Dog Timer Out
00013	RMCSO	1.1.5.13	RMCS Interlock Out
00014	STROBEO	1.1.5.14	Strobe Light Out
00015	PWR2EXHSTRO	1.1.5.15	Power To Exhauster Lamp Out
00016		1.1.5.16	Spare
00017		1.2.1.1	Spare
00018		1.2.1.2	Spare
00019		1.2.1.3	Spare
00020		1.2.1.4	Spare
00021		1.2.1.5	Spare
00022		1.2.1.6	Spare
00023		1.2.1.7	Spare
00024		1.2.1.8	Spare
00025		1.2.1.9	Spare
00026		1.2.1.10	Spare
00027		1.2.1.11	Spare
00028		1.2.1.12	Spare
00029		1.2.1.13	Spare
00030		1.2.1.14	Spare
00031		1.2.1.15	Spare
00032		1.2.1.16	Spare

Discrete Internal Coils

00100	COMPABORT	COMPOSITE ABORT
00101	POWERUP	POWER UP
00102	DHDTTIMER	dH/dT Data Capture Timer Reset
00103	DHDTCAP	dH/dT Data Capture Control
00104	DHDTALARM	dH/dT Alarm (unfiltered)
00105	DHDTABORT	dH/dT Alarm & Abort
00200	HEATCONT1	Heating Control 1
00201	HEATCONT2	Heating Control 2
00202	COOLCONT1	Cooling Control 1
00203	COOLCONT2	Cooling Control 2
00204	WDTCOUNT	WDT Counter
00205	PWRUPTMR	Power Up Timer
00206	BCKGNDTMR1	Background Pressure Timer 1
00207	BCKGNDTMR2	Background Pressure Timer 2
00208	NOTSTROBE	Strobe Output NOT enabled
00209	NOTRMCSO	RMCS truck output NOT enabled
00300	PRESSABRT	Tank Pressure Abort
00401	HITANKPRESS	High Tank Pressure Alarm
00402	PRESSUREBAD	Pressure Transducer Bad (<2mA measured)
00301	DELTAPRESS	6 Minute Delta Pressure Abort
00502	DCGDTTIMER	dCG/dT data Capture Timer Reset
00503	DCGDTCAP	dCG/dT Data Capture Control
00504	DCGDTALARM	dCG/dT Alarm (unfiltered)
00505	DCGDTABORT	dCG/dT Alarm & Abort

Discrete Input Registers

10001	ESTOPI	1.1.4.1	Exhauster ESTOP In
10002	EXHSTRI	1.1.4.2	Exhauster Running In
10003	HBYPASSI	1.1.4.3	Heater Bypass In
10004	MOTSTRTI	1.1.4.4	Motor Starter In
10005	ESTOPFI	1.1.4.5	ESTOP Feedback In
10006	KBYPASSI	1.1.4.6	Keyswitch Bypass In
10007	FGWLEI	1.1.4.7	FGWL Enable In
10008	EXFANRUNI	1.1.4.8	Exhauster Fan Running In
10009		1.1.4.9	Spare
10010		1.1.4.10	Spare
10011		1.1.4.11	Spare
10012		1.1.4.12	Spare
10013		1.1.4.13	Spare
10014		1.1.4.14	Spare
10015		1.1.4.15	Spare
10016		1.1.4.16	Spare

Analog Input Registers

30001	MOD1STAT		Module 1 (ADU206) Operation Status Register
30002	ICBTEVAL	1.2.2.1	Inside Cabinet Temperature
30003	COMBGVAL	1.2.2.2	Combustible Gasses
30004	H2VAL	1.2.2.3	Whittaker H2 Signal
30005	PRESSVAL	1.2.2.4	Pressure
30006	MOD2STAT		Module 2 (ADU206) Operation Status Register
30007	OCBTEVAL	1.2.3.1	Outside Cabinet Temperature
30008		1.2.3.2	Spare
30009		1.2.3.3	Spare
30010		1.2.3.4	Spare

Output Registers

40001	MOD1MODE		Module 1 (ADU206) Mode/Range Register
40002	MOD2MODE		Module 2 (ADU206) Mode/Range Register

Holding Registers

41001	TCLOVAL	Temperature Control Low Value
41002	TCHIVAL	Temperature Control High Value
41003	ZERO	System Zero
41004	TAHIVAL	Temperature Alarm High Value
41005	CGABVAL	Combustible Gas Abort Value
41006	HH2ABVAL	High Hydrogen Abort Value
41007	DHDTRAW	dH/dT Raw Unsigned Value
41008	DHDTABVAL	dH/dT Abort Value
41009	DHDTVAL1	dH/dT Value 1
41010	DHDTVAL2	dH/dT Value 2
41011	DHDTTRVAL	dH/dT Rate Value
41012	LOPRABVAL	Low Pressure Abort Value
41013	HIPRABVAL	High Pressure Abort Value
41101	SCRATCH	
41102	HTCONDVAL	Heating Control Delta Value
41103	CTCONDVAL	Cooling Control Delta Value
41200	WDTTMR	WDT Timer Register
41201	DHDTTMR	dH/dT Timer Register
41202	DHDTFTMR	dH/dT Filter Timer Register
41203	H2DLYTMR	Hydrogen Startup Delay Timer Register
41204	PWRUPTMR	Power Up Delay Timer Register
41205	HTOFFTMR	Heat Off Pulse Timer Register
41207	EXHSTRTMR	Exhauster Running Delay Timer Register
41208	BCKGNDTMR	Background Pressure Update Timer
41301	TWOTHOUSAND	System Constant (2000)
41303	THREETHOUSAND	System Constant (3000)
41401	HITANKPRESSVAL	Hi Tank Pressure Alarm point (-0.1"W.C.)
41501	DCGDTTMR	dCG/dT Timer Register
41502	DCGTFTMR	dCG/dT Filter Timer Register
41507	DCGDTRAW	dCG/dT Raw Unsigned Value
41508	DCGDTABVAL	dCG/dT Abort Value
41509	DCGDTVAL1	dCG/dT Value 1
41510	DCGDTVAL2	dCG/dT Value 2
41511	DCGDTRVAL	dCG/dT Rate Value

APPENDIX C

PLC System Configuration

FGTEI Ladder Logic - July 2, 1996

Configuration

CONFIGURATION OVERVIEW			
PLC :		Size of Full Logic Area	07277
PLC Type	984 -COMPACT	No. of I/O Map Words	00073
Model	A145		
Memory	8.0K	I/O :	
Extended Memory	K	Number of Segments	12
		I/O Drops	1
		I/O Modules	8
		Specials :	
		Battery Coil	01536
Ranges :		Timer Register	41864
0xxxx 00001 - 01536		Time of Day Clock	41865 - 41872
1xxxx 10001 - 10512		Config Extension Size	0
3xxxx 30001 - 30048			
4xxxx 40001 - 41872			
4xxxx <-> SFC	None		
0xxxx <-> SFC	None		

CONFIGURATION EXTENSION BLOCKS

No Configuration Extensions found

PORTS

Number	Mode	Data Bits	Parity	Stop Bits	Baud	Keyboard	Address Delay
MODBUS							
01	RTU	8	EVEN	1	9600	1	10 ms
02	RTU	8	EVEN	1	9600	1	10 ms

I/O MAP
984-120/130/145 CONTROLLERS

PLC :	COMPACT A145	Rack :	1
Number Inputs :	176	Number Outputs:	64

Module	Reference Numbers	Data	Module
--------	-------------------	------	--------

Slot	Type	Input	Output	type	Description
101	984				PLC-COMPACT
102	984				PLC-COMPACT
103	P120				POWER SUPPLY
104	DEP218	10001 -10016			16-I 115VAC
105	DAP218		00001 -00016		16-O 115VAC

PLC : COMPACT A145 Rack : 2

Slot	Module Type	Reference Input	Numbers Output	Data type	Module Description
201	DAP218		00017 -00032		16-O 115VAC
202	ADU206	30001 -30005	40001 -40001	BIN	4 CHN A/D
203	ADU206	30006 -30010	40002 -40002	BIN	4 CHN A/D
204	P120				POWER SUPPLY
205	** AVAILABLE SLOT **				

APPENDIX D

Ladder logic Network Diagrams

FGTEI Ladder Logic - September 12, 1996

Network List Segment: 01

```

+-----+ +-----+
|P000|--| #00001| WATCH DOG / POWERUP DELAY TIMERS
+-----+ +-----+
| #00002| TOGGLE HEATOFF0 / SET HIPRABVAL
+-----+ +-----+
| #00003| ALARM & ABORT INITS
+-----+ +-----+
| #00004| ADU206 INIT - UNI/OFFSET EXT RES
+-----+ +-----+
| #00005| EXHSTR. & RMCS SHUTDOWN
+-----+ +-----+
| #00006| STROBE / BACKGROUND PRESSURE
+-----+ +-----+
| #00007| LOW TEMPERATURE CONTROL (HEAT)
+-----+ +-----+
| #00008| HIGH TEMPERATURE CONTROL (COOL)
+-----+ +-----+
| #00009| TEMP OUT OF RNGE/PWR2EXSTR/ESTOP
+-----+ +-----+
| #00010| COMBUSTIBLE GAS, HYDROGEN ABORTS
+-----+ +-----+
| #00011| LOW PRESS. ABORT/PRESS. ALARM
+-----+ +-----+
| #00012| dH/dT DATA CAPTURE
+-----+ +-----+
| #00013| dH/dT ALARM & ABORT
+-----+ +-----+
| #00014| dCG/dT DATA CAPTURE
+-----+ +-----+
| #00015| dCG/dT ALARM & ABORT
+-----+ +-----+
| #00016| dH/dT & dCG/dT Alarm Outputs
+-----+ +-----+

```

THIS PAGE INTENTIONALLY LEFT BLANK

MODSOFT									
Utility	Format	Setting	ChoHndu	Transfer	Template	Disable	Quit		
F1	F2	F3	F4	F5	F6	F7-Lev 8	F8-OFF	F9	
Seg. 1 #2 / 2 TOGGLE HEATOFF0 / SET HIPRABVAL									
<div> <div>()</div> <div>00101</div> </div>									
<div> <div>#0020</div> <div>10003 00101 41205 00007</div> <div>TO.1 ()</div> </div>									
<div> <div>#0180</div> <div>10008 41207</div> <div>T1.0</div> <div>00206</div> </div>									
<div> <div>P</div> <div>00206</div> <div>P</div> <div>00207</div> <div>30005</div> <div>#0800</div> <div>SUB</div> <div>41013</div> <div>41003</div> <div>41013</div> <div>BLKM</div> <div>#0001</div> </div>									
Reference Data									
<div> <div>Format :Decimal</div> <div>Offline</div> <div>Range : 1</div> </div>									

Seq. 1 #3 / 3 ALARM & ABORT INITIS

00101

#0500	#0004	HUL	41300
-------	-------	-----	-------

41301	#0125	ADD	41002
-------	-------	-----	-------

#0500	#0006	HUL	#1302
-------	-------	-----	-------

41301	#0375	1ADD	41004
-------	-------	------	-------

41301	#0000	41005
	ADD	

41301	#0000	ADD	41006
-------	-------	-----	-------

```

#0040
#0000
|ADD
91008

```

```
#0800
#0400
|ADD
41012
```

#0900	#0225	ADD	41001
-------	-------	-----	-------

#0040	#0000	1ADD	41508
-------	-------	------	-------

Reference Data

Format :Decimal

Off line

Range : 1

MODSOFT									
Utility	Format		Setting	ChgHndu	Transfer	Template	Disable	Quit	
F1	F2	F3	F4	F5	F6	F7-Lev 8	F8-OFF	F9	
Seg. 1 #4 / 4 ADU2D6 INIT - UNI/OFFSET EXT RES									
[P]	00101	#0112		#0040					
		#0000		#0000					
		ADD		ADD					
		40001		41401					
[P]	00101	#0112		#0000		#0004			
		#0000		#0000		30001	()		00402
		ADD		ADD		SENS			
		40002		41003		#0001			
Reference Data									
Format :Decimal Offline Range : 1

THIS PAGE INTENTIONALLY LEFT BLANK

MODSOFT									
Utility	Format	Setting	ChgAndu	Transfer	Template	Disable	Quit		
F1	F2	F3	F4	F5	F6	F7-Lev 8	F8-OFF	F9	
Seg. 1 #9 / 9 TEMP OUT OF RANGE/PHR2EXSTR/ESTOP									
<div style="display: flex; justify-content: space-between;"> <div> <div style="border: 1px solid black; padding: 2px;">30002</div> <div style="border: 1px solid black; padding: 2px;">41004</div> <div style="border: 1px solid black; padding: 2px;">SUB</div> <div style="border: 1px solid black; padding: 2px;">41101</div> </div> <div> <div style="border: 1px solid black; padding: 2px;">00002</div> <div style="border: 1px solid black; padding: 2px;">30005</div> <div style="border: 1px solid black; padding: 2px;">41401</div> <div style="border: 1px solid black; padding: 2px;">SUB</div> <div style="border: 1px solid black; padding: 2px;">41101</div> </div> <div> <div style="border: 1px solid black; padding: 2px;">00206</div> <div style="border: 1px solid black; padding: 2px;">00401</div> </div> </div>									
<div style="display: flex; justify-content: space-between;"> <div> <div style="border: 1px solid black; padding: 2px;">10004</div> <div style="border: 1px solid black; padding: 2px;">00015</div> <div style="border: 1px solid black; padding: 2px;">00300</div> <div style="border: 1px solid black; padding: 2px;">10001</div> <div style="border: 1px solid black; padding: 2px;">00008</div> </div> <div> <div style="border: 1px solid black; padding: 2px;">00008</div> </div> </div>									
Reference Data									
<div style="display: flex; justify-content: space-between;"> <div>Format :Decimal</div> <div>Offline</div> <div>Range : 1</div> </div>

APPENDIX E

Coil/Register Utilization Tables

FGTEI Ladder Logic - September 12, 1996

Used OX References

00000	B B B B B B B B	00010	B B B B B M M M
00020	M M M M M M M M	00030	M M M - - - - -
00040	- - - - - - - -	00050	- - - - - - - -
00060	- - - - - - - -	00070	- - - - - - - -
00080	- - - - - - - -	00090	- - - - - - - -
00100	L L L L L L - -	00110	- - - - - - - -
00120	- - - - - - - -	00130	- - - - - - - -
00140	- - - - - - - -	00150	- - - - - - - -
00160	- - - - - - - -	00170	- - - - - - - -
00180	- - - - - - - -	00190	- - - - - - - -
00200	L L L L L L L ?	00210	- - - - - - - -
00220	- - - - - - - -	00230	- - - - - - - -
00240	- - - - - - - -	00250	- - - - - - - -
00260	- - - - - - - -	00270	- - - - - - - -
00280	- - - - - - - -	00290	- - - - - - - -
00300	L L - - - - - -	00310	- - - - - - - -
00320	- - - - - - - -	00330	- - - - - - - -
00340	- - - - - - - -	00350	- - - - - - - -
00360	- - - - - - - -	00370	- - - - - - - -
00380	- - - - - - - -	00390	- - - - - - - -
00400	- L L - - - - -	00410	- - - - - - - -
00420	- - - - - - - -	00430	- - - - - - - -
00440	- - - - - - - -	00450	- - - - - - - -
00460	- - - - - - - -	00470	- - - - - - - -
00480	- - - - - - - -	00490	- - - - - - - -
00500	- - L L L L - -	00510	- - - - - - - -
00520	- - - - - - - -	00530	- - - - - - - -
00540	- - - - - - - -	00550	- - - - - - - -
00560	- - - - - - - -	00570	- - - - - - - -
00580	- - - - - - - -	00590	- - - - - - - -
00600	- - - - - - - -	00610	- - - - - - - -
00620	- - - - - - - -	00630	- - - - - - - -
00640	- - - - - - - -	00650	- - - - - - - -
00660	- - - - - - - -	00670	- - - - - - - -
00680	- - - - - - - -	00690	- - - - - - - -
00700	- - - - - - - -	00710	- - - - - - - -
00720	- - - - - - - -	00730	- - - - - - - -
00740	- - - - - - - -	00750	- - - - - - - -
00760	- - - - - - - -	00770	- - - - - - - -
00780	- - - - - - - -	00790	- - - - - - - -
00800	- - - - - - - -	00810	- - - - - - - -
00820	- - - - - - - -	00830	- - - - - - - -
00840	- - - - - - - -	00850	- - - - - - - -

00860	- - - - -	00870	- - - - -
00880	- - - - -	00890	- - - - -
00900	- - - - -	00910	- - - - -
00920	- - - - -	00930	- - - - -
00940	- - - - -	00950	- - - - -
00960	- - - - -	00970	- - - - -
00980	- - - - -	00990	- - - - -
01000	- - - - -	01010	- - - - -
01020	- - - - -	01030	- - - - -
01040	- - - - -	01050	- - - - -
01060	- - - - -	01070	- - - - -

Key : UPPER CASE LETTER = DOCUMENTED; lower case letter = un-documented

B = In both Logic and I/O

- = Available

L = In Logic only

? = Documented, but not used

M = In I/O only

FGTEI Ladder Logic - July 2, 1996

Used OX References

01080	-	-	-	-	-	-	-	-	-	01090	-	-	-	-	-	-	-	-	-
01100	-	-	-	-	-	-	-	-	-	01110	-	-	-	-	-	-	-	-	-
01120	-	-	-	-	-	-	-	-	-	01130	-	-	-	-	-	-	-	-	-
01140	-	-	-	-	-	-	-	-	-	01150	-	-	-	-	-	-	-	-	-
01160	-	-	-	-	-	-	-	-	-	01170	-	-	-	-	-	-	-	-	-
01180	-	-	-	-	-	-	-	-	-	01190	-	-	-	-	-	-	-	-	-
01200	-	-	-	-	-	-	-	-	-	01210	-	-	-	-	-	-	-	-	-
01220	-	-	-	-	-	-	-	-	-	01230	-	-	-	-	-	-	-	-	-
01240	-	-	-	-	-	-	-	-	-	01250	-	-	-	-	-	-	-	-	-
01260	-	-	-	-	-	-	-	-	-	01270	-	-	-	-	-	-	-	-	-
01280	-	-	-	-	-	-	-	-	-	01290	-	-	-	-	-	-	-	-	-
01300	-	-	-	-	-	-	-	-	-	01310	-	-	-	-	-	-	-	-	-
01320	-	-	-	-	-	-	-	-	-	01330	-	-	-	-	-	-	-	-	-
01340	-	-	-	-	-	-	-	-	-	01350	-	-	-	-	-	-	-	-	-
01360	-	-	-	-	-	-	-	-	-	01370	-	-	-	-	-	-	-	-	-
01380	-	-	-	-	-	-	-	-	-	01390	-	-	-	-	-	-	-	-	-
01400	-	-	-	-	-	-	-	-	-	01410	-	-	-	-	-	-	-	-	-
01420	-	-	-	-	-	-	-	-	-	01430	-	-	-	-	-	-	-	-	-
01440	-	-	-	-	-	-	-	-	-	01450	-	-	-	-	-	-	-	-	-
01460	-	-	-	-	-	-	-	-	-	01470	-	-	-	-	-	-	-	-	-
01480	-	-	-	-	-	-	-	-	-	01490	-	-	-	-	-	-	-	-	-
01500	-	-	-	-	-	-	-	-	-	01510	-	-	-	-	-	-	-	-	-
01520	-	-	-	-	-	-	-	-	-	01530	-	-	-	-	-	-	-	-	-

Key : UPPER CASE LETTER = DOCUMENTED; lower case letter = un-documented
B = In both Logic and I/O - = Available
L = In Logic only ? = Documented, but not used
M = In I/O only

FGTEI Ladder Logic - July 2, 1996

Used IX References

10000	B	M	B	B	M	B	B	M	10010	M	M	M	M	M	M	-	-
10020	-	-	-	-	-	-	-	-	10030	-	-	-	-	-	-	-	-
10040	-	-	-	-	-	-	-	-	10050	-	-	-	-	-	-	-	-
10060	-	-	-	-	-	-	-	-	10070	-	-	-	-	-	-	-	-
10080	-	-	-	-	-	-	-	-	10090	-	-	-	-	-	-	-	-
10100	-	-	-	-	-	-	-	-	10110	-	-	-	-	-	-	-	-
10120	-	-	-	-	-	-	-	-	10130	-	-	-	-	-	-	-	-
10140	-	-	-	-	-	-	-	-	10150	-	-	-	-	-	-	-	-
10160	-	-	-	-	-	-	-	-	10170	-	-	-	-	-	-	-	-
10180	-	-	-	-	-	-	-	-	10190	-	-	-	-	-	-	-	-
10200	-	-	-	-	-	-	-	-	10210	-	-	-	-	-	-	-	-
10220	-	-	-	-	-	-	-	-	10230	-	-	-	-	-	-	-	-
10240	-	-	-	-	-	-	-	-	10250	-	-	-	-	-	-	-	-
10260	-	-	-	-	-	-	-	-	10270	-	-	-	-	-	-	-	-
10280	-	-	-	-	-	-	-	-	10290	-	-	-	-	-	-	-	-
10300	-	-	-	-	-	-	-	-	10310	-	-	-	-	-	-	-	-
10320	-	-	-	-	-	-	-	-	10330	-	-	-	-	-	-	-	-
10340	-	-	-	-	-	-	-	-	10350	-	-	-	-	-	-	-	-
10360	-	-	-	-	-	-	-	-	10370	-	-	-	-	-	-	-	-
10380	-	-	-	-	-	-	-	-	10390	-	-	-	-	-	-	-	-
10400	-	-	-	-	-	-	-	-	10410	-	-	-	-	-	-	-	-
10420	-	-	-	-	-	-	-	-	10430	-	-	-	-	-	-	-	-
10440	-	-	-	-	-	-	-	-	10450	-	-	-	-	-	-	-	-
10460	-	-	-	-	-	-	-	-	10470	-	-	-	-	-	-	-	-
10480	-	-	-	-	-	-	-	-	10490	-	-	-	-	-	-	-	-
10500	-	-	-	-	-	-	-	-	10510	-	-	-	-	-	-	-	-

Key : UPPER CASE LETTER = DOCUMENTED; lower case letter = un-documented
B = In both Logic and I/O - = Available
L = In Logic only ? = Documented, but not used
M = In I/O only

FGTEI Ladder Logic - July 2, 1996

Used 3X Registers

30000	B	B	B	B	B	M	M	M	M	30010	M	-	-	-	-	-	-	-	-
30020	-	-	-	-	-	-	-	-	-	30030	-	-	-	-	-	-	-	-	-
30040	-	-	-	-	-	-	-	-	-	30050									

Key : UPPER CASE LETTER = DOCUMENTED; lower case letter = un-documented
B = In both Logic and I/O - = Available
L = In Logic only ? = Documented, but not used
M = In I/O only

FGTEI Ladder Logic - July 2, 1996

Used 4X Registers

40000	B B	- - - - -	40010	- - - - -
40020	- - - - -	- - - - -	40030	- - - - -
40040	- - - - -	- - - - -	40050	- - - - -
40060	- - - - -	- - - - -	40070	- - - - -
40080	- - - - -	- - - - -	40090	- - - - -
40100	- - - - -	- - - - -	40110	- - - - -
40120	- - - - -	- - - - -	40130	- - - - -
40140	- - - - -	- - - - -	40150	- - - - -
40160	- - - - -	- - - - -	40170	- - - - -
40180	- - - - -	- - - - -	40190	- - - - -
40200	- - - - -	- - - - -	40210	- - - - -
40220	- - - - -	- - - - -	40230	- - - - -
40240	- - - - -	- - - - -	40250	- - - - -
40260	- - - - -	- - - - -	40270	- - - - -
40280	- - - - -	- - - - -	40290	- - - - -
40300	- - - - -	- - - - -	40310	- - - - -
40320	- - - - -	- - - - -	40330	- - - - -
40340	- - - - -	- - - - -	40350	- - - - -
40360	- - - - -	- - - - -	40370	- - - - -
40380	- - - - -	- - - - -	40390	- - - - -
40400	- - - - -	- - - - -	40410	- - - - -
40420	- - - - -	- - - - -	40430	- - - - -
40440	- - - - -	- - - - -	40450	- - - - -
40460	- - - - -	- - - - -	40470	- - - - -
40480	- - - - -	- - - - -	40490	- - - - -
40500	- - - - -	- - - - -	40510	- - - - -
40520	- - - - -	- - - - -	40530	- - - - -
40540	- - - - -	- - - - -	40550	- - - - -
40560	- - - - -	- - - - -	40570	- - - - -
40580	- - - - -	- - - - -	40590	- - - - -
40600	- - - - -	- - - - -	40610	- - - - -
40620	- - - - -	- - - - -	40630	- - - - -
40640	- - - - -	- - - - -	40650	- - - - -
40660	- - - - -	- - - - -	40670	- - - - -
40680	- - - - -	- - - - -	40690	- - - - -
40700	- - - - -	- - - - -	40710	- - - - -
40720	- - - - -	- - - - -	40730	- - - - -
40740	- - - - -	- - - - -	40750	- - - - -
40760	- - - - -	- - - - -	40770	- - - - -
40780	- - - - -	- - - - -	40790	- - - - -
40800	- - - - -	- - - - -	40810	- - - - -
40820	- - - - -	- - - - -	40830	- - - - -
40840	- - - - -	- - - - -	40850	- - - - -

40860	-	-	-	-	-	-	-	-	40870	-	-	-	-	-	-	-
40880	-	-	-	-	-	-	-	-	40890	-	-	-	-	-	-	-
40900	-	-	-	-	-	-	-	-	40910	-	-	-	-	-	-	-
40920	-	-	-	-	-	-	-	-	40930	-	-	-	-	-	-	-
40940	-	-	-	-	-	-	-	-	40950	-	-	-	-	-	-	-
40960	-	-	-	-	-	-	-	-	40970	-	-	-	-	-	-	-
40980	-	-	-	-	-	-	-	-	40990	-	-	-	-	-	-	-
41000	-	L	L	L	L	L	L	L	41010	L	L	L	L	-	-	-
41020	-	-	-	-	-	-	-	-	41030	L	-	-	-	-	-	-
41040	-	-	-	-	-	-	-	-	41050	-	-	-	-	-	-	-
41060	-	-	-	-	-	-	-	-	41070	-	-	-	-	-	-	-

Key : UPPER CASE LETTER = DOCUMENTED; lower case letter = un-documented
 B = In both Logic and I/O - = Available
 L = In Logic only ? = Documented, but not used
 M = In I/O only

FGTEI Ladder Logic - July 2, 1996

Used 4X Registers

41080	-	-	-	-	-	-	-	-	-	41090	-	-	-	-	-	-	-	-	-
41100	-	L	L	L	-	-	-	-	-	41110	-	-	-	-	-	-	-	-	-
41120	-	-	-	-	-	-	-	-	-	41130	-	-	-	-	-	-	-	-	-
41140	-	-	-	-	-	-	-	-	-	41150	-	-	-	-	-	-	-	-	-
41160	-	-	-	-	-	-	-	-	-	41170	-	-	-	-	-	-	-	-	-
41180	-	-	-	-	-	-	-	-	-	41190	-	-	-	-	-	-	-	-	-
41200	L	L	L	?	L	L	-	L	L	41210	-	-	-	-	-	-	-	-	-
41220	-	-	-	-	-	-	-	-	-	41230	-	-	-	-	-	-	-	-	-
41240	-	-	-	-	-	-	-	-	-	41250	-	-	-	-	-	-	-	-	-
41260	-	-	-	-	-	-	-	-	-	41270	-	-	-	-	-	-	-	-	-
41280	-	-	-	-	-	-	-	-	-	41290	-	-	-	-	-	-	-	-	-
41300	I	L	I	L	-	-	-	-	-	41310	-	-	-	-	-	-	-	-	-
41320	-	-	-	-	-	-	-	-	-	41330	-	-	-	-	-	-	-	-	-
41340	-	-	-	-	-	-	-	-	-	41350	-	-	-	-	-	-	-	-	-
41360	-	-	-	-	-	-	-	-	-	41370	-	-	-	-	-	-	-	-	-
41380	-	-	-	-	-	-	-	-	-	41390	-	-	-	-	-	-	-	-	-
41400	-	L	-	-	-	-	-	-	-	41410	-	-	-	-	-	-	-	-	-
41420	-	-	-	-	-	-	-	-	-	41430	-	-	-	-	-	-	-	-	-
41440	-	-	-	-	-	-	-	-	-	41450	-	-	-	-	-	-	-	-	-
41460	-	-	-	-	-	-	-	-	-	41470	-	-	-	-	-	-	-	-	-
41480	-	-	-	-	-	-	-	-	-	41490	-	-	-	-	-	-	-	-	-
41500	-	L	L	-	-	-	-	L	L	41510	L	L	-	-	-	-	-	-	-
41520	-	-	-	-	-	-	-	-	-	41530	-	-	-	-	-	-	-	-	-
41540	-	-	-	-	-	-	-	-	-	41550	-	-	-	-	-	-	-	-	-
41560	-	-	-	-	-	-	-	-	-	41570	-	-	-	-	-	-	-	-	-
41580	-	-	-	-	-	-	-	-	-	41590	-	-	-	-	-	-	-	-	-
41600	-	-	-	-	-	-	-	-	-	41610	-	-	-	-	-	-	-	-	-
41620	-	-	-	-	-	-	-	-	-	41630	-	-	-	-	-	-	-	-	-
41640	-	-	-	-	-	-	-	-	-	41650	-	-	-	-	-	-	-	-	-
41660	-	-	-	-	-	-	-	-	-	41670	-	-	-	-	-	-	-	-	-
41680	-	-	-	-	-	-	-	-	-	41690	-	-	-	-	-	-	-	-	-
41700	-	-	-	-	-	-	-	-	-	41710	-	-	-	-	-	-	-	-	-
41720	-	-	-	-	-	-	-	-	-	41730	-	-	-	-	-	-	-	-	-
41740	-	-	-	-	-	-	-	-	-	41750	-	-	-	-	-	-	-	-	-
41760	-	-	-	-	-	-	-	-	-	41770	-	-	-	-	-	-	-	-	-
41780	-	-	-	-	-	-	-	-	-	41790	-	-	-	-	-	-	-	-	-
41800	-	-	-	-	-	-	-	-	-	41810	-	-	-	-	-	-	-	-	-
41820	-	-	-	-	-	-	-	-	-	41830	-	-	-	-	-	-	-	-	-
41840	-	-	-	-	-	-	-	-	-	41850	-	-	-	-	-	-	-	-	-
41860	-	-	-	-	-	-	-	-	-	41870	-	-	-	-	-	-	-	-	-

Key : UPPER CASE LETTER = DOCUMENTED; lower case letter = un-documented
B = In both Logic and I/O - = Available
L = In Logic only ? = Documented, but not used
M = In I/O only

41864 Timer Register

41865 - 41872 Time/Date Register

APPENDIX F

ADU206 Control Register Reference

ADU 206 40XXX Control Register Quick Reference

EXAMPLE: