LA-SUB--97-40-At.1

RECEIVED

AUG 25 1997

OSTI

CONTRACT 9-XG3-3453J-1

Report on Completion of Task 1.1.1

THE LANL P14 TEMPERATURE CONTROL ELECTRONICS
FOR THE WAVESHAPING FILTER

Norris S. Nahman Consulting Electrical Engineer

Boulder, CO. 80303

December 17, 1993

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

MASTER

Norris S. Nahman

Norris S. Nahman
Ph.D., P.E.

12/17/93

Date

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

kg

DISCLAIMER

Portions of this document may be illegible in electronic image products. Images are produced from the best available original document.

TABLE OF CONTENTS

1. Operating Instructions -----	3
1.1. Environment -----	3
1.2. Operation -----	3
2. Calibration Sequence -----	5
2.1. Calibration of the controller circuits -----	5
2.2. Calibration of the temperature sensing circuits -----	6
3. Maintenance instructions for the electronic circuits -----	9
3.1. General -----	9
3.2. Circuit and assembly notes -----	9
4. Parts Lists -----	11
4.1. Resistors -----	11
4.2. Integrated circuits -----	13
4.3. Diodes -----	13
4.4. Transistors -----	14
4.5. Capacitors -----	14
4.6. Switches -----	15
4.7. Other components -----	15
5. Temperature controller circuit diagrams	
5.1. Temperature sensor head circuit -----	16
5.2. Temperature reference voltage circuits -----	17
5.3. Temperature indicator circuits -----	18
5.4. Heater control amplifier circuits -----	19
5.5. Heater switch circuits -----	20
5.6. Power supply circuits -----	21
5.7. AC wiring circuits -----	22
6. Temperature controller circuit board layouts	
6.1. Component side pulse shaping head circuit board -----	23
6.2. Trace side pulse shaping head circuit board -----	24
6.3. Trace side temperature controller circuit board -----	25
6.4. Component side temperature controller circuit board -----	26

1. Operating Instructions.

Los Alamos National Laboratory, P-14
Waveform Standard Temperature Controller, based on the 1980
NBS/Boulder CO design. NSN, 10/20/92.

1.1. ENVIRONMENT.

- 1.1.1. The Pulse Waveform Standard is designed to be operated in a laboratory environment in which the temperature is controlled and maintained nominally at 22 deg. C (72 deg.F).
- 1.1.2. The unit should be set up in a location free from drafts, sunlight, or other sources which cause temperature variations.
- 1.1.3 The unit should be connected to the operating measurement system, and the two systems should be allowed to operate together continuously for twenty four (24) hours prior to making a calibration measurement using the waveform of the pulse waveform standard.
- 1.1.4. The temperature controller of the Pulse Waveform Standard must be set to operate at 30 deg.C, thus the unit will be held at a temperature higher than that of the environment, 30 deg.C (84 deg.F).

1.2. OPERATION.

- 1.2.1. Before proceeding with placing the unit in operation set the AC line voltage switch on the rear panel of the temperature controller to the mains AC voltage at your installation.
- 1.2.2. Attach the cable which connects the temperature controller to the pulse wave shaping head.
- 1.2.3. Set the temperature controller temperature selector switch to 30 degrees Celsius.
- 1.2.4. Connect recorder channels to the insulated BNC connectors located on the rear panel of the temperature controller. The temperature channel output is 10 mV/degree Celsius, while that of the error channel is 1.0 V/degree Celsius.
- 1.2.5. Turn the unit on.

1. Operating Instructions.

1.2. OPERATION (CONT.).

- 1.2.6. When the temperature is not within a nominal temperature range of plus or minus 0.25 degree Celsius of the selected temperature, the red READY LED will be lit.
- 1.2.7. When the temperature is within a nominal temperature of range plus or minus 0.25 degree Celsius of the selected temperature, the green READY LED will be lit.
- 1.2.8. When the green ready light is on and after the operating temperature has stabilized, the temperature regulator will hold the temperature to a nominal plus and minus 0.1 degree Celsius.
- 1.2.9. IMPORTANT: However, even though the green READY light is on follow the environmental instructions given in 1.0 above before making a calibration measurement.

2. Calibration Sequence.

The calibration procedure consists of two tasks which must be accomplished in the proper order. The first task to be performed is the calibration of the controller circuitry located on the circuit board in the temperature controller unit. The second task is the calibration of the temperature sensing circuits located on the circuit board in the pulse shaping head. This circuit board is found behind the front panel of the pulse shaping head.

2.1. CALIBRATION OF THE CONTROLLER CIRCUITS.

- 2.1.1. The two (controller and pulse shaping head) units should be at ambient temperature; if they are not, turn the system off and wait at least two hours for the system to stabilize at the ambient temperature.
 - 2.1.2. Remove the cable connecting the controller to the pulse shaping head.
 - 2.1.3. Disable the heater circuits by removing the heater disabling jumper, P6 from J6.
 - 2.1.4. Turn on and allow a 30 minute warm-up.
- ## 2. Calibration Sequence.

2.1. CALIBRATION OF THE CONTROLLER CIRCUITS (CONT.).

- 2.1.5. Turn off; Remove IC U8.
- 2.1.6. Using short clip leads ground test points TP1, TP4, and TP6 to the circuit board ground.
- 2.1.7. Turn on.
- 2.1.8. Null IC U7 by adjusting R67 and observing the DC voltage at TP5; the green ready light should turn on.
- 2.1.9. Turn off.
- 2.1.10. Remove IC U4.
- 2.1.11. Turn on.
- 2.1.12. Null IC U3 by adjusting R65 and observing the DC voltage at TP2.
- 2.1.13. Turn off.
- 2.1.14. Reinstall IC U4.
- 2.1.15. Remove ground from TP1 and ground TP2.
- 2.1.16. Ground base of Q1.
- 2.1.17. Turn on.
- 2.1.18. Null IC U4 by adjusting R66 and observing the DC voltage at TP3. This is a high gain comparator; the zero crossing may be approximated by watching the DC meter reading.
- 2.1.19. Turn off.
- 2.1.20. Remove all of the grounding leads.
- 2.1.21. Reinstall IC U8.
- 2.1.22. Remove P5 from J5.
- 2.1.23. Ground TP7.

2.1. Calibration Sequence.

2.1. CALIBRATION OF THE CONTROLLER CIRCUITS (CONT.).

- 2.1.24. Turn on.
- 2.1.25. Null IC U8 by adjusting R64 and observing the DC voltage at TP6.
- 2.1.26. Turn off.
- 2.1.27. Replace P5 onto J5.
- 2.1.28. Remove ground from TP7.
- 2.1.29. Turn on.
- 2.1.30. Check reference voltage at TP6. This value should be minus (-) 3 volts when the controller temperature control is set to 30 Degrees Celsius.

The 20K trim pot R25 provides a small degree of adjustment of the reference voltage. This adjustment should be made using only a 4 and 1/2 digit DVM. When TP6 = 10 X TP1, TP5 voltage should be zero. R67 should be adjusted slightly to make TP5 zero.

- 2.1.31. Replace heater disable jumper P6 onto J6; the red LED on the circuit board positioned next to P6/J6 should light when the jumper is reconnected.
- 2.1.32. Turn off.

2.2. CALIBRATION OF THE TEMPERATURE SENSING CIRCUITS.

- 2.2.1. On the temperature controller circuit board disable the heater circuits by removing the heater disabling jumper, P6 from J6.
- 2.2.2. Connect the cable connecting the controller to the pulse shaping head.
- 2.2.3. Remove the eight (8) screws holding the pulse shaping head front panel and rotate the panel downward to a horizontal position.
- 2.2.4. Note the black dot on the brass support block which marks the position for placing the temperature probe for calibration purposes.
- 2.2.5. Note the circuit board position in the circuit board slots as the circuit board must be returned to the same slot position.
- 2.2.6. Place some static free insulation below the circuit board slots and wedge it between the rotated panel plate and the pulse shaping housing, and on top of the coaxial line.

2. Calibration Sequence.

2.2. CALIBRATION OF THE TEMPERATURE SENSING CIRCUITS (CONT.).

- 2.2.7. Carefully withdraw the circuit board from its slot and place it on the insulator surface ensuring that the board's components, etc. are not in contact with the metal structure of the pulse shaping head.
- 2.2.8. Remove IC's U2 and U6.
- 2.2.9. Turn on.
- 2.2.10. Measure and monitor the brass block temperature at the black dot.
- 2.2.11. Refer to the Sensor Circuit Board Layout Drawing Top View. Attach a high impedance DVM to the Test Point "A" which connects to pin 3 of the IC U2 socket.
- 2.2.12. Adjust trim pot R84 to the voltage corresponding to the temperature observed in step 2.10 which should be 10 mVolts/degree Celsius. For example, 231 mVolts would correspond to 23.1 degrees Celsius.
- 2.2.13. Refer to the Sensor Circuit Board Layout Drawing Top View. Attach a high impedance DVM to the Test Point "B" which connects to pin 3 of the IC U6 socket.
- 2.2.14. Adjust trim pot R90 to the voltage corresponding to the temperature observed in step 2.10 which should be 10 mVolts/degree Celsius. For example, 231 mVolts would correspond to 23.1 degrees Celsius.
- 2.2.15. Turn off.
- 2.2.16. Reinstall IC's U2 and U6.
- 2.2.17. On the temperature controller circuit board remove IC U8.
- 2.2.18. On the temperature controller circuit board ground TP6.
- 2.2.19. Remove the plug PS from the temperature sensors U1 and U5 mounted on the brass block in the pulse shaping head.
- 2.2.20. On the plug PS insert jumper wires into pins 5,6,7,8,9, and 10 and connect them together; this shorts the inputs of the op-amps U2 and U6 which will allow their offsets to be set to zero.
- 2.2.21. Refer to the Sensor Circuit Board Layout Drawing Top View. Set the IC U2 offset to zero by adjusting R62 and observing the DC voltage at the "U2 Control Output Test Point" (the right hand wire of R86) which connects to pin 6 of IC U2. This point is electrically the same as test point TP1 on the controller board.

2. Calibration Sequence.

2.2. CALIBRATION OF THE TEMPERATURE SENSING CIRCUITS (cont.).

- 2.2.22. Refer to the Sensor Circuit Board Layout Drawing Top View. Set the IC U6 offset to zero by adjusting R63 and observing the DC voltage at the "U6 Control Output Test Point" (the right hand wire of R92) which connects to pin 6 of IC U6. This point is electrically the same as test point TP4 on the controller board.
- 2.2.23. Turn off.
- 2.2.24. Remove the jumper wires from PS and reconnect PS to the temperature sensors.
- 2.2.25. Carefully replace the temperature sensing circuit board in its original circuit board slot.
- 2.2.26. Ensure that the temperature sensor connection JS/PS has not become disconnected during the reinstallation of the circuit board.
- 2.2.27. Reinstall the pulse shaping head front panel.
- 2.2.28. On the temperature controller circuit board replace IC U8.
- 2.2.29. On the temperature controller circuit board remove the ground from TP6.
- 2.2.30. On the temperature controller circuit board replace the heater disable jumper P6 onto J6.

The calibration is now complete. Operate the system with the temperature controller set to 30 degrees Celsius. The performance of the temperature controller can be monitored by connecting DVM's or recorder channels to the BNC connectors on the rear panel of the temperature controller. The BNC connectors are insulated from the chassis. The Temperature Output Connector provides the same voltage that appears at test point TP4 while the Error Output Connector provides the same voltage appearing at Test Point TP5.

Note 1. After the system has been run for 24 hours, the Error Voltage offset may be adjusted so that the error fluctuates about zero volts by adjusting the trim pot. R67, the offset control for IC U7. In normal operation the green LED ready light will only remain lit when the error voltage is between plus and minus 250 mVolts which corresponds to plus and minus 0.25 degree C.

3. Maintenance Instructions for the Electronic Circuits.

The following instructions are for the maintenance of the electronic circuits found in the temperature controller and in the pulse waveform shaping head. The liquid filled coaxial line in the pulse waveform shaping head is a sealed unit and no instructions are given here to repair the coaxial structure if it is mechanically damaged.

3.1. GENERAL.

3.1.1. The LANL P14 pulse waveform standard is a copy of the National Bureau of Standards (NBS) Pulse Transition Duration Standard, Model 100-2, which includes the NBS 724-04 temperature controller. However, some of the circuitry in the LANL P14 unit may be slightly different from that in the NBS unit.

3.1.2. P14 maintenance personnel should refer to the internal NBS report entitled " N.B.S. Transition Duration Standard Electronics", by E. E. Baldwin for the principles of operation of the electronic circuits in temperature controller and pulse shaping head. (A copy of the NBS report is in the P14 file for the LANL set of NBS Reference Waveform Standards.)

3.1.3. For trouble shooting, repairs and calibration procedures only use the LANL P14 circuit diagrams, parts list, circuit board layouts, and calibration sequence.

3.2. CIRCUIT AND ASSEMBLY NOTES.

3.2.1. The temperature controller circuit board has insulating nylon washers between the bottom of the circuit board (i.e., the copper trace side) and the metal stand-off posts supporting the circuit board. If the circuit board is removed, when replacing the circuit board, be sure to include the nylon washers.

3.2.2. Unpolarized plugs connecting to circuit board mounted jacks are position coded by a silver dot painted on the plug and a corresponding silver dot painted on the circuit board.

3. Maintenance Instructions for the Electronic Circuits.

3.2. CIRCUIT AND ASSEMBLY NOTES (cont.).

- 3.2.3. If the circuit board in the pulse waveform shaping head must be removed for calibration or repair, for its removal follow the instructions given in the Calibration Sequence, Steps 2.1- 2.7 and its replacement, Step 2.23.
- 3.2.4. If the red or green (wait or ready) LED mounted on the front panel of the temperature controller needs to be replaced, the entire LED circuit board must be removed from the front panel.

To do so, grasp the top and bottom of the LED circuit board with a thumb and forefinger and then carefully rock the circuit board up and down while pulling away from the rear of the front panel. The LED's with their rubber inserts on the LED leads will come free from the panel mounted LED holders. Remove the faulty LED by desoldering it from the LED circuit board. Be sure to install the rubber insert on the new LED before soldering it to the circuit board.

4. Parts List.

4.1. RESISTORS.

P/N	VALUE	DESCRIPTION
R1	34 K	RESISTOR:
R2	1.00 K	RESISTOR: 0.1%, 1W
R3	1.00 K	RESISTOR: 0.1%, 1W
R4	1.00 K	RESISTOR: 0.1%, 1W
R5	1.00 K	RESISTOR: 0.1%, 1W
R6	1.00 K	RESISTOR: 0.1%, 1W
R7	1.00 K	RESISTOR: 0.1%, 1W
R8	1.00 K	RESISTOR: 0.1%, 1W
R9	1.00 K	RESISTOR: 0.1%, 1W
R10	1.00 K	RESISTOR: 0.1%, 1W
R11	1.00 K	RESISTOR: 0.1%, 1W
R12	25 K	RESISTOR:
R13	24	RESISTOR: 5%, 1/4W, C.F.
R14	0.0	RESISTOR: 5%, 1/4W, C.F.
R15	4.7	RESISTOR: 5%, 1/4W, C.F.
R16	39	RESISTOR: 5%, 1/4W, C.F.
R17	100	RESISTOR: 5%, 1/4W, C.F.
R18	191	RESISTOR: 5%, 1/4W, C.F.
R19	300	RESISTOR: 5%, 1/4W, C.F.
R20	470	RESISTOR: 5%, 1/4W, C.F.
R21	630	RESISTOR: 5%, 1/4W, C.F.
R22	820	RESISTOR: 5%, 1/4W, C.F.
R23	1082	RESISTOR: 5%, 1/4W, C.F.
R24	4.7 K	RESISTOR: 5%, 1/4W, C.F.
R25	20 K	MULTITURN TRIM POT
R26	17.5 K	RESISTOR: 1%, 1/4W, C.F.
R27	10.0 K	RESISTOR: 1%, 1/4W, C.F.
R28	10.0 K	RESISTOR: 1%, 1/4W, C.F.
R29	91	RESISTOR: 5%, 1/4W, C.F.
R30	909	RESISTOR: 1%, 1/4W, C.F.
R31	100 K	RESISTOR: 1%, 1/4W, C.F.
R32	910	RESISTOR: 5%, 1/4W, C.F.
R33	1.0 K	RESISTOR: 5%, 1/4W, C.F.
R34	1.0 K	RESISTOR: 5%, 1/4W, C.F.
R35	47 K	RESISTOR: 5%, 1/4W, C.F.
R36	1.5 K	RESISTOR: 5%, 1/2W, C.F.
R37	2.0 K	RESISTOR: 5%, 1/4W, C.F.
R38	10 K	RESISTOR: 5%, 1/4W, C.F.
R39	1.5 K	RESISTOR: 5%, 1/4W, C.F.

4. Parts List.

4.1. RESISTORS (cont.).

P/N	VALUE	DESCRIPTION
R40	10 K	RESISTOR: 5%, 1/4W, C.F.
R41	10 K	RESISTOR: 5%, 1/4W, C.F.
R42	1.0 K	RESISTOR: 5%, 1/4W, C.F.
R43	10 K	RESISTOR: 5%, 1/4W, C.F.
R44	100	RESISTOR: 5%, 1/4W, C.F.
R45	1.0 K	RESISTOR: 5%, 1/4W, C.F.
R46	91	RESISTOR: 1%, 1/4W, C.F.
R47	909	RESISTOR: 1%, 1/4W, C.F.
R48	100 K	RESISTOR: 1%, 1/4W, C.F.
R49	910	RESISTOR: 5%, 1/4W, C.F.
R50	1.0 K	RESISTOR: 5%, 1/4W, C.F.
R51	2.0 K	RESISTOR: 1%, 1/4W, C.F.
R52	2.0 K	RESISTOR: 1%, 1/4W, C.F.
R53	104 K	RESISTOR: 1%, 1/4W, C.F.
R54	104 K	RESISTOR: 1%, 1/4W, C.F.
R55	1.0 K	RESISTOR: 1%, 1/4W, C.F.
R56	1.0 K	RESISTOR: 1%, 1/4W, C.F.
R57	15 K	RESISTOR: 1%, 1/4W, C.F.
R58	10 K	RESISTOR: 1%, 1/4W, C.F.
R59	10 K	RESISTOR: 1%, 1/4W, C.F.
R60	470	RESISTOR: 1%, 1/4W, C.F.
R61	470	RESISTOR: 1%, 1/4W, C.F.
R62	20 K	MULTITURN TRIM POT
R63	20 K	MULTITURN TRIM POT
R64	20 K	MULTITURN TRIM POT
R65	20 K	MULTITURN TRIM POT
R66	20 K	MULTITURN TRIM POT
R67	20 K	MULTITURN TRIM POT
R68	0.0	RESISTOR: jumper 1/4W size
R69	0.0	RESISTOR: jumper 1/4W size
R70	0.0	RESISTOR: jumper 1/4W size
R71	0.0	RESISTOR: jumper 1/4W size
R72	0.0	RESISTOR: jumper 1/4W size
R73	0.0	RESISTOR: jumper 1/4W size
R74	0.0	RESISTOR: jumper 1/4W size
R75	470	RESISTOR: 5%, 1/4W, C.F.
R76	15	RESISTOR: 15W, W.W. (heater)
R77	15	RESISTOR: 15W, W.W. (heater)
R78	1.0	RESISTOR: 5%, 1/2W, C.C.
R79	1.0	RESISTOR: 5%, 1/2W, C.C.

4. Parts List.

4.1. RESISTORS (cont.).

P/N	VALUE	DESCRIPTION
R80	1.0	RESISTOR: 5%, 1/2W, C.C. (sensor heater)
R81	12 K	RESISTOR: 1%, 1/4W, C.F.
R82	27.4 K	RESISTOR: 1%, 1/4W, C.F.
R83	39 K	RESISTOR: 1%, 1/4W, C.F.
R84	5 K	MULTITURN TRIM POT
R85	5.6 K	RESISTOR: 1%, 1/4W, C.F.
R86	16 K	RESISTOR: 1%, 1/4W, C.F.
R87	12 K	RESISTOR: 1%, 1/4W, C.F.
R88	27.4 K	RESISTOR: 1%, 1/4W, C.F.
R89	39 K	RESISTOR: 1%, 1/4W, C.F.
R90	5 K	MULTITURN TRIM POT
R91	5.6 K	RESISTOR: 1%, 1/4W, C.F.
R92	16 K	RESISTOR: 1%, 1/4W, C.F.
R93	470	RESISTOR: 5%, 1/4W, C.F.
R94	1.0 K	RESISTOR: 5%, 1/4W, C.F.

4.2. INTEGRATED CIRCUITS.

P/N	VALUE	DESCRIPTION
U1	LM3911	IC: TEMP. SENSOR
U2	OP-07	IC: OP. AMP
U3	OP-07	IC: OP. AMP
U4	OP-07	IC: OP. AMP
U5	LM-3911	IC: OP. AMP
U6	OP-07	IC: OP. AMP
U7	OP-07	IC: OP. AMP
U8	OP-07	IC: OP. AMP
U9	IL-5	IC: OPTO-ISOLATOR
U10	LM301	IC: OP. AMP
U11	LM301	IC: OP. AMP
U12	LM399H	IC: 6.9V VOLTAGE REFERENCE
U13	7812	IC: 12V VOLTAGE REGULATOR
U14	7912	IC: -12V VOLTAGE REGULATOR

4.3. DIODES.

P/N	VALUE	DESCRIPTION
D1	1N5230	DIODE: 4.7V ZENER
D2		DIODE: GREEN LED (front panel)
D3		DIODE: RED LED (front panel)
D4		DIODE: RED LED
D5		DIODE: RED LED (front panel, diode and front panel socket not installed)

4. Parts List.

4.3. DIODES (cont.).

D6	1N4004	RECTIFIER: +12V SUPPLY
D7	1N4004	RECTIFIER: +12V SUPPLY
D8	1N4004	RECTIFIER: -12V SUPPLY
D9	1N4004	RECTIFIER: -12V SUPPLY
D10	1N4004	RECTIFIER: +30V FULL WAVE SUPPLY
D11	1N4004	RECTIFIER: +30V FULL WAVE SUPPLY
D12	1N4004	RECTIFIER: +30V BRIDGE SUPPLY (not connected)
D13	1N4004	RECTIFIER: +30V BRIDGE SUPPLY (not connected)

4.4. Transistors.

P/N	VALUE	DESCRIPTION
Q1	2N3904	TRANSISTOR: OPTO-ISOLATOR DRIVER
Q2	2N3906	TRANSISTOR: HEATER SWITCH CIRCUIT
Q3	2N3906	TRANSISTOR: HEATER SWITCH CIRCUIT
Q4	2N4922	TRANSISTOR: HEATER DRIVER
Q5	2N3055	TRANSISTOR: HEATER DRIVER
Q6	2N3904	TRANSISTOR: LED INDICATORS DRIVER
Q7	2N3904	TRANSISTOR: LED INDICATORS DRIVER
Q8	2N3906	TRANSISTOR: RED LED WAIT INDICATOR DRIVER
Q9	2N3906	TRANSISTOR: GREEN LED READY INDICATOR DRIVER

4.5. CAPACITORS.

P/N	VALUE	DESCRIPTION
C1	0.1 UF	CAPACITOR: 12V, DISC CERAMIC
C2	0.1 UF	CAPACITOR: 12V, DISC CERAMIC
C3	1000 PF	CAPACITOR: 50V, MYLAR
C4	0.01 UF	CAPACITOR: 50V, DISC CERAMIC
C5	0.1 UF	CAPACITOR: 12V, DISC CERAMIC

4. Parts List.

4.5. CAPACITORS (cont.).

P/N	VALUE	DESCRIPTION
C6	1.0 UF	CAPACITOR: 12V, DISC CERAMIC
C7	0.01 UF	CAPACITOR: 50V, DISC CERAMIC
C8	22 UF	CAPACITOR: 16V, ELECTROLYTIC
C9	10 UF	CAPACITOR: 16V, ELECTROLYTIC
C10	0.01 UF	CAPACITOR: 50V, DISC CERAMIC
C11	10 UF	CAPACITOR: 16V, ELECTROLYTIC
C12	0.01 UF	CAPACITOR: 50V, DISC CERAMIC
C13	1000 UF	CAPACITOR: 35V, ELECTROLYTIC
C14	10 UF	CAPACITOR: 35V, ELECTROLYTIC
C15	10 UF	CAPACITOR: 16V, ELECTROLYTIC
C16	1000 UF	CAPACITOR: 35V, ELECTROLYTIC
C17	10 UF	CAPACITOR: 35V, ELECTROLYTIC
C18	10 UF	CAPACITOR: 16V, ELECTROLYTIC
C19	2200 UF	CAPACITOR: 35V, ELECTROLYTIC

4.6. SWITCHES.

P/N	VALUE	DESCRIPTION
S1	2P1T	FRONT PANEL AC POWER TOGGLE SW.
S2	2P2T	REAR PANEL AC VOLTAGE SLIDE SELECTOR SW.
S3	1P11T	FRONT PANEL TEMP. SELECTOR ROTARY SW.

4.7. OTHER COMPONENTS.

P/N	VALUE	DESCRIPTION
J1	3 WIRE	IEE MAINS RECEPTICLE/EMI FILTER
F1	3AG/1AMP	FUSE
FH1	3AG	REAR PANEL FINGER GRIP FUSE HOLDER
T1		PRI:115/230 VAC,50/60 HZ. SEC:14/28 VAC

LANL NBS 724-04
 P-L4 Temp. Controller
 Temperature Sensor
 Head Circuits.
 10/20/92 NSN

→ 14 pin DIP Socket Numbers
 Jack on Circuit board.

heater
 mounted on
 input block

LANL NBS 724-04
P-14 Temp. Controller
Temperature Reference
Voltage Circuits.
10/20/92 NSN

100X Error Amp

Window Comparator

FRONT PANEL LED INDICATOR LIGHTS

Ready LED is on when the temperature is greater or less than reference temperature $\pm 0.1^{\circ}\text{C}$, respectively.

To insulated BNC connectors on rear panel.

LANL NBS 729-04
P-14 Temp. Controller
Temperature Indicator Circuits
10/20/92 NSN

RTASK11L.

D12 & D13 optional
used for bridge ckt.

LANL NBS 724-04
P-14 Temp. Controller
Power Supply
Circuits.
10/20/92 NSN

2/19/93

P.S. Common Ref.
Test Point

Temp. Sensor
Offset Adj.

optional jumper
to connect P.S. common
line to case.

U6 Temp.
Output
Test Point
(Same as TP4
on temperature
controller board)

Component SIDE
View

U2 Control
Output
Test Point
(Same as TP1
on Temperature
controller board)

Control
Sensor
Offset
Adj.

Test
Point "A"

Temp.
Sensor
Calib.

Control
Sensor
Calib.

Pulse Shaping Head Circuit Board.

Location of Jumper Wires

2/19/93

1.5"

Component Side View

2.375"

PULSE SHAPING HEAD CIRCUIT BOARD

Copper Trace
Side View.

TEMPERATURE CONTROLLER CIRCUIT BOARD

Page-25 of 26 Pages RTASK111.

Copper Trace
Side View.

W. Davis
2020 15 EC

12

Component Side
View.

TEMPERATURE CONTROLLER CIRCUIT BOARD
Page 26 of 26 Pages RTASK111

e"