NOTICE

**CERTAIN DATA
CONTAINED IN THIS
DOCUMENT MAY BE
DIFFICULT TO READ
IN MICROFICHE
PRODUCTS.**

WSRC-RP--92-491

DE92 015335

RCRA FACILITY INVESTIGATION: ROAD A CHEMICAL BASIN (U)

by

Westinghouse Savannah River Company
Savannah River Site
Aiken, South Carolina 29808

An EPA/SCDHEC & General Public

Approved for Release
JUN 11 1992

This report was prepared in connection with work done under Contract No. DE-AC09-89SR18035 with the U.S. Department of Energy. By acceptance of this report, the publisher and/or recipient acknowledges the U.S. Government's right to retain a nonexclusive, royalty-free license in and to any copyright covering this report, along with the right to reproduce and to authorize others to reproduce all or part of the copyrighted report.

MASTER

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

SAVANNAH RIVER SITE

**RCRA
FACILITY INVESTIGATION PLAN**

Road A Chemical Basin (U)

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by the trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

June 1989

**Westinghouse Savannah River Company
Savannah River Site
Aiken, SC 29808**

PREPARED FOR THE U. S. DEPARTMENT OF ENERGY UNDER CONTRACT DE-AC09-88SR18035

This Page Intentionally Left Blank.

CONTENTS

	<u>Page</u>
EXECUTIVE SUMMARY	1
1.0 INTRODUCTION	
1.1 Site Conditions	1-1
1.1.1 Location and History	1-1
1.1.2 Hydrogeologic Framework at SRS	1-4
1.2 RFI Plan	1-8
2.0 SAFETY, HEALTH, AND EMERGENCY RESPONSE PLAN	2-1
2.1 Introduction	2-1
2.2 Coordination and Responsibility	2-5
2.3 Training of Personnel	2-5
2.4 Medical Surveillance and Bioassay	2-6
2.5 Recordkeeping	2-7
2.6 Required Personal Protection Equipment and Procedures	2-8
2.7 Standard Safety Procedures and Controls	2-10
2.8 Site Control Measures	2-11
2.9 Emergency Procedures and Equipment	2-13
2.10 Emergency Spill Response	2-14
2.11 Emergency Services and Telephone Numbers	2-14
3.0 QUALITY ASSURANCE/QUALITY CONTROL (QA/QC) PLAN	3-1
3.1 Introduction	3-1
3.2 QA Requirements	3-3
3.2.1 Organization	3-3
3.2.2 Reporting Requirements and Project Deliverables	3-4
3.2.3 Document Control	3-6
3.2.4 Training Requirements	3-7
3.3 General QC Requirements for Sampling and Field Measurements	3-7
3.3.1 Sample Order	3-8
3.3.2 Control of Measuring and Test Equipment	3-8
3.3.3 Documentation Procedures for Preparation of Reagents or Supplies Which Become Part of the Samples	3-14
3.3.4 Sample Container Requirements	3-15
3.3.5 Sample Identification and Labeling	3-16
3.3.6 Field Notes	3-25
3.3.7 Photographs	3-28
3.3.8 Sample Handling	3-30

CONTENTS continued

Page

3.3.9	Sample Chain-of-Custody	3-31
3.3.10	Request for Analysis Form	3-37
3.3.11	Sample Packaging	3-37
3.3.12	Sampling Equipment Decontamination Procedures	3-42
3.3.13	Field Analytical Instrument Decontamination	3-46
3.3.14	Field Quality Control Samples	3-46
3.4	Media-Specific QC Considerations	3-50
3.4.1	Soil Sampling QC Methodology	3-50
3.4.2	Groundwater Sampling QC Methodology	3-58
3.4.3	Surface Water/Sediment Sampling QC Methodology	3-61
3.4.4	Health and Safety Monitoring QC Methodology	3-
3.5	Laboratory QA/QC	3-73
3.6	Required Documentation	3-74
3.7	Storage of Contractor Deliverables and Records	3-76
3.8	Site Inspections and Audits	3-76
3.9	Control of Nonconforming Items	3-77
4.0	DATA MANAGEMENT REQUIREMENTS	4-1
4.1	Introduction	4-1
4.2	Contractor and SRS Personnel Data Management Responsibilities	4-2
4.2.1	Oversight Contractor Project Manager	4-2
4.2.2	Oversight Contractor Field Oversight Coordinator	4-2
4.2.3	Oversight Contractor Health and Safety Officer	4-3
4.2.4	Laboratory Contractor QA Manager	4-3
4.2.5	SRS RFI Program Team and Task Order Manager	4-3
4.3	Recording of Field Data	4-4
4.3.1	Additional Field Data	4-5
4.3.2	Photographs	4-6
4.3.3	Other Field Data Not Part of the Field Log Book	4-6
4.4	Recording of Laboratory Data	4-7
4.4.1	Field Laboratory Data Requirements	4-9

CONTENTS continued

Page

4.4.2	Off-Site Laboratory Data Requirements	4-10
4.5	Recording of Development Data	4-11
4.6	Recording of SHERP Data	4-11
4.7	RFI Data Reporting Requirements	4-12
4.7.1	Progress Reports	4-12
4.7.2	RFI Final Report Requirements	4-13
4.7.3	Quality of Reports	4-15
4.8	Directives	4-15
5.0	RESULTS OF PREVIOUS INVESTIGATIONS	5-1
5.1	Contaminant Characterization	5-1
5.2	Hydrogeology	5-2
6.0	SITE SCREENING PLAN	6-1
7.0	SITE ASSESSMENT PLAN	7-1
7.1	Soil Assessment Sampling	7-1
7.2	Groundwater Assessment Sampling	7-7
7.3	Surface Water and Sediment Assessment Sampling Plan	7-9
7.4	Ambient Air Assessment Sampling	7-14
7.5	Management and Collection of Samples	7-14
8.0	CONCLUSIONS AND RECOMMENDATIONS	8-1
9.0	REFERENCES	9-1
Appendix A--Safety Manual - Item 104		
Appendix B--Groundwater Sampling Results		

TABLES

Page

3-1	Containers, Preservation, Storage, and Holding Times	3-17
7-1	Summary of RACB Soil Assessment Sampling 7-6	

FIGURES

1-1	Vicinity of Road A Chemical Basin	1-2
1-2	Road A Chemical Basin	1-3
1-3	Coastal Plain Sediments at SRS	1-6
1-4	Hydrologic and Stratigraphic Units	1-9
2-1	Generic Schematic for RFI Site Control--General	2-12
3-1	SRS RFI Program Plan QA Organization and Interfaces	3-5
3-2	Sample Instrument Calibration	3-13
3-3	Chain-of-Custody Form	3-34
3-4	Completed Chain-of-Custody Form	3-38
3-5	Completed Request for Analysis Form	3-39
4-1	Field Data Collection Form--Groundwater Sampling	4-8
5-1	Monitoring Wells for RACB	5-3
5-2	Well Hydrographs for RACB	5-5
7-1	Soil Assessment Sampling Locations	7-4
7-2	Monitoring Well Locations	7-8
7-3	Surface Water/Sediment Sample Locations	7-11

EXECUTIVE SUMMARY

The nature of wastes disposed of at the Road A Chemical Basin (RACB) is such that some degree of soil contamination is probable. Lead has also been detected in site monitoring wells at concentrations above SRS background levels.

A RCRA Facility Investigation (RFI) is proposed for the RACB and will include a ground penetrating radar (GPR) survey, collection and chemical and radiological analyses of soil cores, installation of groundwater monitoring wells, collection and chemical and radiological analyses of groundwater samples, and collection and chemical and radiological analyses of surface water and sediment samples.

The specific RFI work to be conducted at the RACB includes:

- A GPR survey
- Drilling and sampling of 9 soil borings to depths ranging from 10 to 35 feet
- Installation of one additional monitoring well in the water table aquifer. The installation of two monitoring wells in the Congaree unit if

contamination is detected in the new Water Table well.

- Sampling and analyses of groundwater samples from five monitoring wells.
- Collection and analyses of two surface water and two sediment samples from a wetlands area downslope of the RACB

The RFI work will be conducted in accordance with procedures presented in the RCRA Facility Investigation Program Plan (RFIPP), Hydrogeologic Data Collection (DPSOP 254), and this RFI plan.

Section 1
INTRODUCTION

This RCRA Facility Investigation (RFI) plan was prepared in partial fulfillment of the requirements of Part V of the Savannah River Site (SRS) Hazardous Waste Permit.

1.1 SITE CONDITIONS

1.1.1 LOCATION AND HISTORY

The Road A Chemical Basin (RACB) is in the southwestern section of SRS, approximately 1/2 mile southwest of the intersection of SRS Road A (South Carolina Rt. 125) and SRS Road 6, and approximately 4 miles from the nearest plant boundary (Figure 1-1).

A description of the RACB is presented in the site Environmental Information Document (EID) (Pickett et al., 1987). The original basin was approximately 100 feet wide, 175 feet long, and 8 to 10 feet deep. The basin was backfilled in 1973, and an area approximately 400 feet by 450 feet around the basin was regraded. A plan of the basin showing its estimated boundaries is presented in Figure 1-2.

SRS
North

1 Mile

Figure 1-1
VICINITY OF ROAD A CHEMICAL BASIN

Legend

- Existing Monitoring Well
- ▭ Graded and Revegetated Areas

**Figure 1-
ROAD A CHEMICAL BASIN**

Figure 1-1 Figure 1-2 Little is known about the history of disposal at the basin; dates of operation and the nature and quantities of materials disposed of have not been determined. The EID states that the contents of the basin have been reported as miscellaneous radioactive and chemical aqueous wastes. Photos show the basin in operation with standing liquids present.

1.1.2 HYDROGEOLOGIC FRAMEWORK AT SRS

At SRS, groundwater and surface water characteristics are largely controlled by physiography and stratigraphy. The following is a summary of the primary physiographic features, general stratigraphic succession, and known hydrogeology at SRS. The purpose of this framework is to describe the relationships between SRS hydrogeology and larger-scale hydrologic systems.

1.1.2.1 Physiography

SRS occupies an area of approximately 300 square miles on the Atlantic Coastal Plain and lies predominantly on the Aiken Plateau. The Plateau is bounded by the Piedmont Province at the Fall Line, the Savannah and Congaree Rivers, and an elevation break of approximately 250 feet above sea level. The Savannah and Congaree Rivers are the largest in the

region, with the Savannah River forming the southwestern boundary of SRS and the Congaree River approximately 60 miles northeast of SRS. The smaller Edisto and Salkehatchie Rivers lie between the Savannah and Congaree Rivers.

1.1.2.2 Topography and Drainage

Ground surface elevations at SRS range from approximately 100 to 350 feet above mean sea level. On the Aiken Plateau there are several southwesterly flowing tributaries of the Savannah River. The major tributaries that cross SRS are Upper Three Runs Creek, Beaver Dam Creek, Four Mile Creek, Pen Branch, Steel Creek, and Lower Three Runs Creek.

1.1.2.3 Geology

The Atlantic Coastal Plain is underlain by a seaward-thickening wedge of unconsolidated and semi-consolidated sediments ranging from Late Cretaceous to Holocene in age. The Late Cretaceous sediments rest directly on crystalline basement rocks of Precambrian/ Paleozoic age or on Triassic age sediments. A generalized stratigraphic column for coastal plain sediments at SRS is shown in Figure 1-3.

The crystalline basement rock is composed of chlorite-hornblende schist, hornblende gneiss, and traces of other crystalline rocks. At SRS, this bedrock is buried beneath

Figure 1-3
COASTAL PLAIN SEDIMENTS AT SRS

about 900 feet of sediments. The Triassic bedrock occurs in Figure 1-3 the southern portion of SRS in a basin known as the Dunbarton Basin. The Dunbarton Basin sediments are composed of poorly sorted conglomerate, sandstone, and mud-rock, and are generally dark red in color.

In the 1930s, the Cretaceous sediments overlying the bedrock were correlated with the Tuscaloosa Group of Mississippi and Alabama. Newer data indicate that the sediments correlate instead with the Eutaw and Selma Groups. The Cretaceous sediments comprise four major divisions beneath SRS: the Cape Fear, Middendorf, Black Creek, and Pee Dee Formations.

Paleocene age sediments of the Black Mingo Group overlie the Cretaceous sediments and are most commonly clays or clayey sands. Eocene sediments, which correlate with the Orangeburg Group of the Claibornian age, overlie the Paleocene sediments. The lower part of this stage is represented by a sandy unit called the Congaree Formation. The upper part of this stage contains mappable sediments known as the Warley Hill, Caw Caw, and McBean members of the Santee Limestone.

Late Eocene age sediments of the Barnwell Group overlie the Orangeburg Group. These include the Dry Branch and Tobacco Road Formations, plus an upland unit, which is mappable yet

unnamed, and which caps most upland areas at SRS. Lithology of the unit varies from coarse gravels to silty clays.

1.1.2.4 Hydrogeology

At SRS, the Middendorf/ Lower Black Creek, the Upper Black Creek/ Pee Dee, the Congaree, and a portion of the Dry Branch Formations are aquifers. The Cape Fear and sections of the Black Creek Formation, the Black Mingo Group, the Caw Caw and most of the McBean members of the Santee Limestone, and the Twiggs clay member of the Dry Branch Formation are considered to be aquitards. Figure 1-4 correlates hydrologic and stratigraphic units at SRS.

The Twiggs clay is discontinuous and therefore is an effective aquitard on only a very local basis. This clay can occur at various levels within the Dry Branch Formation and has often been called the "tan" clay. The Caw Caw Member of the Santee Limestone, a dark green to black shale, has also been called the "green" clay.

1.2 RFI PLAN

The RFI plan for the RACB is presented in the following sections:

Hydrologic Units (Zones)		Stratigraphic Units		Former Name
8		Upland	Tobacco Road	Tan Clay McBean
7	7c	Dry Branch		
	7b			
	7a			
6		Santee		Green Clay Congaree
5	5b	Congaree		
	5a			
4		Williamsburg		Ellenton
		Rhems		
3	3b	Pee Dee		Upper Tuscaloosa Aquifer
	3a			
2	2c	Black Creek		Middle Tuscaloosa Confining Unit
	2b			
	2a	Middendorf		
1		Cape Fear		Basal Confining Unit

Figure 1-4
HYDROLOGIC AND STRATIGRAPHIC UNITS

- Section 1 -Introduction
- Section 2 - Safety, Health, and Emergency
Response Plan
- Section 3 - Quality Assurance/Quality Control Plan
- Section 4 - Data Management Requirements
- Section 5 - Results of Previous Investigations
- Section 6 - Site Screening Plan
- Section 7 - Site Assessment Plan
- Section 8 - Conclusions and Recommendations

Section 2
SAFETY, HEALTH, AND EMERGENCY RESPONSE PLAN

2.1 INTRODUCTION

This section summarizes the components of the Safety, Health, and Emergency Response Plan (SHERP) for the RACB RFI. The overall requirements of the program for field activities are presented in this plan.

In addition to this SHERP, the Oversight Contractor will develop site-specific health and safety plans that are in compliance with OSHA 1910.120 prior to beginning field work. These site-specific health and safety plans will include:

- A detailed description of the field activities planned and an evaluation of the anticipated hazards associated with these activities
- A summary of site characteristics, facility description, site history, and any unusual or special features of the site
- Identification of field team members for the activity

- A description of the site organization (Exclusion Zone, Contamination Reduction Zone, and Support Zone) and site entry and exit procedures for the planned activities
- Contingency plan for emergency response and medical evacuation procedures (including maps to hospital)
- Plan for management of waste materials generated (to include personal protective equipment that must be disposed of)

The criteria presented in this SHERP for use of personal protection equipment and procedures are those specified in Chapter 2 of the RFIPP. These criteria and procedures may be adjusted in the site-specific health and safety plan to address site-specific conditions and work activities. These plans will be updated to reflect data gathered as field activities are completed. On-site personnel will be required to adhere to the requirements of the SHERP and this site-specific health and safety plan.

If it is suspected that radioactive contaminants may be encountered during field activities, SRS Health Protection (HP) Area Survey personnel will be requested to provide field screening prior to and during field activities.

The following documents will be utilized in the preparation of the site-specific health and safety plan:

- Road A Chemical Basin Environmental Information Document, DPST-85-699
- OSHA standards 29 CFR 1910, 1904 and 1926, specifically 29 CFR 1910.120, "Hazardous waste operations and emergency response"
- SRS Health Protection DPSOP 40 Series
- SRS DPSOP-254, Hydrogeologic Data Collection
- NIOSH/OSHA/ USCG/ EPA "Occupational Safety and Health Guidance Manual for Hazardous Waste Site Activities," October 1985
- NIOSH "A Guide to Safety in Confined Spaces," July 1987
- SRS Safety Guidelines for Subcontractors, April 1, 1986
- Safety Information for Savannah River Plant Subcontract Personnel, May 1986

- DOE-SR Safety, Health and Fire Protection Orders, 5480 Series
- National Drilling Federation "Drilling Safety Guide"
- National Water Well Association "Manual of Recommended Safe Operating Procedures and Guidelines for Water Well Contractors and Pump Installers"
- RCPA Facility Investigation Program Plan (RFIPP)

In addition to development and approval of an site-specific health and safety plan, SRS requires all contractor personnel to adhere to the SAFETY MANUAL-ITEM 104. A copy of this item is included as Appendix A. Item 104 establishes rules for contractor personnel and responsibilities of SRS representatives. In accordance with Item 104, personnel participating in the implementation of this RFI plan are required to attend orientations conducted by the Area Safety Engineering, Health Protection, Security, and Environmental groups at SRS.

2.2 COORDINATION AND RESPONSIBILITY

Field work will not begin until the site-specific health and safety plan has been reviewed and signed by field personnel. The Oversight Contractor will institute the site control necessary to carry out the provisions of the site-specific health and safety plan. The Oversight Contractor's Health and Safety Officer (HSO) will monitor for compliance with the SHERP and site-specific health and safety plan during all site operations. The HSO will have the authority to stop work should health and safety conditions warrant; this authority will transcend any contractor-subcontractor arrangements. Subcontractors will be provided with a copy of this SHERP and site-specific health and safety plans and will comply with all aspects of these plans.

2.3 TRAINING OF PERSONNEL

Field personnel must have successfully completed a hazardous waste health and safety training program which complies with OSHA 1910.120. Field personnel will be informed by the SRS representative of safety practices specified in Item 104 of the Safety Manual (see Appendix A). In addition, site-specific training will be carried out by the HSO before entry to the site. This will consist of a review of the specific chemicals of concern, risks, symptoms of exposure, and an

overview of the SHERP and site-specific health and safety plan to include delineation of work zones, site access, decontamination and safety procedures, and emergency contacts. SRS HP personnel will provide guidance for personnel involved in site operations at suspected radioactive sites. HP Area Survey personnel will review this RFI plan to develop monitoring requirements appropriate to the site and work.

In addition to the HSO, a second qualified person will be identified as an alternate HSO. Assignment of personnel to work at the site will be subject to review and approval by SRS.

2.4 MEDICAL SURVEILLANCE AND BIOASSAY

To implement the provisions of 29 CFR 1910.120, personnel who work extensively at the site for implementation of this RFI must be under a medical monitoring program, and each must provide a physician's certification that there are no medical conditions that restrict normal physical exertion necessary to perform field work or use of respiratory protective equipment.

Monitoring of the work station will be performed and documented in the bound field logbook assigned to the project. This monitoring will be performed by the HSO for the project and will include portable direct reading instrumentation.

This program is intended in part to provide information on possible worker exposure during field work at hazardous waste sites.

Monitoring at the borehole, excavation, and decontamination station will include instrumentation for detecting VOCs, flammable/ combustible vapors, and radiological contaminants, as needed. Passive dosimetry issued by SRS HP will be worn during on-site work activities, as needed. SRS HP policies and programs will apply.

2.5 RECORDKEEPING

The Oversight Contractor will maintain logs and reports to document the implementation of the personal protection program. This documentation will consist of certification of OSHA 40-hour and annual refresher training for the Oversight Contractor's personnel, daily activity logs (to include information as specified in Section 3.3 of this plan as well as health and safety monitoring results), and accident reports. Daily activity logs must be maintained by the HSO, as specified in Section 3.6 of this plan.

2.6 REQUIRED PERSONAL PROTECTION EQUIPMENT AND PROCEDURES

Personal protection equipment (PPE) and operational procedures will be determined based on available analytical and toxicological data as shown in Appendices E, F, G, and H of the RFIPP and will be described in the site-specific health and safety plan (see Section 2.1). The minimum PPE for any work activity at the RACB is as follows:

- Blue disposable coveralls, Tyvek or equivalent
- Steel-toed, steel shank Neoprene rubber boots
- Chemical-resistant Neoprene rubber gloves
- Safety glasses
- Hard hats
- Hearing protection (if permissible noise exposure is exceeded)
- Face shield (if specific site conditions warrant)

During work activities in areas with unknown VOCs, use of respiratory protection equipment according to airborne

concentrations in the breathing zone will be as specified in the RFIPP:

<u>Concentration</u>	<u>Equipment</u>
Detectable to 1 ppm above background	Half mask organic vapor
>1 to 10 ppm above background	Full mask organic vapor
10 to 100 ppm above background	Supplied air or SCBA (positive pressure)
>100 ppm above background	Supplied air with escape pack or SCBA (positive pressure)
>200 ppm above background	Requires special work plan authorized by SRS HP and DOE-SRS Safety Division

More stringent requirements may be specified in the site-specific health and safety plan. An explosimeter/O₂ meter will also be used to monitor combustible gas concentrations during field activities. Action levels for percent lower explosive limit (LEL) readings will be as follows:

<u>Percent LEL</u>	<u>Action</u>
0 - 5	Continue
5 - 20	Continue, monitor continuously scanning for sources, record every 15 minutes, no welding.
>20	STOP WORK, evacuate to safe upwind position, allow vapors to dissipate.

For conditions requiring protection against inhalation of radioactive species, or other special situations, SRS HP Area

Survey will provide guidance for the selection of the most practical methods.

2.7 STANDARD SAFETY PROCEDURES AND CONTROLS

Standard safety procedures identified in the previously cited references will be followed during implementation of the RFI. These precautionary measures are designed to reduce the risks of accidental chemical exposure or injury to personnel during onsite operations. Personal precautions and operational requirements outlined in the site-specific health and safety plan will be followed by site personnel.

Safety precautions will include, but are not limited to, familiarity with and adherence to the site-specific health and safety plan, restriction of hand-to-mouth contact in the work zones, implementation of safety restrictions and activities in contaminated areas (i.e., no contact lenses, no facial hair if it prohibits a satisfactory mask-to-face seal, periodic face/respirator seal checks), and thorough washing of hands and face when leaving work area and avoidance of contact with contaminated surfaces when possible.

Operational precautions will include, but are not limited to, adequate training of field personnel, proper selection and use of protective and monitoring equipment, use of the buddy

system and maintenance of sight or voice contact between field personnel, site control such as designation and proper use of entrance/ exit locations to and from contaminated areas, and strict adherence to the site-specific health and safety plan.

Whole-body counts and biological sampling may be conducted for certain work activity at sites identified by the SRS HP Area Survey and Industrial Hygiene Group. Determining the need for and frequency of this monitoring will be the responsibility of SRS HP and will be based upon the field activities described later in this plan. SRS HP Area Survey and Industrial Hygiene Group will be consulted for guidance on personnel monitoring and bioassay requirements for potential chemical exposures.

2.8 SITE CONTROL MEASURES

Work zones will be established in the site-specific health and safety plan (Section 2.1) for the RACB RFI. The flow of personnel and equipment between zones will be controlled through access control points designated by the Oversight Contractor's HSO. Three general areas of operation will be established. A generic layout of the work zones and access control points is shown in Figure 2-1. The three areas are:

Figure 2-1
Generic Schematic for RFI Site Control
General

Source: RCRA Facility Investigation Program Plan

- Exclusion Zone
- Contamination Reduction Zone
- Support Zone

The use of the three-area designation with access control points coupled with established decontamination procedures provides reasonable assurance against the translocation of contaminants. This system of control is based on a "worst case" situation. Less stringent site control and decontamination procedures may be required in the site-specific health and safety plan based upon field activities and results of monitoring data.

2.9 EMERGENCY PROCEDURES AND EQUIPMENT

Some risk of personal injury or chemical exposure is inherent in hazardous waste site activities. These risks of unpredictable events such as injury, chemical exposure, fire, or explosion are to be reduced by adhering to good work practices, using personal protective equipment appropriate to the field conditions, performing adequate monitoring of individuals and ambient field conditions, and staying alert both for personal performance and for that of co-workers.

In the event of an accident, site personnel are to follow the procedures developed in the site-specific health and safety plan. These emergency procedures will be coordinated with SRS personnel.

2.10 EMERGENCY SPILL RESPONSE

In the event of a spill, the Oversight Contractor's HSO will notify the SRS Emergency Operations Center (EOC), SRS Task Order Manager, and SRS RFI Program Coordinator. A spill response team or contractor will immediately initiate necessary containment measures.

In the case of minor spills, the Oversight Contractor will exhume and contain the contaminated soils. Should a larger spill occur (which the Oversight Contractor cannot adequately respond to or which may result in any off-site impact) the SRS EOC will be asked to immediately mobilize the SRS Spill Response Team.

2.11 EMERGENCY SERVICES AND TELEPHONE NUMBERS

Good judgment is to be used to avoid needlessly jeopardizing lives in attempts to respond to emergency situations. In extremely hazardous conditions, field personnel should await emergency service. The appropriate contact(s) from the following list will be made for emergency situations:

<u>Emergency Contacts</u>	<u>Site No.</u>
● SRS Emergency Operations Center	5-2117
● Ambulance	7-4122
● Fire Protection	7-4000
● Wackenhut Security	7-8420
● M-Area Emergency Coordinator	5-1795
● RFI Program Coordinator	5-6211
● RFI Task Order Manager	5-3556

This Page Intentionally Left Blank.

Section 3

QUALITY ASSURANCE/QUALITY CONTROL (QA/QC) PLAN

3.1 INTRODUCTION

The purpose of a field sampling program is to produce accurate and verifiable data. This information is obtained in part from the laboratory analysis of representative samples collected from the study area, but also includes records of observations and decisions, photographs, and other field-generated documentation. The objective of this plan is to provide appropriate procedures and guidance for implementation and documentation of the RACB RFI. The emphasis of this QA/QC plan is on activities which generate analytical data. Specific requirements are provided for the sampling and analysis of soils, groundwater, and surface water, as well as health and safety monitoring.

The key QA elements addressed in this plan are:

- Organization
- Reporting requirements and project deliverables
- Document control
- Training requirements

The key QC elements addressed in this plan are:

- Sampling methodology
- Quality control samples
- Decontamination
- Sample handling and packaging

The QC requirements of appropriate laboratory analyses performed during the RACB RFI will follow the protocols of the EPA Contract Laboratory Program (CLP). Key CLP laboratory QC elements include:

- Method blanks
- Laboratory control samples
- Calibration check samples
- Replicate samples
- Matrix-spiked samples
- Control charts
- Surrogate samples
- Zero and span gases
- Reagent quality control checks

3.2 QA REQUIREMENTS

3.2.1 ORGANIZATION

The Oversight Contractor will have oversight responsibilities during implementation of the RFI. The Oversight Contractor's project team members responsible for QC are:

Project Manager (PM)

Field Oversight Coordinator (FOC)

Quality Assurance Manager (QAM)

Specific responsibilities of the project team are described below.

The PM will monitor field activities to promote compliance with project objectives and scope. The PM will communicate with the SRS Program Coordinator, SRS Task Order Manager, and, as appropriate, other parties on progress in the field program.

The FOC will oversee sampling and field-based activities. The FOC will observe and record the progress of field activities, and will be available and will have the authority to direct subcontractors (if needed) in plan implementation to aid in adherence to the RFI plan. The FOC will also monitor adherence of on-site personnel to the requirements of

the SHERP (see Section 2). The FOC will have the authority to stop work if unsafe conditions exist. The FOC will become familiar with QA/QC requirements outlined in the SRS QA manual and will have the manual, the RFIPP, and a copy of this plan on-site during field activities.

The QAM is responsible for the team that audits and monitors adherence to the project QA objectives. The QAM's responsibilities include periodically contacting the analytical laboratories to confirm that samples arrive properly prepared, packaged, and identified. Also, the QAM may conduct field audits of sampling episodes to verify that sample identification and chain-of-custody procedures are being followed. The QAM may contact the FOC to ensure that personnel assigned to field sampling episodes are properly trained in sample identification and chain-of-custody procedures.

The SRS and Contractor QA organizational structure and interface for the SRS RFI Program Team are shown in Figure 3-1.

3.2.2 REPORTING REQUIREMENTS AND PROJECT DELIVERABLES

The Oversight Contractor will deliver the following documents to the SRS RFI Program Team:

Figure 3-1
SRS RFI PROGRAM PLAN
QA ORGANIZATION AND INTERFACES

- Site-Specific RFI Work Plan
- Site-Specific RFI Report
- Progress/interim reports required by Part V of the SRS Hazardous Waste Permit

Project deliverable documents listed above will undergo internal review by the Oversight Contractor prior to submittal to SRS. Reviews will typically be conducted at both the initial draft and final draft stages. Copies of mark-ups and partial drafts will be retained until approval of the document for submittal to SRS. Documentation of these reviews will be maintained with the record file for the duration specified for the project.

3.2.3 DOCUMENT CONTROL

The latest revisions of approved procedures will be used for sampling and field measurement. A procedure index will be readily available for reference to confirm the latest revision of procedures. A procedure for handling temporary changes will be documented. The procedures are to be retained as records in accordance with the requirements of this section and the SRS QA Manual.

3.2.4 TRAINING REQUIREMENTS

Personnel involved in the RACB RFI are to be trained to fulfill the qualifications and requirements of their respective assignments. The documentation will demonstrate successful completion of necessary training elements. Records are to be maintained for each individual by his or her parent organization while that person is on a particular RFI assignment.

The SRS RFI Program Team will review and approve key contractor personnel selected for involvement in RFI activity at the SRS.

3.3 GENERAL QC REQUIREMENTS FOR SAMPLING AND FIELD MEASUREMENTS

This section describes QC procedures for field sampling and measurement, and is primarily excerpted from the RFIPP. This section is also consistent with EPA Region IV Standard Operating Procedures and Quality Assurance Manual (April 1986). The procedures discussed are applicable to soils, groundwater, subsurface gas, surface water, and ambient air. The objectives of the general QC requirements are to:

- Establish standard field sampling and measurement practices and methods for RFIs
- Establish procedures for demonstrating the consistency of sampling and measurement methods
- Assist in recognition of deficiencies which may affect the quality of data obtained by the sampling efforts
- Develop the methodology to verify the quality of the data submitted to the South Carolina Department of Health and Environmental Control (DHEC) and EPA

3.3.1 SAMPLE ORDER

The sampling order at sites will begin, where possible, with background or ambient samples and end with samples where levels of contamination are expected to be the highest. The sample order will be determined prior to the sampling event. A map showing physical features of the specific site will be reviewed in determining sampling order.

3.3.2 CONTROL OF MEASURING AND TEST EQUIPMENT

This section describes calibration and documentation procedures for field instruments. During implementation of the RFI, proper calibration of measuring and test equipment is required. Improperly calibrated field instruments will affect the validity of the field measurements.

The calibration policies and procedures apply to measuring and test equipment. This includes tools, gauges, instruments, standards, and other devices/systems used to make measurements or to monitor the safety of personnel and the environment. Measuring and test instruments fall into three general categories: those which are calibrated prior to each use, those which are calibrated on a scheduled or periodic basis, and those used for references.

An identification number will be permanently affixed to equipment that requires calibration. For measuring and test equipment requiring periodic calibration, a label will be affixed to each instrument showing:

- Description or nomenclature
- Manufacturer
- Model number

- Serial number
- Date of last calibration or maintenance
- Signature and name of person who performed calibration/maintenance
- Date of next scheduled calibration

A master list of equipment used for a specific RFI will be prepared and maintained with the above information. Calibration reports and compensation or correction figures will be maintained with the instrument. Thermometers are exempted from the labeling requirement, but not from the calibration requirement.

A written stepwise calibration procedure must be available for measuring and test equipment prior to field work. Any instrument which is not calibrated to within the required specifications must display a warning tag to prevent the use of the equipment. Equipment which does not meet approved calibration specifications will not be used. The required calibration ranges and uncertainties for each measuring and test device will be documented.

3.3.2.1 Calibration Identification

Instruments past due for calibration or maintenance must be immediately removed from service, either physically or, if this is impractical, by tagging, sealing, labeling, or other means.

The Oversight Contractor will provide calibration and maintenance of equipment based on manufacturer specifications or documented requirements prior to use. Likewise, the Oversight Contractor will maintain the required record-keeping system pertaining to calibration and maintenance of equipment including the tagging of equipment not meeting the required standards.

3.3.2.2 Calibration Standards

The physical, electronic, or chemical measurements or calibrations performed must be traceable, directly or indirectly, through a chain of properly conducted calibrations (supported by reports or data sheets). Measurements and calibrations will be referenced to National Bureau of Standards (NBS) standards or physical constants, or to standards prepared by nationally recognized procedures, and will adhere to the manufacturer's specifications. Reports must be up-to-date for each reference standard and each subordinate standard used for calibration of measuring

and test equipment. Standards will have an uncertainty rating of no more than one-fourth of the specified uncertainty for the measuring or test equipment under calibration.

3.3.2.3 Calibration Frequency

At a minimum, calibration and maintenance intervals for field instruments must be those recommended by the manufacturer. When the manufacturer has not specified a calibration interval for the equipment, the interval will be established in writing by the user of such equipment and approved by the SRS RFI Program Team. Adherence to the calibration schedule is mandatory. The fact that these calibrations may be performed by an outside source does not exempt the user from the responsibility for identifying, monitoring, and controlling calibration intervals and ensuring that maintenance checks are made on time.

Documentation of field instrument calibrations will be the responsibility of the Oversight Contractor. Calibration records will be maintained in a Field Instrument Calibration Notebook. This notebook will contain the instrument operation manual including the specific calibration procedure for that instrument. In addition, the following information will be recorded in the notebook on a log sheet similar to Figure 3-2:

Figure 3-2
Sample Instrument Calibration

Sample Instrument Calibration

Make _____

Model # _____

Serial # _____

1. Recommended Calibration Frequency: _____
2. Last Calibration Date: _____
3. Calibrated By: _____
4. Calibration Standards Used: _____
5. Source of Calibration Standard: _____
6. Calibration Procedure Used if more than one method in manual

7. Usage Date	<u>Sample ID Number</u>	<u>Location</u>
_____	_____	_____
_____	_____	_____

- Equipment type or nomenclature (e.g., pH meter)
- Manufacturer and model number
- Serial number
- Recommended calibration frequency
- Date of latest calibration
- Dates of field measurement (use)
- Name of person who calibrated instrument
- Calibration standards used
- Source of calibration standards
- Calibration procedure

Entries in the log book will be made at the beginning of each sampling or measuring effort and when each instrument is calibrated. Documentation in the log book will be made in ink. If an error is made, corrections will be made by crossing a line through the error and entering the correct information. Changes will be dated and initialed. No entries will be obliterated or rendered unreadable. Records will be kept for instruments requiring calibration.

3.3.3 DOCUMENTATION PROCEDURES FOR PREPARATION OF REAGENTS OR SUPPLIES WHICH BECOME PART OF THE SAMPLES

Reagents or supplies which become an integral part of the sample must be properly prepared and documented. A bound log book will be maintained concerning the use and preparation of

chemicals, reagents, or other materials (e.g., filter media) which are used at the RACB. This record will include:

- Preparation date
- Preparer's name
- Expiration date
- Measurements made during reagent preparation (e.g., individual chemical weights or volumes)
- Reference chemicals or materials used
 - Date of receipt
 - Source
 - Purity
 - Chemical composition
 - Expiration date

This log book will be maintained by the Laboratory QAM or his designee.

3.3.4 SAMPLE CONTAINER REQUIREMENTS

Sample container preparation will be conducted as specified in DPSOP 254, Chapter XI, Attachment 4. Other containers

will be cleaned and certified clean through (1) the Contractor laboratory providing the analytical services of containers, or (2) a laboratory approved for such activities by the SRS Program Team.

Prior to the field sampling event, sample container and preservation requirements will be predetermined. Analytical methods and detection limits will be those specified under the EPA CLP for chemical parameters and Special Analytical Services (SAS) for radiological parameters. The analytical method or methods will determine the required sample volume, which will be determined prior to sampling. The parameters to be analyzed at the laboratory will determine the container material, volume, and preservative, if any. Table 3-1 identifies container material and preservative requirements.

3.3.5 SAMPLE IDENTIFICATION AND LABELING

Proper sample identification is an essential part of any field sampling project. Because of its importance to accurate data acquisition, documentation and labeling of samples in the field is necessary. Each sample, including blanks and duplication, will be identified in the field log book and on the sample container label. The sample label will include the following information:

Table 3-1
Containers, Preservation, Storage,
and Holding Times

Parameter	Container ^b Water Soil	Preservative-c,d		Maximum Holding Time for all Matrices	Sample Volume (ml)
		Water	Soil		
INORGANIC TESTS					
Acidity	P G	Cool, 4°C	Cool, 4C	14 days	
Alkalinity	P G	Cool, 4°C	Cool, 4°C	14 days	100
Ammonia	P G	Cool, 4°C H ₂ SO ₄ to pH <2	Cool, 4°C	28 days	400
Asbestos	P G	Cool, 4°C	Cool, 4°C	48 hours ^f	1000
Bicarbonate	P G	None Required	None Required	Analyze Immediately	100
Biological Oxygen Demand (BOD) and Carbonaceous BOD	G G Bottle and Top	Cool, 4°C	Cool, 4°C	48 hours	1000
Bromide	P G	None Required	None Required	28 days	100
Carbonate	P G	None Required	None Required	Analyze Immediately	100
Chemical Oxygen Demand (COD)	P G	Cool, 4°C H ₂ SO ₄ to pH <2	Cool, 4°C	28 days	
Chloride	P G	None Required	None Required	28 days	50
Chlorine, Total Residual	P N/A	None Required	N/A	Analyze Immediately	200
Color	P N/A	Cool, 4°C	N/A	48 hours	50

Table 3-1
(Continued)

Parameter	Container ^b Water Soil	Preservative ^{c,d}		Maximum Holding Time for all Matrices ^e	Sample Volume (ml)
		Water	Soil		
Kjeldahl and Organic Nitrogen	P G	Cool, 4°C H ₂ SO ₄ to pH <2	Cool, 4°C	28 days	500
Metals ⁱ					
Chromium VI	P G	Cool, 4°C	Cool, 4°C	24 hours	100
Mercury	P G	HNO ₃ to pH <2	Cool, 4°C	28 days	100
Others	P G	HNO ₃ to pH <2	Cool, 4°C	6 months	200
Nitrate	P G	Cool, 4°C	Cool, 4°C	48 hours	100
Nitrate plus Nitrite	P G	Cool, 4°C H ₂ SO ₄ to pH <2	Cool, 4°C	28 days	100
Nitrite	P G	Cool, 4°C	Cool, 4°C	48 hours	50
Oil and Grease	P G	Cool, 4°C H ₂ SO ₄ to pH <2	Cool, 4°C	28 days	1000
Orthophosphate	P G	Filter Immediately Cool, 4°C	Cool, 4°C	48 hours	50
pH	P G	None Required	None Required	Analyze Immediately	

Table 3-1
(Continued)

Parameter	Container ^b Water Soil	Preservative ^{c, d}		Maximum Holding Time for all Matrices ^e	Sample Volume (ml)
		Water	Soil		
Cyanide, Total and Amenable to Chlorination	P G	Cool, 4°C NaOH to pH >12 0.6 g Ascorbic Acid ^g	Cool, 4°C	14 days ^h	500
Dissolved Oxygen Probe	G N/A Bottle and Top	None Required	N/A	Analyze Immediately	100
Winkler	G N/A Bottle and Top	Fix On Site Store in Dark	N/A	8 hours	
Fluoride	P G	None Required	None Required	28 days	300
Hardness	P N/A	HNO ₃ or H ₂ SO ₄ to pH<2	NA	6 months	100
Hydrazine	P G	If not analyzed immediately, collect under acid. Add 90 ml of sample to 10 ml HCl.	Cool, 4°C	7 days	100
Iodide	P G	Cool, 4°C	Cool, 4°C	24 hours	100
Iodine	P G	None Required	None Required	Analyze Immediately	500

Table 3-1
(Continued)

Parameter	Container ^b		Preservative ^{c,d}		Maximum Holding Time for all Matrices ^e	Sample Volume (ml)
	Water	Soil	Water	Soil		
Sulfide	P	G	Cool, 4°C Add Zinc Acetate plus NaOH to pH >9	Cool, 4°C	28 days	500
Sulfite	P	G	None Required	None Required	Analyze Immediately	50
Surfactants	P	G	Cool, 4°C	Cool, 4°C	48 hours	250
Temperature	P	G	None Required	None Required	Analyze Immediately	100
Turbidity	P	N/A	Cool, 4°C	N/A	48 hours	100
ORGANIC TESTS¹						
Acrolein and Acrylonitrile	S	S	Cool, 4°C 0.008% Na ₂ S ₂ O ₃ g Adjust pH to 4-5 ^k	Cool, 4°C	14 days ^k	40
Benzidines ¹	G	G	Cool, 4°C ^m 0.008% Na ₂ S ₂ O ₃ g pH 2-7	Cool, 4°C	7 days until extraction ⁿ	40
Chlorinated Hydrocarbons ¹	G	G	Cool, 4°C	Cool, 4°C	7 days until extraction 40 days after extraction	40
Haloethers ¹	G	G	Cool, 4°C 0.008% Na ₂ S ₂ O ₃ g	Cool, 4°C	7 days until extraction 40 days after extraction	40

Source: RCRA Facility Investigation Program Plan

Table 3-1
(Continued)

Parameter	Container ^b		Preservative ^{c,d}		Maximum Holding Time for all Matrices ^e	Sample Volume (ml)
	Water	Soil	Water	Soil		
Nitroaromatics and Isophorones ¹	G	G	Cool, 4°C Store in Dark	Cool, 4°C Store in Dark	7 days until extraction 40 days after extraction	
Nitrosamines ^{1,0}	G	G	Cool, 4°C Store in Dark 0.008% Na ₂ S ₂ O ₃ g	Cool, 4°C Store in Dark	7 days until extraction 40 days after extraction	
PCBs	G	G	Cool, 4°C	Cool, 4°C	7 days until extraction 40 days after extraction	
Pesticides ¹	G	G	Cool, 4°C pH 5-9p	Cool, 4°C	7 days until extraction 40 days after extraction	
Phenols ¹	G	G	Cool, 4°C 0.008% Na ₂ S ₂ O ₃ g	Cool, 4°C	7 days until extraction 40 days after extraction	
Phthalate Esters ¹	G	G	Cool, 4°C	Cool, 4°C	7 days until extraction 40 days after extraction	
Polynuclear Aromatic Hydrocarbons	G	G	Cool, 4°C 0.008% Na ₂ S ₂ O ₃ g Store in Dark	Cool, 4°C Store in Dark	7 days until extraction 40 days after extraction	
Purgeable Aromatic Hydrocarbons	S	S	Cool, 4°C 0.008% Na ₂ S ₂ O ₃ g HCl to pH <2g	Cool, 4°C	14 days ^g	
Purgeable Halocarbons	S	S	Cool, 4°C 0.008% Na ₂ S ₂ O ₃ g	Cool, 4°C	14 days	

Source: RCRA Facility Investigation Program Plan

Table 3-1
(Continued)

Parameter	Container ^b		Preservative ^{c,d}		Maximum Holding Time for all Matrices ^e	Sample Volume (ml)
	Water	Soil	Water	Soil		
1000 ¹	G	G	Cool, 4°C 0.008% Na ₂ S ₂ O ₃ g	Cool, 4°C	7 days until extraction 40 days after extraction	100
Total Organic Carbon	G	G	Cool, 4°C HCl or H ₂ SO ₄ to pH <2	Cool, 4°C	28 days	100
Total Organic Halogen	G	G	Cool, 4°C 1 ml of 0.1 M sodium sulfite	Cool, 4°C	7 days	100

Analytes not listed should be preserved at 4°C and held not longer than 7 days.

^aPreservatives and holding times are from Federal register, Vol. 49, No. 209, Friday, October 26, 1984, Page 43260 and Characterization of Hazardous Waste Sites: A Methods Manual -- Volume II. Sampling Methods Second Edition, EPA-600/4-84-076. Container requirements are consistent with these references.

bp = Polyethylene

G = Amber Glass with Teflon-lined cap

S = Glass Vial with Teflon-lined septum cap

^cSample preservation should be performed immediately upon sample collection. For composite samples, each aliquot should be preserved at the time of collection. When use of an Automatic sampler makes it impossible to preserve each aliquot, samples may be preserved by maintaining at 4°C until compositing and sample splitting is completed.

Table 3-1
(Continued)

^dWhen any sample is to be shipped by common carrier or sent through the U.S. Mail, it must comply with the Department of Transportation Hazardous Materials Regulations (49 CFR Part 172). The person offering such material for transportation is responsible for ensuring such compliance. For the preservation requirements in this table, the Office of Hazardous Materials, Materials Transportation Bureau, Department of Transportation, has determined that the Hazardous Materials Regulations do not apply to the following materials: Hydrochloric acid (HCl) in water solutions at concentrations of 0.04% by weight or less (pH about 1.96 or greater); Nitric acid (HNO₃) in water solutions at concentrations of 0.15% by weight or less (pH about 1.62 or greater); Sulfuric acid (H₂SO₄) in water solutions at concentrations of 0.35% by weight or less (pH about 1.15 or greater); and Sodium hydroxide (NaOH) in water solutions at concentrations of 0.080% by weight or less (pH about 12.3 or less).

^eSamples should be analyzed as soon as possible after collection. The times listed are the maximum times that samples may be held before analysis and still be considered valid. Some samples may not be stable for the maximum time period given in the table. A laboratory is obligated to hold the sample for a shorter time if knowledge exists to show this is necessary to maintain sample integrity.

^fIf samples cannot be filtered within 48 hours, add 1 ml of a 2.71% solution of mercuric chloride to inhibit bacterial growth.

^gShould only be used in the presence of residual chlorine.

^hMaximum holding time is 24 hours when sulfide is present. Optionally, all samples may be tested with lead acetate paper before pH adjustment in order to determine if sulfide is present. If sulfide is present, it can be removed by addition of cadmium nitrate powder until a negative spot test is obtained. The sample is filtered and then NaOH is added to pH 12.

ⁱFor dissolved metals, filter immediately on site before adding preservative.

^jGuidance applies to samples to be analyzed by GC, LC, or GC/MS for specific compounds.

^kThe pH adjustment is not required if acrolein will not be measured. Samples for acrolein receiving no pH adjustment must be analyzed within three days of sampling.

Table 3-1
(Continued)

When the extractable analytes of concern fall within a single chemical category, the specified preservative and maximum holding times must be observed for optimum safeguard of sample integrity. When the analytes of concern fall within two or more chemical categories, the sample may be preserved by cooling to 4°C, reducing residual chlorine with 0.008% sodium thiosulfate, storing in the dark, and adjusting pH to 6-9; samples preserved in this manner may be held for 7 days before extraction and 40 days after extraction. Exceptions to this optimal preservation and holding time procedure are noted in footnotes g, n, and o.

If 1,2-diphenylhydrazine is likely to be present, adjust the pH of the sample to 4.0 ± 0.2 to prevent rearrangement to benzidine.

Extracts may be stored up to 7 days before analysis if storage is conducted under an inert (oxidant-free) atmosphere.

For the analysis of diphenylnitrosamine, add 0.008% $\text{Na}_2\text{S}_2\text{O}_3$ and adjust pH to 7-10 with NaOH within 24 hours of sampling.

The pH adjustment may be performed upon receipt at the laboratory and may be omitted if the samples are extracted within 72 hours of collection. For the analysis of aldrin, add 0.008% $\text{Na}_2\text{S}_2\text{O}_3$.

Sample receiving no pH adjustment must be analyzed within 7 days of sampling.

- Date and time
- Sample ID number
- Project number
- Sampler (name)
- Sample location
- Preservative (if any)
- Matrix type

The sample identification number as discussed above (as part of the sample label) will identify the following:

- RFI site
- Sample matrix type and number

When existing groundwater monitoring wells are sampled, the sample identification system currently in use by SRS will also be used by the Oversight Contractor. The Oversight Contractor will maintain the monitoring well identification number used by SRS in documents and reports generated. Similarly, surface water samples taken from NPDES-permitted outfalls will be identified by the established SRS identification.

3.3.6 FIELD NOTES

Field notes provide evidence attesting to the quality of the RFI, must be designated as records, and must comply with requirements outlined in the SRS QA Manual, QA Procedure 17-1 for nonpermanent records. Contractors must provide copies of log book entries in accordance with the schedule established by the SRS RFI Program Team.

A bound field log book will be maintained to provide a daily record of events. At the beginning of each entry, the following will be recorded:

- Date
- Time
- Meteorological conditions
- Field personnel present
- Levels of personal protection
- Signature of the person making the entry
- Anticipated performance for that day

Field log books will provide the means of recording data regarding sample collection. As such, entries will be described in as much detail as possible so that the information is properly documented. Documentation in log books is to be made legibly in water-proof ink. If a correction is made, corrections will be made by crossing out the original entry and making a new entry.

the error and entering the correct information. Changes will be dated and initialed. No entries will be obliterated or rendered unreadable. Unused pages or portions of pages in the log book will be crossed through and initialed.

A simple drawing of the site (not to scale) will be included in the log book to provide an illustration of sampling points.

The cover of each log book used will contain:

- Person or organization to whom the book is assigned
- Book number
- Project name, number
- Start date
- End date

Entries in the log book are to include at a minimum the following for each sample date:

- Site designation
- Location of sampling points
- Description of sampling points

- References to photographs of the RFI site and brief sketch of sampling points
- Sample designation
- Number of samples taken
- Time of sample collection
- Reference to sample location map
- Number of QA samples taken (e.g., duplicates)
- Collectors' names
- Field observations
- Sample distribution (e.g., QA laboratory, agency split)
- Field measurements made (e.g., pH, temperature, specific conductance)

At the end of each day's entry, a paragraph will summarize the work accomplished, deviations from the anticipated performance, and an explanation of the deviations. The entries will be signed and witnessed daily.

3.3.7 PHOTOGRAPHS

The FOC and the SRS Task Order Manager will determine the need for photographs for documentation purposes. The SRS Task Order Manager will arrange for an SRS photographer to take photographs. Photographs will be considered non-permanent records and will meet the requirements of QA Manual, QA Procedure 17-1.

Photographs will be taken to document unusual sampling locations or conditions and other pertinent information such as site topography and current site conditions. The name of the photographer, date, time, site location, and site description are to be entered sequentially in the field log book as photos are taken. Film and photographs taken within SRS will become the property of SRS. The Oversight Contractor will document photographs taken by the SRS photographer for a specific RFI site.

Special lenses, films, filters, or other image enhancement techniques must be noted in the field log book. However, aperture settings and shutter speeds for photographs taken within the normal automatic exposure range need not be recorded. The following table summarizes pertinent notes in regard to accurate photography:

- 35-mm color slides will be used unless specified otherwise
- Photos are to show surrounding area and reference objects for scale
- Picture number, roll number (if more than one roll of film is used), and description of pictures will be logged in the field notebook
- Location of pictures will be identified by taking a photograph of an informational sign on the first and last frames of the roll

3.3.8 SAMPLE HANDLING

Personnel collecting samples will take the following precautions to minimize sample contamination or cross-contamination between samples:

- At a minimum, latex surgical gloves will be used while taking samples. The gloves will be disposed of after equipment has been decontaminated, and a clean pair used for the next sample
- Sampling personnel will not touch the inside of the sampling container

- Sampling personnel will not walk over any areas where samples will be taken

Immediately following the collection of the sample, preservative will be added according to Table 3-1, the container will be sealed, and the sample will be labeled and entered in the field sampling log book as described in Sections 3.3.5 and 3.3.6. At this time, the Chain-of-Custody Form will be completed to note the acquisition of the sample (see Section 3.3.9.2). The sample will then be placed in the shipping container.

3.3.9 SAMPLE CHAIN-OF-CUSTODY

It is imperative that an accurate record of sample collection, preservation, transport, analysis, and disposal be maintained and documented. Therefore, chain-of-custody procedures will be instituted and followed throughout the RFI.

Chain-of-custody procedures include field custody, laboratory custody and evidence files. The National Enforcement Investigation Center (NEIC) of the EPA defines custody of evidence in the following ways:

- In actual physical possession
- In view after being in physical possession
- In a locked repository
- In a secure, restricted area

It is necessary to establish documentation to trace sample possession from the time of collection until disposal. The following list outlines field custody requirements:

- As few people as possible will handle sample(s)
- Sampler will be responsible for the care and custody of the samples until they are transferred or dispatched properly

Samples are to be stored by those individuals or facilities designated on the Chain-of-Custody Form. The following methodologies will be used to document proper transfer:

- Ensure that samples are accompanied by a chain-of-custody record at all times.
- Pack samples for shipment so that bottles will not dislodge and/or break during shipment.
- Include with shipped samples separate custody records (one for field laboratory, one for samples

hand delivered to offsite laboratory, and one for samples shipped offsite).

- Ship samples via a 24-hour delivery service, when required, to ensure holding times are not exceeded.
- Record methodology of shipment, courier name(s), and other pertinent information on the Chain-of-Custody Form, with special handling procedures used by the delivery service.
- When samples are split with an outside source or government agency, record the split on a Receipt of Sample form.
- If either party refuses a split sample, record the refusal on an appropriate form signed by both parties.
- Retain records pertaining to the shipment of a sample (freight bills, post office receipts, and bills of lading).

3.3.9.1 Chain-of-Custody Form

Figure 3-3 is the Chain-of-Custody Form to be used. The Laboratory Contractor will not accept samples for analysis

without a correctly prepared Chain-of-Custody Form. The Laboratory Contractor will maintain chain-of-custody of the sample(s) from time of receipt to disposal and will use forms and techniques specified by the EPA CLP to ensure the integrity of the samples.

The Chain-of-Custody Form must be signed by each individual who has the sample(s) in their possession. Preparation of the Chain-of-Custody Form will be as follows:

- The chain-of-custody record will be initiated in the field by the person collecting the sample, for every sample. Each sample will be assigned a unique identification number as described in Section 3.3.5; the number is entered on the Chain-of-Custody Form. Samples can be grouped for shipment using a single form. The Chain-of-Custody Form allows for 12 sample records.
- The record is to be completed in the field to indicate project, sampling team, etc.
- If the person collecting the sample does not transport the samples to the laboratory or deliver the sample containers for shipment, the first blocks for "Relinquished By _____," "Received By _____" will be completed in the field.

- The person transporting the samples to the laboratory or delivering them for shipment must sign the record form as "Relinquished By _____."
- If the samples are shipped to the laboratory by commercial carrier, the Chain-of-Custody Form will be sealed in a plastic bag, placed in the shipping container, and the shipping container sealed prior to being given to the carrier.
- If the samples are directly transported to the laboratory, the Chain-of-Custody Form is to be kept in the possession of the person delivering the samples.
- For samples shipped by commercial carrier, the waybill will serve as an extension of the Chain-of-Custody Form between the final field custodian and receipt in the laboratory.
- Upon receipt in the laboratory, the Laboratory Sample Receiving Supervisor will open the shipping containers, compare the contents with the chain-of-custody record, ascertain that document control information is accurate and complete, and sign and

date the record. Discrepancies are to be noted on the Chain-of-Custody Form.

- If a discrepancy occurs or is suspected, the samples in question are to be segregated from normal sample storage and the field personnel immediately notified.
- The Chain-of-Custody Form (Figure 3-3) is completed upon receipt of the samples by the analytical service. The completed Chain-of-Custody Form will be returned to the FOC.
- The analytical service will track, internally, sample integrity utilizing a procedure defined by the CLP.

3.3.9.2 Completed Chain-of-Custody Form

Figure 3-4 presents a sample of a completed Chain-of-Custody Form.

3.3.10 REQUEST FOR ANALYSIS FORM

The Request for Analysis Form is to be used to supplement the information on the Chain-of-Custody Form. The Request for Analysis Form (see Figure 3-5) will be completed by the FOC

Figure 3-4
Completed Chain of Custody

CUSTODY TRANSFER RECORD			SHIP TO:	
RFI Contractor			RFI Contractor Laboratory	
Sample I.D. 631-1765/10108101		SAMPLE DATE 10/13/89	DUPLICATE ID NONE	
ITEM	PRESERV.	CONTAINER	ANALYSES REQUESTED	
1	NONE/4°C	200 ml glass	Ammonia, Nitrate	
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				

ITEMS	RELINQUISHED BY	DATE	TIME	RECEIVED BY	DATE	TIME	REASON FOR TRANSFER
1	John DOE	10/13/89	5:45PM	Bob Jones	10/14/89	10:30AM	Analysis

Figure 3-5

Completed Request for Analysis Form

U.S. GOVERNMENT PRINTING OFFICE: 1984 - 750-932

ANALYSIS REQUEST - SAVANNAH RIVER PLANT

DISTRIBUTION: WHITE - LABORATORY-RETURN TO ORIGINATOR; PINK - LABORATORY; YELLOW - ORIGINATOR

LABORATORY		SUBMITTED BY		LOCATION	
Laboratory X Inc.		Contractor X INC.		RFI Site	
DATE SUBMITTED		STUDY NO. OR ACCOUNT CODE			
March 30, 1989		RFI Contract No.			
SAMPLE DESCRIPTION AND IDENTIFICATION					
Soil sample, 1 liter glass, I.D. No. 631-176/5/03 3089/02					
SPECIAL SAFETY PRECAUTIONS					
Glass, Fragile					
ACTIVITY		LAB. SERIAL NO.			
Soil Sample		1234567890			
ANALYSES REQUESTED		ESTIMATED		FOUND BY LABORATORY	
Hg		0-15 mg/kg		13 mg/kg	
Fe		50-100 mg/kg		70 mg/kg	
SO ₄ ⁻		150-300 mg/kg		325 mg/kg	
REQUEST APPROVED		ANALYSIS APPROVED		DATE COMPLETED	
Laboratory QA Manager		Laboratory Project Manager		April 10, 1989	

and included with the chain-of-custody record. It is important that the Request for Analysis Form be provided to document the specific analytical requirements and sample holding times. Analytical methods and detection limits will be those specified under the EPA CLP for chemical parameters and SAS for radiological parameters.

3.3.11 SAMPLE PACKAGING

The transportation of environmental samples from the time they are collected to their arrival at the laboratory is an integral part of the QC process. The mode of travel must be such that the sample is not altered physically, chemically, radiologically, or biologically. The chain-of-custody must also be maintained during the transportation process.

Samples collected at the site will be immediately placed in the sample cooler, and the cooler will be placed in a vehicle or other secure storage facility until the completion of the day's sampling activities. The following protocol will be followed for packaging of samples:

- Only metal or equivalent strength plastic ice chests and coolers will be used.
- Ice chests will be watertight.

- The volume level will be marked on each filled bottle with a grease pencil or tape.
- Tape will be placed around the lid of sample containers, except for volatile organic samples.
- Approximately three inches of inert absorptive cushioning material will be placed in the bottom of the cooler.
- The sample containers will be placed upright in the cooler in such a way that they do not touch and will not touch during shipment. In addition, sample containers will be placed in clear plastic leakproof bags. Care will then be taken to ensure that sample labels are legible through the bag.
- Additional inert packing material will be placed in the cooler to partially cover the sample containers. Freeze packs will be placed around, among, and on top of the sample containers, but not in contact with the sample jars.
- Each cooler will be filled with additional absorptive cushioning materials, with a 1.5 volume

absorptive capacity to prevent movement of samples during shipment.

- The Chain-of-Custody Form will be placed in a waterproof plastic bag and placed just under the lid of the cooler.
- If the cooler is equipped with a drain plug, the plug will be taped shut.
- The lid will be secured with strapping tape at a minimum of two locations. No labels will be covered.
- The completed shipping label will be attached to the top of the cooler.
- "This Side Up" labels will be placed on two sides of the cooler, and "Fragile" labels will be placed on all four sides.
- Numbered and signed custody seals will be placed on the front right and back left of each cooler. These seals will be covered with clear tape.
- The weight limit of the shipper will be maintained.

- The packaged samples will meet applicable DOT requirements prior to shipment.

3.3.12 SAMPLING EQUIPMENT DECONTAMINATION PROCEDURES

Equipment decontamination is essential to prevent cross-contamination between samples. Equipment must be decontaminated prior to the collection of each sample. Decontamination procedures for sampling devices will be uniform to provide consistency. The procedure that will be used to decontaminate sampling devices such as hand trowels, hand spades, hand augers, monitoring well bailers, etc., will be performed in accordance with the following:

1. Clean with tap water and laboratory detergent (Liquonox or equivalent) using a brush if necessary to remove particulate matter and surface films.
2. Rinse thoroughly with tap water.
3. Rinse thoroughly with deionized or distilled water.
4. Rinse two times with high grade isopropanol solvent and allow to air dry.
5. Rinse thoroughly with deionized or distilled water and allow to air dry.

6. Wrap with aluminum foil (shiny side not in contact with equipment), if appropriate to prevent contamination if equipment is to be stored or transported.

The decontamination procedure that will be used for equipment such as truck-mounted drill rigs, trailer-mounted drill rigs, boring equipment, and other equipment will be in accordance with the following:

1. The drill rig and equipment will be free from excess grease, oils and caked-on soils from previous work prior to arrival at the site. Equipment which leaks fuel, coolant, crankcase oil, transmission fluids, hydraulic fluids, or lubricants will not be brought to the site.
2. Equipment, including drill rigs, that have a potential to leak (i.e., grease, oil, etc.) will be placed on plastic sheeting (6 mil or thicker).
3. Prior to use, equipment that will enter the borehole must be cleaned by a pressure washer (water at 200°F and 1500 psi) at the well site. If the equipment will not be used immediately, it must be placed on a clean plastic sheet in a clean area. Other equipment that has a potential to induce contamination into the borehole

(mud pumps, flow lines, etc.), will be flushed clean with potable water prior to use.

4. Well casings, screens, centralizers, tremie pipe, measuring lines, etc., will be steam cleaned immediately prior to starting a well.
5. Clean, new disposable rubber gloves are to be worn when handling well screens or casings. Personnel handling these items will not handle tools or equipment while installing the well.

The decontamination procedure that will be used for submersible pumps will be in accordance with the following:

1. Rinse or pump a mixture of tap water and laboratory detergent (Liquonox or equivalent) thoroughly through the pump using a brush if necessary to remove particulate matter or surface film.
2. Rinse and pump with deionized or distilled water (minimum of 30 gallons) and allow to air dry.
3. Wrap with aluminum foil (shiny side not in contact with equipment) to prevent contamination if equipment is to be stored or transported.

Submersible pumps (or bailers) which are taken out of the well casing should be placed on clean aluminum foil or other appropriate material to prevent contamination.

Decontamination rinse waters must be contained so as to prevent the introduction of contamination. Rinsate will be collected in a compatible container and properly disposed of to prevent cross-contamination to adjacent areas.

3.3.13 FIELD ANALYTICAL INSTRUMENT DECONTAMINATION

Portable analytical instruments (e.g., pH meters, specific conductance meters) will be rinsed with deionized or distilled water prior to such use. During sampling, organic vapor monitoring equipment, such as an OVA, will require proper cleaning based on manufacturer specifications prior to use.

3.3.14 FIELD QUALITY CONTROL SAMPLES

In order to verify the quality of the sample collection, transportation, and analysis of samples collected during the RFI, several types of quality control samples will be collected for each media type. These samples will include: duplicates, sampler rinsates, trip blanks, field splits, and field blanks.

For the purposes of this plan, QA/QC samples will be defined as follows:

- Duplicate Samples - these are blind quality control samples which are duplicates of field samples, and which are submitted to the Laboratory Contractor. Duplicate samples for volatile organic analyses will be grab samples as opposed to composite samples. Internal quality assurance duplicate samples will be collected at a frequency of one per matrix type or one for each 10 samples of each matrix type sent to the Contractor laboratory, whichever is greater. These sample results will be compared to those of the original samples for final data validation.
- Trip Blank Samples - these samples, prepared by the Laboratory Contractor, are used for volatile organic samples only. The samples are submitted blind to the Contractor laboratory with each cooler containing volatile organic field samples.

Trip blanks are defined as containers filled with native soils determined to be free of organic contamination or deionized or distilled water, depending on the sample media. These blanks will accompany the field samples during sampling,

storage, and transportation to the laboratory. These samples will be analyzed to determine if storage or handling has affected the field samples. The results of the trip blanks will be used for final data validation purposes. Trip blanks will be submitted at a frequency of one per sampling day where volatile organic samples have been taken.

- Split Samples - these are samples submitted to the SRS quality assurance laboratory. Split samples for volatile organic analyses will be grab samples as opposed to composite samples unless otherwise specified by the SRS Task Order Manager. The number of split samples will be determined by the SRS RFI Program Team.
- Rinsate Samples - these samples will consist of distilled rinse water which has been poured over decontaminated sampling equipment such as hand spades, trowels, augers, bailers, submersible pumps, etc. Rinsate samples for soil, sediment, and sludge sampling equipment will be labeled as rinsate samples and submitted to the Laboratory Contractor and, optionally, to the SRS Quality Assurance laboratory. Rinsate samples from water sampling equipment will be submitted blind to the

Laboratory Contractor and, optionally, to the SRS Quality Assurance laboratory.

Sampler rinsate samples will be collected periodically during each sampling day. Rinsate samples will be collected at a minimum frequency of at least one per sampling day for each specific cleaning procedure or as specified by the SRS Task

Order Manager for soil sampling equipment and at a minimum frequency of 10 per matrix type or one per sampling day, whichever is greater, for water sampling equipment. These samples will be collected following the cleaning of a bailer, trowel, hand auger, or submersible pump by pouring deionized or distilled water over and inside the sampler after decontamination. A portion of this water will be collected and tested to verify the adequacy of the field cleaning procedures. The results of these samples will be used for final data validation purposes.

- **Field Blanks** - these samples will consist of soils previously collected and analyzed. A portion of these soils will be transferred to another clean container prior to the sampling event. This container will be transported to the field during the sampling period and, using proper handling techniques, the soils will be transferred to an

appropriate analytical container in the field. Field blanks for water sampling activities will consist of deionized water.

Field blank samples are quality control samples provided to the SRS Quality Assurance laboratory or its designated laboratory at SRS's option. The results of these samples will be used for final data validation purposes. Field blanks will be taken as appropriate or as requested by authorized SRS personnel.

3.4 MEDIA-SPECIFIC QC CONSIDERATIONS

3.4.1 SOIL SAMPLING QC METHODOLOGY

Section 6 of the RFIPP (Soils Sampling Program Requirements) discusses soil sampling procedures. Section 6 of the RFIPP should be used in conjunction with this QA/QC Plan and sections below to control the quality of field sampling. Appendix I of the RFIPP summarizes the soils classification system detailed in DPSOP 254, which will be used for RFI projects.

3.4.1.1 Sampling Locations

The selection of sampling points will be based on existing data for each RFI site as described in Sections 6.6.2.2 and 6.6.2.3 (Confirmation Sampling Phase) and 6.6.3.2 and 6.6.3.3 (Assessment Sampling Phase) of the RFIPP and reconnaissance trips. The sampling points will be selected and clearly marked on a site map prior to the sampling event. Section 6 of this plan presents the soil sampling plan for this site.

3.4.1.2 Surface and Shallow Soil Sampling Procedures

Equipment to be utilized for collection of surface soils include stainless steel scoops, spatulas, trowels, tile spades, and hand augers. Surface and shallow soil sampling (1-15 cm depth) will be in accordance with Method II-1 from Characterization of Hazardous Waste Sites - A Methods Manual: Volume II, Available Sampling Methods, 2nd Edition (EPA-600/4-84-076):

1. Upon reaching the approximate sample depth, remove and discard a thin layer of soil using a scoop or spatula.
2. Transfer sample into an appropriate sample bottle using the same stainless steel scoop or spatula noted above. The sampler will collect an adequate volume of sample.

3. Check that a Teflon liner is present in the cap if required. Secure the cap tightly. The chemical preservation of solids is generally not recommended. Refrigeration is usually the best approach supplemented by a minimal holding time. Table 3-1 should be consulted for container and preservation requirements.
4. Immediately after the sample is collected, the following documentation is required:
 - Label as specified in Section 3.3.5
 - Enter sample designation in field log book as specified in Section 3.3.6
 - Photograph as specified in Section 3.3.7
 - Complete sample Chain-of-Custody Form as specified in Section 3.3.9
5. Decontaminate equipment after each sample (as described in Section 3.3.12).
6. Discard contaminated personal protective clothing as specified in the activity-specific safety plan.

7. Place sample in cooler and prepare for packaging as specified in Section 3.3.11.

3.4.1.3 Intermediate Depth Soil Sampling

For samples collected at depths of 1-3 meters, the following procedure (Method II-2) from Volume II of Characterization of Hazardous Waste Sites, using a hand or power auger and thin-wall tube coring apparatus, will be followed:

1. After reaching the desired sample depth, slowly and carefully remove the auger from the boring. (Note: When sampling directly from auger, collect sample after auger is removed from boring and proceed to Step 7).
2. Remove auger tip from drill rods and replace with a cleaned thin-wall tube sampler. Install proper cutting tip.
3. Carefully lower corer down borehole and gradually force corer into soil. Care should be taken to avoid scraping the borehole sides. Hammering of the drill rods to facilitate coring should be avoided as the vibrations may cause the boring walls to collapse.
4. Remove corer and unscrew drill rods.

5. Remove cutting tip and remove core from device.
6. Discard top of core (approximately 2.5 cm), which represents material collected by the corer before penetration of the layer in question. Place remaining core into sample container.
7. Check that a Teflon liner is present in the cap if required. Secure the cap tightly. The chemical preservation of solids is generally not recommended. Refrigeration is usually the best approach supplemented by a minimal holding time. Table 3-1 should be consulted for specific container and preservation requirements.
8. After the sample is collected, the following documentation is required:
 - Label the container as specified in Section 3.3.5
 - Enter sample designation in field log book as specified in Section 3.3.6
 - Photograph as specified in Section 3.3.7

- Complete Chain-of-Custody Form as specified in Section 3.3.9.

9. Decontaminate equipment after each sample as specified in Section 3.3.12.
10. Discard personal protective clothing, if contaminated, as specified in the site-specific health and safety plan.
11. Place sample in cooler and prepare for packaging as specified in Section 3.3.11.

Samples should not be removed directly from the auger, because a disturbed sample may be produced which could be contaminated by overlying soils. In rocky soil, where it is impossible to insert a thin-tube sampler, sampling directly from the auger may be the only viable method. In loose soil where the borehole will not remain open when the auger is removed, a temporary casing can be used until the desired sampling depth is reached. In some cases it may be necessary to use a hollow-stem auger to prevent the borehole from collapsing.

3.4.1.4 Deep Soil Sampling

Procedures for soil borings deeper than 3 meters are presented in Section 7 of the RFIPP. For most cases, a split-spoon sampler will be used to collect the necessary soil sample. It may be necessary to substitute other sample devices in place of the split-spoon samplers. In this case, specific sample collection procedures will be developed prior to sampling using the information presented in Sections 6 and 7 of the RFIPP. In all cases, Steps 4 through 7 below must be followed. If a split-spoon sampler is used to obtain deep soil samples, the samples will be collected as specified in ASTM D1586-84. Each split-spoon sample will be taken according to the following procedures:

1. Decontaminate sampler as specified in Section 3.3.12.
2. Drive sampler 24 inches with a 140-pound hammer falling 30 inches, recording the number of blows required.
3. Sample aliquots will be removed from the split-spoon sampler using a decontaminated stainless steel spatula, scoop, or spoon and placed in the appropriate containers.
4. After the sample is taken, the following documentation is required:

- Label as specified in Section 3.3.5
 - Enter sample identification in field log book as specified in Section 3.3.6
 - Photograph as specified in Section 3.3.7
 - Complete Chain-of-Custody Form as specified in Section 3.3.9
5. Decontaminate split spoon by steam cleaning between samples in the same borehole, as specified in Section 3.3.12.
 6. Discard latex surgical gloves as specified in Section 3.3.8.
 7. Place sample in cooler at 4°C and prepare for packaging as specified in Section 3.3.11.

3.4.1.5 Organic Vapor Screening

Selected soil samples will be screened using an OVA or HNu analyzer. The following procedure will be followed for screening of organic vapor concentration:

1. Place a small portion of the sample in an air-tight plastic bag. Seal and label the bag. Place the bag in a warm location such as inside a field sampling vehicle.
2. After approximately twenty minutes, the headspace of the bag sample will be screened using the HNu or OVA. This value will be recorded in the Field Sampling Log Book (See Section 3.3.6).

3.4.2 GROUNDWATER SAMPLING QC METHODOLOGY

Section 7 of the RFIPP should be used in conjunction with this QA/QC plan to control data quality.

3.4.2.1 Sampling Locations

Sampling point locations will be selected according to the criteria specified in Sections 7.4.3 and 7.4.4 (Preliminary Sampling Phase) and 7.5.3 and 7.5.4 (Assessment Sampling Phase) of the RFIPP. The selection of sampling locations will also be based on existing monitoring well data for each RFI site and other monitoring wells installed to characterize the RFI site. The locations will be clearly marked on a site map prior to sampling. The groundwater sampling plan is presented in Section 7 of this plan.

3.4.2.2 Bailer Sampling OC Procedures

This section describes the procedure for sampling groundwater from a monitoring well using a bailer. Bailers will be used to evacuate and sample low yield wells. Bailer samples will be taken according to the following procedures:

1. Decontaminate bailer as specified in Section 3.3.12
2. Follow bailer sampling procedure per DPSOP 254-XI.7. Latex surgical gloves will be used during well evacuation and sampling.
3. After sample is obtained, the following documentation is required.
 - Label as specified in Section 3.3.5.
 - Enter sample identification in field log book as specified in Section 3.3.6.
 - Photograph as specified in Section 3.3.7.
 - Complete Chain-of-Custody Form as specified in Section 3.3.9.

4. Discard personal protective clothing, if contaminated, as specified in the site-specific health and safety plan.
5. Place sample containers in cooler and prepare for packaging as specified in Section 3.3.11.

3.4.2.3 Submersible Pump OC Procedures

This section describes the procedure for sampling groundwater from a monitoring well using a submersible pump. Submersible pumps will be used to sample medium to high yield wells.

1. Decontaminate pump as specified in Section 3.3.12.
2. Follow pump sampling procedures as described in DPSOP 254-XI.8. Note: Latex surgical gloves will be used during well evacuation and sampling.
3. After sample is obtained, the following documentation is required.

- Label as specified in Section 3.3.5.

- Enter sample identification in field log book as specified in Section 3.3.6.

- Photograph as specified in Section 3.3.7.
 - Complete Chain-of-Custody Form as specified in Section 3.3.9.
4. Discard personal protective clothing, if contaminated, as specified in the site-specific health and safety plan.
 5. Place sample containers in cooler and prepare for packaging as specified in Section 3.3.11.

3.4.2.4 Containment of Evacuated Groundwater

Containment of evacuated groundwater from monitoring wells will be evaluated on a site-and well-specific basis. At a minimum, containment of evacuated water will be required at sites where existing data indicate the existence of groundwater contamination.

3.4.3 SURFACE WATER/SEDIMENT SAMPLING OC METHODOLOGY

Section 8 of the RFIPP (Surface Water/Sediment Sampling Strategy) discusses the general procedures for surface water and sediment sampling at RFI sites. Section 8 of the RFIPP

should be used in conjunction with this plan to control data quality.

3.4.3.1 Sampling Locations

Sampling locations will be selected according to the criteria specified in Sections 8.6.1 and 8.6.2 of the RFIPP. Sampling strategies are dependent on the type of surface water body being sampled (e.g., impoundments, streams, drainage ditches, wetlands). The locations will be clearly marked on a site map prior to sampling. The surface water and sediment plan is presented in Section 8 of this plan.

3.4.3.2 Field Equipment Calibration

Field equipment used for surface-water and sediment measurements will be calibrated in accordance with the generic calibration procedures listed in Section 3.3.2. Sampling and field measurements will not be conducted until equipment is properly calibrated.

The pH, specific conductance, and dissolved oxygen meter(s) will be calibrated whenever the equipment is moved to another sampling site. The pH meter will be calibrated using standard buffer solution at two different pH values. The specific conductance meter will be calibrated using a KCl (potassium chloride) standard. The oxygen meter and

flowmeter, if utilized, will be calibrated according to procedures listed in the specific equipment operating manual. Thermometers will be calibrated at least monthly, using an NBS certified thermometer.

3.4.3.3 Shallow Surface-Water Sampling

Shallow surface water sampling will be conducted in accordance with DPSOP 254 and Characterization of Hazardous Waste Sites - A Methods Manual: Volume II. Available Sampling Methods, Second Edition (EPA-600/ 4-84-076). The procedure for shallow surface water sampling is as follows:

1. Exercise care when opening and filling the bottles since some of the bottles contain carefully measured amounts of chemical preservatives. The preservatives vary, but some are small amounts of concentrated sulfuric and nitric acid which are extremely corrosive.
2. Do not mix the caps or rinse the sample containers.
3. Grab samples may be collected directly in the sampling container. Reduce risk of sample contamination by sampling against the stream flow.
4. Fill the sample containers with the proper volume of water according to specifications in Table 3-1. DO NOT

OVERFLOW (except in case of VOCs-- refer to special VOCs sampling instructions) to prevent loss of preservative.

5. Cap containers tightly.
6. After sample is collected, the following information is required:
 - Label as specified in Section 3.3.5
 - Enter sample designation in field log book as specified in Section 3.3.6
 - Photograph as specified in Section 3.3.7
 - Complete sample Chain-of-Custody Form as specified in Section 3.3.9
7. Decontaminate equipment after each sample (as described in Section 3.3.12).
8. Discard contaminated personal protective clothing as specified in the site-specific health and safety plan.
9. Place sample in cooler and prepare for packaging as specified in Section 3.3.11.

10. Measure designated in-situ field parameters and record data in field log book.

Disposable gloves will be used during sampling events. The inside of the sampling container must never be touched or contaminated with repellents, perfumes, or other organic liquids and vapors.

3.4.3.4 Deep or Stratified Water Sampling

Sampling of stratified waters or waters too deep to sample using the procedure in Section 3.4.3.3 above will be sampled using a Kemmerer bottle or equivalent method as indicated below:

1. Inspect sampler bottle for thorough cleaning and ensure that sample drain valve is closed (if bottle is so equipped).
2. Measure and then mark sample line at desired sampling depth.
3. Open bottle by lifting top stopper-trip head assembly.
4. Gradually lower bottle until desired level is reached (mark from Step 2).

5. Place messenger on sample line and release.
6. Retrieve sampler; hold sampler by center stem to prevent accidental opening of bottom stopper.
7. Rinse or wipe off exterior of sampler body (wear proper gloves and protective clothing).
8. Recover sample by grasping lower stopper and sampler body with one hand (gloved), and transfer sample by either (a) lifting top stopper with other hand and carefully pouring contents into sample bottles, or (b) holding drain valve (if present) over sample bottle and opening valve.
9. Allow sample to flow slowly down side of sample bottle with minimal disturbance.
10. Select sample bottles and preserve the sample if necessary as per guidelines in Section 3.3.4.
11. Check that a Teflon liner is present in the cap if required. Secure the cap tightly.
12. After the sample is collected, the following documentation is required:

- Label as specified in Section 3.3.5
 - Enter sample designation in field log book as specified in Section 3.3.6
 - Photograph as specified in Section 3.3.7
 - Sample Chain-of-Custody Form as specified in Section 3.3.9
13. Decontaminate equipment after each sample (as described in Section 3.3.12).
14. Discard contaminated personal protective clothing as specified in the site-specific health and safety plan.
15. Place sample in cooler and prepare for packaging as specified in Section 3.3.11.

3.4.3.5 Sediment and Sludge Sample Collection

Sediment and sludge sampling will be conducted in accordance with DPSOP 254 and Characterization of Hazardous Waste Sites - A Methods Manual: Volume II, Available Sampling Methods, Second Edition (EPA-600/ 4-84-076).

3.4.3.5a Sludge or Sediment Sampling With a Ponar Grab

The dredge or grab will be capable of sampling most of the aquatic sediment types encountered at SRS. The procedures outlined below are for the Ponar grab, but will be applicable to other commercially available clamshell-type scoops.

1. Attach a cleaned Ponar to the necessary length of sample line. Solid braided 5 mm (3/16 inch) nylon line is usually of sufficient strength; however, 20 mm (3/4 inch) or greater nylon line allows for easier hand hoisting.
2. Measure and mark the distance to bottom on the sample line. A secondary mark, 1 meter shallower, will indicate proximity so that lowering rate can be reduced, thus preventing unnecessary bottom disturbance.
3. Open sampler jaws until latched. From this point on, support sampler by its lift line; (otherwise, the sampler will be tripped and the jaws will close).
4. Tie free end of sampler line to fixed support to prevent accidental loss of sampler.
5. Begin lowering the sampler until the proximity mark is reached.

6. Slow the rate of descent through the last meter until contact is felt.
7. Allow sample line to slack several centimeters. In strong currents more slack may be necessary to release mechanism.
8. Slowly raise dredge clear of water surface.
9. Place Ponar into a stainless steel or Teflon tray and open. Lift Ponar clear of the tray.
10. Collect a suitable aliquot with a cleaned stainless steel lab spoon or equivalent and place sample into appropriate container, as specified in Table 3-1.
11. Check for a Teflon liner in cap if required and secure cap tightly. The chemical preservation of solids is generally not recommended (refer to guidelines in Table 3-1).
12. After the sample is collected, the following documentation is required:

- Label as specified in Section 3.3.5.

- Enter sample designation in field log book as specified in Section 3.3.6.
 - Photograph as specified in Section 3.3.7.
 - Complete Chain-of-Custody Form as specified in Section 3.3.9
13. Decontaminate equipment after each sample (as described in Section 3.3.12).
 14. Discard contaminated personal protective clothing as specified in the site-specific health and safety plan.
 15. Place sample in cooler and prepare for packaging as specified in Section 3.3.11.

3.4.3.5b Sludge or Sediment Sampling With a Hand Corer

Sediment sampling through vegetated soils likely to be encountered in wetlands or floodplains will be conducted with the use of a hand corer. The corer can be used to sample in small clearings and is capable of cutting through underlying root mats to obtain a discrete sample. A number of core types may be utilized effectively; each is used following the procedure presented below:

1. Force corer in with smooth continuous motion.
2. Twist corer, then withdraw in a single smooth motion.
3. Withdraw sample into a stainless steel or Teflon tray.
4. Transfer sample into an appropriate sample bottle with a stainless steel lab spoon or equivalent.
5. Check that a Teflon liner is present in cap if required. Secure the cap tightly. Chemical preservation of solids is generally not recommended (refer to guidelines in Table 3-1).
6. After sample is collected, the following documentation is required:
 - Label as specified in Section 3.3.5.
 - Enter sample designation in field log book as specified in Section 3.3.6.
 - Photograph as specified in Section 3.3.7.
 - Complete Chain-of-Custody Form as specified in Section 3.3.9.

7. Decontaminate equipment after each sample (as described in Section 3.3.12).
8. Discard contaminated personal protective clothing as specified in the site-specific health and safety plan.
9. Place sample in cooler and prepare for packaging as specified in Section 3.3.11.

3.4.4 HEALTH AND SAFETY MONITORING QC METHODOLOGY

This section outlines the required QC procedures for health and safety monitoring during the RFI at the RACB. Ambient air sampling is not anticipated to be required during the RFI; therefore, QC procedures for ambient air sampling are not included. It may, however, be necessary to implement ambient air sampling during site remediation. QC procedures for such sampling should be developed at that time.

3.4.4.1 Monitoring Equipment Calibration and Preparation

Air monitoring equipment will be properly calibrated and prepared before field use according to the guidelines listed in Section 3.3.

The following air monitoring equipment may be used for health and safety monitoring.

- Flame ionization detector
- Photoionization detector
- Portable, field-operable GC
- Stain detector (colorimetric) tube
- Rad-mini

Calibration, preparation, and operation procedures are presented in Section 3.4.4 of the RFIPP.

3.4.4.2 Equipment Operating Procedures

The operating procedures for the air monitoring equipment are presented in Section 3.4.4 of the RFIPP.

3.5 LABORATORY QA/QC

The primary objective of a laboratory QA/QC program is to ensure the precision and accuracy of data generated by contractor laboratories. Prospective RFI laboratory contractors will prepare and submit to the SRS RFI Program Team for approval a detailed laboratory QA/QC Plan for all RFI projects. Due to the nature and number of the RFI sites at SRS, laboratory uniformity is required in the following areas:

- Sample handling
- Methods control
- Performance evaluation
- Analytical data generation and control
- Data management

To achieve the uniformity described above, SRS will use the EPA CLP protocols as the standard for laboratories which will be used during all RFI work. SRS will require laboratories involved in the RFI process to be either contract laboratories to the CLP or laboratories which adhere and conform to the requirements of the CLP.

3.6 REQUIRED DOCUMENTATION

This section presents the documentation requirements for the RACB RFI. Documents will become the property of SRS and no document will be released by consultants or contractors without the written approval of SRS and DOE.

The following documents will be submitted to the SRS Task Order Manager by the Oversight Contractor:

- RFI Site-Specific Work Plans
- RFI Report (including data,

- All progress or interim reports which may be required per SRS RCRA Permit Section V

The Oversight Contractor will also maintain for a period of 3 years, or longer if contracted for, information, data, or reports in a secured area. The SRS Task Order Manager may request this information from the appropriate contractor if required by South Carolina DHEC or EPA. Information to be maintained by the Oversight Contractor includes:

- Field Log Books
- Field Laboratory Log Book
- Field Instrument Calibration Log Book
- Approved RFI Work Plans
- Chain-of-Custody Forms
- Data reduction calculations
- SHERP data

Information to be maintained by the laboratory contractor includes, but may not be limited to:

- Laboratory Log Book
- Laboratory notes
- Internal laboratory performance audits
- Chromatograms
- Raw data printouts

3.7 STORAGE OF CONTRACTOR DELIVERABLES AND RECORDS

The SRS Task Order Manager, in conjunction with the SRS RFI Program Team, will specify for each RFI project the storage location of contractor deliverables. Documents which will remain at SRS will be stored in areas conforming to SRS QA Manual Procedure QAP 17.1.

3.8 SITE INSPECTIONS AND AUDITS

The SRS RFI Program Team has the authority to conduct or coordinate site investigations and audits of site sampling and laboratory analytical work. The purpose of these inspections or audits will be to identify nonconformances with the requirements outlined herein. Where a nonconformance is identified, the SRS RFI Program Team has the authority to stop the contractors' work until the nonconformance is corrected.

3.9 CONTROL OF NONCONFORMING ITEMS

Nonconforming items will be identified, controlled, and documented. After identification of a nonconforming item, the item will be tagged and segregated as appropriate to preclude further use until the proper disposition is determined and completed. The effect of the nonconforming items on the RFI will be determined and any adverse effect will be brought to the attention of the SRS RFI Program Team for review, evaluation, and corrective action, as appropriate. Control of nonconforming items will be in accordance with SRS QA Procedure 15-1.

This Page Intentionally Left Blank.

Section 4
DATA MANAGEMENT REQUIREMENTS

4.1 INTRODUCTION

This section presents the data management plan for the RACB RFI and provides procedures necessary to document, track, and manage field data and laboratory data generated during the course of the RFI. The purpose of the RFI Program Data Management plan is to:

- Identify data management responsibilities for SRS and Oversight Contractor personnel
- Identify field, laboratory, and development data to be recorded and maintained
- Identify data coding requirements
- Identify data to be included on progress and site investigation reports to SRS

4.2 CONTRACTOR AND SRS PERSONNEL

DATA MANAGEMENT RESPONSIBILITIES

This Data Management Plan provides format requirements for presenting raw data, tabulated data, and summary data of the field investigations and laboratory analyses. Deviations from data formats and required information will not be permitted unless written approval for such is obtained from the SRS Task Order Manager. Where applicable, data management activities will conform to the requirements specified in DPSOP 254.

4.2.1 OVERSIGHT CONTRACTOR PROJECT MANAGER

The Oversight Contractor's Project Manager is responsible for reviewing the analytical data received from the laboratory to determine if the data meet the requirements of the SRS RFI contract. Data which do not meet these requirements will be identified and reported to the SRS RFI Program Team.

4.2.2 OVERSIGHT CONTRACTOR FIELD OVERSIGHT COORDINATOR

The Oversight Contractor's Field Oversight Coordinator (FOC) will maintain and record information and data required in the field log book discussed in Section 3.

4.2.3 OVERSIGHT CONTRACTOR HEALTH AND SAFETY OFFICER

The Oversight Contractor's Health and Safety Officer (HSO) will be responsible for maintaining and recording information and data required by Section 2.

4.2.4 LABORATORY CONTRACTOR QA MANAGER

The Laboratory Contractor QA Manager will submit laboratory data to SRS and to the Oversight Contractor (for review) in the proper format.

4.2.5 SRS RFI PROGRAM TEAM AND TASK ORDER MANAGER

The RFI Program Team must approve any changes or deviations from the reporting of data as required under this Data Management Plan.

The RFI Program Team and Task Order Manager will perform inspections related to the generation, collection, and storage of data under the scope of work required of the contractor and in accordance with SRS QA Manual procedure QAP 18-1.

4.3 RECORDING OF FIELD DATA

Data, checklists, photographs, calibration logs, etc., generated during the course of the investigation will be included as part of the RFI project file and/or field log books. After completion of the investigation, data and reports will be maintained by the Oversight Contractor in accordance with Section 3.7.

The field log book and calibration logs will be maintained by the Oversight Contractor until the completion of the investigation. The Oversight Contractor's FOC will label each of the log books on the front cover with the information specified in Section 3.3.6.

Data recorded in the field log book will be printed in a legible manner using waterproof ink. Log book entries will contain accurate and inclusive documentation of project activities, specifically daily activities. Because the information contained in these log books forms a basis for the later written reports, such information and data must contain only facts and observations. Language is to be objective, factual, and free of personal feelings or any other terminology that may prove to be inappropriate or irrelevant. The field log book will contain that information, at a minimum, specified in Section 3.3. The

field log book will be maintained at the RFI site during times that the FOC is present.

The field calibration forms specified in Appendix Q of the RIFPP will be completed as necessary and stored in the project files.

4.3.1 ADDITIONAL FIELD DATA

During the course of the RFI, additional field data will be generated which may not be directly entered into the field log book but will eventually become an integral part of the project files. The additional information and data will include (but is not limited to) the following:

- Monitoring Well Specifications Form DPSOP 254-V-1
- Monitoring Well Installation Form DPSOP 254-V-2
- Monitoring Well Construction Details Form DPSOP 254-V-3
- Well Development Form DPSOP 254-V-6

* These data will be entered or included as part of the project files for each particular site. This information will be

maintained by the Oversight Contractor as specified in Section 3.

4.3.2 PHOTOGRAPHS

Photographs may be requested by the Oversight Contractor as a means of providing visual evidence of unusual items and anomalies discovered during the course of the RFI. Such photographs will be taken only by SRS approved personnel. The Oversight Contractor will be responsible for references to these photographs as part of the field log book. Photographs will be taken in accordance with the requirements specified in Section 3.

4.3.3 OTHER FIELD DATA NOT PART OF THE FIELD LOG BOOK

Most hydrogeological data, etc., will be managed and transferred between parties in accordance with DPSOP 254, Chapter XVI. A field data record in the format specified in DPSOP 254, Chapter XVI will be maintained after completion of the RFI. A field data collection form will be developed by SRS to provide a means of managing field data in accordance with a standardized SRS system. Figure 4-1 presents a copy of the field data collection form developed by SRS related to groundwater sampling, which will be completed to facilitate entrance into computer files. Directions for completing this form appear in DPSOP 254-XVI and Appendix R of the RFIPP.

The data record will be submitted to SRS in the form of a standard ASCII text file on a 5-1/4 inch "floppy" diskette or a 3-1/2 inch "micro floppy" diskette as requested by SRS.

4.4 RECORDING OF LABORATORY DATA

Recording requirements related to the management of data delivered to the laboratory from the Oversight Contractor are the use of the required sample labeling, chain-of-custody forms, and analysis request forms. These forms will not be included as part of the field log book but will be part of the data received from the laboratory by the Oversight Contractor to be maintained as part of the project files. The Oversight Contractor and the Laboratory Contractor will be responsible for storing certain information and data related to the RFI. This information and data to be stored and maintained by the Oversight Contractor will include:

- Chain-of-Custody Forms
- Tabulated data printouts
- Laboratory QA/QC data

The information and data to be stored and maintained by the Laboratory Contractor will include, but not be limited to:

- Laboratory notes
- Internal laboratory performance audits

- Chromatograms
- Raw data printouts

Data will be available within 48 hours upon request by SRS if allowed for in the contract. The data and information will be stored in an environmentally sound manner that will protect their integrity until relief from these requirements is provided by SRS. Reports and data will be stored in accordance with SRS QA Manual procedure QAP 17-1.

Appendix S of the RFIPP presents Chain-of-Custody and Request for Analysis Forms required as part of the laboratory data to be generated.

4.4.1 FIELD LABORATORY DATA REQUIREMENTS

A field laboratory log book will be utilized by the analysts who conduct field analyses. This log book will include

information documenting the analyses performed and documenting the dates and results of calibration of mobile laboratory equipment. It will also be a record of any incidents that occur during the survey, such as power outage, tampering with equipment, etc. Appropriate notations of visitors to the mobile laboratory, such as facility personnel, will be entered into the log book.

Figure 4-1
Field Data Collection Form
Groundwater Sampling

WELL	DATE	TIME	WATER TEMP (°F)	PH	SPECIFIC CONDUCT. (µMHOS/CM)	DEPTH TO WATER (FT)	VOLUME PURGED (GALS)	AIR TEMP (°F)	METHOD	PROGRAM	SAMPLER INITIALS	TOTAL ALKALINITY (MGL)
COMMENTS												
COMMENTS												
COMMENTS												
COMMENTS												
COMMENTS												
COMMENTS												
COMMENTS												
COMMENTS												
COMMENTS												
COMMENTS												
COMMENTS												

4.4.2 OFF-SITE LABORATORY DATA REQUIREMENTS

An off-site laboratory log book will be utilized by the analysts. This log book will not only include information documenting the analyses performed but will also document the dates and results of equipment calibrations, incidents that occur during analyses, and visitors to the laboratory. Laboratory performance audits will be recorded in this log book as well as other requirements set forth under the work contract.

The Laboratory Contractor will be responsible for ensuring the proper recording of laboratory data generated for the analyses of media samples. Forms developed by SRS for this purpose, such as "Chemical Analysis Results Coding Forms and Descriptions" for groundwater will be used as appropriate. These forms and the directions for their use are included in Appendix T of the RFIPP. Upon development and implementation by SRS, the "Chemical Analysis Results Coding Forms and Descriptions" and directions for other media will be added to Appendix T for reference. Tables 1, 2 and 3 of Appendix T along with the supplemental code list presented in Appendix U are to be used in completing the form currently developed by SRS for groundwater. This information as presented in

Appendix U may be used upon final development and implementation of the media forms.

4.5 RECORDING OF DEVELOPMENT DATA

"Development data" refers to information or data gathered from field or laboratory based activities and will be included in the progress report and the final report. These data will be prepared in a clear, concise manner using graphical displays and standard symbols or, where necessary, those symbols approved by SRS. The Oversight Contractor will store and maintain these data in an environmentally sound manner to protect the integrity thereof, as allowed for in the contract.

4.6 RECORDING OF SHERP DATA

"SHERP data" refers to information or data (such as health and safety training records, field monitoring results, safety and emergency procedures, etc.) required by Section 2 (Safety, Health, and Emergency Response plan) of this RFI plan. Each contractor will be responsible for generating these data in a clear, concise manner. The Oversight Contractor's HSO will store and maintain the data pertaining to the Oversight Contractor's personnel or RFI field activities in an environmentally sound manner to protect the integrity thereof as allowed for in the contract. Data

records will be produced if requested by the SRS RFI Program Team and as allowed by the contract.

4.7 RFI DATA REPORTING REQUIREMENTS

4.7.1 PROGRESS REPORTS

The Oversight Contractor will prepare progress reports at each of the four checkpoints identified below. Specifically, reports will be presented to the RFI Task Order Manager after completion of the following activities:

<u>Checkpoint</u>	<u>Activity</u>
No. 1	Preliminary Site Evaluation
No. 2	Site Screening
No. 3	Soils Assessment
No. 4	Groundwater, Surface-Water/Sediment, and Ambient Air Assessments

The Oversight Contractor will use professional judgment in determining the degree of information to be included in progress reports. Sufficient information will be provided to enable the RFI Program Team to understand the progression of activities and the investigation results. An outline of any subsequent investigation activities will also be provided. For those RFI sites which require no further investigation

after Checkpoint No. 1 or No. 2, the Oversight Contractor will prepare an abbreviated final report.

4.7.2 RFI FINAL REPORT REQUIREMENTS

The Oversight Contractor will prepare a final report upon completion of the site-specific RFI. This report will be submitted to the SRS Task Order Manager for appropriate distribution and review.

The report will detail RFI activities completed and will include a discussion about key decision points encountered and resolved during the course of the investigation. This report will also contain data necessary to understand the project in its entirety including investigative methods and procedures.

At a minimum the following information will be included in this report:

- Conclusions related to the preliminary site evaluation
- Data and results generated from the site screening
- Analytical data generated from the soils sampling

- Analytical data generated from the groundwater sampling
- Analytical data generated from the surface-water/sediment sampling (if performed)
- Analytical data generated from the ambient air sampling (if performed)
- Topographic map of site denoting sample locations

In addition to this information and data, it will be necessary to discuss any upset conditions that occurred during any sampling events or laboratory analyses that may influence the results. It will also be necessary to enter into the text of the final report development data (i.e., well drilling logs, stratigraphic cross-sections, etc.) that provide additional support to the data and interpretations discussed. It may be necessary to introduce key elements of the development data into the text of the final report using graphical displays (isopleths, potentiometric, ecological, cross-sections, etc.).

The objective of the final report is to describe the RFI and present the results. The final report will not detail any further recommendations for additional site work or remediation efforts.

4.7.3 QUALITY OF REPORTS

Reports will be prepared on classic crest grade paper or better. Only black ink will be used in conjunction with standard type (10 character per inch) at 1-1/2 spacing. The front and back of each page will be used unless otherwise specified by SRS. Reports will be securely bound and clearly identified for each specific site. The Oversight Contractor will supply the contracted number of copies of reports prepared in accordance with instructions from the SRS Task Order Manager.

4.8 DIRECTIVES

At any time during the RFI, contractors may be asked to submit unsorted raw data, chain-of-custody forms, chromatograms, etc., to SRS, as allowed by the contract. This information may be in addition to that included in the final report.

This Page Intentionally Left Blank.

Section 5

RESULTS OF PREVIOUS INVESTIGATIONS

This section summarizes the results of previous site investigations at the RACB presented in the site Environmental Information Document (EID) (Pickett et al., 1987).

5.1 CONTAMINANT CHARACTERIZATION

Previous studies at the RACB have included the installation of four groundwater monitoring wells in 1983 and 1984 to depths of approximately 60 feet (Figure 1-2). The SRS Health Protection Department has sampled these wells quarterly as part of the SRS groundwater monitoring program; sampling results are tabulated in Appendix B.

A statistical analysis of the 1984 and 1985 data (presented in the EID) found lead to be the only constituent detected at a significantly higher concentration in a downgradient well (BRD-1) than in the upgradient well (BRD-3). However, the average lead concentration of 42 $\mu\text{g/l}$ was still below the U.S. EPA Maximum Contaminant Level (MCL) of 50 $\mu\text{g/l}$. Gross alpha was detected in wells at concentrations slightly above

normal SRS groundwater concentrations, but since 1985 at concentrations below the MCL of 15 pCi/l.

5.2 HYDROGEOLOGY

The relative depths of the monitoring wells and groundwater levels at RACB are shown in Figure 5-1. The BRD series wells are probably screened within Hydrologic Unit 6 (the McBean member of the Santee Limestone). The water table in the vicinity of the basin is approximately 35 feet below ground surface at an elevation of approximately 170 feet above mean sea level (msl). It is expected that the natural discharge of groundwater from the site is southwest toward the wetland where the ground surface elevation is approximately 150 feet msl (see Figure 1-1).

It is stated in the EID that the elevation of the piezometric surface in Hydrologic Unit 5 (the Congaree Formation) at the RACB is approximately 130 feet msl. This is lower than the water table elevation, and thus there is the potential for downward flow from the water table to Hydrologic Unit 5. The elevation of the piezometric surface in Hydrologic Unit 3 (the Black Creek Formation) is reported to be approximately 164 feet msl, which is higher than that in Hydrologic Unit 5, suggesting the potential for upward flow. Upward flow to

Figure 5-1
MONITORING WELL SCREEN DATA

Hydrologic Unit 5 would reduce the potential for contamination from the site to reach Hydrologic Unit 3.

Hydrographs for the BRD wells are shown in Figure 5-2. Well BRD-3 is generally considered to be the upgradient well (see Figure 1-2) and wells BRD-1 and BRD-4 appear to be downgradient wells. Well BRD-4 does not appear to be directly downgradient of the basin and well BRD-1 appears to be downgradient of only a portion of the basin. If the cross-over in hydraulic head values between wells BRD-2 and BRD-3 is not due to measurement error, it suggests the possibility of seasonal changes in groundwater flow direction beneath the site.

Aquifer testing has not been conducted in the BRD wells nor have aquifer properties been measured or estimated at a nearby location. The EID assumes a horizontal flow velocity of 33.8 ft/year for the RACB area based on calculations for the Congaree Formation in the A/M area of SRS.

Figure 5-2
WELL HYDROGRAPHIC END DATA

1

This Page Intentionally Left Blank.

Section 6
SITE SCREENING PLAN

A review of existing available data and information for the RACB suggests that:

- Hazardous chemical and radioactive materials were placed in the RACB.
- Lead and gross alpha have been detected above background concentrations in groundwater.
- Historical photographs show standing liquids in the basin.

The objective of site screening at the RACB is to estimate the boundaries of the original basin. Therefore, ground penetrating radar (GPR) will be performed. The GPR survey will consist of three profiles in the direction of the major axis of the basin (generally north-south) at approximately 10-meter (33-foot) intervals, and three profiles in the direction of the minor axis of the basin (generally east-west) at approximately 15- to 20-meter (50- to 70-foot) intervals. The GPR survey should be capable of penetrating to a depth of approximately 3 to 5 meters (10 to 16 feet).

Based on the results of this survey, additional profile lines may be conducted.

The GPR survey will be performed in accordance with existing contracts at SRS. A discussion of GPR methods is presented in Appendix L of the RFIPP.

A soil gas survey is not recommended for the RACB at this time because total organic halogen (TOH) concentrations in groundwater samples have typically been reported at below detection limits, and because soil samples within the basin will be analyzed for specific VOCs.

The nature of wastes disposed of at the RACB is such that the presence of some degree of soil contamination is probable. Therefore, confirmatory soil sampling will not be conducted. Instead, the RFI will proceed directly into the soil assessment sampling phase described in Section 7 to assess whether soil contaminants are at concentrations above background levels.

Section 7
SITE ASSESSMENT PLAN

Assessment plans for the RACB are presented in the following sections:

- Soil Assessment Sampling--Section 7.1
- Groundwater Assessment Sampling--Section 7.2
- Surface Water and Sediment Assessment
Sampling--Section 7.3
- Ambient Air Assessment Sampling--Section 7.4

7.1 SOIL ASSESSMENT SAMPLING

The RFIPP specifies the following objectives for soil assessment sampling:

- Provide additional data concerning the release and transport of waste constituents to the surrounding soil.

- Characterize the nature and vertical and horizontal extents of soil contamination.
- Generate data to identify the need for corrective measures and soil remediation.
- Generate data that can be used in the design and implementation of corrective measures.

To meet the objectives of soil assessment sampling, the following data are needed at the RACB:

- The nature of contamination within and adjacent to the basin
- The extent of contamination indicated by the GPR survey
- Physical properties of the soil
- Soil lithology and texture

The following activities will be performed to meet these data needs:

- Three soil borings will be drilled 35 feet deep in the RACB.

- Five soil borings will be drilled 10 feet deep adjacent to the RACB.
- One soil boring will be drilled 35 feet deep adjacent to the RACB.
- Samples will be collected for analyses of the physical, chemical, and radiological properties of the soil.

Proposed locations of soil borings are shown on Figure 7-1.

Three soil borings will be drilled in the RACB to estimate the nature and the extent of contamination within the basin. The sampling locations are uniformly distributed across the RACB, but may be changed to incorporate the results of the GPR survey. The soil borings will provide data to formulate a profile of contamination within the basin and estimate where sludges may be. The basin was originally about 10 feet deep, whereas the current depth to groundwater is approximately 35 feet. Therefore, the three soil borings will be drilled to the water table to evaluate the migration of contaminants to groundwater.

Six soil borings will be drilled outside the basin to confirm the basin boundaries shown on Figure 7-1. Five of the soil borings will be drilled to the approximate depth of the former basin (10 feet), while the sixth soil boring, west and downslope of the basin, will be drilled to the water table (approximately 35 feet).

Soil borings will be sampled continuously with a split-spoon sampler and samples for chemical analyses will be collected as summarized in Table 7-1. The samples from depths of 8 feet within the basin are intended to be of sludges, if they exist, and will be analyzed for the full set of chemical and radiological parameters. Sludges will be identified from inspection of the soil samples and from field screening of VOC vapors. Samples of fill material above sludge and undisturbed soil beneath sludge will be analyzed for VOCs and metals.

Duplicate soil samples will be collected from two soil borings within the RACB and from one soil boring outside the RACB. These duplicate samples will be used in the quality control of the analytical data, as described in Section 3 of this plan.

Physical properties of soil may affect the migration of contaminants and the options for soil remediation. Therefore, samples selected from the soil borings inside the

Legend

- Existing Monitoring Well
- 10 Foot Soil Boring
- △ 35 Foot Soil Boring
- ▭ Graded and Revegetated Areas

Figure 7-1
SOIL ASSESSMENT SAMPLING LOCATIONS
ROAD A CHEMICAL BASIN

Table 7-1
SUMMARY OF RACB SOIL ASSESSMENT SAMPLING

Boring Depth (Ft)	Total Number of Borings	Sample Zone Depth (Ft)	Analyses per Boring				
			VOC	ABN	PPCB	Metals	Rad
10	5	6 10	X X			X X	
35 (Inside Basin)	3	4 6 8 10 15 20 25 30 35	X X X X X X X X X	X	X	X X X X X X X X X	X
35 (Outside Basin)	1	10 15 20 25 35	X X X X X			X X X X X	

NOTES:

VOC--Volatile Organic Compounds
 ABN--Acid/Base Neutrals
 PPCBs--Pesticides and Polychlorinated Biphenyls
 Rad--Includes Gross Alpha, Gross Beta, and Total Radium
 Metals--Arsenic, Barium, Cadmium, Chromium, Lead, Mercury, Aluminum, and Lithium

basin will be tested for bulk density, porosity, cation exchange capacity, soil organic content, soil pH, particle size distribution, and moisture content. Standard penetration tests conducted during advancement of the soil borings will be used to assess the strength of non-cohesive soils.

7.2 GROUNDWATER ASSESSMENT SAMPLING

The objectives of groundwater assessment sampling are:

- Determine groundwater flow directions in the vicinity of the RACB.
- Determine the nature and extent of contaminants in groundwater.
- Obtain data to assess contaminant migration in groundwater.

Four monitoring wells, screened in the Water Table, exist at the RACB. One additional monitoring well will be installed in the water table aquifer to better determine groundwater flow direction. Locations of the existing and proposed monitoring wells are shown on Figure 7-2. Water level data

collected from the monitoring wells will allow for assessment of groundwater flow directions to confirm the designation of upgradient and downgradient wells given in Section 5. Two wells will be installed in the Congaree unit (up and down gradient) if contamination is detected in the new Water Table well.

The five monitoring wells will be sampled and the groundwater will be analyzed for VOCs; gross alpha, gross beta, and radium; and total concentrations of As, Ba, Cd, Cr, Pb, Hg, Al, and Li. Indicator parameters will also be included in the sample analyses (pH, specific conductance, TOC, and TOH). If results indicate that no contamination has entered groundwater, no further sampling will be required. If soil sampling results indicate the presence of contaminants above background concentrations, the shallow and deep wells downgradient of the site will be sampled for analyses of acid/base/neutral extractables, pesticides, and PCBs.

7.3 SURFACE WATER AND SEDIMENT ASSESSMENT SAMPLING PLAN

According to the RFIPP, surface water and sediment assessment sampling should be done when one or more of the following conditions occur:

- The site is an active surface impoundment

- Wet weather drainage swales or runoff channels extend from within the site.
- A surface water body is located within 100 meters (330 feet) downslope from the site (or further, based on site characteristics).

The surface water body closest to the RACB is a wetland area located approximately 300 meters (1,000 feet) southwest of the basin (Figure 7-3). Local topography indicates that surface water runoff from the RACB would flow toward this wetland along a surface slope of approximately 4 to 5 percent. The wetland is at an elevation lower than that of the water table beneath the RACB; it is therefore expected that the natural discharge of groundwater from the site is southwest toward the wetland.

The objectives of surface water and sediment sampling are:

- Determine whether surface water and sediment contamination has resulted from the release of contaminants from the basin.
- Identify potential exposure pathways associated with releases from the RACB to surface water bodies.

Figure 7-
SURFACE WATER/SEDIMENT
SAMPLE LOCATION

Two surface water samples will be collected from the wetland at the locations shown on Figure 7-3. One sample will be collected directly downslope of the RACB, and the second will be obtained approximately 1,000 feet downstream in the wetland. Two sediment samples from depths of approximately 6 inches will be collected from the same locations and at the same time as the surface water samples. The samples will be collected during low-flow conditions, if possible.

The actual sample locations may be modified at the time of sampling based on the following field observations:

- Surface water and sediment samples will be obtained from areas of standing water in the wetland.
- Surface water and sediment samples will be obtained from areas of stressed vegetation (if such areas are observed) in the wetland.
- Surface water and sediment samples will be obtained from areas of apparent surface water runoff contribution to the wetland (i.e., eroded or currently discharging areas).

In the event that no standing water is observed at the time of sampling, only sediment samples will be obtained from the two locations shown in Figure 7-3.

The following parameters will be measured for surface water samples:

- Depth
- Temperature
- Dissolved Oxygen
- pH
- Specific Conductivity
- Total Dissolved Solids (TDS)
- Total Suspended Solids (TSS)
- Total Organic Carbon (TOC)
- Total Organic Halogens (TOH)
- Gross Alpha, Gross Beta, Radium

The following parameters will be measured for sediment samples:

- pH
- Specific Conductivity
- Total Organic Carbon (TOC)
- Total Organic Halogens (TOH)
- Gross Alpha, Gross Beta, Radium

The surface water and sediment samples will also be analyzed for VOCs and total concentrations of As, Ba, Cd, Cr, Pb, Hg, Al, and Li. The analyses conducted on surface water and sediment samples can be modified based upon the results of soil and groundwater sampling.

7.4 AMBIENT AIR ASSESSMENT SAMPLING

On the basis of waste characteristics, site data, operational history, meteorological factors, and environmental setting, releases of VOCs to the atmosphere from the RACB are not expected. Analyses of groundwater samples indicate that concentrations of VOCs are less than 40 µg/l and do not appear to be a problem at this site. No characterization studies of soils beneath or around the RACB have been performed. Therefore, ambient air sampling is not recommended at this time. However, if soil sampling indicates that elevated levels of VOCs are present, the need for ambient air sampling should be reevaluated.

7.5 MANAGEMENT AND COLLECTION OF SAMPLES

The RFIPP and DPSOP 254 list specific requirements and procedures to be followed during implementation of RFIs at SRS. Media-specific sampling procedures discussed in

Section 3.4 of this plan will be followed. The procedures for sample labeling, sample identification, photographic records, chain-of-custody forms, decontamination, sample packaging, and personal protective equipment outlined in this plan will also be followed. Samples will be screened onsite for organic vapors and radiation. Section 3.4 of this plan lists the procedures for measuring organic vapors with an OVA or HNu.

Soil sample boreholes will be tremie grouted as specified in Section 6000 of DPSOP 254. Drilling will be conducted by a driller licensed in the State of South Carolina.

To reduce the potential for cross-contamination of samples, the sample collection order will begin, whenever possible, with samples least expected to be contaminated and proceed to those most likely to be contaminated. The procedures outlined in Section 3.3 of this plan will be followed for decontaminating field equipment. Procedures outlined in Section 3.3 of this plan will be followed in decontaminating analytical instruments used onsite.

Section 2 of this plan specifies safety procedures to be followed during site activities. Work conducted during sampling phases will be done in accordance with these site safety procedures. Weather and other environmental conditions can affect the soil sampling. Section 6.4.2.8 in

the RFIPP discusses appropriate responses to these conditions.

Section 4 of this plan outlines data management and record-keeping procedures to be followed during site work. Section 4.3 discusses field notes and records and is especially applicable to soil sampling.

Section 8

CONCLUSIONS AND RECOMMENDATIONS

Previous investigations have indicated the presence of contamination at the RACB. A RCRA Facility Investigation (RFI) should be conducted at the site to estimate the nature and extent of contamination, to determine if site remediation is necessary, and to generate data for use in designing and implementing site remediation if needed.

This RFI plan proposes field sampling and analytical work to meet the objectives presented above. The proposed work includes sampling and chemical and radiological analyses of soil, groundwater, surface water, and sediment.

Upon completion of the proposed RFI field work and chemical and radiological analyses, an RFI report should be prepared to present conclusions on the nature and extent of contamination at the site, and to make recommendations for site remediation. If contamination is detected at concentrations above SRS background levels, a receptor analysis should be done to evaluate potential impacts of site contamination on nearby populations.

This Page Intentionally Left Blank.

Section 9

REFERENCES

1. Pickett, J. B., C. F. Muska, and H. W. Bledsoe. "Road A Chemical Basin," Environmental Information Document. March 1987.
2. "Engineering Support Branch Standard Operating Procedures and Quality Assurance Manual," U.S. EPA Region IV. April 1, 1986.
3. "Hydrogeologic Data Collection," E.I. DuPont de Nemours and Company. DPSOP 254. May 1987.

This Page Intentionally Left Blank.

Appendix A

SAFETY MANUAL--ITEM 104

SAFETY OF NONCOMPANY PERSONNEL

A. PURPOSE

This item establishes Du Pont responsibility for the safety practices of noncompany personnel serving Du Pont at the Savannah River Plant and lists general safety guidelines for these personnel on the site. Only safety practices acceptable to Du Pont will be permitted by noncompany personnel who make deliveries or perform a service for Du Pont or one of our subcontractors.

B. GENERAL PLANT RULES

- 1) The department responsible for arranging for the service by noncompany personnel is responsible for designating a Du Pont representative to maintain liaison and to arrange for a safety orientation by the Area Safety Engineer and Health Protection and Security representatives. Safety orientation must be repeated every two (2) years. *
- 2) All injuries shall be reported to a Du Pont representative who will direct or assist the person or persons to Plant Medical (refer to item 104, division E).

C. RULES FOR NONCOMPANY PERSONNEL

- 1) Park in designated areas.
- 2) Do not block operating areas, passageways, road, or railways without specific Du Pont permission.
- 3) Fire alarms, fire extinguishers, fire hose boxes, gas masks, safety showers, and other safety equipment are plainly marked. Keep them free of obstruction for emergency use.
- 4) Comply with posted area safety rules.
- 5) Personal protective equipment must be worn as specified by posted safety rules, or as specified by Du Pont personnel.
- 6) The vendor is responsible for providing the equipment necessary for safe work performance; this includes personal protective equipment.
- 7) Transport and store flammable liquids in UL-approved safety cans, tanks, or trucks, or original unopened shipping containers.
- 8) Wheels of vehicles must be chocked when loading or unloading materials using material handling equipment.
- 9) Drivers are responsible for the proper loading of their vehicles and for the proper securing of loads.

- 10) Noncompany employees will not use Du Pont tools or equipment unless authorized by Du Pont supervision.
- 11) All tools and equipment brought onto the site for use are subject to inspection and approval by the Du Pont representative.
- 12) Employers of noncompany employees providing services for Du Pont are responsible for complying with the Department of Energy Order 5480.1A.
- 13) Intoxicants and persons under the influence of intoxicants or narcotics are not permitted on the plantsite.
- 14) Firearms are prohibited unless authorized by the Security Department.
- 15) Materials and equipment that may emit hazardous or objectionable gases are not permitted in the vicinity of building air intake ducts.
- 16) Place or arrange equipment and materials properly in accordance with good housekeeping and safety practices.

D. RESPONSIBILITIES OF DU PONT REPRESENTATIVE

- 1) Thoroughly explain to the noncompany employee any chemical or other hazards associated with the work.
- 2) Ensure that equipment and material brought on the Plant by the noncompany employee does not present a hazard to Du Pont employees.
- 3) Point out posted safety rules, protective equipment, safety showers, and emergency equipment to the noncompany employee.
- 4) Direct the noncompany employee in the event of plant emergency alarms.
- 5) Do not use or permit other Du Pont personnel to use noncompany equipment or tools.
- 6) Coordinate locking, tagging, and trying of equipment before allowing the noncompany employee to begin work.
- 7) Should an injury occur, investigate the incident and write a factual report. Omit conclusions and recommendations. Forward the report to the Central Safety Office, 703-2A (refer to Safety Manual item 104, division E).
- 8) Maintain continuing liaison with personnel working on plant.
- 9) Report prime subcontractor and all subcontractors to the prime subcontractor work hours to the Central Safety office monthly.

E. HANDLING VISITOR AND VENDOR INJURIES

1. First Aid

Plant Medical will render first aid to the extent required by the circumstances.

2. Highway Accident (Serious)

- 1) Wackenhut investigates all highway accidents. *
- 2) Plant Medical renders first aid, contacts the vendor's company for the name of their company doctor, and proceeds as requested by the company's doctor.
- 3) Plant Medical records the incident and disposition.

3. Plant Accidents

3.1 Serious

- Same as Safety Manual item 104, steps E, 2, 2) and 3).
- Custodian of the building investigates and sends report to the Central Safety Office, Building 703-1A.

3.2 Minor Cases

Minor cases are given first aid at Plant Medical. Medical records the incident and disposition.

4. Personal Cases (Fainting, etc.)

Plant Medical handles these cases as circumstances dictate.

Appendix B
GROUNDWATER SAMPLING RESULTS

NOTES to APPENDIX B

1. Groundwater sampling results are summarized from the Health Protective Department, Environmental Monitoring, quarterly groundwater monitoring reports.
2. An asterisk indicates that data are reported for a sample and a duplicate. The higher of the two concentrations is presented in this appendix.
3. A blank space indicates that a concentration was not reported in the groundwater monitoring reports.

Well BRD-1

Parameters (conc in ppb)	1 0 84	2 0 84	3 0 84	4 0 84	1 0 85	2 0 85	3 0 85	4 0 85	1 0 86	2 0 86	3 0 86	4 0 86
METALS												
Ag		<1		<2	<0.5*	<0.45				<2		
Al												
As		<3		<2	<1*	<2						
Ba		560	24		27*	19						
Be		<10	<2									
Cd		12	<2		<2*	<2						
Cr		61	<4		<4*	<4						
Cu		32	10									
Fe		24400	55		31*	35			47			
Mg		<0.2	<0.2		<0.2	<0.2						
K												
Mn		850	97		98*	68			46		60	
Na		2600	2370		3130*	1660			2370			
Ni		31	<4									
Pb		309	47		46*	32			120		12	19
Se		<3	<1		<5*	<2						
Zn		156	45									
NONMETALS & INORGANIC COMPOUNDS												
Cl		4500	2100		3600	2180			2300			
CN		<5	<5									
F		<100	<100		<100	70						
Surfactants		<10	<10									
NO3		2200			1700	1750						
SO4		<5000	<10000		<5000	<5000			<5000			
Silica												
Total Phosphates												
RADIOISOTOPES (pCi/L)												
Gross Alpha		30	8		<2	<2			8			1.1
Gross Beta		16	5		<3	<3			<3			1.8
Radium Total		13	3		<1	<1			2			<1
Tritium												

Well BRD-1 (Continued)

Parameter: (conc in ppb)	1 0 84	2 0 84	3 0 84	4 0 84	1 0 85	2 0 85	3 0 85	4 0 85	1 0 86	2 0 86	3 0 86	4 0 86
ORGANICS												
DOC		<5000	<5000									
GC Scan		<40	<40									
Phenols		<2	<10									
TOC		8000	<5000									
TOM		17	10									
Endrin		<0.04										
Lindane		<1										
Methoxychlor		<20										
Toxaphene		<1										
24D		<20										
245TP (Silver)		<2										
Carbon Tetrachlor												
Chloroform												
Tetrachloroethylene												
Trichloroethylene												
1,1,1-Trichloro-ethane												
PHYSICAL PARAMETERS												
pH		4.2	5.1									
Conductivity(umho		52	41									
TDS		56000	40000									
Temperature (C)		20.6	18.4									
Turbidity		3.5	1									
Water Level (ft)		171.3	172.6	172.1								
					172.1	171.3	170.5	169.6	169.2	169.2	168.3	166.7

Well 880-1 (Continued)

Parameters (conc in ppb)	1 0 87	2 0 87	3 0 87	4 0 87	1 0 88	2 0 88	3 0 88	4 0 88
METALS								
Ag	<2							
Al								
As	<2							
Ba	17							
Be								
Ce	1010							
Cd	<2							
Cr	<4							
Cu								
Fe	29							
Hg	<0.2*							
K	712							
Mg	490							
Mn	39		41		358			
Na	2320	2610	3030	2330	2510			
Ni								
Pb	12	13	13	18	16			
Se	<2							
Zn								
NONMETALS & INORGANIC COMPOUNDS								
Cl	2880*							
CM								
F	<100							
Surfactants								
NO3	1760*	2050	2000	2040	1540		1500	
SO4	<3000							
Silica	5140							
Total Phosphates	<10*							
RADIOCLIDES (pCi/L)								
Gross Alpha	<3	<3	1.7	1.2	3		2.48	
Gross Beta	1.6	<2	1.9	<2	1.9		2.89	
Radium Total	1.1	1.3	1.4	1.5	1.2		0.58	
Tritium	2160							

Well BRD-1 (Continued)

Parameters (conc in ppb)	1 Q 87	2 Q 87	3 Q 87	4 Q 87	1 Q 88	2 Q 88	3 Q 88	4 Q 88
ORGANICS								
DOC								
GC Scan								
Phenols								
TOC	<2		<1000					
TOH	<5		<5					
Endrin								
Lindane								
Methoxychlor								
Toxaphene								
24D								
245TP (Silver)								
Carbon Tetrachlor	<1							
Chloroform	<1							
Tetrachloroethylene	<1							
Trichloroethylene	<1							
1,1,1-Trichloro-ethane	<1							
PHYSICAL PARAMETERS								
pH	5		5.5	5.8	5.1			
Conductivity(umho	31		33	33	28			
TDS	30000							
Temperature (C)	19.2		20.6	19.3	18.8			
Turbidity								
Water Level (ft)	166.1	168.2	168*	167.1	166.8	166.3	165.4	

Well 880-2

Parameters (conc in ppb)	1 0 84	2 0 84	3 0 84	4 0 84	1 0 85	2 0 85	3 0 85	4 0 85	1 0 86	2 0 86	3 0 86	4 0 86
METALS												
Ag				<2	<0.5					<2		
Al		<1	<2	<2								
As		<3	<2	<1	<1							
Ba		120	15	6	7							
Be		<10	<2	<2								
Ca			<2	<2	<2							
Cd		230	<2	<4	<4							
Cr		153	<4	<4								
Cu		28	<4	<4								
Fe		34200	272	17	11				26			
Hg		<0.2	<0.2	<0.2	<0.2							
K												
Mg		950	38	10	10				12		8	
Mn		1960	1770	1870	1960				1880			
Na		27	<4	<4								
Ni		99	4	<4	<4				<10		<6	114
Pb		<3	<1	<1	<5							
Se												
Zn		305	11	10								
NONMETALS & INORGANIC COMPOUNDS												
Cl		7000	4800	2200	2600				1700			
CN		<5	<5	<5								
F		<100	190	<100	<100							
Surfactants		<10	<10	<10								
NO3		1900	1000	1000	1150				<5000			
SO4		<5000	17000	<5000	<5000							
Silica												
Total Phosphates												
RADIOISOTOPES (pCi/L)												
Gross Alpha	137	5	3	3	<2				4			<3
Gross Beta	53	9	3	3	<3				<3			<2
Radium Total	52	4	<1	<1	<1				<1			<1
Tritium												

Well BRD-2 (Continued)

Parameters (conc in ppb)	1 Q 84	2 Q 84	3 Q 84	4 Q 84	1 Q 85	2 Q 85	3 Q 85	4 Q 85	1 Q 86	2 Q 86	3 Q 86	4 Q 86
ORGANICS												
DOC												
GC Scan												
Phenols												
TOC												
TOM												
Endrin												
Lindane												
Methoxychlor												
Toxaphene												
24D												
245TP (Silvex)												
Carbon Tetrachlor												
Chloroform												
Tetrachloroethylene												
Trichloroethylene												
1,1,1-Trichloro-ethane												
PHYSICAL PARAMETERS												
pH												
Conductivity(umho												
TDS												
Temperature (C)												
Turbidity												
Water Level (ft)												

Well BRD-2 (Continued)

Parameters (conc in ppb)	1 0 87	2 0 87	3 0 87	4 0 87	1 0 88	2 0 88	3 0 88	4 0 88
METALS								
Ag	<2							
Al								
As	<2							
Ba	6							
Be								
Ca	1660							
Cd	<2							
Cr	<4							
Cu								
Fe	10							
Mg	<0.2							
K	456							
Mg	342							
Mn	7		15*					
Na	1910	2260*	2100*	2110	2250	6		
Ni								
Pb	10	15*	61*	26	29			
Se	<2							
Zn								
NONMETALS & INORGANIC COMPOUNDS								
Cl	2670							
CN	<100							
F								
Surfactants								
NO3	1350	1100	1530*	1480	1380		1000	
SO4	<3000							
Silica	4520							
Total Phosphates	25							
RADIOISOTOPES (pCi/L)								
Gross Alpha	1.4	<3	1*	2	<3		0.9*	
Gross Beta	3.8	<2	3.2*	2.3	<2		1.58*	
Radium Total	0.8	0.8	0.9*	0.5	<1		<1*	
Tritium	1800							

B-8

Well BRD-2 (Continued)

Parameters (conc in ppb)	1 0 8 7	2 0 8 7	3 0 8 7	4 0 8 7	1 0 8 8	2 0 8 8	3 0 8 8	4 0 8 8
ORGANICS								
DOC								
GC Scan								
Phenols								
TOC	<2		<1000*					
TOM	<5		<5*					
Endrin								
Lindane								
Methoxychlor								
Toxaphene								
240								
245TP (Silvex)								
Carbon Tetrachlor	<1							
Chloroform	<1							
Tetrachloroethylene	<1							
Trichloroethylene	<1							
1,1,1-Trichloro-ethane	<1							
PHYSICAL PARAMETERS								
pH	5.3		6.2	5.7	5.7			
Conductivity(umho	28		31	30	26			
TDS	24000							
Temperature (C)	19.6		21.5	19.5	18.8			
Turbidity								
Water Level (ft)	167.8	167.9	168.8	167.7	169.3	168.8	170.2	

Well BAD-3

Parameters (conc in ppb)	1 0 84	2 0 84	3 0 84	4 0 84	1 0 85	2 0 85	3 0 85	4 0 85	1 0 86	2 0 86	3 0 86	4 0 86
METALS												
Ag												
Al												
As												
Ba												
Be												
Ce												
Cd												
Cr												
Cu												
Fe												
Hg												
K												
Mg												
Mn												
Na												
Ni												
Pb												
Se												
Zn												
NONMETALS & INORGANIC COMPOUNDS												
Cl												
CN												
F												
Surfactants												
NO3												
SO4												
Silica												
Total Phosphates												
RADIOISOTOPES (pCi/L)												
Gross Alpha												
Gross Beta												
Radium Total												
Tritium												

B-10

Well BRD-3 (Continued)

Parameters (conc in ppb)	1 0 84	2 0 84	3 0 84	4 0 84	1 0 85	2 0 85	3 0 85	4 0 85	1 0 86	2 0 86	3 0 86	4 0 86
ORGANICS												
DOC	<5000	<5000	<5000	<5000								
GC Scan	<40	<40	<40	<40								
Phenols	6	<10	<10	<2								
TOC	10000	<5000	<5000	<5000	1480	300	320	560	<2		1000	
TOM	13	9		<5	<5	<5	5	<5	<1000			
Endrin	<0.04			<0.04	<0.04				<5			
Lindane	<1			<1	<1							
Methoxychlor	<20			<20	<20							
Toxaphene	<1			<1	<1							
24D	<20			<20	<20							
245TP (Silvex)	<2			<2	<2							
Carbon Tetrachlor												
Chloroform												
Tetrachloroethylene												
Trichloroethylene												
1,1,1-Trichloro-ethane												
PHYSICAL PARAMETERS												
pH	4.9	5.5	4.8	4.8	5.1	5.1	4.4	4.6	5.6	5.1	5.2	
Conductivity(umho)	56	43	31	31	38	46	28	30	30.6	25	27.5	
TDS	52000	16000	38000	38000								
Temperature (C)	20.3	18.2	18.5	18.5	18.9	19.6	19.8	19		20.1		
turbidity	5.6	3	1.3	1.3	0							
Water Level (ft)	173.9	173.7	173.6	173.6	173.9	172.6	171.8	170.8	170	170.8	170.3	169

Well BRD-3 (Continued)

Parameters (conc in ppb)	1 0 87	2 0 87	3 0 87	4 0 87	1 0 88	2 0 88	3 0 88	4 0 88
METALS								
Ag	<2							
Al								
As	<2							
Ba	19							
Be								
Ca	2070							
Cd	<2							
Cr	<4							
Cu								
Fe	20							
Hg	<0.2							
K	820							
Mg	585							
Mn	26							
Na	1890	1600	19	1530	20			
Ni		2210			1910			
Pb	39	155	83	116				
Se	<2				135			
Zn								
NONMETALS & INORGANIC COMPOUNDS								
Cl	2060							
CH								
F	<100							
Surfactants								
HQS	1690	2150	2040	2140	1720		1450	
SO ₄	3000							
Silica	4110							
Total Phosphates	45							
RADIOCLIDES (pCi/L)								
Gross Alpha	3.7	2.7	2.7	1.8	6.3		2.26	
Gross Beta	5.2	<2	3.1	2	4.2		2.12	
Radium Total	5.9	0.8	1.2	0.7	<1		<1	
Tritium	4470							

B-12

Well BRD-3 (Continued)

Parameters (conc in ppb)	1 0 8 7	2 0 8 7	3 0 8 7	4 0 8 7	1 0 8 8	2 0 8 8	3 0 8 8	4 0 8 8
ORGANICS								
DOC								
GC scan								
Phenols								
TOC	<2		1200					
TOH	<5							
Endrin								
Lindane								
Methoxychlor								
Toxaphene								
240								
245TP (Silvex)								
Carbon Tetrachlor	<1							
Chloroform	<1							
Tetrachloroethylene	<1							
Trichloroethylene	<1							
1,1,1-Trichloro-ethane	<1							
PHYSICAL PARAMETERS								
pH	5.9		5.1*	6.3	6			
Conductivity(umho	34		29.3*	32	34			
TDS	40000							
Temperature (C)	20.6			19.9	16.5			
Turbidity								
Water Level (ft)								

Well BRD-4

Parameters (conc in ppm)	1 Q 85	2 Q 85	3 Q 85	4 Q 85	1 Q 86	2 Q 86	3 Q 86	4 Q 86	1 Q 87	2 Q 87	3 Q 87	4 Q 87	1 Q 88	2 Q 88	3 Q 88	4 Q 88
METALS																
Ag	<0.5	<0.45	<0.45	<2		<2			<2							
Al																
As	<1	<2*	<2	<2					<2							
Ba	5	4	5	6					5							
Be																
Ca	<2	<2	<2	<2					915							
Cd	<4	<4	<4	<4					<2							
Cr									<4							
Cu																
Fe	29	22	95	22	10				12							
Mg	<0.2	<0.2	<0.2	<0.2					<0.2							
K									420							
Mn	5	4	7	5	2				361							
Ni	1860	1350	1760	2040	1660				5							
Pb	18	12	<10	7	<10				1540	1970*	1930	2420	1930			
Se	<5	<2*	<2	<2					7	<3*	8	<6	<6			
Zn									<2							
NONMETALS & INORGANIC COMPOUNDS																
Cl	2000	2180	1900	2350	1700				2470							
CH																
F	<100*	70	<100	30					<100							
Surfactants																
NO3	1230	1320	1250	1260					1150*	1250	1460	1340	1310		1230	
SO4	<5000	<5000	<5000	<5000	<5000				8000							
Silica									4110							
Total Phosphates									14							
RADIOCLIDES (pCi/L)																
Gross Alpha	<2	<2	<2	<2	3			<3	<3*	<1*	1.2*	1.7	2.0*		0.58	
Gross Beta	<3	<3	4	<3	<3			1.3	2.4*	2.5*	<2*	1.7	<2*		0.98	
Radium Total	<1	<1	<1	<1	2			<1	<1*	0.7*	1.2*	<1	<1*		<1	
Tritium									2790*							

IN-14

Well BRD-4 (Continued)

Parameters (conc. in ppb)	1 0 85	2 0 85	3 0 85	4 0 85	1 0 86	2 0 86	3 0 86	4 0 86	1 0 87	2 0 87	3 0 87	4 0 87	1 0 88	2 0 88	3 0 88	4 0 88
ORGANICS																
DOC																
GC Scan																
Phenols																
TOC																
TCF																
Endrin																
Endone																
Methoxychlor																
Toxachene																
240																
245TP (Silvex)																
Carbon Tetrachlor																
Chloroform																
Tetrachloroethylene																
Trichloroethylene																
1,1,1-Trichloro-ethane																
PHYSICAL PARAMETERS																
pH																
Conductivity (umho)																
TDS																
Temperature (C)																
Turbidity																
Water Level (ft)																

B-15

END

**DATE
FILMED**

7 / 28 / 92