USGS-WSP--2194

DE84 900495

Methods for Collection and Analysis of Geopressured Geothermal and Oil Field Waters

By MICHAEL S. LICO, YOUSIF K. KHARAKA,
WILLIAM W. CAROTHERS, and VICTORIA A. WRIGHT

031-52627
12-22-83
RECEIVED

GEOLOGICAL SURVEY WATER-SUPPLY PAPER 2194

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

UNITED STATES DEPARTMENT OF THE INTERIOR

JAMES G. WATT, Secretary

GEOLOGICAL SURVEY

Dallas L. Peck, Director

UNITED STATES GOVERNMENT PRINTING OFFICE: 1982

For sale by the Superintendent of Documents
U.S. Government Printing Office
Washington, D.C. 20402

Library of Congress Cataloging in Publication Data

Methods for collection and analysis of geopressured
geothermal and oil field waters

(Geological Survey water-supply paper; 2194)

Bibliography: p. 20.

1. Geothermal engineering. 2. Water, Underground.

3. Oil field brines. 4. Water--Analysis.

I. Lico, Michael S. II. Series.

TJ280.7.M47

621.44

82-600061

AACR2

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency Thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

DISCLAIMER

Portions of this document may be illegible in electronic image products. Images are produced from the best available original document.

CONTENTS

Abstract	1
Introduction	1
Field procedures	1
Sampling at the wellhead	1
Sample filtration and preservation	2
Extraction of aluminum	3
Sample collection and preparation for stable carbon isotopes and total dissolved carbonate	4
Chemical analysis	4
Sulfide determination by iodometric method	5
Sulfide determination by specific-ion electrode method	6
Alkalinity	7
pH	7
Ammonia	8
Specific conductance	8
Laboratory procedures	8
Sodium	8
Potassium	9
Calcium	9
Magnesium	9
Strontium	10
Iron	10
Manganese	11
Zinc	11
Lead	11
Aluminum	11
Mercury	12
Lithium	12
Rubidium	13
Cesium	13
Barium	13
Chloride by titration with silver nitrate	14
Fluoride by ion-specific electrode	14
Bromide and iodide by hypochlorite oxidation method	15
Sulfate by thorin method with alumina pretreatment	17
Boron by carmine method	18
Silica by molybdate blue method	19
Aliphatic acid anions by gas chromatography	19
References	20

FIGURES

1. Diagram of gas collecting apparatus 5
2. Diagram of alumina column and associated apparatus 18

Methods for Collection and Analysis of Geopressured Geothermal and Oil Field Waters

By Michael S. Lico, Yousif K. Kharaka, William W. Carothers, and Victoria A. Wright

Abstract

Present methods are described for the collection, preservation, and chemical analysis of waters produced from geopressured geothermal and petroleum wells. Detailed procedures for collection include precautions and equipment necessary to ensure that the sample is representative of the water produced. Procedures for sample preservation include filtration, acidification, dilution for silica, methyl isobutyl ketone (MIBK) extraction of aluminum, addition of potassium permanganate to preserve mercury, and precipitation of carbonate species as strontium carbonate for stable carbon isotopes and total dissolved carbonate analysis. Characteristics determined at the well site are sulfide, pH, ammonia, and conductivity.

Laboratory procedures are given for the analysis of lithium,

sodium, potassium, rubidium, cesium, magnesium, calcium, strontium, barium, iron, manganese, zinc, lead, aluminum, and mercury by atomic absorption and flame emission spectroscopy. Chloride is determined by silver nitrate titration and fluoride by ion-specific electrode. Bromide and iodide concentrations are determined by the hypochlorite oxidation method. Sulfate is analyzed by titration using barium chloride with thorin indicator after pretreatment with alumina. Boron and silica are determined colorimetrically by the carmine and molybdate-blue methods, respectively. Aliphatic acid anions (C_2 through C_5) are determined by gas chromatography after separation and concentration in a chloroform-butanol mixture.

INTRODUCTION

An intensive research and development effort is presently underway by public agencies and private companies to determine the feasibility of using geopressured geothermal waters as a source of energy. Huge volumes of water are required for the extraction of heat, hydraulic energy, and dissolved gases from geopressured systems. For example, the volume of water produced from one geopressured geothermal well is expected to range from about 1,600 cubic meters, or 10,000 barrels, to more than 8,000 cubic meters, or 50,000 barrels, per day. Approximately 10 wells will be required to supply geothermal fluids at 150°C to each 25-megawatt powerplant (Underhill and others, 1976).

The amount of water produced with oil and gas also will continue to increase. This increase is the result of increasing total amounts of oil and gas being produced and, more importantly, petroleum wells that produce large volumes of water are now economical to keep in production. Proper management of these larger volumes of water will require more detailed and accurate data on the chemical composition of the water than the data routinely obtained by petroleum companies.

The authors have been collecting and analyzing geopressured geothermal and oil field waters for 10 years. This report summarizes their latest methods for the collection, preservation, and detailed analysis of these wa-

ters. These methods are, for the most part, based upon, but are significantly different from, those used for surface and shallow ground waters (Skougstad and others, 1979; American Public Health Association, 1971), or those now used for oil-field waters (American Petroleum Institute, 1968; Collins, 1975), or those used for geothermal waters (Presser and Barnes, 1974; Watson, 1978). For the methods of analysis of trace metals not reported here, see Skougstad and others (1979).

FIELD PROCEDURES

Sampling at the Wellhead

Collection of samples should include steps to prevent contamination and to preserve the samples for later analysis; therefore, it is essential to collect samples as near the wellhead as possible and to isolate them from the atmosphere. Most oil field and geopressured geothermal wells have, or can be fitted with, sampling valves at or close to the wellhead. If the sample must be taken from the separator, the separator should be emptied of contained fluids and solids before sampling. The separator is then flushed with new formation water prior to sampling. Samples for trace metals should not be taken at or downline from the separator because of the possibility of precipitation of heavy metal oxyhydroxides

and carbonates in the separator and the possible presence of corrosion products that could contaminate the sample. If corrosion inhibitors are being added to the well, it is necessary to stop adding them at least 1 hour prior to sampling the well.

Wells should be carefully selected to ensure that the samples obtained are representative of the waters present in the producing zone. The wells sampled should (1) be perforated over known intervals, (2) be producing from a single zone, (3) not be affected by water flooding, and (4) not contain water diluted by condensed water which is common in gas wells producing less than about 1 cubic meter of water per 30,000 cubic meters of gas, or 6 barrels per million cubic feet (Kharaka and others, 1977).

Application

All formation waters for collection and determination of cations, anions, alkalinity, stable isotopes, pH, and temperature.

Reagents

SAOB II solution (as described in the section on "Sulfide determination by specific-ion electrode method").

Apparatus

1. Carboy, 2- or 5-gallon, with bottom spigot.
2. Glass wool.
3. Bottles, flint-glass, 125-mL, with Poly-Seal¹ caps.
4. Thermometer.
5. Tubing, polyvinyl chloride, and fittings for well-head connections.
6. Flasks, volumetric, 100-mL.

Procedure

1. Attach tubing to the wellhead, open valve, and flush the lines.
2. Measure the temperature of water under flow.
3. Rinse all collection containers at least twice with sample water.
4. Fill the carboy with water. Minimize contact of the sample with air by inserting the tubing as far as possible into the carboy through a hole in the cap. Plug the hole in the cap with a rubber stopper after the carboy is filled.
5. Fill completely and tightly cap four separate flint-glass bottles by passing the water from the tubing through glass wool placed in a funnel to remove any solids and oil droplets. These bottles will be used for the hydrogen sulfide (iodometric), alkalinity, carbon isotopes, and pH determinations. Label these samples raw unacidified (RU).
6. Collect sample for specific-ion electrode determination of sulfide by filling a 100-mL volumetric

flask containing 50 mL of SAOB II solution (see section on "Sulfide determination method by specific-ion electrode") to the mark with sample.

7. Collection from oil and gas-condensate wells is somewhat different. Fluid is collected in a carboy and the two phases (oil and water) are allowed to separate. This takes from 5 minutes to several hours, depending on the temperature and the proportion of water produced. When separation occurs, proceed with steps 5 through 6 using water obtained through the spigot at the bottom of the carboy.

Sample Filtration and Preservation

Filtration and preservation of samples immediately after collection is important to prevent loss of constituents through precipitation and colloidalization. Cations such as manganese, calcium, iron, strontium, and barium can form oxyhydroxides and carbonates that may precipitate if the samples are not treated. Filtration through 0.1- μ m filters is required for trace-metal and mercury samples because colloidal metallic hydroxides and clay particles can pass through larger pore sizes (Kennedy and others, 1974). These particles would dissolve upon acidification, thus forming concentrations of trace metals not representative of the waters. Filtration through a 0.45- μ m filter is adequate for determination of anions and other cations.

Polyethylene bottles with airtight caps are used to store the filtered samples. The bottles must be prewashed with 10-percent nitric acid and rinsed with distilled-deionized water. Bottles for trace metals are prewashed with a 10-percent sulfuric-nitric acid mixture, rinsed with distilled-deionized water, and dried under positive-filtered air flow (J. W. Ball, oral commun., 1980). Bottles for mercury samples are cleaned by soaking in a chromic acid solution for 24 hours, followed by rinsing with distilled-deionized water, and then by heating in an oven at >200 °C for 24 hours (Ball and others, 1976).

A filtration unit described by Ball and others (1976) is used to filter the samples. This unit is constructed of two Geofilter plastic disks sealed with a rubber O-ring and supported by polyvinyl legs. All tubing used is Tygon plastic. A peristaltic pump provides pressure for filtration.

NOTE: All chemicals used in the following analyses are American Chemical Society certified reagent-grade chemicals unless otherwise stated.

Application

Formation waters relatively free of oils or suspended matter can be filtered rather easily.

Reagents

1. Hydrochloric acid, concentrated.

¹Any use of trade names is for descriptive purposes only and does not imply endorsement by the U.S. Geological Survey.

2. Nitric acid, doubly distilled (J. T. Baker's Ultrex HNO_3).
3. Potassium permanganate solution (KMnO_4), 5 percent. Dissolve 5 g of KMnO_4 in water, dilute to 100 mL.

Apparatus

1. Filtration pump (Cole Parmer-Masterflex).
2. Filtration assembly and holder for 142-mm disk filter membrane.
3. Filter membrane, 0.1- μm and 0.45- μm (142-mm diam).
4. Tubing, Tygon, for connecting pump and filter.
5. Bottles, polyethylene, with caps, 1-liter and 125-mL.
6. Bottles, flint-glass, with Poly-Seal caps, 125 mL.
7. Bottles, glass stoppered, 1-liter, for mercury samples.

Procedure

1. Attach Tygon tubing to the carboy, filtration pump, and filtration unit.
2. Rinse the filter (0.1- μm) by first passing through at least 1 liter of sample. Discard the first 250 mL of sample; use the remainder to rinse all bottles (rinse twice) prior to filling. Collect a 1-liter sample in a polyethylene bottle for trace-metal analyses.
3. Collect 1 liter of sample filtered through a 0.1- μm filter in a 1-liter glass-stoppered bottle for mercury analysis. Add potassium permanganate solution until sample remains purple. Record amount of solution added for later volume correction.
4. Collect 2 liters of water filtered through a 0.45- μm (or 0.1- μm) filter in polyethylene bottles for cation and anion analyses. Label one of these as filtered unacidified (FU). Acidify the other bottle with concentrated HCl to pH $\sim$ 1.5-2.0; label this sample filtered acidified (FA).
5. Collect sample for stable isotopes (H/D and $^{18}\text{O}/^{16}\text{O}$) in a 125-mL flint-glass bottle. Fill bottle completely with water.
6. Acidify the sample for trace metals with nitric acid to pH 1.5.
7. Make 1:4 and 1:1 dilutions on a filtered, unacidified sample for silica analysis in the laboratory. Store in 125-mL polyethylene bottles.

Extraction of Aluminum

Extraction of monomeric or reactive aluminum in solution must be done in the field if measured aluminum values are to be used in chemical models that study water-rock reactions (Kharaka and Barnes, 1973).

Aluminum is complexed with 8-hydroxyquinoline and extracted in methyl isobutyl ketone (MIBK) after the sample has been filtered through 0.1- μm filter paper (Barnes, 1975). Samples with concentrations of iron greater than about 0.4 mg/L require pretreatment; samples with concentrations of iron greater than 10 mg/L cannot be extracted by this method (Barnes, 1975).

Application

Formation waters with total aluminum concentrations greater than 3 $\mu\text{g/L}$.

Reagents

1. Hydrochloric acid, concentrated, metal free.
2. Ammonium hydroxide, concentrated, metal free.
3. Standards, Aluminum, 0, 12.5, 25, 50 $\mu\text{g/L Al}$.
Dissolve 0.500 g of Al wire in concentrated HCl, dilute to 500 mL with distilled-deionized water. Dilute this stock (1,000 mg/L Al) to appropriate concentrations for field standards.
4. Phenol red. Dissolve 0.1 g of phenol red in 28 mL of 0.01 N NaOH and dilute to 250 mL with aluminum-free water.
5. 8-hydroxyquinoline, 5 percent. Dissolve 5 g of 8-hydroxyquinoline in 10 mL of glacial acetic acid and dilute to 100 mL with aluminum-free water.
6. MIBK (methyl isobutyl ketone).
7. Hydroxylamine hydrochloride, 20 percent. Dissolve 20 g of hydroxylamine hydrochloride in water and dilute to 100 mL with aluminum-free water.
8. 1,10-phenanthroline, 1 percent. Dissolve 1 g of 1,10-phenanthroline in water to which a few drops of concentrated HCl have been added and dilute to 100 mL with aluminum-free water.
9. Buffer solution. Add 223 mL of 19 M NH_4OH (metal free) and 115 mL of glacial acetic acid to approximately 500 mL water. Adjust the pH to 8.3 with 10 M NH_4OH or glacial acetic acid. Dilute to 1,000 mL with aluminum-free water.

NOTE: These reagents should be kept refrigerated after preparation.

Apparatus

1. Separatory funnels, 500-mL.
2. Graduated cylinders, 500-mL.
3. Ring stand and holder for separatory funnels.
4. Vials, 15-mL, with Poly-Seal caps.

Procedures

1. Measure 400 mL of sample into the separatory funnel.
2. Add 10 to 15 drops of phenol-red solution and 2 mL of 5 percent 8-hydroxyquinoline and swirl.
3. Raise the pH by adding ammonium hydroxide until solution turns red (pH $\sim$ 8). If a greenish-black precipitate forms as the pH is

raised (step 3), discard the sample and pretreat a new aliquot of the sample as follows:

- a. Measure 400 ml of sample into separatory funnel.
- b. Add 5 mL of 20 percent hydroxylamine hydrochloride and 5 mL of 1 percent 1,10-phenanthroline.
- c. Adjust the pH to about 4 with hydrochloric acid, swirl, and allow to stand ~30 minutes to reduce iron.
- d. Continue with step 2 above.

NOTE: If red color of indicator is obscured as pH is raised in step 3, use a pH meter to monitor the pH.

4. Immediately add 5 mL of buffer solution and 15 mL of MIBK.
5. Shake vigorously 10 to 30 seconds (shaking time and intensity must be uniform for all standards and samples).
6. Allow the two phases to separate.
7. Discard the aqueous phase.
8. Collect the MIBK extract in vials which are then tightly sealed and refrigerated.
9. Standards as well as samples must be carried through steps 1 through 8 in the field.

Sample Collection and Preparation for Stable Carbon Isotopes and Total Dissolved Carbonate

Principle

Dissolved carbonate species are precipitated as strontium carbonate in evacuated glass cylinders containing a saturated solution of strontium chloride in ammonium hydroxide (ammoniacal strontium chloride) at the sampling site. The collection method prevents the sample from being exposed to atmospheric contamination. The precipitate is filtered, washed, dried, and weighed under laboratory conditions. A weighed portion of the sample is reacted with phosphoric acid and evolved carbon dioxide is measured for total dissolved carbonate. The $^{13}\text{C}/^{12}\text{C}$ ratio of the carbon dioxide is measured by mass spectrometer.

Application

$^{13}\text{C}/^{12}\text{C}$ ratios of total dissolved carbonate species in formation waters can be determined.

Reagents

1. Ammonium hydroxide, concentrated.
2. Strontium chloride, crystals.

Apparatus (fig. 1)

1. Cylinders, 125-mL glass gas-collecting, with stopcocks at both ends.
2. Filter membranes, 0.45- μm , (47 mm diam.).

3. Filter holder, 47 mm.
4. Syringes, 50-mL (two).
5. Tubing, Tygon.
6. Valves, plastic, three- and four-way (one each).
7. Connectors, tubing.

Procedures

1. Pre-field preparations. The following steps are to be done in a carbon dioxide-free environment, usually a glove box purged with an inert gas:
 - a. Prepare the ammoniacal strontium chloride by dissolving strontium chloride in concentrated ammonium hydroxide until supersaturated. Let stand 24 hours.
 - b. Filter the ammoniacal strontium chloride solution.
 - c. Place 15 mL of ammoniacal SrCl_2 in a 125-mL glass gas-sampling cylinder and evacuate the cylinder before closing it.
2. Sampling site:
 - a. Connect tubing, filter, syringes, and gas-collecting cylinder as shown in figure 1.
 - b. By use of four-way valve (A), flush sampling syringe with water from the wellhead.
 - c. Collect the water in the sample syringe and note the volume.
 - d. Close the feed line of the wellhead.
 - e. Evacuate the air in the line by use of syringe (B) and valve (C).
 - f. Open top stopcock on the collecting cylinder.
 - g. Open valve (A) of the sampling syringe and force the sample into the gas-collecting cylinder.
 - h. Close the top stopcock of the collecting cylinder.
 - i. Shake the collecting cylinder to ensure mixing.
 - j. Measure and note volume in the line between the sampling syringe and collecting cylinder.
3. Laboratory procedures
 - a. Filter and wash the precipitate through a 0.45- μm filter membrane in a carbon dioxide-free atmosphere.
 - b. Dry the precipitate in an oven.
 - c. Weigh the precipitate.
 - d. To determine the $^{13}\text{C}/^{12}\text{C}$ ratio of the precipitated strontium carbonate, react a portion of the sample as outlined by McCrea (1950).

Chemical Analysis

For accurate analysis, several parameters must be measured in the field shortly after the sample has been

collected because certain chemical species are unstable when the sample is brought to the surface and exposed to a different environment.

Included in this category are hydrogen sulfide, alkalinity, pH, specific conductance, and ammonia. Although ammonia preferably is measured in the field, it can be analyzed later in the laboratory by adding mercuric chloride (40 mg of Hg per liter of sample) to prevent the bacteria from multiplying; such a sample should be kept in the dark and refrigerated (Brown and others, 1970).

Our philosophy with regard to field analyses is to perform only those analyses in the field for which samples cannot be preserved for later laboratory analysis. Laboratory analysis is preferred because of stability of instruments, decreased risk of contamination, and operator comfort. For field analyses, some type of shelter is desirable. Laboratory trucks, trailers, or "dog houses" are sufficient for this purpose.

In the following descriptions, quantities of reagents are given to the degree of specificity required—some to one significant figure, some to more as needed.

Sulfide Determination by Iodometric Method

Principle

The iodometric method involves the reduction of a known amount of iodine by any dissolved oxidizable sulfur species in an acidified solution. The excess iodine is titrated with thiosulfate and, by difference, concentration of sulfide is determined. Interferences in this method are reducing substances (for example, heavy metals) and oxidizing agents that liberate iodine (for example, oxygen).

Application

The iodometric method is applicable to waters containing more than 0.5 mg/L sulfide.

Figure 1. Gas collecting apparatus.

Reagents

1. Hydrochloric acid, concentrated.
2. Iodine solution, 0.01 *N*. Dilute J. T. Baker Dilut-it to volume with distilled-deionized water.
3. Sodium thiosulfate solution, 0.10 *N*. Dissolve 25.0 g of $\text{Na}_2\text{S}_2\text{O}_3 \cdot 5\text{H}_2\text{O}$ in carbon dioxide-free water, add 1 g of Na_2CO_3 and dilute to 1,000 mL.
4. Sodium thiosulfate standard solution, 0.010 *N*. Dilute 100.0 mL of 0.10 *N* sodium thiosulfate solution to 1,000 mL with carbon dioxide-free water and standardize against potassium iodate as follows: dry approximately 0.5 g of KIO_3 for 2 hours at 180°C. Dissolve 0.3567 g in water and dilute to 1,000 mL. Pipet 25.00 mL of KIO_3 solution into a 250-mL iodine flask, then add successively 75-mL of water and 0.5 g of KI crystals. After solution is complete, add 10 mL of 3.6 *M* H_2SO_4 . Allow the stoppered flask to stand 5 minutes in the dark, then titrate with the 0.01 *N* $\text{Na}_2\text{S}_2\text{O}_3$ solution using 0.5 mL of starch indicator as the end point is approached (light straw color).
5. Potassium iodide, iodate free.
6. Starch indicator solution. Dissolve 1 to 2 g of soluble starch in 100 mL hot water. Add 1 g of boric acid as a preservative.
7. Potassium iodate.

Apparatus

1. Buret, 10-mL.
2. Buret holder.
3. Ring stand.
4. Magnetic stirrer.
5. Pipets, 100-mL, 10-mL, and 1-mL.
6. Flasks, iodine, 250-mL.

Procedure

1. Measure out 100 mL of sulfide-free deionized water for blank determination.
2. Add 10 mL of concentrated HCl.
3. Immediately add 10 mL of I_2 solution.
4. Titrate (moderate stirring) with 0.01 *N* $\text{Na}_2\text{S}_2\text{O}_3$ until a light straw color is reached.
5. Add 1 mL of starch indicator solution.
6. Continue titrating until the solution is clear. (The blue color will return if solution is allowed to stand.) Record the amount of titrant used.
7. Repeat steps 1 through 6 using the sample collected and sealed at the well site after it has cooled to near room temperature.
8. Calculate concentration of hydrogen sulfide, in milligrams per liter, as follows:

$$C_{\text{H}_2\text{S}} = \frac{1.000 \times 17.04}{V_s} \times N_t \times (V_{bt} - V_{st})$$

where:

$C_{\text{H}_2\text{S}}$ is concentration of H_2S in milligrams per liter,
 V_s is volume of sample in milliliters,
 N_t is normality of sodium thiosulfate titrant,
 V_{bt} is volume of titrant used for blank determination,
 V_{st} is volume of titrant used for sample determination.

NOTE:

1. Volumes of blank and sample must be the same; they may be more or less than 100 mL, depending on the concentration of hydrogen sulfide in the sample.
2. Analysis should be done with waters near 25°C.

Sulfide Determination by Specific-Ion Electrode Method

Principle

The sulfide specific-ion electrode method is used to determine sulfide ion under basic conditions. This method is more sensitive than the iodometric method and is less susceptible to interferences.

Application

The sulfide specific-ion method is applicable to waters containing more than 0.05 mg/L sulfide.

Reagents

1. Sodium sulfide stock solution. Dissolve approximately 100 g of $\text{Na}_2\text{S} \cdot 9\text{H}_2\text{O}$ in 100 mL of deaerated water. Shake well and allow to stand overnight. Store in a tightly stoppered glass bottle. This solution should remain stable for a month or more if kept refrigerated. Prepare a weekly standard by pipetting 10 mL of the stock solution into a 1-liter volumetric flask. Add 50 mL of SAOB II (Orion Research Inc., 1978) and dilute to the mark with deaerated water. Determine the exact concentration of this solution by titrating 10 mL of solution against 0.1 *M* lead perchlorate standard according to instructions given in electrode instruction manual. Prepare daily standards by serial dilution of the weekly standard. Mix equal portions of standard and SAOB II solution together.
2. SAOB II solution. Dissolve 80 g of NaOH, 35 g of ascorbic acid, and 67 g of disodium EDTA² in distilled water, dilute to 1 liter. Keep solution in dark and cool place.

Apparatus

1. Sulfide specific-ion electrode (Orion Model 94-16A).
2. Double-junction reference electrode (Orion Model 90-02-00).
3. Potentiometer.

²[Ethylenedinitrilo] tetra-acetic acid disodium salt.

4. Electrode holders.
5. Magnetic stirrer.

Procedure

1. Prepare sulfide standards from a previously standardized stock solution in the range desired (usually 0.05 to 5 mg/L sulfide). Dilute the standards 1:1 with SAOB II solution. Measure the mV potentials of the standards and construct a standard curve on semilogarithmic paper.
2. Measure the mV potential of the sample collected at the wellhead.
3. Determine the sulfide concentration of the sample by using the standard curve and report as milligrams per liter sulfide.

Alkalinity

Principle

Unfiltered unacidified sample is titrated with dilute sulfuric acid as described by Barnes (1964). The pH and volume of acid added are monitored during the titration which is continued to a pH of about 2.5, and a titration curve is constructed. The observed inflection point gives total titratable species (carbonate, bicarbonate, organic acid anions, borates, ammonium hydroxide, silicates, and other species). Carothers and Kharaka (1978) showed that titration to pH of about 2.5 is necessary to titrate all the organic acid anions.

Application

Formation waters containing any weakly ionized species that will become protonated upon addition of acid.

Apparatus

1. Buret, 25-mL.
2. pH meter and electrode.
3. Magnetic stirrer.
4. Pipets, 50-mL.

Reagents

1. pH buffers (pH 4 and 7).
2. Sulfuric acid standard solution, 0.05 N. Dilute J. T. Baker Dilut-it to 1,000 mL with distilled-deionized water. Standardize this with primary standard sodium carbonate.

Procedure

1. Calibrate pH meter with buffer solutions of pH 4 and 7.
2. Pipet 50 mL of raw unacidified sample (collected at the wellhead in a 125-mL flint-glass bottle) into a 100-mL beaker when it has cooled to near 25°C.
3. Start magnetic stirrer.
4. Immerse the electrode into solution and record the pH.

5. Add 1.0 mL aliquots of standard 0.05 N H₂SO₄, recording the stable pH after each addition. Use smaller aliquots of acid near the end point (~pH 4.5). Titrate to pH 2.5.
6. Plot acid volume against pH on rectangular graph paper and determine the amount of acid used to reach the inflection point.
7. Calculate alkalinity as bicarbonate in milligrams per liter, as follows:

$$C_{\text{HCO}_3^-} = \frac{N_t \times V_t}{V_s} \times 61,000$$

where:

N_t is the normality of H₂SO₄ titrant,

V_t is the volume in milliliters of H₂SO₄ used to reach the inflection point,

V_s is the volume in milliliters of sample used,

$C_{\text{HCO}_3^-}$ is the alkalinity of the sample expressed as mg/L HCO₃⁻.

pH

Principle

A combination electrode is used to measure the pH of samples collected at the wellhead in 125-mL flint-glass bottles fitted with Poly-Seal caps. The pH should be determined as soon as possible after collection to avoid loss of carbon dioxide and other gases from the water. Samples should be kept close to the wellhead temperature for measurement by using a constant-temperature water bath. To minimize error, the pH meter is calibrated with buffers at the same temperature as the sample.

Reagents

pH buffers (pH 4 and 7).

Apparatus

1. pH meter.
2. Combination pH electrode with rubber sleeve to fit mouth of 125-mL flint-glass bottles.
3. Constant-temperature water bath.

Procedure

1. Place buffers and sample in sealed 125-mL flint-glass bottles into the water bath and adjust to desired temperature. (This temperature should be as close to collection temperature as possible.)
2. When buffers have reached a constant temperature, calibrate pH meter.
3. Insert electrode into sample; make sure that a good seal is made with the bottle and the rubber sleeve.
4. Record the pH reading every 15 to 20 seconds

until the reading is constant. The constant pH is taken as the pH of the sample. In cases where carbon dioxide is lost from solution, pH will go through a minimum value with time; report minimum pH value.

Ammonia

Principle

Filtered unacidified samples are made basic by the addition of sodium hydroxide. The resulting dissolved ammonia is measured using an ammonia gas-sensing electrode.

Application

Ammonia can be measured in waters down to 1 mg/L.

Reagents

1. Ammonium chloride standard solution, 1,000 mg/L as N. (Orion Model 95-10-07).
2. Sodium hydroxide solution, 10 M. Dissolve 40 g of NaOH in distilled water, dilute to 100 mL.

Apparatus

1. Orion ammonia electrode (Model 95-10).
2. Millivolt meter, Orion Model 901 or equivalent.
3. Magnetic stirrer.
4. Ring stand.
5. Beakers, plastic, 30-mL.

Procedure

1. Make dilutions of standard solution to cover a range of 1 to 100 mg/L as N.
2. Place 10 mL of standard in beaker, place electrode into solution, begin stirring.
3. Add 2 drops of 10 M NaOH.
4. Record millivolt reading when stable.
5. Repeat for all standards.
6. Plot millivolt readings versus standard concentration on semilogarithmic paper.
7. Determine ammonia in filtered unacidified samples by using above procedure, recording millivolt reading, and finding concentration of ammonia from standard curve.

Interferences

Volatile amines interfere with electrode measurements. Temperature changes during measurements can cause electrode response to shift and change slope.

Specific Conductance

Principle

The specific conductance of an aqueous solution is the ability of that solution to carry an electric current and, in dilute solutions, yields an approximation of the solution's salinity (Rainwater and Thatcher, 1960).

The specific conductance is measured using a

specific conductance meter. The total dissolved solids (TDS) concentration of the sample is then calculated from this value.

Application

This method may be used to determine the specific conductance and the approximate TDS (salinity) of any water sample.

Reagents

1. Potassium chloride standard solution, 0.00702 N. Dissolve 0.5232 g of KCl, dried at 180°C for 1 hour, in distilled-deionized water and dilute to 1,000 mL. This solution will have a specific conductance of 1,000 μ S/cm at 25°C.

Apparatus

1. Meter, specific conductance, Lab-Line Lectro Mho-meter (Model MC-1, Mark IV) with temperature compensation.
2. Thermometer, graduated in 0.1°C.

Procedure

1. Calibrate meter by checking the specific conductance of the standard potassium chloride solution at exactly 25°C. The specific conductance should be 1,000 μ S/cm. If not, calibrate the meter according to the instruction manual.
2. Rinse the cell with filtered unacidified sample two or three times, then fill the cell.
3. Measure the specific conductance of the sample and record the temperature to the nearest 0.1°C at the time of measurement.
4. If the specific conductance of the sample is $>3 \times 10^3 \mu$ S/cm, also measure the specific conductance of a 1/100 dilution of the sample. Multiply the specific conductance by 0.65 ± 0.1 and the dilution factor. This number will approximate the TDS of the sample in milligrams per liter.

LABORATORY PROCEDURES

Analyses of cations are performed on filtered, acidified samples that are preserved at the well site. All cations are determined by atomic absorption or flame emission spectrophotometry. A Perkin-Elmer Model 603 was used under the conditions described in this section, most of which are referenced in Perkin-Elmer (1976a). Any atomic absorption spectrophotometer with similar capabilities can be used in its place with appropriate changes in the instrument operating conditions.

Sodium

Operating Parameters for PE 603

1. Wavelength: 295.3 nm visible.
2. Slit: 4.
3. Lamp: Sodium hollow cathode; current; 8 mA.

4. Gases: Air, 30 lb/in² (60 on flow meter); C₂H₂, 8 lb/in² (40 on flow meter).

5. Burner: Boling 4 inch, 3 slot at 90°.

Interferences

None reported. However, sodium ionizes easily in the air-acetylene flame. Potassium chloride is added to the samples and standards to bring concentrations to $\geq 1,000$ mg/L K which controls the ionization of sodium.

Stock Standard

Standard sodium solution, 1,000 mg/L Na. Dissolve 2.542 g of NaCl in distilled water, dilute to 1,000 mL.

Standard Dilutions

Samples and standards are typically diluted to the 10 to 100 mg/L sodium range.

Sample Preparation

Prepare appropriate dilutions of filtered-acidified (HCl) samples. Pipet 5 mL of each sample, standard and blank into a small plastic beaker. Add 50 μ L of 100,000 mg/L K to each. Mix and determine absorbance by AA using above conditions.

Comments

Samples with low sodium concentration may be run with lower standards and with the burner in the normal position.

Potassium

Operating Parameters for PE 603

1. Wavelength: 383.7 nm visible with red filter.
2. Slit: 4.
3. Lamp: Potassium hollow cathode; current: 12 mA.
4. Gases: Air, 30 lb/in² (60 on flow meter); C₂H₂, 8 lb/in² (40 on flow meter).
5. Burner: Boling 4 inch, 3 slot.

Interferences

Sodium interferes. This effect may be reduced by using a reducing flame and by positioning the burner approximately 0.05 cm below the optical path. Data indicate that interference effects may be virtually eliminated by keeping the concentration of sodium between 2,000 and 3,000 mg/L Na.

Stock Standard

Standard potassium solution, 100 mg/L K. Dissolve 0.1907 g of KCl (previously dried for one hour at 180°C) in distilled water. Dilute to 1,000 mL with distilled water.

Standard Dilutions

Samples and standards are typically diluted to the 1 to 10 mg/L potassium range.

Sample Preparation

Prepare appropriate dilution of filtered-acidified

(HCl) samples. Pipet 5 mL aliquots of each sample, standard, and blank into small plastic beakers. Add 100 μ L of 100,000 mg/L Na to each beaker. Mix and determine absorbance by using the above conditions.

Comments

Lower potassium values can be determined by using lower standards and expanding the output of the spectrophotometer.

Calcium

Operating Parameters for PE 603

1. Wavelength: 211.8 nm visible.
2. Slit: 4.
3. Lamp: Calcium hollow cathode; current: 15 mA.
4. Gases: Air, 30 lb/in² (60 on flow meter); C₂H₂, 8 lb/in² (40 on flow meter).
5. Burner: Boling 4 inch, 3 slot at 90°.

Interferences

Phosphate, sulfate, and aluminum interfere, but they are masked by the addition of lanthanum. As low calcium values result if the pH of the sample is above 7, standards are prepared in dilute hydrochloric acid solution. Samples are preserved in the field with hydrochloric acid. Concentrations of magnesium greater than 1,000 mg/L cause low calcium values. Concentrations of up to 500 mg/L each of sodium, potassium, and nitrate cause no interference.

Stock Standard

Standard calcium solution, 1,000 mg/L Ca. Dissolve 2.500 g of CaCO₃ (previously dried at 180°C) in dilute hydrochloric acid. Dilute to 1,000 mL with distilled water.

Standard Dilutions

Samples and standards are typically diluted to the 20 to 100 mg/L calcium range.

Sample Preparation

Prepare appropriate dilutions of filtered-acidified (HCl) samples. Pipet 5 mL aliquots of each sample, standard, and blank into small plastic beaker. Add 500 μ L of LaCl₃ solution (116 g of La₂O₃ dissolved in 1,000 mL of concentrated HCl and then dilute to 2,000 mL with water) to each beaker. Mix and determine absorbance by AA using the above conditions.

Comments

Samples with lower calcium concentrations may be analyzed using lower concentration standards and with the burner head in the normal position.

Magnesium

Operating Parameters for PE 603

1. Wavelength: 285.2 nm uv.
2. Slit: 4.
3. Lamp: Magnesium hollow cathode; current: 15 mA.
4. Gases: Air, 30 lb/in² (60 on flow meter); C₂H₂, 8 lb/in² (40 on flow meter).
5. Burner: Boling 4 inch, 3 slot.

Interference

1. The interference caused by aluminum at concentrations greater than 2,000 µg/L is masked by the addition of lanthanum. As low magnesium values result if the pH of the sample is above 7, standards are prepared in hydrochloric acid solution and samples are preserved in the field with hydrochloric acid.
2. Nitrate, sulfate, and silica interfere, but in the lanthanum chloride-hydrochloric acid solution at least 2,000 mg/L NO₃, 1,000 mg/L SO₄, and 200 mg/L SiO₂, can be tolerated. Sodium, potassium, and calcium cause no interference at concentrations less than 400 mg/L.

Stock Standard

Standard magnesium solution, 1,000 mg/L Mg. Dissolve 1.000 g of pure Mg metal in 6 N hydrochloric acid; dilute to 1,000 mL with distilled water.

Standard Dilutions

Samples are diluted so that the sodium, potassium, and calcium concentrations are all less than 400 mg/L. Standards are typically in the 0.2 to 2.0 mg/L magnesium range.

Sample Preparation

Prepare appropriate dilutions of filtered-acidified (HCl) samples. Pipet 5 mL aliquots of each sample, standard, and blank into small plastic beakers. Add 500 µL LaCl₃ solution (116 g of La₂O₃ dissolved in 1,000 mL concentrated HCl and then diluted to 2,000 mL with distilled water) to each beaker. Mix and determine absorbance by AA using the above conditions.

Strontium

Operating Parameters for PE 603

1. Wavelength: 230.7 nm visible.
2. Slit: 4.
3. Lamp: Strontium hollow cathode; current: 20 mA.
4. Gases: Air, 30 lb/in² (60 on flow meter); C₂H₂, 8 lb/in² (40 on flow meter).
5. Burner: Boling 4 inch, 3 slot.

Interferences

1. Strontium ionizes significantly in the air-acetylene flame causing suppression of the signal. Sodium and potassium decrease the ionization. To control the ionization, 1,000 mg/L of

potassium are added to both standards and samples.

2. Aluminum, phosphate, and silica interfere, but they are masked by the addition of lanthanum.
3. Nitrate interferes, but in the presence of lanthanum chloride-potassium chloride solution, at least 2,000 mg/L can be tolerated.
4. Low strontium values result even in the presence of potassium and lanthanum if the dissolved solids concentration exceeds 2,500 mg/L. For this reason, brines and highly mineralized waters must either be diluted or analyzed by the standard-addition method. When using the standard addition method, the dissolved solids concentration of the samples must be reduced to less than 20,000 mg/L.

Stock Standard

Standard strontium solution, 100 mg/L Sr. Dissolve 0.1684 g of SrCO₃ in a minimum amount of 3 N hydrochloric acid. Dilute to 1,000 mL with distilled water.

Standard Dilutions

Samples are diluted so that sodium + chloride is <2,500 mg/L. Samples are typically in the 1 to 10 mg/L strontium range.

Sample Preparation

Prepare appropriate dilutions of filtered-acidified (HCl) samples. Pipet 5 mL aliquots of each sample, standard, and blank into small plastic beaker. Add 500 µL of La₂O₃-KCl solution (dissolve 117.3 g of La₂O₃, 19.1 g of KCl and dilute to 1,000 mL with distilled water) to each beaker. Mix and determine absorbance by AA using the above conditions.

Comments

Lower standard concentrations may be prepared for waters containing lower strontium concentrations with appropriate changes in instrumental operating conditions.

Iron

Operating Parameters for PE 603

1. Wavelength: 248.3 nm uv.
2. Slit: 3.
3. Lamp: Iron hollow cathode; current: 30 mA.
4. Gases: Air, 30 lb/in² (60 on flow meter); C₂H₂, 8 lb/in² (40 on flow meter).
5. Burner: Boling 4 inch, 3 slot.

Interferences

Sodium and potassium concentrations affect the level of iron observed in the air-acetylene flame. Consequently, sodium and potassium concentrations are adjusted to 1,000 mg/L each in samples and standards.

Stock Standard

Standard iron solution, 100 mg/L Fe. Dissolve 0.1000 g of reagent grade iron wire (previously cleaned in dilute hydrochloric acid, rinsed, and dried) in a minimum amount of 3 N hydrochloric acid. Dilute to 1,000 mL with distilled water.

Standard Dilutions

Samples generally are run between 0.5 and 4.0 mg/L iron.

Sample Preparation

Prepare appropriate dilutions of filtered-acidified (HCl) samples. Pipet 5 mL of each sample, standard, and blank into small plastic beakers. Add the volume of 100.000 mg/L Na (127 g of NaCl dissolved in 500 mL of water) needed to bring each up to 1,000 mg/L sodium. Add enough water to make all of the volume adjustments the same. Repeat the above for potassium. Mix and run according to AA conditions stated above.

Manganese

Operating Parameters for PE 603

1. Wavelength: 279.8 nm uv.
2. Slit: 3.
3. Lamp: Manganese hollow cathode; current: 20 mA.
4. Gases: Air, 30 lb/in² (60 on flow meter); C₂H₂, 8 lb/in² (40 on flow meter).
5. Burner: Bolding 4 inch, 3 slot.

Interferences

Iron in excess of 25 mg/L or magnesium in excess of 100 mg/L interfere. Other cations and anions found in water do not interfere.

Stock Standard

Standard manganese solution, 1,000 mg/L Mn. Dissolve 1.000 g of Mn metal in a minimum volume of 6 N nitric acid; dilute to 1,000 mL with 1 percent hydrochloric acid.

Standard Dilution

Standards are typically run between 0.05 and 10.0 mg/L manganese.

Sample Preparation

Prepare appropriate dilutions of filtered-acidified (HCl) samples. Pipet 5 mL aliquots of each sample so that the manganese and iron concentrations are less than 100 and 25 mg/L, respectively.

Zinc

Operating Parameters for PE 603

1. Wavelength: 214 nm uv.
2. Slit: 4.
3. Lamp: Zinc hollow cathode; current: 10 mA.
4. Gases: Air, 30 lb/in² (55 on flow meter); C₂H₂, 8 lb/in² (35 on flow meter).
5. Burner: Bolding 4 inch, 3 slot at 90°.

Interferences

Sodium, potassium, sulfate, and chloride do not interfere up to 9,000 mg/L; at greater concentrations, their effect is unknown. It is suggested that at concentrations of chloride greater than 9,000 mg/L, the concentration of chloride should be nearly equal in the samples and standards.

Stock Standard

Standard zinc solution, 1,000 mg/L Zn. Dissolve 1.000 g of reagent grade Zn metal in slight excess of hydrochloric acid; dilute to 1,000 mL with distilled-deionized water.

Standard Dilutions

At the above operating parameters, standards are run in the 5 to 30 mg/L zinc range; the range can be varied by changing the instrument settings.

Sample Preparation

Use filtered-acidified (HNO₃) samples. Dilute, if necessary, to proper chloride level.

Lead

Operating Parameters for PE 603

1. Wavelength: 283 nm uv.
2. Slit: 4.
3. Lamp: Lead hollow cathode; current: 10 mA.
4. Gases: Air, 30 lb/in² (60 on flow meter); C₂H₂, 8 lb/in² (40 on flow meter).
5. Burner: Bolding 4 inch, 3 slot.

Interferences

If chloride concentration of sample exceeds 9,000 mg/L, samples and standards should be made to contain the same concentration of chloride.

Stock Standard

Standard lead solution, 1,000 mg/L Pb. Dissolve 1.598 g of Pb(NO₃)₂ in 1 percent (v/v) nitric acid and dilute to 1,000 mL with 1 percent (v/v) nitric acid.

Standard Dilutions

Standards are generally run in the 0.5 to 2.0 mg/L lead range.

Sample Preparation

Use filtered-acidified (HNO₃) samples; dilute, if necessary, to proper chloride concentration.

Aluminum

Operating Parameters for PE 603

1. Wavelength: 309 nm uv.
2. Slit: 4.
3. Lamp: Aluminum hollow cathode; current: 25 mA.
4. Gases: N₂O, 30 lb/in² (33 on flow meter); C₂H₂, 8 lb/in² (55 on flow meter).
5. Burner: Nitrous oxide head.

Interferences

Iron interferes in the extraction procedure (see section on "Extraction of aluminum,"), but it is reduced by the addition of hydroxylamine hydrochloride (Barnes, 1975). No other interferences are presently known.

Stock Standard

Standard aluminum solution, 1,000 mg/L Al. Dissolve 1.000 g of high-purity Al metal in 50 mL of 6 M HCl; dilute to 1,000 mL with water.

Standard Dilutions

Typically standards of 0, 12.5, 25, and 50 $\mu\text{g/L}$ aluminum, extracted in the field, are used to construct a standard curve. Samples usually do not need dilution.

Sample Preparation

Samples are prepared according to directions given in section on the "Extraction of aluminum." No further treatment is necessary.

Mercury

Principle

An aliquot of sample is treated in the field with potassium permanganate to oxidize all mercury. In the laboratory, the sample is acidified. Excess permanganate is then reduced with hydroxylamine hydrochloride, and the mercury is reduced to metallic mercury with stannous chloride. An aerator is used to sweep the mercury through an absorption cell placed in the light path of an atomic absorption spectrophotometer (Perkin-Elmer, 1976b). Mercury concentration is proportional to absorbance.

Application

Small concentrations of mercury ($>0.01 \mu\text{g/L}$ Hg) can be determined in geopressured geothermal and oil field waters.

Reagents

NOTE: All reagents and distilled water must be mercury-free.

1. Potassium permanganate solution, 5 percent. Dissolve 25 g of KMnO_4 in distilled water. Dilute to 500 mL.
2. Nitric acid, 5.6 N. Add 175 mL concentrated HNO_3 to 300 mL of distilled water; dilute to 500 mL.
3. Sulfuric acid, 18 N. Carefully add 250 mL of concentrated H_2SO_4 to about 200 mL of distilled water; dilute to 500 mL.
4. Hydroxylamine hydrochloride solution, 1.5 percent. Dissolve 7.5 g of hydroxylamine hydrochloride in distilled water; dilute to 500 mL.
5. Stannous chloride solution, 10 percent. Dissolve

50 g of $\text{SnCl}_2 \cdot 2\text{H}_2\text{O}$ in distilled water; dilute to 500 mL.

6. Mercury stock standard, 1,000 mg/L Hg. Dissolve 1.080 g of HgO in a minimum volume of 6 N hydrochloric acid. Dilute to 1,000 mL with distilled water.

Apparatus

1. Atomic absorption spectrophotometer, Perkin-Elmer Model 603 with recorder.
2. Mercury hollow cathode lamp.
3. Mercury analysis system, Perkin-Elmer Model 303-0832.

Procedure

1. Prepare standards down to $0.01 \mu\text{g/L}$ mercury and a blank.
2. Place 100 mL of standard into aspirator bottle and add 2 drops of 5 percent KMnO_4 .
3. Add 5.0 mL of 5.6 N HNO_3 and swirl, wait 15 seconds.
4. Add 5.0 mL of 18 N H_2SO_4 and swirl, wait 5 seconds.
5. Add 5.0 mL of 1.5 percent hydroxylamine hydrochloride solution and swirl. The solution should become clear after this addition. If not, add hydroxylamine hydrochloride crystals until solution becomes clear.
6. Add 5.0 mL of 10 percent SnCl_2 solution and immediately insert the aerator into the bottle.
7. Record the peak height. Repeat procedure with other standards generating a standard curve. Run samples using the above procedure. Read sample concentrations directly from the standard curve.

Lithium

Operating Parameters for PE 603

1. Wavelength: 336.0 nm visible with red filter.
2. Slit: 4.
3. Gases: Air, 30 lb/in² (60 on flow meter); C_2H_2 , 8 lb/in² (40 on flow meter).
4. Burner: Belling 4 inch, 3 slot.
5. Mode: Emission.

Interferences

The following elements interfere when the indicated concentrations are exceeded: sodium, 1,000 mg/L; potassium, 100 mg/L; magnesium, 200 mg/L; chloride, 1,000 mg/L; sulfate, 2,000 mg/L; nitrate, 100 mg/L; and strontium, 5 mg/L.

Stock Standard

Standard lithium solution, 1,000 mg/L Li. Dissolve 5.324 g of Li_2CO_3 in a minimum volume of 6 N hydrochloric acid. Dilute to 1,000 mL with distilled water.

Standard Dilutions

Samples are diluted so that the sodium is between

200 and 1,000 mg/L.

Sample Preparation

Prepare appropriate dilutions of filtered-acidified (HCl) samples. Pipet 5 mL aliquots of each sample, standard, and blank into small plastic beakers. Add 10 μ L of 100,000 mg/L Na (127 g of NaCl dissolved in 500 mL of water) to the standards and samples with < 200 mg/L sodium. Add 10 μ L of water to the rest of the samples. Mix and determine the emission of samples and standards by flame emission.

Rubidium

Operating Parameters for PE 603

1. Wavelength: 390.3 nm visible with red filter.
2. Slit: 5.
3. Gases: Air, 30 lb/in² (60 on flow meter); C₂H₂, 8 lb/in² (40 on flow meter).
4. Burner: Belling 4 inch, 3 slot.
5. Mode: Emission.

Interferences

A large fraction of rubidium atoms is ionized in an air-acetylene flame. The ionization can be stopped by adding a large quantity of another alkali salt to both standards and samples.

Stock Standard

Standard rubidium solution, 1,000 mg/L Rb. Dissolve 1.415 g of RbCl in distilled water and dilute to 1,000 mL.

Standard Dilutions

Standards are diluted so that the sodium concentration is <10,000 mg/L. The sodium concentration will later be brought to a given level between 4,000 and 10,000 mg/L, as described below. Standards are typically run in the 0.1 to 1.0 mg/L rubidium range.

Sample Preparation

Prepare appropriate dilutions of filtered-acidified (HCl) samples. Pipet 5 mL aliquots of each sample, standard, and blank into small plastic beakers. Calculate the mg/L sodium in each of these aliquots. Determine a convenient concentration of sodium between 4,000-10,000 mg/L to adjust the aliquots. Add an aliquot of 100,000 mg/L Na (127 g of NaCl dissolved in 500 mL of water) to each beaker as necessary to make the adjustment to the chosen concentration $\pm$ 500 mg/L sodium. Add water to each beaker, as necessary, so that the total volume of water and sodium solution is identical for each sample, standard, and blank. Mix and run by flame emission using above conditions.

Cesium

Operating Parameters for PE 603

1. Wavelength: 428.8 nm visible with red filter.
2. Slit: 5.
3. Gases: Air, 30 lb/in² (60 on flow meter); C₂H₂, 8 lb/in² (40 on flow meter).
4. Burner: Belling 4 inch, 3 slot.
5. Mode: Emission.

Interference

Cesium has a lower ionization potential than any other metal; thus, a significant portion of the cesium atoms will be ionized in the air-acetylene flame. Another alkali metal salt is added to both standards and samples to stop the ionization.

Stock Standard

Standard cesium solution, 1,000 mg/L Cs. Dissolve 1.267 g of CsCl in distilled water and dilute to 1,000 mL.

Standard Dilutions

Samples are diluted so that the sodium concentration is <10,000 mg/L. The sodium concentration will later be brought to a given level between 4,000 and 10,000 mg/L, as described below. Standards are typically run in the 0.1 to 1.0 mg/L cesium range.

Sample Preparation

Prepare appropriate dilutions of filtered-acidified (HCl) samples. Pipet 5 mL aliquots of each sample, standard, and blank into small plastic beakers. Calculate the mg/L sodium in each of these aliquots. Determine a convenient concentration of sodium to which to adjust all the aliquots so that they will all be between 4,000 and 10,000 mg/L sodium and $\pm$ 500 mg/L sodium of the chosen value. Add an aliquot of 100,000 mg/L Na (127 g of NaCl dissolved in 500 mL of water) to each beaker, as necessary, to make the adjustment. Add water to each beaker, as necessary, so that the total volume of water and sodium solution is identical for each sample, standard, or blank. Stir and run by flame emission as above.

Barium

Operating Parameters for PE 603

1. Wavelength: 277.4 visible.
2. Slit: 2.
3. Gases: N₂O, 30 lb/in² (33 on flow meter); C₂H₂, 8 lb/in² (55 on flow meter).
4. Burner: Nitrous oxide head.
5. Mode: Emission.

Interferences

Sodium has been found to control ionization of barium in the flame. No effect is seen if sodium concentrations are kept between 8,000 and 14,000 mg/L sodium. No other dissolved species are known to interfere with the flame emission determination of barium.

Stock Standard

Standard barium solution, 100 mg/L Ba. Dissolve 0.178 g of $\text{BaCl}_2 \cdot 2\text{H}_2\text{O}$ in distilled water; dilute to 1,000 mL.

Standard Dilutions

Standards are generally run between 0.25 to 1.5 mg/L barium.

Sample Preparation

Use filtered acidified (HCl) samples; dilute samples so that sodium concentrations are between 8,000 and 14,000 mg/L. Add 8,000 mg/L sodium to standards and blank.

Chloride by Titration with Silver Nitrate

Principle

Filtered unacidified sample is titrated with silver nitrate using a metallic silver indicator electrode.

Application

Concentrations of chloride can be measured in formation waters down to about 1.0 mg/L.

Reagents

1. Chloride standard solution 1,000 mg/L Cl. Dissolve 1.648 g of primary standard grade NaCl in distilled water and dilute to 1,000 mL.
2. Silver nitrate titrant, 0.1 N or 0.01 N prepared from J. T. Baker Dilut-it or reagent-grade silver nitrate crystals.

Apparatus

1. Metrohm EA 536 titrator.
2. Metrohm EA 246 combination electrode (Ag metal and AgCl-KNO_3 saturated reference).

Procedure

1. Set up instrument as follows:
 - a. mV range: 500 mV.
 - b. Compensating potential: +600 mV.
 - c. Titrating speed: 5 min/100 percent volume.
 - d. Buret: 10 or 20 mL.
 - e. Chart: 400 mm/100 percent volume.
 - f. Percent U: Off.
 - g. $\text{U} \rightarrow \text{O}$.
2. Standardize the silver nitrate titrant with standard chloride solution.
3. Prepare appropriate dilutions of samples, and titrate an aliquot with standard silver nitrate solution.
4. Calculate chloride concentration using the following equations:
 - a. Standardization of titer:

$$C_t = \frac{V_{st} \times C_{st}}{V_t}$$

b. Samples:

$$C_s = 1,000 \times \frac{V_t \times C_t}{V_s}$$

where:

C_t is concentration of titrant in milligrams of chloride per milliliter of silver nitrate.

V_{st} is volume in milliliters of chloride standard solution.

C_{st} is the concentration of chloride standard solution, in milligrams per milliliter.

V_t is the volume of silver nitrate titrant in milliliters.

V_s is the volume of sample used in milliliters.

C_s is the concentration of chloride in sample in milligrams per liter.

Interferences

Fluoride, bromide, iodide, phosphate, and sulfide interfere. However, in typical geothermal waters, the chloride level is several orders of magnitude higher than these other anions; consequently, these interferences are not usually significant.

Fluoride by Ion-Specific Electrode

Principle

Filtered unacidified sample is placed in a constant ionic-strength buffer, and the potential of the solution is measured with a fluoride ion-specific electrode.

Application

Concentrations of fluoride in waters can be measured down to 0.1 mg/L.

Reagents

1. Fluoride standard solution, 1,000 mg/L F. Dissolve 2.210 g of NaF in distilled water and dilute to 1,000 mL.
2. TISAB IV ionic strength adjustor (Orion Research Inc., 1976). Add 84 mL of concentrated HCl (36-38 percent), 242 g of TRIS (hydroxymethyl amino methane), and 230 g of sodium tartrate ($\text{Na}_2\text{C}_4\text{H}_4\text{O}_6 \cdot 2\text{H}_2\text{O}$) to approximately 500 mL of distilled water. Stir to dissolve, cool to room temperature, then dilute to 1,000 mL with distilled water.

Apparatus

1. Fluoride specific-ion electrode, Orion Model 94-09.
2. Single-junction reference electrode, Orion Model 90-01-00.
3. Millivolt meter, Orion Model 901 or equivalent.
4. Magnetic stirrer.
5. Beakers, plastic, 100-mL.

Procedure

1. Prepare standards in the range of 0.1 to 2.0 mg/L fluoride. Add sodium chloride to standards so

- that the chloride concentration approximates that of samples. Transfer all solutions to plastic bottles as soon as possible.
2. Add equal volumes of standard and TISAB IV to 100 mL beakers.
 3. Place electrodes in the 2.0 mg/L fluoride standard, begin stirring, record millivolts when a constant potential reading is observed.
 4. Rinse electrodes, blot dry, and place into next lowest standard, record stable reading.
 5. Repeat step 4 until all standards have been read.
 6. Plot the millivolt readings (linear axis) against concentration (log axis) on semilogarithmic paper. Curve should be linear down to about 0.4 mg/L fluoride.
 7. Pipet equal volumes of sample and TISAB IV into a plastic beaker. Place electrodes in solution, record millivolt reading when stable; repeat for all samples.
 8. Read sample concentration directly from the standard curve.
 9. Check standard curve for drift after one to two hours. This is especially important if ambient temperature has changed during the analysis.

Bromide and Iodide by Hypochlorite Oxidation Method

Principle

The hypochlorite oxidation method (Brown and others, 1970) is used to determine combined bromide and iodide. Iodide is then determined by the bromine oxidation method. The difference of these two methods gives the bromide concentration. In principle, bromide and iodide are oxidized to bromate and iodate by the addition of hypochlorite. Upon addition of potassium iodide to the acidified solution, free iodine is liberated equivalent to the amount of iodate and bromate present. The liberated iodine is titrated with standard thiosulfate using starch as the indicator. Iodide is then determined, on a separate aliquot, by oxidation to iodate with bromine in a buffered solution. Iodine equivalent to the iodate is then liberated from added potassium iodide and titrated with thiosulfate as in the combined determination. Analysis is performed on filtered unacidified sample.

Application

Concentrations of bromide and iodide can be determined in geopressed geothermal and oil-field waters down to 1.0 mg/L.

Reagents

1. Acetic acid, 2.2 M. Mix 125 mL of glacial

$\text{HC}_2\text{H}_3\text{O}_2$ (sp. gr. 1.049) with water and dilute to 1,000 mL.

2. Bromine water, saturated. Add to approximately 250 mL of water slightly more liquid bromine than will dissolve when shaken. Store in a glass-stoppered actinic glass bottle.
3. Calcium carbonate (CaCO_3), powder.
4. Calcium oxide (CaO), anhydrous powder.
5. Hydrochloric acid, 6 M. Mix 50 mL of concentrated HCl (sp. gr. 1.19) with distilled water and dilute to 100 mL.
6. Methyl red indicator solution. Dissolve 0.01 g of water-soluble methyl red in 100 mL of distilled water.
7. Potassium fluoride ($\text{KF} \cdot 2\text{H}_2\text{O}$), crystals.
8. Potassium hypochlorite solution. Dissolve 6.2 g of KOH in 100 mL of distilled water. Saturate the solution with bromine-free chlorine while continually cooling and stirring. Store in glass-stoppered actinic-glass bottle. Prepare fresh daily. Alternatively, commercial "Chlorox" bleach can be used for this reagent.
9. Potassium iodate (KIO_3), crystals.
10. Potassium iodide (KI), crystals, free from iodate. The potassium iodide can be tested for iodate by dissolving about 0.1 g in 5 mL of water, acidifying with 1 or 2 drops of concentrated H_2SO_4 , and adding 2 mL of starch indicator. Immediate appearance of a blue color indicates the presence of iodate; slow color formation is due to atmospheric oxidation.
11. Sodium acetate solution. Dissolve 273 g of $\text{NaC}_2\text{H}_3\text{O}_2 \cdot 3\text{H}_2\text{O}$ in distilled water and dilute to 1,000 mL.
12. Sodium chloride (NaCl), crystals. In addition to conforming to American Chemical Society specifications, these shall also be free from iodide, iodate, bromide, and bromate. The sodium chloride can be tested for iodate and bromate by dissolving about 0.1 g in 5 mL of water, acidifying with 1 or 2 drops of concentrated H_2SO_4 (sp. gr. 1.84), and adding 2 mL of starch solution. Immediate appearance of blue color indicates presence of iodate or bromate; slow color formation is caused by atmospheric oxidation.
13. Sodium formate solution. Dissolve 50 g of NaCHO_2 in hot distilled water and dilute to 100 mL. Prepare fresh daily.
14. Sodium molybdate solution. Dissolve 1.0 g of $\text{Na}_2\text{MoO}_4 \cdot 2\text{H}_2\text{O}$ in distilled water and dilute to 100 mL.
15. Sodium thiosulfate solution, 0.10 N. Dissolve 25.0 g of $\text{Na}_2\text{S}_2\text{O}_3 \cdot 5\text{H}_2\text{O}$ in carbon dioxide-free water, add 1 g of Na_2CO_3 , and dilute to 1,000

mL. Or, alternatively, prepare from $\text{Na}_2\text{S}_2\text{O}_3$ J. T. Baker Dilut-it.

16. Sodium thiosulfate standard solution, 0.010 *N*. Dilute 100.0 mL of 0.10 *N* $\text{Na}_2\text{S}_2\text{O}_3$ solution to 1,000 mL with carbon dioxide-free water and standardize against potassium iodate as follows: Dry approximately 0.5 g of KIO_3 for 2 hours at 180°C. Dissolve 0.3567 g in water and dilute to 1,000 mL. Pipet 25.00 mL of the KIO_3 solution into a 250-mL iodine flask, then add successively 75 mL of water and 0.5 g of KI crystals. After solution is complete, add 10 mL of 3.6 *M* H_2SO_4 . Allow the stoppered flask to stand 5 minutes in the dark, then titrate with sodium thiosulfate solution adding 0.5 mL of starch indicator as the end point is approached (light straw color).
17. Starch indicator solution. Dissolve 1 to 2 g of soluble starch in hot distilled water. Dilute to 100 mL with distilled water.
18. Sulfuric acid, 3.6 *M*. Carefully mix 200 mL of concentrated H_2SO_4 (sp. gr. 1.84) with water and dilute to 1,000 mL.

Apparatus

1. Buret, 10-mL or 25-mL.
2. Flask, iodine, 250-mL.
3. Magnetic stirrer.

Procedure

1. Remove soluble iron, manganese, and organic matter by adding a slight excess of calcium oxide to approximately 400 mL of filtered unacidified sample, shake, let stand about 1 hour, and then filter through dry paper. Discard the first 75 mL of filtrate.
2. For the combined bromide and iodide determination, pipet a volume of the filtrate containing less than 5.0 mg bromide + iodide (100.0 mL maximum) into a 250-mL iodine flask, and adjust the volume to approximately 100 mL.
3. Prepare a blank of 100 mL demineralized water and carry it through the procedure along with the sample.
4. Add sufficient sodium chloride crystals to produce a 3.0 g chloride content.
5. Add a drop of methyl red indicator solution and neutralize the solution with 6 *M* HCl.
6. Add 10 mL of KClO solution (or 8 mL commercial bleach), 0.5 mL of 6 *M* HCl, and sufficient CaCO_3 to produce an excess of approximately 0.1 g after it has consumed any excess acid.
7. Heat the solution to boiling and maintain this temperature for about 8 minutes.
8. Reduce the excess hypochlorite by adding 2 mL of NaCHO_2 solution, taking precautions to wash down the sides of the flask with a small

amount of hot water. Keep the solution hot for an additional 8 minutes.

9. Cool and add several drops of Na_2MoO_4 solution. If any iron precipitates at this point, add 0.5 g of $\text{KF} \cdot 2\text{H}_2\text{O}$.
10. Add approximately 1 g of KI and 10 mL of 3.6 *M* H_2SO_4 ; let stand 5 minutes in the dark; make sure that the flask is tightly stoppered.
11. Titrate the liberated iodine with 0.01 *N* thiosulfate solution, adding 0.5 mL of starch indicator as the end point is approached. Record the volume of titrant used. Disregard the return of the blue color after the end point has been reached.
12. For the iodide determination, pipet a volume of filtrate (step 1) containing less than 5.0 mg of iodide (100.0 mL maximum) into a 250-mL iodine flask, and adjust the volume to approximately 100 mL.
13. Prepare a blank of 100 mL demineralized water and carry it through the procedure along with the sample.
14. Add a drop of methyl red indicator solution, and add 3.6 *M* H_2SO_4 until the solution just becomes acid.
15. Add 15.0 mL of $\text{NaC}_2\text{H}_3\text{O}_2$ solution, 5.0 mL of 2.2 *M* $\text{HC}_2\text{H}_3\text{O}_2$, and sufficient bromine water to produce a light yellow color, mix, and allow to stand 5 minutes.
16. Reduce the excess bromine by adding NaCHO_2 solution until the yellow tinge in the sample disappears, then add an excess of 1 mL.
17. Wash down the sides of the flask with a small amount of water and blow out any bromine vapors with a syringe and a glass tube inserted through the mouth of the flask. If any iron precipitates at this point, add 0.5 g of $\text{KF} \cdot 2\text{H}_2\text{O}$.
18. Add approximately 1 g of KI and 10 mL of 3.6 *M* H_2SO_4 ; let stand 5 minutes in the dark; make sure the flask is tightly stoppered.
19. Titrate the liberated iodine with 0.01 *N* $\text{Na}_2\text{S}_2\text{O}_3$, adding 0.5 mL of starch indicator as the end point is approached. Record volume of titrant used. Disregard any return of the blue color after the end point has been reached.
20. Calculate bromide and iodide in the sample by using the following equations:

$$E_i = \frac{1,000 \times N_i}{V_s \times 6} \times (V_{iT} - V_{bT})$$

$$E_I = \frac{1,000 \times N_i}{V_s \times 6} \times (V_{iI} - V_{bI})$$

$$C_{Br} = 79.92 \times (E_i - E_j)$$

$$C_i = 126.9 \times E_i$$

where:

N_i is the normality of the thiosulfate standard,

E_i is the equivalents per liter of combined bromide and iodide,

E_j is the equivalents per liter of iodide,

V_s is the volume of sample in milliliters,

V_{bT} is the titrant volume, in milliliters, for blank determination on combined procedure,

V_{bI} is the titrant volume, in milliliters, for blank determination on iodide procedure,

V_{iT} is the titrant volume, in milliliters, for combined determination,

V_{iI} is the titrant volume, in milliliters, for iodide determination,

C_{Br} is the concentration of bromide in milligrams per liter, and

C_i is the concentration of iodide in milligrams per liter.

Interferences

Iron, manganese, and organic material interfere, so remove them by preliminary treatment with calcium oxide.

Sulfate by Thorin Method with Alumina Pretreatment

Principle

Filtered acidified brine sample is passed through an activated alumina column (Fritz and others, 1975). The sulfate is retained in the column while cations and other anions (chloride, bromide, etc.) pass through. The sulfate is then eluted from the alumina with dilute ammonium hydroxide, and the eluate is then passed through a cation exchange column in the hydrogen form. The solution is neutralized with concentrated ammonium hydroxide (pH ~5-7) and titrated against barium chloride using thorin indicator as described by Skougstad and others (1979).

Application

Small amounts of sulfate (≥ 0.5 mg/L SO_4) can be determined in waters of very high salinity.

Reagents

1. Ammonium hydroxide, 1 M. Dilute 65 mL of concentrated NH_4OH to 1,000 mL with distilled water.
2. Ammonium hydroxide, 0.1 M. Dilute 100 mL of 1 M NH_4OH to 1,000 mL.
3. Hydrochloric acid, 1 M. Dilute 88 mL of concentrated HCl to 1,000 mL with distilled water.

4. Barium standard solution, 1.00 mL = 0.20 mg SO_4 . Dissolve 0.434 g of anhydrous $BaCl_2$, which was dried for 1 hour at $180^\circ C$, in distilled water and dilute to 1,000 mL.
5. Thorin indicator solvent solution. Dissolve 0.025 g of thorin and 0.5 g of anhydrous sodium acetate in 10 mL of distilled water; warm gently to ensure complete dissolution. Filter the solution through Whatman No. 1 filter paper into 1,000 mL of 95 percent ethanol; discard filter paper without washing or rinsing. Add 12 mL of glacial acetic acid and mix.
6. Sulfate standard solution, 1,000 mg/L SO_4 . Dissolve 1.4787 g of Na_2SO_4 , which was dried for two hours at $180^\circ C$, in distilled water and dilute to 1,000 mL.

Apparatus

1. Alumina column, 12-mm ID (fig. 2): Add some chromatographic alumina (80-200 mesh) to a beaker, wash with distilled water, and allow to settle. Decant the supernatant and repeat the above procedure until the supernatant is clear. Transfer washed alumina into column to create a 6-cm bed. Wash the alumina with 50 mL of 1 M NH_4OH , several 5 mL portions of 0.1 M NH_4OH , and finally with 50 mL of water. Then wash with 10 mL of 1.0 M HCl. Do not allow the alumina column to become dry at any time.
2. Ion exchange column, 15 mm ID $\times$ 24 cm. Place approximately 10-12 centimeters of cation exchange resin (Dowex 50-X8, 50-100 mesh) into the column. To assure resin is in the hydrogen form, wash the resin with 20 mL of 1.0 M HCl. Rinse with distilled water until pH of effluent is near neutral. Regenerate the resin between each sample run.
3. Buret, 10-mL, 0.01 mL accuracy.
4. Spectrophotometer, Beckman Model B, or equivalent:
 - a. Wavelength: 520 nm.
 - b. Phototube: Blue-sensitive.
 - c. Initial sensitivity: 1.
 - d. End point: at 0.20 absorbance.
5. Spectrophotometer titration assembly with stirrer.
6. Beakers, 100-mL, scratch-free.
7. Vacuum pump.

Procedure

1. Acidify 100 mL of sample to approximately pH 1 with concentrated HCl, if necessary. Pass the sample through the alumina column at the rate of approximately 120 drops per minute. Vacuum must be applied to the column to achieve this rate.
2. Wash with 10 mL of 1.0 M HCl.

3. Wash with 25 mL of water in 5 mL portions. Discard all effluent collected up to this point.
4. Place a 100-mL volumetric flask under the column and elute the sulfate from the column by washing with 5 mL of 1 M NH_4OH .
5. Wash with 20 mL of 0.1 M NH_4OH .

Figure 2. Alumina column and associated apparatus (Fritz and others, 1975).

6. Wash with 20 mL of 0.1 M NH_4OH in 5 mL portions.
7. Wash with 25 mL of water.
8. Bring the 100-mL volumetric flask up to the 100-mL level with distilled water.
9. Regenerate the alumina column by washing with 10 mL 1.0 M HCl .
10. Pass the sulfate-containing effluent through the cation exchange column, discarding the first 20 to 30 mL of effluent.
11. Adjust the pH of the effluent to between 5 and 7 with concentrated NH_4OH .
12. Pipet a volume of sample (10.0 mL maximum) containing less than 2 mg of sulfate into a 100 mL beaker containing a stir bar and adjust the volume to 10.0 mL with water.
13. Add 40 mL of thorin indicator solvent solution.
14. Start stirrer and set absorbance at 0.100.
15. Titrate with barium chloride standard to an absorbance of 0.200 that is stable for 30 seconds.
16. Determine a blank correction by running distilled water through the entire procedure.
17. Run standards along with samples through the entire procedure.
18. Calculate sulfate concentration by using the following equation:

$$C_{\text{SO}_4} = \frac{1000 \times C_t}{V_s} \times (V_t - V_b)$$

where

C_{SO_4} is the concentration of sulfate in milligrams per liter,

C_t is the concentration of barium chloride titrant expressed as milligrams per milliliter sulfate,

V_s is the volume of sample in milliliters,

V_t is the volume of barium chloride titrant used for sample in milliliters,

V_b is the volume of barium chloride titrant used for blank in milliliters.

Boron by Carmine Method

Principle

Boron forms a colored complex ($\lambda_{\text{max}} = 600 \text{ nm}$) with carmine in acid solution. Maximum color development requires about one hour. The color is not stable after this time, fading by at least 25 percent after 2 hours. Analysis is performed on filtered unacidified samples.

Application

Concentration of boron in water can be determined in the 0.5 to 10 mg/L range.

Interferences

Silica may interfere, but the effect is independent of

silica concentration and dependent on boron concentration (Skougstad and others, 1979).

Reagents

1. Boron standard solution, 100 mg/L B. Dissolve 0.8813 g of recrystallized $\text{Na}_2\text{B}_4\text{O}_7 \cdot 10\text{H}_2\text{O}$ in distilled water and dilute to 1,000 mL. Store in a plastic bottle.
2. Hydrochloric acid, concentrated (sp. gr. 1.19).
3. Sulfuric acid, concentrated (sp. gr. 1.84).
4. Carmine solution. Suspend 0.50 g of carmine in 1,000 mL of concentrated H_2SO_4 and mix with a mechanical stirrer until completely dissolved.

Apparatus

1. Spectrophotometer (flow-through cell optional), Perkin-Elmer-Coleman Model 55, $\lambda = 600$ nm.
2. Beakers, plastic, 50-mL.

Procedure

1. Prepare blank, standards (usually 0.5 to 10.0 mg/L B), and samples by pipetting solutions (2.0 mL maximum) into 50-mL plastic beakers. Adjust the volumes to 2.0 mL with distilled water.
2. Add 2 drops concentrated HCl, 10 mL of concentrated H_2SO_4 , mix, and allow to cool for at least 30 minutes.
3. Add 10 mL of carmine solution and allow to stand approximately one hour.
4. Measure and record percent transmittance of the samples, standards, and blank at 600 nm.
5. Plot mg/L boron versus percent transmittance of standards; read sample concentrations directly from the standard curve.

Silica by Molybdate Blue Method

Principle

Silica in solution as silicic acid or silicate reacts with ammonium molybdate in acid solution to form the yellow-colored molybdate complex. The silicomolybdate complex is then reduced by sodium sulfite to form the molybdate blue color.

Application

Concentrations of silica, up to 50 mg/L, in formation waters can be determined. Dilutions prepared in the field should be used to determine silica content of samples greater than 50 mg/L.

Reagents

1. Ammonium molybdate solution. Dissolve 52 g of $(\text{NH}_4)_6\text{Mo}_7\text{O}_{24} \cdot 4\text{H}_2\text{O}$ in distilled water, adjust the pH to between 7 and 8 with 10 M NaOH, and dilute to 1,000 mL with distilled water. Filter through 0.45- μm membrane filter if necessary.
2. Hydrochloric acid, 1.0 M. Mix 88 mL of concen-

trated HCl with distilled water and dilute to 1,000 mL.

3. Silica standard solution, 1.00 mL = 0.50 mg SiO_2 . Stabilize 3 g of $\text{Na}_2\text{SiO}_3 \cdot 5\text{H}_2\text{O}$ by drying over calcium chloride for 2 to 3 hours. Dissolve 1.765 g in distilled water and dilute to 1,000 mL. The concentration of this solution must be verified by standard gravimetric analysis (American Public Health Association, 1971). Store in a plastic bottle.
4. Disodium EDTA solution. Dissolve 10 g of $\text{C}_{10}\text{H}_{14}\text{O}_8\text{N}_2\text{Na}_2 \cdot 2\text{H}_2\text{O}$ in distilled water and dilute to 1,000 mL.
5. Sodium sulfite solution. Dissolve 170 g of Na_2SO_3 in distilled water and dilute to 1,000 mL.
6. Tartaric acid solution. Dissolve 100 g of $\text{H}_2\text{C}_4\text{H}_4\text{O}_6$ in distilled water and dilute to 1,000 mL.

Apparatus

1. Spectrophotometer, Perkin-Elmer-Coleman Model 55, or equivalent.
2. Beakers, plastic, 50-mL.

Procedure

1. Pipet filtered unacidified sample containing less than 0.5 milligrams of silica (10.0 mL maximum) into a 50-mL beaker, adjust the volume to 10.0 mL with distilled-deionized water.
2. Pipet a distilled water blank and standards into 50-mL beakers and adjust the volume of each to 10.0 mL. Standards are generally run in the 0 to 50 mg/L silica range.
3. Add to each beaker, with stirring, 5.0 mL of 1.0 M HCl, 5.0 mL of Na_2EDTA solution, and 5.0 mL of ammonium molybdate solution and mix.
4. After five minutes, add 5.0 mL of tartaric acid solution and mix.
5. Add 10 mL of Na_2SO_3 solution and mix.
6. Allow to stand for approximately 30 minutes. The colored complex will be stable for several hours after this time.
7. Determine the absorbance of the samples and standards against the blank at 700 nm.
8. Determine the concentration of silica, in milligrams per liter, in the samples from a plot of absorbance versus concentration of standards.

Aliphatic Acid Anions by Gas Chromatography

Principle

Acidified aqueous solution of aliphatic acid anions (C_2 through C_5) is absorbed on silicic acid, then the acid anions are eluted with a chloroform-butanol mixture (Carothers and Kharaka, 1978).

This mixture is titrated against standard sodium hydroxide to yield total titratable organic species. After titration, the solution is evaporated to dryness. The dried salt is then dissolved in distilled water and passed through a column packed with strong-acid ion-exchange resin in hydrogen form. The resulting aqueous solution is analyzed for free aliphatic acids by conventional gas chromatography.

Application

Aliphatic acid anions (C_2 through C_5) can be determined in formation waters of very high salinity. This method gives reproducible recoveries of 93 ± 5 percent.

Reagents

1. Silicic acid, 50-200 mesh. Remove fines by letting a distilled-water slurry of silicic acid settle for 15 minutes and then by decanting off the supernatant. Repeat this procedure until no fines are present. Put the washed acid in an oven at 103°C and leave it there until it is absolutely dry. Store in a desiccator.
2. Chloroform-butanol reagent. Mix 300 mL of reagent-grade chloroform, 100 mL of n-butanol, and 80 mL of 0.5 N H_2SO_4 in a separatory funnel; shake; and then allow the water and organic phases to separate. Drain the lower organic (chloroform-butanol) layer through a fluted filter paper into a dry bottle.
3. Thymol blue indicator solution. Dissolve 80 mg of thymol blue in 100 mL of absolute methanol.
4. Phenolphthalein indicator solution. Dissolve 80 mg of phenolphthalein in 100 mL of absolute methanol.
5. Sodium hydroxide stock solution. Dissolve 40 g of NaOH in distilled water, dilute to 1,000 mL with distilled water.
6. Sodium hydroxide standard titrant, 0.02 N. Dilute 20 mL of 1.0 N NaOH stock solution to 1,000 mL with absolute methanol. Standardize according to American Public Health Association (1971) procedure.
7. Hydrochloric acid, concentrated.
8. Strong-acid ion-exchange resin. BioRad AG 50W-X8, 50-100 mesh resin in the hydrogen form.

Apparatus

1. Crucibles, Gooch or fritted glass, with filtering flask and vacuum source.
2. Separatory funnel.
3. Purge source, nitrogen or carbon dioxide-free air.
4. Buret, 25-mL.
5. Rotary evaporator and heating bath.
6. Gas chromatograph, Perkin-Elmer Sigma 3 or

equivalent with flame ionization detector.

7. Chromatographic column, 2 mm $\times$ 1.8 m. Pack column with Supelco packing material that is 10 percent SP1200 and 1 percent phosphoric acid AW Chromosorb W(80-100 mesh).

Procedure

1. To about 20 mL of filtered acidified sample, add a few drops of thymol blue indicator solution and adjust the pH to between 1 and 1.2 (red color of thymol blue).
2. Place 12 g of silicic acid in a Gooch filter and apply suction to pack the column. Use a new column for each sample.
3. Pipet 5.0 mL of sample as uniformly as possible over the surface of the column, applying suction momentarily to draw the liquid into the silicic acid. Release vacuum as soon as the last portion of the sample has entered the column.
4. Quickly add 65 mL of chloroform-butanol mixture to the column and apply vacuum. Discontinue suction just before the last of the reagent enters the column.
5. Remove the filter flask and purge the eluted sample with nitrogen or carbon dioxide-free air immediately before titration.
6. Titrate the sample in the filter flask with 0.02 N sodium hydroxide to the phenolphthalein end point while continuing purging.
7. Prepare a blank and standards, acidify, place on columns, extract with chloroform-butanol mixture, and titrate with sodium hydroxide as above.
8. Place titrated sample into rotary evaporator and evaporate to dryness at 50°C under vacuum.
9. Dissolve the dried salts in a minimum amount of distilled water.
10. Pass this solution through a column packed with strong-acid ion-exchange resin in the hydrogen form. Dilute to a final volume of 5.0 mL.
11. Store aqueous solutions of aliphatic acids under refrigeration until analyzed by gas chromatography.
12. Analyze blank, standards, and samples on gas chromatograph under the following conditions:
Injection volume 0.5 μL
Injection temperature 150°C
Column temperature 120°C
Detector temperature 150°C
Carrier gas (He) flow rate 20 mL per minute.

REFERENCES

American Petroleum Institute, 1968, API recommended practice for analysis of oil-field waters (2d ed.): Washington, D.C., 49 p.

- American Public Health Association. 1971. Standard methods for the examination of water and waste-water (13th ed.): Washington, D.C., 874 p.
- Ball, J. W., Jenne, E. A., Burchard, J. M., and Truesdell, A. H., 1976. Sampling and preservation techniques for water in geysers and hot springs: Proceedings of the First Workshop on Sampling Geothermal Effluents: U.S. Environmental Protection Agency, EPA-600/9-76-0111, p. 219-234.
- Barnes, Ivan, 1964. Field measurement of alkalinity and pH: U.S. Geological Survey Water-Supply Paper 1535-H, 17 p.
- Barnes, R. B., 1975. The determination of specific forms of aluminum in natural water: *Chemical Geology*, v. 15, p. 177.
- Brown, Eugene, Skougstad, M. W., and Fishman, M. J., 1970. Methods for collection and analysis of water samples for dissolved minerals and gases: U.S. Geological Survey Techniques of Water-Resources Investigations, Book 5, Chapter A1, 160 p.
- Carothers, W. W., and Kharaka, Y. K., 1978. Aliphatic acid anions in oil-field waters—Implications for origin of natural gas: *American Association of Petroleum Geologists Bulletin*, v. 62, no. 12, p. 2441-2453.
- Collins, A. G., 1975. *Geochemistry of oilfield waters*: New York, Elsevier Scientific Publishing, 496 p.
- Fritz, J. S., Yamamura, S. S., and Richard, M. J., 1975. Titration of sulfate following separation with alumina: *Analytical Chemistry*, v. 29, p. 159.
- Kennedy, V. C., Zellweger, G. W., and Jones, B. F., 1974. Filter pore-size effects on the analysis of Al, Fe, Mn, and Ti in water: *Water Resources Research*, v. 10, no. 4, p. 785.
- Kharaka, Y. K., and Barnes, Ivan, 1973, SOLMNEQ: Solution-mineral equilibrium computations: U.S. Department of Commerce, National Technical Information Service PB-215 899, 82 p.
- Kharaka, Y. K., Callender, Edward, and Carothers, W. W., 1977. Geochemistry of geopressured geothermal waters from the Texas Gulf Coast: Geopressured-Geothermal Energy Conference, 3rd, Lafayette, Louisiana, University of Southwestern Louisiana, 1977 Proceedings, G1-121-125.
- McCrea, J. M., 1950. The isotopic chemistry of carbonates and a paleotemperature scale: *Journal of Chemical Physics*, v. 18, p. 849-858.
- Orion Research Inc., 1976. Instruction manual Fluoride Electrodes, Models 94-09 and 96-09: 32 p.
- Orion Research Inc., 1978. Instruction manual for sulfide ion electrode, silver ion electrode Model 94-16: 40 p.
- Perkin-Elmer Corporation, 1976a. Analytical methods for atomic absorption spectrophotometry, Standard Conditions Section, 155 p.
- Perkin-Elmer Corporation, 1976b. Instructions for mercury analysis system, Perkin-Elmer report 303-3119, 21 p.
- Presser, T. S., and Barnes, Ivan, 1974. Special techniques for determining chemical properties of geothermal waters: U.S. Geological Survey Water-Resources Investigations, 22-74, 11 p.
- Rainwater, F. H., and Thatcher, L. L., 1960. Methods for collection and analysis of water samples: U.S. Geological Survey Water-Supply Paper 1454, 301 p.
- Skougstad, M. W., Fishman, M. J., Friedman, M. C., Erdman, D. E., and Duncan, S. S., 1979. Methods for determination of inorganic substances in water and sediments: U.S. Geological Survey Techniques of Water-Resources Investigations, Book 5, Chapter A1, 626 p.
- Underhill, G. K., Carlson, R. A., Clendinning, W. A., Erdos, J., Gault, J., Hall, J. W., Jones, R. L., Michael, H. K., Powell, P. H., Riemann, C. F., Rios-Castellon, L., Sheppard, B. P., and Wilson, J. S., 1976. Surface technology and resource utilization: Geopressured-Geothermal Energy Conference, 2d, Austin, University of Texas, 1976, Proceedings, v. 4, 1976, 203 p.
- Watson, J. C., 1978. Sampling and analysis methods for geothermal fluids and gases: Pacific Northwest Laboratory Report PNL-MA-572, 522 p.