DS Poch Suldet

Volume 2: Commercial Technology

SERI/TP--254-4098B

DE91 002154

DSM Pocket Guidebook

Volume 2: Commercial Technologies

prepared by
Solar Energy Research Institute
1617 Cole Boulevard
Golden, Colorado 80401
(303) 231-7303

prepared for (under subcontract to)

Contract DE-IA65-90WA07253 with
Western Area Power Administration
1627 Cole Boulevard, P.O. Box 3402
Golden, Colorado 80401
(303) 231-7504

Contract DE-AC02-83CH10093 with
U.S. Department of Energy
Washington, D.C.

SERI/TP-254-4098B ■ APRIL 1991
DE91002154

MASTER

25

DISCLAIMER OF WARRANTY AND LIMITATION OF LIABILITY

This manual is provided "as is" without warranty of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. The entire risk as to the quality, performance, and accuracy of the manual is with the holder. In no event will the authors be liable to the holder or any party to whom holder distributes the manual for any damage, including but not limited to damages for any lost profits, lost savings, or other incidental or consequential damages arising out of the use or inability to use the manual, even if the author(s) have been advised of the possibility of such damage.

Printed in the United States of America
Available from National Technical Information Service
U.S. Department of Commerce
5285 Port Royal Road
Springfield, VA 22161

Price: Microfiche A01 / Printed Copy A07

Codes are used for pricing all publications. The code is determined by the number of pages in the publication. Information pertaining to the pricing codes can be found in the current issue of the following publications which are generally available in most libraries: *Energy Research Abstracts (ERA)*; *Government Reports Announcements and Index (GRA and I)*; *Scientific and Technical Abstract Reports (STAR)*; and publication NTIS-PR-360 available from NTIS at the above address.

TABLE OF CONTENTS

Brief #		Page No.
	Introduction to Volume 2, Commercial Technologies	1
	BUILDING ENVELOPE	9
1	Fenestration	10
2	Passive Solar Design	17
	HVAC SYSTEMS	19
3	Heat Recovery from Exhaust Air	22
4	Outside Air Economizers	25
5	Evaporative Cooling	28
6	Cool Storage	31
7	Heat Recovery from Chillers	35
8	High-Efficiency Air Conditioning	37
9	Heat Pumps	40
10	Energy Management Systems	44
	LIGHTING	49
11	Fluorescent Lamps	51
12	Exit Light Conversion	57
13	High-Intensity-Discharge Lamps	59
14	Light Sensors/Controllers	62
15	Daylighting Controllers	65
	APPLIANCES	69
16	Water Heater Retrofits	70
17	Refrigeration Systems	73
18	Cooking Equipment	76
	MOTORS	79
19	Electric Motors—General	81
20	Energy-Efficient Motors	87
21	Electronic Adjustable-Speed Drives (ASDs)	90
22	Single-Phase vs. Polyphase Induction Motors	93

Brief #	Page No.
23 Motor Oversizing	95
24 Motor Rewinding vs. Energy-Efficient Motors	100
25 Wire Sizing	103
26 Power Supply Tune-Up	105
27 Maintenance Practices	108
28 Transmission Efficiency	111

FOREWORD

In previous years of low-cost energy, many demand-side management (DSM) technologies simply were not cost effective. Today, however, with rising energy prices and the mandate to conserve, utility DSM programs and advanced energy-efficient technologies offer utilities significant opportunity for economic means to reduce operating costs and shift or defer load growth. Furthermore, recent developments in DSM technologies have improved energy quality and reduced customer maintenance costs.

This series of guidebooks is intended as a tool for utility personnel involved in DSM programs and services. Both the novice and the DSM expert can benefit from the information compiled.

Efficient energy utilization through DSM applications helps Western meet one of its primary objectives—elimination of wasteful energy practices and adoption of conservation programs that meet customer needs in an era of diminished resources and increased environmental concerns.

PREFACE TO THE DSM POCKET GUIDEBOOK

■ INTRODUCTION

It has been estimated that if electricity were used more efficiently with commercially available end-use technologies, 24%–44% of the nation's current demand for electricity could be eliminated. Almost all major electric utilities in the west are investigating such demand-side management (DSM) opportunities. In some service territories, for example, improved efficiency could soon produce as much power as that from new coal-fired plants (Figure P-1) and produce it at a lower cost (Figure P-2). Even utilities that currently have excess capacity are finding that DSM offers an opportunity to build efficient end-use stock to help them meet their future load shape objectives.

Utility DSM programs typically consist of several measures designed to modify the utility's load shape (for example, innovative rate structures, direct utility control of loads, promotion of energy-efficient technologies, and customer education). The coordinated implementation of such measures requires planning, analysis of options, engineering, marketing, monitoring, and other coordination activities (Figure P-3). This guidebook addresses one facet of an overall DSM program: selection of end-use technologies within the electrical utilities.

■ TECHNOLOGY SELECTION

All facets of a utility's DSM program, including technology selection, must be planned with the utility's overall objectives in mind. Selected technologies must make the utility better able to serve its customers by providing low-cost reliable power. Yet the utility must also be able to recover its fixed and operating costs. In

Figure P-1. Source: "Planning for Stable Growth, Pacific Power and Utah Power Resource and Market Planning Program, Volume 1—Summary Report" (Nov. 1989).

Figure P-2. Source: "Planning for Stable Growth, Pacific Power and Utah Power Resource and Market Planning Program, Volume 1—Summary Report" (Nov. 1989).

Figure P-3. DSM technology alternatives—position in the overall DSM program process. Source: Electric Power Research Institute, "DSM Technology Alternatives," EPRI EM-5457 (Oct. 1987).

practice, this usually means that the technology must provide the same or expanded cost-effective energy service to the customer while also smoothing out the utility's load curve and delaying the need for additional power plants. This guidebook directly addresses these requirements by estimating the simple payback (to the end user) for energy-efficient end-use technologies and their impacts on the utility's load curve.

A number of additional factors must be considered in technology selection. Primary among these are customer acceptance of different end-use technologies, the type of marketing effort required to promote each, and the potential impact on the utility's revenues. These are not addressed in this guidebook.

■ INTENDED AUDIENCE

This guidebook is intended to be a quick reference source both for utility field representatives in their customer interactions and for utility planners in the early stages of developing a DSM program. It is designed to allow a quick screening of commercially available electric end-use technologies with emphasis on the residential, commercial, and agricultural sectors. Only a limited number of technologies applicable to industrial processing (motors, adjustable-speed drives) are included because industrial customers usually are better informed about their energy options, they have more resources and incentive to investigate such options in detail, and the full range of industrial processes is beyond the scope of this guidebook.

Finally, this guidebook is directed primarily at small municipal utilities and rural electric cooperatives within the Western Area Power Administration (Western) service area (see Figure P-4). Large utilities with more abundant resources may find the guidebook useful as only a starting point. Their technology selection process will undoubtedly also include review of other source documents and detailed system and engineering analyses of the options.

**Figure P-4. Western Area Power Administration
area map**

BA-G0718811

Figure P-4 (continued). Western Area Power Administration area map

■ METHODOLOGY/DATA

For each technology the guidebook presents a short numbered "technology brief"—text that describes the option, its relevant applications, and its potential impact on the utility's load duration curve. Each brief also includes a summary table (usually not specifically referred to by number) with quantitative estimates of initial costs, energy savings, and simple payback to the customer. All costs are expressed in 1990 dollars. For most technologies, capital cost and energy savings are estimated for one or more energy-efficient options and a reference case—usually an electric technology.

Where sufficient data exist, payback (to the end user) for the energy-efficient option is also compared to that for the reference case. Payback is determined by dividing the capital cost (incremental over the reference case) by the annual dollar savings (relative to the reference case). For simplicity, regional utility variations in electricity prices are ignored; the payback calculations use electricity prices of \$0.08/kWh, \$0.07/kWh, and \$0.07/kWh in the residential, commercial, and agricultural sectors, respectively. To estimate payback using actual local electricity prices, multiply the payback by actual electricity price in dollars per kilowatt hour/assumed electricity price in dollars per kilowatt hour. For technologies such as replacement windows or insulation in which payback varies based on the climate, a payback range is given or the energy savings and payback are calculated for more than one climate.

Demand charges generally are not included in the payback calculations, because demand rates and possible reductions vary widely by region and utility, and for most of the options demand savings is small. For those technologies that have a large impact on demand (e.g., commercial building cool storage), a range of demand savings is presented and included in the payback calculations.

In almost all cases, the quantitative estimates of costs and energy savings have been taken from existing

literature, including documentation of completed utility DSM programs, field studies and experiments, manufacturers' data, laboratory experiments, and computer simulation and analysis. The sources used varied depending primarily on the availability of data and the complexity of the technology. For example, manufacturers' data were used for several cost estimates, but only rarely for performance estimates, and then only in conjunction with data from field studies or simulations. On the other hand, for more complex technologies such as passive solar home design, the data were drawn from field studies and simulations to capture all the interactions that occur between building components and the local climate.

As might be expected, cost and performance values drawn from different sources are frequently inconsistent. (The reasons for such variations and the resulting uncertainties in the guidebook data are addressed later in this preface.) To reconcile such inconsistencies, the reports were first examined in detail and, in many cases, their authors contacted to identify the higher-quality studies and/or reasonable causes for the differences. For some technologies, we eliminated conflicting sources, either because the system or climate was not like the one being described in the guidebook, or because one analysis was clearly superior. If no clear distinction could be made between the analyses, the guidebook presents either a range of values or an average value.

Because of the condensed nature of this guidebook and our desire to keep it simple, we have provided only limited references for the source materials and computations. The guidebook is not intended to substitute for a detailed analysis, but rather to point the reader toward those technologies most likely to benefit both the end user and the utility. For more details, the reader should consult the references (in sections titled "For More Information") at the end of each brief.

■ DATA VARIABILITY AND UNCERTAINTY

A problem with guidebooks like this is that the data can at best present only a simple overview of each technology. Yet hundreds of volumes have been written describing the application of these technologies. Consequently, the cost and performance estimates presented here should be used with a clear understanding of the sources of variability and uncertainty.

Variations in performance occur with climate and with the technology's design and configuration, the system within which it is applied, and the way it is used. Cost varies with the quality or brand of an individual component, the size (e.g., cost per ton for large commercial air conditioning systems is less than for small unitary systems), the quantity ordered (e.g., cost per lamp for a major commercial retrofit will be less than the retail purchase price of a single lamp), and/or the time of purchase (inflation and technological improvements change costs over time). Generally, the only variation quantified in this guidebook is the range in performance with different climatic conditions.

Similarly, there are significant sources of uncertainty in the cost and performance data. The uncertainties, which largely result from drawing cost and performance statistics from a number of different sources, include

- Lack of complete documentation of the assumptions, data, and methods used in many of the studies
- Lack of statistically valid generalizations because of small sample sizes (i.e., results in the referenced studies are frequently based on only a few applications or systems)
- Reference study results based on simulations and limited testing, not field testing
- The use of multiple studies or sources for the cost and performance values of a single technology.

Where possible, we have avoided such problems by identifying excellent sources. However, as might be expected, we are more confident of some of the results than others. Thus for many technologies, we have included a rough measure (high, medium, low) of our confidence and the extent of the data variability and uncertainty. We expect that future revisions of this guidebook will provide the opportunity to reduce some of these uncertainties.

■ ORGANIZATION AND USE OF THE GUIDEBOOK

The guidebook consists of three pocket-sized volumes, each introduced by this preface. The first volume considers end-use technologies for the residential sector. The second volume includes technologies for the commercial sector as well as motors and variable-speed drives applicable to the commercial, industrial, and agricultural sectors. The third volume discusses energy-efficient technologies for the agricultural sector with an emphasis on the central and western United States (see area map in Figure P-4).

A number of technologies (e.g., energy-efficient windows) apply to more than one end-use sector. Where applicable, cross references are provided in the briefs. They are also summarized in Table P-1.

Each volume contains two sets of matrices to allow a quick screening of the technologies. One matrix addresses payback values, and the other identifies the most likely impact of each technology on the utility load duration curve (see Figure P-5). A utility planner who has identified the types of load changes desired and the appropriate end-use sectors can use the matrices to quickly identify candidate technologies. The text in the briefs provides background information.

Table P-1. Cross-Sector References

Technology	End-Use Sector / Volume Number		
	Residential 1	Commercial 2	Agricultural 3
Insulation	1,3	■	
Windows	4,5,6	1	
Weatherstripping	7	■	
Duct leaks	15	■	
Passive solar	8	2	
Heat pumps	9	9	
Efficient air conditioners	13	8	
Energy management	■	10	■
Hot water efficiency	17	16	7
Solar hot water	19	■	■
Fluorescent lamps	21	11	
Cooking	25	18	
Swimming pools	26	■	
Motors		19-28	■

Each number refers to a written brief that describes the technology. A solid box (■) indicates that the technology is of interest in the sector, but is not written up. For example, see Vol. 1 (residential), technology brief #17, for a thorough discussion of hot water efficiency. See Vol. 2 (commercial), technology brief #16, or Vol. 3 (agricultural), technology brief #7, for additional information. If you are interested in motors in the agricultural sector (Vol. 3), the black box directs you to consult technology briefs #19-#28 in Vol. 2 (commercial).

Load Shifting
Example: Cool storage

Peak Clipping
Example: Direct control
of air conditioning units

Valley Filling
Example: Thermal
energy storage

Strategic Load Growth
Example: Heat pumps

Flexible Load Shape
Example: Direct
control of residential
water heaters

Strategic Conservation
Example:
Weatherization and
efficient appliances

Figure P-5. Typical load shape changes resulting from selected demand-side alternatives. Adapted from Clark W. Gellings, highlights of a speech presented to the 1982 Executive Symposium of EEI Customer Service and Marketing Personnel.

COMMERCIAL

INTRODUCTION

Annual electricity sales to commercial customers represent about 25% of total utility electricity sales and 30% of summer peak demand. Most commercial buildings consume most of their electricity for lighting, air conditioning, and space heating. However, the relative importance of different end uses varies significantly among customer types. Office buildings, for example, have high space cooling loads, whereas retail establishments generally have high lighting loads. For groceries, refrigeration emerges as the most important end use, whereas cooking is the major end use for restaurants. Figure C-1 compares these differences. Until 1980, natural gas was the primary space heating fuel used in commercial buildings. However, in the 1980s approximately 40% of all new commercial floor space was built with electric space heating; so that today 23% of all commercial buildings are heated electrically. In addition, air conditioning has become commonplace in almost all new commercial buildings.

Utility rate structures for commercial buildings generally include a demand component—i.e., a customer is billed for maximum rate of use (in kilowatts) as well as for the quantity of energy used (in kilowatt hours). Also, many utilities' rates vary by season and/or time of day. It is difficult to identify a representative rate structure for the Western region, because the demand and energy components of the rate vary greatly throughout the region. For the purpose of calculating a simple payback for the measures covered in this section, we used a nationwide average rate of \$0.07/kWh.

With its wide range of customers and end uses, the commercial sector provides a wealth of opportunities to meet utility demand-side management (DSM) objectives. However, this diversity also makes it difficult to design,

M11-G0657305

Figure C-1. Building energy use by type of business

implement, and evaluate DSM programs having sector-wide applicability.

This volume covers opportunities for commercial DSM. In many cases, a DSM technology covered in Volume 1 (the residential sector) is also applicable to the commercial sector. For these measures, the reader is referred to Volume 1.

In this volume on the commercial sector, Table C-1 identifies technologies that can be used to reduce or shift peak load, increase demand during off-peak periods (valley filling), provide strategic conservation or load growth, or allow for flexible load management. Table C-2 shows the simple payback for the energy-efficient options evaluated.

Table C-1.
Demand-Side Management Strategies
Matrix: Commercial Measures

	PC*	VF*	LS*	SC*	SG*	FLS*
BUILDING STRUCTURE						
1. Fenestration		■			■	
• Tinted IG low-E suspended						
• Low-E IG (bronze)						
• Tinted IG (green)						
• Tinted IG low-E suspended						
• Low-E IG (green)						
• Clear low-E						
2. Passive solar design		■	■		■	
HEATING, VENTILATING, AND AIR CONDITIONING						
3. Heat recovery from exhaust air						■
4. Outside air economizers						■
5. Evaporative cooling		■				■
• Direct						
• Direct/indirect						
6. Cool storage			■	■		
• Chilled water, partial storage						
• Ice, partial storage						
7. Heat recovery from chillers						■
• Double-bundle chillers						
8. High-efficiency air conditioning						■
9. Heat pumps		■			■	■
10. Energy management systems		■			■	
• Single-function controls (small building)						
• Single-function controls (modium building)						
• Stand-alone multifunction						
LIGHTING						
11. Fluorescent lamps						■
• High-efficiency lamps						
• Electronic ballasts						
• Reflectors						
• Combination						
12. Exit light conversion						■
13. High-intensity-discharge lamps						■
• High-pressure sodium						
• Low-pressure sodium						

**Table C-1. Demand-Side
Management Strategies Matrix:
Commercial Measures (Concluded)**

	PC*	VF*	LS*	SC*	SG*	FLS*
LIGHTING (Continued)						
14. Light sensors/controllers						■
• Ultrasonic occupancy sensors						
• Photocell						
15. Daylighting controllers		■			■	
• Continuous dimming (retrofit)						
• Continuous dimming (new)						
HOT WATER						
16. Water heater retrofits						■
• Booster heater						
• Reduce hot water circulation						
REFRIGERATION						
17. Refrigeration systems		■			■	
• Multiplex compressors						
• Floating head pressure control						
• Ambient subcooling						
• Mechanical subcooling						
• Hot gas defrost						
• Evaporative condenser						
• Display case glass doors						
COOKING						
18. Cooking equipment		■			■	
• Energy-efficient fryer						
• Combination steamer/oven						
MOTORS						
19. Electric motors --general						■
20. Energy-efficient motors						
21. Adjustable-speed drives						
22. Polyphase motors						
23. Motor oversizing						
24. Motor rewinding						
25. Wire sizing						
26. Power supply tune-up						
27. Maintenance						
28. Transmission efficiency						

* PC = peak clipping; VF = valley filling; LS = load shifting; SC = strategic conservation; SG = strategic growth; FLS = flexible load shape.

Table C-2.
Payback for Demand-Side Management
Strategies: Commercial Measures¹

		No. of Years			
		<2	2-5	6-10	>10
BUILDING STRUCTURE					
1. Fenestration					
Wall-to-window ratio = 0.75					
• Tinted IG low-E suspended (green)				■	■
Wall-to-window ratio = 0.50					
• Low-E IG (bronze)				■	■
• Tinted (green)	■				
• Tinted IG low-E suspended (green)					■
• Low-E (green)				■	
Window-to-wall ratio = 0.25					
• Clear low-E				■	■
2. Passive solar design			■		
HEATING, VENTILATING, AND AIR CONDITIONING					
3. Heat recovery from exhaust air			■		
4. Outside air economizers	■		■		
5. Evaporative cooling					
• Direct			■		
• Direct/indirect				■	
6. Cool storage					
• Chilled water, partial storage	■			■	
• Ice, partial storage	■				■
7. Heat recovery from chillers					
• Double-bundle chillers				■	
8. High-efficiency air conditioning			(varies)		
9. Heat pumps	■				
10. Energy management systems					
• Single-function controls (small building)	■				
• Single-function controls (medium building)			■		
• Stand-alone multifunction			■		
LIGHTING					
11. Fluorescent lamps					
• High-efficiency lamps	■				
• Electronic ballasts			■		
• Reflectors			■		
• Combination			■		
12. Exit light conversion	■				
13. High intensity discharge lamps					
• High pressure sodium	■				
• Low-pressure sodium	■				

Table C-2. Payback for Demand-Side Management Strategies: Commercial Measures¹ (Concluded)

		No. of Years			
		<2	2-5	6-10	>10
LIGHTING (Continued)					
14. Light sensors/controllers					
• Ultrasonic occupancy sensor	■				
• Photocell	■				
15. Daylighting controllers					
• Continuous dimming (retrofit)			■		
• Continuous dimming (new)			■		
HOT WATER					
16. Water heating retrofits					
• Booster heater			■		
• Reduce hot water circulation	■				
REFRIGERATION					
17. Refrigeration systems					
• Multiplex compressors			■		
• Floating head pressure control			■		
• Ambient subcooling	■				
• Mechanical subcooling			■		
• Hot gas defrost	■				
• Evaporative condenser	■				
• Display case glass doors			■		
COOKING					
18. Cooking equipment					
• Energy-efficient fryer				■	
• Combination steamer/oven	■				
MOTORS					
19. Electric motors—general					
20. Energy-efficient motors	■	-----	-----	-----	■
21. Adjustable-speed drives			■	-----	■
22. Polyphase motors					
23. Motor oversizing	■	-----	-----	-----	■
24. Motor rewinding					
25. Wire sizing	■	-----	-----	-----	■
26. Power supply tune-up					
27. Maintenance					
28. Transmission					

■ = A representative payback, as calculated based on assumptions found in each of the technology briefs. ■-----■ = A payback range depending on various conditions. For example, the payback for the cool storage measures was calculated for a range of cost/peak demand. The fenestration measures were calculated for a hot versus a cold climate.

1. These paybacks are representative. They vary based on building type, use, location, utility rate structure, and other factors.

COMMERCIAL BUILDING ENVELOPE

The building envelope consists of walls, roofs, floors, windows, doors, and other openings. Of all such components, windows have the greatest impact on energy consumption, because they are major contributors to overall heat loss and gain and lighting requirements. Although for many large commercial buildings the envelope plays a smaller role than in the residential sector, considerable conservation can be achieved in most commercial buildings by optimizing the envelope's structure and form and the building's orientation.

Demand-side management strategies covered in this section include fenestration and passive solar design. The reader is referred to Volume 1 on the residential sector for more information on insulation, radiant barriers, and window treatments.

FENESTRATION**■ DESCRIPTION**

In commercial buildings, fenestration (the arrangement, proportioning, and design of windows and doors in a building) is the most significant determinant of energy use. Commercial building fenestration systems can be designed to introduce natural daylight through windows or skylights or to block solar gain to minimize building cooling loads. (In a daylight space, the fenestration system needs to be integrated with an automatic control system for the electric lights. For more information on daylighting controls, the reader is referred to brief #15 in this volume, daylighting in commercial buildings. For more information on insulating and low-E glazings, the reader is referred to Volume 1, brief #4, residential windows.)

Glazing materials have three principal performance characteristics:

- The U-value determines the conductive heat losses and gains.
- Visible light transmission (T_v) determines the relative amount of daylight that will enter a space.
- Shading coefficient (SC) determines the relative amount of solar gain, which contributes to cooling loads.

For good daylighting design, the glazing should have the highest possible T_v with the lowest possible SC. Table C-5 lists T_v and SC for various types of glazing. The optimum glazing area for a given space depends on the desired illumination level, the type of glazing material used, and building orientation. For typical office illumination levels, an effective aperture area of approximately 0.30 is recommended. Therefore the optimum glazing area is larger for glazing materials with a lower T_v (such as tinted glass) and smaller for glazing

materials with a higher T_v (such as clear glass). Reflective architectural glazings have T_v levels around 10%. They provide for very low savings from daylighting and are used to provide sun and glare control while reducing cooling loads. When designing daylit buildings, it is important to optimize the benefits of reduced electric lighting loads without increasing cooling energy requirements.

For skylights, the optimal glazing area is smaller and depends again on the design illuminance, the glazing material, and the size and shape of the skylight well.

■ DEFINITIONS AND TERMS

DESIGN ILLUMINANCE This term refers to levels of task lighting. Recommendations by the Illuminating Engineering Society for different tasks are found in Table C-16 in brief #11 on commercial fluorescent lamps.

EFFECTIVE APERTURE The product of the WWR and T_v

INSULATION GLASS (IG) Double-paned glass

WINDOW-TO-WALL RATIO (WWR) The area occupied by interior windows in relation to wall area.

SHADING COEFFICIENT (SC) The ratio of the solar heat gain through the glazing (including the fraction of solar gain absorbed in the glazing that is subsequently transferred to the room) to the solar heat gain through single glazing

T_v The percentage of light that is transmitted through the glass.

■ APPLICABILITY

BUILDING TYPE Primarily new commercial

CLIMATE All

DEMAND MANAGEMENT STRATEGY Strategic conservation, peak clipping

■ FOR MORE INFORMATION

Sweltzer, G.; D. Arasteh, and S. Selkowitz (1986), "Effects of Low-Emissivity Glazings on Energy Use Patterns in Nonresidential Daylighted Buildings." Berkeley, CA: Lawrence Berkeley Laboratory (LBL-21577).

Table C-3.
Incremental Costs over Clear
IG for Glass Features

Feature	Cost/ft² of window area (\$)
Tinting	0.50-1.00
Reflective coating	3.00-4.00
Low-E coating (on glass)	2.75
Triple glazing	3.30
Low-E on suspended film	3.50-4.50
Gas fill	1.00

Table C-4. Commercial Building Fenestration: Costs and Benefits

Options ¹	Costs ² (\$/ft ²)	Energy Use ³ (kWh/ft ² /yr)		Cost Savings (\$/ft ² /yr)		Simple Payback ⁴		Peak ⁵ (W/ft ²)	Chiller ⁶ (ft ³ /ton)	Life (yrs)	Confidence
		South	North	South	North	South	North	(all zones)	(all zones)		
COLD CLIMATE (7800 HDD, 425 CDD)											
WWR = 0.75											
Reflective IG (bronze)	1.45	8.6	8.9	—	—	—	—	3.3	667	20	M
Tinted IG low-E suspended (green)	11.50	6.9	6.4	0.12	0.18	3.7	2.5	2.6	555	20	M
WWR = 0.50											
Tinted IG (bronze)	0.21	7.9	7.9	—	—	—	—	2.9	588	20	M
Low-E IG (bronze)	1.00	6.8	7.0	0.08	0.06	9.9	13.2	2.5	689	20	M
Tinted IG (green)	0.21	7.1	7.0	0.06	0.06	immediate		2.5	645	20	M
Tinted IG low-E suspended (green)	1.33	6.7	6.8	0.08	0.06	14.0	18.8	2.5	667	20	M
Low-E IG (green)	1.00	6.3	6.7	0.11	0.08	7.1	9.9	2.4	714	20	M
WWR = 0.25											
Clear IG	0.00	7.3	8.0	—	—	—	—	2.7	589	20	M
Clear IG low-E	0.39	7.0	7.5	0.02	0.04	19.5	9.8	2.5	714	20	M

Table C-4. Commercial Building Fenestration: Costs and Benefits (Continued)

Options ¹	Costs ² (\$/ft ²)	Energy Use ³ (kWh/ft ² /yr)		Cost Savings (\$/ft ² /yr)		Simple Payback ⁴		Peak ⁵ (W/ft ²) (all zones)	Chiller ⁶ (ft ² /ton) (all zones)	Life (yrs)	Confidence
		South	North	South	North	South	North				
HOT CLIMATE (1498 HDD, 2738 CDD)											
WWR = 0.75											
Reflective IG	1.45	8.6	9.3	—	—	—	—	3.6	546	20	M
WWR = 0.50											
Tinted IG (bronze)	0.21	9.0	8.0	—	—	—	—	3.7	465	20	M
Low-E IG (bronze)	1.00	7.8	7.4	0.08	0.04	9.9	19.9	3.5	546	20	M
Tinted IG (green)	0.21	8.2	7.2	0.05	0.06	immediate		3.5	476	20	M
Low-E IG (green)	1.00	7.5	7.0	0.11	0.07	7.2	11.3	3.4	562	20	M
WWR = 0.25											
Clear IG	0.00	7.6	7.3	—	—	—	—	3.4	540	30	M
Low-E IG (clear)	0.39	7.5	7.4	0	0	N/A	N/A	3.3	588	20	

Table C-4. Commercial Building Fenestration: Costs and Benefits (Concluded)

- 1 Options are compared for three different window-to-wall ratios (WWR).¹
- 2 The costs are incremental costs over clear double-paneled glass. They are costs/ft² of floor area and were derived by multiplying the costs in Table C-3 by WWR $\times$ wall area/floor area = WWR $\times$ 85.150 (see footnote 3).
- 3 Energy use is based on DOE2.1 simulations of an office building and represents total energy use per ft² of floor area for heating, cooling, and lighting (assuming daylighting controls are used). The results are for a perimeter zone with various glazings and WWRs. A perimeter zone is a 10-ft-wide by 15-ft-deep by 8.5-ft-high closed office. The simulation assumes that perimeter zones face each cardinal direction surrounding a 100-ft² core zone. Controls are in place to select the amount of electric lights to supplement natural lighting. Shading controls also are employed to control thermal comfort and glare in the simulation whenever the directly transmitted solar radiation exceeds 20 Btu/hr-ft². These data were taken from Sweitzer et al. (1986).
- 4 The simple paybacks were calculated based on energy savings only. Dollar savings is also possible due to reductions in peak demand. In new construction the first cost for cooling equipment may be lower because the equipment needed may be smaller.
- 5 Average number for all five zones simulated (see footnote 3).
- 6 The capital cost of providing one ton of cooling is approximately \$2000. For new construction, each ton of cooling capacity can serve a larger amount of floor area when the glazing options listed above are used. For example, in the cold climate base case with WWR = 0.50, one ton of cooling serves 588 ft², whereas for the low-E IG (green) option, one ton of cooling serves 714 ft². The dollar savings in first cost per ft² of floor area would be $(\$2000/588) - (\$2000/714) = \$0.60$. The cooling equipment savings can be used to offset the added cost of the energy-conserving glazing but was not included in the payback values of this table.

Table C-5. Glazing Characteristics

Glazing Type	R-Value ¹ (hr-ft ² -°F/Btu)	Shading Coefficient	Visible Light Transmission (T _v)	Ratio T _v /SC
Reflective insulating glass (IG) (bronze)	2.5	0.20	0.10	0.5
Tinted IG (bronze)	2.0	0.57	0.47	0.8
Clear single glass	0.9	1.00	0.92	0.9
Clear IG	2.0	0.82	0.80	1.0
Low-E IG (bronze)	3.0	0.42	0.41	1.0
Low-E IG (clear)	3.0	0.66	0.72	1.1
Tinted IG (green)	2.0	0.56	0.67	1.2
Low-E monolithic (green)	0.9	0.53	0.65	1.2
Triple glazing - IG (green) with low-E coated polyester suspended in air space	3.6	0.47	0.58	1.2
Low-E IG (green)	3.0	0.41	0.61	1.5

¹ Based on ASHRAE winter conditions. Source: Sweitzer, G., D. Arasteh, and S. Selkowitz (1986). "Effects of Low-Emissivity Glazings on Energy Use Patterns in Nonresidential Daylighted Buildings." Berkeley, CA: Lawrence Berkeley Laboratory (LBL-21577).

COMMERCIAL BRIEF #2

PASSIVE SOLAR DESIGN

■ DESCRIPTION

The term "passive solar" refers to the integration of many design techniques and materials that enable a building to use the environment to heat, cool, or light its interior. More than 17,000 passive solar commercial buildings have been built throughout the country to date. These designs are characterized by large window areas with advanced glazing materials, a summer-season self-shading form, thermal storage, and natural ventilation. The designs are generally site specific based on climate, function, applicable utility rate structure, and other factors such as owner preference and cost. Passive solar designs provide more than heat. Their use of natural light also reduces the need for artificial light during the day (daylighting), saving electricity directly and reducing cooling loads.

■ DEFINITIONS AND TERMS

CLIMATE-RESPONSIVE DESIGN This is another term often used to describe a passive solar commercial building.

■ APPLICABILITY

BUILDING TYPE New construction

CLIMATE All

DEMAND MANAGEMENT STRATEGY Strategic conservation, peak clipping, valley filling (where thermal storage is used)

■ FOR MORE INFORMATION

Burt Hill Kosar Rittleman Associates and Min Kantrowitz Associates (1987), *Commercial Building Design: Integrating Climate, Comfort, and Cost*. New York: Van Nostrand Reinhold Company.

Table C-6. Passive Solar Design: Costs and Benefits

Options	Added Costs ¹ (\$/ft ²)	Energy Savings ¹ (kWh/ft ² -yr)	Cost Savings (\$/ft ² -yr)	Simple Payback (yr)	Life (yr)	Confidence
Passive solar design	3.30	10.8	0.75	4.4	50+	M

¹ The costs and savings are based on results from 19 small new passive commercial buildings that were built, analyzed and, in a few cases, monitored under a U.S. Department of Energy demonstration program. In each case the energy savings is compared to a simulated "nonsolar" conventional building of the same size located in the same climate and serving the same function. On average these buildings (ranging in size from 3000 ft² to 67,000 ft²) use 40,000 Btu/ft²-yr versus 77,000 Btu/ft²-yr for the conventional alternative. The cost to build these buildings ranged from \$46-\$55/ft². The study concluded that "most climate-responsive, nonresidential buildings do not cost more to build than conventional buildings of the same type." When a passive solar building cost more than its conventional alternative, it did so by less than 10%. The added cost shown in the table is 5% of the cost/ft² midpoint.

COMMERCIAL HEATING, VENTILATING, AND AIR CONDITIONING SYSTEMS

The energy performance of heating, ventilating, and air conditioning (HVAC) systems varies substantially with different energy distribution systems, the hours of operation, and the method of control. Controls can be either direct (e.g., a thermostat based on indoor temperature) or indirect based on outdoor temperature. Figure C-2 shows the relative energy performance of the most commonly used types of HVAC systems. Systems using large-fan horsepower and indirect control to serve large areas require more energy. Those HVAC systems using minimum-fan horsepower and direct controls and serving smaller areas tend to use less energy.

Many commercial buildings are ventilated at a constant volume rather than by a system that matches air flow to their needs. Constant-air-volume, dual-duct, and reheat systems all respond to varying thermal loads by changing the air temperature—for example, by supplying air of a different temperature or by reheating chilled air to the desired level. Variable-air-volume (VAV) systems change the amount of conditioned air flowing to the space without varying the temperature. VAV results in more efficient system operation while saving air transport energy. Conversion kits are available to retrofit the supply air control boxes. In addition, the conversion involves adding adjustable-speed drives to the supply fans. VAV retrofits cited in the literature have good paybacks (less than three years). The cost of the retrofit varies based on the existing system.

(continued)

There are many other limited-function systems. For example, one company has introduced a ventilation preheat system for warehouses and manufacturing plants that uses solar energy incident on the buildings' walls to reduce heating requirements. Ventilation preheat can provide an energy-efficient way to satisfy new federal requirements for increased ventilation levels in certain types of buildings.

In general it takes more energy to move conditioned air through a building than it does to pump heated or cooled liquids. Thus, for new buildings, heating and cooling should be distributed as far as possible in the form of chilled or hot water and converted to chilled or heated air as close as possible to the space being served. This often requires more air-handling equipment than would otherwise be the case, which increases construction costs. In addition to reducing the amount of energy consumed by the building's distribution system, more air-handling systems will allow the disengaging of other systems that are no longer required, further reducing energy consumption.

In this section the following demand management strategies in commercial buildings are covered: (1) ventilation (economizers; heat recovery from exhaust air), (2) cooling (evaporative cooling; cool storage; heat recovery from chillers; high-efficiency air conditioning), (3) heat pumps, and (4) energy management systems.

Very low	Low	Moderate	High	Very high
----------	-----	----------	------	-----------

M11-G5657305

Single zone

Variable volume

Multizone

Dual duct

Reheat

Induction

Fan coil

Unit ventilator

Individual units

Heat pumps

Figure C-2. Relative energy use, common HVAC systems
 Source: Enviro-Management & Research, Inc. Energy Management Handbook. Edlson Electric Institute. Washington, DC (1984).

HEAT RECOVERY FROM EXHAUST AIR

■ DESCRIPTION

Heat recovery in ventilation systems involves transferring part of the heat energy in exhaust air to incoming air. Conversely, heat energy can be transferred from warmer incoming fresh air to cooler air exhausted to the atmosphere to reduce the cooling load. In new buildings, heat recovery can both save fuel costs and lower the initial heating system cost by reducing the size and operation of the heating and cooling system. Four heat-recovery devices are currently in use: run-around coils, plate exchangers, rotary exchangers, and heat pipes.

■ DEFINITIONS AND TERMS

RUN-AROUND COILS The air being exhausted is passed through a recovery coil, and a hydronic circulating system transfers the recovered sensible heat to a preconditioning coil in the supply air stream. An antifreeze solution is normally used to prevent freezing. The advantage of this type of system is that the supply and return air ducts do not need to be adjacent. This allows its use for retrofits.

PLATE-TYPE EXCHANGERS Sensible heat is transferred from one air stream to another through direct contact on either side of a metal heat-transfer surface. Because of lower temperature differences, these are not used for cooling applications. This type of heat exchanger does not require an external power source and has no moving parts.

ROTARY HEAT EXCHANGER A rotary air-to-air heat exchanger or heat wheel is a revolving cylinder packed with coarsely knitted metal mesh or a desiccant-

impregnated material. As the cylinder is rotated, adjacent streams of exhaust air and incoming air pass through it. Sensible and latent energy absorbed by the heat-transfer media is transferred from one air stream to the other. Heat wheels are available in sizes ranging from 250 to 60,000 cfm.

HEAT PIPE A heat pipe is a small pipe with a liquid-filled wick. The pipe is charged with a low-temperature vaporizing fluid and the ends are sealed. The heat pipe is essentially a closed refrigeration cycle. When one end is heated, the fluid evaporates and moves to the colder end. There it condenses, and the cold fluid migrates by capillary action back to the warm end. As long as there is a temperature difference, the cycle will continue. The heat pipe has many advantages. It has no moving parts and requires no external power source. It is smaller than conventional heat recovery units. It requires that supply and exhaust ducts be adjacent. Its big disadvantage is its relatively high cost.

■ **APPLICABILITY**

BUILDING TYPE Heat recovery is best applied in buildings with large ventilation loads such as restaurants, commercial kitchens, office buildings, schools, and hospitals.

CLIMATE All

DEMAND MANAGEMENT STRATEGY Strategic conservation

Table C-7. Heat Recovery From Exhaust Air: Costs and Benefits

Options	Costs (\$/10 ³ cfm)	Energy Savings (kWh/10 ³ cfm/yr)	Cost Savings (\$/yr/10 ³ cfm)	Simple Payback (yr)	Life (yr)	Confidence
Heat exchanger ¹	3760	17000	1190	3.1	20	L

¹ Cost and savings vary by application. The numbers in this table represent the average of numbers found in one company's product literature for a rotary heat exchanger and analysis for two office buildings in cold climates. In one building the system was a run-around; in the other it wasn't defined. Run-around systems and heat pipes are the most expensive of the systems listed. If the supply and return air streams are not adjacent, a run-around coil is the only option that will work. Likewise, if size is a critical factor, a heat pipe may be the only option. Plate and rotary systems cost about the same for air exchange rates of 70-100 cfm. For higher flow rates, the rotary is less expensive. In temperate climates run-around systems have poor paybacks.

OUTSIDE AIR ECONOMIZERS

■ DESCRIPTION

An economizer brings in outside air when it is cool and dry, thereby reducing the use of chillers. Percentage savings from economizers depends on outside temperature, internal and external building loads, and HVAC system performance. Performance is higher in buildings in mild climates, using systems with higher internal loads or large glass areas, and when minimum supply air temperatures are higher.

An economizer consists of indoor and outdoor temperature and humidity sensors, dampers, motors, and motor controls. ASHRAE 90 standards require economizers on all new buildings. Recently issued ASHRAE standards (62-1989) include higher ventilation rates than previously recommended. For smaller systems (packaged units), economizers can be bought off the shelf. For larger applications, the controls and dampers are custom designed. Generally, one economizer control system is required for each separate air distribution system. In some cases economizers cannot be installed because there is not enough space to install an outside air damper large enough to bring in 80%–100% outside air. Similarly, it may not be possible to retrofit some packaged air conditioning units with economizers.

■ DEFINITIONS AND TERMS

ASHRAE American Society of Heating, Refrigerating, and Air Conditioning Engineers

■ APPLICABILITY

BUILDING TYPE Applicable to all commercial building types—new, retrofits, and renovations. In several

situations economizers are not advantageous, including in space that is being humidified or that uses heat recovery systems or air-mixing-type air handling systems such as dual duct and multizone.

CLIMATE Most applicable to temperate climates. Savings is much smaller in extremely hot or humid climates.

DEMAND MANAGEMENT STRATEGY Strategic conservation

Table C-8. Outside Air Economizers: Costs and Benefits

Options	Retrofit Costs ¹ (\$/ton)	Energy Savings ² (kWht/ton)	Cost Savings (\$/yr/ton)	Simple Payback (yr)	Life (yr)	Confidence
Outside air economizer:	62.50	162-1785	11.5-125	5.5-0.5	10-20	L

1 Exact costs are highly site specific and tend to show economies of scale. The cost of an economizer per peak ton of cooling capacity decreases with cooling system size and can vary considerably depending on the cooling system and ease of installation. The estimated installed cost of an economizer control per peak ton of cooling capacity ranges from \$125/ton for 5-10 tons, \$62.50/ton for 15-20 tons, to \$35 for 100+ tons. In this example, the cost is assumed to be in the mid-size range.

2 Savings in cooling energy usage ranges from 38% (hot climate—Fresno, CA) to 40% (moderate climate—Los Angeles) to 60% (mild climate—San Francisco). These percentages are based on a constant-volume HVAC system. Savings will be considerably less with a variable-volume system. Cooling loads typically range from 1-7 kWht/ft²/yr. For this table, savings was calculated for two extremes: 38% of 1 kWht/ft²/yr and 60% of 7 kWht/ft²/yr. It is assumed that one ton of cooling supplies 425 ft² of floor area to make the cost and savings units consistent. In addition, with an economizer, there may be a first-cost saving (not included in the analysis shown in the table) from reductions in chiller, cooling tower pump and fan, and chilled water circulation pump.

COMMERCIAL BRIEF #5

EVAPORATIVE COOLING

■ DESCRIPTION

An evaporative cooling process removes heat by evaporating water. Evaporative cooling techniques are most effective in warm, dry climates. Evaporative cooling systems require 100% outside air intake capability. Systems should be set up with economizer controls. There are three basic types of evaporative cooling systems for commercial buildings:

DIRECT In this type, the air stream is brought in direct contact with water (from sprayers, or by passing the air through a wetted medium). As the air stream uses its heat to evaporate the water, the sensible heat of the stream drops, lowering the dry-bulb temperature but increasing the moisture content of the air (humidity ratio).

INDIRECT There are several ways to do indirect evaporative cooling. One way relies on a heat exchanger. The air supplied to the building is sensibly cooled by passing it by a separate stream which has been cooled using the direct process. The most typical configuration consists of a set of metal air-to-air plate heat exchangers. The building air is sent through the heat exchanger; outside air is passed over the wet side, which is sprayed with water. An indirect cooler requires an additional (wet-side) fan and a water pump. Another approach uses a cooling coil in combination with a remote cooling tower. This requires piping and automatic valves to connect the chilled water system to the cooling tower. A filter is needed to keep impurities in the cooling tower water from entering the chilled water loop. During cooler months and/or night operation, cooling towers can produce water cold enough to be used in the building's chilled-water loop.

COMBINATION (TWO-STAGE COOLER) The building air stream is sensibly cooled through an indirect cooler (reducing dry-bulb temperature only) and is further cooled (and moisture added) with a direct cooler. For more humid climates, a small refrigerated chiller can be added to ensure comfort on very hot days.

■ **APPLICABILITY**

BUILDING TYPE All spaces except those requiring strict humidity control unless a humidity controller is installed as well. Evaporative cooling is generally recommended for schools in the southwestern states.

CLIMATE Direct evaporative cooling works best in hot arid climates. Indirect evaporative cooling also works well in areas of higher humidity. Indirect/direct evaporative cooling backed by downsized mechanical refrigeration can work well in a larger area of the United States.

DEMAND MANAGEMENT STRATEGY Strategic conservation, peak clipping

■ **FOR MORE INFORMATION**

Supple, R. (Aug. 1982), *Evaporative Cooling for Comfort*. ASHRAE Journal.

Scolfield, M. (June 1980), *EBTR Compliance and Comfort Cooling Tool* ASHRAE Journal.

Evaporative Cooling Institute, P.O. Box 3ECI, Las Cruces, NM 88003.

Table C-9. Evaporative Cooling: Costs and Benefits

Options	Costs (\$) ¹ (\$/ton)	Energy ² Savings (kW/ton)	Cost Savings (\$/ton/yr)	Simple Payback ³ (yr)	Life (yr)	Confidence
Refrigerated air conditioning	650	—	—	—	20	
Direct evaporative cooling	650	1241	67	23	5-20	M
Indirect-direct evaporative cooling	1275	1150	80.5	7.8 [6.0-8.3]	5-20	M

1 The cost for refrigerated air conditioning varies. The larger the unit, the lower the cost per ton. Based on a manufacturer's estimate, the cost range is \$550-\$750 per ton for a 25-30-ton system. The installed cost for a top-of-the-line evaporative cooling system (including all system components except duct work) is approximately \$2,000/cfm. Assuming one ton of air conditioning serves 425 ft² of floor area and 1 cfm of air is required per ft² of floor space, the cost for the direct evaporative cooling system equals approximately \$850 per ton. The cost for the top-of-the-line complete indirect-direct evaporative cooling system is \$3,000/cfm or \$1,275 per ton.

2 Based on engineering analysis found in the information sources listed in the brief, savings for direct indirect evaporative cooling are reported as kilowatts of power required for the evaporative system versus mechanical cooling for three cities as follows: Tucson, 0.22 kW/ton vs. 1.46 kW/ton; Albuquerque, NM, 0.31 kW/ton vs. 1.46 kW/ton; Denver, CO, 0.157 kW/ton vs. 1.0 kW/ton. The savings in the table is based on Albuquerque, with a payback range given in brackets for Tucson and Denver. One thousand cooling load hours were assumed for Albuquerque, 800 for Denver, and 1200 for Tucson (based on Figure R-7 in Volume 1 (Residential)). Calculations for savings are as follows: $(1.46 - 0.31 \text{ kW/ton}) \times 1000 \text{ hrs} = 1150$. Savings for direct evaporative cooling as reported elsewhere is 80%-90% of mechanical cooling in the southwestern U.S. The savings reported in the table is 0.85 (1.46 kW/ton) $\times$ 1000 = 1241.

3 The simple payback is based on the incremental cost for evaporative cooling over mechanical cooling. It is based on savings in energy only, although there is demand savings as well. The payback range is for the southwestern U.S. only.

Note: Added maintenance is required for direct evaporative cooling systems. This is not reflected in the costs or payback.

COOL STORAGE**■ DESCRIPTION**

Commercial space cooling currently accounts for about 20%-40% of most utilities' summer peak demand. Cool storage is a technique for shifting all or part of a building's air conditioning requirements from peak to off-peak hours. Refrigeration equipment is typically operated at night to make ice or chilled water which is stored in insulated tanks and used the next day to meet all, or part of, a building's cooling requirements.

The use of thermal storage in commercial buildings has grown steadily in the past decade. Today, there are more than 1000 cool storage systems in the United States. Cool storage systems can use ice, chilled water, or phase change materials. Water and ice are by far the most common. Systems can be designed for full storage, in which 100% of the cooling load is moved off peak, or partial storage, in which only part of the load is moved off peak and the rest is met by the chiller. A comparison of ice versus chilled water is found in Table C-11.

Most cool storage systems are installed in buildings during construction. Cool storage systems can be retrofit into existing buildings, although the cost is higher and the installation may be difficult. Also, chilled water systems, in particular, take up substantial amounts of floor space. Packaged cool storage systems, which are now being marketed by a number of manufacturers, facilitate retrofit of cool storage systems in medium-sized buildings. This development should expand the potential market for cool storage systems.

Operating savings in electricity charges is greatest when demand or energy charges vary by time of day. For new buildings, first-cost savings from downsizing the

chiller capacity, and operating-cost savings due to lower demand, pay for some—and in some cases all—of the costs of storage. Because of lower operating temperatures fans, pumps, and ducts can also be downsized, further reducing first costs.

■ **APPLICABILITY**

BUILDING TYPE Cool storage is most effective in buildings that have a high, narrow cooling load profile during a utility's "on-peak" period. Office, retail, and health facilities are prime candidates, followed by schools, colleges, restaurants, and lodging facilities. The use of an economizer significantly reduces year-round peak- and energy-shifting potential. Because existing chillers can be used with chilled water systems, these systems may suit retrofit applications better than ice storage systems do.

CLIMATE All

DEMAND MANAGEMENT STRATEGY Load shifting, valley filling

■ **FOR MORE INFORMATION**

Electric Power Research Institute (1984), "Commercial Cool Storage Primer" (EM-3371), Palo Alto, CA: EPRI.
Electric Power Research Institute (1986), "Commercial Cool Storage: Presentation Materials" (EM-4405), Palo Alto, CA: EPRI.

Pietto, M. A., E. Wyatt, and J. Harris (1988), "Technology Assessment: Thermal Cool Storage in Commercial Buildings," Berkeley, CA: Lawrence Berkeley Laboratory.

Table C-10. Cool Storage: Costs and Benefits

Options	Retrofit Costs (\$) ¹ (Installed)	Energy Savings ² (kW/ton)	Cost Savings ³ (\$/yr)	Simple Payback ⁴ (yr)	Life (yr)	Confidence
Chilled water, partial storage	75 ton-h	1.0	18.00	4.1 [12.5-2.5]	20	M
Ice, partial storage	100 ton-h	1.0	18.00	5.5 [16.2-3.3]	20	M

1. Cost for chilled water ranges from \$25-125 ton-h; cost of ice storage ranges from \$50-\$150 ton-h of capacity. The cost per ton-hour decreases as the system size increases. For new construction, some of the added cost for cool storage can be offset by decreased first costs for chiller equipment.

2. The energy savings is based on a system bigger than 200 tons.

3. 1 ton = 12,000 Btu/h x (1 kWh/3,413 Btu) x (1 kWh/4.0 kWh) (COP) = 1.0 kW. Full cool storage offsets 100% of the 1.0 kW load. The cost savings was calculated for a moderate demand charge of \$6.00/kW. It is assumed that the savings will occur for three summer months: 3 x [1.0 kW x 6.00 kW] = \$18.00.

4. A payback range is given in brackets based on a utility demand charge of \$2.00/kW to \$10/kW.

Table C-11.
Ice Versus Chilled Water Storage
(assuming identical cooling loads)

Characteristic	Ice	Chilled Water
Space requirements	One-fourth to one-third of chilled water	Large
Compressor size availability	Limited ¹	Various
Design and operating experience ²	Limited	Widely available
Size flexibility	Good, modular	Limited
Design constraints ³	Few	Many
Air distribution, first costs	Low	Moderate
Packaged systems availability	Good	Limited
Interfacing with existing systems	Complicated	Simple
Heating capability	Poor	Good
First cost for large systems ⁴	Varies	Varies
Power requirements	0.85–1.5 kW/ton	0.75–1.25 kW/ton
Chilled water pumping power	Low	High
Heat loss	Low	Moderate
Maintenance ⁵	Moderate	High
Warranty availability	Good	Limited

1 Many ice storage units require direct-expansion units, which generally require recharging of screw compressors. These are not available in very large sizes. Chilled water storage systems often use centrifugal compressors.

2 Ice storage systems often require large direct-expansion or flooded-coil refrigeration systems with which building designers and operators apparently are not familiar.

3 Chilled water storage systems require wider temperature ranges and thus require controls with which many designers are unfamiliar.

4 Smaller ice storage systems (less than 2000 ton-h) have lower first costs per unit capacity than water storage systems. Water storage systems become more competitive in larger sizes.

5 Maintenance requirements are site and installation specific. Because ice systems do not have the extra circulating pumps and heat exchangers that water systems do, maintenance costs may be lower for ice systems.

Source: Pottle, M. A., E. Wyatt, and J. Harris (1988), "Technology Assessment. Thermal Cool Storage in Commercial Buildings." Berkeley, CA: Lawrence Berkeley Laboratory.

HEAT RECOVERY FROM CHILLERS

■ DESCRIPTION

One way to increase the efficiency of HVAC systems in large commercial buildings is to use double-bundle chillers. Double-bundle chillers are similar to conventional chillers, except that two circuits are available in the condenser for rejecting heat. One circuit is used to reject heat in the conventional way (such as to a cooling tower). The second circuit is for space heating or service water heating. This saves energy when the building requires heat and cooling at the same time.

■ APPLICABILITY

BUILDING TYPE Double-bundle chillers are not usually good candidates for retrofits. They are applicable to new commercial buildings that require simultaneous heating and cooling much of the time during operating hours. Buildings that use economizers for cooling with outside air during heating periods may not be suited to double-bundle chillers, because chillers will not be running or will be running at low loads when the economizer is operating, and will be rejecting little heat.

CLIMATE All

DEMAND MANAGEMENT STRATEGY Strategic conservation

■ FOR MORE INFORMATION

- Usibilli, A., et al. (1985), "Commercial-Sector Conservation Technologies." (LBL-18543). Berkeley, CA: Lawrence Berkeley Laboratory.

Table C-12. Heat Recovery From Chillers: Costs and Benefits

Options	Added Costs ¹ (\$ per ton)	Energy Savings (kWh/yr/ton)	Cost Savings ² (\$/ft ² /yr)	Simple Payback (yr)	Life (yr)	Confidence
Double-bundle chillers	125	225	15.75	7.9	20	L

1 The added cost over a conventional chiller ranges from \$50 to \$200 a ton.
 2 Based on a DOE-1 simulation for Los Angeles, 4.95 kBtu/ft²/yr of heat was available for recovery. 1.45 kWh/ft²/yr would be needed to supply this heat using electricity. In addition, the double-bundle chiller used 0.92 kWh/ft²/yr more energy than the conventional chiller because the full-load coefficient of performance of a double-bundle chiller is up to 30% less than that of a conventional centrifugal chiller. The net savings is 0.53 kWh/ft²/yr or 225 kWh/ton. (One ton cools approximately 425 ft².)

HIGH-EFFICIENCY AIR CONDITIONING

■ DESCRIPTION

Air conditioning in commercial buildings can be supplied by either a unitary or a component-based system. In unitary systems, all the air conditioning components—including the compressors, condenser and evaporative heat-exchange coils, refrigeration expansion devices, fans, and controls—are assembled into a package. Unitary systems have a nominal cooling capacity up to 30 tons. These systems are only used in smaller commercial buildings, typically those under 15,000 ft². The most common unitary systems are single-packaged, split-system, and packaged terminal systems. Equipment manufacturers generally offer only energy-efficient models (rather than a standard and an energy-efficient model) with EERs in the range of 8–9. The cost range for a 30-ton system is between \$550 and \$750 per ton. For more information on unitary systems under five tons, see brief #13 in Volume 1, residential air conditioning.

Component-based systems are used to provide air conditioning in larger buildings. They are generally engineered for a specific site. It is difficult to generalize cost and savings information for these systems because of the variety of equipment and system configurations available. A water-cooled chiller is more energy efficient than an air-cooled chiller. Strategies to save energy and reduce demand generally involve reducing the number of hours that the chiller is operating. This can be done through the use of economizers, direct and/or indirect

evaporative cooling, cool storage, and various control strategies. In addition, energy-efficient lighting, the use of daylighting, and appropriate selection of glazing and window treatments can reduce building cooling requirements. These topics are covered elsewhere in this guide. In new construction, if the building cooling requirements are reduced through the use of these strategies, cooling equipment can be downsized and therefore will cost less. For existing systems, cooling system maintenance represents an opportunity for savings. Basic maintenance such as cleaning condensers, changing filters, oiling the bearings, and fixing refrigerant leaks can often save up to 1 kWh/ft²/year.

■ DEFINITIONS AND TERMS

ENERGY-EFFICIENCY RATIO (EER) This is used to compare the performance of cooling equipment including air conditioners and heat pumps in the cooling season. EER is calculated by dividing cooling capacity (in Btu/h) by the power input (in watts) under a given set of rating conditions.

SINGLE-PACKAGED UNITS In unitary-system units, components and controls are packaged in one factory-made assembly, and the assembly is mounted on the roof of a building. Cooled air is distributed to the space through ducts.

SPLIT-SYSTEMS These are the most popular systems for small commercial buildings. They typically have an indoor and an outdoor section connected by refrigerant tubing and a thermostat. The outdoor section generally houses the compressor fan, condenser coil, and controls.

PACKAGED TERMINAL UNITS These are designed to serve a room or a zone. They are intended for through-the-wall applications. Their capacities range from 0.5 to 1.5 tons.

■ **APPLICABILITY**

BUILDING TYPE New and retrofit commercial buildings. Energy-efficient packaged rooftop-type air conditioning units are particularly well suited for single-story buildings such as schools, banks, bowling alleys, office buildings, department stores, and motels.

CLIMATE All

DEMAND MANAGEMENT STRATEGY Strategic conservation

HEAT PUMPS

■ DESCRIPTION

Both air-source and closed-water-loop heat pumps are applicable for use in commercial buildings. The reader is referred to Volume 1, brief #9, for information on residential air-source heat pumps and for definitions; the present brief covers only water-loop heat pumps.

In multiroom buildings, a closed-water-loop heat pump provides year-round space conditioning through "balanced heat recovery." In the system, internal heat gains are collected and redistributed to meet immediate heating requirements in the building perimeter zones, or they are stored in the form of warm water for future use. Supplemental heat can be provided from storage or from an external source. During the cooling season, cool water also can be stored to help reduce cooling demand during peak periods. Studies show that these systems save energy with or without storage.

A water-loop heat pipe typically uses a two-pipe closed-water-loop supply-and-return circuit that circulates continuously at a temperature between 60°F and 90°F. During warm weather most or all of the units in the building operate in the cooling mode, removing heat from the conditioned space and transferring it to the water loop. If heat needs to be rejected, a cooling tower or other equipment is used. During cold weather, most perimeter water-source closed-loop heat pumps, typically averaging about two tons capacity, operate in the heating mode, transferring heat from the water loop to the conditioned spaces. In most instances, core-area units will still be operating in a cooling mode, adding enough heat to the loop water to meet perimeter-area heating requirements. When the loop water falls below a specified temperature, heat is added to the loop from

either thermal storage or from a supplemental source to maintain minimum loop temperature.

■ DEFINITIONS AND TERMS

ENERGY-EFFICIENCY RATIO (EER) This is used to compare the performance of cooling equipment including air conditioners and heat pumps in the cooling season. EER is calculated by dividing cooling capacity (in Btu/h) by the power input (in watts) under a given set of rating conditions.

COEFFICIENT OF PERFORMANCE (COP) This is used primarily to compare the performance of heat pumps in the heating cycle. For this use, it is determined by dividing the total heating capacity provided (Btu), including the circulating fans but not including supplemental heat, by the total electrical input in watt-hours and multiplying by 3.413. The higher the COP, the more efficient the heat pump.

HEATING PERFORMANCE FACTOR (HPF) HPF and COP are terms that are often used interchangeably. Performance factor is a measure of COP at various outdoor temperatures. Standard ratings call for two conditions, "high-temperature heating" and "low-temperature heating." In both cases, the air entering the indoor coil is at 70°F with a maximum 55% relative humidity. The high-temperature conditions require that the air entering the outdoor coil be at 47°F. The low-temperature conditions require it to be at 17°F. The HPF allows comparison of the efficiency of fossil-fuel furnaces and heat pumps.

SEASONAL ENERGY-EFFICIENCY RATIO (SEER)

The ratio of the total seasonal cooling requirement measured in Btu to the total seasonal watt-hours (Wh) of energy used, expressed in terms of Btu/Wh. (The SEER rating equals 3.413 times the seasonal COP.)

■ **APPLICABILITY**

BUILDING TYPE New and/or renovated commercial buildings. Good candidate buildings for this system include office buildings, shopping centers, radio and television complexes, university campuses, apartments, medical buildings, nursing homes, schools, and dormitories. This system is applicable in buildings where simultaneous heating and cooling occur and where high internal heat loads exist.

CLIMATE Climates that do not have extreme winters or summers are best suited for water-loop heat pump systems.

DEMAND MANAGEMENT STRATEGY Peak clipping, strategic conservation, strategic load growth

■ **FOR MORE INFORMATION**

Pietsch, J. A. (1988), "Water-Loop Heat Pump Systems: Assessment Study." Electric Power Research Institute, Palo Alto, CA: EM-5437.

Table C-13. Heat Pumps: Costs and Benefits

Options	Installed Costs ¹ (\$/ton)	Energy Uses ² (kW/yr)	Cost Savings (\$/yr)	Simple Payback (yr)	Life (yr)	Confidence
Four-pipe fan-coil system with reciprocating air-cooled chiller	2130	—	—	—	20	M
Two-pipe VAV system with reciprocating air-cooled chiller	1630	—	—	—	20	M
Water-loop heat pump	1500	Cooling: Same Heating: 38%–75% lower	—	Immediate	15	M

1 Cost and performance information was taken from Pleiston, cited in this brief. Costs are compared for two systems plus water-loop heat pumps. The systems are based on 100 tons of cooling capacity. The cost is for new construction. The cost of a retrofit water-loop heat pump ranges from 68% to 100% of the cost of a new system. It is less than the cost for the new system when usable components and distribution systems of a central system can be salvaged.

2 The cooling energy requirements for the central and water-loop heat pump (WLHP) systems are equivalent. If an electric boiler is used, the energy and cost for the WLHP will be 38%–75% less than the central system. If a gas boiler is used in both the WLHP and central system, the WLHP will be less costly to operate only if the building requires simultaneous heating and cooling at least 40% of the time. The choice also depends on the relative prices of gas and electricity.

ENERGY MANAGEMENT SYSTEMS

■ DESCRIPTION

Automatic energy management controls provide planned load scheduling, cycling, and shedding to reduce energy consumption and peak demand. Many types of energy management controls are available. They can be classified into the following generic categories:

- Single-function systems
- Stand-alone, multifunction, microprocessor-based systems
- Central-station, multifunction, distributed-intelligence systems
- Fully distributed systems.

The first category is generally applicable to buildings under 10,000 ft². The second category is applicable to buildings between 10,000 ft² and 50,000 ft². The third and fourth categories are generally applicable to larger buildings. A number of smaller pieces of equipment can be purchased individually for energy management and demand control. They include timers, schedulers, duty cyclers, and interlocks (priority relays). These devices are used in agricultural applications as well as in commercial buildings.

The first category includes manual electromechanical controllers that can be supplemented by pneumatic equipment. Limited to one or two control points within an energy system, this group can only control one of the following functions: start/stop control, optimal start/stop, economizer control, enthalpy control, or supply temperature reset. The actual control apparatus is self contained and located near the equipment being controlled.

Systems in the second category are microprocessor based and designed to perform several functions. They

generally have from 8 to 16 control points. Functions available include start/stop control, temperature setback/setup, demand control, duty cycling, and monitoring/alarm.

■ DEFINITIONS

DUTY CYCLERS In addition to on/off switching, these devices control the percentage of the appliances' "on" time within a given period of time.

ECONOMIZER CONTROL When conditions permit, the economizer control measures the dry-bulb temperature of the return air and the outside air and selects an appropriate amount of cooler outdoor air for building conditioning by adjusting outdoor supply and return air dampers.

SCHEDULERS More sophisticated than timers, schedulers control multiple circuits on an hourly, weekly, or seasonal basis.

INTERLOCKS A simple logic board and one or more circuit sensors designed to prevent the simultaneous operation of two or more energy-consuming devices.

START/STOP This is a programmed function to shut down electrically operated equipment when it is not required. Of all energy management system functions, this one generally yields the highest return on investment.

START/STOP OPTIMIZATION This function optimizes starts/stops for HVAC equipment. Start and stop times are computer controlled to maintain comfort levels based on measurement and comparison of outdoor air temperature, solar effects, indoor temperatures, indoor humidities, and consideration of building mass.

SUPPLY AIR RESET When heating or cooling is required, most HVAC systems supply a constant water or air temperature. These temperatures are established to satisfy peak heating and cooling requirements. Much of the time energy can be saved by adjusting or resetting supply air and water temperatures proportionately to reductions in heating and cooling loads.

TEMPERATURE SETBACK/SETUP This provides an adjustment in building temperature when the building is unoccupied.

TIMERS Simple devices that turn equipment on or off at certain times.

■ **APPLICABILITY**

BUILDING TYPES All commercial, new, and retrofit. In general, energy management systems have not been widely adopted as retrofit measures, except for time clocks, time clock thermostats, and possibly demand limiters. In new construction, they have been included as original equipment.

CLIMATE All

DEMAND MANAGEMENT STRATEGY Peak clipping, strategic conservation.

■ **FOR MORE INFORMATION**

Electric Power Research Institute (1987), *Energy Management for Commercial Buildings*. New York: Hemisphere Publishing Company.

Table C-14. Energy Management Systems: Costs and Benefits

Options	Costs (\$) ¹	Energy Savings (kWh/yr)	Cost Savings ² (\$/yr)	Simple Payback (yr)	Life (yr)	Confidence
Single-function controls (based on a 1000-ft ² building)	300	2790	195	1.5	10	M
Single-function controls (based on a 5000-ft ² building)	2,000	9300	651	3.0	10	M
Stand-alone multifunction systems (based on a 30,000-ft ² building)	8,000	48000	3360	2.4	10	M

¹ Representative installed cost for each size of building listed. For medium and large multifunction systems, costs are often listed in terms of \$/control point. Costs typically range from \$200 to \$1200 per control point.

² Based on an EPRI survey of 200 EMS users, the savings from an energy management system is approximately 15% of building energy use. The average electricity use for each building size listed was based on the Energy Information Administration's (EIA) Commercial Building Consumption 1986.

LIGHTING

Retail and office buildings and warehouses are all big users of electricity for lighting. Retail buildings are the largest single user of lighting energy in the service territory of two of the largest California utility service districts. They are also one of the largest users of incandescent lighting, especially for display lights and spotlights. Color is an important element in lighting design and retail marketing efforts. This may limit the applicability of fluorescent retrofits in retail buildings except perhaps for lamps with higher-quality color.

Office buildings also require significant lighting. They typically use fluorescent lamps, most of which (80%-90%) are 40 watts and 4 feet long. Although many offices have already "delamped" (switched to lower-wattage lamps and conducted other lighting conservation measures), significant conservation potential remains in office lighting.

Because color is not a major concern, warehouses can use high-intensity-discharge lamps. In addition timers, occupancy sensors, and centralized lighting controllers used with fluorescent lighting can yield major energy and power savings in warehouses.

Hotels and motels are the largest users of incandescent lighting of any of the major commercial building types. Energy-efficient substitutes for incandescent lamps are covered in Volume 1 (residential).

(continued)

Retrofits to lighting systems save cooling energy as well as lighting energy. One kilowatt of lighting input produces 3413 Btu of heat. Depending on the type of lighting fixture, between 60% and 80% of this heat appears as a room load. The remainder is rejected from the ballast and top surface of the lighting fixture into the ceiling plenum air space and exhausted to the outside. Reducing the power for lighting will reduce the sensible cooling load in the room but will increase heating loads slightly. Significant reductions in cooling equipment and its capital and operating costs can be achieved through more efficient lighting; however, these savings are not quantified here because they are so variable.

Demand management opportunities discussed in this section include energy-efficient replacements for standard fluorescent lamps; high-intensity-discharge lamps for buildings, parking garages, and street lighting; lighting controllers; and dimming systems to integrate natural and electric light.

FLUORESCENT LAMPS**■ DESCRIPTION**

When comparing lighting options, it is important to consider the quantity of light (in lumens) provided by the lamp or fixture, the wattage, and the quality and distribution of the light. For example, areas in which visual display terminals (VDTs) are used require less overall light from above, and VDT operators are particularly sensitive to glare. The retrofits described below rely on lamps, ballasts, and fixtures that are more efficient than standard lighting products. By using these products a building owner may be able to maintain a proper illumination level using significantly less power.

■ DEFINITION AND TERMS

BALLAST A device used to start and operate gaseous-discharge lamps. Ballasts are either electromagnetic (also called core-coil) or electronic (also called solid-state). An electromagnetic ballast can be either standard or high efficiency. Standard ballasts can no longer be sold in California, Massachusetts, Florida, or New York, where building codes require the use of at least high-efficiency electromagnetic ballasts. Electronic ballasts are a newer class of ballasts. They generally reduce flicker and improve ballast/lamp system efficacy by 20%–25% over a standard electromagnetic ballast. Hybrid electronic ballasts can increase harmonic distortion of the power supply.

BALLAST FACTOR This is the ratio of lumens produced by a lamp with a given ballast divided by the manufacturer's rated lamp lumens. It differs for various lamp/ballast combinations. Ballasts approved by the Certified Ballast Manufacturers Association must have a ballast factor of at least 95% ($\pm 2.5\%$) of the

manufacturer's output for a standard F40, rapid-start, argon-filled lamp.

COLOR RENDERING An expression for the effect of a light source on the color appearance of objects in comparison with their color appearance under a reference light source. The Color Rendering Inde., (CRI) is a scale from 1-100 that measures lamp color rendering. The higher the number, the better the lamp's color-rendering properties.

EFFICACY The amount of light produced (in lumens) for a given amount of power input to the lamp and ballast (lumens/watt). The higher the efficacy, the less energy required to achieve a given illumination level. Technical options to improve the efficacy of a lamp include the use of smaller-diameter lamps (which increases the lamp surface-to-volume ratio), advanced phosphors, and an internal reflector coating between the glass tube and the phosphor coating.

F40T12CW A specification for a standard fluorescent lamp. F stands for fluorescent; 40 means 40 watts (40-W lamps are four feet long; approximately 70% of fluorescent lamps in the United States meet this description); and T12 refers to the tube diameter in eighths of an inch ($12 = 12/8$ or 1.5 in.). The last two letters stand for the color temperature of the lamp. CW stands for cool white, WW stands for warm white, and D stands for daylight. An example specification for a high-efficacy lamp might be F32T8CW.

LUMEN Quantity of light emitted from a light source. Footcandles = lumens/square feet of area.

SPECULAR IMAGING REFLECTORS Specular reflectors have mirrorlike characteristics. The most common materials are aluminum and silver. Silver has the highest reflectivity; aluminum has the lowest cost. The materials and shape of the reflector are designed to reduce absorption of light within the fixture while delivering light in the desired angular pattern. Specular reflectors added to existing light fixtures may change the light distribution characteristics of the fixture.

■ **APPLICABILITY**

CLIMATE REGIONS All

BUILDING TYPES All

DEMAND MANAGEMENT OBJECTIVE Strategic conservation, peak clipping

■ **CALCULATION PROCEDURE**

To determine the demand and energy impact of a retrofit, compare the existing lighting to the proposed retrofit as follows:

Demand: Number of fixtures $\times$ wattage per fixture (lamps plus ballast).

Energy: Number of fixtures $\times$ wattage per fixture (lamps plus ballast) $\times$ yearly number of hours the lamps are on.

See the sample calculation for one fixture in the footnote to Table C-15.

■ **FOR MORE INFORMATION**

California Energy Commission (March 1990), "Advanced Lighting Guidelines." Sacramento, CA (pub. no. 400-90-014).

Piette, M. A., F. Krause, and R. Verderber (March 1989), "Technology Assessment: Energy-Efficient Commercial Lighting." Lawrence Berkeley Laboratory (LBL-27032).

Illuminating Engineering Society, 345 E. 47th Street, New York, NY.

Table C-15. Lighting: Costs and Benefits
(on a per-fixture basis)

Options ¹	Retrofit Costs (\$) ² (Installed)	Power ² (W/fixture)	Cost Savings ³ (\$/fixture/yr)	Simple Payback (yr)	Relative Light Output (%)	Life (hours)	Confidence
Two standard ballasts, four lamps	30.00	184	—	—	100	20,000 (lamps)	H
Replace lamps with high-efficacy lamps	18.00	153	9.30	0.9 ⁴	93	20,000	H
Replace two ballasts with one electronic ballast	66.00	135	14.68	3.1	104	45,000 (ballast)	H
Remove two lamps, add reflector	65.00	88	28.75	2.3	65 ⁵	132,000 (reflector)	H
Remove two lamps; add reflector and electronic ballast	104.00	64	35.90	2.9	63 ⁵	see above	H

Table C-15. Lighting: Costs and Benefits (Concluded)
(on a per-fixture basis)

- 1 A typical conservation measure is to replace 40-W lamps with 34-W T-8 lamps. This option is not included because the reduction in light is approximately equal to the reduction in power input. Thus the efficacy of the lamp remains virtually the same.
- 2 The cost is installed cost. The cost for two standard ballasts is \$20.00; for four standard lamps, \$10.00. One electronic ballast that controls two lamps is \$39.00; one that controls four lamps is \$66.00; a reflector is \$65.00; and the high-efficiency lamps are \$4.50 each.
- 3 Cost savings per fixture was calculated assuming that lamps are used 3744 hr/yr ($12 \text{ h/d} \times 6 \text{ d/w} \times 52 \text{ w/yr}$) at an average cost of \$0.07/kWh. The base case cost is $164 \text{ W/fixture} \times 3744 \text{ hr/yr} \times 0.07 \text{ kWh} = \$48.22/\text{fixture/yr}$. Savings in cooling load costs is not included.
- 4 Payback in this case only is based on the incremental cost of \$8.00 (\$18.00-\$10.00) for the high-efficiency lamps (assuming that the retrofit will be performed when the lamps need replacing). In all the other cases, the payback is based on full replacement costs.
- 5 This is relative fixture light output rather than lamp output only.

Table C-16.
IES Illuminance Recommendations
(footcandles)

Type of Activity	Illuminance Range
Public spaces with dark surroundings	2-5
Simple orientation for short temporary visits	5-10
Working spaces where visual tasks are only occasionally performed	10-20
Performance of visual tasks of medium contrast or small size	50-100
Performance of visual tasks of low contrast or very small size	100-200
Performance of visual tasks of low contrast and very small size over a prolonged period	200-500
Performance of very prolonged and exacting visual tasks	500-1000
Performance of very special visual tasks of extremely low contrast and small size	1000-2000

COMMERCIAL BRIEF #12

EXIT LIGHT CONVERSION

■ DESCRIPTION

Conversion of incandescent lamps in illuminated exit signs can save energy. Exit signs can be converted by installing compact fluorescent retrofit kits or by replacing the existing exit sign with a new one that uses compact fluorescent lamps. Even though the wattage of the incandescent lamp in the exit light is relatively low to begin with, the compact fluorescent lamp uses up to 80% less electrical energy than the replaced incandescent lamp. The energy savings comes from the fact that exit light signs must be illuminated 24 hours per day, 365 days per year, and many commercial buildings have numerous signs. With an average life of 10,000 hours for a compact fluorescent lamp versus 750 for an incandescent lamp, maintenance costs are also reduced dramatically.

■ APPLICABILITY

BUILDING TYPE All

CLIMATE All

DEMAND MANAGEMENT STRATEGY Strategic conservation

Table C-17. Exit Light Conversion: Costs and Benefits

Options	Costs (\$) ¹	Energy Savings ² (kWh/yr)	Cost Savings ³ (\$/yr)	Simple Payback (yr)	Life (hours)	Confidence
Exit light conversion kit	39.00	289	29.36	1.32	10,000	H

¹ The exit light conversion kit is a one-time cost. In subsequent years, only the bulb needs to be replaced at an approximate cost of \$6.00.
² Energy savings is based on replacing one 40-W bulb with a 7-W bulb. Energy savings equals $(40 \text{ W} - 7 \text{ W}) \times 9760 \text{ h} (1000 \text{ W/kWh}) = 289 \text{ kWh}$.
³ The life of an incandescent bulb is 750 hours, so in one year an exit light uses approximately 12 bulbs. At an average cost of \$0.83/bulb, 11 replacement bulbs cost \$9.13. Cost savings includes bulb replacement cost and energy savings. Savings in labor costs is not included.

HIGH-INTENSITY- DISCHARGE LAMPS

■ DESCRIPTION

High-intensity-discharge (HID) lamps include mercury vapor, metal halide, and high- and low-pressure sodium. Low-pressure sodium has the highest efficacy of any lighting technology in the marketplace but has very poor color rendition. High-pressure sodium (HPS) lamps have the second-highest efficacy and provide acceptable color rendition for street lighting, parking garages, and some commercial applications including warehouses, shopping malls, and display halls. They can replace fluorescent and incandescent lights by refixturing and can replace mercury vapor or metal halide lamps by direct substitution or reballasting.

Metal halide and mercury vapor have lower efficacies than high- and low-pressure sodium. Metal halide is twice as efficient as mercury vapor and has better color-rendering properties. Metal halide is also a great substitute for incandescent lights.

■ DEFINITIONS AND TERMS

EFFICACY The amount of light produced (in lumens) for a given amount of power input (in watts) to the lamp. The higher the efficacy, the less energy required to achieve a given illumination level.

MOGUL BASE HID lamps have either a standard (also called "medium") base or a mogul base. A standard base is the size of the screw base for an incandescent lamp. A mogul base is larger in diameter and is typically found in fixtures designed for lamps greater than approximately 200 W. HID fixtures under 200 W can have either a standard or mogul base.

REFIXTURING Refixturing involves removing the existing lighting fixture including the lamps and replacing it with a new fixture, lamp, ballast(s), and so on. In most cases a repositioning of the fixtures is suggested to maximize efficiency and to reduce the retrofit cost.

■ **APPLICABILITY**

BUILDING TYPE Mostly for new applications, although retrofit applications are possible by refixturing and rebalasting. There are many factors to consider, including the base type and the ballast, when determining whether a HPS lamp can be substituted directly for a metal halide or mercury vapor lamp. The major lighting manufacturers offer lines of HPS lamps that can be directly substituted for metal halide or mercury vapor lamps. These lamps may have a shorter life than a metal halide or mercury vapor or than HPS used with the proper ballast. Low-pressure sodium lamps cannot be directly substituted for mercury vapor, metal halide, or HPS lamps.

CLIMATE All

DEMAND MANAGEMENT STRATEGY Strategic conservation

■ **FOR MORE INFORMATION**

California Energy Commission (March 1990), "Advanced Lighting Guidelines." Sacramento, CA (pub. no. 400-90-014).

Table C-18. High-Intensity-Discharge Lamps: Costs and Benefits

Options	Costs (\$)	Power Savings ¹ (watts/fixture)	Cost Savings ¹ (\$/yr)	Simple Payback (yr)	Light Output Difference (%)	Life (hours)	Confidence
100-W mercury vapor (118-W ballast)	24.50	—	—	—	—	12000–24000	H
50-W HPS (66-W ballast)	25.66	52	16.00	0.1	-1%	12000–24000	H
35-W LPS (60-W ballast)	40.46	56	17.66	1.1	-32%	12000–18000	H
400-W mercury vapor (454-W ballast)	28.00	—	—	—	—	12000–24000	H
200-W HPS (240-W ballast)	55.00	214	55.91	0.4	-1%	12000–24000	H
325-W metal halide	45.00	75	29.13	0.7	-23%	10000–20000	H
1000-W mercury vapor (1075-W)	62.50	—	—	—	—	12000–24000	H
400-W HPS (465-W ballast)	29.50	610	187.66	0	-7%	12000–24000	H

¹ The options presented in the table are for outdoor or indoor applications in new construction. They include material cost only and do not include costs for rebalasting and refixturing. Generally HID substitutions will require refixturing or rebalasting. HID substitutions for incandescent and fluorescent lamps are not included in the table because it is difficult to estimate the cost of new fixture design and replacement.

² The energy savings is based on a comparison of the system watts per fixture.

³ Cost savings is based on 4400 hours of use per year (approximately 12 hours per day year round) and a cost of \$0.07 per kWh.

LIGHT SENSORS/CONTROLLERS

■ DESCRIPTION

Occupancy sensors, also called motion sensors, automatically turn lights off in rooms unoccupied for long periods of time. These systems consist of controls, sensors, and associated wiring. Occupancy sensors have been successfully installed in a variety of locations including warehouses, storage areas, conference rooms, lunchrooms, classrooms, and offices occupied briefly or periodically. It is generally feasible to install sensors in 15% of the floor space of a typical commercial building. Two types of occupancy sensors are commonly used: infrared and ultrasonic. Both types detect virtually any motion within a specific area, triggering a switch that controls a lighting circuit.

Photocell controls turn interior or exterior lighting on or off depending on the amount of daylight present. Photocells for interior applications are similar to those used outdoors, but they require a greater degree of precision and accuracy, and they must be adjustable to match various conditions and lighting requirements. A photocell may control one or two light fixtures by sensing the light level at the task, or it may control an entire lighting circuit. If desired, relays can be added to the system to enable a single photocell to control multiple circuits. A photocell is generally not used with high-intensity-discharge (HID) lamps because HID lamps require 2-4 minute warm-up periods and 10-15 minute restrike periods.

■ DEFINITIONS AND TERMS

INFRARED SENSORS Detect slight changes in temperature

ULTRASONIC SENSORS Detect motion by emitting inaudible high-frequency sound waves and monitoring their echoes

■ **APPLICABILITY**

BUILDING TYPE Commercial (new or retrofit)

CLIMATE All

DEMAND MANAGEMENT STRATEGY Strategic conservation

■ **FOR MORE INFORMATION**

California Energy Commission (March 1990), "Advanced Lighting Guidelines." Sacramento, CA (pub. no. 400-90-014).

Illuminating Engineering Society, 345 E. 47th Street, New York, NY 10017, (212) 705-7926.

Table C-19. Light Sensors/Controllers: Costs and Benefits

Options	Retrofit Costs (\$) ¹	Energy Savings (kWh/yr)	Cost Savings ² (\$/yr)	Simple Payback (yr)	Life (yr)	Confidence
Ultrasonic occupancy sensor	130.00	952	75	1.7	5	M
Photoeye	12.00	219	17.52	0.7	5	M

¹ The cost for the hardware of an ultrasonic occupancy sensor is approximately \$90-\$105 plus approximately an hour installation time at \$35 an hour. The cost of hardware for an infrared sensor is approximately \$60. The location of the wall switch can affect the performance of the infrared sensor. For example, in a restaurant the presence of someone behind a partition may not be detected. Photocell cost range is \$5-\$15.
² Savings depends on the type and quantity of light controlled and use of the space. A rule-of-thumb estimate is that occupancy sensors save 40%-60% lighting energy use for the room in which they are installed. The savings presented in the chart is based on the following assumptions: one sensor installed in a conference room with 10 fluorescent fixtures (95 W each). The lights in the conference room were on four hours a day five days a week in the pre-retrofit case. With the sensor they are on half that amount. Savings for the pre-retrofit assumes that the photocell is controlling two 150-W incandescent floodlights. Use varies between 10 and 12 hours a day.

COMMERCIAL BRIEF #15

DAYLIGHTING CONTROLLERS

■ DESCRIPTION

Interest is high and growing in using daylight as an energy-saving and load-management strategy. Specifically, daylighting's potential to reduce peak electrical demand in summer is being recognized. It is a building design feature associated with increased productivity and improved view and health.

Daylighting uses natural light from the clear or overcast sky to replace or supplement electric lighting in buildings. Good daylighting design provides uniform light distribution with minimum solar heat gain during the cooling season. Daylighting can be cooler than electric lighting when it is admitted through vertical windows and when the installed electric lighting in the building is greater than 2 watts/ft².

A daylighting system has two components, the aperture or window and the electric light control system. The design of the window is discussed in brief #1 on commercial building fenestration. Proper fenestration design to control solar gain and glare is critical to reducing building energy consumption and imperative for successful daylighting design.

This section considers costs and benefits of electric lighting control strategies used with vertical windows in 15-ft-deep perimeter zones of office buildings. Electric lighting control systems can either be continuously dimmed or "stepped" (i.e., on/off or intermediate steps between on and off or both). Control systems can be manual or automatic.

Daylighting can also be done in skylighted spaces. These spaces offer a savings potential comparable to that of windows. The energy benefits of daylighting with

horizontal skylights can be easily negated due to unwanted heat gain in summer.

■ **DEFINITIONS AND TERMS**

EFFECTIVE APERTURE The product of the visible transmittance of the glass and the ratio of the glass area to the floor-to-ceiling wall area.

■ **APPLICABILITY**

BUILDING TYPE Primarily office buildings and schools.

CLIMATE All

DEMAND MANAGEMENT STRATEGY Peak clipping, strategic conservation

■ **FOR MORE INFORMATION**

Usibelli, A., et al. (1985), "Commercial-Sector Conservation Technologies." Berkeley, CA: Lawrence Berkeley Laboratory.

Robbins, C., K. Hunter, and N. Carlisle (1985), "Energy and Economic Efficiency Alternatives for Electric Lighting in Commercial Buildings." Golden, CO: Solar Energy Research Institute

Table C-20. Daylighting Controllers: Costs and Benefits

Options (for vertical windows)	Costs ¹ (\$/ft ²)	Energy Use ² (kWh/ft ² /yr)	Energy Savings (kWh/ft ² /yr)	Cost Savings ³ (\$/ft ² /yr)	Simple Payback (yr)	Life (yr)	Confidence
Existing building, no daylighting	—	8.40	—	—	—	—	—
Add continuous dimming daylighting controls (retrofit)	2.75	2.50	5.9	0.41	6.7	5-15	M
New building, no daylighting	—	5.3	—	—	—	—	—
Add continuous dimming daylighting controls (new)	1.25	1.6	3.7	0.26	4.8	5-15	M

1. The cost of square foot of floor space varies \$1.00-\$1.50 for a retrofit system and \$1.00-\$1.50 for new buildings. The costs are based on a continuous dimming control system in the perimeter zone. It includes dimmer controls, photosensors, and associated wiring. (A continuous dimming system also requires the use of a dimmable electronic ballast. A step control does not require this type of ballast. For more information on electronic ballasts, see brief #11 on fluorescent lighting.)

2. The lighting in the existing building is assumed to be 2.7 W/ft² of floor space in the new building, it is assumed to be 1.7 W/ft². In both cases, it is fluorescent and operates 9.00 hours per day x 6 d/wk x 52 w/yr x 1000 W/kWh. The savings is for the perimeter zone only, where the use of daylighting controls can reduce electric lighting energy use by 70%. Savings will vary depending on how many hours the electric lights are on when natural lighting is available. Because daylighting can only be used in part of the building, overall reduction in use of lighting for electricity will be less.

3. The numbers in the table are for lighting energy only. The use of dimming also reduces a building's cooling energy load and peak demand and may increase the building's heating requirements. These impacts vary by location and therefore are not included in the table. Depending on the utility rate structure and the building's fuel mix, these impacts may have significant cost implications. For example, a building heated relatively inexpensively by gas in a location with a high electric demand charge may benefit significantly more than the table indicates because of reduced peak demand charges for cooling as well as lighting.

COMMERCIAL APPLIANCES

There are a large number of commercial appliances for which it should be possible to modify the amount of power consumed. This section addresses three such appliances—water heaters, refrigerators, and cooking equipment.

In most large commercial buildings, energy to heat water is generally about 4% of the annual energy used. In smaller commercial buildings, the percentage is even smaller. However, in restaurants, cafeterias, and especially laundromats, the relative percentage of energy used to heat water can be much greater.

The opportunities to conserve energy for commercial water heating are basically the same as in the residential sector. They include (1) reducing the load by decreasing the quantity of hot water used and lower the water temperature, (2) reducing the system losses by repairing leaks and insulating the tanks and pipes and by reducing recirculating pump operating time, and (3) increasing the efficiency of the hot water system.

Food refrigeration systems account for approximately 60% of the total annual energy consumption in grocery stores, and they also consume significant amounts of energy in refrigerated warehouses and food service facilities. Many energy conservation techniques can be used to maximize their energy efficiency.

Food service establishments are the most energy efficient in the commercial sector. Based on monitoring of seven restaurants, food preparation accounts for 35% of the energy used in restaurants. Another 18% is used for sanitation and 6% for refrigeration; the remaining 42% is used for lighting, heating, and cooking.

COMMERCIAL BRIEF #16

WATER HEATER RETROFITS

■ DESCRIPTION

In commercial buildings, hot water can be provided in several ways in addition to the separate water heater with integral storage tank commonly used in homes. Some of the other systems are described below. The reader is referred to the residential water heating section in Volume 1 for more information.

In many commercial buildings, the space heating boiler also provides heat for the domestic hot water system. Although this is satisfactory during the heating season, it is inefficient in the summer to operate large boilers at small loads to provide domestic hot water. It may be more cost effective to install a separate water heater sized for the hot water demand and to shut down the large boiler for the summer.

When multiple temperature requirements are met by a central domestic hot water system, the minimum generation temperature is determined by the maximum usage temperature. Lower water temperatures are met by mixing with cold water at the tap. Where the majority of hot water usage is at the lower temperature and higher temperatures are required at only a few specific locations, booster heaters can be installed to attain higher temperatures (see Table C-21 for sizing information for booster water heaters). These heaters have no storage tanks. In new construction, they may be installed in place of a conventional water heater to provide hot water instantaneously only when needed. This prevents heat loss through the walls of a conventional hot water tank. The use of these heaters may increase peak demand.

In commercial buildings, hot water is often continually pumped through piping to the fixtures so that it is

Table C-21. Booster Heater Sizing

Water Temperature Rise Required (°F)	Sizing Factor (watts/GPH)
10	24
20	49
30	73
40	98
50	122
60	146
70	171

GPH = gallons per hour

kW = sizing factor x flow rate (GPH)/1000

Note: If equipment operates less than one hour, multiply gallons used by (60/minutes used) to determine GPH.

delivered instantly at the faucets. However, the pump requires electrical power for operation, and the system loses heat through the pipes. As a retrofit, the recirculating pump could be turned off with a timer when the building is not occupied. When commercial buildings require hot water for short periods of heavy use at various locations, it may be more efficient to provide water heaters close to the point of use rather than using a central boiler and long pipe runs.

■ DEFINITIONS AND TERMS

BOOSTER HEATER A heater placed in the primary hot water supply line to boost the temperature of heated or incoming water to the desired level at the point of use.

■ APPLICABILITY

BUILDING TYPE All

CLIMATE All

DEMAND MANAGEMENT STRATEGY Strategic conservation

Table C-22. Water Heater Retrofits: Costs and Benefits

Options	Retrofit Cost (\$)	Energy Savings (kW/h/yr)	Cost Savings (\$/yr)	Simple Payback (yr)	Life (yr)	Confidence
Electric water heater	315.00	—	—	—	13	—
Booster water heater	640.00 ¹	1.453 ²	116	2.8	13	[³
Reduce hot water recirculation	110.00 ⁴	26.250 ⁵	1,640	Immediate	10	M

1. First cost for a tank capable of providing up to 15 kW of power.

2. Energy savings is based on an example found in product literature for a residential system monitored by a utility. For commercial applications, it is more difficult to determine savings because of differing flow rates and the temperatures required. According to a manufacturer's representative, the residential example can be generalized for commercial applications as follows: if a business uses less than 70 gallons of hot water per day, energy use with a booster heater will be approximately 40% less than with a conventional water heater. The savings presented in the chart above is based on a usage of 70 gallons per day. As the hot water requirement increases, the savings decreases. Depending on the time and size of the peak demand, the peak demand for a business using 70 gallons per day may be 40% greater with a booster heater than with a conventional heater. The peak demand may increase further with greater use.

3. Confidence of the energy savings is low because of lack of monitored data.

4. \$110 is for the installed cost of the timer.

5. Cost savings is based on an actual building that uses a 7.5-hp pump for circulating water. It is assumed that the pump can be turned off for 12 h/day. The calculation is as follows:

$$0.5 \text{ hp} \times 0.746 \text{ kW/hp} \times 0.92 = 6 \text{ kW}$$

$$6 \text{ kW} \times 12 \text{ h/day} \times 365 \text{ days/yr} = 26,280 \text{ kWh/yr}$$

COMMERCIAL BRIEF #17

REFRIGERATION SYSTEMS

■ DESCRIPTION

A conventional refrigeration system uses a single compressor for each display case lineup or walk-in refrigerator. A "multiplex refrigeration system" consists of multiple refrigeration compressors piped to common suction and discharge manifolds. These systems commonly consist of three or four compressors sized to meet maximum refrigeration needs when operating simultaneously. They can be cycled on or off to match the refrigeration load. Energy-efficiency enhancements to multiplex refrigeration systems include floating head pressure, ambient subcooling, mechanical subcooling, evaporative condensers, hot gas defrost, and heat reclaim.

Display-case energy conservation features include various forms of plastic strip curtains, hard plastic covers, roll-down flexible plastic or perforated polyester covers, and glass doors for open display cases.

■ DEFINITIONS AND TERMS

AMBIENT SUBCOOLING The cooling of the liquid refrigerant below the condensing temperature by heat rejection to the ambient

EVAPORATIVE CONDENSER Heat rejection is through the evaporation of water to the ambient air. The condensing temperature is controlled by the ambient wet-bulb temperature.

FLOATING HEAD PRESSURE CONTROL This allows the compressor-discharge pressure (and therefore temperature) to drop when ambient air temperature drops, resulting in increased efficiency.

HEAT RECLAIM Heat rejected through the refrigeration system is recovered for space or water heating.

HOT GAS DEFROST Frost can be melted and energy conserved by circulating the refrigerant gas from either the compressor discharge or the receiver to the display case evaporator.

MECHANICAL SUBCOOLING The liquid refrigerant can be further cooled through the use of a vapor compression system. Cooling is provided by evaporating a refrigerant at a higher temperature than the main evaporator temperature. This allows the vapor compression system to operate at a lower temperature than the main system.

■ **APPLICABILITY**

BUILDING TYPE The display-case measures are applicable to new or retrofit; the other measures are primarily applicable to new construction.

CLIMATE All

DEMAND MANAGEMENT STRATEGY Strategic conservation, peak clipping

■ **FOR MORE INFORMATION**

Foster-Miller Inc. (1990), "Guide to the Selection of Supermarket Refrigeration Systems." Palo Alto, CA: Electric Power Research Institute.

Table C-23. Refrigeration Systems: Costs and Benefits

Options	Costs (\$)	Energy Savings (kWh/yr)	Cost Savings (\$/yr)	Simple Payback (yr)	Life (yr)	Confidence
Multiplex compressors	22,500 ¹	63,875 ¹	4471	5.0	15	M
Floating head pressure control (vs. fixed head)	5,304	27,740	1942	2.7	15	M
Ambient subcooling (vs. no subcooling)	3,657	36,500	2555	1.4	15	M
Mechanical subcooling (vs. no subcooling)	4,850	17,520	1226	3.4	15	M
Hot gas defrost (vs. electric defrost)	2,851	20,440	1431	2.0	15	M
Evaporative condenser (vs. water-cooled)	-4,750		3296	Immediate	15	M
(vs. air-cooled)		47,065	1507	Immediate		
Display case glass door retrofit kits	27,040 ²	152,000	10640	2.5	15	M

¹ The costs and savings for all but the last measure are based on testing for 2.5 years in a grocery store in Menlo Park, CA. The results of the testing are found in Foster-Miller Inc. (1990). The savings for the last measure is based on information in an unpublished paper by the same authors. The energy use for a conventional refrigeration system in this store is 734,609 kWh/yr.

² \$130/L (taken from EPRRI-1987) DSM Technology Alternatives, EM-5-557) x 203 LF (based on the Menlo Park store).

COOKING EQUIPMENT

■ DESCRIPTION

Some of the more energy-efficient technologies available for food preparation include a two-sided griddle, energy-efficient fryers, and combination oven/steamers. The two-sided griddle cooks food such as frozen hamburger, bacon, or chicken faster at a lower temperature than a standard one-sided griddle. This results in lower energy use and lower demand. Several griddle manufacturers offer a retrofit option to convert their standard griddles into two-sided griddles. The energy-efficient features of the improved fryer include increased frypot insulation and electronic, rather than mechanical, controls that modulate the amount of energy to the electric elements for greater reliability and more precise temperature control. An oven/steamer combination has three cooking modes—steam, hot air, and combination—in which the food is cooked with moist heat. It is capable of performing all the functions of a convection steamer and a convection oven.

■ APPLICABILITY

BUILDING TYPE Commercial kitchen

CLIMATE All

DEMAND MANAGEMENT STRATEGY Peak clipping, strategic conservation

■ FOR MORE INFORMATION

Pieretti, Gloria, et al. (August 1990), "Cooking Appliance Performance Report." San Ramon, CA: Pacific Gas and Electric Corporation (Report 008.1-90.8).

Table C-24. Cooking Equipment: Costs and Benefits

Options	Added Costs (\$)	Energy Savings (kWh/yr)	Demand Savings (kW)	Cost Savings (\$/yr)	Simple Payback (yr)	Life (yr)	Confidence ³
Energy-efficient fryer ¹	300	583		40.80	7.3	20	L
Combination oven/steamer ²	Less costly than conventional alternative	—	95	—	Immediate	20	L

¹ The cost is the premium for an energy-efficient model. The energy savings is 10% of energy used by a standard fryer. According to monitoring by the Pacific Gas and Electric Co., a standard fryer uses 19.7 kWh/day. The energy savings assumes six days/week operation: $0.10 (6 \times 52 \times 19.7) = 583 \text{ kWh/yr}$.

² One electric combination oven/steamer at 61 kW can replace 13 conventional steamers at 7-9 kW each and four convection ovens at 11-15 kW each. The cost for a steamer/oven this size is \$27,000, approximately one-third the total cost of the replaced products.

³ The confidence is low because the energy savings estimates in both cases were from manufacturers. No written performance data were provided to back up claims, but both manufacturers' products are currently undergoing extensive utility testing.

MOTORS

Electric motors supply most of the drive energy in the United States, surpassing vehicle energy use while consuming more than half of the nation's electricity. These devices are also unique in their prodigious consumption of energy. A typical industrial motor operating a large fraction of the time consumes more than 10 times its capital cost *each year*. That's like spending \$100,000 a year on gas for a \$10,000 car. With figures like this, small gains in overall system efficiency are significant.

In buildings, mechanical energy from motors is used to operate fans, pumps, and compressors for cooling, air transport, and refrigeration systems. On farms, motors are used primarily for irrigation pumping, ventilation, material handling, and feed grinding. Industrial use ranges widely from pumping to mechanical drive systems.

Table C-25 shows the distribution of motors by size in the U.S. in 1980. Although small motors (less than 1 horsepower [hp]) are in the vast majority, the larger motors account for more energy consumption. The smaller motors are typically installed in various appliances by original equipment manufacturers. Because such motors are not generally good retrofit candidates, retrofit savings are precluded for about one-fourth of all motor energy consumption.

This section includes a number of efficiency improvements that address the motor as well as transmission of the energy to the load (e.g., gears) and the power supply. Because not all efficiency measures are applicable to all motor types, the first technology brief (#19) presents an overview of the more common motors and their uses. Terms pertaining to motor efficiency measures are also defined.

Table C-25.
Population and Energy Use of Electric
Motors, by Size, in the United States

Motor Size (hp)	Installed Population (millions (%))	Energy Use (TWh/yr (%))
1/6-1	900 (90)	224 (14.2)
1-5	75 (7.5)	160 (10.2)
5 1-20	15 (1.5)	93 (6.0)
21-50	5 (0.5)	160 (10.2)
51-125	3 (0.3)	345 (22.0)
>125	0.2 (0.02)	587 (37.4)
Total	998.2 (100)	1,569 (100)

Source: "Classification and Evaluation of Electric Motors and Pumps,"
DOE/CS 0147 (February 1980).

ELECTRIC MOTORS-GENERAL

■ DEFINITIONS AND TERMS

STATOR The stationary part of the motor. The word generally applies to the wire-wound electromagnets or permanent magnets on the motor case.

ROTOR The rotating part of the motor. The rotor may contain wire-wound poles like the stator along with the necessary slip rings and commutators to transmit electricity to the rotating components (some motor types).

SYNCHRONOUS SPEED The rotation frequency of the magnetic field produced by the stator of an induction or synchronous motor. It is determined by the alternating-current frequency (3600 cycles per minute = 60 Hertz) and the number of poles in the motor ($\text{rpm} = \text{current frequency} / \text{number of pole pairs}$). For example, a motor with one pair of poles will rotate at 3600 rpm; a motor with three pole pairs will rotate at 1200 rpm ($3600/3$).

SLIP The difference in speed between the synchronous speed and the slightly slower rotor speed.

POLE PAIR This refers to a north/south pair of permanent magnets or electromagnets in the stator or rotor.

CORE The iron or steel on which the electromagnetic windings are placed. It is typically made up of a stack of thin laminations electrically insulated from each other.

LOAD PROFILE The percentage of time the motor operates at various fractions of the rated full load.

DUTY CYCLE The hours per year of motor operation.

POWER FACTOR The ratio of useful real power in kilowatts to apparent power in kilovolt-amperes.

■ DESCRIPTION

The twisting force on the motor's shaft, or rotor, is caused by the interaction of magnetic fields. The way these magnetic fields are generated in the stator and rotor determines the categories of electric motors. The relative merits and characteristics of principal motor types are shown in Table C-26.

INDUCTION MOTORS These alternating-current motors are by far the most common type sold today. They come in single-phase varieties for households and polyphase for commercial and industrial applications. A wide range of power ratings is available from fractional to thousands of horsepower. Similarly, a range of speeds is available, although each motor is designed to operate at only one speed which is determined by the number of poles. The most common speed is 1800 rpm (two pole pairs).

Different types of induction motors are determined by the rotor construction. The simplest and most common type of induction motor is the squirrel-cage induction motor, in which the changing magnetic fields in the stator "induce" electrical currents in copper or aluminum bars arranged like a squirrel-cage in the rotor. In a wound-rotor induction motor, the rotor magnetic fields are produced as they are in a squirrel-cage induction motor. Slip rings and brushes are used to connect variable resistances into the rotor circuits to control the torque and speed characteristics of the motor. A pole amplitude motor (PAM) is a single-winding squirrel-cage induction-type motor that can operate at two different speeds. Other multispeed motors, generally less efficient, are based on switched sets of stator windings. PAMs are typically twice as expensive as single-speed motors and are available in a limited range of speed ratios including 3600/900, 3600/720, 1800/1200, 1800/720, 1200/900, 1200/720, and 900/720. A pony motor is a second standard induction motor used to

power the same piece of equipment but at a different speed. This economical and reliable two-speed control method is becoming standard practice in some prepackaged equipment.

SYNCHRONOUS MOTORS These are very similar to induction motors except they have an additional set of rotor windings. One set of windings is used to start the motor (starter windings) to near the synchronous speed. The second set of windings (field windings) produces a field that locks the rotor at the synchronous speed.

DIRECT-CURRENT MOTORS As the name implies, these motors use direct current and a complex commutator that switches the electric current among different poles on the rotor as it spins. The commutator and brushes are the weak link in these motors, requiring additional maintenance and reducing reliability. The main advantage of these motors is simple speed control with voltage adjustment. They are used primarily in low-energy-requirement applications like small appliances and hand tools and where good speed control is needed (e.g., machine tools, industrial processes, elevators).

PERMANENT-MAGNET MOTORS In this motor, the squirrel cage or wound poles in the rotor are replaced with one or more permanent magnets. Wound-rotor types are also available. The magnet aligns with the rotating magnetic field in the stator, thereby matching the synchronous speed. Because permanent magnets are bulky and expensive, this type of motor has been limited to fractional-horsepower applications. Larger permanent-magnet motors have shown impressive efficiencies of up to 97%. In lower-horsepower ranges, permanent-magnet motors can be 5%–10% more efficient than their induction-motor counterparts. Recent advancements in permanent-magnet materials mean that these motors could soon establish a new standard for premium-efficiency motors.

Table C-26. Principal Motor Types and Their Characteristics

Squirrel Cage	Induction-Type Motors			Pony Motors
	Wire Wound		Pole Amplitude	
Simple construction	Ratings >100 hp		Dual speeds available	Refers to the use of two induction motors of different speeds on the same piece of driven equipment
Low cost	More expensive than squirrel-cage type		Single winding efficiency	Many speed combinations possible
High reliability	External resistors allow the control of starting and torque/speed characteristics		Twice the price of single-speed induction motor	Reliable
Single-speed operation			Reliable squirrel-cage rotor	Easy maintenance
Fractional hp to thousands of hp			Slow speed, gentle start	Use of standard starter equipment

Table C-26. Principal Motor Types and Their Characteristics (Concluded)

Synchronous	Direct Current	Permanent Magnet	Reluctance
Slightly higher efficiency than induction motors	High starting torque	Bulky and expensive due to permanent magnets in rotor	Iron rotor
Better lower-speed operation and efficiency than induction motors	Inherent low-cost speed control	Limited to fractional to hundreds of horsepower	Subfractional-horsepower applications
Expensive due to complex rotor	Bulky	Very efficient	
Generation or consumption of reactive power (inherent power factor control)	Cannot sustain high speeds	High reliability	
Large hp ratings (>200 hp)	Less efficient than similar-sized AC motors		
Slower speed ratings common	Not as reliable as induction motors due to complex rotor, commutator, and brushes		

RELUCTANCE MOTORS These motors combine a cheap iron rotor with an imbedded squirrel cage for starting. The stator field magnetizes the iron in the rotor. These motors are typically used in subfractional-horsepower applications.

■ **APPLICABILITY**

In buildings, mechanical energy from motors is used to operate fans, pumps, and compressors for cooling, air transport, and refrigeration systems. On farms, motors are used primarily for irrigation pumping, ventilation, material handling, and feed grinding. Industrial use ranges widely from pumping to mechanical drive systems.

ENERGY-EFFICIENT MOTORS

■ DESCRIPTION

Energy-efficient motors (EEMs) are also known as high-efficiency motors and premium motors. They are virtually interchangeable with standard motors, but differences in construction make them more energy efficient. Energy-efficient motors use additional copper to reduce electrical losses, better magnetic materials to reduce magnetic losses, and lower friction to reduce mechanical losses. Use of better materials results in longer motor life as well as increased energy efficiency. Small (<5 hp) motors are as much as 8 percentage points more energy efficient than standard motors. The efficiency improvements for larger motors (>50 hp) are approximately 3–5 percentage points. For example, a 5-hp standard motor may be 80% efficient while the equivalent premium motor may have an 86% efficiency. This is an improvement of 6 percentage points but represents a 7.5% increase in energy efficiency.

The starting torque for EEMs can be smaller than for standard motors. If starting torque is critical, EEMs may not be practical. Fortunately, very few loads have critical starting-torque requirements. Loads with high starting torque requirements include large fans, conveyors and other types of equipment that start under load, and equipment with journal rather than ball bearings.

■ APPLICABILITY

EEMs are most applicable in new construction or when replacing a damaged motor; early replacement of motors with poor full-load efficiencies or of motors that are significantly oversized can also be economical. This

measure is not feasible for smaller motors that are integral parts of an appliance or piece of equipment.

DEMAND MANAGEMENT OBJECTIVE Strategic conservation

■ FOR MORE INFORMATION

Usibilli, A., et al. (1985), "Commercial-Sector Conservation Technologies." Berkeley, CA: Lawrence Berkeley Laboratory, LBL-18543.

Nadel, S., et al. (1991), *Energy-Efficient Motor Systems: A Handbook on Technology, Program, and Policy Opportunities*, Washington, DC: American Council for an Energy-Efficient Economy.

Baldwin, S. (1989), "Energy-Efficient Electric Motor Drive Systems," in Johansson, T., et al., eds., *Electricity: Efficient End-Use and New Generation Technologies and Their Planning Implications*, Lund, Sweden: Lund University Press.

Table C-27. Energy-Efficient Motors: Costs and Benefits

Size (hp)	Average Size (hp)	Std. Effic. ¹ (%)	EEM Effic. ¹ (%)	Std. vs EEM Savings ² (kW)	Std. Motor Cost ¹ (\$)	EEM Motor Cost ¹ (\$)	Annual Savings ³ (kWh/yr)	Payback (yr)
1-5	2.75	80.2	86.4	0.13	166	215	520	1.3
7.5-20	13.1	86.7	91.4	0.44	401	523	1760	1.0
25-50	36.3	90.2	93.4	0.77	919	1189	3080	1.3
60-125	90	91.9	94.8	1.67	2526	3146	6660	1.3
150-250	200	93.7	95.5	2.25	5273	6915	9000	2.6

¹ Average of TEFC totally enclosed fan cooled; and ODP (open drip proof) types.

² Assumes 75% full-load operation.

³ Assumes 4000 hr/yr operation and \$0.07 kWh for new construction. Assumes all non-equipment costs are equal.

Source: Nadel, S., et al. (1991). *Energy-Efficient Motor Systems: A Handbook on Technology, Program, and Policy Opportunities*, Washington, DC: American Council for an Energy-Efficient Economy, p. 264. See this source for multiple primary references.

ELECTRONIC ADJUSTABLE- SPEED DRIVES (ASDs)

■ DESCRIPTION

In most motor applications, performance and energy efficiency can be maximized by ensuring that the motor's speed is properly matched to changing load requirements. This can be accomplished with several different transmission methods (see brief #28 on transmission efficiency) or electronically by adjustable-speed drives that alter the frequency of the AC electricity before it gets to the motor.

ASDs are usually more cost effective than transmission alternatives. Savings depends on the load profile and type of motor-driven equipment. ASDs are most cost effective for motors that could run at partial speed for a large percentage of the time. They are not recommended for motors that must run at rated speed, because they cost more and are a few percent less efficient at rated speed than are their simple induction-motor counterparts.

Energy savings from ASDs is especially good for pumping, fans, and other centrifugal loads, because the power requirements for these loads often vary as the cube of their shaft speed. For example, a reduction in speed (and thus flow) of 25% results in a power requirement reduction of 58%.

An additional advantage of ASDs is that the motor is isolated from the power source; thus it is protected from voltage imbalance and harmonics and from brief power interruptions. However, ASDs also produce harmonics. ASDs are unsuitable for especially harsh environments where their electronic components might be damaged by dirt, moisture, or heat. Locating the ASD away from the motor can solve this problem in many cases.

Fractional-horsepower ASDs are available but have higher dollar-per-horsepower costs.

■ **APPLICABILITY**

ASDS are best where induction motors are used to meet variable-speed loads such as variable-volume air distribution and water pumping, air conditioning chillers, and possibly refrigeration (although this has not been applied on a wide scale). They are suitable for new and retrofit applications in commercial buildings and also have many industrial applications.

ASDs also have a large potential market in the residential sector. U.S. and Japanese manufacturers are starting to incorporate them into some household equipment.

Typical energy savings for ASDs range from 10% to 50%. In addition to the energy savings, ASDs can have other favorable effects that are difficult to quantify. These include reduced wear on equipment, increased reliability, reduced noise, soft-start capability, and fault protection.

DEMAND MANAGEMENT OBJECTIVE Strategic conservation

■ **FOR MORE INFORMATION**

Greenberg, S., et al. (1988), "Technology Assessment: Adjustable-Speed Motors and Motor Drives (Residential and Commercial Sectors)." Berkeley, CA: Lawrence Berkeley Laboratory. LBL-25080, UC-400.

Usibelli, A., et al. (1985), "Commercial-Sector Conservation Technologies." Berkeley, CA: Lawrence Berkeley Laboratory. LBL-18543.

Nadel, S., et al. (1991), *Energy-Efficient Motor Systems: A Handbook on Technology, Program, and Policy Opportunities*, Washington, DC: American Council for an Energy-Efficient Economy.

Baldwin, S. (1989), "Energy-Efficient Electric Motor Drive Systems," in Johansson, T., et al., eds., *Electricity: Efficient End-Use and New Generation Technologies and Their Planning Implications*, Lund, Sweden: Lund University Press.

Table C-28. Adjustable-Speed Drives: Costs and Benefits

Motor Size (hp)	Commercial Application Cost ¹ (\$)	Industrial Application Cost ¹ (\$)	Annual Savings (kWh)	Cost Savings ² (\$)	Commercial New Const. Payback ³ (yr)	Industrial New Const. Payback ³ (yr)
5	2,100	2,700	3,356	235	9.0	11.5
10	2,800	3,600	6,711	470	6.0	7.6
20	3,800	4,800	13,424	940	4.0	5.1
50	7,200	8,800	33,557	2,349	3.0	3.7
100	11,000	14,000	67,114	4,698	2.3	2.9
250	—	25,000	167,782	11,745	—	2.1

¹ Nadel, S., et al. (1991), *Energy-Efficient Motor Systems: A Handbook on Technology, Program, and Policy Opportunities*, Washington, DC: American Council for an Energy-Efficient Economy, p. 121.

² Assumes 4000 hr/yr operation, 75% full load, and \$0.07 kWh. Also assumes a 30% energy savings excluding demand savings.

³ These are gross equipment cost paybacks that do not treat differential cost. As such, the paybacks are quite conservative. Typical paybacks are 1-6 yr.

SINGLE-PHASE VS. POLYPHASE INDUCTION MOTORS

■ DESCRIPTION

Single-phase electrical service (e.g., 120/240 AC) is most commonly used in residences and some small businesses and farms. Hence, most of the motors in use in the U.S. are single phase. They tend to be less efficient, bulkier, and more expensive than similar-hp polyphase motors. Single-phase motors generally require special starter capacitors. In installations with many single-phase motors, voltage can be imbalanced because of uneven distribution of the motor loads across different phases. Polyphase motors, however, present a balanced load to the electrical distribution system. In addition, because single-phase motors often have lower power factors, the reactive power losses in the application's distribution equipment are increased. See Table C-29 for ratings and potential annual savings for some fractional-horsepower motors.

In some farm applications larger single-phase motors are common. Sometimes special conditioning equipment is used to synthesize polyphase voltages from a single-phase source, enabling use of polyphase motors. Single-phase motors larger than 10 hp are uncommon.

■ APPLICABILITY

Facilities with polyphase service where single-phase motors are used; farms that use single-phase motors

DEMAND MANAGEMENT OBJECTIVE Strategic conservation

COST The principal cost in changing from a single-phase motor to a polyphase motor is the cost of converting the electrical service. These costs are highly variable. In general, polyphase motors are 10%-25% less expensive than single-phase motors.

Table C-29. Polyphase Motors: Costs and Benefits

Size (hp)	Single Phase ¹		Polyphase ²		Annual Savings (\$/yr)
	Efficiency (%)	Power Factor	Efficiency (%)	Power Factor	
0.50	72	0.74	75	0.82	6
0.75	75	0.77	78	0.84	8
1.0	77	0.79	82	0.86	16
1.5	76	0.77	84	0.86	39
2.0	79	0.87	87	0.88	49
3.0	83	0.95	87	0.82	35
5.0	86	0.98	89	0.85	41
7.5	79	0.82	90	0.90	242
10.0	83	0.84	91	0.90	221

¹ Single-phase, capacitor run, 40°C, continuous duty, Energy Saver™.

² Three-phase, 40°C, continuous duty, Energy Saver™.

³ Based on 4000-hr/yr operation and \$0.07 kWh; savings from improved power factors are not included.

Source: General Electric, "Commercial and Industrial Fractional Horsepower Motors (sizes less than or equal to 1 hp)" (1986). Marathon Electric catalog for 1.5 hp and greater.

MOTOR OVERSIZING

■ DESCRIPTION

Motors are typically oversized for their loads to account for load growth and safety margin. Few data exist on the sizing of the existing population of motors, but recent studies suggest that in the average installation, the load may be on the order of 60% or less of the rated motor load. Most sizing criteria are based on acceptable operating temperature for the motor rather than on energy efficiency. The cost of the additional energy is often small compared to the cost of down time.

The effects of motor loading on efficiency and power factor are shown in Figures C-3 and C-4. Motor manufacturers generally design their motors for peak efficiency at 75% of rated load to account for this oversizing. Motors operate near their optimum efficiency down to 50% of their rated load. Below this level (depending on motor size), the efficiency trails off rapidly. More dramatic is the decrease in power factor, which is more a function of loading than of efficiency. Lower power factors increase losses in electrical equipment and can increase power-factor charges from the utility. Power factor is also a function of the design speed for the motor; the slower motors (more poles) have lower power factors.

Smaller motors are the best candidates for oversizing retrofits, because larger motors are more efficient and have better power factors over a wider range of loading

BA-G0657306

Figure C-3. Effect of motor loading on efficiency for motors of different sizes. Source: "Energy Guide for Selection and Use of Polyphase Motors," NEMA, 2101 L Street NW, Washington, DC (1983).

Figure C-4. Effect of motor loading on power factor for motors of different sizes. Source: "Energy Guide for Selection and Use of Polyphase Motors," NEMA, 2101 L Street NW, Washington, DC (1983).

Figure C-5. Efficiency of a standard and energy-efficient motor as a function of motor loading. Source: J. C. Adreas, *Energy-Efficient Electric Motors*, New York: Marcel Dekker (1982).

conditions. Also, efficiency curves for energy-efficient motors are flatter than shown in Figure C-3 for all motor sizes (see Figure C-5) and result in even greater savings when used to correct oversizing problems in standard motors. Adjustable-speed drives alone should not be considered for oversizing corrections.

■ **APPLICABILITY**

Retrofit with an energy-efficient motor when a standard-efficiency medium-sized to small motor operates at loads less than 40% of its rated load

DEMAND MANAGEMENT OBJECTIVE Strategic conservation

Table C-30. Motor Oversizing: Costs and Benefits¹

Size (hp)	Delivered Load ² (hp)	Oversized Motor		EEM			Potential Savings (\$/yr)	Payback (yr)
		25% Full Load Efficiency (%)	New Size (hp)	New Motor Cost (\$1990)	Retrofit Labor ³ (\$)	Efficiency (%)		
1	0.25	45	1/3	60	132	84.0 (75% FL)	53	3.6
10	2.5	75	3	360	132	88.8 (83% FL)	108	4.5
100	25.0	87	30	3398	856	93.2 (83% FL)	367	11.6

¹ Assumes 4000 hr of operation and \$0.07 kWh.

² Nadel, S., et al. (1991). *Energy-Efficient Motor Systems: A Handbook on Technology, Program, and Policy Opportunities*, Washington, DC: American Council for an Energy-Efficient Economy, p. 264.

³ Delivered load is the horsepower output measured at the shaft of the motor, not the nameplate horsepower rating.

Source: General Electric normal efficiency motor performance data and "Energy Guide for Selection and Use of Polyphase Motors," NEMA, 2101 L Street NW, Washington, DC (1983).

MOTOR REWINDING VS. ENERGY-EFFICIENT MOTORS

■ DESCRIPTION

When a motor fails or is damaged, the operator has the choice of replacing or repairing it. For most standard motors of medium to larger size, the best option is often to replace the motor. Repair or "rewinding" is typically performed four to five times during the lifetime of a motor of 20 hp or more. Rewinding involves the removal of the old windings from the stator (and rotor if applicable), rewinding with new wire, turning the stator, and replacement of damaged mechanical components like bearings. For smaller motors (about 5 hp or less) the cost of rewinding can exceed the cost of an EEM; i.e., EEMs can yield immediate payback.

Motors typically fail because overheating damages either the insulation between core lamination or the magnetic properties of the core material itself. The core can also be damaged during rewinding if the old winding insulation is softened by baking or burnout. Alternate winding-removal methods are available that reduce or eliminate the danger of core damage. One excellent way to test for core damage is to use modern electronic core testing equipment before and after rewinding.

Rewinding usually reduces motor efficiency 1% to 5% because of inferior workmanship or parts, the use of smaller-gauge wire (or longer lengths of the same-gauge wire), and damage to the core during rewinding. However, replacement of aluminum rotor windings with copper and repair of core damage do sometimes result in improved motor efficiency after rewinding.

■ **APPLICABILITY**

High-efficiency motors one horsepower and larger.

DEMAND MANAGEMENT OBJECTIVE Strategic conservation

COST Rewinding costs are highly variable depending on materials, method, and turnaround time.

■ **FOR MORE INFORMATION**

EASA, "Core Iron Study," Electrical Apparatus Service Association (1985).

Nadel, S., et al. (1991), *Energy-Efficient Motor Systems: A Handbook on Technology, Program, and Policy Opportunities*, Washington, DC: American Council for an Energy-Efficient Economy.

Table C-31. Rewinding Versus Energy-Efficient Motors: Costs and Benefits¹

Motor Size (hp)	Standard Full Load Efficiency ² (%)	EEM Cost ² (\$)	EEM Efficiency ² (%)	Rewind Cost ² (\$)	Rewind Efficiency Reduction in Percentage Points									
					1		2		3		4		5	
					Savings (\$/yr)	Payback (yr)	Savings (\$/yr)	Payback (yr)	Savings (\$/yr)	Payback (yr)	Savings (\$/yr)	Payback (yr)	Savings (\$/yr)	Payback (yr)
5	83.9	290	89.0	335	65	-0.7	76	-0.6	88	-0.5	100	-0.4	113	-0.4
10	86.4	665	91.0	440	112	2.0	135	1.7	157	1.4	180	1.3	203	1.1
20	88.3	787	92.7	610	209	0.8	251	0.7	293	0.6	337	0.5	381	0.5
50	91.5	1874	93.8	1175	304	2.0	401	1.7	500	1.4	601	1.2	704	1.0
100	91.9	4285	95.0	1610	743	3.6	935	2.9	1131	2.4	1331	2.0	1536	1.7
200	94.0	8294	95.6	2420	916	6.4	1282	4.6	1636	3.5	2036	2.9	2429	2.4

¹ Assumes 4000 h/yr operation and 50.0 ¢/kWh. Inlet des rewind cost

² Nadel, S., et al. (1991), *Energy-Efficient Motor Systems: A Handbook on Technology, Program, and Policy Opportunities*, Washington, DC: American Council for an Energy-Efficient Economy, p. 264.

WIRE SIZING

■ DESCRIPTION

Electrical conductors, wires, or busbars used to bring power from a distribution point to a motor are typically sized according to the National Electric Code (NEC), which provides standards for overcurrent and fire protection. Although these codes provide guidance for building safety, they do not address energy efficiency. Larger wires are more efficient. Power loss in the conductors is proportional to the resistance of the wire and the square of the current passing through it. The resistance in a wire is directly proportional to its length and the inverse of the square of its diameter.

In new construction, substantial savings can be accrued by selecting motor feeder wire that is larger than specified by the NEC but does not involve larger conduit. Retrofit applications are also economical if larger conduit is not required and labor to remake the old wire and install the new wire is not included in the analysis (e.g., included as part of a maintenance upgrade).

■ APPLICABILITY

Retrofit or new construction where existing conduit can accept larger feeder conductors (NEC guidelines for fill factors).

DEMAND MANAGEMENT OBJECTIVE Strategic conservation

Table C-32. Wire Sizing: Costs and Benefits

Motor Size (hp)	Design Ampacity ¹	NEC Guideline Wire Sizing				One Size Larger			Cost ⁴ \$/cft	Saved \$/yr/cft	Payback (yr) ⁵	
		Wire Type ²	T-Ohms ³ per cft	Waste W per cft	Cost ⁴ \$/cft	New Wire Type ²	T-Ohms ³ per cft	Waste W per cft			New Payback	Retrofit Payback
7.5	27.5	10 awg	0.11123	252	11.75	8 awg	0.07023	159	16.00	26.04	0.7	2.3
10	35	8 awg	0.07023	258	16.00	6 awg	0.04514	166	22.70	25.82	1.0	3.3
15	52.5	8 awg	0.07023	581	16.00	6 awg	0.04514	373	22.70	58.10	0.5	1.5
20	67.5	6 awg	0.04514	617	22.70	4 awg	0.02831	387	35.10	64.38	0.8	2.0
25	85	4 awg	0.02831	614	35.10	3 awg	0.02252	488	45.60	35.15	1.2	4.8
30	100	3 awg	0.02252	675	45.60	2 awg	0.01783	535	60.80	39.38	1.5	5.7
40	130	2 awg	0.01783	904	60.80	1 awg	0.01416	718	75.40	52.20	1.1	5.3
50	162.5	1/0	0.01121	868	94.10	2/0	0.00889	704	106.80	51.59	1.1	7.7
60	192.5	2/0	0.00889	968	106.80	3/0	0.00704	783	131.20	57.51	1.6	8.4
75	240	4/0	0.00559	966	171.80	250 mcm	0.00473	818	198.60	41.36	2.6	17.5
100	310	300 mcm	0.00394	1137	237.75	350 mcm	0.00337	973	276.90	46.01	3.4	22.0
125	390	500 mcm	0.00237	1082	382.20	600 mcm	0.00197	898	445.10	51.68	4.9	31.5
150	450	600 mcm	0.00197	1195	445.10	800 mcm	0.00148	899	570.90	82.67	6.1	25.4

¹ Table 430-150, NEC 1987, Article 430-22. ² Table 310-16, THHN, NEC 1987. ³ Chapter 9, Table 8, uncoated copper at 50% NEC 1987. ⁴ List price.

⁵ Based on four conductors per motor, 10% salvage value (for retrofit), and a \$200 installation cost.

Note: Based on 230-volt 3-phase motor, 100-ft feeder. Abbreviations: cft = 100 ft; awg = American weight gauge; mcm = thousands of circular mils.

POWER SUPPLY TUNE-UP

■ DESCRIPTION

The quality of the electrical power strongly affects the performance of electric motors. Typical power quality problems include phase voltage imbalance, voltage fluctuations, low power factors, and harmonics.

PHASE VOLTAGE IMBALANCE Electric motors are designed and efficiencies determined using an assumption of perfect voltage balance between phases. Voltage imbalance can be caused by a blown fuse or a trip in one of the phases, different wire sizes in the different phases upstream of the motor, the starting of arc furnaces or welders, and so on. The percent voltage unbalance is calculated as the maximum difference between phase voltages divided by the average of the three line voltages. NEMA recommends that no motor be operated with more than 5% phase voltage imbalance.

Consequences of large voltage imbalances include overheating and thermal/mechanical stressing of the core, higher winding temperatures producing insulation degradation, and pulsation and wear on mechanical parts. Few data are available on the prevalence of phase voltage imbalance. Some evidence suggests losses can be increased by 25% for a voltage imbalance as small as 2%.

VOLTAGE FLUCTUATION Unlike imbalance, voltage fluctuations are changes in the root-mean square voltage of all phases caused by changes in the utility source or equipment switching. Reductions in voltage counter motor oversizing by increasing motor efficiency and power factor in oversized motors. This is the principal source of savings from utility conservation voltage-reduction programs.

POWER FACTOR CORRECTION The power factor in small to medium-sized motors operating at partial load can be quite low (40%–50% in some cases). This low power factor increases the electrical losses in all components upstream of the motor by causing the electrical system to produce more reactive power, which produces no real work. Some larger customers may have to pay power-factor penalties for power factors below a range of 85%–95%. In these cases, it is usually economical to install power-factor correction, although few applications are found above 50 hp. Power-factor controllers also provide soft-start capabilities.

HARMONICS Harmonics are the distortion of an ideal AC voltage or current sinusoidal waveform. Causes include switching power supplies, electronic fluorescent light ballasts, and even adjustable-speed drives and power-factor controllers. Current that is drawn at some frequency other than 60 Hz produces no useful torque in the motor (without ASDs), because the rotor is trying to match the synchronous speed of the rotating stator field. Harmonics can affect the efficiency of motors by increasing the losses in the windings and producing torque pulsation in the motor.

■ **APPLICABILITY**

Any site with voltage imbalance problems, power-factor charges, or significant harmonics content.

DEMAND MANAGEMENT OBJECTIVE Strategic conservation

■ **FOR MORE INFORMATION**

NEMA, "Effects of Unbalanced Voltages on the Performance of Polyphase Induction Motors," Bulletin MG1-14.35 (1987).

Table C-33. Voltage Imbalance: Costs and Benefits*

Motor Size (hp)	Average Size (hp)	Rated Efficiency (%)	1% Imbalance				New Efficiency and Additional Annual Cost				4% Imbalance			
			(derating: 1%)		2% Imbalance		(derating: 5%)		(derating: 10%)		(derating: 17%)			
			New Eff. (%)	Cost (\$)	New Eff. (%)	Cost (\$)	New Eff. (%)	Cost (\$)	New Eff. (%)	Cost (\$)	New Eff. (%)	Cost (\$)	New Eff. (%)	Cost (\$)
<1	0.28	70.0	69.4	1	66.9	4	63.7	8	58.9	15	58.9	15		
1-5	1.34	80.5	80.1	2	75.5	9	76.4	13	73.3	34	73.3	34		
5.1-20	8.61	85.0	84.7	6	83.5	39	81.8	81	79.5	147	79.5	147		
21-50	25.9	89.0	88.8	15	87.9	78	86.7	152	84.9	290	84.9	290		
51-125	80.6	91.0	90.8	37	90.1	189	89.1	392	87.7	700	87.7	700		
>125	195	93.3	93.2	63	92.6	324	91.9	668	90.8	1188	90.8	1188		

* Assumes 4000 hr operation and \$0.07/kwh. Derating percentages are based on NEMA constant temperature derating factors for induction motors.

MAINTENANCE PRACTICES**■ DESCRIPTION**

Good maintenance practice can improve the performance of rotating equipment while improving energy efficiency by as much as 10%–15%. Refer to Table C-34 to see the cost impact of a single-percentage-point change in motor efficiency. The double benefit from motor system maintenance calls for careful record keeping, data collection, and analysis. It is not enough to collect motor performance data. These data must be analyzed and compared with expectations and trends. This brief provides a guide for common motor maintenance practices.

INSTALLATION The best maintenance practices cannot overcome poor installation. Alignment of the motor with the load is critical.

BELT TENSIONING Proper tensioning in V-belt transmissions is critical to their performance and lifetime. Other shaft-applied transmission equipment may require as much or more maintenance effort as the motor itself.

ELECTRICAL MONITORING Electrical measurements on the motor can indicate imminent motor failure. Useful measurements include winding resistance, mega-ohm readings of winding insulation to ground, and input phase voltage and current balance. More advanced monitoring might include power-factor and harmonic-content monitoring. See brief #26 on power supply.

LUBRICATION Regular and careful lubrication should be performed with proper materials by skilled people. Overlubrication can decrease the life of the bearing, blow out seals (introducing dirt into the bearing), and inhibit heat transfer by collecting dirt. The consequences of improper lubrication are so severe that careful scheduling and monitoring of lubrication practice is important.

Table C-34.

1 Assumes motors operating at 75% of their rated horsepower.

VIBRATION MONITORING Vibration monitors are easy to use and provide quick information on rotor warping and bearing failure. Trend information can be quite valuable.

TEMPERATURE Heating is a proxy measurement for most types of motor failures. Instrumentation can be as sophisticated as infrared imaging equipment or as simple as stick-on liquid crystal display meters. Again, tracking temperature trends is quite valuable in diagnosing motor failure.

■ **APPLICABILITY**

All medium to large motor installations. Especially applicable to locations with many motors.

DEMAND MANAGEMENT OBJECTIVE Strategic conservation

COST Costs are highly local depending on labor rates and time required for each procedure.

TRANSMISSION EFFICIENCY

■ DESCRIPTION

Methods other than DC motors and adjustable-speed drives (ASDs) exist for speed control. This brief treats speed control in the transmission applied between the motor and the driven load. One common way of controlling the flow of liquid and gases is through the use of flow-restriction devices such as throttling valves, inlet vanes, and outlet dampers. These methods, although inexpensive to install, are not energy efficient. Using a throttling device is analogous to driving your car with the accelerator always on the floor while using the brakes to change your speed!

Speed control devices installed between the motor and driven load have either a fixed speed ratio (e.g., gears and belts) or a variable speed ratio (e.g., hydraulic coupling, eddy current drives, and friction disks).

In retrofit applications, space constraints often preclude consideration of transmission speed control. More often, a retrofit considers the replacement of the transmission with an ASD, which is generally more efficient and needs less maintenance. In new designs, transmission speed control competes with electronic ASDs for smaller loads on the basis of cost.

The advantages of transmission speed control include

- No harmonic injection into the distribution system
- Often less costly than ASD.

Gross oversizing of a transmission has the same effect as in motors. Delivered power is reduced while losses remain constant, thereby dramatically reducing efficiency. Table C-35 shows the characteristics of various gear-type transmissions. Table C-36 shows the characteristics of general categories of transmissions.

Table C-35.
Characteristics of Various
Geared Speed Reducers

Type	Ratio Range	Efficiency Range (%)	Maximum Horsepower
Helical	2:1-400:1	92-98	10000
Bevel	1:1-5:1	97	2000
Bevel/helical	5:1-200:1	92-95	3500
Planetary	3:1-1000:1	91-97	900
Worm	5:1-70:1	55-94	800
Worm/helical	20:1-1750:1	55-94	150
Cycloidal	6:1->	85-93	200

Source: "The State of the Art: Drivopower," COMPEXITEK™, Rocky Mountain Institute (April 1989).

■ **APPLICABILITY**

All loads requiring variable speed from fractional to thousands of horsepower.

DEMAND MANAGEMENT OBJECTIVE Strategic conservation

Table C-36.
Characteristics of Motor Transmission Applied Between the Motor and the Driven Load

Adjustable Pulleys	Friction Disks	Hydraulic Couplings	Eddy Current Drives	Traction Drives	Gear Drives
~95% efficient	Up to 10:1 speed reduction	Up to 5:1 speed reduction	Uses 2% of the rated drive power for generation and control of the mag- netic field in the drive	Compact and rugged	Variety of designs
\$50-\$800 hp (higher for smaller drives)	\$300-\$500 hp	Efficiency is an inverse function of speed reduc- tion. For 50% speed reduction the efficiency is typically 40%.	1.5-2000 hp available Up to 3:1 ratio either reduction or increase	1-17 hp ratings Up to 3:1 ratio either reduction or increase	55%-98% efficiency depending on reduc- tion ratio and number of stages

Table C-36.

Characteristics of Motor Transmission Applied Between the Motor and the Driven Load (Concluded)

Adjustable Pulleys	Friction Disks	Hydraulic Couplings	Eddy Current Drives	Traction Drives	Gear Drives
Limited to 125 hp or less	Limited to a few horsepower	1-10,000 hp available	\$100-5000 hp (less expensive per horsepower for larger drives)	75%-90% efficient	Fractional to thousands of hp
Not suitable for shock loads because of pulley slippage	77%-90% efficient	Bulky	Applicable to loads operating at 70%-100% of rated speed most of the time	Precise speed control	Ratios >1000:1 available
Up to 3:1 speed reduction available	No automatic controls		Bulky	\$300-\$1300 hp depending on size	Shock loading
	Limited shock loading		Reliable in clean environments		

END

**DATE
FILMED**

08 / 10 / 91

1