FEB 02 1989

APCALL - BEAM POSITION MONITOR PROGRAM

R. A. Early
Stanford Linear Accelerator Center
Stanford University, Stanford, California 94305

I. INTRODUCTION

APCALL is an applications program operational on the PEP MODCOMP IV computer for the purpose of converting beam position monitor (BPM) button voltage readings to x,y coordinates. Calibration information and the BPM readings are read from the MODCOMP IV data base. Corresponding x,y coordinates are written in the data base for use by other programs. APCALL is normally activated by an other program but can be activated by a touch panel for checkout purposes.

II. THE DATA BASE

The use of the data base is described here for completeness.

Each read or write data base record consists of no more than 108 16-bit words (INTEGER*2) or 54 32-bit words (REAL*4) and occupies a track on the MODCOMP disk pack.

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

To read from, or write to the data base:

CALL GETXX(ID,N,ARRAY)

CALL PUTXX(ID,N,ARRAY)

ARRAY will contain N 16-bit words of data contained in location ID. The first word of ARRAY is always the number of 16-bit words of data in ARRAY which immediately follow. If ARRAY is REAL*4, then ARRAY(1) must also be REAL*4, but its value must still be the number of half-words to follow. For example: to write 30 REAL*4 data words using PUTXX, N is 60, and ARRAY(1) is set to 60. ARRAY must contain 31 words, all of which are written on the disk, since ARRAY(1) is already used. On a call to GETXX, however, N should usually be set to 108 because the number of data words in the file is unknown until the actual read has been done.

ID is obtained from:

CALL GETID(NAME,NMAX,ID,NN)

NAME contains the alphanumeric name of the data set (like '2C1/XX1. '), NMAX is the maximum number of signals wanted, ID is an array of location numbers, and NN is the number of signals actually found.

Since the maximum number of half-words which can be read or written in one call is 108, the BPM calibration constants must be broken up into many separate data base locations.

MASTER

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

III. THE HELM FITTING CONSTANTS

The BPM's have been calibrated by J-L Pellegrin's group and the results analysed by R. Helm. This process is described in PTM-162. The four button voltages for each of 25 different x,y positions have been entered in a WYLBUR library (WYL.RL.EYG.LJB) with the BPM serial number as the member name. A two-dimensional polynomial fit was performed and it was found best to classify the BPM's into four fitting families, each having it's own set of coefficients (15 in x and 15 in y). In addition each monitor has associated with it two sets of offset constants u,v and x,y. Each installed monitor has a location number in the ring (like 7A8). So that for each monitor installed in the ring, the following information is required:

- 1) POLYNOMIAL COEFFICIENTS
- 2) SERIAL NO, FAMILY NO, LOCATION NO
- 3) U,V OFFSET CONSTANTS
- 4) X,Y OFFSET CONSTANTS

And to compute the x,y coordinates of the beam we need:

- 5) BUTTON READINGS
- 6) LOCATION TO WRITE X,Y

In the case of item 2 above, APCALL really only needs the family number. The serial number and location numbers help in checkout runs and provide a ready access to a record of which was installed where.

IV. PROCEEDURE FOR LOADING THE DATA BASE

The results of Helm's fitting routines are written on disk files. WYL.RL.RAE.LIB(BPMCAL1) reads these files and writes them out in a format suitable for downloading into the MODCOMP data base. Although nearly all of the BPM's have been calibrated, only those actually installed can be put into the data base because the location numbers of uninstalled monitors are unknown. For this reason, the data base will have to be modified from time to time until all are installed.

BPMCAL1 sets up a list of allowed location numbers, partly from data cards, and assumes complete symmetry of location numbers around the ring. If some region has a unique location number, it will have to be edited in by hand on WYLBUR. All else is completely automatic and requires no touching of the data "by human hands." As monitors are installed, their position numbers and calibration serial numbers are added to the data cards at the end of BPMCAL1.

The procedure is then to get BPMCAL1 into an active WYLBUR file, RUN-HOLD and FETCH the output. Delete everything before the data base output, renumber, save in WYL.RL.RAE.LIB(ISD.CAL1) and then download ISD.CAL1 into the MODCOMP data base.

The first four pages of ISD.CAL1 are appended to illustrate the data base format.

Raw button voltage readings from the BPM calibrations can also be downloaded for checkout purposes by following the exact same procedure with WYL.RL.RAE.LIB(BPMCAL2). The data cards for this program are the same as for BPMCAL1. The member name is now ISD.CAL2.

These codes and procedures allow a complete verification of the data base constants and APCAL1 by comparing the x,y results directly with those of Helm which were generated after his fitting process. This check has been (and should be) made with every change to the data base.

For the case of empty locations (no monitor installed), the offset constants and family numbers are set to zero and the serial numbers and position numbers are filled with blanks in the data base.

V. APCAL1

The alphanumeric data base names required by APCAL1 are passed in the OWNLIS array from the calling program. For checkout purposes, SUBROUTINE SUBDAT is included to fill the OWNLIS array when APCAL1 is initiated by touch panel T402. At this writing, the A MODCOMP contains the working version of APCAL1 and the B MODCOMP contains identical coding and data base information. The difference is that all WRITE statements and the call to SUBDAT are commented out on the

A machine. New versions of the data base should be tested on the B machine to avoid interference with other users, since to test all BPM's, there is a considerable amount of printout.

OWNLIS(10) -> OWNLIS(13) CONTAIN COEFF CAL'IB DATA
e.g. 'ZC/XX1.'

OWNLIS(20) -> OWNLIS(23) CONTAIN FAMILY NUMBERS
e.g. 'WRH/XX1.'

OWNLIS(30) -> OWNLIS(33) CONTAINS U,V OFFSET CONSTANTS
e.g. 'WRH/XX2.'

OWNLIS(40) -> OWNLIS(43) CONTAINS X,Y OFFSET CONSTANTS
e.g. 'WRH/XX3.'

OWNLIS(50) -> OWNLIS(54) CONTAIN THE RAW BUTTON READINGS
e.g. 'WRPH/XX1.'

OWNLIS(60) -> OWNLIS(64) CONTAIN 15 X'S, THEN 15 Y'S
CLOCKWISE AROUND RING
e.g. 'WRPH/XX3.'

OWNLIS is filled by either a call to PBEGIN or SUBDAT. Next, GETID is called for the six alphanumeric ID names to get their corresponding location numbers. If any of these calls fail to return an ID location number, the code will fail, so an error message is printed out on the line printer and control is returned to the calling program. The error message indicates which call to GETID failed.

The second call to GETID (above) returns the number of half-planes which are to be treated.

Next, the fitting coefficients are read from the data base and stored in a two-dimensional array ARR(30,4).

For each half-plane, a call to GETXX brings in the family numbers and serial numbers for each monitor installed in the ring. Monitor information is stored in the data base in a clockwise direction around the ring. In an "A" half-plane, the monitor nearest the symmetry plane is first and that nearest the IR last, while in a "B" half-plane, the monitor nearest the IR is first and that nearest the symmetry plane last.

There are fifteen allowed positions per half-plane. Fourteen have been assigned position numbers, one is labeled SPEAR. Family numbers and names are stored in strings of seven 1*2 words. The first three words contain the calibration serial number (3A2), the next word is the Helm fitting family number (A2), and the final three words contain the ring position number (3A2). The first word of the array filled by the call to GETXX contains the number of half-words to follow and is divided by seven to get the number of monitors in the list. All that is required for APCAL1 is the family number. If J is the index of a monitor, then $JJ = 7 * J - 2$ is the index of the corresponding family number. The family number is in ASCII and is converted to binary by subtracting off the ASCII bits.

The U,V offsets are obtained next by a call to GETXX for the half-plane under consideration. Again, the first word in the array filled by the call is the number of half-words to follow and is divided by four to obtain the number

of monitors in the list, since each monitor has two REAL*4 offset constants.

The X,Y offset constants are obtained next in the exact same manner as for the U,V offsets.

Raw button readings are obtained next, followed by the computation of x and y using the appropriate constants, but first we must deal with an awkward feature of the data base structure. So far, we are in a loop, reading from the data base a half-plane at a time in a clockwise sense. The alphanumeric data base names have the form WRH, where R and H can take on the values 1 to 6 and 1 to 2 respectively. The rightmost index runs first so that we get ID numbers in the order:

W11
W12
W21
W22
...
...
W62

But the BPM button readings and the corresponding x,y output information has the form WRPH, where P is either 1 or 2 depending on whether a positron or an electron bunch is under consideration. The calls to GETID return an array of ID location numbers. These are in the same order as the order of the alphanumeric data base name, so that in order to avoid unnecessary calls having the format WRH, the indices of the ID array of WRPH data are computed so that two values of P are handled for a given WRH.

ID index for WRH

1	W11
2	W12
3	W21
4	W22
5	W31
6	W32
7	W41
8	W42

ID index for WRPB

1	W111
2	W112
3	W121
4	W122
5	W211
6	W212
7	W221
8	W222

matching R's and H's:

1	W11
2	W12
3	W21

1	W111
3	W121
2	W112
4	W122
5	W211
7	W221

So if the ID index for WRH is odd, then the two
corresponding indices for WRPB are: $IDwr1h = 2 * IDwrh - 1$
and: $IDwr2h = 2 * IDwrh + 1$

If the ID index for wrh is even, then the two
corresponding indices for WRPB are: $IDwr1h = 2 * IDwrh - 2$
and: $IDwr2h = 2 * IDwrh$

Now, for values of $P = 1$, then for $P = 2$, the button
readings can be read from the data base and the corresponding
x,y pairs calculated and written into the data base.

GETXX is called to fill the array BUTN. The first word
of BUTN is divided by four to get the number of monitors in
the list. The index for the Jth monitor is: $I = 4 * J - 2$.
The four button readings per monitor are labeled R1,R2,R3,
and R4 and their sum S. Button readings are stored as
integer in the data base, but are floated for computations.

We now loop through the monitor positions in the half-plane. If the family number for a monitor location is 0, the reading is flagged as bad, since it means that there is no calibration data in the data base.

If $S = 0$, the reading is bad, or the monitor is unconnected. The reading is flagged as bad.

If more than one button reading is below a tolerance (VTOL, set in a data statement at the head of the program), the reading is flagged as bad.

If more than one button is below the product of a relative tolerance (RTOL, set in a data statement) and S , the reading is flagged as bad.

In the case of bad readings, or unconnected monitors, both x and y are set to 999.

The U and V functions are computed from:

$$U = (R1 - R2 - R3 + R4) / S - Uoffset$$

$$V = (R1 + R2 - R3 - R4) / S - Voffset$$

Most of the monitors are in one family. Because of this, but mostly for clarity, the fitting coefficients are relabeled to be exactly the same as in Helm's fitting program. This only has to be re-done when the family number changes.

$CX(L) = ARR(L,K)$ Where L runs from 1 to 15

$CY(L) = ARR(L+15,K)$ and K is the family number.

Finally:

$$\begin{aligned} X = & (((CX(15)*U+CX(14)*V+CX(13))*U \\ & + ((CX(12)*V+CX(11))*V+CX(10))*U \\ & + ((CX(9)*V+CX(8))*V+CX(7))*V+CX(6))*U \\ & + (((CX(5)*V+CX(4))*V+CX(3))*V+CX(2))*V+CX(1) \\ & - XOFF(J) \end{aligned}$$

$$\begin{aligned} Y = & ((CY(15)*U+CY(14)*V+CY(13))*U \\ & + ((CY(12)*V+CY(11))*V+CY(10))*U \\ & + ((CY(9)*V+CY(8))*V+CY(7))*V+CY(6))*U \\ & + (((CY(5)*V+CY(4))*V+CY(3))*V+CY(2))*V+CY(1) \\ & - YOFF(J) \end{aligned}$$

The array BUFGY is filled, first with 15 x values for the half-plane, then with 15 y values. Again, the first word of BUFGY is the number of half-words to follow, in this case 60.

BUFGY is written out on the data base by a call to PUTXX and control is returned to the calling program.

CAUTION

The fitting coefficients are only valid over the range of ± 10 mm in x and y. Further, since there are cross terms in u and v, one cannot expect linearity for even small values of either u or v if one of them is large. This has caused some confusion on occasions when monitors were being checked out with actual voltages on the BPM buttons.

BPY DATA BASE FORMAT NCV 20, 1979

* 2*15 CONSTANTS FOR X,Y PLANE CALC FROM BPM FAMILY # 1
 * FOR C= 1 (FAMILY # 1)

ZC1/XX1, SC=XX, XR=1 30., XR=33 30.
 , XR= 3 0.0 , XR=35 0.0
 , XF= 5 -7.23536E-01, XR=37 6.58227E+01
 , XR= 7 -1.58329E-04, XR=39 -6.84084E+00
 , XP= 9 -2.76223E+00, XR=41 3.96119E+01
 , XR=11 2.61107E-01, XR=43 1.37101E+02
 , XP=13 6.59729E+01, XR=45 6.69256E-01
 , XR=15 -3.03176E+00, XR=47 -2.04193E+00
 , XP=17 -1.61776E+01, XR=49 4.26040E+00
 , XR=19 3.95623E+01, XR=51 -1.19645E+01
 , XR=21 5.51919E+00, XR=53 4.31749E-05
 , XF=23 5.02181E+00, XR=55 -1.84745E+01
 , XR=25 3.02428E+01, XR=57 5.48954E+01
 , XF=27 3.63564E+01, XR=59 2.91379E-04
 , XR=29 -1.04321E-02, XR=61 2.61947E+01
 , XR=31 -2.92776E+02, XR=63 -7.42869E+01

* 2*15 CONSTANTS FOR X,Y PLANE CALC FROM BPM FAMILY # 2
 * FOR C= 2 (FAMILY # 2)

ZC2/XX1, SC=XX, XR=1 30., XR=33 30.
 , XR= 3 0.0 , XR=35 0.0
 , XR= 5 3.29979E-01, XR=37 4.90945E+01
 , XR= 7 1.02259E+00, XR=39 3.04746E+00
 , XR= 9 -6.24802E+00, XR=41 2.76612E+01
 , XF=11 -2.09563E+01, XR=43 -9.24211E+01
 , XR=13 4.92062E+01, XR=45 6.69345E-01
 , XR=15 2.80577E+00, XR=47 -8.03648E-01
 , XR=17 -2.19615E+01, XR=49 5.07739E+00
 , XR=19 -3.48900E+01, XR=51 -1.39881E+01
 , XF=21 -7.03893E+00, XR=53 7.81522E+00
 , XR=23 7.70733E-01, XR=55 -1.46626E+01
 , XR=25 4.38412E+01, XR=57 3.60285E+01
 , XR=27 3.50348E+01, XR=59 -1.02978E+01
 , XR=29 -3.00276E+01, XR=61 7.21756E+01
 , XR=31 1.55337E+02, XR=63 -1.67256E+02

* 2*15 CONSTANTS FOR X,Y PLANE CALC FROM BPM FAMILY # 3
 * FOR C= 3 (FAMILY # 3)

ZC3/XX1, SC=XX, XR=1 30., XR=33 30.
 , XR= 3 0.0 , XR=35 0.0
 , XR= 5 -1.20820E-01, XR=37 3.23985E+01
 , XP= 7 -2.86175E+00, XR=39 5.31229E-01
 , XR= 9 4.67812E-02, XR=41 2.31883E+01
 , XR=11 -1.40543E+00, XR=43 -9.79847E-01
 , XR=13 1.60501E+01, XR=45 1.46328E-01
 , XR=15 -3.59784E-01, XR=47 3.30934E-01
 , XR=17 -1.62544E+01, XR=49 -1.63880E-01
 , XR=19 3.49254E-04, XR=51 -2.64983E+00
 , XR=21 6.94639E-01, XR=53 -2.62620E-01
 , XF=23 3.46972E-02, XR=55 -2.81358E+01
 , XR=25 1.47176E+00, XR=57 1.09760E-03
 , XR=27 1.00486E+01, XR=59 4.72142E-02
 , XR=29 4.45308E-01, XR=61 1.92653E+00
 , XR=31 1.24756E+00, XR=63 1.89060E-02

* 2*15 CONSTANTS FOR X,Y PLANE CALC FROM BPM FAMILY # 4

* FOR C= 4 (FAMILY # 4)

2C2/XX1, SC=XX, XF=1 30., XR=33 30.
 , XP= 3 0.0 , XR=35 0.0
 , XR= 5 -6.68831E-02, XR=37 3.22176E+01
 , XR= 7 -1.76170E+00, XR=39 1.10249E+00
 , XR= 9 -7.64983E-01, XR=41 3.02929E+01
 , XR=11 3.11417E+00, XR=43 -5.23360E+00
 , XR=13 1.64091E+01, XR=45 1.43548E-01
 , XR=15 -1.84137E-01, XR=47 6.21298E+00
 , XR=17 -1.35473E+01, XR=49 -8.14961E-01
 , XR=19 -1.57420E+00, XR=51 -1.23659E+01
 , XR=21 -5.65256E-01, XR=53 -9.85723E-02
 , XR=23 -2.53022E-01, XR=55 -1.95892E+01
 , XR=25 -8.08958E+00, XR=57 1.11185E+00
 , XR=27 1.17592E+01, XR=59 -3.15253E-01
 , XR=29 4.10109E-01, XR=61 -9.83773E+00
 , XR=31 -2.91264E+00, XR=63 -1.93233E-01

* 7*15 BPM CALIBRATION SERIAL NOS

* E.G. - 14A06<P> WHERE F=HELMS FAMILY NO

* FOR R = 1 H = 1

WP1H1/XX1, SC=XX, XI=1 105
 , XA= 2 ' 0 1B9 '
 , XA= 9 ' 0 1B8 '
 , XA= 16 '14B14 3 1B7 '
 , XA= 23 '14B07 3 1B6 '
 , XA= 30 '14B05 3 1B5 '
 , XA= 37 '14B06 3 1B4 '
 , XA= 44 '14B09 3 1B3 '
 , XA= 51 '14B03 3 1B2 '
 , XA= 58 '14B12 3 1B1 '
 , XA= 65 'MCR05 3 2A579'
 , XA= 72 ' 0 2A360'
 , XA= 79 ' 0 2A200'
 , XA= 86 ' 0 2A095'
 , XA= 93 ' 0 2A050'
 , XA=100 ' 0 2SPAR'

* 2*15 BPM ALIGNMENT, CALIBRATION OFFSET CONSTANTS U,V:

* FOR: R = 1 H = 1

WP1H1/XX2, SC=XX, XR=1 60.
 , XR= 3 0.0 , XR= 5 0.0
 , XR= 7 0.0 , XR= 9 0.0
 , XR= 11 1.15163E-02, XR= 13 -1.97580E-02
 , XR= 15 -4.71006E-02, XR= 17 1.49882E-02
 , XR= 19 -5.52421E-02, XR= 21 -1.19441E-02
 , XR= 23 7.52761E-03, XR= 25 -3.71890E-02
 , XR= 27 3.47072E-02, XR= 29 -1.32966E-03
 , XR= 31 6.71366E-02, XR= 33 -2.69408E-02
 , XR= 35 2.77244E-02, XR= 37 3.06814E-02
 , XR= 39 2.38574E-02, XR= 41 9.64981E-03
 , XR= 43 0.0 , XR= 45 0.0
 , XR= 47 0.0 , XR= 49 0.0
 , XR= 51 0.0 , XR= 53 0.0
 , XR= 55 0.0 , XR= 57 0.0
 , XR= 59 0.0 , XR= 61 0.0

* 2*15 BPM ALIGNMENT, CALIBRATION OFFSET CONTSANTS X,Y:

* FOR: F = 1 H = 1

* WF1H1/XX3, SC=XX, XF=1 60.

, XR= 3 0.0	, XR= 5 0.0
, XR= 7 0.0	, XR= 9 0.0
, XR= 11 0.0	, XR= 13 0.0
, XR= 15 0.0	, XR= 17 0.0
, XR= 19 0.0	, XR= 21 0.0
, XR= 23 0.0	, XR= 25 0.0
, XR= 27 0.0	, XR= 29 0.0
, XR= 31 0.0	, XR= 33 0.0
, XR= 35 0.0	, XR= 37 0.0
, XR= 39 0.0	, XR= 41 0.0
, XR= 43 0.0	, XR= 45 0.0
, XR= 47 0.0	, XR= 49 0.0
, XR= 51 0.0	, XR= 53 0.0
, XR= 55 0.0	, XR= 57 0.0
, XR= 59 0.0	, XR= 61 0.0

* 7*15 BPM CALIBRATION SERIAL NOS

* E.G. - 14A06<P> WHERE F=HELMS FAMILY NO

* FOR F = 1 H = 2

* WF1H2/XX1, SC=XX, XI=1 105

, XA= 2	0 2B050'
, XA= 9	0 2B095'
, XA= 16	0 2B200'
, XA= 23	0 2B360'
, XA= 30	3 2B579'
, XA= 37	3 3A1
, XA= 44	3 3A2
, XA= 51	0 3A3
, XA= 58	3 3A4
, XA= 65	4 3A5
, XA= 72	3 3A6
, XA= 79	3 3A7
, XA= 86	0 3A8
, XA= 93	0 3A9
, XA= 100	0 3SPAR

* 2*15 BPM ALIGNMENT, CALIBRATION OFFSET CONTSANTS U,V:

* FOR: R = 1 H = 2

* WF1H2/XX2, SC=XX, XR=1 60.

, XR= 3 0.0	, XR= 5 0.0
, XR= 7 0.0	, XR= 9 0.0
, XR= 11 0.0	, XR= 13 0.0
, XR= 15 0.0	, XR= 17 0.0
, XR= 19 3.43313E-02	, XR= 21 2.31230E-02
, XR= 23 4.92003E-02	, XR= 25 3.44205E-02
, XR= 27 4.25719E-02	, XR= 29 -2.55660E-02
, XR= 31 0.0	, XR= 33 0.0
, XR= 35 1.52175E-03	, XR= 37 -1.55571E-02
, XR= 39 4.06917E-03	, XR= 41 -3.00765E-03
, XR= 43 5.01412E-02	, XR= 45 4.76791E-02
, XR= 47 2.04538E-02	, XR= 49 -2.59090E-03
, XR= 51 0.0	, XR= 53 0.0
, XR= 55 0.0	, XR= 57 0.0
, XR= 59 0.0	, XR= 61 0.0


```

*
*
* 2*15 BPM ALIGNMENT, CALIBRATION OFFSET CONSTANTS X,Y:
* FOR: R = 1 H = 2
WF2H2/XX3, SC=XX, XR=1 60.
, XF= 3 0.0 , XR= 5 0.0
, XR= 7 0.0 , XR= 9 0.0
, XR= 11 0.0 , XR= 13 0.0
, XR= 15 0.0 , XR= 17 0.0
, XR= 19 0.0 , XR= 21 0.0
, XR= 23 0.0 , XR= 25 0.0
, XR= 27 0.0 , XR= 29 0.0
, XR= 31 0.0 , XR= 33 0.0
, XR= 35 0.0 , XR= 37 0.0
, XR= 39 0.0 , XR= 41 0.0
, XR= 43 0.0 , XR= 45 0.0
, XR= 47 0.0 , XR= 49 0.0
, XR= 51 0.0 , XR= 53 0.0
, XR= 55 0.0 , XR= 57 0.0
, XR= 59 0.0 , XR= 61 0.0
*
* 7*15 BPM CALIBRATION SERIAL NOS
* E.G. - 14A06<F> WHERE F=HELMS FAMILY NO
* FOR R = 2 H = 1
WF2H1/XX1, SC=XX, XI=1 105
, XA= 2 ' 0 3B9 '
, XA= 9 ' 0 3B8 '
, XA= 16 '14B40 3 3B7 '
, XA= 23 '14B42 3 3B6 '
, XA= 30 '14B19 3 3B5 '
, XA= 37 '14B20 3 3B4 '
, XA= 44 '14B22 3 3B3 '
, XA= 51 '14B37 3 3B2 '
, XA= 58 '14B23 3 3B1 '
, XA= 65 'MCR06 3 4A579'
, XA= 72 ' 0 4A360'
, XA= 79 ' 0 4A200'
, XA= 86 ' 0 4A095'
, XA= 93 ' 0 4A050'
, XA=100 ' 0 4SPAF'
*
*
* 2*15 BPM ALIGNMENT, CALIBRATION OFFSET CONSTANTS U,V:
* FOR: R = 2 H = 1
WF2H1/XX2, SC=XX, XR=1 60.
, XR= 3 0.0 , XF= 5 0.0
, XR= 7 0.0 , XF= 9 0.0
, XR= 11 -1.79926E-02, XF= 13 1.86274E-02
, XR= 15 1.34043E-02, XR= 17 4.32331E-02
, XR= 19 2.36214E-02, XF= 21 -6.12400E-03
, XR= 23 -1.28009E-02, XR= 25 1.03560E-02
, XR= 27 -3.30190E-02, XR= 29 4.77947E-03
, XR= 31 -1.09786E-02, XR= 33 9.54076E-03
, XR= 35 -3.83007E-02, XR= 37 -5.32246E-02
, XR= 39 3.32971E-02, XR= 41 1.58928E-04
, XR= 43 0.0 , XR= 45 0.0
, XR= 47 0.0 , XR= 49 0.0
, XR= 51 0.0 , XR= 53 0.0
, XR= 55 0.0 , XR= 57 0.0
, XR= 59 0.0 , XR= 61 0.0

```