Manufactured Homes Acquisition Program

DOE/BP/35738--5

Heat Loss Assumptions and Calculations Heat Loss Coefficient Tables

DE92 015598

Bob Davis
David Baylon

April 1992

Ecotope, Inc.
Seattle, Washington 98112

Prepared for Bonneville Power Administration
under Contract Number DE-AM79-91BP13330
Task Order AT79-91BP25112
Contract Manager Steven Onisko

MASTER

ds
DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

Table of Contents

1 Introduction	1
2 Heat Loss Methodology	2
2.1 Thermal Conductivities	3
2.1.1 Standard Building Materials	3
2.1.2 Fiberglass Batt Insulation	4
2.1.3 Rigid Board Insulation	6
2.1.4 Blown-in Insulation	7
2.2 Parallel Heat Loss Calculations	8
2.3 Buffered Heat Loss	9
3 Component Analysis	10
3.1 Floor Systems	10
3.1.1 Construction Techniques	10
Transverse Floor System	10
Upright Transverse Floor System	11
Longitudinal Floor System	11
3.1.2 Thermal Analysis	12
Insulation Compression and Conductance	12
Effect of Forced Air Furnace and Ducts on Floor Performance	13
3.2 Ceiling Systems	15
3.2.1 Insulation Techniques	15
3.2.2 Thermal Analysis	17
3.3 Wall Systems	20
3.3.1 Construction Techniques	20
Post and Beam Walls	20
Stress-Skin Walls	21
3.3.2 Thermal Analysis	21
3.4 Windows	22
3.4.1 Window Types	23
Vinyl Frame Window	23
Wood Frame Window	23
Other Window Frames	23
3.4.2 Glazing Products	23
Multiple Glazings	23
Argon Fill	24
Low- ϵ Coatings	24
3.4.3 Testing and Simulation	25
3.5 Skylights	25
3.6 Opaque Doors	26
4 Acknowledgments	27
5 References	28
COMPONENT U-FACTORS	29
FLOOR SYSTEMS	30

CEILING SYSTEMS	38
WALL SYSTEMS	53
WINDOWS	58
SKYLIGHTS	61
OPAQUE DOORS	62

Table of Figures

Insulation Compression Regions, R-33 Floor System	12
Uninsulated Slots Over Truss Members	15
Oversized Batts Covering Truss Members	16
Ceiling System With Crushed Batts, Baffle, and Soffit Vents	16
Ceiling System With Crushed Batts and Gable Vents	17
Detail at Truss Edge for Blown-in Insulation	18

Table of Tables

Thermal Resistances for Air Spaces and Surfaces	3
Thermal Resistances for Standard Building Components	4
Comparison of Specifications and Calculated R-Values	6
R-Value Per Inch of Rigid Insulation Types	7
Loose Fill Insulation Values	8
Heating System Efficiency Factors	14
Wall Framing Factors	22

1 Introduction

This manual is intended to assist builders of manufactured homes in assessing the thermal performance of structural components (floors, ceilings, walls, and windows) used in the Manufactured Housing Acquisition Program (MAP) sponsored by the Bonneville Power Administration (BPA). U-factors for these components are calculated using the ASHRAE (1989) parallel heat loss method, with adaptations made for the construction practices found in the Pacific Northwest manufactured home industry.

This report is divided into two parts. The first part describes the general assumptions and calculation procedures used to develop U-factors and R-values for specific materials used in the construction industry, overall U-factors for component sections, and the impact of complex framing and thermal configurations on various components' heat loss rates. The individual components of manufactured homes are reviewed in terms of overall thermal conductivity. This includes a section on each of the following:

- Floors: transverse, "upright transverse," and longitudinal floors, with the effect of duct losses included;
- Ceilings: flat and sloped ceilings, with different venting strategies, oversized and standard batts, and blown insulation;
- Walls: standard (post and beam) and stress-skin walls, with and without insulated sheathing;
- Windows, skylights, and opaque doors.

The second part contains tables showing the results of heat loss calculations expressed as U-factors for various configurations of the major building components: floor systems, ceiling systems, wall systems, windows, doors and skylights. These values can be used to establish compliance with the MAP specifications and thermal performance criteria or to compare manufactured homes built to different standards.

2 Heat Loss Methodology

An examination of the thermal conductivities of residential building materials serves three functions:

- 1) The first is to provide an estimate of the overall heat loss rate of a building through its individual components. This can be summed in order to estimate of the amount of heat which will flow from the building for each degree of temperature difference between the inside and outside of the building. The building heat loss rate is used to determine the amount of heat that needs to be supplied to the house under peak conditions, and the equipment required to supply this heat. This allows engineers and mechanical system designers to economically size heating systems which can be relied upon to give comfort to the building occupants under all reasonable conditions, within a particular climate.
- 2) The second purpose of the heat loss calculation is to provide a basis for estimating the long term performance of the dwelling in the context of the range of weather conditions which occur on average in a particular climate zone. In this context the heat loss rate is an essential input to performance prediction tools, and when combined with weather can predict the fueling requirements for heating a home over a long period of time.
- 3) The third use of heat loss calculations is to establish the overall compliance of a building with energy standards and energy codes. In this context, heat loss rates of individual components can be summed to establish an effective overall heat loss rate and can be used with code performance analysis tools such as WATTSUN and SUNDAY to establish whether a building meets the performance requirements set in the energy code standards.

The general heat loss calculation procedure is to develop a thermal conductivity for each component of the building which can be used in parallel with the other building components to establish the heat rate loss of the entire building. This procedure is area-weighted, that is; the calculation procedure assumes that heat flows through materials as a function of their overall area and thermal properties, independent of all other components contained in the building. Thus the sum of all the wall areas times the heat loss rate (U-factor) of all the wall areas will describe the total amount of heat that will flow through those walls under particular temperature conditions. This amount of heat, insofar as the building is maintained at a given temperature, will be completely independent of the amount of heat that flows through the windows or the ceiling, or any other building component.

Thermal conductivities for a number of standardized building components have been calculated and tabulated in this report. These calculations involve a number of assumptions regarding physical layout, construction practices, and materials, as well as environmental factors influencing heat loss. The assumptions used were derived from extensive investigation of building conditions in the manufactured home industry in the Pacific Northwest.

For most of the analysis, one-dimensional heat flow was assumed, with heat traveling perpendicular to the inside surface for all calculations. Only the floors were calculated using a combination of heating system simulation and parallel heat flow through the floor structure.

Manufacturing plant detailing and procedures were reviewed, particularly in wall, ceiling and floor construction, to provide a good representation of practices in this industry and to assess the need for modifications to upgrade building performances. Many of the details and procedures documented in the following sections represent modifications in existing practice designed to upgrade the overall thermal performance of manufactured homes.

2.1 Thermal Conductivities

2.1.1 Standard Building Materials

Thermal conductivities for the various standard building materials, air film resistances and dead air spaces were taken from the *1989 ASHRAE Handbook, Fundamentals* and are found in Tables 1 and 2.

TABLE 1			
THERMAL RESISTANCES FOR AIR SPACES AND SURFACES			
A. SURFACES			
Position of Surface	Direction of Heat Flow	R-Value (<i>hr • ft² • °F/Btu</i>)	
STILL AIR			
Horizontal	Upward	0.61	
Sloping 45 degrees	Upward	0.62	
Vertical	Horizontal	0.68	
Sloping 45 degrees	Downward	0.76	
Horizontal	Downward	0.92	
MOVING AIR (any position)			
15 mph	Any	0.17	
7.5 mph	Any	0.25	
B. AIR SPACES			
Position of Air Space	Direction of Heat Flow	Thickness (in.)	R-Value (<i>hr • ft² • °F/Btu</i>)
Horizontal	Upward	0.75	0.77
		1.5	0.80
		3.5	0.84
Sloping 45 degrees	Upward	0.75	0.82
		1.5	0.84
		3.5	0.86
Vertical	Horizontal	0.75	0.94
		1.5	0.90
		3.5	0.91
Sloping 45 degrees	Downward	0.75	0.99
		1.5	1.00
		3.5	1.00
Horizontal	Downward	0.75	1.02
		1.5	1.14
		3.5	1.22

- Notes:
- Adapted from *1989 ASHRAE Handbook, Fundamentals*.
  - Effective emissivity of surfaces assumed to be 0.9.
  - Effective emissivity of air spaces assumed to be 0.82.
  - Mean air temperature of air space assumed to be 50 °F
  - Temperature difference across air space assumed to be 30 °F

TABLE 2'		
THERMAL RESISTANCES FOR STANDARD BUILDING COMPONENTS		
DESCRIPTION	RESISTANCE (R) PER INCH THICKNESS (hr • ft ² • °F/Btu • inch)	RESISTANCE (R) FOR THICKNESS LISTED (hr • ft ² • °F/Btu)
BUILDING BOARD		
Gypsum Wall Board (GWB) - 1/2"	.	0.45
Gypsum Wall Board (GWB) - 5/8"	.	0.56
Plywood - 1/2"	.	0.62
Plywood - 3/4"	.	0.94
Plywood - 1-1/8"	.	1.41
Plywood Facing - 1/4"	.	0.31
Lapped Wood Siding - 1/2"	.	0.81
T-111 Siding - 1/2"	.	0.62
ROOFING AND FLOORING		
Roof (Plywood/Shingles)	.	1.12
Built-up Roof - 3/8"	.	0.33
Carpet and Rubber Pad	.	1.23
Floor Underlayment - 1/2"	.	0.53
Finish Floor - 3/4"	.	0.68
OTHER		
Wood Framing	1.25	.
Concrete	0.083	.

* Adapted from. 1989 ASHRAE Handbook, Fundamentals.

2.1.2 Fiberglass Batt Insulation

Fiberglass batt insulation has been produced for over fifty years and is currently made by a few major companies. In this period, the material itself has changed relatively little, although the sophistication of the manufacturing and quality control process has improved notably. The specifications for the R-values of individual fiberglass batts vary, depending upon the manufacturer (or even the manufacturing plant).

In spite of the relatively flexible nature of the manufacturing technology, relatively little standardizations exist in either the density or thickness of fiberglass batts. As a result, the manufacturer's specifications must be carefully reviewed. A further difficulty with fiberglass batts is that the specifications for R-values apply only to the manufacturer's specified thickness. In many configurations the batts must be compressed somewhat to fit into an available stud or roof cavity. R-19 fiberglass batts, for example, are specified 6 to 6-1/2 inches thick depending on manufacturer and as a result must be compressed 8-15% in order to fit into a 2 x 6 stud cavity. This problem has been reduced by the introduction of R-21 high-density batts, which deliver full R-value in a 2 x 6 stud cavity (5.5").

Each manufacturer has published the impact of various framing cavity thicknesses on their insulation batts. These compression corrections vary substantially, as shown in Table 3. Furthermore, these values do not represent necessarily the actual tested values but rather those values for which the insulation company will certify performance of the batts. It is safe to assume that these represent a somewhat conservative estimate of the insulation values actually achievable under these conditions.

In order to make this process somewhat less confusing and independent of manufacturers, a linear regression fit was done between these various products. This linear regression was conducted over compressed thicknesses that were between 100% of full manufacturer's specifications and 50% of full manufacturer's specifications. In this area, the manufacturer's specifications are roughly linear and, as a result, a good regression fit was possible on case by case basis. When all of these data were combined and standardized, a single equation was developed:

$$R_{Nom} = \left(4.53 + (K_n - 4.53) \frac{T_F}{T_I} \right) T_F \quad \text{Eq. 1.}$$

Where:

$$K_n = \text{R-Value per inch} \left(K_n = \frac{R_{man}}{T_I} \right)$$

$$R_{man} = \text{Manufacturer's specified R-Value}$$

$$T_I = \text{Initial batt thickness}$$

$$T_F = \text{Final batt thickness}$$

$$R_{Nom} = \text{Batt nominal R-Value}$$

R-value calculations from this equation are compared to the values specified by the manufacturers in Table 3. As can be seen, this equation generates equivalent R-values in all but a few cases. This allows for standardization of the calculation procedure given variations in manufacturer's specifications and quality control. The overall R^2 of the regression (predicted on manufacturer's R-value specification) is .998.

TABLE 3												
Comparison of Specified* and Calculated R-Values												
Nominal R-value of batt	38	38	38	30	30	30	22	21	19	19	13	11
Initial thickness (inches)	12	13	10.25	9.5	10.25	8.25	6.75	5.5	6.0	6.5	3.63	3.5
Final thickness (inches)	11.25	11.25	--	9.25	9.25	--	5.5	--	5.5	5.5	3.5	2.5
•Specified R-value	37	35		30	29		20		18	17	13	9
•Calculated R-value	36.6	35.3		29.6	28.5		19.2**		18.0	17.4	12.7	8.8
Final thickness (inches)	9.25	9.25		7.25	7.25		3.5		3.5	3.5	2.5	1.5
•Specified R-value	32	31		26	25		14		13	12	10	6
•Calculated R-value	32.2	31.3		25.2**	24.6		13.5		13.1	12.8**	9.7	5.9
Final thickness (inches)	7.25	7.25		5.5	5.5							1.5
•Specified R-value	27	26		21	20							6
•Calculated R-value	26.9	26.3		20.6	20.2							6.2

Bold entries are for high-density batts.

* Based on Owens-Corning & Manville Corporation thickness specifications.

** Rounds to a different value than manufacturer's data.

2.1.3 Rigid Board Insulation

Rigid board insulation differs markedly from fiberglass in that its manufactured size and specifications do not vary with installation or with manufacturing plants, etc. There are, however, many types of insulation with varying R-value characteristics. Table 4 illustrates the five main types of rigid insulation and the R-values per inch of each of those types.

TABLE 4		
R-Value Per Inch of Rigid Insulation Types		
Insulation type	R-Value per inch	Reference
Expanded Polystyrene	3.9	ASHRAE
Extruded Polystyrene	5.1	Dow Chemical Co.
Polyurethane	6.2	ASHRAE
Polyisocyanurate	7.2/8.7*	Celotex Corp.
Phenolic Foam	8.3	Manville Corp.

*Blackore™, polyisocyanurate with carbon black, which reduces radiant heat flow of regular polyisocyanurate foam insulation.

In general, the polystyrene-based insulations use air bubbles entrapped in the foam material to provide the insulation value. The two products are chemically the same; however, the extruded product is expanded with CFCs or other inert gas and maintained at a more uniform and higher density, thus providing a higher R-value per inch. Typically, the expanded polystyrene is the least expensive of all rigid insulations. However, to get a given R-value it requires the greatest thickness. Expanded polystyrenes have a wide range of R-values per inch depending on manufacturer and density; typical values range between 3.5 and 4.5. In all cases, the manufacturer's specification should be consulted when using expanded polystyrene.

The remaining types of insulation, polyurethane, polyisocyanurate and phenolic foam use an inert gas, usually freon, entrapped in bubbles within the material to provide the insulation value. Since this inert gas has better thermal characteristics than air, the resulting insulation has considerably better characteristics. However, in the case of urethane and polyisocyanurate the foam material is somewhat permeable, thus the freon tends to migrate out. As a result, the insulation value of these materials declines over time. The values published here are aged values from manufacturer's data and from the *1989 ASHRAE Handbook, Fundamentals*. While individual products may claim values somewhat different from this, it is important to note whether these values take into account the short term decline in insulation rates that exist after the manufacturing process.

The last type of foam, phenolic foam, is similar to polyisocyanurate except that the plastic material is not permeable to the entrapped gas. Thus, the insulation value of this material over time does not appreciably deteriorate and as a result the insulating value of the material as generated from the factory remains at a very high level.

2.1.4 Blown-in Insulation

The final insulation type that shall be discussed is blown-in insulation. The R-value per inch of blown-in insulation varies not so much with manufacturer as with installation techniques. For blown-in fiberglass for example, the U-factors can vary by 25%. In addition to fiberglass, blown-in insulation can be cellulose or mineral wool. Table 5 illustrates the range of R-values per inch of thickness available in various blown-in products installed in ceilings.

In general these values depend on the properties of the specific material and the installation practices used by the contractor. Manufacturers often specify a "bag count" or "bag coverage" to reach a particular R-value in a given area. This sets the total amount of the product which should be installed and assumes (given uniform coverage) that it will settle to the specified density and thickness. The values in the table are recommended as a default in the absence of manufacturer's information.

TABLE 5			
Loose Fill Insulation Values*			
Insulation type	R-value/inch* (range)	Value assumed: R-value/inch (hr • ft ² • °F/Btu • inch)	Density (lb/ft ³)
Fiberglass **	2.2-2.9	2.6	1.2
Cellulose *	3.1-3.7	3.4	2.8
Mineral Wool **	2.2-2.9	2.9	1.7
Vermiculite *	2.1	2.1	7.0

* 1989 ASHRAE Handbook, Fundamentals

** Manufacturer's recommended density and insulation value

2.2 Parallel Heat Loss Calculations

The resistance to heat flow through building components such as flat ceilings, floors or walls (or curved surfaces if curvature is small) is equal to the numerical sum of the resistances of all parts of the component, added in series:

$$R = R_1 + R_2 + R_3 + R_4 + \dots + R_n \quad \text{Eq. 2.}$$

where R is the resistance of the component from inside surface to outside surface and $R_1, R_2, \dots, R_n$ are the individual resistances of the parts. These resistances are commonly known as "R-values" and have units of $\text{hr} \cdot ^\circ\text{F} \cdot \text{ft}^2/\text{Btu}$. Note that the R-value (R_1) of a single homogeneous material of conductivity k and thickness x can be calculated as $R_1 = x/k$.

To obtain the total resistance of the building component R_T , add the surface-to-surface resistance R and the resistances of the inside and outside air films, R_i and R_o :

$$R_T = R_i + R + R_o \quad \text{Eq. 3.}$$

The overall coefficient of heat transmission, or U-factor, is equal to the reciprocal of the total resistance ($U = 1/R_T$). A U-factor has units of $\text{Btu/hr} \cdot ^\circ\text{F} \cdot \text{ft}^2$.

In most installations, components are arranged so that parallel heat flow paths of different conductances result. For example, in a standard insulated frame wall, one heat flow path passes through the insulated section of the wall while another heat flow path passes through the studs. The R-value of the insulation is obviously much greater than the R-value of the studs, so heat passes more quickly through the studs; however, the relative area of the insulated section is greater so it tends to dominate the heat loss rate. If we assume that there

is negligible lateral heat flow between paths, each path can be considered to extend from inside to outside, and the resistance of each path can be calculated using Eq. (2) and (3). The average transmissivity, or U-factor, is then:

$$U_{av} = a(U_a) + b(U_b) + \dots + n(U_n) \quad \text{Eq. 4.}$$

where $a, b \dots n$ are respective fractions of a given area composed of the several different paths with transmissivities $U_a, U_b \dots U_n$. For example, for a standard frame wall with 10% of the area taken up by framing:

$$U_{av} = (0.1 \times U_{stud}) + (0.9 \times U_{insul}) \quad \text{Eq. 5.}$$

2.3 Buffered Heat Loss

When heat flow through a given component of the building is buffered by an intermediate unheated space between the living zone and the outside, the heat loss rate through individual building components is reduced. For standard residential construction, crawl spaces, attics, garages, and enclosed porches are typical buffer spaces. For purposes of this report we have considered buffer spaces in calculations for both the ceiling and floor U-factors. The procedure for including these effects is designed to establish the heat loss rate from the building to the buffer, then from the buffer space to the outside. These two heat flows are added together in series in the same manner as resistances.

Neglecting thermal storage in the buffer, the total effective heat loss rate through a component coupled with a buffer space is:

$$UA_i = \frac{1}{\frac{1}{UA_1} + \frac{1}{UA_2}} \quad \text{Eq. 6.}$$

Where:

- UA_1 = The heat loss rate from the house to the buffer space.
- UA_2 = The heat loss rate from the buffer to outside (including conductive and infiltration losses).
- UA_i = The effective heat loss rate for the entire section.

or:

$$UA_i = UA_1 \left(\frac{UA_2}{UA_1 + UA_2} \right) \quad \text{Eq. 7}$$

where the ratio

$$\frac{UA_2}{UA_1 + UA_2} \quad \text{Eq. 8.}$$

is multiplied by the component heat loss rate to correct for the buffer effect.

3 Component Analysis

3.1 Floor Systems

3.1.1 Construction Techniques

Manufactured home floor systems differ from site-built home floors in two important respects. First, the floor is framed on top of a steel undercarriage made of steel I-beams (which run the length of the home) and outriggers (placed several feet apart, which run from the outer I-beam to the perimeter of the home). This undercarriage is the means by which the structure is towed from the factory to the home site. In the most commonly found construction techniques, the crushing of insulation batts between the floor joists and the undercarriage reduces the performance of insulation. Second, heating system ducts run in the floor system. In most insulation strategies currently used, the ducts compromise the thermal performance of the floor system; however, the effect has been reduced a great deal in homes built to MAP specifications, where duct losses are confined to the area between the steel I-beams (transverse and upright transverse floors) or to one joist cavity (longitudinal floor). Drawings of these floors are found in the appendix.

Three floor system construction techniques are described here. The transverse floor, in which the floor is framed upside down and is perpendicular to the steel undercarriage, is the most common technique found in the Northwest. The second framing scheme, the upright transverse floor system, is similar but the floor is constructed upright. The longitudinal floor is framed so that the floor joists run parallel to the steel I-beams and are supported with steel stays which run orthogonally to the I-beams.

Transverse Floor System

Most Northwest manufacturers construct a floor structure which is called "transverse." In this configuration, 2 x 6 (or 2 x 8) floor joists are placed at right angles to the steel I-beams and parallel to steel outriggers (which extend from the I-beams to the rim joists) that make up the undercarriage of the home. The floor is assembled upside down, with the heating ducts, plumbing lines, and electrical service located in the center ("belly") portion of the floor system. A "belly blanket" (one or more layers of insulation) is placed over the floor framing and the various utility conduits, then covered with a reinforced plastic sheet called the "belly board" (or "bottom board"). The steel undercarriage is placed on top of this layer and strapped and bolted to the joist assembly. The entire system is then flipped back over and the interior flooring and heating registers are installed.

The belly blanket insulation is brought up into the joist cavity in the outrigger region (the outer 3 feet of each side of the double-wide) by cutting the batts where they come up against the joists and pushing the batts into the joist cavity. This strategy reduces the compression which normally occurs when the belly blanket is crushed between the steel undercarriage and the joists. (The compression is not totally reduced, because the bottom layer or layers of belly insulation are usually still crushed between the floor joists and I-beams.)

The belly blanket is crushed at the edges of the home and between the steel I-beams and the floor joists. Normal density joist insulation may be compressed depending on the framing depth and the insulation thickness. For example, an R-19 batt is usually 6" thick. If an R-19 batt is placed in a 2 x 6 frame, where the cavity space is only

5-1/2", compression reduces the performance of the insulation by 5.3%. (See Table 3.) The R-21 high-density batt has an uncompressed thickness of 5 1/2", so it will retain full R-value in the 5 1/2" joist cavity.

Each half of a double-wide home's floor is thus constructed. The two halves are joined, and an insulated flexible crossover duct, which runs below the belly board, connects the two supply ducts in each half.

Duct conductive losses and the infiltration/exfiltration they induce affect the performance of floor insulation. The effect of duct leakage on the floor U-factor is taken into account in the U-factor calculation. Duct insulation improves the floor system's thermal performance. Duct insulation is assumed to be a full R-5 insulation wrap around the duct.

Upright Transverse Floor System

The upright transverse floor is framed similarly to the more common transverse floor, except the floor is framed on top of the undercarriage, rather than the other way around. This presents some problems, since the insulation drapes over the undercarriage prior to the framing.

Typically, the belly blanket insulation is laid on top of the belly board before framing the ends. Then the space between the joists is insulated with insulation that extends across the floor structure and under the supply duct. Since the belly blanket is continuous across the floor, additional layers are placed in the center section of the steel undercarriage (between the I-beams) before the duct is placed in the frame. Then, the floor framing is put in place, compressing the belly blanket at the steel carriage. A partial layer of insulation is placed in the floor cavity space from above before the flooring is installed. This last layer of insulation is cut so that the insulation does not extend over the duct but falls down into the cavity space above the belly blanket. It is important to ensure that the joist insulation not cover the duct at all, thereby minimizing the effect of duct losses on the floor's insulation performance.

Longitudinal Floor System

In the longitudinal configuration, the floor structure is constructed similarly to the transverse floor; however, the floor joists are placed parallel to the steel undercarriage I-beams. Each heating duct is located inside one joist cavity (rather than being strapped to the bottom of the joists and perpendicular to them).

In this case the floor is framed upright, similar to the upright transverse floor. The belly blanket is draped over the steel carriage and framing is placed on top of the belly blanket, compressing it. The joist cavities are insulated individually, with the insulation supported by the steel structure below. In the center a single joist cavity is given over to the duct. The thermal performance of this floor improves due to the amount of insulation that can be installed below the duct.

3.1.2 Thermal Analysis

To analyze thermal performance of floor systems in manufactured homes, we used a one-dimensional heat loss analysis, adjusted to account for two important factors. The first of these is the compression (and subsequent reduction in performance) of belly blanket and joist insulation. The second is the interaction between the heating system ducts and the floor system insulation.

The first step in finding a U-factor for a given insulation value is to calculate a "steady-state" conductance of the floor system. This calculation takes into account the compression of insulation in the belly blanket and (if applicable) in the joist cavities. The framing correction is also made in this step. For homes with zonal heating (baseboard units or wall heaters), this value is in fact the floor U-factor. The next step is to adjust the U-factor so that the effects of duct losses are included. Ducts affect floor insulation performance by pressurizing some of the floor assembly and by compromising the effectiveness of joist insulation which might be placed above the duct. (The second effect is not an issue in floors built to MAP specifications, since no joist insulation is placed above the duct region.) The buffering effect of the crawlspace is taken into account in this step.

Insulation Compression and Conductance

The belly blanket conductance varies due to compression of the insulation. There are several distinct compression regions for the belly blanket, each corresponding to an area of the floor, and each with a different conductance. Belly blanket insulation is compressed between the belly board and the underside of the joists in the outrigger region, between the I-beams and the joists, and between the belly board and the bottom of the heating duct (in some cases).

The compression for different insulation configurations was determined from site visits and some simplifications were made (for example, assuming a uniform slope of the insulation in compression zones, as shown in the following figure). Figure 1 shows the compression regions with corrected R-values for an R-33 transverse floor. This figure extends from the rim joist (at left) to the other side of one half of a double-wide home.

Figure 1. Insulation Compression Regions, R-33 Transverse Floor System

In cases where the compression in the region was less than or equal to 50% of the nominal thickness of the batt or batts, Equation 1 (Section 2.1.2) was used to find an R-value. In cases where compression exceeds 50% (where insulation is crushed between joist and I-beam, for example), information from manufacturers (Manville, 1988) was used to estimate the R-value.

R-values were calculated for the joist and belly regions in each compression zone. These values were weighted by the zone's square footage and summed. The reciprocals of the values for joist and belly regions, the so-called "steady-state" U-factors, were input into the duct model (described below) to calculate an overall floor system U-factor. For homes without forced-air systems, the steady-state floor U-factors should be used.

Effect of Forced Air Furnace and Ducts on Floor Performance

System supply ducts located in the belly cavity (between the floor joists and the belly blanket) complicate the calculation of the floor U-factor. The ducts conduct heat and leak conditioned air into this cavity. The belly cavity behaves like a buffer space and the total floor-to-buffer and buffer-to-ambient conductivities must be added in series (after correction for insulation compression, described above) to get the overall floor system U-factor.

We define the buffer in a transverse and upright transverse floor as the space where air moves freely between the lower edge of the joists and the belly blanket. For transverse and upright transverse floors, the buffer was considered to be restricted to the area between the I-beams if there is enough thickness of insulation in the joist space to completely fill the space. An R-22 transverse floor would meet this condition, as the nominal thickness of the R-22 is 7" and the available joist space is only 5.5" if 2x6 floor joists are used. (The belly board also compresses the insulation by more than 1.5" in some parts of the outrigger region.) If the joist space is not full, duct losses will pressurize more of the floor system and the floor U-factor will increase. In longitudinal floors, because the duct runs inside one joist cavity, the buffer is confined to the cavity in which the duct is located.

We calculated an overall floor conductivity (U-factor) for various insulation strategies. These U-factors were further adjusted to include duct insulation. To determine floor U-factors, we used a special version of the SUNDAY simulation program. The program combines SUNDAY with an equipment model developed for use in WATTSUN 5.0. The full model explanation can be found in Kennedy (1991), but a brief description follows.

SUNDAY is used to calculate the building load for a typical year. The equipment model then calculates the duct load and equipment energy needed to meet the building load. The model estimates a duct space temperature (in this case, the belly cavity temperature) and duct temperature, which are then used to calculate duct conduction loss and to adjust the floor loss. The effective conductivity of the belly region is this adjusted floor loss, normalized by the house-to-ambient temperature difference and the belly cavity area (square footage).

Inputs necessary for the duct model are the conductivity of the supply duct, the conductivity of the house-to-belly cavity interface and the belly cavity-to-ambient interface, the belly cavity area, and the leakage fraction of the supply ducts. The furnace on-time is also needed. It is found in an earlier part of the model through an iterative solution which is based on building heating load and furnace capacity.

The supply duct conductivity is calculated based upon the duct area and the presence of insulation. Heat loss from the bottom of the duct is ignored in this calculation since it presses directly into the belly insulation and does not contribute heat into the belly cavity. The conductivity used for bare metal duct is 1 Btu/hr-ft²-°F; the conductivity for a metal duct with R-5 insulation is 0.25 Btu/hr-ft²-°F. The duct insulation conductivity is an estimate and is considered roughly the same for duct insulation between R-4 and R-7. For the higher R-values, insulation compression will reduce the actual R-value of the insulation. We chose R-5 as the most likely average R-value of duct insulation and used a U-factor (0.25) which is even more conservative to account for compression.

The calculated conductive duct heat loss (UA) for longitudinal floors is significantly reduced from that for transverse floors because the heating risers make up considerably less length in longitudinal floors.

We use a supply duct leakage fraction of 3.5 percent of the air handler flow. This value was derived from detailed constant-injection tracer gas measurements of a manufactured home (Palmiter & Bond, 1991). This value may vary, depending on duct sealing techniques and flow configuration. In the absence of further data, the quality of duct sealing must be emphasized. Careful application of high quality sealants and metal duct tape at register boots and duct ends is key to minimizing duct losses and consequent degradation of floor thermal performance.

Table 6 shows the extent to which the performance of floor systems is reduced by the effects of a forced air furnace and ducts. The numbers listed (called "heating system efficiency factors") are the ratio between the yearly building load without heating system effects and the load with induced infiltration and conduction losses from the heating system and ducts included.

The table can be used to compare homes with forced air furnaces to those without. A home's steady-state UA can be divided by the appropriate furnace efficiency factor to calculate a corrected UA which includes heating system and duct effects.

Table 6 Heating System Efficiency Factors				
floor type	nominal belly insulation	nominal joist ins.	w/uninsulated ducts	w/R-5 duct wrap
	R- value		Htg Sys.	Factor
transverse	22	--	0.92	0.95
	33	--	0.93	0.95
	44	--	0.94	0.95
upright transverse	11	22	--	0.96
longitudinal	all cases		0.96	0.96

3.2 Ceiling Systems

3.2.1 Insulation Techniques

In general, ceiling systems in manufactured homes are similar to those in site-built homes. Pre-manufactured trusses are shipped to the manufactured home plant or are made in the plant. Batt or blown insulation is used to insulate the attic or vault cavity. Because of the sequence of building in manufactured home plants, access to the attic and vault area is more convenient and therefore one can, in general, expect a consistently better job of ceiling insulation than found in site-built homes.

There are three common methods for insulating ceilings in manufactured homes:

The first and most common method is to blow mineral fiber, cellulose or fiberglass into the ceiling structure prior to the installation of the roof sheathing. This technique delivers reasonably consistent depth and density control. As a result, blown-in insulation is among the most cost-effective and least labor-intensive of any ceiling insulation strategy.

Some manufacturers use fiberglass batt insulation. When standard size batts are used, the insulation is rolled out and placed in the ceiling in one step. This strategy is not very labor-intensive. However, it does create a substantial amount of insulation void between the trusses (Figure 2), resulting in a 25% to 30% reduction in the overall insulation value of the ceiling. As a result, this insulation strategy does not meet the minimum standards required by the MAP specifications.

Figure 2. Uninsulated Slots Over Truss Members

An increasing number of manufacturers use oversized (or "mushroom") fiberglass batts (Figure 3). These batts are actually cut to the same width as the on-center truss member spacing (assumed to be 16" or 24") so that the batt laps over the truss chords and can be crushed between the truss members. This technique substantially reduces the uninsulated (void) fraction but is more labor-intensive since it requires a second step: pressing the insulation between the truss members after laying it out. For this strategy to be effective, the trusses must be spaced evenly, with a half to a quarter of an inch accuracy. Inconsistent truss spacing results in large voids and a reduction in the overall performance of the ceiling insulation.

Figure 3. Oversized Batts Covering Truss Members

For ceilings insulated with batts, U-factors are calculated for two venting scenarios. The first scenario (Figure 4) assumes the full thickness of insulation is placed at least as far as the middle of the top plate and that the batts are crushed in place to allow a 1" airspace above. A cardboard baffle stapled to the top of the truss members is commonly used for this purpose.

The second method (Figure 5) uses gable vents and induced attic ventilation and places the full nominal R-value of insulation into the available space at the junction with the top plate (requiring considerable crushing, in most cases).

Figure 4. Ceiling System With Crushed Batts, Baffle, and Soffit Vents

Figure 5. Ceiling System With Crushed Batts and Gable Vents

3.2.2 Thermal Analysis

For the purpose of calculating an overall heat loss coefficient for a ceiling system with blown insulation (Figure 6), there are two main sections of ceiling which must be examined: the section from the edge to the point where the insulation reaches the maximum depth (from $X=0$ to $X=X_{ins}$) and the center section of the ceiling with uniform insulation depth (from $X=X_{ins}$ to $X=X_c$). The first section must be integrated numerically, since the insulation depth changes with distance from the edge. This resultant R-value must then be added in parallel with the R-value of the rest of the ceiling.

Figure 6. Detail at Ceiling Edge for Blown-in Insulation

This results in the following equation for the overall U-value of the ceiling assembly between truss framing members:

$$\bar{U}_{ins} = \frac{1}{X_c P K_{ins}} \ln \left[1 + \frac{K_{ins} P X_{ins}}{R_1} \right] + \frac{X_c - X_{ins}}{X_c (Y_{ins} K_{ins} + R_2 - K_w W)} \quad \text{Eq. 9.}$$

where: X_c = horizontal distance from peak of roof to edge (inches)

P = pitch of roof

W = width of truss framing member (inches)

C = clear venting space (in inches) above insulation (if applicable)

K_w = thermal resistivity of wood framing member (R-value per inch)

K_{ins} = thermal resistivity of insulation (R-value per inch)

Y_{edge} = nominal heel width (inches)

Y_{ins} = depth of insulation required for nominal R-value (inches)

R_1 = R-value of insulation at edge of ceiling $(Y_{edge} - C)K_{ins}$
plus the R-value of the top and bottom air film and ceiling board

R_2 = R-value of top and bottom air films, ceiling board, and lower truss member

Now this U-value must be added in parallel to the U-value of the ceiling assembly at the framing members, where the insulation value is reduced due to the higher thermal conductivity of the wood. The equation for the overall heat loss coefficient of the ceiling assembly at the framing members is:

$$\bar{U}_{truss} = \ln \left[\frac{1 + K_{ins} P X_{ins}}{R_2 + R_3} \right] + \frac{X_c - X_1}{X_c [R_2 + (Y_{ins} - W) K_{ins}]} \quad \text{Eq. 10.}$$

where:

X_1 = horizontal distance from edge of ceiling to full depth insulation on top of framing member

R_3 = R-value of insulation at edge of ceiling plus R-value of lower truss member

These two U-values are then added in parallel to determine the overall heat loss coefficient from the house to the attic.

A variety of trusses were observed on field visits. For purposes of analysis, trusses are assumed to measure 158" from the outside edge of the top plate to the king post at the marriage line of the ceiling. In attics, the most commonly found insulation space (measured from the ceiling board upward to the underside of the roof sheathing) at the king post is 40". For sloped ceilings, this dimension is 16". The situation is more complicated at the other end of the truss. Here, (at the truss "heel") we found the most common insulation cavity was 5-1/8". (For ceilings with soffit vents, this means the cavity, measured at the middle of the top plate, was 6 1/8," with a 1" airspace above the insulation for venting.) U-factors were calculated for a total of six heel heights, ranging from 3.5" to 9.5".

Mineral wool (2.9 hr•ft²•°F/Btu•inch) was the assumed material for blow-in cases. The outside roof pitch was set at 2.5:12 (0.21). Ceiling pitch varies depending on the heel height. A 1" airspace above the insulation for ventilation is assumed in homes with soffit vents. In other cases, venting is provided by gable-end vents.

A continuous solution was also used for batt insulation. The equations are similar in format to the blown ceiling equations.

When insulating with batts, it is best to use multiple layers of oversized batts, thereby allowing more consistent placement across the depth of the insulation. It is assumed in these calculations that attic insulation is placed carefully so the insulation blankets cover the lower chord of the truss and minimize the gaps around truss members. Field investigation showed an uninsulated (void) fraction of between 8% to 18%. In attics with trusses placed 24" o.c., the 8% void fraction is used in calculating a U-factor. In sloped ceilings framed at 16" o.c., the void fraction is 18%.

To determine the overall heat loss coefficient from the house to ambient a correction must be made to account for the buffering effect of the attic. This is done by applying the series heat loss calculations to the ventilated attic space. The U-factor calculation also incorporates the R-value of the roofing assembly, the gable end walls, and the ventilation rate of the attic.

The Uniform Building Code (UBC) specifies a ventilation area of 1 square foot for every 150 square feet of attic area. While this value can be met in a wide variety of ways, the UBC does not specify the configuration of the venting or whether this ventilation area will actually induce an air flow through the attic area. Thus it is a matter of considerable conjecture as to how much air ventilation may be occurring in the attic buffer. If this value is relatively high, such as five air changes per hour, then the attic buffer is of little consequence and the heat loss rate of the ceiling is not changed by a buffer calculation. If the ventilation rate is very low, then the attic buffer can add as much as 10% to the overall insulation value of the attic. For purposes of the tables in this volume, the attic is assumed to have a ventilation rate of 3 air changes per hour.

Given the tendency for moisture to accumulate in attic areas, it is important that effective attic ventilation be installed.

3.3 Wall Systems

3.3.1 Construction Techniques

Two main advantages of manufactured housing are its more efficient use of material and consistent quality control. This is especially true for walls.

Wall system design in manufactured homes is significantly different from site-built design. Up to 70% of the design stress load on the wall occurs during transportation to the building site. The walls are therefore designed to handle the stresses of transportation as well as to support the roof.

Wall systems are designed in two ways. The first is to use conventional site-built structural methods. These methods rely on a post and beam design strategy in which the studs and plates in the wall structure are designed as simple load-bearing spans. The alternative is to design the entire wall as a diaphragm or stress-skin panel. Using this design strategy, the wall sheathing and members work together to provide greater wall structural stability. This method uses significantly less lumber to frame the walls but requires more design and quality control in the assembly of the wall. Manufacturers use the post and beam wall largely for marketing reasons, arguing that the additional lumber required gives a wall equivalent in strength to the stress-skin wall without requiring unusual design or testing.

In both construction approaches, the wall design is the product of detailed engineering calculations and/or rigorous field testing. Field tests employ standard methods to demonstrate that the home can withstand the forces associated with transportation to the building site. These tests are reviewed by H.U.D. or their representative and must be repeated for a new home design. Acceptable engineering practice can substitute for often lengthy and costly field testing; often, however, relying on calculations alone results in the use of more structural material than necessary.

Post and Beam Walls

Post and beam walls contain a greater percentage of wood (more framing) than stress-skin walls. This decreases significantly the thermal performance and hence increases the U-factor of the wall.

Various combinations of header and corner framing strategies are used in these walls. (See drawings in appendix.) The "solid header" is composed of three 2 x 6's or one 4 x 6 over each window and door opening. The second header type is a "box beam," which is usually assembled from 2 x 6's and which allows at least a 2 1/2" space for insulation. The corner framing technique most often used is the "3 stud" corner. A "2.5 stud" corner, with two 2 x 6's and an extra piece of blocking, is also used. Although this amount of wood is probably unnecessary, it is in keeping with the manufacturer's intent to build a wall that is very similar or identical to a site-built wall.

Stress-Skin Walls

Stress-skin design has distinct advantages to manufacturers. This design allows the engineered wall to include the structural characteristics of the interior and exterior sheathing in order to make a full diaphragm. The sheathing, which is glued and nailed to each structural member, assists the structural member in carrying the load by reducing buckling and transmitting the load laterally away from window and door openings. This approach allows less wood to be used in headers and increases the structural strength of the individual framing members and the sheathing. This method also allows the use of fewer studs, permitting more room for insulation than is typical of site-built homes or of homes built by manufacturers who use the simple-span method to determine structural requirements.

The net result of using stress-skin wall construction is about a 30% reduction in the wall framing correction. This means the wall conserves resources at the start and more energy in the long run than the post & beam wall for a given wall R-value.

There are two variations of the stress-skin framing method. In one, the corner is framed with only two studs, the remainder of the area being given over to insulation cavity. In the other, the corner is framed with two and a half studs, where an additional framing member is placed at the corner. With this framing approach, no special header detail is required, although the insulated box beam is sometimes used.

3.3.2 Thermal Analysis

Calculating the insulation value of a wall requires assessing several parallel heat flow paths through the wall structure. These paths are:

- through the framing. This is the portion of the wall characterized by the insulation value of the wood members themselves (studs, plates, frames).
- through the header. The header spans the wall area above windows and doors to carry structural loads. It is characterized by either a solid wood beam, or a beam with two to three inches of air space to make up the full thickness of the wall. This air space can be replaced with either rigid insulation or fiberglass to enhance the insulation value.
- through the cavity. This is the area between the studs where the insulation is placed. This cavity is, of course, characterized by the actual depth of studs and often the fiberglass is crushed to fit into the stud cavity.

In addition to these general features of the wall, specific variations can be introduced. The most notable of these is the use of rigid foam insulated sheathing, which can cover the entire exterior or interior of the wall and add additional R-value over all components. In the manufactured home industry, this is usually 1/2 inch thick extruded polystyrene (R-5 per inch), installed over the entire exterior or interior of the wall. This sheathing is usually non-structural and additional framing must be added to provide lateral stability to the wall structure itself, either in the form of structural sheathing (plywood) or bracing, let-in diagonally through the studs.

In calculating the wall U-factors, for walls with R-11 batts, 2 x 4 framing at 16" on center is assumed. For R-19, R-21, and R-22 walls, 2 x 6 framing at 16" on center is assumed. For R-19 and R-22 walls, some compression of the batts occurs; this compression reduces the performance of the insulation and is figured into the calculation of the U-factor. The R-21 wall uses a high-density batt of thickness 5 1/2", so the batt is uncompressed. The framing factors in Table 7 correspond to the corner framing and header construction details found in manufactured homes.

Table 7 Wall Framing Factors (studs at 16" o.c.)			
Type*	Frame	Cavity	Header
SS1	.133	.867	--
SS2	.138	.862	--
SS3	.136	.824	.040
PB1	.170	.790	.040
PB2	.179	.781	.040

* Explanation of Types:

- SS1: 2 stud corner, no header
- SS2: 2.5 stud corner, no header
- SS3: 2.5 stud corner, box beam header
- PB1: 2.5 stud corner, box beam header
- PB2: 3 stud corner, solid header

3.4 Windows

Window performance is typically established using standardized tests. These tests are conducted by independent testing laboratories using an ASTM protocol. Because these tests often vary substantially for otherwise similar windows, the industry has embarked on a new protocol. The protocol will be developed by the National Fenestration Rating Council (NFRC).

This protocol is to be based on the results of the *Window 4.0*, an upgrade of the simulation program, *Window 3.1*, which is developed by Lawrence Berkeley Laboratory, and which was used to derive some of the U-factors found in the appendix. The simulated results would be compared with laboratory tests for selected samples of a manufacturer's window line.

The implementation of this protocol is not expected by the summer of 1992. It is the intention of the MAP to use the NFRC values when they are available. In the interim, the MAP specification has assigned four window types which can be used and has assigned U-factors which are approximately equivalent to the U-factors expected when the NFRC results are published. A table of these U-factors is found in the appendix, along with a more general table of window U-factors constructed by using *Window 3.1*.

For purposes of the MAP, doors with more than 50% glazing will be considered windows, and the U-factor for the door will be based on the door material and the type of glazing. Doors with less than 50% glazing will be considered opaque doors. U-factors for doors can be found in Section 3.6.

3.4.1 Window Types

The MAP specifications require that windows have vinyl or wood frames. They must be double-glazed with class-A glazing seals and have a 1/2" to 3/4" space between the glazing surfaces which is filled with either argon or air. A low- ϵ coating may be placed on the inside surface of either of the glazings for enhanced performance.

Vinyl Frame Window

The vinyl frame window currently on the market is a common energy-efficient window used in residential construction and has become increasingly important to the manufactured home industry over the last two years. The frame is made with a standardized extrusion and improves the performance of the windows over aluminum windows by about 40%. Windows built with vinyl frames perform better than any windows with metal frames, even aluminum frame windows with a thermal break.

Wood Frame Window

Wood frame windows, although rarely used by manufactured home builders, offer significant improvements in thermal performance over metal frame windows. U-factors for wood frame windows (equivalent to those for vinyl windows) are included in the table found in the appendix.

Other Window Frames

Other window frames such as aluminum frame windows (with or without thermal break) and aluminum frame windows with various combinations of storm windows are not accepted under the MAP specifications. There are some listings for these windows in the second table of U-factors found in the appendix.

3.4.2 Glazing Products

In the last decade, the availability and the thermal performance of glazing products have improved markedly. We describe three strategies used to reduce the thermal conductivity of a single clear pane of glass.

Multiple Glazings

The first and most common glazing improvement is the use of multiple layers of clear glass, particularly double-glazing, which is available in practically every product line made by every window maker in the country. This consists of two layers of clear

glass sealed at their edges, with dry air or inert gas inserted between the two panes. Some manufacturers use three or even four layers of glazing to provide additional benefits.

The space between the glazing layers accounts for most of the improved thermal performance. For double-glazed windows, a half-inch of air space is the minimum width needed to meet the MAP specifications. Additional thermal benefits accrue to air spaces up to three-quarters of an inch. With triple glazing, the air space can be up to a half-inch. However, the limits of overall glazing thickness in most frame types often prevent this much air space (common air spaces are three-eighths or five-sixteenths of an inch) and reduce the performance of triple glazing from what might be expected in the ideal situation.

Argon Fill

One method of improving the performance of double-glazed windows is to fill the sealed air space between the glass panes with a low-conductivity gas such as argon or krypton. The presence of this gas improves the performance of double glazing by 5 to 10%. The principal problem with this method is ensuring that the argon is properly installed and that replacement windows are also argon-filled so that the window performance remains the same over the life of the home. There are unresolved questions about gas diffusion through the window seals, which could reduce window performance.

Low- ϵ Coatings

One of the most important advances in window performance was the development of low-emissivity (low- ϵ) coatings which can be applied to the glass surface. Since one of the principal modes of heat transfer through glass is absorption and re-radiation, the emissivity of the glass surface is a principal determinant of the amount of heat that is able to pass through the glass from the living space to outside. Use of a low-emissivity coating reduces the amount of heat absorbed by the glass, thus reducing glass conductivity.

There are numerous types of low- ϵ coatings on the market and the performance of these coatings, for the most part, is determined by the coefficient of emissivity ϵ . In general, there are two types of low- ϵ coating: soft coat and hard coat. The soft coat, or sputter coat, has a emissivity of between 0.05 and 0.15 and results in a U-factor improvement of 30-35% over a typical double-glazed window. The hard coat has emissivities of 0.20 to 0.40 and results in less improvement than the soft coat. Typically, fabricating windows with the soft coat is more complicated and therefore more expensive. The MAP specifications assume a maximum emissivity of 0.20.

A related product, called Heat Mirror®, is distributed to a limited extent. With this product, the low- ϵ coating is applied on a plastic sheet which is suspended between the two layers of glass. This results in an effective triple-glazing with low- ϵ coating, giving an overall conductivity reduced to almost half of conventional double-glazed windows.

Low- ϵ coatings can be combined with low-conductivity gas (e.g. argon) to further improve performance. For most windows currently available, this configuration is limited to low- ϵ soft and hard coats and results in a 5 to 10% gain over the performance of the low- ϵ coating alone.

3.4.3 Testing and Simulation

The most common method for estimating window performance, although not the approach used in this report, is to use a tested value provided by each manufacturer for each window type. One reference which summarizes these values is the periodic publication of the Seattle Department of Construction and Land Use (1990). These values are based on tests conducted by the American Architectural Manufacturers' Association (AAMA) (test procedure #1503.1-1980), or on results from the American Society of Testing Materials (ASTM) test C-236.

The testing procedures used by AAMA include details of testing conditions which are essential in interpreting the test results. These include the presence or absence of window shades and drapes, the degree to which the window is protected from air flow (wind) by being recessed in the frame, the possibility that on-site wind speeds may average substantially less than the tested assumption of 15 mph, the window's orientation and solar flux, the outdoor relative humidity and temperature, and the shading and obstructions around the building. In addition, test values can be influenced by the size of the window and the performance of the window seals. With test values, the window makers and particular windows may vary from 5 to 10% around a particular value; and for specific windows, variations even larger than that may be present even though the windows might perform equivalently when installed in the home.

Since test values are conducted using a simulated 15 mph wind, it should be pointed out that wind speeds substantially lower than that can result in a 5% reduction in U-factor. Tests conducted on homes in the Northwest typically find average wind speeds between 1/2 and 2 mph, suggesting that the use of 15 mph winds imposes a conservative bias on estimates of window performance.

Window tests do not include air leakage. Although some leakage may occur, both the MAP specifications and the testing protocol treat ventilation separately. The MAP specifications stipulate this rate may not exceed 0.3 cfm per linear foot of window frame, as established by an ASTM testing procedure.

3.5 Skylights

Two types of skylights are typically installed in manufactured homes. The most common is a curbless skylight which mounts flush to the roof and is flashed into the roofing material. These skylights are usually made of multiple layers of polycarbonate to improve thermal performance. The other type of skylight is the curbed, mounted skylight. This type of skylight is more typical in site-built homes. In this style, a wood or metal curb is mounted on the roof surface and flashed to the roofing. The skylight is mounted on the curb, thus raising it three to six inches above the roof's surface. Because of the extra surface area created by raising the skylight above the roof surface, this type of skylight has additional heat loss.

The testing procedures used for skylights are less reliable as performance prediction techniques than tests used for windows. This is because the testing protocol requires that skylights be mounted vertically (rather than horizontally or at 45° to horizontal) for the test. The testing protocol also requires that the skylights be mounted on curbs during the tests; but, the heat loss of the curbs is removed from the final results. Finally, the area of the skylight is standardized to that of the rough opening area. This doesn't take into account differences in configuration. For instance, a skylight that insets into a curb and is thus somewhat smaller than the rough opening should be more efficient than a similar skylight configured to mount over the curb and having a glazing area the same or larger than the rough opening. Both the NFRC and ASTM are revising and standardizing skylight testing procedures to ensure a

consistent level of testing and quality in skylights. Until these revisions are complete, it is fairly difficult to assign an accurate heat loss coefficient to any particular skylight configuration.

In the MAP specifications, the maximum U-value for skylights is set at 0.50. The configuration which leads to 0.50 has been limited to a specific number of components, which are independent of mounting procedures and curbing details. Like windows, the skylight tables may be revised depending on the outcome of the NFRC simulation testing procedures and their applicability to the skylights used in manufactured homes.

3.6 Opaque Doors

Doors most commonly used to meet the MAP specifications are fiberglass or metal with foam core, at least 1 1/2" thick, with a thermal break.

Under the MAP specifications, a door is considered "opaque" if less than 50% of the door's surface area is taken up by double glazing. Doors with 50% of or more glazing are considered windows.

Tables of U-factors for opaque doors commonly used in manufactured housing are found in the appendix. These values are derived from data found in the 1989 *ASHRAE Handbook, Fundamentals* (1989) and from tests done according to AAMA or ASTM standards. The values given in the table assume a 15 mph wind across the exterior surface. Doors are to be completely weatherstripped. If storm doors are used, they are to be made from the same material as the primary door.

4 Acknowledgments

Grateful acknowledgment is made to Leknarf and to Porterfield Design for the graphics found in this manual. Mike Kennedy's assistance in developing a heating system model for manufactured homes greatly increased our understanding of the floor systems and improved the quality of the thermal performance estimates. This work draws heavily on previous evaluations of manufactured homes and the support of Steve Onisko of BPA was crucial to the quality of this work. Finally, members of the Manufactured Housing Technical Advisory Group provided many useful comments and insights especially Ken Eklund of Idaho Department of Water Resources, Tom Hewes of Oregon Department of Energy and Alan Lee of Battelle Pacific Northwest Laboratory.

5 References

- American Society of Heating, Refrigerating and Air Conditioning Engineers, Inc. 1989. *1989 ASHRAE Handbook -- Fundamentals*. Atlanta, GA.
- Baylon, David and Jonathan Heller. 1988a. *Super Good Cents Heat Loss Reference. Volume I: Heat Loss Assumptions and Calculations*. Ecotope, Inc. Prepared for Bonneville Power Administration.
- Baylon, David and Jonathan Heller. 1988b. *Super Good Cents Heat Loss Reference. Volume II: Heat Loss Coefficient Tables*. Ecotope, Inc. Prepared for Bonneville Power Administration.
- Bonneville Power Administration. 1990. *Super Good Cents Technical Specifications for Manufactured Homes*. Prepared by Residential Programs Branch.
- City of Seattle, Department of Construction and Land Use. 1991. *Glazing and Opaque Door U-Values For Demonstrating Compliance With The Energy Code*. Seattle, WA.
- Kennedy, Michael. 1991. *Documentation for a Simplified Heating System Equipment Model*. Ecotope, Inc. Prepared for Washington State Energy Office under contract 88-04-21.
- Lawrence Berkeley Laboratory. 1989. *Window 3.1* (simulation software). Windows and Daylighting Group, Lawrence Berkeley Laboratory, Berkeley, CA.
- Manville Corporation. 1988. *Technical Data, Fiberglass Building Insulation*. Denver, CO.
- Palmiter, Larry and Tami Bond. 1991. *Modeled and Measured Infiltration: A Detailed Case Study of Four Electrically Heated Homes*. Ecotope, Inc. Prepared for Electric Power Research Institute under contract RP 2034-40.

COMPONENT U-FACTORS

FLOOR SYSTEMS

Transverse Floor System

In this floor configuration, the 2 x 6 (or 2 x 8) floor joists are placed at right angles to the steel I-beams and parallel to steel outriggers (which extend from the I-beams to the rim joists) that make up the undercarriage of the home. The floor is assembled upside down, with the heating ducts, plumbing lines, and electrical service located in the center ("belly") portion of the floor system. A "belly blanket" (one or more layers of insulation) is placed over the floor framing and the various utility conduits, then covered with a reinforced plastic sheet called the "belly board" (or "bottom board"). The steel undercarriage is placed on top of this layer and strapped and bolted to the joist assembly. The entire system is then flipped back over and the flooring and heating registers installed.

Each half of a double-wide home's floor is thus constructed. The two halves are joined, and an insulated flexible crossover duct, which runs below the belly board, connects the supply ducts in each half to each other.

The belly blanket is brought up into the joist cavity in the outrigger region (the outer three feet of each side of the home) by cutting the batts where they come up against the joists and pulling the batts into the joist cavity. This strategy eliminates or greatly reduces (depending on the amount of insulation used) the "sandwich" effect in the transverse floor, where the batts are crushed between the I-beams and floor joists.

The belly blanket is still compressed somewhat in the outrigger region and much more where the I-beams and floor joists attach. (See the depiction of the R-33 floor on the next page). Some compression also occurs between the bottom of the duct and the belly board.

In the cavity at the end of each trailer, the insulation should be cut into the last cavity or a batt of similar R-value added at the joist cavity between the I-beams or vertically between the flooring and the belly blanket insulation.

Two types of U-factors are found in the table in this section. A "steady-state" U-factor is listed for homes with zonal heating (baseboard units and wall heaters). For houses with forced air heating systems, duct conductive losses and the infiltration/exfiltration they induce affect the performance of floor system insulation. These effects must be taken into account when calculating the floor system U-factor for homes with forced air heating systems. (See Section 3.1.2 for further discussion.) The U-factors in the two right columns of the table include duct losses.

MAP Transverse Floor System U-Factors (Btu/hr·ft ² ·°F)				
nominal belly insulation (R-value)	floor framing	steady state (no duct effects included)	ducts with R-5 wrap	uninsulated ducts
33	2 x 6	0.032	0.033	0.035
33	2 x 8	0.031	0.032	0.034
44	2 x 6	0.030	0.031	0.032
44	2 x 8	0.029	0.030	0.031

Additional Transverse Floor System U-Factors (Btu/hr·ft ² ·°F)				
nominal belly insulation (R-value)	floor framing	steady state (no duct effects included)	ducts with R-5 wrap	uninsulated ducts
11	2 x 6	0.066	0.070	0.075
19	2 x 6	0.048	0.050	0.054
22	2 x 6	0.044	0.046	0.049

Upright Transverse Floor System

The upright transverse floor system is similar to the transverse floor system except that it is framed upright on the steel undercarriage. As a result, the cut-in technology used for conventionally-framed transverse floors cannot be used. The belly board and belly blanket are draped over the steel undercarriage. The duct is put in place along with electrical and plumbing services and then the framing is placed over the top, crushing the belly blanket and allowing insulation to be placed in from the top.

The general strategy is to increase the amount of belly insulation between the two steel I-beams and to install shortened batts in the joist space which extend from the rim joist to about 6 inches from the edge of the duct. (See first drawing on next page.) Since the insulation is placed in from above, more conventional batt insulation can be used with depth depending on the size of the floor joists themselves.

The analysis procedure used for this floor system is essentially the same as that used for the conventional transverse floor. Duct behavior is similar. Some improvement in performance is possible, given the extra insulation installed between the steel carriage I-beam and the duct. Duct insulation, as with all other floor systems, improves the performance of the floor. We used R-5 duct insulation in the calculations.

It is very important to use enough insulation between the rim joist and the I-beam so that air movement from the duct region to the rim joist is minimized. An extra piece of R-11 is added in two of the 2 x 8 floors to do this; the batt should extend at least 1' from the rim joist toward the center of the floor. (See second drawing on next page.)

The rim joist at the end of each trailer must also be insulated. If the duct extends to the outer wall, a R-19 or R-21 insulation batt should be placed vertically between the flooring and the belly blanket insulation, between the I-beams. If the duct stops short of the outside wall, then regular floor joist insulation should be placed in the last joist cavity next to the end wall.

For the last listing in the table, R-30 is used as the joist insulation, with this full value extending to within 6" of the duct (as described above).

Upright Transverse Floor System U-Factors (Btu/hr·ft ² ·°F)				
nominal belly/joist insulation (R-value)	floor framing	steady state (no duct effects included)	ducts with R-5 wrap	unin- sulated ducts
33*/19	2 x 6	0.028	0.029	0.030
33/19+11(o)***	2 x 8	0.028	0.029	0.030
33/21**	2 x 6	0.026	0.027	0.028
33/22	2 x 6	0.027	0.028	0.029
33/21+11(o)***	2 x 8	0.027	0.028	0.030
33/22+11(o)	2 x 8	0.028	0.029	0.030
33/30	2 x 8	0.024	0.025	0.026

* R-11 belly blanket throughout, with additional R-22 under duct region (see first drawing on next page)

** R-21 joist insulation is high density fiberglass (5 1/2" thick)

*** Extra R-11 batt extending from outrigger (o) at least 1' toward center of floor (see second drawing on next page)

Longitudinal Floor System

In the longitudinal floor configuration, the floor is constructed in a way that is similar to the transverse floor; however, the 2 x 6 floor joists are placed parallel to the steel undercarriage I-beams. The heating ducts, plumbing lines, and electrical service are located inside joist cavities in the center portion of the floor.

The floor is assembled upside down. First, the wooden floor frame is nailed together. The utility conduits (electrical and plumbing lines, heating ducts) are installed, then a "belly blanket" (one or more layers of insulation) is rolled over the assembly and covered with a reinforced plastic sheet called the "belly board" (or "bottom board"). The steel undercarriage is placed on top of all of this and strapped and bolted to the joist assembly. The entire system is then flipped back over and the flooring and heating registers installed.

Each half of a double-wide home's floor is thus constructed. The two halves are joined, and an insulated flexible crossover duct, which runs below the belly board, connects the supply duct in each half.

Depending on the manufacturer, various levels of insulation are used in the belly blanket and joist cavities. The belly blanket is compressed somewhat in the region between the outermost I-beam and the rim joists and crushed dramatically where the I-beams and floor joists cross. Joist cavity insulation is compressed if it is R-19 or R-22, since the cavity space is only 5 1/2". This compression reduces the performance of the insulation and was taken into account when computing the overall floor U-factor. The high-density R-21 batt fits into the 5 1/2" space with no compression.

Two types of U-factors are found in the table in this section. A "steady-state" U-factor is listed for homes with zonal heating (baseboard units and wall heaters). For houses with forced air heating systems, duct conductive losses and the infiltration/exfiltration they induce affect the performance of floor system insulation. These effects must be taken into account when calculating the floor system U-factor for homes with forced air heating systems. (See Section 3.1.2 for further discussion.) The U-factors in the three right columns (calculated for uninsulated ducts and two levels of duct insulation) do factor in duct losses.

Because of its positioning, the ductwork (whether insulated or not) contributes less to the heat loss of the longitudinal floor than the transverse floor. There is always some belly blanket insulation below the ducts, but never any above, since the duct takes up almost all of the space in the joist cavity where it is located. Conductive and other duct losses are confined in a relatively small space and a significant portion of the losses leak back into the house. Increasing belly blanket insulation beyond R-11 enhances this effect. Adding joist cavity insulation further improves floor thermal performance.

Duct insulation improves the floor system's thermal performance. We calculated the U-factor for the floor system with an R-5 wrap around the duct. (To account for compression of the R-5 wrap, its R-value is reduced to R-4.)

MAP Longitudinal Floor System U-Factors (Btu/hr•ft ² •°F)				
belly/joist insulation nominal R-value	floor framing	steady state (no duct effects included)	ducts with R-5 wrap	unin- sulated ducts
11*/22	2 x 8	0.032	0.031	0.033
22/19	2 x 6	0.030	0.031	0.033
22/22	2 x 6	0.030	0.031	0.032
22/21**	2 x 6	0.029	0.030	0.031

* Assumes an extra R-7 batt under the duct region.

** High density R-21 batt (5 1/2" thick)

Additional Longitudinal Floor System U-Factors (Btu/hr·ft ² ·°F)				
belly/joist insulation nominal R-value	floor framing	steady state (no duct effects included)	ducts with R-5 wrap	unin- sulated ducts
11/19	2 x 6	0.037	0.039	0.042
14/19	2 x 6	0.035	0.036	0.038
11/22	2 x 6	0.036	0.038	0.041
14/22	2 x 6	0.034	0.035	0.038
11/21*	2 x 6	0.035	0.037	0.040
14/21	2 x 6	0.033	0.034	0.036

* High density R-21 batt (5 1/2" thick)

CEILING SYSTEMS

Truss Geometry

A variety of trusses are used by manufactured home builders. For the purposes of the many tables in the following sections, standard assumptions about trusses were used:

- a ceiling pitch of 2.5:12;
- trusses constructed of 2 x 2s;
- maximum available insulation cavity space (at the center, or "king post") of 40" in attics and 16" in sloped ceilings;
- gable-end venting for some ceilings, continuous soffit vents with 1" insulation clearance (assured by baffles) for other ceilings, as noted.

Sloped ceilings have become increasingly popular, and therefore, additional tables were prepared which pair the smallest ("heel") and largest ("king post") truss cavities for R-38 sloped ceilings. Both dimensions are varied to achieve a U-factor which meets the MAP specifications.

The roof pitch in these cases is set at 2.5:12, a 1" airspace above the insulation is assumed in the first table, and the framing is 2 x 2 pre-manufactured trusses, spaced at 16" o.c. The inside ceiling pitch is determined by the king post dimension. The drawing below indicates where the important truss measurements are taken.

R-38 Sloped Ceiling With Soffit Vents		
heel height (inches)	blown insulation*	batt insulation**
	king post height	king post height
4.25	22.5 (80)***	23 (77)
4.75	20.5 (87)	21 (86)
5.125	19 (97)	19.5 (93)
5.875	17 (112)	16.5 (113)
6.125	16.5 (116)	16 (122)
6.875	15 (136)	14.5 (145)
7.25	14.5 (143)	--

* Mineral wool: $R = 2.9 \text{ hr}\cdot\text{ft}^2\cdot^\circ\text{F}/\text{Btu}\cdot\text{inch}$

** Fiberglass: $R = 3.16 \text{ hr}\cdot\text{ft}^2\cdot^\circ\text{F}/\text{Btu}\cdot\text{inch}$

*** Horizontal distance along truss where insulation reaches full depth

R-38 Sloped Ceiling With Gable-End Vents		
heel height* (inches)	blown insulation	batt insulation
	king post height	king post height
3.5	21 (81)	21 (81)
4.25	18.5 (93)	18 (96)
4.75	17 (102)	16 (112)
5.125	16 (110)	15 (122)
5.875	14.5 (127)	13.5 (144)
6.125	14 (134)	--
7.25	14.5 (143)	--

* This dimension is measured at the same place as the heel for the soffit vent cases, the difference being no baffle and hence no 1" venting space.

Attics and Sloped Ceilings With Batt Insulation and Gable Vents

To calculate the U-factors found in the following tables, a parallel heat loss calculation, corrected for the effects of the attic or vault buffer space, was done for different ceiling insulation nominal R-values. A detailed description of the analysis is found in Sections 2.2 and 3.2.2 of this manual.

Until recently, manufactured home ceiling assemblies were insulated with batts which were not wide enough to cover the space over the truss chords. This increased the uninsulated (void) portion of the ceiling and subsequently reduced its thermal performance. So-called oversized, or "mushroom" batts are now available, and use of these batts enables ceilings to meet MAP specifications. (See first drawing on next page.)

In most manufactured homes, there is about 6" of space available for insulation above the top plate. This allows an R-19 fiberglass batt to be placed all the way to the edge of the ceiling without being crushed. For ceilings built to MAP specifications, much more insulation than this must be placed all the way to the edge; hence, batts are sometimes crushed quite a lot to fit into the truss heel. The degradation in insulation performance due to crushing is accounted for in the calculation of the overall ceiling U-factor.

Depending on manufacturer (and climate zone), the size of the cavity at the top plate (called the "heel height") varies. The most common heel height found in field visits was 6 1/8." In all cases, a 0.21 roof pitch was assumed. Vaulted (inside) ceiling pitch varies depending on manufacturer.

Some manufacturers used polyurethane foam mastic to attach the ceiling gypsum board to the trusses. This technique offers a slight improvement in the ceiling U-factor and is shown in the U-factor table for oversized batts.

Attic venting is accomplished with gable-end vents and some sort of mechanical ventilation.

Following are drawings of flat and sloped ceilings with gable vents, a table of U-factors for ceilings insulated with oversized batts and a table of additional U-factors for ceilings insulated with standard size batts.

U-factors for Attics and Sloped Ceilings (oversized batts, gable vents and trusses spaced 16" o.c)							
Attic		U-Factor (Btu/hr·ft ² ·°F)		Sloped Ceiling		U-Factor (Btu/hr·ft ² ·°F)	
nominal R-value	heel height (inches)	crushed batts	with foam mastic	nominal R-value	heel height (inches)	crushed batts	with foam mastic
30	4.5	.033	.033	30	4.5	.035	.035
	6.125	.032	.031		6.125	.034	.033
	9.	.032	.031		9.	.033	.032
38	4.5	.028	.027	38	4.5	.032	.031
	6.125	.027	.026		6.125	.030	.029
	9.	.026	.026		9.	.028	.027
49	4.5	.024	.023				
	6.125	.023	.022				
	9.	.022	.021				

U-factors for Attics and Sloped Ceilings (oversized batts, gable vents and trusses spaced 24" o.c)							
Attic		U-Factor (Btu/hr·ft ² ·°F)		Sloped Ceiling		U-Factor (Btu/hr·ft ² ·°F)	
nominal R-value	heel height (inches)	crushed batts	with foam mastic	nominal R-value	heel height (inches)	crushed batts	with foam mastic
30	4.5	.032	.032	30	4.5	.035	.034
	6.125	.032	.031		6.125	.033	.033
	9.	.031	.031		9.	.032	.031
38	4.5	.027	.027	38	4.5	.031	.031
	6.125	.026	.026		6.125	.029	.029
	9.	.026	.025		9.	.027	.027
49	4.5	.023	.023				
	6.125	.022	.022				
	9.	.021	.021				

Additional U-Factors for Attics and Sloped Ceilings (crushed standard batts, gable vents, and trusses spaced 16" o.c.)					
Attic			Sloped Ceiling		
nominal R-value	heel height (inches)	U-Factor (Btu/hr·ft ² ·°F)	nominal R-value	heel height (inches)	U-Factor (Btu/hr·ft ² ·°F)
19	4.5	.056	19	4.5	.056
	6.125	.056		6.125	.056
	9.	.056		9.	.056
25	4.5	.049	25	4.5	.049
	6.125	.048		6.125	.048
	9.	.048		9.	.048
30	4.5	.045	30	4.5	.048
	6.125	.044		6.125	.046
	9.	.044		9.	.044
33	4.5	.043	33	4.5	.046
	6.125	.042		6.125	.044
	9.	.042		9.	.042
38	4.5	.040	38	4.5	.043
	6.125	.039		6.125	.041
	9.	.039		9.	.039
49	4.5	.037			
	6.125	.036			
	9.	.035			

Attics and Sloped Ceilings With Batt Insulation, Cardboard Baffle, and Soffit Vents

To calculate the U-factors found in the following tables, a parallel heat loss calculation, corrected for the effects of the attic or vault buffer space, was done for different ceiling insulation nominal R-values. A detailed description of the analysis is found in Sections 2.2 and 3.2.2 of this manual.

Until recently, manufactured home ceiling assemblies were insulated with batts which were not wide enough to cover the space over the truss chords. This increased the uninsulated (void) portion of the ceiling and subsequently reduced its thermal performance. So-called oversized, or "mushroom" batts are now available, and use of these batts enables ceilings to meet MAP specifications. (See first drawing on next page.)

In most manufactured homes, there is about 6" of space available for insulation at the ceiling's edge (above the top plate). This allows an R-19 fiberglass batt to be placed all the way to the edge of the ceiling without being crushed. For ceilings built to MAP specifications, much more insulation than this must be placed all the way to the edge; hence, batts are sometimes crushed quite a lot to fit into the truss heel. The degradation in insulation performance due to crushing is accounted for in the calculation of the overall ceiling U-factor.

Soffit vents and cardboard baffles are used in this approach. The baffle is stapled to the top of the trusses and maintains an air space of at least 1" between the insulation and the roof sheathing. The full nominal value of insulation is placed all the way to the edge of the truss heel, even if it must be crushed into the small space. Depending on the initial thickness of the batt and the extent to which it is crushed, the ceiling's thermal performance can be reduced considerably by crushing. This reduction is accounted for in the calculation of the overall ceiling U-factor.

Depending on manufacturer (and climate zone), the size of the available cavity at the top plate (called the "heel height") varies. The most common heel height found in field visits was 5 1/8". This heel height is the same as in the ceilings which use gable-end vents, reduced by the 1" venting space. In all cases, a 0.21 roof pitch is assumed. Vaulted (inside) ceiling pitch varies depending on manufacturer; for these tables, a 16" inch cavity at the ceiling's center line ("king post") is assumed.

Some manufacturers used polyurethane foam mastic to attach the ceiling gypsum board to the trusses. This technique offers a slight improvement in the ceiling U-factor and is shown in the U-factor table for oversized batts.

Following are drawings of flat and sloped ceilings with soffit vents, a table of U-factors for ceiling systems insulated with oversized batts and tables of additional U-factors for ceilings insulated with crushed and stepped standard size batts.

U-factors for Attics and Sloped Ceilings (oversized batts, soffit vents and trusses spaced 16" o.c.)							
Attic		U-Factor (Btu/hr·ft ² ·°F)		Sloped Ceiling		U-Factor (Btu/hr·ft ² ·°F)	
nominal R-value	heel height (inches)	crushed batts	with foam mastic	nominal R-value	heel height (inches)	crushed batts	with foam mastic
30	3.5	.033	.033	30	3.5	.037	.036
	5.125	.032	.031		5.125	.035	.034
	8.	.032	.031		8.	.033	.032
38	3.5	.028	.028	38	3.5	.034	.033
	5.125	.027	.027		5.125	.031	.030
	8.	.026	.026		8.	.028	.028
49	3.5	.024	.024				
	5.125	.023	.023				
	8.	.022	.022				

U-factors for Attics and Sloped Ceilings (oversized batts, soffit vents, cardboard baffle and trusses spaced 24" o.c.)							
Attic		U-Factor (Btu/hr·ft ² ·°F)		Sloped Ceiling		U-Factor (Btu/hr·ft ² ·°F)	
nominal R-value	heel height (inches)	crushed batts	with foam mastic	nominal R-value	heel height (inches)	crushed batts	with foam mastic
30	3.5	.033	.032	30	3.5	.036	.036
	5.125	.032	.031		5.125	.034	.033
	8.	.031	.031		8.	.032	.031
38	3.5	.028	.028	38	3.5	.033	.033
	5.125	.027	.026		5.125	.030	.030
	8.	.026	.025		8.	.027	.027
49	3.5	.024	.024				
	5.125	.023	.022				
	8.	.021	.021				

Additional U-Factors for Attics and Sloped Ceilings (crushed standard batts, soffit vents, cardboard baffle, and trusses spaced 16" o.c.)					
Attic			Sloped Ceiling		
nominal R-value	heel height (inches)	U-Factor (Btu/hr·ft ² ·°F)	nominal R-value	heel height (inches)	U-Factor (Btu/hr·ft ² ·°F)
19	3.5	.056	19	3.5	.056
	5.125	.056		5.125	.056
	8.	.056		8.	.056
25	3.5	.049	25	3.5	.050
	5.125	.049		5.125	.049
	8.	.048		8.	.048
30	3.5	.045	30	3.5	.047
	5.125	.044		5.125	.045
	8.	.044		8.	.044
33	3.5	.043	33	3.5	.046
	5.125	.042		5.125	.044
	8.	.042		8.	.042
38	3.5	.041	38	3.5	.044
	5.125	.040		5.125	.042
	8.	.039		8.	.039
49	3.5	.037			
	5.125	.036			
	8.	.035			

Additional U-Factors for Attics and Sloped Ceilings (stepped standard batts, soffit vents, cardboard baffle, and trusses spaced 16" o.c.)					
Attic			Sloped Ceiling		
nominal R-value	heel height (inches)	U-Factor (Btu/hr·ft ² ·°F)	nominal R-value	heel height (inches)	U-Factor (Btu/hr·ft ² ·°F)
22	3.5	.054	22	3.5	.059
	5.125	.053		5.125	.056
	8.	.052		8.	.052
30	3.5	.046	30	3.5	.051
	5.125	.045		5.125	.048
	8.	.044		8.	.045
33*	3.5	.046	33	3.5	.049
	5.125	.045		5.125	.047
	8.	.044		8.	.044
38	3.5	.043	38	3.5	.052
	5.125	.042		5.125	.050
	8.	.041		8.	.046
49	3.5	.040			
	5.125	.039			
	8.	.037			

* In R-33 "step", first 2 R-11s are compressed together in truss heel.

Flat and Vaulted Ceilings With Blown-In Insulation and Gable Vents

A parallel heat loss calculation, corrected for the effects of the attic or vault buffer space, was done for different ceiling insulation nominal R-values. A detailed description of the analysis is found in Section 2.2 and 3.2.2 (above).

For this section, the material used for insulation is assumed to be blown-in mineral wool, R-2.9 per inch (if installed at 1.7 lb/ft³). Pre-manufactured trusses form the ceiling structure, and insulation is blown into the ceiling cavity, completely covering the lower truss cord for the amounts of insulation analyzed.

The venting strategy in this case is a gable-end vent with an induced attic ventilation system. The insulation is blown in at the edge all the way to the roof sheathing to achieve higher insulation values than could be obtained if a uniform airspace were needed above the insulation. (This is what occurs in the next section, where soffit vents are used.) This gives better thermal performance, especially for vaulted ceilings.

Depending on manufacturer (and climate zone), the size of the available cavity at the top plate (called the "heel height") varies. The most common heel height found in field visits was 6 1/8." In all cases, a 0.21 roof pitch is assumed. Vaulted (inside) ceiling pitch varies depending on manufacturer; for these tables, a 16" inch cavity at the ceiling's center line ("king post") is assumed.

The following pages present drawings of the ceiling systems.

U-factors for Blown Attics and Sloped Ceilings (mineral wool and gable vents)					
Attic			Sloped Ceiling		
nominal R-value	heel height (inches)	U-factor (Btu/hr•ft ² •°F)	nominal R-value	heel height (inches)	U-factor (Btu/hr•ft ² •°F)
19	4.5	.046	19	4.5	.046
	6.125	.045		6.125	.045
	9	.045		9	.045
25	4.5	.038	25	4.5	.039
	6.125	.036		6.125	.037
	9	.034		9	.035
30	4.5	.032	30	4.5	.035
	6.125	.031		6.125	.032
	9	.030		9	.030
33	4.5	.030	33	4.5	.033
	6.125	.029		6.125	.030
	9	.028		9	.028
38	4.5	.028	38	4.5	.032
	6.125	.026		6.125	.029
	9	.025		9	.026
49	4.5	.024			
	6.125	.023			
	9	.021			

Flat and Vaulted Ceilings With Blown-In Insulation and Soffit Vents

A parallel heat loss calculation, corrected for the effects of the attic or vault buffer space, was done for different ceiling insulation nominal R-values. A detailed description of the analysis is found in Section 2.2 and 3.2.2 (above).

For this section, the material used for insulation is assumed to be blown-in mineral wool, R-2.9 per inch (if installed at 1.7 lb/ft³). Pre-manufactured trusses form the ceiling structure, and insulation is blown into the ceiling cavity, completely covering the lower truss cord for the amounts of insulation analyzed.

The venting strategy in this case is a continuous soffit vent at the eaves. The insulation is blown in to allow 1" clearance below the roof sheathing. This results in reduced depth at the truss heel and over much of the truss area, particularly for vaulted ceilings.

Depending on manufacturer (and climate zone), the size of the available cavity at the top plate (called the "heel height") varies. The most common heel height found was 5 1/8". This heel height is the same as in the ceilings which use gable-end vents, reduced by the 1" venting space. In all cases, a 0.21 roof pitch is assumed. Vaulted (inside) ceiling pitch varies depending on manufacturer; for these tables, a 16" inch cavity at the ceiling's center line ("king post") is assumed.

The following page presents drawings of these ceiling systems.

U-factors for Blown Attics and Sloped Ceilings (with mineral wool and soffit vents)					
Attic			Sloped Ceiling		
nominal R-value	heel height (inches)	U-factor (Btu/hr•ft ² •°F)	nominal R-value	heel height (inches)	U-factor (Btu/hr•ft ² •°F)
19	3.5	.047	19	3.5	.049
	5.125	.046		5.125	.047
	8.	.044		8.	.044
25	3.5	.039	25	3.5	.041
	5.125	.037		5.125	.038
	8.	.035		8.	.035
30	3.5	.033	30	3.5	.037
	5.125	.032		5.125	.033
	8.	.030		8.	.031
33	3.5	.032	33	3.5	.035
	5.125	.030		5.125	.032
	8.	.028		8.	.029
38	3.5	.029	38	3.5	.034
	5.125	.027		5.125	.030
	8.	.025		8.	.026
49	3.5	.026			
	5.125	.023			
	8.	.021			

WALL SYSTEMS

Stress-Skin Walls

Walls for Northwest manufactured home are constructed in two ways. One way employs conventional post-and-beam (simple span) construction. The other method is to design the entire wall as a diaphragm or stress-skin panel. This design strategy allows the wall sheathing and framing to work together to provide more sufficient structural stability while using less wood than in the post and beam wall.

A primary reason the stress-skin method is used by manufacturers is because of their ability to enforce strict quality control in the factory. Another reason is the combination of reduced framing and improve thermal performance this technique offers. The stress-skin design depends on an integrated, whole-wall structural system. The wall finish and exterior sheathing combine with the wall studs to give the wall its strength. As a result, most of the ceiling load is borne without needs for true headers; window and door openings require little additional framing. The amount of wood needed for wall framing is reduced by about 25% and the U-factor of the wall is correspondingly better, since this wood is replaced by fiberglass insulation.

The stress-skin approach uses a single-stud "header" (actually, the cross-section looks like the rest of the wall) and a two stud corner. Some manufacturers use a box beam header (not for R-11 walls, since they are framed with 2 x 4s), especially for large openings, and a two stud corner with an extra piece of blocking (the "2.5" stud corner), which creates an additional uninsulated cavity.

The assumptions used to generate U-factors for this wall framing strategy are:

- The wall studs are framed at 16" on center, with single studs at large openings.
- For R-19 and R-22 walls, the insulation is crushed into the 5 1/2" cavity, reducing its performance somewhat. This crushing is factored into the wall U-factor calculation. The R-21 insulation is a high-density batt which is 5 1/2" thick and therefore uncompressed.
- Single layer exterior sheathing and siding is used, a single layer of interior gypsum wall board is used.
- A 1 x 6 single bottom plate and a 2 x 6 single top plate are continuous across the wall length.

Some manufacturers add 1/4" of foam (R-1) to the wall exterior during framing. This adds a continuous layer of R-1 to the wall. Others use 1/2" of extruded polystyrene (R-2.5). Stress-skin walls that meet the MAP prescriptive specifications are shown below. A table with other stress-skin wall U-factors follows the description of post-and-beam walls.

MAP Stress-Skin Wall U-Factors (Btu/hr·ft ² ·°F)							
	insulation nominal R-value	2 stud corner	w/ R-1 foam	w/R-2.5 rigid ins.	"2.5" stud corner	w/R-1 foam	w/R-2.5 rigid ins.
single stud header	19	DNC*	.052	.048	DNC	.052	.048
	21	.050	.047	.044	.050	.048	.044
	22	DNC	.051	.047	DNC	.051	.047
box beam header	19	--	--	--	DNC	DNC	.049
	21	--	--	--	.051	.048	.045
	22	--	--	--	DNC	.051	.047

* does not comply with MAP prescriptive specifications

Post & Beam Walls

The wall framing strategy used by some manufacturers is similar to that used in site-built homes. The structural engineering is based on a post-and-beam, (simple span) design which assumes, for the most part, that each structural element in the wall operates independently. As a consequence of this, a larger portion of the wall is given over to studs, headers, and other structural members than in the other type of wall (stress-skin) used in the industry.

Two building methods for this type of wall were observed in the field. The first uses solid wood headers (usually three 2 x 6s) and solid wood corners (three 2 x 6 studs or a 4 x 6). The second method uses a box beam header, with insulation stuffed into the 2 1/2 space between two 2 x 6s, and a two stud corner with an extra piece of blocking (the "2.5" stud corner) which creates an additional uninsulated cavity. When framing is done with 2 x 4 studs, these methods are identical, since there are no cavities available for extra insulation.

The assumptions used to generate U-factors for this wall framing strategy are:

- The wall studs are framed at 16" on center, with extra studs for headers.
- For R-19 and R-22 walls, the insulation is crushed into the 5 1/2" cavity, reducing its performance somewhat. This crushing is factored into the wall U-factor calculation. The R-21 insulation is a high-density batt which is 5 1/2" thick and therefore uncompressed.
- Single layer exterior sheathing and siding is used, a single layer of interior gypsum wall board is used.
- A 1 x 6 single bottom plate and a 2 x 6 single top plate are continuous across the wall length.

Some manufacturers add 1/4" of foam (R-1) to the wall exterior during framing. This adds a continuous layer of R-1 to the wall. Others use 1/2" of extruded polystyrene (R-2.5).

MAP Post & Beam Wall U-Factors (Btu/hr·ft ² ·°F)							
	insulation nominal R-value	3 stud corner	w/ R-1 foam	w/R-2.5 rigid ins.	"2.5" stud corner	w/R-1 foam	w/R-2.5 rigid ins.
box beam header	19	DNC*	DNC	.050	DNC	DNC	.049
	21	DNC	.050	.046	.051	.048	.045
	22	DNC	DNC	.049	DNC	.051	.047
solid header	19	DNC	DNC	.051	--	--	--
	21	DNC	.052	.048	--	--	--
	22	DNC	DNC	.050	--	--	--

* does not comply with MAP prescriptive specifications

Wall Corner Types

2 Stud Corner

"2.5" Stud Corner

3 Stud Corner

Header Types

Single Stud Header

Box Beam Header

Solid Header

Additional Stress-Skin Wall U-Factors (Btu/hr·ft ² ·°F)							
	insulation nominal R-value	2 stud corner	w/ R-1 foam	w/R-2.5 rigid ins.	"2.5" stud corner	w/R-1 foam	w/R-2.5 rigid ins.
Single Stud Header	11	.081	.075	.067	.082	.075	.067
	19	.055	MAP*	MAP	.056	MAP	MAP
	22	.054	MAP	MAP	.054	MAP	MAP
Box Beam Header	19	--	--	--	.056	.053	.049
	22	--	--	--	MAP	MAP	.047

Additional Post & Beam Wall U-Factors (Btu/hr·ft ² ·°F)							
	insulation nominal R-value	3 Stud corner	w/ R-1 foam	w/R-2.5 rigid ins.	"2.5" stud corner	w/R-1 foam	w/R-2.5 rigid ins.
Box Beam Header	19	.058	.054	MAP	.056	.053	MAP
	21	.053	MAP*	MAP	MAP	MAP	MAP
	22	.056	.053	MAP	.055	MAP	MAP
Solid Header	11	.088	.080	.071	--	--	--
	19	.060	.056	MAP	--	--	--
	21	.056	MAP	MAP	--	--	--
	22	.059	.054	MAP	--	--	--

* See MAP wall table (previous page)

WINDOWS

MAP Windows and Simulated U-factors

The following table shows those windows which are acceptable under the MAP program, indicating the frame type, glazing coatings (if any) and the gas found in the minimum 1/2" space between the panes. The U-factors for these windows are the defaults to be used until an improved combined simulation/testing program is developed by the National Fenestration Rating Council (NFRC).

Window area is based on rough opening dimensions. Doors with 50% or more glazing are considered windows, and shall use window defaults for the entire opaque and non-opaque area, the default value determined by the window type and door material (window frame).

An additional table of window U-factors is provided. These U-factors come from the *Window 3.1* simulation program (Lawrence Berkeley Laboratory, 1991). The primary assumptions used in the simulation are a frame conductivity (U-factor) of 0.40 and double-strength panes with a space of 1/2" between them. This space is filled with air or argon. The performance of vinyl frame windows varies with extrusion technique and other factors. The conductivity of the frame used in these simulation is higher than most vinyl or wood frame configurations and results in U-factors which are generally higher than tested values. *Window 3.1* does not give significant improvement in U-factor for airspaces greater than 1/2", although tested values usually show marked improvement with airspaces of, for example, 3/4". There is always disagreement between tested U-factors and simulated U-factors for windows with argon fill. Tested values for argon-fill windows are generally better (lower U-factor) than simulated values.

We ran simulations for several combinations of window frame and low-emissivity (low- ϵ) coatings, including vinyl window frames, low- ϵ hard coats ($\epsilon = 0.40$), and low- ϵ soft coats ($\epsilon = 0.10$). Most low- ϵ manufacturers use windows with coatings in the middle emissivity range ($\epsilon = 0.20$). We also ran a simulation for a single- and double-pane aluminum frame storm window added to a prime aluminum frame window.

We calculated the values in the table by averaging the simulation results for two window types: a large fixed window and a smaller operable window. Because these values are averages, the U-factors differ slightly from those contained in the 1989 *ASHRAE Handbook, Fundamentals*. Since manufactured homes typically contain a variety of window sizes and frame types, the average is probably a good representation of window packages installed in manufactured homes.

MAP Window Default U-factors (Btu/hr·ft ² ·°F)			
frame material	Glazing Type		
	low- ϵ coating (if any) coefficient	gas in space between panes	U-factor (Btu/hr·ft ² ·°F)
vinyl or wood	none	air	0.45
vinyl or wood	0.20	air	0.40
vinyl or wood	none	argon	0.40
vinyl or wood	0.20	argon	0.35

Simulated (Window 3.1) Window U-factors (Btu/hr·ft ² ·°F)												
Frame Type	Glazing Type											
	double clear		hard coat low-ε (ε=0.4)		hard coat low-ε (ε=0.2)		soft coat low-ε (ε=0.1)		Heat Mirror®		Triple Glaze	
	air	argon	air	argon	air	argon	air	argon	air	argon	air	argon
wood or vinyl	0.49	0.47	0.42	0.40	0.39	0.35	0.37	0.33	0.31	0.29	0.37	0.35
aluminum w/TB*	0.62	0.59	0.55	0.52	0.51	0.48	0.49	0.44	0.44	0.41	0.50	0.48
aluminum w/storm	0.45	0.43	0.42	0.40	0.40	0.38	0.39	0.36	--	--	--	--
aluminum w/double storm	0.35	--	--	--	--	--	--	--	--	--	--	--

* thermal break

SKYLIGHTS

Skylights

Two types of skylights are typically installed in manufactured homes. The most common is a curbless skylight which mounts flush to the roof and is flashed into the roofing material. These skylights are usually made of multiple layers of polycarbonate to improve thermal performance. The other type of skylight is the curbed, mounted skylight. This type of skylight is more typical in site-built homes. In this style, a wood or metal curb is mounted on the roof surface and flashed to the roofing. The skylight is mounted on the curb, thus raising it three to six inches above the roof's surface. Because of the extra surface area created by raising the skylight above the roof surface, this type of skylight has additional heat loss.

In the MAP specifications, the maximum U-value for skylights is set at 0.50. The configuration which leads to 0.50 has been limited to a specific number of components, which are independent of mounting procedures and curbing details (see first table).

For skylights of lower thermal performance, default values have been tabulated (second table) for use in component performance calculations. Skylights in this table are not eligible under MAP prescriptive paths.

As for windows, the skylight tables may be revised depending on the outcome of the NFRC simulation testing procedures and their applicability to the skylights used in manufactured homes.

MAP Default Skylight U-factors						
frame material	curb	glazing type	number of glazing layers	coating (if any)	gas in space between panes	U-factor (Btu/hr·ft ² ·°F)
none	none	acrylic (dome)	3	none	air	0.50
vinyl	2 x 3	glass	2	low-ε	argon	0.40
TIM*	2 x 3	glass	2	low-ε	argon	0.50
wood	2 x 3	glass	2	low-ε	argon	0.40

Additional Skylight U-factors						
frame material	curb	glazing type	number of glazing layers	coating (if any)	gas in space between panes	U-factor (Btu/hr·ft ² ·°F)
none	none	acrylic (dome)	2	none	air	0.70
vinyl	2 x 3	glass	2	none	air	0.70
TIM*	2 x 3	glass	2	none	air	0.70
wood	2 x 3	glass	2	none	air	0.70

* thermally improved metal (frame has thermal break)

OPAQUE DOORS

Opaque Doors

Doors most commonly used to meet the MAP specifications are fiberglass or metal with foam core, at least 1 1/2" thick, with a thermal break.

Under the MAP specifications, a door is considered "opaque" if less than 50% of the door's surface area is taken up by double glazing. Doors with 50% of or more glazing are considered windows.

Tables of U-factors for opaque doors commonly used in manufactured housing are found in the appendix. These values are derived from data found in ASHRAE *Fundamentals* (1989) and from tests done according to AAMA or ASTM standards. The values given in the table assume a 15 mph wind across the exterior surface. Doors are to be completely weatherstripped. If storm doors are used, they are to be made from the same material as the primary door.

Default MAP U-factors for Exterior Doors (Btu/hr•ft ² •°F)	
Type	
Fiberglass or TIM*, 1 3/4" thick, foam core, flush (no glazing)	0.14
Fiberglass or TIM*, 1 1/2" (minimum) thick, foam core	0.19
Wood, 1 1/2" (minimum) thick, solid core	0.40

Additional U-factors for Exterior Doors (Btu/hr•ft ² •°F)		
		with storm door
Wood, 1 3/8", solid core flush	0.40	0.26
Wood, 1 3/8", solid core panel	0.57	0.33
Wood, 1 3/8", hollow core flush	0.47	0.30
Wood, 1 3/4", solid core flush	0.33	0.28
Wood, 1 3/4", solid core panel	0.57	0.33
Wood, 1 3/4", hollow core flush	0.46	0.29
Wood, 2 1/4", solid core flush	0.27	0.20
Metal, 1 3/4", thick, foam core, no thermal break	0.30	0.25

* thermally improved metal (has thermal break)

END

**DATE
FILMED**

7 / 28 / 92