AIM

Association for Information and Image Management

1100 Wayne Avenue, Suite 1100
Silver Spring, Maryland 20910
301/587-8202

Centimeter

Inches

MANUFACTURED TO AIM STANDARDS
BY APPLIED IMAGE, INC.

1 of 1

NOTICE

**CERTAIN DATA
CONTAINED IN THIS
DOCUMENT MAY BE
DIFFICULT TO READ
IN MICROFICHE
PRODUCTS.**

DECLASSIFIED

This document contains information affecting the national defense of the United States within the meaning of the espionage laws, the transmission or the revelation of its contents in any manner to an unauthorized person is prohibited by law and may result in severe criminal or civil penalties.

10-17211
cc: 2 CC Casertofeld
3 RC Thorburn
4 DL Reid
5 JW Realy
6 700 File
7 Pink Copy
8 Yellow Copy
RECEIVED
JUL 21 1993
O S/TI

RECORD COPY FILE
March 15, 1950

Dr. F. C. Wende, Jr.
Mound Laboratory
Monsanto Chemical Co.
Miamisburg, Ohio

RECEIVED

MAR 29 1956

300 AREA
CLASSIFIED FILES

THIS DOCUMENT CONSISTS OF 4 PAGES NO. 8
OF 8 COPIES, SERIES

Dear Frank:

TTA ANALYSIS

Classified by 10-17211
DECLASSIFIED
By Authority of 10-17211

During your visit to Hanford, in February of 1950, you requested a copy of the TTA procedure which we are currently using in Bio-Assay for urine analysis. Since we are, at the moment, in the state of reorganizing all work in the Bio-Assay group, it is apparent that a complete set of procedures will not be available for some time to come. For that reason I am sending you the current TTA analysis now in use in this group. The procedure as listed below is given for urine but should be usable for other materials and has been used for water samples, for instance, with obvious modifications in the preparation of the sample.

1. Add about 200 ml of nitric acid to the urine sample in a 2 liter erlenmeyer flask.
2. Place the erlenmeyer on a hot plate; evaporate the contents to dryness. Do not boil rapidly or spattering will occur.
3. Allow the flask to cool, and add about 100 ml of 8N acid. Heat on a slow heat until the solids go into solution and the crud is washed from the sides of the flask.
4. When the sample is in solution transfer to a 250 ml beaker, rinse the erlenmeyer thoroughly with distilled water, and add the wash water to the beaker.
5. Evaporate the sample to dryness on a hot plate.
6. When the sample is dry muffle at 600° C for thirty minutes or longer if necessary to obtain a white or grayish-white ash. This removes most of the urea and other organic materials. If the sample is not completely white or a grayish-white, add a small amount of conc. nitric acid, reheat on the hot plate to dryness and repeat the muffling step.
7. Add 50 ml of 2N nitric acid to the beaker containing the salts and dissolve by stirring and a small amount of heat if necessary.

DISTRIBUTION RESTRICTED TO U.S. ONLY

DECLASSIFIED

MASTER

DECLASSIFIED

8. Add 1 gm of hydroxylamine hydrochloride and stir until dissolved.
9. Transfer the sample to 100 ml pyrex centrifuge tube.
10. To each tube add 20 mg. of La^{+++} carrier as the nitrate dissolved in 1 ml of water, and stir.
11. Add 7 mls of 27N hydrofluoric acid to each tube and stir thoroughly.
12. Centrifuge for 5 minutes at 1800 rpm.
13. Discard the supernate liquid.
14. Wash the precipitate with 10 ml of 1N HF -1N HNO_3 solution, centrifuge and discard the washings.
15. Break up the precipitate with a stirring rod and stir the slurry with 1/2 ml of aluminum nitrate solution. This step should be done with great care since a good slurry, at this point, will aid considerably in dissolving the lanthanum fluoride precipitate.
16. Add exactly 40 ml of aluminum nitrate solution to the tube and dissolve the lanthanum fluoride precipitate.
17. Transfer the contents of the centrifuge tube to a 120 ml separatory funnel. Wash the centrifuge tube carefully with exactly 10 ml of water and add the washings to the separatory funnel.
18. Add 0.25 ml of a solution containing 1.2 gms of sodium nitrite in 10 ml of distilled water.
19. Allow the funnel to stand for 15 minutes.
20. Add 10 ml of a solution containing 10 gms of TTA dissolved in 100 ml of benzene.
21. Shake the separatory funnel for 20 minutes.
22. Discard the aluminum nitrate solution.
23. Add 30 ml of distilled water and shake for 10 minutes.
24. Discard the water wash, add 10 ml distilled water and shake for 10 minutes.
25. Discard the wash water.
26. Add 10 ml of 8N nitric acid on a 1-1/2 inch diameter stainless steel plate. Wash the TTA benzene solution remaining with 5 ml of 8N nitric acid and evaporate on the same plate.

27. Flame the plate in a Bunsen burner flame and count for alpha emitters.

I. The Aluminum Nitrate.

The acid normality of the aluminum nitrate solution for the extraction is very critical. If the normality is too high the plutonium will not extract, if the normality is too low other contaminants normally present in lanthanum will extract and give erroneous results. The solution is made by dissolving 1489 gms of aluminum nitrate in 2000 mls. of water. Acid is then added until a titration to a methyl orange end point of 5 mls. of the solution requires between 2.60 and 2.70 mls of 1N NaOH. This designation was chosen rather than the normality because of the difficulties in expressing acid normalities in a solution containing a large amount of aluminum which will precipitate if the titration is carried to end points below that of methyl orange. This normality of acid in the aluminum nitrate will give good extraction when 40 ml of the solution are diluted with the 10 ml of wash water. For this reason it is quite important in the procedure to follow the exact quantities in this step precisely.

II. Lanthanum Nitrate.

All of the lanthanum commercially available appears to be rather highly contaminated with some alpha emitter which is presumably in the actinium series. When using the TTA procedure to look for trace amounts on the order of 0.5 dis/min of plutonium, this contamination can be extremely serious. Two methods of purifying the lanthanum are available at Hanford; first is a more or less brute force method which appears to eliminate the daughters fairly successfully. The second one which is still in process of development is the ion column procedure. The process now in use consists of a barium sulfate precipitation followed by a manganese dioxide precipitation and extraction with TTA from an approximately neutral solution. This procedure is listed stepwise below for your use if interested.

1. Dissolve 25 gms. of lanthanum in water and precipitate twice with ammonium hydroxide.
2. Dissolve the final ammonium hydroxide precipitate in a minimum of acid and neutralize until precipitate just forms.
3. Add 200 mg of barium as barium nitrate and 10 ml of sodium sulfate solution containing 500 mg of sodium sulfate per 10 ml of water.
4. Allow the solution to stand until the precipitate forms.
5. Centrifuge the precipitate and wash with 250 ml of cold water.
6. Repeat step 5 three times and combine the washings.
7. Precipitate the lanthanum twice with ammonium hydroxide.
8. Dissolve the ammonium hydroxide precipitate in 50 ml of 4N nitric acid and heat to a low boil.

DECLASSIFIED

9. Add 200 mg. of potassium permanganate and neutralize with caustic to a pH of 8. Allow to stand for one hour at 60 to 90°C and make acid with conc. nitric.
10. Cool the solution under tap water.
11. Acidify to pH 2 to 3 and centrifuge the solution.
12. Dilute the supernate to 250 ml and add 150 ml of ammonium hydroxide.
13. Centrifuge and repeat the ammonium hydroxide precipitation.
14. Dissolve the precipitate in a minimum amount of nitric acid and dilute.
15. Neutralize to a methyl orange end point with ammonium hydroxide. Add this ammonium hydroxide slowly so that the lanthanum hydroxide does not form.
16. Dissolve 50 gms of ammonium nitrate in the solution.
17. Place equal portions in five separatory funnels and shake with 20 ml of TTA in each funnel for 25 minutes.
18. Discard the benzene-TTA solution and precipitate the lanthanum from the raffinate with ammonium hydroxide.
19. Dissolve the precipitate in a minimum amount of acid and adjust concentration to that desired.

These procedures will give good results if applied by a person who is careful in his work and has had a little experience. One thing which has come up recently indicates that low yields may be obtained on the process if the starting solution contains large amounts of salts. We believe this to be due to the presence of sulfates and phosphates in the urine. If you are to be dealing with solutions containing large amounts of salts, we have found that dissolving the original lanthanum precipitate in 2N nitric acid by adding the concentrated acid then the water and reprecipitating gives good yields.

If there are any other details on this procedure with which you have trouble or which I may help please do not hesitate to call on me.

Sincerely yours,

J. W. Healy
Development Division
Health Instrument Divisions

JWH:L

DECLASSIFIED

**DATE
FILMED**

9 / 2 / 93

END