DOE/PC/91159--T1

DEVELOPMENT OF A REBURNING BOILER PROCESS MODEL

DOE/PC/91159--T1

DE92 013027

First Quarterly Progress Report

October 1, 1991 through December 31, 1991

Prepared for:

U.S. Department of Energy
Pittsburgh Energy Technology Center

DOE Contract No. DE-FG22-91PC91159

Prepared by:

K.T. Wu

Energy and Environmental Research Corporation
18 Mason
Irvine, California 92718

January 30, 1992

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

MASTER
DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

215

1.0 OBJECTIVE

The overall objective of this program is to integrate EER's expertise in boiler reburning performance evaluation into a package of analytical computer tools. Specific objectives of the program are to develop a computational capability with the following features:

- (a) can be used to predict the impact of gas reburning application on thermal conditions in the boiler radiant furnace, and on overall boiler performance
- (b) can estimate gas reburning NO_x reduction effectiveness based on specific reburning configurations and furnace/boiler configurations.
- (c) can be used as an analytical tool to evaluate the impact of boiler process parameters (e.g., fuel switching and changes in boiler operating conditions) on boiler thermal performance.
- (d) is adaptable to most boiler designs (tangential and wall fire boilers) and a variety of fuels (solid, liquid, gaseous and slurried fuels).
- (e) is sufficiently user friendly to be exercisable by engineers with a reasonable knowledge of boilers, and with reasonable computer skills. Here, "user friendly" means that the user will be guided by computer codes during the course of setting up individual input files for the boiler performance model.

2.0 APPROACH

The approach to the development of the reburning boiler process model is through the modification and integration of EER's current reburning system submodels. As with any comprehensive engineering computer models, the reburning submodels occupy a substantial amount of computer memory and usually require a list of inputs to describe the complex boiler environment. These submodels are considered to be too unwieldy to be directly incorporated into a single generalized design/evaluation procedure. As an alternative, the approach is to package these submodels into three main analytical tools, namely, a furnace heat transfer model, a boiler performance model, and a reburning NO_x model. The coupling of process design information amongst the three submodels will be established through input/output interfaces, and through the use of boiler design data and any available field measurements.

3.0 PROGRAM STRUCTURE

In order to achieve the overall objectives, the execution of the program has been broken down into five tasks. These tasks and their individual objectives are briefly discussed in the following.

Task 1. Development of a 2D Furnace Heat Transfer Model

Under this task, EER's 2D furnace heat transfer model (2DHT) will be modified for most boiler designs, firing configurations, as well as different fuels. Specifically, the 2D Model will be set up for treatment of tangential and wall fired boilers, and adapted to solid, liquid, gaseous and slurried fuels. The code will also incorporate the ability to describe gaseous reburning fuel injection, overfire air injection and flue gas recirculation.

In conjunction with the 2D Model modifications, Task 1 will also focus on modification and improvement of a guided input-code (2DINPT) so that the user will be guided stepwise through the necessary input routines, and will be provided with default values for certain key parameters. This input code will also be used by the user to update key model inputs for cases defined.

Task 2. Development of a Boiler Performance Model

The purpose of Task 2 is to develop a Boiler Performance Model which calculates steam- and gas-side heat balance for boiler sections that are not included in the domain of the 2D Model, such as the backpass convective section and air preheater. The approach taken to prepare the Boiler Performance Code will be in line with the preparation of the 2D Furnace Heat Transfer Model. EER's Boiler Performance Code will be modified and tested in responding to any changes made in the 2D Model to ensure mutual consistency. In addition, a separate input code for the operation of the Boiler Performance Model will be prepared in order to provide guidance to the user in input file preparations.

Task 3. Development of a Reburning NO_x Model

The purpose of this task is to develop a NO_x model which provides reasonable working estimates for the expected NO_x reduction potential as a function of the major boiler process controlling parameters. The boiler process parameters include furnace gas temperature profiles and residence time distributions, local stoichiometries up- and down-stream of the reburning fuel injection zone, reburn fuel and overfire air local mixing rates, and injection locations.

To develop the Reburning NO_x Model, EER's chemical kinetics codes will firstly be modified to take account of a wide range of boiler operating conditions with the consideration of reburning zone injection temperature, stoichiometry, flue gas quench rates and residence times. The model will assume that mixing of both reburning fuel and overfire air is adequate so that bulk mixing rates of the injected jets can be represented by characteristic mixing times. The model will then be coupled with the outputs of the Furnace Heat Transfer Code which in turn incorporates the input of boiler-specific information such as temperature gradients and gas residence times. This model will predict NO_x emissions for a specific set of boiler input and

reburning conditions, so that the user will be able to evaluate NO_x reduction potentials associated with the assumed operating conditions.

Task 4. System Model Integration

As discussed above, six computer codes (i.e., three input-codes, and three main-codes) will be developed upon completion of Tasks 1 to 3. Task 4 will integrate these six computer codes into a complete boiler reburning model-package through input/output file connections. The operation of the boiler modeling package will be streamlined and kept as simple as possible to the user. This task will also carry out testing and performance evaluation of the integrated computer package. Example cases will be selected to demonstrate the use of different model options and capabilities.

Task 5. Document Preparation and Model Delivery

This task consists of two major reporting items: Preparation of a User's Manual, and provision of consulting and short courses. The purpose of this task is to assist the user in applying the boiler model-package, and to provide necessary support until he become familiar with the operation of the computer codes.

The manual will be constructed to include: (a) a brief description of the physical and chemical basis of the models, (b) a complete description of the model applicability, options and input/output, (c) a description of the default inputs, (d) a detailed description of worked examples. The Reburning Boiler Performance codes will be structured in PC formats. Executable versions of the codes will be prepared in the form of floppy disk sets and delivered with the User's Manual.

This task will also provide telephone consultation service for a limited time period following delivery of the Reburning Boiler Performance Model. A three-day short course instruction will be provided on the basis of necessity.

4.0 TECHNICAL PROGRESS

During this reporting period, the model developmental effort has focused on modification of the 2D heat transfer code, in order to accommodate the various options as stated in the work scope of Task 1. Specific progress and accomplishments are summarized in the following.

(a). Completion of the Furnace Input Code (2DINPT)

Extensive code modifications and testing have been carried out on the furnace input-code.

Completed items which are of significance to the users are:

- Modifications for gas and oil firing
- Modifications for reburn/co-firing options
- Addition of default values for oil and gas firing
- Improvement on the ease of use in flow field descriptions
- Improvement on the quality of user/computer interactive communications

The completed 2DINPT Code has been tested for several assumed boiler cases which fired different fuels such as coal, oil, and gas. The results indicate that the code is fully functional and performs as designed. A sample output for a gas-fired furnace is shown in Appendix A. Additional refinement of the 2DINPT code is expected as the development of other computer codes continues. However, the extent of future modifications would be relatively narrow compared to those already have been accomplished.

(b). Modification and Testing of the Furnace Code (2DHT)

In conjunction with the work accomplished in item (a), the Furnace Code has been modified to include additional capabilities. These modifications include abilities to handle oil and gas fired furnaces, and fuel co-firing/reburning applications. For oil firing, the code can include the use of steam for fuel atomization. Codings for reburning applications, including the use of FGR for reburn gas injection, have also been placed. In addition, a large portion of the code have been re-structured to improve computational efficiency and output flexibility.

The revised 2DHT Code has been tested for coal, gas, and oil firing. Satisfactory results have been obtained for the oil and coal cases. However, difficulties of numerical instability had occurred for the oil firing cases. The cause of this instability has been identified, and work is continued to improve the ability of the code to handle oil-fired furnaces. Appendix B shows the format of the model outputs for a preliminary test case with oil firing.

5.0 PLANS

The next reporting period will focus on the remaining of the tasks, especially, on the execution of the following items which are listed in order of priorities:

- Completion of the Furnace Code modifications and testing
- Development of the NO_x Model and an input-code for the NO_x Model.
- Preparation of the Boiler Performance Model
- Model integration

APPENDIX A. SAMPLE OUTPUT FROM THE INPUT CODE

-- This is an interactive program (2DINPT) to create
or update a data file which is required to run the
EER two-dimensional heat transfer code (2DHT)
-- Version 1.68, January 1992

***** Attention *****
This interactive program accepts inputs from keyboard
in UPPER case only.
-- Please set your keyboard to the UPPER case symbols
(i.e., Caps Lock !).
-- To continue, type C and press Return (or Enter)

C

STATUS OF INPUT FILE:

To Create an input file, press C key
To Update an input file, press Return
You chose to update an existing input file

NOTE:

-- To update an existing file, you have to copy the
existing file to file "INPUT.DAT" under DOS before you
execute this input code.
-- The updated file will have a default file name as "2DINPT.DAT"

To continue, press Return

STATUS OF 2D GRID FILE (GRID.DAT)

Option A : Generation of grid file by ALTGEO
 You will exit this program and execute ALTGEO
Option B : Use an existing grid file
Option C : Use this program to create a grid file
Option D : None of the above

For option A, press: A key
For option B, B key
For option C, C key
For option D, Return

You chose option D

Chapter 1 :

INPUT/OUTPUT SPECIFICATIONS AND PARAMETERS WHICH
CONTROL THE EXTENT OF NUMERICAL CALCULATIONS

Press: P key to by-pass this chapter
Return to proceed through this chapter

Specify the name (BOLNAM) of the boiler: HENNEPIN
-- Maximum characters allowed: 24
-- Characters can be alphabetic or numeric

Press: C key to change the values
Return to continue

Specify a two-digit case number (NRCS) for
current run (e.g., 01, 02, or 03): 02
-- Case number can be used to distinguish the boiler operating
conditions, or parametric parameters being studied

Press: C key to change the values
Return to continue

Specify a two-digit version number (NRVS) for
current run (e.g., 01, 02, or 03): 01
-- Version number can be used to further document cases run
under the same case number as specified above

Press: C key to change the values
Return to continue

Specify boiler load (CLOAD) for current run: 100.
-- Boiler load may be described as 60.5, 90.0, or 100.0,
to show the % of current load relative to the boiler MCR

Press: C key to change the values
Return to continue

Name of input data file (FINPT): 2dinpt.dat
-- Default file name is 2DINPT.DAT

Press: D key for default values
C key to change the values
Return to continue

Name of input array file (FINPTAR): IARR0201
-- The default name has format as IARRCSVS.LLL
-- IARR denotes "input array"
-- CSVS represents the case number and the version numbers
-- .LLL shows the boiler load percentage.

Press: D key for default values
C key to change the values
Return to continue

Name of output array file (FINPTAR): OARR0201
-- The default name has format as OARRCSVS.LLL
-- OARR denotes "output array"

Press: D key for default values
C key to change the values
Return to continue

Name of output graphic file (FGRFOPT): GRFO
-- The default name has format as GRFOCSVS.LLL
-- GRFO denotes "graphic array"

Press: D key for default values
C key to change the values
Return to continue

Name of output printer file (FHDOPT): hdot0201
-- The default name has format as HDOTCSVS.LLL
-- HDOT denotes "printer file"

Press: D key for the default file name
C key to change the file name
B key to direct the file to your monitor
Return to continue

Specification of output level (LOUTPUT) :
Current output level is DEFAULT
-- DEFAULT setting is most useful and recommended
-- In addition to the default setting, you can choose from
four other output levels : 1, 2, 3, and 4
-- Higher output levels give more comprehensive information

Press: D key for default values
C key to change the values

Return to continue

You can include your comments on the front page of the printout :

- Comment block may consist of 10 lines
- Each line may have a max. of 78 characters

To continue, press Return

Current comments are:

" Line 1 is blank "

CASE 1: Baseline, Hennepin

100% LOAD (75 MWe Gross)

" Line 4 is blank "

Test case for v 1.68

. GAS firing

. start from scratch

. same thermal input as coal firing (0101)

. same flow field

" Line 10 is blank "

Press: C key to change the values
Return to continue

Maximum number of iterations for this run

NIMAX=100

-- During the test phase, set NIMAX =1

-- For production runs, use NIMAX values between 30 and 100

Press: C key to change the values
Return to continue

Switch to suppress the Monte Carlo averaging-process

0: not to suppress (Default), 1: to suppress

Currently, ICONTRL= 0

Press: D key for default values
C key to change the values
Return to continue

Number of iterations at which the averaging procedure is initialized to smooth-out the Monte Carlo effects :

NITACC= 71

-- For runs without averaging, set NITACC = NIMAX

-- For complete averaging, set NITACC =1

-- For typical runs, set NITACC = NIMAX - 30

Press: C key to change the values
Return to continue

Convergence criteria (ERRMX) for total energy balance = 0.45000 %

Convergence criteria (HEBMX) for gas zone heat balance = 0.25000 %

-- Default values are 0.45 % and 0.25 %, respectively.

Press: D key for default values
C key to change the values
Return to continue

Number of sub-iterations for fixed carbon mass balances per iteration of total heat balance :

NIMX= 1

-- During test phase, set NIMX=1

-- For coal combustion, set NIMX between 5 and 10

-- For gaseous and oil fuels, set NIMX=1

Press: C key to change the values
Return to continue

(a) Number of divisions on the largest linear dimension of volume zones: NMAX= 2

(b) Divisions of polar angle: NPFI= 4

(c) Cut-off value for beam tracking: EXACT=0.000100
Default values are: NMAX = 2
 NPHI = 4
 EXACT = 0.0001
NMAX and NPHI must be even numbers

Press: D key for default values
 C key to change the values
 Return to continue

Number of iterations after which field variables
of total heat balances are printed :

NPRIN= 100

-- Default value is NPRIN=NIMAX (recommended)

Press: D key for default values
 C key to change the values
 Return to continue

Switch for printing mean emissivities along furnace:

0: to turn-off, 1: to turn-on this option

Currently, IPNTEM= 0

Press: C key to change the values
 Return to continue

Switches to print detailed outputs of:

-- total energy balance for volume and surface zones

-- mass balance for volume zones

Enter: Y key to print
 N key to suppress
 Return to continue

Switches to write or read files to/from hard disk :

NWRTE: Switch to save data file at the end of the 2DHT run

Currently, NWRTE= 1

NREAD: Switch to read variable values from a restarting

file at the beginning of the 2DHT run

Currently, NREAD= 0

-- For trial runs, set NWRTE=1 and NREAD=0

-- For continued runs, set NWRTE=1 and NREAD=1

Press: C key to change the values
 Return to continue

NWRTE= 1, NREAD= 0, Are these values O.K. ?

Press: C key to change the values
 Return to continue

Chapter 2 :

BOILER FURNACE OPERATING DATA

Press: P key to by-pass this chapter
 R key to save file and exit 2DINPT
 Return to proceed through this chapter

FUEL TYPE

For gaseous fuels, set NGAS= 1, NLIQ= 0, NSLL= 0

For liquid fuels, set NGAS= 0, NLIQ= 1, NSLL= 0

For solid fuels, set NGAS= 0, NLIQ= 0, NSLL= 1

Currently, NGAS= 1 NLIQ= 0 NSLL= 0

Press: C key to change the values
 Return to continue

You chose gas as fuel

Press Return to continue

Do you want to change fuel composition ?

Press: C key to change the values
Return to continue

The following is only information

Equivalent proximate analysis of fuel in kg/kg wet
PCFX=0.0001 PVOL=0.9998 PMOI=0.0000 PASH=0.0001

Equivalent ultimate analysis of fuel in kg/kg dry
UCAR=0.7487 UHYD=0.2513 UNIT=0.0000
UOXY=0.0000 USUL=0.0000 UASH=0.0001

Press Return to continue

Gross (higher) heating value of fuel in kJ/kg wet :
HUSW= 55647.0

Press: C key to change the values
Return to continue

Fuel flow rate in kg wet / sec :
FUSW= 3.9845

Press: C key to change the values
Return to continue

Gross fuel heat input is 221725.5 kw

Press: C key to change the values
Return to continue

Temperature of gaseous fuel in K :
TFS= 298.15

Press: C key to change the values
Return to continue

Specific heat of fuels in kJ/kg dry K :
CPFS= 2.2490
Default values: 1.1000 for coal
1.8334 for oil
2.2490 for gas

Press: D key for default values
C key to change the values
Return to continue

Air Flow Rates and Properties

Current settings:

Total air (wet, kg/sec) flow rate = 75.9860
Total stoichiometric air ratio = 0.0000
O2 % (dry) in flue gas = 0.0000

You have three options to choose:

Option A -- Specify total air flow rate (wet) in kg/sec
Option B -- Specify total stoichiometric air ratio
Option C -- Specify O2 % (dry) in the flue gas

Press A, B, or C for your option
Press Return to continue

DMA2W = 75.9860
AIRNR = 0.0000
FLUO2D= 0.0000
Are these final settings O.K. ?

Press: C key to change the values
Return to continue

Water vapor content in air

(a) Relative humidity in % : RELHA2= 50.0000
(b) Saturation pressure in bar : PSH2A2= 0.0317
Default values are 50 % and 0.0317 bar at 298.15 K

Press: D key for default values
C key to change the values
Return to continue

Temperature of secondary air in K :
TA2= 545.47

Press: C key to change the values
Return to continue

Amount of primary air in % of stoichiometric air :
PASTCH=20.0
Default value is 20%

Press: D key for default values
C key to change the values
Return to continue

Convective heat transfer coefficient at furnace walls
in $\text{kw/m}^2 \text{ K}$: ALPHA= 0.0116
Default value is 0.0116 $\text{kw/m}^2 \text{ K}$

Press: D key for default values
C key to change the values
Return to continue

Cool side temperature of furnace walls in K : TOUT=634.00
Default value is 750.0 K

Press: D key for default values
C key to change the values
Return to continue

Chapter 3 :

INITIAL COAL PARTICLE SIZE DISTRIBUTION

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

Gas Firing:
Default values have been automatically set
Press Return to continue

Chapter 4 :

PARAMETERS FOR CHAR AND VOLATILE BURN-OUT

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

Fuel "Volatile" Burnout Characteristics
"Volatile" burnout time in sec : TLFMAX= 0.78
-- Default values are 0.7 sec
-- For highly swirling flow, set TLFMAX=0.4
-- For delayed mixing flame such for T-fired
boiler, set TLFMAX=1.4

Press: D key for default values

C key to change the values
Return to continue

Number of lumps used to represent fuel "volatile"
combustion : NVLTOT= 10000.
-- Default value is 10000.

Press: D key for default values
C key to change the values
Return to continue

Fractional conversion of "volatile" carbon to soot :
CMCVLS= 0.00
-- Default value is 0.1 (for high volatile bituminous flames)
-- For lignite flames, set to 0.05
-- For heavy oil flames, set to 0.2
-- For non-luminous gaseous flames, set to 0.0

Press: D key for default values
C key to change the values
Return to continue

Chapter 5 :

PARAMETERS FOR SORBENT REACTIVITIES

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

Switch to exercise sorbent injection option:
NSORB= 0
-- To exercise sorbent injection option, set NSORB= 1
Otherwise, set NSORB= 0
-- Default value is NSORB= 0

Press: D key for default values
C key to change the values
Return to continue

This is only information
Flag NFLOLD for flow field status :
NFLOLD= 1

Fraction of total sulfur as pyritic sulfur :
PRSULF= 0.3665
-- Default value is 0.0
-- For gas and oil firing, may set to 0.0

Press: D key for default values
C key to change the values
Return to continue

Chapter 6 :

PARAMETERS FOR PARTICLE SCATTERING

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

Switch for ash particle scattering
0: to turn-off, 1: to turn-on this option
Currently, NNSCT= 0

Press: C key to change the values
Return to continue

Chapter 7 :

SPECIFICATION OF FURNACE MODEL GEOMETRY

Press: P key to by-pass this chapter
 R key to save file and exit 2DINPT
 Return to proceed through this chapter

Number of volume zones in X-direction, NX=22

Press: C key to change the values
 Return to continue

Number of volume zones in Y-direction, NY= 4

Press: C key to change the values
 Return to continue

Zone extension in X-direction DX(i) in m :

3.0280	0.9075	1.7385	1.7384	1.2540	1.2540	1.2540	2.0698	1.0723	2.1018
0.8550	2.1161	2.1161	3.2217	1.6000	2.9494	2.9494	2.9495	1.9577	1.9577
2.4073	2.3762								

Press: C key to change the values
 Return to continue

Furnace extension in X-direction in m : 43.8724

Press: C key to change the values
 Return to continue

Zone extension in Y-direction DY(j) in m :

2.1114	0.8745	0.5647	0.4865
--------	--------	--------	--------

Press: C key to change the values
 Return to continue

Furnace extension in Y-direction in m : 4.0371

Press: C key to change the values
 Return to continue

Minimum I-indices :

1	1	2	3
---	---	---	---

Press: C key to change the values
 Return to continue

Maximum I-indices :

22	22	13	13
----	----	----	----

Press: C key to change the values
 Return to continue

Minimum J-indices :

1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
1	1																	

Press: C key to change the values
 Return to continue

Maximum J-indices :

2	3	4	4	4	4	4	4	4	4	4	4	2	2	2	2	2	2	2
2	2																	

Press: C key to change the values
 Return to continue

Chapter 8 :

PARAMETERS FOR REBURNING OR CO-FIRING

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

Switch for reburning or co-firing
0: to turn-off, 1: to turn-on this option
Currently, NREB= 0

Press: C key to change the values
Return to continue

Chapter 9 :

SPECIFICATION OF HEAT EXTRACTIONS

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

Heat Extraction by Heat Sinks
Option A: No additional surface area
Option B: Cooled surface area located at
circumferential walls (M=4) of
a refractory covered furnace
Option C: Simulation of radiant heat exchangers
in upper furnace

Currently option C is exercised

Press: C key to change
Return to continue

--- Simulation of Radiant Heat Exchangers ---

Press: P key to by-pass this section
R key to save file and exit 2DINPT
Return to proceed through this section

- (a) Lower index of I zone layers occupied by the
simulated heat exchangers: ISHL=19
- (b) Upper index of I zone layers occupied by the
simulated heat exchangers: ISHU=22

Press: C key to change the values
Return to continue

Heat exchanger geometric configurations

Press: P key to by-pass this subsection
Return to proceed through

----- ZONE LAYER I =19 -----
Total heat sink surface area (m**2)
at I=19 is 282.7989
-- Set to 0.0 if it is a cavity.

Press: C key to change the values
Return to continue

Outer diameter of exchanger tubes (m)
at I = 19 is 0.054000

Press: C key to change the values
Return to continue

Simulation of heat exchanger arrangement at I= 19

You have three options :

- Option A: Specify number of cylindrical panels,
and equi-distant radial spacing
- Option B: Specify number of tubes per cylindrical panel,
and equi-distant radial spacing
- Option C: Computer-aided simulation

Press the corresponding key for your option
To proceed without change, press Return

--- At zone layer I= 19 ---

Number of panels= 10
Distance between panels= 0.2838
Number of tubes per panel= 17

Press: C key to change the values
Return to continue

Factor which relates radiation intercepting area to
projected area of the simulated panel (FAKPR)
at I=19 is 1.0000

-- If tube spacing is small, a value larger than 1.0 may be
used, but [tube number*O.D.*FAKPRR] should not exceed DX(1)
-- Default value is 1.0.

Press: D key for default values
C key to change the values
Return to continue

Ratio of panel projected-area to zonal area (PROB)
at i=19 is 0.4688

----- ZONE LAYER I =20 -----

Total heat sink surface area (m**2)
at I=20 is 237.6496

-- Set to 0.0 if it is a cavity.

Press: C key to change the values
Return to continue

Outer diameter of exchanger tubes (m)
at I = 20 is 0.054000

Press: C key to change the values
Return to continue

Simulation of heat exchanger arrangement at I= 20

You have three options :

- Option A: Specify number of cylindrical panels,
and equi-distant radial spacing
- Option B: Specify number of tubes per cylindrical panel,
and equi-distant radial spacing
- Option C: Computer-aided simulation

Press the corresponding key for your option
To proceed without change, press Return

--- At zone layer I= 20 ---

Number of panels= 8
Distance between panels= 0.3643
Number of tubes per panel= 17

Press: C key to change the values
Return to continue

Factor which relates radiation intercepting area to
projected area of the simulated panel (FAKPR)
at I=20 is 1.0000

-- If tube spacing is small, a value larger than 1.0 may be

used, but [tube number*O.D.*FAKPRR] should not exceed DX(1)
-- Default value is 1.0.

Press: D key for default values
C key to change the values
Return to continue

Ratio of panel projected-area to zonal area (PROB)
at i=20 is 0.4689

----- ZONE LAYER I =21 -----
Total heat sink surface area (m**2)
at I=21 is 434.9701
-- Set to 0.0 if it is a cavity.

Press: C key to change the values
Return to continue

Outer diameter of exchanger tubes (m)
at I = 21 is 0.054000

Press: C key to change the values
Return to continue

Simulation of heat exchanger arrangement at I= 21
You have three options :
Option A: Specify number of cylindrical panels,
and equi-distant radial spacing
Option B: Specify number of tubes per cylindrical panel,
and equi-distant radial spacing
Option C: Computer-aided simulation

Press the corresponding key for your option
To proceed without change, press Return

--- At zone layer I= 21 ---
Number of panels= 12
Distance between panels= 0.2378
Number of tubes per panel= 22

Press: C key to change the values
Return to continue

Factor which relates radiation intercepting area to
projected area of the simulated panel (FAKPR)
at I=21 is 1.0000
-- If tube spacing is small, a value larger than 1.0 may be
used, but [tube number*O.D.*FAKPRR] should not exceed DX(1)
-- Default value is 1.0.

Press: D key for default values
C key to change the values
Return to continue

Ratio of panel projected-area to zonal area (PROB)
at i=21 is 0.4935

----- ZONE LAYER I =22 -----
Total heat sink surface area (m**2)
at I=22 is 437.8012
-- Set to 0.0 if it is a cavity.

Press: C key to change the values
Return to continue

Outer diameter of exchanger tubes (m)
at I = 22 is 0.054000

Press: C key to change the values

Return to continue

Simulation of heat exchanger arrangement at I= 22

You have three options :

- Option A: Specify number of cylindrical panels,
and equi-distant radial spacing
- Option B: Specify number of tubes per cylindrical panel,
and equi-distant radial spacing
- Option C: Computer-aided simulation

Press the corresponding key for your option
To proceed without change, press Return

--- At zone layer I= 22 ---

Number of panels= 13

Distance between panels= 0.2149

Number of tubes per panel= 21

Press: C key to change the values
Return to continue

Factor which relates radiation intercepting area to
projected area of the simulated panel (FAKPR)
at I=22 is 1.0000

- If tube spacing is small, a value larger than 1.0 may be
used, but [tube number*O.D.*FAKPRR] should not exceed DX(1)
- Default value is 1.0.

Press: D key for default values
C key to change the values
Return to continue

Ratio of panel projected-area to zonal area (PROB)
at I=22 is 0.4773

Switch to distribute absorbed heat to tube banks
0: to turn-off, 1: to turn on
Currently, IDISHT= 0

Press: C key to change the values
Return to continue

Initial Values of Heat Exchanger Surface Temperatures (Gas Side, in K)

In volume zone layer I=19 :

J= 1 TWSINK= 814.10; J= 2 TWSINK= 803.72

In volume zone layer I=20 :

J= 1 TWSINK= 864.97; J= 2 TWSINK= 851.40

In volume zone layer I=21 :

J= 1 TWSINK= 829.27; J= 2 TWSINK= 819.03

In volume zone layer I=22 :

J= 1 TWSINK= 737.89; J= 2 TWSINK= 731.41

-- Default values are 800.00 K

Press: D key for default values
C key to change the values
Return to continue

Emissivities of heat exchanger surfaces

In volume zone layer I=19 :

J= 1 EWSINK= 0.7000; J= 2 EWSINK= 0.7000

In volume zone layer I=20 :

J= 1 EWSINK= 0.7000; J= 2 EWSINK= 0.7000

In volume zone layer I=21 :

J= 1 EWSINK= 0.7000; J= 2 EWSINK= 0.7000

In volume zone layer I=22 :

J= 1 EWSINK= 0.7000; J= 2 EWSINK= 0.7000

-- Default values are 0.7

Press: D key for default values

C key to change the values
Return to continue

Values of deposit conductivity/thickness ratios in $\text{kw/m}^2 \text{K}$

In volume zone layer I=19 :
J= 1 CSSINK= 0.3600; J= 2 CSSINK= 0.3600
In volume zone layer I=20 :
J= 1 CSSINK= 0.3600; J= 2 CSSINK= 0.3600
In volume zone layer I=21 :
J= 1 CSSINK= 0.2000; J= 2 CSSINK= 0.2000
In volume zone layer I=22 :
J= 1 CSSINK= 0.2000; J= 2 CSSINK= 0.2000
-- Default values are 0.4, 0.6, and 1.0 for coal,
oil, and gas-fired furnaces, respectively

Press: D key for default values
C key to change the values
Return to continue

Convective heat transfer coefficients (ALSH) at heat
exchanger surfaces in zone layers I=19 to 22,
in $\text{kw/m}^2 \text{K}$ (total surface area) :
0.0482 0.0482 0.0804 0.0807
-- Default values are 0.0500.

Press: D key for default values
C key to change the values
Return to continue

Heat exchanger steam or water side temperatures
(TOUTSH) in zone layers I=19 to 22, in K
734.00 815.00 784.00 700.00
-- Default values are 750.0 K.

Press: D key for default values
C key to change the values
Return to continue

Chapter 11 :

RELATIVE MASS FLOW RATE DISTRIBUTIONS

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

--- Prescription of Relative Inlet Mass Flows ---

Press: P key to by-pass this subsection
Return to proceed through

Relative inlet mass flow rates in pos. X-direction :
0.0000 0.0000 0.0000 0.0000

Press: C key to change the values
Return to continue

Relative inlet mass flow rates in neg. Y-direction :
0.0000 0.0000 0.0000 0.0000 0.3334 0.3333 0.3334 0.0000 0.0000 0.0000
0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000
0.0000 0.0000

Press: C key to change the values
Return to continue

--- Prescription of Relative Outlet Mass Flows ---

Press: P key to by-pass this subsection
Return to proceed through

Relative outlet mass flow rates in neg. X-direction :
0.0000 0.0000 0.0000 0.0000

Press: C key to change the values
Return to continue

Relative outlet mass flow rates in pos. X-direction :
0.5000 0.5000

You have three options to describe outlet flow
in positive X-direction:

Option A -- Zonewise prescription, press A key

Option B -- Use profile factors, press B key

Option C -- Default plug flow, press D key

To Proceed without any change, press Return

NOTE:

If you choose options B or D, it is assumed
that any additional outflow through side walls
prescribed later is due to flue gas recirculation

Relative outlet mass flow rates in neg. Y-direction :
0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000
0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000
0.0000 0.0000

Press: C key to change the values
Return to continue

Relative outlet mass flow rates in pos. Y-direction :
0.0000 0.0000 0.0000 0.0000 0.0000 0.0001 0.0000 0.0000 0.0000 0.0000
0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000
0.0000 0.0000

Press: C key to change the values
Return to continue

--- Prescription of Relative Zonal Mass Flow Rates ---

You have two options

-- Option A: Direct (i.e., zone by zone) prescription

-- Option B: Computer aided prescription (recommended)

Press: A key for option A
B key for option B
Return to continue

Relative mass flow rates DM1(i,j) in pos. X-direction:

J= 4	0.0000	0.0000	0.0000	0.0000	0.0000	0.0755	0.1510	0.0404	0.1195
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000	0.0755	0.1510	0.0894	0.1593
J= 2	0.0000	0.0000	0.0000	0.1050	0.2250	0.2412	0.2573	0.4061	0.3366
J= 1	0.0000	0.0500	0.2000	0.2450	0.2250	0.2412	0.2573	0.5141	0.3847
I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	
J= 4	0.1195	0.1195	0.1195	0.1195	0.0000	0.0000	0.0000	0.0000	0.0000
J= 3	0.1593	0.1593	0.1593	0.1593	0.0000	0.0000	0.0000	0.0000	0.0000
J= 2	0.3366	0.3366	0.3366	0.3366	0.2857	0.3846	0.3846	0.3846	0.3846
J= 1	0.3847	0.3847	0.3847	0.3847	0.7143	0.6154	0.6154	0.6154	0.6154
I=10	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	
J= 4	0.0000	0.0000	0.0000	0.0000	0.0000				
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000				
J= 2	0.3846	0.3846	0.4615	0.4615	0.5000				
J= 1	0.6154	0.6154	0.5385	0.5385	0.5000				
I=19	I=20	I=21	I=22	I=23					

Press: C key to change
Return to continue

If NFLOLD=2, you can NOT change

Relative mass flow rates DM3(i,j) in neg. X-direction:

J= 4	0.0000	0.0000	0.0000	0.1750	0.2250	0.1500	0.0750	0.0500	0.0000
J= 3	0.0000	0.0000	0.1536	0.1750	0.2250	0.1500	0.0750	0.0000	0.0000
J= 2	0.0000	0.0500	0.0464	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	
J= 4	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
I=10	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	
J= 4	0.0000	0.0000	0.0000	0.0000	0.0000				
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000				
J= 2	0.0000	0.0000	0.0000	0.0000	0.0000				
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000				
I=19	I=20	I=21	I=22	I=23					

Press: C key to change
Return to continue

If NFLOLD=2, you can NOT change

Relative mass flow rates DM2(i,j) in pos. Y-direction

J= 5	0.0000	0.0000	0.0000	0.0000	0.0000	0.0001	0.0000	0.0000	0.0000
J= 4	0.0000	0.0000	0.0000	0.0000	0.0750	0.0750	0.0250	0.1290	0.0000
J= 3	0.0000	0.0000	0.0000	0.0000	0.1500	0.1500	0.1086	0.1989	0.0000
J= 2	0.0000	0.0000	0.0000	0.0200	0.0750	0.0750	0.0491	0.1294	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	
J= 5	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 4	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.0000	0.0989	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
I=10	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	
J= 5	0.0000	0.0000	0.0000	0.0000					
J= 4	0.0000	0.0000	0.0000	0.0000					
J= 3	0.0000	0.0000	0.0000	0.0000					
J= 2	0.0000	0.0769	0.0000	0.0385					
J= 1	0.0000	0.0000	0.0000	0.0000					
I=19	I=20	I=21	I=22						

Press: C key to change
Return to continue

If NFLOLD=2, you can NOT change

Relative mass flow rates DM4(i,j) in neg. Y-direction

J= 5	0.0000	0.0000	0.0000	0.0000	0.3334	0.3333	0.3334	0.0000	0.0000
J= 4	0.0000	0.0000	0.1750	0.0500	0.2579	0.2577	0.4440	0.0000	0.0000
J= 3	0.0000	0.1536	0.1964	0.1000	0.1824	0.1822	0.5141	0.0000	0.0000
J= 2	0.0500	0.1500	0.0450	0.0000	0.0912	0.0911	0.3059	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	
J= 5	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 4	0.0000	0.0000	0.0000	0.1195	0.0000	0.0000	0.0000	0.0000	0.0000
J= 3	0.0000	0.0000	0.0000	0.2787	0.0000	0.0000	0.0000	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.3296	0.0000	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
I=10	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	
J= 5	0.0000	0.0000	0.0000	0.0000					
J= 4	0.0000	0.0000	0.0000	0.0000					
J= 3	0.0000	0.0000	0.0000	0.0000					
J= 2	0.0000	0.0000	0.0000	0.0000					
J= 1	0.0000	0.0000	0.0000	0.0000					
I=19	I=20	I=21	I=22						

Press: C key to change
Return to continue

If NFLOLD=2, you can NOT change

Residual of total mass balance for volume zones
as fraction of total input mass flow :

J= 4	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0001	0.0000
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	-0.0001	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0001	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
	I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9
J= 4	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 3	0.0000	0.0000	0.0000	-0.0001	0.0000	0.0000	0.0000	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
	I=10	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18
J= 4	0.0000	0.0000	0.0000	0.0000					
J= 3	0.0000	0.0000	0.0000	0.0000					
J= 2	0.0000	0.0000	0.0000	0.0000					
J= 1	0.0000	0.0000	0.0000	0.0000					
	I=19	I=20	I=21	I=22					

To continue, press Return

Chapter 12 :

PRESCRIPTION OF RECIRCULATING FLOW FIELD

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

Recirculating flow over cross-section I= 2
is 5.00 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I= 3
is 20.00 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I= 4
is 35.00 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I= 5
is 45.00 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I= 6
is 30.00 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I= 7
is 14.99 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I= 8
is 4.99 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I= 9
is 0.00 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=10
is 0.00 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=11
is 0.00 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=12
is 0.00 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=13
is 0.00 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=14
is -0.01 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=15
is -0.01 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=16
is -0.01 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=17
is -0.01 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=18
is -0.01 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=19
is -0.01 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=20
is -0.01 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=21
is -0.01 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Recirculating flow over cross-section I=22
is -0.01 % of total inlet mass flow.

Press: C key to change the values
Return to continue

Normalized velocities in Y-direction

J= 5	0.0000	0.0000	0.0000	0.0000	-0.5367	-0.5363	-0.5367	-0.0001	0.0000
J= 4	0.0000	0.0000	-0.2310	-0.0660	-0.3348	-0.3344	-0.7669	0.1430	0.0000
J= 3	0.0000	-0.4619	-0.3083	-0.1570	-0.0705	-0.0701	-0.8827	0.2623	0.0000
J= 2	-0.0638	-0.6379	-0.0999	0.0444	-0.0499	-0.0496	-0.7904	0.2413	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	
J= 5	0.0000	0.0000	0.0000	0.0001	0.0000	0.0000	0.0000	0.0000	0.0000
J= 4	0.0000	0.0000	0.0000	-0.1295	0.0000	0.0000	0.0000	0.0000	0.0000
J= 3	0.0000	0.0000	0.0000	-0.3594	0.0000	0.0000	0.0000	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	-0.6012	0.1185	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
I=10	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	
J= 5	0.0000	0.0000	0.0000	0.0000					
J= 4	0.0000	0.0000	0.0000	0.0000					
J= 3	0.0000	0.0000	0.0000	0.0000					
J= 2	0.0000	0.1516	0.0000	0.0625					
J= 1	0.0000	0.0000	0.0000	0.0000					
I=19	I=20	I=21	I=22	I=					

To continue, press Return

Chapter 13 :

PRESCRIPTION OF TURBULENT MASS FLUX VECTORS

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

This is the current relative turbulent mass flux
field with respect to the X-direction :

J= 4	0.0000	0.0000	0.0000	0.0000	0.0000	0.0755	0.0750	0.0404	0.0000
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000	0.0755	0.0750	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	
J= 4	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
I=10	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	
J= 4	0.0000	0.0000	0.0000	0.0000	0.0000				
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000				
J= 2	0.0000	0.0000	0.0000	0.0000	0.0000				
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000				
I=19	I=20	I=21	I=22	I=23	I=				

To continue, press Return

This is the current turbulent mass flux field
with respect to the Y-direction :

J= 5	0.0000	0.0000	0.0000	0.0000	0.0000	0.0001	0.0000	0.0000	0.0000
------	--------	--------	--------	--------	--------	--------	--------	--------	--------

J= 4	0.0000	0.0000	0.0000	0.0000	0.0750	0.0750	0.0250	0.0000	0.0000
J= 3	0.0000	0.0000	0.0000	0.0000	0.1500	0.1500	0.1086	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.0000	0.0750	0.0750	0.0491	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
	I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9
J= 5	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 4	0.0000	0.0000	0.0000	0.0001	0.0000	0.0000	0.0000	0.0000	0.0000
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
	I=10	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18
J= 5	0.0000	0.0000	0.0000	0.0000					
J= 4	0.0000	0.0000	0.0000	0.0000					
J= 3	0.0000	0.0000	0.0000	0.0000					
J= 2	0.0000	0.0000	0.0000	0.0000					
J= 1	0.0000	0.0000	0.0000	0.0000					
	I=19	I=20	I=21	I=22	I=				

To continue, press Return

You have three options to modify the turbulent field

Option A : Default distribution calculated by the
2DHT program (recommended)

Option B : No turbulence at all

Option C : Column- and row-wise prescriptions

Press: a corresponding key for your option

Return to continue

Residual of total mass balance for volume zones
as fraction of total input mass flow :

J= 4	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
	I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9
J= 4	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 3	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 2	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
J= 1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
	I=10	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18
J= 4	0.0000	0.0000	0.0000	0.0000					
J= 3	0.0000	0.0000	0.0000	0.0000					
J= 2	0.0000	0.0000	0.0000	0.0000					
J= 1	0.0000	0.0000	0.0000	0.0000					
	I=19	I=20	I=21	I=22					

To continue, press Return

Chapter 14 :

FUEL INLET FLOWS

Press: P key to by-pass this chapter

R key to save file and exit 2DINPT

Return to proceed through this chapter

Relative Fuel Inlet Flow Rates :

Default distribution assumes fuel inlet flows are
proportional to total mass flow rates, i.e., burners
are fired at same stoichiometry

Press: D key for default distribution

Return to continue

Prescription of Relative Fuel Inlet Flow Rates

Relative fuel inlet flow rates in pos. X-direction :

0.0000 0.0000 0.0000 0.0000

Press: C key to change the values

Return to continue

Relative fuel inlet flow rates in neg. Y-direction :

0.0000	0.0000	0.0000	0.0000	0.3333	0.3333	0.3334	0.0000	0.0000	0.0000
0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
0.0000	0.0000								

Press: C key to change the values
Return to continue

Chapter 15 :

DATA FOR INITIAL VOLUME AND SURFACE ZONE TEMPERATURES

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

--- Specification of Initial Volume-Zone Temperatures ---

Press: P key to by-pass this subsection
Return to proceed through

Initial temperature T(i,j) for volume zones
in degree K :

-- Default values are T(i,j)=1600 K
-- If you intend to read these data from disk (i.e., NREAD=1)
initial data of T(i,j) can be arbitrary

Press: D key for default values
C key to prescribe a constant value for all zones
Press: Return to prescribe zonal values, or to continue
without change

Initial data for volume zone temperatures T(i,j)
in degree K :

J= 4	1.00	1.00	1667.00	1613.00	1275.00	1255.00	1289.00	1642.00	1705.00
J= 3	1.00	1586.00	1664.00	1664.00	1566.00	1571.00	1582.00	1695.00	1718.00
J= 2	1317.00	1558.00	1636.00	1651.00	1640.00	1658.00	1675.00	1718.00	1720.00
J= 1	1308.00	1485.00	1525.00	1575.00	1612.00	1647.00	1673.00	1690.00	1685.00
	I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9
J= 4	1691.00	1649.00	1588.00	1518.00	1.00	1.00	1.00	1.00	1.00
J= 3	1713.00	1679.00	1623.00	1545.00	1.00	1.00	1.00	1.00	1.00
J= 2	1703.00	1680.00	1637.00	1571.00	1525.00	1492.00	1447.00	1404.00	1364.00
J= 1	1675.00	1654.00	1629.00	1584.00	1555.00	1535.00	1500.00	1462.00	1422.00
	I=10	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18
J= 4	1.00	1.00	1.00	1.00					
J= 3	1.00	1.00	1.00	1.00					
J= 2	1274.00	1196.00	1079.00	980.50					
J= 1	1322.00	1257.00	1136.00	1028.00					
	I=19	I=20	I=21	I=22					

To change the initial data column by column
press C key; else press Return

--- Specification of Initial Surface-Zone Temperatures ---

Press: P key to by-pass this subsection
Return to proceed through

Initial temperature TW(i,j) for surface zones
in degree K :

-- Default values are TW(*,*)=1200. K, except at outlets,
where you have to specify equivalent surface temperatures

Press: D key for default values
C key to prescribe a constant value for all zones
Press: Return to prescribe zonal values, or to continue

without change

Surface temperatures TW(*,1) in K :
400.00 748.10 887.30 1065.00

Press: C key to change the values
Return to continue

Surface temperatures TW(*,3) in K :
782.00 782.00 799.80 795.10

Press: C key to change the values
Return to continue

Surface temperatures TW(*,2) in K :
0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.00
0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.00
0.00 0.00

Press: C key to change the values
Return to continue

Surface temperatures TW(*,4) in K :
744.80 864.30 1062.00 1155.00 968.30 927.00 1018.00 1387.00 1345.00 1277.00
1080.00 891.30 793.40 786.70 765.90 757.70 736.60 721.90 675.90 669.50
662.20 649.60

Press: C key to change the values
Return to continue

--- Specification of Equivalent Surface Temperatures for Furnace Outlets ---

Press: P key to by-pass this subsection
Return to proceed through

Equivalent surface temperature (K) at outlet
J= 1, I=22 : TW(*,*)= 782.00

Press: C key to change the values
Return to continue

Equivalent surface temperature (K) at outlet
J= 2, I=22 : TW(*,*)= 782.00

Press: C key to change the values
Return to continue

Press: C key to check outlet-zone surface temperatures one more time
Return to continue without checking

Chapter 16 :

DATA FOR EMISSIVITIES AND DEPOSIT CONDUCTIVITIES

Press: P key to by-pass this chapter
R key to save file and exit 2DINPT
Return to proceed through this chapter

--- Specification of Surface Zone Emissivities ---

Press: P key to by-pass this subsection
Return to proceed through

Emissivity EW(*,*) for various furnace wall sections :
-- Default values are EW(*,*)=0.7, except at outlets,
where EW(*,*)=1.0

Press: D key for default values
C key to prescribe a constant value for all zones
Press: Return to prescribe zonal values, or to continue
without change

Surface emissivities EW(*,1) :
1.0000 0.7000 0.7000 0.7000

Press: C key to change the values
Return to continue

Surface emissivities EW(*,3) :
1.0000 1.0000 0.7000 0.7000

Press: C key to change the values
Return to continue

Surface emissivities EW(*,2) :
0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000
0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000
0.0000 0.0000

Press: C key to change the values
Return to continue

Surface emissivities EW(*,4) :
0.7000 0.7000 0.7000 0.7000 0.7000 0.7000 0.7000 0.7000 0.7000 0.7000
0.7000 0.7000 0.7000 0.7000 0.7000 0.7000 0.7000 0.7000 0.7000 0.7000
0.7000 0.7000

Press: C key to change the values
Return to continue

Press: C key to check surface-zone EW(*,*) values one more time
Return to continue without checking

--- Specification of Surface Emissivity for Outlet Zones ---

Press: P key to by-pass this subsection
Return to proceed through

Emissivities at outlet
J= 1, I=22 : EW(*,*)= 1.0000

Press: C key to change the values
Return to continue

Emissivities at outlet
J= 2, I=22 : EW(*,*)= 1.0000

Press: C key to change the values
Return to continue

Press: C key to check outlet-zone EW(*,*) values one more time
Return to continue without checking

--- Specification of Deposit Conductivity/Thickness Ratios ---

Press: P key to by-pass this subsection
Return to proceed through

Deposit thermal-conductivity/thickness ratios
CS(*,*) for surface zones in kw/m**2 K
-- Default values for non-outlet zones are: 0.4, 0.6 and 1.0
for coal, oil and gas fired furnaces, respectively
-- Default values for outlet zones are 0.0

Press: D key for default values
C key to prescribe a constant value for all zones

Press: Return to prescribe zonal values, or to continue
without change

Deposit thermal conductivity to thickness ratios

CS(*,1) in kw/m**2 K :

0.0000 0.2900 0.2600 0.2000

Press: C key to change the values
Return to continue

Deposit thermal conductivity to thickness ratios

CS(*,3) in kw/m**2 K :

0.0000 0.0000 0.1900 0.1900

Press: C key to change the values
Return to continue

Deposit thermal conductivity to thickness ratios

CS(*,2) in kw/m**2 K :

0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000
0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000
0.0000 0.0000

Press: C key to change the values
Return to continue

Deposit thermal conductivity to thickness ratios

CS(*,4) in kw/m**2 K :

0.2900 0.2600 0.2000 0.1700 0.2000 0.2200 0.1700 0.1400 0.1500 0.1600
0.1700 0.1800 0.1900 0.2000 0.2200 0.2400 0.2700 0.3000 0.3600 0.3600
0.3600 0.3600

Press: C key to change the values
Return to continue

Press: C key to check surface-zone CS(*,*) values one more time
Return to continue without checking

--- Specification of Deposit Conductivity/Thickness Ratios for Outlet Zones ---

Press: P key to by-pass this subsection
Return to proceed through

Deposit thermal conductivity/thickness ratios

for furnace outlet surfaces

-- Default is CS(*,*)= 0.0 (recommended)

Press: D key for default values
C key to change the values
Return to continue

NOTE:

- Your new or updated input file was saved as file 2dinpt.dat
- To update 2dinpt.dat further, you have to copy file 2dinpt.dat
to file INPUT.DAT under DOS, then rerun 2DINPT
- If you want to save the original contents of file
INPUT.DAT, make sure you save it under a different name

APPENDIX B. SAMPLE OUTPUT FROM THE FURNACE CODE

NUMBER OF MEMORY STORAGE REQUIRED FOR UNLABELLED COMMON BLOCK A : 5747 (DECIMAL)

* GENERAL INFORMATION *

BOILER NAME: HENNEPIN
CASE NUMBER: 03
VERSION NUMBER: 01
THERMAL LOAD: 100. % OF FULL LOAD

* INPUT/OUTPUT *

NREAD: 0
NWRITE: 1

NAME OF INPUT DATA FILE: 2dinpt.dat
NAME OF INPUT ARRAY FILE: IARR0301
NAME OF OUTPUT ARRAY FILE: OARR0301
NAME OF GRAPHICS OUTPUT FILE: GRFO
HARDCOPY OUTPUT DATA FILE: hdot0301
OUTPUT LEVEL: 4

* USER'S COMMENTS *

o
o CASE 1: Baseline, Hennepin
o 100% LOAD (75 MWe Gross)
o
o Test case for v 1.68
o OIL FIRING
o START FROM SCRATCH
o
o
o

 * SUMMARY OF INPUT PARAMETERS *

FUEL TYPE: LIQUID
 TOTAL FUEL FLOW: 5.2012 KG WET/S
 TOTAL AIR FLOW: 74.4057 KG WET/S
 EXCESS AIR: 7.2232 %
 O2-CONTENT OF FLUE GAS: 1.5211 VOL. % DRY
 SEC. AIR TEMPERATURE: 545.4700 K
 PRIM. MIXTURE TEMPERATURE: 311.0000 K
 AMOUNT OF PRIM. AIR: IN % OF STOICH. AIR: 20.0000 %
 ATOMISING STEAM FLOW: 0.0500 KG STEAM/KG FUEL DRY

FUEL PROPERTY -

PROXIMATE: CPIX 0.1200 KG/KG WET
 VOL 0.8592 KG/KG WET
 MOI 0.0200 KG/KG WET
 ASH 0.0008 KG/KG WET
 ULTIMATE: C 0.8570 KG/KG DRY
 H 0.1050 KG/KG DRY
 N 0.0046 KG/KG DRY
 O 0.0046 KG/KG DRY
 S 0.0280 KG/KG DRY
 ASH 0.0008 KG/KG DRY

UPPER HEATING VALUE: 42630.0000 KJ/KG WET
 LOWER HEATING VALUE: 41208.8516 KJ/KG DRY

REBURNING -

REBURN OR COFIRING: NO
 FUEL TYPE: GAS
 FUEL FLOW: 0.0000 KG DRY/S
 FGR FLOW: 0.0000 KG/S
 FUEL TEMPERATURE: 310.9300 K
 FGR TEMPERATURE: 555.3700 K

SORBENT -

SORBENT INJECTION: NO
 SORBENT TYPE: HYDRATE
 CA/S MOLAR RATIO: 0.0000
 SORBENT FLOW: 0.0000 KG/S
 TRANSPORT AIR FLOW: 0.0000 KG WET/S
 MIXTURE TEMPERATURE: 0.0000 K
 OPTIMUM INJECTION TEMPERATURE 0.0000 K

ASH RADIATION -

CLOUD SPECIFIC ABSORPTION COEFFICIENT: 13.6364 1/((KG/M**3)M)
 CLOUD SPECIFIC SURFACE AREA: 545.4500 M**2/KG
 SCATTERING: NO
 ABSORPTION EFFICIENCY: 0.1000
 SCATTERING EFFICIENCY: 0.0000

NUMERICAL PARAMETERS -

NMAX: 2
 NPHI: 4
 EXACT: 0.00010
 NO. OF ITERATIONS: 100
 NO. OF AVERAGED ITERATIONS: 30
 WEIGHTING FACTOR FOR HEAT FLUXES OF A PREVIOUS RUN: 0

STOICHIOMETRIC CALCULATIONS AT COMPLETE COMBUSTION

NAME OF VARIABLE	MEANING OF VARIABLE	VALUE	UNITS
O2MIN	STOICHIOMETRIC O2	3.1398	KG O2/KG FUEL DRY
AIRMIN	STOICHIOMETRIC AIR	13.4803	KG AIR DRY/KG FUEL DRY
AIRNR	TOTAL AIR NUMBER	1.0722	
H2OPOT	HUMIDITY OF FUEL	0.0204	KG H2O/KG FUEL DRY
H2OA2	HUMIDITY OF AIR	0.0099	KG H2O/KG AIR DRY
FUTOT	FLOW RATE OF DRY FUEL	5.0972	KG FUEL DRY/S
DMA	FLOW RATE OF DRY AIR	73.6746	KG AIR DRY/S
DMH2O	FLOW RATE OF H2O	1.0900	KG H2O /S
DNTOT	TOTAL INPUT MASS FLOW RATE	79.8618	KG /S
HL	TOT.NET CAL. VALUE OF DRY FUEL	41208.8516	KJ/KG FUEL DRY
O2MINV	STOICHIOMETRIC O2 FOR VOLATILE FUELS	2.8033	KG O2/KG FUEL DRY
AIRMINV	STOICHIOMETRIC AIR FOR VOLATILE FUELS	12.0358	KG AIR DRY/KG FUEL DRY
FUS	MASS FLOW RATE OF BURNER FUEL	5.0972	KG FUEL DRY/S
FUSW	MASS FLOW RATE OF BURNER FUEL	5.2012	KG FUEL WET/S
FUG	MASS FLOW RATE OF REBURN FUEL	0.0000	KG FUEL DRY/S
FUGW	MASS FLOW RATE OF REBURN FUEL	0.0000	KG FUEL WET/S
FUGV	VOLUME FLOW RATE OF REBURN FUEL	0.0000	M3N GAS DRY/S
FUGVW	VOLUME FLOW RATE OF REBURN FUEL	0.0000	M3N GAS WET/S
DMA2	MASS FLOW RATE OF TOTAL OR SEC. AIR	73.6746	KG AIR DRY/S
DMA2W	MASS FLOW RATE OF TOTAL OR SEC. AIR	74.4057	KG AIR WET/S
DMA2V	VOLUME FLOW RATE OF TOTAL OR SEC. AIR	0.0000	M3N AIR DRY/S
DMA2VW	VOLUME FLOW RATE OF TOTAL OR SEC. AIR	0.0000	M3N AIR WET/S
DMCG	VOLUME FLOW RATE OF COMBUSTION GASES	58.5110	M3N GAS DRY/S
DMCGW	VOLUME FLOW RATE OF COMBUSTION GASES	66.3822	M3N GAS WET/S
HL8	NET CAL. VALUE OF BURNER FUEL	41208.8516	KJ/KG FUEL DRY
HUBW	GROSS CAL. VALUE OF BURNER FUEL	42630.0000	KJ/KG FUEL WET
HLG	NET CAL. VALUE OF REBURN FUEL	1.0000	KJ/KG REBURN-FUEL DRY
HUGW	GROSS CAL. VALUE OF REBURN FUEL	0.0000	KJ/KG REBURN-FUEL WET

HLGV	NET CAL. VALUE OF RETURN FUEL	0.0000	KJ/M3N GAS DRY
HUGVM	GROSS CAL. VALUE OF RETURN FUEL	0.0000	KJ/M3N GAS WET
SPLOWF	ATOMIZING STEAM IN BURNER FUEL	0.2549	KG-STEAM/SEC

MASS CONCENTRATION OF GASEOUS SPECIES IN KG/KG WET									
CO2	H2O	N2	O2	VOL	SO2	ASH	CHAR	SOOT	
0.2004	0.0735	0.7079	0.0148	0.0000	0.0036	0.0001	0.0000	0.0000	
CONCENTRATION OF GASEOUS SPECIES IN VOL. FRACTION WET									
CO2	H2O	N2	O2	VOL	SO2				
0.1323	0.1186	0.7341	0.0134	0.0000	0.0016				
CONCENTRATION OF GASEOUS SPECIES IN VOL. FRACTION DRY									
CO2	H2O	N2	O2	VOL	SO2				
0.1501	0.0000	0.8329	0.0151	0.0000	0.0018				
SO2 CONCENTRATION IN PPM MASS					3571.				
SO2 CONCENTRATION IN PPM VOL WET					1619.				
SO2 CONCENTRATION IN PPM VOL DRY					1837.				

HEAT CAPACITY OF COMBUSTION SPECIES (KJ/KG-K)									
	CO2	H2O	N2	O2	VOL	SO2	ASH	CHAR	SOOT
AT 545.47K	0.9520193	1.9157062	1.0478872	0.9492909	2.6162302	0.6881223	0.8373600	1.1109865	1.0334244
AT 311.00K	0.8510554	1.8649184	1.0395800	0.9186417	2.2336755	0.6261053	0.8373600	0.9290423	0.7299049
AT 310.93K	0.8510472	1.8649468	1.0395799	0.9186344	2.2335899	0.6260983	0.8373599	0.9289843	0.7290025
AT 1800.00K	1.2005430	2.3140147	1.1634477	1.0747626	4.3484931	0.8270922	0.8373600	1.6863927	1.5045161
AT 900.00K	1.0583812	2.0220244	1.0806181	0.9992388	3.2324150	0.7527937	0.8373600	1.3415941	1.3412676

MEAN HEAT CAPACITIES OF SOME INPUT/OUTPUT STREAMS		
INPUT STREAM	TEMPERATURE (K)	MEAN Cp (KJ/KG-K)
AIR	311.00	1.0197977
AIR	545.47	1.0336750
FLUE GAS	900.00	1.1429865
FLUE GAS	1800.00	1.2529379

MASS BALANCE FOR VOLUME ZONES

NR	I	J	MCONIN KG/S	MCONNT KG/S	MDIFIN KG/S	MDFNT KG/S	MTOTIN KG/S	MTOTEX KG/S	MTOTNT KG/S
1	1	1	3.993	0.000	9.249	0.000	13.242	13.242	0.000
1	1	2	3.993	0.000	9.248	0.000	13.241	13.241	0.000
2	1	2	15.972	0.000	9.444	0.000	25.417	25.417	0.000
2	2	2	15.972	0.000	12.101	0.000	28.073	28.073	0.000
2	3	3	12.267	0.000	6.920	0.000	19.187	19.187	0.000
3	1	1	19.566	0.000	11.883	0.000	31.449	31.449	0.000
3	2	2	15.685	0.000	16.196	0.000	31.881	31.881	0.000
3	3	3	27.952	0.000	20.351	0.000	48.303	48.303	0.000
3	4	4	13.976	0.000	10.657	0.000	24.633	24.633	0.000
4	1	1	19.566	0.000	11.883	0.000	31.449	31.449	0.000
4	2	2	17.969	0.000	16.653	0.000	34.622	34.622	0.000
4	3	3	21.962	0.000	19.153	0.000	41.115	41.115	0.000
4	4	4	17.969	0.000	13.265	0.000	31.234	31.234	0.000
5	1	1	19.263	0.000	18.007	0.000	37.270	37.270	0.000
5	2	2	20.556	0.000	36.312	0.000	56.868	56.868	0.000
5	3	3	20.556	0.000	44.565	0.000	65.122	65.122	0.000
5	4	4	32.578	0.000	26.281	0.000	58.836	58.836	0.000
6	1	1	20.548	0.000	18.264	0.000	38.813	38.813	0.000
6	2	2	21.834	0.000	36.567	0.000	58.402	58.402	0.000
6	3	3	14.591	0.000	50.560	0.000	65.151	65.151	0.000
6	4	4	26.610	0.000	32.265	0.000	58.874	58.874	0.000
7	1	1	41.057	0.000	19.884	0.000	60.941	60.941	0.000
7	2	2	52.932	0.008	36.338	0.000	89.271	89.279	0.008
7	3	3	39.532	0.008	39.553	0.000	79.084	79.076	-0.008
7	4	4	33.462	0.000	25.470	0.000	58.932	58.932	0.000
8	1	1	41.057	0.000	16.867	0.000	57.924	57.924	0.000
8	2	2	42.766	0.000	23.268	0.000	66.034	66.034	0.000
8	3	3	23.024	0.000	21.489	0.000	44.513	44.513	0.000
8	4	4	10.302	0.008	16.758	0.000	27.060	27.068	0.008
9	1	1	30.723	0.000	12.735	0.000	43.458	43.458	0.000
9	2	2	26.881	0.000	15.106	0.000	41.988	41.988	0.000
9	3	3	12.722	0.000	13.036	0.000	25.758	25.758	0.000
9	4	4	9.543	0.000	9.261	0.000	18.805	18.805	0.000
10	1	1	30.723	0.000	14.867	0.000	45.590	45.590	0.000
10	2	2	26.881	0.000	20.251	0.000	47.133	47.133	0.000
10	3	3	12.722	0.000	19.634	0.000	32.356	32.356	0.000
10	4	4	9.543	0.000	12.845	0.000	22.389	22.389	0.000
11	1	1	30.723	0.000	12.286	0.000	43.008	43.008	0.000
11	2	2	26.881	0.000	14.020	0.000	40.902	40.902	0.000
11	3	3	12.722	0.000	11.643	0.000	24.365	24.365	0.000
11	4	4	9.543	0.000	8.505	0.000	18.048	18.048	0.000
12	1	1	30.723	0.000	14.896	0.000	45.619	45.619	0.000
12	2	2	26.881	0.000	20.323	0.000	47.204	47.204	0.000
12	3	3	12.722	0.000	19.726	0.000	32.448	32.448	0.000
12	4	4	9.543	0.000	12.895	0.000	22.438	22.438	0.000
13	1	1	57.045	0.000	20.161	0.000	77.206	77.206	0.000
13	2	2	49.139	0.000	24.774	0.000	73.913	73.913	0.000
13	3	3	22.265	-0.008	19.824	0.000	42.089	42.081	-0.008
13	4	4	9.543	0.000	11.085	0.000	20.629	20.629	0.000
14	1	1	57.045	0.000	22.450	0.000	79.495	79.495	0.000
14	2	2	30.715	0.000	17.183	0.000	47.898	47.898	0.000
15	1	1	49.147	0.000	17.513	0.000	66.660	66.660	0.000
15	2	2	30.715	0.000	13.826	0.000	44.541	44.541	0.000
16	1	1	49.147	0.000	20.306	0.000	69.453	69.453	0.000
16	2	2	30.715	0.000	16.619	0.000	47.334	47.334	0.000
17	1	1	49.147	0.000	20.306	0.000	69.453	69.453	0.000
17	2	2	30.715	0.000	16.619	0.000	47.334	47.334	0.000
18	1	1	49.147	0.000	16.755	0.000	65.902	65.902	0.000
18	2	2	30.715	0.000	13.990	0.000	44.705	44.705	0.000
19	1	1	49.147	0.000	7.098	0.000	56.245	56.245	0.000
19	2	2	30.715	0.000	5.255	0.000	35.969	35.969	0.000
20	1	1	49.147	0.000	6.791	0.000	55.938	55.938	0.000
20	2	2	36.856	0.000	5.562	0.000	42.418	42.418	0.000
21	1	1	43.006	0.000	6.484	0.000	49.489	49.489	0.000

21 2	36.856	0.000	5.869	0.000	42.725	42.725	0.000
22 1	43.006	0.000	3.242	0.000	46.247	46.247	0.000
22 2	39.931	0.000	2.934	0.000	42.865	42.865	0.000

TOTAL MASS BALANCE FOR THE FURNACE VOLUME
INCLUDING SYMMETRICAL FLUXES IF EXISTING:

1860.85	0.00	1156.11	0.00	3016.96	3016.96	0.00
---------	------	---------	------	---------	---------	------

iter. no. = 1,	act.err. = 30.7087 %	avg.err. = 30.7087 %	20 it.err. = 30.7087 %	hb.err. = -3.5340 %
iter. no. = 2,	act.err. = -28.6355 %	avg.err. = 1.0366 %	20 it.err. = 1.0366 %	hb.err. = -21.3885 %
iter. no. = 3,	act.err. = 1.3259 %	avg.err. = 1.1330 %	20 it.err. = 1.1330 %	hb.err. = -9.0280 %
iter. no. = 4,	act.err. = 14.3574 %	avg.err. = 4.4391 %	20 it.err. = 4.4391 %	hb.err. = -7.5975 %
iter. no. = 5,	act.err. = 10.7956 %	avg.err. = 5.7104 %	20 it.err. = 5.7104 %	hb.err. = -4.5236 %
iter. no. = 6,	act.err. = 13.4845 %	avg.err. = 7.0061 %	20 it.err. = 7.0061 %	hb.err. = -6.6219 %
iter. no. = 7,	act.err. = 14.6697 %	avg.err. = 8.0723 %	20 it.err. = 8.0723 %	hb.err. = -5.6072 %
iter. no. = 8,	act.err. = 13.3466 %	avg.err. = 8.7316 %	20 it.err. = 8.7316 %	hb.err. = -4.1947 %
iter. no. = 9,	act.err. = 12.8740 %	avg.err. = 9.1919 %	20 it.err. = 9.1919 %	hb.err. = -4.6821 %
iter. no. = 10,	act.err. = 12.9377 %	avg.err. = 9.5664 %	20 it.err. = 9.5664 %	hb.err. = -4.3663 %
iter. no. = 11,	act.err. = 30.811 %	avg.err. = 9.6876 %	20 it.err. = 9.6876 %	hb.err. = -4.5343 %
iter. no. = 12,	act.err. = 11.0075 %	avg.err. = 9.8776 %	20 it.err. = 9.8776 %	hb.err. = -3.2829 %
iter. no. = 13,	act.err. = 12.077 %	avg.err. = 10.0491 %	20 it.err. = 10.0491 %	hb.err. = -4.9337 %
iter. no. = 14,	act.err. = 12.0747 %	avg.err. = 10.1890 %	20 it.err. = 10.1890 %	hb.err. = -4.2360 %
iter. no. = 15,	act.err. = 11.1485 %	avg.err. = 10.2509 %	20 it.err. = 10.2509 %	hb.err. = -3.3280 %
iter. no. = 16,	act.err. = 10.4606 %	avg.err. = 10.2640 %	20 it.err. = 10.2640 %	hb.err. = -3.1349 %
iter. no. = 17,	act.err. = 8.9235 %	avg.err. = 10.1852 %	20 it.err. = 10.1852 %	hb.err. = -3.7648 %
iter. no. = 18,	act.err. = 10.4406 %	avg.err. = 10.1994 %	20 it.err. = 10.1994 %	hb.err. = -3.7516 %
iter. no. = 19,	act.err. = 8.6696 %	avg.err. = 10.1189 %	20 it.err. = 10.1189 %	hb.err. = -3.3018 %
iter. no. = 20,	act.err. = 7.3065 %	avg.err. = 9.9783 %	20 it.err. = 9.9783 %	hb.err. = -3.8721 %
iter. no. = 21,	act.err. = 8.9389 %	avg.err. = 9.9288 %	20 it.err. = 9.9288 %	hb.err. = -3.2144 %
iter. no. = 22,	act.err. = 7.7010 %	avg.err. = 9.8275 %	20 it.err. = 10.7066 %	hb.err. = -3.3807 %
iter. no. = 23,	act.err. = 7.7492 %	avg.err. = 9.7371 %	20 it.err. = 11.0277 %	hb.err. = -2.4211 %
iter. no. = 24,	act.err. = 8.0382 %	avg.err. = 9.6663 %	20 it.err. = 10.7116 %	hb.err. = -2.6408 %
iter. no. = 25,	act.err. = 6.1171 %	avg.err. = 9.5244 %	20 it.err. = 10.4779 %	hb.err. = -3.2929 %
iter. no. = 26,	act.err. = 8.9094 %	avg.err. = 9.5007 %	20 it.err. = 10.2491 %	hb.err. = -1.9120 %
iter. no. = 27,	act.err. = 6.1671 %	avg.err. = 9.3773 %	20 it.err. = 9.8340 %	hb.err. = -1.5930 %
iter. no. = 28,	act.err. = 4.6400 %	avg.err. = 9.2081 %	20 it.err. = 9.3986 %	hb.err. = -2.4405 %
iter. no. = 29,	act.err. = 4.8037 %	avg.err. = 8.9562 %	20 it.err. = 8.9951 %	hb.err. = -2.3259 %
iter. no. = 30,	act.err. = 5.3552 %	avg.err. = 8.9328 %	20 it.err. = 8.6160 %	hb.err. = -1.4328 %
iter. no. = 31,	act.err. = 2.8069 %	avg.err. = 8.7352 %	20 it.err. = 8.2114 %	hb.err. = -1.0209 %
iter. no. = 32,	act.err. = 2.0238 %	avg.err. = 8.5255 %	20 it.err. = 7.7142 %	hb.err. = -2.1536 %
iter. no. = 33,	act.err. = 4.5334 %	avg.err. = 8.4045 %	20 it.err. = 7.3355 %	hb.err. = -0.5594 %
iter. no. = 34,	act.err. = 3.2956 %	avg.err. = 8.2542 %	20 it.err. = 6.8999 %	hb.err. = -0.9823 %
iter. no. = 35,	act.err. = 2.4564 %	avg.err. = 8.0886 %	20 it.err. = 6.4668 %	hb.err. = -1.6950 %
iter. no. = 36,	act.err. = 2.9937 %	avg.err. = 7.9471 %	20 it.err. = 6.0935 %	hb.err. = -0.3730 %
iter. no. = 37,	act.err. = 3.0692 %	avg.err. = 7.8152 %	20 it.err. = 5.8008 %	hb.err. = -1.5352 %
iter. no. = 38,	act.err. = 4.2575 %	avg.err. = 7.7216 %	20 it.err. = 5.4916 %	hb.err. = 0.2027 %
iter. no. = 39,	act.err. = 0.1215 %	avg.err. = 7.5267 %	20 it.err. = 5.0642 %	hb.err. = -1.2184 %
iter. no. = 40,	act.err. = 1.5572 %	avg.err. = 7.3775 %	20 it.err. = 4.7767 %	hb.err. = -1.1149 %
iter. no. = 41,	act.err. = 0.9252 %	avg.err. = 7.2201 %	20 it.err. = 4.3761 %	hb.err. = -1.1309 %
iter. no. = 42,	act.err. = 2.9669 %	avg.err. = 7.1189 %	20 it.err. = 4.1393 %	hb.err. = -0.3190 %
iter. no. = 43,	act.err. = 2.9337 %	avg.err. = 7.0215 %	20 it.err. = 3.8986 %	hb.err. = 0.7059 %
iter. no. = 44,	act.err. = -0.2454 %	avg.err. = 6.8564 %	20 it.err. = 3.4844 %	hb.err. = -2.7441 %
iter. no. = 45,	act.err. = 1.1482 %	avg.err. = 6.7295 %	20 it.err. = 3.2360 %	hb.err. = -0.8981 %
iter. no. = 46,	act.err. = 2.8306 %	avg.err. = 6.6448 %	20 it.err. = 2.9320 %	hb.err. = 0.0968 %
iter. no. = 47,	act.err. = 2.6879 %	avg.err. = 6.5606 %	20 it.err. = 2.7581 %	hb.err. = 1.0846 %
iter. no. = 48,	act.err. = 1.7335 %	avg.err. = 6.4600 %	20 it.err. = 2.6127 %	hb.err. = -1.4110 %
iter. no. = 49,	act.err. = 2.4396 %	avg.err. = 6.3780 %	20 it.err. = 2.4945 %	hb.err. = -0.5651 %
iter. no. = 50,	act.err. = 1.3711 %	avg.err. = 6.2778 %	20 it.err. = 2.2953 %	hb.err. = 0.2674 %
iter. no. = 51,	act.err. = 0.1824 %	avg.err. = 6.1583 %	20 it.err. = 2.1641 %	hb.err. = -0.7786 %
iter. no. = 52,	act.err. = -0.4725 %	avg.err. = 6.0308 %	20 it.err. = 2.0393 %	hb.err. = -0.1133 %
iter. no. = 53,	act.err. = -0.6978 %	avg.err. = 5.9038 %	20 it.err. = 1.7777 %	hb.err. = -0.8328 %
iter. no. = 54,	act.err. = 1.9641 %	avg.err. = 5.8309 %	20 it.err. = 1.7111 %	hb.err. = -0.9067 %
iter. no. = 55,	act.err. = 0.0882 %	avg.err. = 5.7265 %	20 it.err. = 1.5927 %	hb.err. = -0.0364 %
iter. no. = 56,	act.err. = 1.1843 %	avg.err. = 5.6453 %	20 it.err. = 1.5023 %	hb.err. = -0.1620 %
iter. no. = 57,	act.err. = 1.0784 %	avg.err. = 5.5652 %	20 it.err. = 1.4027 %	hb.err. = 0.8263 %
iter. no. = 58,	act.err. = -1.3955 %	avg.err. = 5.4452 %	20 it.err. = 1.1201 %	hb.err. = -1.0166 %
iter. no. = 59,	act.err. = 0.7725 %	avg.err. = 5.3660 %	20 it.err. = 1.1526 %	hb.err. = -0.7083 %
iter. no. = 60,	act.err. = 1.2014 %	avg.err. = 5.2966 %	20 it.err. = 1.1348 %	hb.err. = 0.0931 %
iter. no. = 61,	act.err. = 2.3690 %	avg.err. = 5.2486 %	20 it.err. = 1.2070 %	hb.err. = 1.0045 %
iter. no. = 62,	act.err. = 0.4177 %	avg.err. = 5.1707 %	20 it.err. = 1.0796 %	hb.err. = -0.0494 %
iter. no. = 63,	act.err. = -0.3856 %	avg.err. = 5.0825 %	20 it.err. = 0.9136 %	hb.err. = -0.3297 %
iter. no. = 64,	act.err. = 0.8458 %	avg.err. = 5.0163 %	20 it.err. = 0.9682 %	hb.err. = 0.8304 %
iter. no. = 65,	act.err. = -1.0239 %	avg.err. = 4.9234 %	20 it.err. = 0.8595 %	hb.err. = -1.0352 %
iter. no. = 66,	act.err. = 0.3635 %	avg.err. = 4.8543 %	20 it.err. = 0.7362 %	hb.err. = 0.3228 %
iter. no. = 67,	act.err. = 1.0430 %	avg.err. = 4.7974 %	20 it.err. = 0.6539 %	hb.err. = 0.7049 %
iter. no. = 68,	act.err. = 0.3762 %	avg.err. = 4.7324 %	20 it.err. = 0.5861 %	hb.err. = 0.8323 %
iter. no. = 69,	act.err. = -2.2505 %	avg.err. = 4.6312 %	20 it.err. = 0.3516 %	hb.err. = -0.6480 %
iter. no. = 70,	act.err. = 0.3108 %	avg.err. = 4.5695 %	20 it.err. = 0.2986 %	hb.err. = -0.5429 %
iter. no. = 71,	act.err. = 0.6566 %	avg.err. = 4.5143 %	20 it.err. = 0.3223 %	hb.err. = 1.0629 %
iter. no. = 72,	act.err. = -1.3677 %	avg.err. = 4.4327 %	20 it.err. = 0.2775 %	hb.err. = -0.2726 %
iter. no. = 73,	act.err. = -1.6276 %	avg.err. = 4.3496 %	20 it.err. = 0.2310 %	hb.err. = -0.6135 %
iter. no. = 74,	act.err. = -1.0971 %	avg.err. = 4.2760 %	20 it.err. = 0.0779 %	hb.err. = -0.3945 %
iter. no. = 75,	act.err. = -0.4182 %	avg.err. = 4.2134 %	20 it.err. = 0.0526 %	hb.err. = -0.0312 %
iter. no. = 76,	act.err. = -0.0922 %	avg.err. = 4.1568 %	20 it.err. = -0.0112 %	hb.err. = 0.1047 %
iter. no. = 77,	act.err. = -0.2663 %	avg.err. = 4.0993 %	20 it.err. = -0.0784 %	hb.err. = -0.0870 %
iter. no. = 78,	act.err. = -0.3712 %	avg.err. = 4.0420 %	20 it.err. = -0.0272 %	hb.err. = -0.2364 %
iter. no. = 79,	act.err. = 0.0335 %	avg.err. = 3.9913 %	20 it.err. = -0.0642 %	hb.err. = -0.1389 %
iter. no. = 80,	act.err. = 0.4439 %	avg.err. = 3.9469 %	20 it.err. = -0.1020 %	hb.err. = 0.1481 %
iter. no. = 81,	act.err. = 0.0666 %	avg.err. = 3.8990 %	20 it.err. = -0.2172 %	hb.err. = -0.0743 %
iter. no. = 82,	act.err. = 0.2092 %	avg.err. = 3.8540 %	20 it.err. = -0.2276 %	hb.err. = 0.0046 %
iter. no. = 83,	act.err. = 0.4851 %	avg.err. = 3.8135 %	20 it.err. = -0.1840 %	hb.err. = 0.2525 %
iter. no. = 84,	act.err. = 0.3074 %	avg.err. = 3.7717 %	20 it.err. = -0.2110 %	hb.err. = 0.1307 %
iter. no. = 85,	act.err. = 0.1844 %	avg.err. = 3.7295 %	20 it.err. = -0.1505 %	hb.err. = 0.0723 %
iter. no. = 86,	act.err. = 0.2990 %	avg.err. = 3.6896 %	20 it.err. = -0.1538 %	hb.err. = 0.1166 %
iter. no. = 87,	act.err. = 0.1155 %	avg.err. = 3.6485 %	20 it.err. = -0.2001 %	hb.err. = 0.0115 %
iter. no. = 88,	act.err. = 0.3147 %	avg.err. = 3.6107 %	20 it.err. = -0.2032 %	hb.err. = 0.1089 %
iter. no. = 89,	act.err. = 0.0682 %	avg.err. = 3.5708 %	20 it.err. = -0.0873 %	hb.err. = -0.0290 %
iter. no. = 90,	act.err. = -0.0142 %	avg.err. = 3.5310 %	20 it.err. = -0.1035 %	hb.err. = -0.0975 %
iter. no. = 91,	act.err. = -0.1162 %	avg.err. = 3.4909 %	20 it.err. = -0.1422 %	hb.err. = -0.1441 %
iter. no. = 92,	act.err. = 0.3606 %	avg.err. = 3.4569 %	20 it.err. = -0.0558 %	hb.err. = 0.1909 %
iter. no. = 93,	act.err. = -0.1575 %	avg.err. = 3.4180 %	20 it.err. = 0.0178 %	hb.err. = -0.1799 %
iter. no. = 94,	act.err. = 0.1091 %	avg.err. = 3.3828 %	20 it.err. = 0.0781 %	hb.err. = 0.0098 %
iter. no. = 95,	act.err. = -0.3256 %	avg.err. = 3.3438 %	20 it.err. = 0.0827 %	hb.err. = -0.2841 %
iter. no. = 96,	act.err. = 0.1092 %	avg.err. = 3.3101 %	20 it.err. = 0.0928 %	hb.err. = 0.0038 %
iter. no. = 97,	act.err. = -0.0759 %	avg.err. = 3.2752 %	20 it.err. = 0.1023 %	hb.err. = -0.0819 %
iter. no. = 98,	act.err. = -0.3156 %	avg.err. = 3.2386 %	20 it.err. = 0.1051 %	hb.err. = -0.2680 %

iter. no.= 99, act.err.= -0.3546 %, avg.err.= 3.2023 %, 20 it.err.= 0.0857 %, hb.err.= -0.3414 %

THE DISTRIBUTION OF SPSU in m**2/kg AFTER 100 ITERATIONS

J= 4	0.000E-01	0.000E-01	3.311E+02	2.835E+02	2.347E+02	2.325E+02	2.360E+02	3.595E+02	4.079E+02	4.651E+02
J= 3	0.000E-01	3.657E+02	3.482E+02	3.135E+02	2.710E+02	2.653E+02	2.579E+02	3.578E+02	4.000E+02	4.509E+02
J= 2	3.966E+02	3.796E+02	3.786E+02	3.732E+02	3.363E+02	3.209E+02	2.941E+02	3.517E+02	3.866E+02	4.330E+02
J= 1	4.005E+02	3.920E+02	3.998E+02	4.106E+02	4.013E+02	3.842E+02	3.484E+02	3.824E+02	4.062E+02	4.394E+02
	I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	I=10
J= 4	4.851E+02	5.105E+02	5.193E+02	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 3	4.704E+02	4.994E+02	5.136E+02	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 2	4.513E+02	4.819E+02	5.055E+02	5.172E+02	5.194E+02	5.230E+02	5.254E+02	5.266E+02	5.267E+02	5.267E+02
J= 1	4.523E+02	4.767E+02	4.966E+02	5.063E+02	5.106E+02	5.174E+02	5.220E+02	5.246E+02	5.251E+02	5.253E+02
	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	I=19	I=20
J= 4	0.000E-01	0.000E-01								
J= 3	0.000E-01	0.000E-01								
J= 2	5.267E+02	5.267E+02								
J= 1	5.254E+02	5.254E+02								
	I=21	I=22								

THE DISTRIBUTION OF UBRT in Fraction of Input fixed-C AFTER 100 ITERATIONS

J= 4	0.000E-01	0.000E-01	2.041E-01	3.933E-01	7.953E-01	8.219E-01	7.844E-01	1.675E-01	9.214E-02	4.389E-02
J= 3	0.000E-01	1.253E-01	1.636E-01	2.686E-01	4.828E-01	5.188E-01	5.742E-01	1.631E-01	9.474E-02	4.821E-02
J= 2	7.728E-02	1.015E-01	1.050E-01	1.269E-01	2.173E-01	2.567E-01	3.543E-01	1.701E-01	1.068E-01	5.703E-02
J= 1	7.088E-02	8.336E-02	7.390E-02	6.831E-02	9.839E-02	1.201E-01	1.818E-01	1.137E-01	7.957E-02	4.759E-02
	I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	I=10
J= 4	3.087E-02	1.907E-02	1.411E-02	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 3	3.476E-02	2.112E-02	1.511E-02	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 2	4.202E-02	2.578E-02	1.722E-02	1.215E-02	1.063E-02	9.112E-03	8.102E-03	7.497E-03	7.397E-03	7.313E-03
J= 1	3.691E-02	2.369E-02	1.694E-02	1.310E-02	1.132E-02	9.375E-03	8.099E-03	7.349E-03	7.130E-03	7.026E-03
	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	I=19	I=20
J= 4	0.000E-01	0.000E-01								
J= 3	0.000E-01	0.000E-01								
J= 2	7.309E-03	7.285E-03								
J= 1	6.993E-03	6.986E-03								
	I=21	I=22								

THE DISTRIBUTION OF PO2 in Vol. Fraction, Wet AFTER 100 ITERATIONS

J= 4	0.000E-01	0.000E-01	2.129E-02	5.349E-02	1.290E-01	1.339E-01	1.344E-01	3.026E-02	1.971E-02	1.542E-02
J= 3	0.000E-01	1.492E-02	2.069E-02	3.778E-02	7.141E-02	7.637E-02	9.066E-02	3.076E-02	2.020E-02	1.531E-02
J= 2	1.495E-02	1.573E-02	1.556E-02	1.816E-02	3.283E-02	3.945E-02	5.785E-02	3.232E-02	2.320E-02	1.670E-02
J= 1	1.468E-02	1.494E-02	1.450E-02	1.456E-02	1.822E-02	2.109E-02	3.243E-02	2.328E-02	1.906E-02	1.546E-02
	I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	I=10
J= 4	1.486E-02	1.439E-02	1.416E-02	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 3	1.452E-02	1.418E-02	1.398E-02	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 2	1.569E-02	1.462E-02	1.407E-02	1.383E-02	1.377E-02	1.369E-02	1.364E-02	1.361E-02	1.360E-02	1.357E-02
J= 1	1.454E-02	1.382E-02	1.376E-02	1.367E-02	1.362E-02	1.357E-02	1.353E-02	1.351E-02	1.350E-02	1.350E-02
	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	I=19	I=20
J= 4	0.000E-01	0.000E-01								
J= 3	0.000E-01	0.000E-01								
J= 2	1.357E-02	1.356E-02								
J= 1	1.349E-02	1.349E-02								
	I=21	I=22								

THE DISTRIBUTION OF VOLO in Number of Vol. Lumps Released AFTER 100 ITERATIONS

J= 4	0.000E-01	0.000E-01	0.000E-01	1.300E+01	3.306E+03	3.310E+03	3.309E+03	3.000E+00	0.000E-01	0.000E-01
J= 3	0.000E-01	0.000E-01	0.000E-01	0.000E-01	1.700E+01	1.600E+01	2.500E+01	0.000E-01	0.000E-01	0.000E-01
J= 2	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 1	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
	I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	I=10
J= 4	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 3	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 2	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 1	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	I=19	I=20
J= 4	0.000E-01	0.000E-01								
J= 3	0.000E-01	0.000E-01								
J= 2	0.000E-01	0.000E-01								
J= 1	0.000E-01	0.000E-01								
	I=21	I=22								

THE DISTRIBUTION OF SO2 in Vol. Fraction, Wet AFTER 100 ITERATIONS

J= 4	0.000E-01	0.000E-01	1.491E-03	1.189E-03	5.034E-04	4.586E-04	4.731E-04	1.447E-03	1.552E-03	1.602E-03
J= 3	0.000E-01	1.554E-03	1.512E-03	1.351E-03	1.027E-03	9.769E-04	8.578E-04	1.445E-03	1.546E-03	1.601E-03
J= 2	1.594E-03	1.572E-03	1.572E-03	1.546E-03	1.406E-03	1.344E-03	1.177E-03	1.431E-03	1.521E-03	1.588E-03
J= 1	1.595E-03	1.588E-03	1.595E-03	1.597E-03	1.558E-03	1.529E-03	1.425E-03	1.517E-03	1.560E-03	1.599E-03
I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	I= 10	
J= 4	1.612E-03	1.621E-03	1.626E-03	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 3	1.613E-03	1.622E-03	1.628E-03	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 2	1.601E-03	1.617E-03	1.627E-03	1.631E-03	1.632E-03	1.634E-03	1.635E-03	1.635E-03	1.636E-03	1.636E-03
J= 1	1.610E-03	1.622E-03	1.628E-03	1.631E-03	1.633E-03	1.634E-03	1.636E-03	1.636E-03	1.637E-03	1.637E-03
I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	I=19	I=20	
J= 4	0.000E-01	0.000E-01								
J= 3	0.000E-01	0.000E-01								
J= 2	1.636E-03	1.636E-03								
J= 1	1.637E-03	1.637E-03								

I=21 I=22
UNBURN FIXED CARBON AT FURNACE EXIT = 0.73% AFTER 100 ITERATIONS

O2 REMOVAL UP TO FURNACE EXIT = 0.10% AFTER 100 ITERATIONS

ATOM OUTFLOW IN KG/S :

C=	4.368280	H=	0.657173	N=	56.532013	O=	18.157495
S=	0.142725	A=	0.004078				
SUM=	79.861763						

ATOM INFLOW IN KG/S :

C=	4.368280	H=	0.657173	N=	56.537956	O=	18.151554
S=	0.142721	A=	0.004078				
SUM=	79.861763						

ATOM BALANCE --> (OUT-IN)/IN IN % :

C=	0.000000	H=	0.000000	N=	-0.010512	O=	0.032732
S=	0.002600	A=	0.000000				
SUM=	0.000000						

HEAT FLUX TO ADDITIONAL HEAT SINKS IN KW
CONVECTIVE FLUX RADIATIVE FLUX TOTAL FLUX
31723.5859 16421.1113 48144.6953

SURFACE TEMPERATURES OF ADDITIONAL HEAT SINKS IN K --- represented by TWSINK(I,J)

TWSINK(19, J) =	893.66	854.05
TWSINK(20, J) =	934.44	897.73
TWSINK(21, J) =	964.44	908.73
TWSINK(22, J) =	865.74	817.77

MEAN FURNACE EXIT TEMPERATURE = 1109.87K AFTER 100 ITERATIONS
TOTAL FURNACE EFFICIENCY = 66.2576 % WITH 209604. KW HEAT RELEASE AND 15825. KW SENSIBLE INPUT

CHEM. HEAT OUTFLOW IN KW :

FUEL=	151.0	SULF.=	0.0	SUM =	151.0	
SENS. HEAT OUTFLOW IN KW :						
EXT.=	76073.5	REC.=	0.0	SUM =	76073.5	
OUTFLOW TO HEAT SINKS IN KW :						
RAD.=	113729.5	CONV.=	35634.1	SUM =	149363.6	
TOTAL HEAT OUTFLOW :					225588.2 KW	
CHEM. HEAT INFLOW IN KW :						
FUEL=	210048.8	EVAP.=	-254.0	CALC.=	0.0	
SULF=	0.0			SUM =	209794.8	
SENS. HEAT AIR INFLOW IN KW :						
SEC.=	15473.6	PRIM.=	181.9	TRANS.=	0.0	
REC.=	0.0			SUM =	15655.5	
SENS. HEAT FUEL INFLOW IN KW :						
DRY =	72.0	H2O=	2.5	SUM =	74.5	
SENS. HEAT SORBENT INFLOW IN KW :						
CAO =	0.0	H2O=	0.0	CO2G =	0.0	
SENS. HEAT BURNER-STEAM INFLOW IN KW :				92.7	SUM =	0.0
TOTAL HEAT INFLOW :					225617.5 KW	
GAS ZONE HEAT BALANCE :						
HEAT BALANCE --> OUT - IN :				-29.3 KW		
HEAT BALANCE --> (OUT-IN)/IN :				-0.012978 %		

THE DISTRIBUTION OF T IN K AFTER 100 ITERATIONS

J= 4	0.000E-01	0.000E-01	1.854E+03	1.770E+03	1.294E+03	1.244E+03	1.243E+03	1.807E+03	1.836E+03	1.812E+03
J= 3	0.000E-01	1.773E+03	1.834E+03	1.806E+03	1.647E+03	1.638E+03	1.595E+03	1.844E+03	1.867E+03	1.839E+03
J= 2	1.470E+03	1.719E+03	1.816E+03	1.824E+03	1.774E+03	1.783E+03	1.761E+03	1.865E+03	1.893E+03	1.892E+03
J= 1	1.473E+03	1.655E+03	1.706E+03	1.733E+03	1.773E+03	1.812E+03	1.841E+03	1.886E+03	1.899E+03	1.895E+03
I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	I= 10	
J= 4	1.780E+03	1.716E+03	1.650E+03	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 3	1.811E+03	1.767E+03	1.699E+03	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 2	1.871E+03	1.823E+03	1.749E+03	1.693E+03	1.658E+03	1.601E+03	1.561E+03	1.513E+03	1.366E+03	1.279E+03
J= 1	1.885E+03	1.856E+03	1.791E+03	1.761E+03	1.735E+03	1.692E+03	1.656E+03	1.607E+03	1.498E+03	1.422E+03
I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	I=19	I=20	
J= 4	0.000E-01	0.000E-01								
J= 3	0.000E-01	0.000E-01								
J= 2	1.148E+03	1.051E+03								
J= 1	1.292E+03	1.168E+03								

I=21 I=22
I J CO2 H2O N2 O2 VOL SO2 ASH CHAR SOOT
- - KG/KG KG/KG KG/KG KG/KG KG/KG KG/KG KG/KG KG/KG KG/KG

1	1	0.1984	0.0735	0.7080	0.0160	0.0000	0.0035	0.0001	0.0006	0.0000
2	1	0.1980	0.0735	0.7081	0.0162	0.0000	0.0035	0.0001	0.0007	0.0000
3	1	0.1983	0.0735	0.7083	0.0158	0.0000	0.0035	0.0001	0.0006	0.0000
4	1	0.1983	0.0735	0.7083	0.0158	0.0000	0.0035	0.0001	0.0005	0.0000
5	1	0.1951	0.0727	0.7074	0.0198	0.0007	0.0034	0.0001	0.0008	0.0001
6	1	0.1917	0.0717	0.7076	0.0230	0.0014	0.0033	0.0001	0.0009	0.0003
7	1	0.1790	0.0679	0.7079	0.0354	0.0044	0.0031	0.0001	0.0014	0.0009
8	1	0.1891	0.0707	0.7079	0.0253	0.0022	0.0033	0.0001	0.0009	0.0004
9	1	0.1938	0.0720	0.7079	0.0207	0.0012	0.0034	0.0001	0.0006	0.0002
10	1	0.1978	0.0731	0.7080	0.0168	0.0003	0.0035	0.0001	0.0004	0.0001
11	1	0.1989	0.0734	0.7079	0.0158	0.0001	0.0035	0.0001	0.0003	0.0000
12	1	0.1997	0.0735	0.7079	0.0150	0.0000	0.0035	0.0001	0.0002	0.0000
13	1	0.1999	0.0735	0.7079	0.0150	0.0000	0.0035	0.0001	0.0001	0.0000
14	1	0.2000	0.0735	0.7079	0.0149	0.0000	0.0035	0.0001	0.0001	0.0000
15	1	0.2001	0.0735	0.7079	0.0148	0.0000	0.0036	0.0001	0.0001	0.0000
16	1	0.2002	0.0735	0.7079	0.0147	0.0000	0.0036	0.0001	0.0001	0.0000
17	1	0.2002	0.0735	0.7079	0.0147	0.0000	0.0036	0.0001	0.0001	0.0000
18	1	0.2002	0.0735	0.7079	0.0147	0.0000	0.0036	0.0001	0.0001	0.0000
19	1	0.2002	0.0735	0.7079	0.0147	0.0000	0.0036	0.0001	0.0001	0.0000
20	1	0.2002	0.0735	0.7079	0.0147	0.0000	0.0036	0.0001	0.0001	0.0000
21	1	0.2002	0.0735	0.7079	0.0147	0.0000	0.0036	0.0001	0.0001	0.0000
22	1	0.2002	0.0735	0.7079	0.0147	0.0000	0.0036	0.0001	0.0001	0.0000
1	2	0.1982	0.0735	0.7079	0.0162	0.0000	0.0035	0.0001	0.0006	0.0000
2	2	0.1973	0.0735	0.7078	0.0171	0.0001	0.0034	0.0001	0.0008	0.0000
3	2	0.1964	0.0732	0.7088	0.0169	0.0003	0.0034	0.0001	0.0008	0.0001
4	2	0.1939	0.0725	0.7085	0.0198	0.0008	0.0034	0.0001	0.0010	0.0002
5	2	0.1786	0.0681	0.7076	0.0358	0.0042	0.0031	0.0001	0.0017	0.0008
6	2	0.1708	0.0658	0.7081	0.0431	0.0060	0.0029	0.0001	0.0020	0.0012
7	2	0.1514	0.0600	0.7072	0.0634	0.0105	0.0026	0.0001	0.0028	0.0021
8	2	0.1799	0.0681	0.7071	0.0352	0.0042	0.0031	0.0001	0.0013	0.0009
9	2	0.1905	0.0712	0.7066	0.0253	0.0019	0.0033	0.0001	0.0008	0.0004
10	2	0.1976	0.0731	0.7068	0.0182	0.0003	0.0035	0.0001	0.0004	0.0001
11	2	0.1986	0.0733	0.7069	0.0171	0.0002	0.0035	0.0001	0.0003	0.0000
12	2	0.1995	0.0735	0.7073	0.0159	0.0000	0.0035	0.0001	0.0002	0.0000
13	2	0.1999	0.0735	0.7075	0.0153	0.0000	0.0035	0.0001	0.0001	0.0000
14	2	0.2001	0.0735	0.7077	0.0150	0.0000	0.0035	0.0001	0.0001	0.0000
15	2	0.2001	0.0735	0.7077	0.0150	0.0000	0.0036	0.0001	0.0001	0.0000
16	2	0.2002	0.0735	0.7077	0.0149	0.0000	0.0036	0.0001	0.0001	0.0000
17	2	0.2002	0.0735	0.7078	0.0148	0.0000	0.0036	0.0001	0.0001	0.0000
18	2	0.2002	0.0735	0.7078	0.0148	0.0000	0.0036	0.0001	0.0001	0.0000
19	2	0.2002	0.0735	0.7078	0.0148	0.0000	0.0036	0.0001	0.0001	0.0000
20	2	0.2002	0.0735	0.7078	0.0148	0.0000	0.0036	0.0001	0.0001	0.0000
21	2	0.2002	0.0735	0.7078	0.0147	0.0000	0.0036	0.0001	0.0001	0.0000
22	2	0.2002	0.0735	0.7078	0.0147	0.0000	0.0036	0.0001	0.0001	0.0000
2	3	0.1959	0.0732	0.7078	0.0184	0.0003	0.0034	0.0001	0.0010	0.0001
3	3	0.1903	0.0716	0.7092	0.0225	0.0015	0.0033	0.0001	0.0013	0.0003
4	3	0.1711	0.0660	0.7095	0.0413	0.0059	0.0030	0.0001	0.0021	0.0012
5	3	0.1351	0.0556	0.7080	0.0784	0.0140	0.0023	0.0001	0.0038	0.0028
6	3	0.1266	0.0537	0.7089	0.0840	0.0155	0.0022	0.0001	0.0041	0.0031
7	3	0.1143	0.0492	0.7074	0.1000	0.0189	0.0019	0.0001	0.0045	0.0038
8	3	0.1815	0.0686	0.7073	0.0335	0.0039	0.0032	0.0001	0.0013	0.0008
9	3	0.1926	0.0718	0.7078	0.0220	0.0014	0.0034	0.0001	0.0007	0.0003
10	3	0.1980	0.0732	0.7080	0.0166	0.0003	0.0035	0.0001	0.0004	0.0001
11	3	0.1991	0.0734	0.7077	0.0158	0.0001	0.0035	0.0001	0.0003	0.0000
12	3	0.1998	0.0735	0.7075	0.0154	0.0000	0.0035	0.0001	0.0002	0.0000
13	3	0.2000	0.0735	0.7076	0.0152	0.0000	0.0035	0.0001	0.0001	0.0000
3	4	0.1880	0.0712	0.7105	0.0232	0.0018	0.0033	0.0001	0.0016	0.0004
4	4	0.1523	0.0607	0.7106	0.0586	0.0100	0.0026	0.0001	0.0031	0.0020
5	4	0.0702	0.0361	0.7081	0.1433	0.0289	0.0011	0.0001	0.0065	0.0058
6	4	0.0650	0.0345	0.7077	0.1489	0.0301	0.0010	0.0001	0.0067	0.0061
7	4	0.0660	0.0345	0.7064	0.1493	0.0301	0.0011	0.0001	0.0064	0.0061
8	4	0.1832	0.0692	0.7061	0.0330	0.0034	0.0032	0.0001	0.0013	0.0007
9	4	0.1949	0.0725	0.7060	0.0214	0.0008	0.0034	0.0001	0.0007	0.0002
10	4	0.1990	0.0735	0.7068	0.0168	0.0000	0.0035	0.0001	0.0003	0.0000
11	4	0.1995	0.0735	0.7070	0.0161	0.0000	0.0035	0.0001	0.0002	0.0000
12	4	0.1999	0.0735	0.7072	0.0156	0.0000	0.0035	0.0001	0.0001	0.0000
13	4	0.2000	0.0735	0.7074	0.0154	0.0000	0.0035	0.0001	0.0001	0.0000

THE DISTRIBUTION OF QG in kW/m**3 AFTER 100 ITERATIONS

J= 4	0.000E-01	0.000E-01	2.834E+02	3.810E+02	-6.021E+02	-4.582E+02	-6.549E+02	2.177E+02	1.015E+02	4.645E+01
J= 3	0.000E-01	1.707E+02	1.899E+02	2.832E+02	2.080E+02	2.457E+02	-4.577E+01	2.352E+02	1.338E+02	7.648E+01
J= 2	4.791E+01	9.050E+01	6.590E+01	1.163E+02	1.958E+02	1.925E+02	1.777E+02	2.170E+02	1.472E+02	7.531E+01
J= 1	1.491E+01	3.028E+00	7.570E+00	7.998E+00	2.669E+01	6.657E+01	1.238E+02	1.287E+02	9.147E+01	6.670E+01
I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	I=10	
J= 4	4.358E+01	4.881E+01	6.060E+01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 3	7.185E+01	3.050E+01	3.448E+01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 2	6.230E+01	5.638E+01	4.470E+01	6.701E+01	6.076E+01	7.255E+01	5.083E+01	5.638E+01	9.568E+01	6.534E+01
J= 1	6.008E+01	3.885E+01	3.525E+01	4.156E+01	5.642E+01	5.411E+01	3.818E+01	5.875E+01	1.216E+02	9.031E+01
I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	I=19	I=20	
J= 4	0.000E-01	0.000E-01								
J= 3	0.000E-01	0.000E-01								
J= 2	5.285E+01	3.351E+01								
J= 1	6.605E+01	6.669E+01								
I=21	I=22									

THE DISTRIBUTION OF TRES in sec AFTER 100 ITERATIONS

J= 4	0.000E-01	0.000E-01	1.624E-01	1.728E-01	6.879E-02	6.883E-02	4.825E-02	1.710E-01	1.292E-01	2.166E-01
J= 3	0.000E-01	1.057E-01	7.956E-02	9.728E-02	5.978E-02	6.212E-02	5.124E-02	1.054E-01	9.306E-02	1.472E-01
J= 2	6.592E-01	9.042E-02	1.472E-01	1.372E-01	6.567E-02	6.422E-02	4.306E-02	8.404E-02	6.775E-02	1.202E-01
J= 1	7.707E-01	1.030E-01	1.509E-01	1.502E-01	9.378E-02	8.944E-02	5.748E-02	9.470E-02	6.455E-02	1.208E-01
I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	I=10	

J= 4	1.133E-01	2.347E-01	2.479E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 3	8.098E-02	1.860E-01	1.251E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 2	5.713E-02	1.258E-01	8.355E-02	2.012E-01	1.112E-01	1.979E-01	2.043E-01	2.395E-01	2.110E-01	1.994E-01	
J= 1	5.270E-02	1.262E-01	7.774E-02	1.187E-01	7.179E-02	1.315E-01	1.349E-01	1.467E-01	1.214E-01	1.343E-01	
	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	I=19	I=20	

J= 4	0.000E-01	0.000E-01
J= 3	0.000E-01	0.000E-01
J= 2	2.659E-01	2.353E-01
J= 1	2.065E-01	1.972E-01
	I=21	I=22

THE DISTRIBUTION OF VONR in kW AFTER 100 ITERATIONS

J= 4	0.000E-01	0.000E-01	7.121E+03	1.900E+04	1.128E+04	1.147E+04	6.384E+03	7.650E+03	1.492E+03	5.478E+02
J= 3	0.000E-01	7.555E+02	3.608E+03	9.180E+03	1.156E+04	1.419E+04	1.356E+04	7.348E+03	2.021E+03	9.633E+02
J= 2	0.000E-01	1.700E+02	1.568E+03	3.627E+03	4.703E+03	6.479E+03	1.026E+04	9.539E+03	2.965E+03	2.267E+03
J= 1	0.000E-01	3.778E+01	1.511E+02	2.644E+02	1.171E+03	2.304E+03	5.100E+03	5.648E+03	1.700E+03	1.511E+03
	I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	I=10

J= 4	1.889E+01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 3	1.511E+02	3.778E+01	1.889E+01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 2	1.889E+02	2.078E+02	1.889E+01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 1	3.400E+02	2.644E+02	1.889E+01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	I=19	I=20

J= 4	0.000E-01	0.000E-01
J= 3	0.000E-01	0.000E-01
J= 2	0.000E-01	0.000E-01
J= 1	0.000E-01	0.000E-01
	I=21	I=22

THE DISTRIBUTION OF VOL in kg/(kg,mixture) AFTER 100 ITERATIONS

J= 4	0.000E-01	0.000E-01	2.141E-03	1.199E-02	3.474E-02	3.620E-02	3.619E-02	4.045E-03	9.268E-04	5.988E-05
J= 3	0.000E-01	3.028E-04	1.776E-03	7.054E-03	1.878E-02	1.856E-02	2.270E-02	4.638E-03	1.648E-03	3.453E-04
J= 2	0.000E-01	7.95E-05	3.084E-04	9.423E-04	5.069E-03	7.262E-03	1.267E-02	5.082E-03	2.224E-03	3.687E-04
J= 1	0.000E-01	1.758E-05	0.000E-01	4.263E-05	8.034E-04	1.716E-03	5.295E-03	2.615E-03	1.399E-03	4.019E-04
	I= 1	I= 2	I= 3	I= 4	I= 5	I= 6	I= 7	I= 8	I= 9	I=10

J= 4	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 3	9.171E-05	1.377E-05	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 2	1.857E-04	4.734E-05	6.046E-06	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
J= 1	1.559E-04	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01	0.000E-01
	I=11	I=12	I=13	I=14	I=15	I=16	I=17	I=18	I=19	I=20

J= 4	0.000E-01	0.000E-01
J= 3	0.000E-01	0.000E-01
J= 2	0.000E-01	0.000E-01
J= 1	0.000E-01	0.000E-01
	I=21	I=22

THE DISTRIBUTION OF TW in K AFTER 100 ITERATIONS

J= 4	1.465E+03
J= 3	1.356E+03
J= 2	1.206E+03
J= 1	4.000E+02
	M1= 1

THE DISTRIBUTION OF QIN in kW/m**2 AFTER 100 ITERATIONS

J= 4	4.594E+02
J= 3	4.097E+02
J= 2	3.043E+02
J= 1	2.814E+02
	M1= 1

THE DISTRIBUTION OF QW in kW/m**2 AFTER 100 ITERATIONS

J= 4	-1.431E+02
J= 3	-1.575E+02
J= 2	-1.322E+02
J= 1	-2.800E+02
	M1= 1

THE DISTRIBUTION OF TW in K AFTER 100 ITERATIONS

J= 4	1.354E+03
J= 3	1.384E+03
J= 2	7.820E+02
J= 1	7.820E+02

M3= 1

THE DISTRIBUTION OF QIM in kW/m**2 AFTER 100 ITERATIONS

J= 4 3.494E+02
J= 3 3.747E+02
J= 2 4.488E+01
J= 1 5.030E+01

M3= 1

THE DISTRIBUTION OF QM in kW/m**2 AFTER 100 ITERATIONS

J= 4 -1.147E+02
J= 3 -1.204E+02
J= 2 -2.342E+01
J= 1 -2.910E+01

M3= 1

THE DISTRIBUTION OF TW in K AFTER 100 ITERATIONS

M4= 1 1.133E+03 1.337E+03 1.511E+03 1.545E+03 1.157E+03 1.078E+03 1.141E+03 1.624E+03 1.618E+03 1.551E+03
I= 1 I= 2 I= 3 I= 4 I= 5 I= 6 I= 7 I= 8 I= 9 I=10
M4= 1 1.497E+03 1.422E+03 1.348E+03 1.283E+03 1.205E+03 1.130E+03 1.063E+03 1.005E+03 8.404E+02 8.206E+02
I=11 I=12 I=13 I=14 I=15 I=16 I=17 I=18 I=19 I=20
M4= 1 8.122E+02 7.844E+02
I=21 I=22

THE DISTRIBUTION OF QIM in kW/m**2 AFTER 100 ITERATIONS

M4= 1 2.468E+02 3.923E+02 5.072E+02 5.128E+02 2.158E+02 1.768E+02 1.891E+02 5.656E+02 5.715E+02 5.071E+02
I= 1 I= 2 I= 3 I= 4 I= 5 I= 6 I= 7 I= 8 I= 9 I=10
M4= 1 4.619E+02 3.999E+02 3.442E+02 2.995E+02 2.547E+02 2.148E+02 1.847E+02 1.584E+02 6.604E+01 5.444E+01
I=11 I=12 I=13 I=14 I=15 I=16 I=17 I=18 I=19 I=20
M4= 1 5.112E+01 3.473E+01
I=21 I=22

THE DISTRIBUTION OF QM in kW/m**2 AFTER 100 ITERATIONS

M4= 1 -1.112E+02 -1.527E+02 -1.522E+02 -1.352E+02 -8.146E+01 -7.213E+01 -6.640E+01 -1.223E+02 -1.303E+02 -1.282E+02
I= 1 I= 2 I= 3 I= 4 I= 5 I= 6 I= 7 I= 8 I= 9 I=10
M4= 1 -1.271E+02 -1.210E+02 -1.135E+02 -1.067E+02 -1.000E+02 -9.115E+01 -8.444E+01 -7.635E+01 -3.253E+01 -2.543E+01
I=11 I=12 I=13 I=14 I=15 I=16 I=17 I=18 I=19 I=20
M4= 1 -2.240E+01 -1.238E+01
I=21 I=22

iter. no.=100, act.err.= 0.1317 %, avg.err.= 3.1716 %, 20 it.err.= 0.0701 %, hb.err.= -0.0130 %

BALANCE OF TOTAL RADIATIVE EXCHANGE

NUMBER OF BEAMS = 367920

SUM OF EMITTED RADIATION (KW) :		M=1	M=2	M=3	M=4	TOTAL
VOLUME ZONES	WALL SECTIONS					
3.709E+06	1.373E+05	5.014E+03	1.118E+04	3.907E+03	1.172E+05	3.047E+06

SUM OF ABSORBED RADIATION (KW) :		M=1	M=2	M=3	M=4	TOTAL
VOLUME ZONES	WALL SECTIONS					
3.635E+06	2.120E+05	1.398E+04	0.000E+01	7.211E+03	1.908E+05	3.847E+06

SUM OF NET EMITTED RADIATION (KW) :		M=1	M=2	M=3	M=4	TOTAL
VOLUME ZONES	WALL SECTIONS					
7.466E+04	-7.466E+04	-8.966E+03	1.118E+04	-3.304E+03	-7.358E+04	-3.156E+00

ERROR OF RADIATIVE ENERGY BALANCE =-8.205E-05 %

TOTAL HEAT BALANCE :

HEAT TO FURNACE WALLS IN KW :			
RAD.=	92453.7	CONV.=	3909.2
SUM =	96362.9		
HEAT TO FURNACE EXIT IN KW :			
RAD.=	738.3	CONV.=	0.0
SUM =	738.3		
HEAT TO FURNACE HOPPER IN KW :			
RAD.=	3921.0	CONV.=	0.0
SUM =	3921.0		

HEAT FLUXES TO ZONAL HEAT EXCHANGERS IN KW :

HOME I	BY RAD.	BY CONV.	SUM
19	6888.0	7618.6	14274.7
20	3819.5	4874.4	8393.9
21	3301.2	9786.2	13087.4
22	2844.4	9444.3	12388.7

CLOSURE OF TOTAL HEAT BALANCE :
 HEAT FLUX FROM FLUE GAS : 149363.6 KW
 HEAT FLUX TO HEAT SINKS : 149166.9 KW
 DIFFERENCE : -196.7 KW
 ACT. PERCENTAGE ERROR : 0.131694 %
 AVG. PERCENTAGE ERROR : 3.171847 %
 AVG. ERROR OF LAST 20 IT. : 0.070086 %

I INDEX	X-CO-ORDINATE M	NET WORK. MASS FLUX -	MEAN TEMP. K	MEAN RES. TIME S
1	1.513	0.0500	1473.02	5.1068
2	3.480	0.2500	1467.95	0.3726
3	4.803	0.5500	1772.35	0.3991
4	6.541	0.8000	1782.81	0.2760
5	8.037	0.9324	1428.79	0.1878
6	9.291	0.8188	1468.15	0.2137
7	10.545	1.0096	1787.08	0.1749
8	12.207	1.0097	1862.31	0.2506
9	13.778	1.0001	1884.37	0.1297
10	15.365	1.0001	1875.27	0.2562
11	16.844	1.0001	1855.61	0.1055
12	18.329	1.0001	1814.23	0.2678
13	20.445	1.0000	1779.01	0.2765
14	23.114	1.0000	1734.74	0.2318
15	25.525	1.0000	1705.40	0.1172
16	27.800	1.0000	1657.29	0.2226
17	30.749	1.0000	1619.56	0.2279
18	33.699	1.0000	1571.15	0.2350
19	36.152	1.0000	1447.50	0.1702
20	38.110	1.0000	1356.62	0.1805
21	40.293	1.0000	1225.94	0.2460
22	42.684	1.0000	1109.85	0.2667

MEAN GAS SPECIES CONCENTRATION ALONG FURNACE :		CO2				O2		VOL		SO2	
I	X-CO-ORD. M	VOL% NET	N2O VOL% NET	N2 VOL% NET		VOL% NET		VOL% NET		VOL% NET	
1	1.513	13.0974	11.8599	73.4369		1.4483	0.0000	0.0000		0.1575	
2	3.480	13.0605	11.8544	73.4340		1.4901	0.0045	0.1545			
3	4.803	12.9040	11.7542	73.4692		1.6306	0.0075	0.1545			
4	6.541	11.9179	11.0600	73.3288		2.8835	0.6678	0.1420			
5	8.037	9.5688	9.3580	72.7665		6.1100	2.0850	0.1118			
6	9.291	9.8287	9.5403	72.8376		5.7487	1.9344	0.1153			
7	10.545	10.6383	10.1054	72.9370		4.7249	1.4687	0.1258			
8	12.207	12.1254	11.1529	73.1843		2.7999	0.5925	0.1449			
9	13.778	12.7077	11.5624	73.2833		2.0442	0.2500	0.1524			
10	15.365	13.0639	11.7984	73.3636		1.5642	0.0524	0.1575			
11	16.844	13.1327	11.8363	73.3754		1.4763	0.0207	0.1587			
12	18.329	13.1844	11.8577	73.3926		1.4027	0.0027	0.1599			
13	20.445	13.1997	11.8604	73.4124		1.3665	0.0003	0.1607			
14	23.114	13.2082	11.8607	73.4147		1.3553	0.0000	0.1610			
15	25.525	13.2114	11.8607	73.4170		1.3498	0.0000	0.1611			
16	27.800	13.2147	11.8607	73.4193		1.3440	0.0000	0.1613			
17	30.749	13.2169	11.8607	73.4212		1.3398	0.0000	0.1614			
18	33.699	13.2182	11.8607	73.4224		1.3372	0.0000	0.1615			
19	36.152	13.2186	11.8607	73.4230		1.3363	0.0000	0.1615			
20	38.110	13.2187	11.8607	73.4235		1.3356	0.0000	0.1615			
21	40.293	13.2187	11.8606	73.4240		1.3351	0.0000	0.1615			
22	42.684	13.2187	11.8606	73.4240		1.3351	0.0000	0.1615			

OTHER MEAN QUANTITIES ALONG FURNACE :		CARBON		TOT. FUEL		SO2		CAO	
I	X-CO-ORD. M	IN ASH	HEAT REL.	HEAT REL.	REDUCTION	UTIL.			
1	1.513	91.5605	0.0274	0.0000	0.0000	0.0000			
2	3.480	93.0138	0.6049	0.5100	0.0000	0.0000			
3	4.803	94.2824	7.3816	7.1000	0.0000	0.0000			
4	6.541	96.8319	24.4498	24.0800	0.0000	0.0000			
5	8.037	98.3527	39.0275	39.2800	0.0000	0.0000			
6	9.291	98.2474	56.5346	57.5100	0.0000	0.0000			
7	10.545	97.7663	74.9448	76.2000	0.0000	0.0000			
8	12.207	95.7489	91.3717	92.1800	0.0000	0.0000			
9	13.778	93.4126	95.8404	96.5100	0.0000	0.0000			
10	15.365	88.5292	98.8444	99.3100	0.0000	0.0000			
11	16.844	85.1848	99.3046	99.6800	0.0000	0.0000			
12	18.329	78.1987	99.7042	99.9500	0.0000	0.0000			
13	20.445	72.2636	99.8029	99.9800	0.0000	0.0000			
14	23.114	66.0864	99.8502	99.9800	0.0000	0.0000			
15	25.525	62.8494	99.8670	99.9800	0.0000	0.0000			
16	27.800	58.6662	99.8858	99.9800	0.0000	0.0000			
17	30.749	55.3540	99.8984	99.9800	0.0000	0.0000			
18	33.699	53.1310	99.9063	99.9800	0.0000	0.0000			
19	36.152	52.5413	99.9081	99.9800	0.0000	0.0000			
20	38.110	52.2835	99.9090	99.9800	0.0000	0.0000			
21	40.293	52.2143	99.9092	99.9800	0.0000	0.0000			
22	42.684	52.2033	99.9092	99.9800	0.0000	0.0000			

concentration of solid species in kg/m**3 :			
I	X(I)	ash	soot
1	1.513	0.024538	0.266217
2	3.480	0.004334	0.000426
3	4.803	0.001853	0.000533
4	6.541	0.001263	0.000421
5	8.037	0.001180	0.000407
6	9.291	0.001317	0.000593
7	10.545	0.000996	0.000573
8	12.207	0.000959	0.001599
9	13.778	0.000958	0.001586

10	15.365	0.000964	0.007436	0.001099
11	16.844	0.000174	0.005599	0.000438
12	18.327	0.000996	0.003573	0.000089
13	20.445	0.001016	0.002447	0.000004
14	23.114	0.001042	0.002030	0.000000
15	25.825	0.001060	0.001793	0.000000
16	27.800	0.001091	0.001548	0.000000
17	30.749	0.001116	0.001384	0.000000
18	33.499	0.001150	0.001304	0.000000
19	36.152	0.001249	0.001382	0.000000
20	38.110	0.001332	0.001460	0.000000
21	40.293	0.001474	0.001611	0.000000
22	42.684	0.001628	0.001779	0.000000

END

**DATE
FILMED
6/16/92**