DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

DE-AC22- DOE/PC/79864--6
DE92 016062

Modeling of Integrated Environmental Control Systems for Coal-Fired Power Plants

Technical Progress Report

To

Pittsburgh Energy Technology Center
U.S. Department of Energy
Pittsburgh, Pennsylvania 15236

From

Center for Energy and Environmental Studies
Carnegie Mellon University
Pittsburgh, Pennsylvania 15213

Prepared by

E.S. Rubin, Principal Investigator

April 1989

MASTER

Jmp

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

Introduction

This is the sixth quarterly report of DOE Contract No. DE-AC22-87PC79864, entitled "Modeling of Integrated Environmental Control Systems for Coal-Fired Power Plants." This report summarizes accomplishments during the period January 1, 1989 to March 31, 1989.

Accomplishments

Efforts this past quarter focused primarily on the preparation of a computer User's Guide for the Integrated Environmental Control Model (IECM). Drafts of the first two chapters are now complete. These chapters constitute the bulk of this quarterly report. Drafts of the remaining chapters are in preparation, and will appear in a future report this year.

We also have been working closely with DOE/PETC to define the computer configuration to be transferred to PETC as a contract deliverable. That process is now complete and the equipment is on order. Delivery of the IECM to PETC is expected during the next calendar quarter.

Finally, we are continuing our efforts to develop and refine a number of clean coal technology process models. These efforts will be summarized and reported at a future date.

DRAFT

**User's Manual for the
Integrated Environmental Control Model
(IECM)**

John S. Salmento

Center for Energy and Environmental Studies
Carnegie Mellon University
Pittsburgh, PA 15213

April 1989

Table of Contents

1. Introduction	1
1.1 Model Overview	1
1.2 Computer Hardware Options	3
1.3 Scope and Organization of this Manual	4
2. Tutorial	5
2.1 Loading the IECM Model	6
2.2 Analyzing the IECM Hierarchy	12
2.3 Displaying and Specifying Input, Control Parameters and Variables	14
2.4 Specifying Vectors and Tables	17
2.5 Typical Demos Commands	20
2.6 Graphing and Probabilistic Analysis	24
2.7 Changing Coals and Coal Cleaning	31
2.8 Redefining Variables	36
2.9 Exiting and Saving the Model	39

List of Figures

Figure 1-1:	Selected air pollution control options for pulverized coal-fired boilers	2
Figure 1-2:	Some ways of expressing uncertainty	2
Figure 2-1:	Picture of the Screen before Starting Demos	7
Figure 2-2:	Picture of Macintosh Screen before Starting Demos	9
Figure 2-3:	Picture of Macintosh Screen after Starting Demos	9
Figure 2-4:	Picture of Macintosh Screen When Demos Needs the Name of the Project	10
Figure 2-5:	Picture of Macintosh Screen When Demos is Ready to Read in a New Model	10
Figure 2-6:	Hierarchy for the IECM Configured with a Wet FGD, ESP, and SCR.	13
Figure 2-7:	Contents of the File, Example.mod	23
Figure 2-8:	Picture of Screen after Graph Elecpc Mwg Command	27
Figure 2-9:	Picture of Screen after Graph Elecpc Mwg Command on the Macintosh	27
Figure 2-10:	Picture of Screen after Pdf Elecpc Command	28
Figure 2-11:	Picture of Screen after Pdf Elecpc Command on the Macintosh	28
Figure 2-12:	Picture of Screen after Cdf Elecpc Command	30
Figure 2-13:	Picture of Screen after Cdf Elecpc Command on the Macintosh Version.	30
Figure 2-14:	Contents of iec.coal File Created by the Fortran Coal Cleaning Program.	34

1. Introduction

1.1 Model Overview

For the past several years, the U.S. Department of Energy (DOE) has been supporting the development of the Integrated Environmental Control Model (IECM) for analyzing integrated environmental control system designs for new coal-fired power plants. It emphasizes the role of advanced technologies for pre-combustion, combustion, and post-combustion control of air pollutant emissions, and the systematic comparison of conventional and advanced integrated system designs based on site-specific plant characteristics. It also facilitates the explicit characterization and analysis of technical and economic uncertainties in model parameters and results.

The IECM currently simulates the performance of 16 pre-combustion, combustion, and post-combustion processes (Figure 1-1), and allows integrated systems to be configured by combining any desired combinations of these options. Each of the boxes in Figure 1-1 represents a module in the IECM model. The technologies above the dashed line represent conventional designs, while the technologies below the dashed line represent advanced designs. The conventional technologies include various levels of coal preparation for pre-combustion, low NO_x burners for combustion modifications, and a variety of post-combustion control measures for the control of particulates, sulfur dioxide, and NO_x . Advanced physical coal cleaning processes include high gradient magnetic separation (HGMS), coal-pyrite flotation and various heavy media separation processes. Other advanced processes that have been modeled to date are furnace sorbent injection, electron beam, NOXSO, and the copper oxide process.

A unique feature of this model is that it was written in the Demos language recently developed by Henrion and his co-workers [1] to facilitate the testing of alternative models and the analysis of uncertainty. Demos is run on computers using the Unix operating system. A more recent version is designed to operate on the Apple Macintosh computer line. Unlike conventional programming languages such as Fortran, Demos employs a nonprocedural format which allows model relationships to be specified or altered quite easily. Thus, modules for individual components can be developed and easily linked to test alternative system configurations. In addition to producing point estimates (deterministic values) of system performance and costs for a particular set of assumptions, the model also can produce probabilistic results based on an explicit characterization of the uncertainty in model parameters.

Figure 1-2 shows some of the ways in which this uncertainty may be quantified. The curves shown are Probability Distribution Functions (PDF). Which show the probability of a parameter having a specified value. A normal (Gaussian) distribution reflects a symmetric (but varying) probability of a parameter value being above or below the mean value (Figure 1-2a). A characteristic of this distribution is the standard deviation, σ . The properties of a Gaussian distribution are such that there is a 68% probability that a value lies within one standard deviation of the mean, and a 95% probability that a value lies within 2σ of the mean. In contrast, for a uniform distribution (Figure 1-2b) there is an equal likelihood of a value lying anywhere within a specified range. A lognormal distribution, on the other hand, is skewed (Figure 1-2c). This distribution is used when the lower bound is more certain than the upper bound. A user-specified distribution also may be employed by assigning probabilities to various fractiles across a range or to discrete point (Figure 1-2d).

Given a specified set of uncertainties in model parameters, a form of Monte Carlo simulation using

Figure 1-1: Selected air pollution control options for pulverized coal-fired boilers

Figure 1-2: Some ways of expressing uncertainty

Latin Hypercube sampling is used to obtain a probabilistic description of output results by randomly sampling from the specified distributions. Thus, a range of output results is achieved which describes statistically the possible effects of simultaneous variations in many parameters. A cumulative frequency distribution then can be generated which characterizes the probability of some result (e.g., cost) exceeding a specified value, or lying within some specified range. Such results are much more comprehensive than the deterministic results of most modeling studies. As a way of characterizing uncertainty, it also offers an advantage over sensitivity analysis, which typically treats variations in only one or two parameters at a time, or establishes bounds on some result with no information as to its likelihood.

1.2 Computer Hardware Options

Demos is capable of running on any VAX or Sun 3 computer running the Unix operating system. Demos also runs on any Macintosh computer running system 6.0, which will be described in more detail below. At Carnegie Mellon University, Demos is currently being used on VAXstation II and Sun 3/52 workstations. These workstations have large, high resolution graphic monitors, 70 Megabyte disk drives, and the Andrew window managing program. A window manager allows the screen to be divided into different sections, which act as individual graphic screens. The Andrew window manager is an IBM software package, which is being developed and tested at CMU. A workstation configuration allows Demos to produce high resolution graphics on the screen and allows multiple programs to be run simultaneously. With a 70 Megabyte disk drive, only about 10 to 15 Megabytes of space is left once all the software is on the disk. So an additional 70 Megabyte disk or one 140 Megabyte disk is recommended.

Demos can also be run from a regular terminal that is connected to any of the above computers; however, only alphanumeric graphs are shown on the terminal. If an IBM PC with a graphics card and color monitor is available, then color graphs can be displayed on its screen.

There are a number of ways to print the graphs produced by Demos. Demos has some built in commands which create files which can be printed on any Postscript printer, such as the Apple Laserwriter. The Andrew window manager can take a snapshot of the screen, which can be printed out to any Postscript or IBM 3812/3820 printers. If an IBM PC is used then, the print screen key can be used to print out the graphs to any dot matrix printer connected to the IBM PC.

For the Macintosh, only two floppy drives and one megabyte of RAM memory is required to run Demos for simple models; however, eight megabytes of memory and an 80 megabyte disk drive are recommended. Demos can take advantage of the color monitors connected to a Macintosh so an IBM PC is not needed for color graphs. Also, it can print out directly to any Apple printer or with the proper software or hardware Demos can print to most printers. Two major differences between the Unix version of Demos and the Macintosh version, are that most of the Demos commands and functions are accessible in pull-down menus. Demos will put up a little window whenever it needs information in the Macintosh version.

1.3 Scope and Organization of this Manual

This manual is intended to allow anyone with a basic understanding of Unix or the Macintosh operation system to use the IECM. Chapter 2 provides a tutorial for beginners and a basic description of the IECM structure. Further details about the Demos language can be found in Reference [1]. It is assumed here that the IECM user has reviewed the Demos User's Manual and has at least some familiarity with the structure of Demos variables and commands. People who have a good understanding of Demos can skip the Tutorial chapter. Chapter 3 provides a detailed description of the IECM submodules, including inputs, outputs, and various intermediate parameters. Analytical documentation for the IECM can be found in Rubin et. al. [2]. The latest analytical documentation for the Copper Oxide process can be found in Frey [3]. Chapter 4 contains documentation on the conventional coal cleaning and HGMS preprocessors. Chapter 5 discusses future additions and refinements to the model.

2. Tutorial

This chapter is a tutorial on how to use the IECM. It shows how to use the Demos language for a typical analysis, and discusses many common errors that may be encountered. This tutorial provides hints on how to use the Andrew window manager and Macintosh operating systems, but it assumes that the user already is familiar with the operating systems and knows how to use a mouse. Where specific differences occur between operating systems, they will be distinguished. The following will be demonstrated in this tutorial:

- Loading a specific configuration into the IECM
- Analyzing the hierarchy of the IECM structure
- Specifying input parameters and variables
- Specifying vectors and tables
- Basic Demos commands
- Probabilistic analysis and graphing
- Changing coals and coal cleaning
- Redefining variables
- Exiting and saving the model

A typical configuration of the IECM contains about 1000 objects. Objects can be commands, functions, models, or variables. Commands can be divided into four groups: inspection, file, graphical, and miscellaneous. Inspection commands are used to display and analyze other objects. File commands are used to create and manipulate files. Graphing commands are used to create and modify graphs. Miscellaneous commands including quitting, help, etc. The names of objects are limited to twelve characters.

Variables	A generic model parameter, which may be represented in term as of other objects via algebraic relationships. For example, $HRcycle = HRsteam / Boiler_eff$.
Models	Objects which group other objects for organization and structure. For example the model Wetscresp contains the models Allinputs, Plant, Esp, Wetfgd, Solwaste, Scr, Economics, lecmfunctions.
Functions	Objects which are similiar to functions in other languages, that is they are algorithms which can have parameters pass into them and return a value. There are two classes of functions, system functions and user-defined functions. For example, $Quadeqn(A,B,C) = (-b - \sqrt{b^2 - 4 * a * c}) / (2 * a)$, returns a root of a quadratic equation with the coefficients A, B, C.

The value of function and variables can be scalars, character strings, arrays, or probabilistic. Any of these values can be entered as an input parameter or calculated by Demos. In addition, it is very easy to convert between scalars, arrays, and probabilistic values. A brief description is given below:

Scalar	A scalar is a single number. For example, $Mwg = 500$.
Character string	A character string is a list of characters. For example, $Disposal = 'landfill'$. The single quotes are used to enter character strings.
Arrays	Arrays can be single or multi dimensional and consist either of scalars or character strings. Most functions and commands in Demos operate on numeric arrays as easily as on scalars. This allows changing the value of a variable to an array, without changing the definitions of any variable that depend upon it, which is very useful for parametric analysis. Single dimensional arrays are called vectors, while multi

dimensional arrays are called tables. An example of a vector of character strings is `gascomp = ['N2','O2','H2O','CO2','CO','SO2','SO3','NO','NO2']`. The square brackets are used to define arrays. An example of a table which contains the coal characteristics is `CoalChar_table = table(Coalindex,CoalChar_index) (13140. .7341 .0427 .0331 .0170 .0128 .1552 .0050)`.

Probabilistic A probabilistic value is an array of scalars generated by either Latin Hypercube or Monte Carlo sampling. The size of the array is controlled by the system variable, `samplesize`. Probabilistic values are generated when one or more probability density functions (normal, lognormal, uniform, fractile, and chance) are used in the definitions of variables. Demos has a number of commands for analyzing and graphing probabilistic values. Some of these commands are described in section 2.6.

Variables are the basic building blocks of any model and do not have any restrictions on their type of value. In other words variables can be scalars, character strings, arrays, or probabilistic. However many times it is useful to constrain the value of input parameter. Demos has five special classes of variable which have restrictions on their value. Of these five, the IECM uses the following three:

Constant	A variable that has a scalar value, such as the universal gas constant, <code>gasR = 1545 ft-lbf/lb mole R</code> .
Decision	A variable that is used to make a choice, such as <code>Furnacetype = 'wall'</code> . The only restriction on these variables is that they can not be probabilistic.
Index	A variable which must be a single dimensional array. For example, the variable with the labels for the coal composition table, <code>Ccoalchar_index = ['HHV','Carbon','Hydrogen','Oxygen','Sulfur','Nitrogen','Ash','Moisture']</code> .

The following conventions will be used in this example. Anything that has to be typed by the user will appear in **bold**. A "Return" key has to be pressed to enter a command; however, it will not be explicitly shown in the example for clarity. Many times Demos will prompt the user with questions, which have a default answer in brackets. The user can either enter an answer or type a "return" for the default. For the Unix version, it is important to enter the proper case for the letters in a file name since Unix is case sensitive. Useful hints will appear in *italics* on the right side. Finally, this example does not show all the commands, shortcuts, or hints possible, but it is enough to start using the IECM productively. For more detail see the Demos User's Manual [1].

2.1 Loading the IECM Model

If you are on a Macintosh skip to the next paragraph. The starting point for the Unix version for this example is that the user, John Salmento, is logged on to a Sun 3 workstation, with a large graphic monitor, and has started the Andrew window manager. The screen should look similar to Figure 2-1. Everything that occurs in the tutorial will appear in the long blank window on the left. Whenever a command causes a new window to appear, a figure of the entire screen will be shown. To start Demos, type **Demos** at the prompt.

```
js04>Demos
Initializing...
```

```
Welcome to Demos (version IV -- Andrew/Unix, 2-Mar-87)
unless you need the current changes. Current modification date
is April 21, 1987.
```

```
Copyright (C) 1983 C-MU.
```

Figure 2-1: Picture of the Screen before Starting Demos

Do you want to start a New Model? [Yes] :
 Name of Project? [Test] : **Example**

Declaring Model Example
 Description: **Example on how to use the IECM**
 Author: **John Salmento**

We now have the revised DEMOS manual for DEMOS version IV.
 Please send mail to nina@andrew for a copy. The manual describes
 the many changes to DEMOS, new additions, and graphic enhancements.

Latest news on 9-March-87. Type "News" to read it.
 Type "Help" if needed.

Example>

The starting point for the Macintosh version for this example is that the Macintosh is turned on, and the user has opened up the Demos folder on the Applications volume. The screen looks like Figure 2-2. To start Demos, double click on the icon (picture) which is labeled Demos. Demos will create a window when it is started, as shown in Figure 2-3. The biggest difference between the Macintosh version and the Andrew versions is that the Macintosh version will display a little window whenever Demos needs some information. For example, in Figure 2-3, Demos is asking if you want to start a new model. Move the mouse pointer to the "yes" button and click the button on the mouse once. Then Demos will open another window requesting the name of the project. Just type in **Example**. Figure 2-4 shows the result after typing in **Example**. Demos will now display two more windows sequentially requesting a description and author for the project. Just type in the information that appears above for these two windows. Figure 2-5 shows the screen when Demos is ready to read in a new model.

The first step is to specify the power plant configuration to be analyzed. While the focus of the IECM is on air pollution control systems, the performance and cost for a complete power plant are estimated since the effects of coal cleaning (if used) can only be properly accounted for by looking at its net effect on power production costs. Thus, the elements of the IECM power plant design which must be specified are:

- Base power plant
- Particulate control system
- SO₂ control system
- NO_x system
- Solid waste disposal system

In addition, various economic and financial parameters must be specified, as well as coal properties, plant design and engineering parameters, and environmental regulatory constraints.

The structure of the IECM uses a series of files to organize information about individual plant components and other necessary data. To configure and analyze a plant, the appropriate series of files is read and loaded into the model (details on each of these files appears later). These files contain various models arranged in a hierarchy, which allows a user to easily examine and find variables.

The IECM also has several files which make it easy to load standard plant configurations involving different combinations of control technology. These files simply contain a series of Demos commands calling the various plant components. For example, the contents of "loadwet.mod" is shown below.

Figure 2-2: Picture of Macintosh Screen before Starting Demos

Figure 2-3: Picture of Macintosh Screen after Starting Demos

Figure 2-4: Picture of Macintosh Screen When Demos Needs the Name of the Project

Figure 2-5: Picture of Macintosh Screen When Demos is Ready to Read in a New Model

```

Model wetscresp           Gives a name to the top model in the hierarchy.
Description: Configuration with an ESP, wet FGD, and Scr.
verb:2                   Prevents extremely verbose variable checking.
read srccom/plant.mod     "srccom/" is one directory with some of the IECM source code.
read srccom/esp.mod       On the Macintosh the "srccom/" would be a "files:srccom:"
read srccom/wetfgd.mod
read srccom/solwaste.mod
read srcpetc/plant.petc   "srcpetc/" is another directory with additional source code.
read srcpetc/scr.petc     On the Macintosh the "srccom/" would be a "files:srcpetc:"
read srcpetc/esp.petc
read srcpetc/wetfgd.petc
read srcpetc/solwaste.petc
read srcpetc/economics.petc
Close wetscresp
heapsize:10M             Sets the amount of memory that Demos can use; not applicable on
samplesize:45            the Macintosh
tabwidth:20              Width of columns in tables, can have a value between 1 and 20.
numberwidth:5

```

A list of the files specifying common plant configurations is given below, while a complete description is provided in Chapter 3.

- loadwet.mod
- loaddry.mod
- loadbeam.mod
- loadnoxso.mod
- loadcuo.mod
- loadlimb.mod

For this example, an analysis of a coal-fired power plant with a wet FGD, a cold-side ESP, and a SCR device will be demonstrated, so the file "loadwet.mod" (which specifies the elements for this configuration) needs to be loaded. Each hash mark represent 10 lines of source code.

Example>read loadwet.mod On the Macintosh type read files:iec:loadwet.mod.

Reading from loadwet.mod

On the Macintosh, the characters "srccom/" would be replace with "files:srccom:".

Reading from srccom/plant.mod

```

#####
#####
#####

```

Reading from srccom/newenth.mod

```

#####

```

Reading from srccom/esp.mod

```

#####

```

Reading from srccom/wetfgd.mod

```

#####

```

Reading from srccom/solwaste.mod

```

#####

```

On the Macintosh, the characters "srcpetc/" would be replace with "files:srcpetc:".

Reading from srcpetc/plant.petc

```

#####

```



```
#####
```

```
Reading from srcpetc/scr.petc
#####
```

```
Reading from srcpetc/esp.petc
#####
```

```
Reading from srcpetc/wetfgd.petc
#####
```

```
Reading from srcpetc/solwaste.petc
#####
```

```
Reading from srcpetc/economics.petc
#####
The definitions of all Variables and Functions are OK
```

```
Example>
```

2.2 Analyzing the IECM Hierarchy

At this point the basic configuration for a wet FGD, with a cold ESP and SCR device has been loaded into Demos, and the user is ready to begin the analysis. The upper four levels of the hierarchy for this configuration are shown in Figure 2-6. All of the models shown in Figure 2-6 contain variables or other models. As can be seen the top model is Example, which contains the model Wetscresp. Wetscresp contains a model for all the devices in this configuration (Plant, Esp, Wetfgd, Solwaste, and Scr) and three other models, Allinputs, Iecmfuctions, and Economics. For now we are only interested in the Allinputs model, which contains all the input models for this configuration. These input models contain the input variables needed for their respective models. A complete list of input parameters can be found in the source code or in Appendix A.

Demos has two basic commands which are useful examining the hierarchy of models, Show and Isin. The Show command displays the description and content of any object. When used on a model it displays the description, its contents, the author, date created, and what other objects it needs. The Isin command displays the model which contains the current object. For example, Allinputs is inside of the model Wetscresp. The example below demonstrates the results of using the Show and Isin commands.

```
Example>show example
Model Example
Description: Example on how to use the IECM
Contains: [Model Wetscresp]
Author: John Salmento
Date: Thu May 11 11:27:01
Savedate: Thu May 11 11:27:01
Needs: [Model Wetscresp]
```

This attribute indicates that this model needs some objects in model Wetscresp.

```
Example>show wetscresp
Model Wetscresp
Description: Configuration with an ESP, wet FGD, and Scr.
Contains: [Model Allinputs, Model Plant, Model Iecmfuction, Model Esp,
Model Wetfgd, Model Solwaste, Model Scr, Model Economics]
Author: js04
Needs: [Model Allinputs, Model Plant, Model Iecmfuction, Model Esp, Model
Wetfgd, Model Solwaste, Model Scr, Model Economics]
```

Figure 2-6: Hierarchy for the IECM Configured with a Wet FGD, ESP, and SCR.

Example>**show allinputs**

Model Allinputs

Description: contains all the input models for all the submodels

Contains: [Model Basecontrols, Model Coalinputs, Model Basepltinput, Model Espmodelinput, Model Wetmodelinput, Model Swdmodelinput, Model Reagents, Model Scrmodelinput, Model Econmodelinp]

Author: js04

Date: Tue Jan 21

Needs: [Model Basecontrols, Model Coalinputs, Model Basepltinput, Model Espmodelinput, Model Wetmodelinput, Model Swdmodelinput, Model Reagents, Model Scrmodelinput, Model Econmodelinp]

Example>**isin allinputs**

Wetscresp

Example>**show basepltinput**

Model Basepltinput

Description: Default input values.

Contains: [Variable Mwg, Variable Hrsteam, Variable Cf, Variable Exair_boiler, Variable Exair_airhea, Variable Temp_furn, Variable Temp_econo, Variable Orgtemp_fgap, Variable Xpulverizers, Variable Xsteampumps, Variable Xfans, Variable Xtowers, Variable Xmisc, Variable Unacc_loss, Index Pltinputlabe, Variable Plantinputs, Index Pltvalue, Model Airemissions, Model Unc_plant, Model Plteconinput]

Author: js04

Needs: [Model Basecontrols, Model Airemissions, Model Unc_plant, Model Plteconinput]

Example>

2.3 Displaying and Specifying Input, Control Parameters and Variables

To display any input parameter, variable, vector, or table, just type its name. If the variable does not depend on any arrays, the value will be displayed; however, if it does depend on arrays then the array dependency will be displayed. For these variables, the Mid command is used to display the value. Note that each module, (i.e., wetfgd, scr, etc.) has its own input parameters, whose names can be found in the source code, in Appendix A, or by using the Show command as displayed above. The default values of some input parameters and variables are shown below. To set up a new run the user simply specifies new values for any model parameter.

Example>**mwg**

Mwg: Gross Electrical Output (MW) = 540

Example>**exair_airheater**

Exair_airhea: Leakage in Air Preheater (fraction) = 0.19

Example>**exair_airboiler**

Response when a variable is incorrectly typed.

?

Undefined name

Example>**exair_boiler**

Exair_boiler: Excess Air at Boiler (fraction) = 0.2

Example>**hrsteam**

Hrsteam : Steam Cycle Heat Rate (Btu/kWh) = 7800

Example>**cf**

Cf : Capacity factor (fraction) = 0.65

Example>show airemissions

Model Airemissions

Description: model containing the input parameters for the ambient air,~
emission constraints, and emission factors for furnace

Contains: [Variable Tai_air, Variable Pai_air, Variable Humdt, Variable
Noxef, Variable Fao, Variable So2ashret, Variable Fso, Variable Fracco,
Variable Cinrefuse, Variable Fracc, Variable Fracso2, Variable Fracno,
Variable Emissconsso2, Variable Emissconsnox, Variable Emissconsash, Index
Air_emislabe, Variable Airemisinput, Index Airvalue]

Author: js04

Needs: [Model Coal_char]

Example>humdt

Humdt : Specific Humidity Ratio (fraction) = 0.018

Example>emissconsso2

Emissconsso2 : Emission Constraint SO2 (lb/MBtu) = 0.06

Example>coalchar_tab

*Input table with coal characteristics, which is in the model,
Coalinputs. Since Coalchar_tab depends upon the arrays,
Coalindex and Coalchar_ind, those arrays are displayed, when
its name is typed. To get its value type mid coalchar_tab.*

Coalchar_tab: Input Coal Characteristics
Table(Coalindex, Coalchar_ind)

Example>mid coalchar_tab *This shows the ultimate analysis of the coal.*

Coalchar_ind	HHV,	Carbon,	Hydrogen,	Oxygen,	Sulfur,
Nitrogen,	Ash,	Moisture			
Coalindex					
1 [	13.1K,	0.734,	0.043,	0.033,	0.017,
0.013,	0.155,	5m]	<i>Demos uses suffixes to denote scientific notation. For example, the suffix m stands for 10⁻³.</i>		

Example>raw_coal_cst

Raw_coal_cst: raw coal cost (\$/wet ton) = Table(Cost_yr)

Example>mid raw_coal_cst

Cost_yr		1988
	[	36.16]

Example>ctrans

Ctrans : Transportation Cost (\$/wet ton) = Table(Cost_yr)

Example>mid ctrans

Cost_yr		1988
	[	2.156]

Changing the value of input parameters is easy. The example below shows how to change the gross capacity to 600 MWg, the steam cycle heat rate to 8,000 Btu/kWh, and the capacity factor to 75%. The IECM uses the range checking feature built into Demos for all input parameters and some intermediate variables. This allows the IECM to catch many typographical errors and other mistakes. The example below shows the result of entering 6000 instead of 600 for the variable, Mwg. Note that Demos does not issue warning until either the value of the variable is requested or Demos evaluates a variable which depends upon Mwg.

Example>mwg:6000

The fact that Demos did not complain about the value entered does not mean that the value is okay. It just indicates that the syntax for the definition is okay.

This shows the type of warning Demos issues for range check errors. For the question, below just hit a return. Notice that Demos, prints out the variable and its attributes.

Example>mwg

Mwg : Gross electrical output (MW)

? Warning:

Variable Mwg fails to satisfy Check : ((250<=Mwg) AND (Mwg<= 1000))

Would you like to stop to try and fix the problem? [Yes]:

Variable Mwg

Title: Gross electrical output

Units: MW

Description: gross electrical output of generator not including ~
auxiliary power requirements.

Definition: 6000

Check: 250 <= mwg and mwg <= 1000

The line above is the source code that checks that mwg is between 250 and 1000 MW. Any variable can have a Check attribute.

Example>mvg:600

Example>hrsteam:8000

Example>cf:0.75

Changing the equation for variables is a little more complicated. It is demonstrated in Section 2.8; however, it should only be done after a person has a good understanding of the IECM structure and Demos.

There are several variables in the IECM which describe the technologies which are used for SO₂, NO_x, TSP, and coalcleaning. These are So2config, Noxconfig, Tspconfig, and Ccconfig, and are in the model Configuration. By typing their names, it is possible to see which technologies have been loaded into the IECM. The value of these parameters should not be changed by the user, since they are used by the other models to set options.

Example>so2config

So2config : SO2 Control Technology = wetfgd

Example>noxconfig

Noxconfig : NOx Control Technology = scr

Example>tspconfig

Tspconfig : Tsp Control Technology = esp

Example>ccconfig

Ccconfig : Coal Cleaning Technology = none

There are also several decision variables which use character strings. They are used to control the type of firing in the furnace, Furnacectl; the cooling system, Coolctl; the type of waste disposal, Disposal; whether the flyash is mixed with the FGD sludge, Mixedctl; and to control the probability distribution functions, Ctl_global. These variables are found in the model, Basecontrols. The individual technologies may also use their own decision variables to set technology specific options. For example, the model

Wetfgd uses the variable, Bpsopt (ByPaSs OPTions), to control the bypass around the FGD. To determine the valid options for these variables use the Show command. Also note that character strings are case sensitive. A complete listing appears in Appendix A.

```

Example>furnacectl
Furnacectl   : Furnace Firing Type                =      wall

Example>coolctl
Coolctl      : Cooling System Option              =      tower

Example>disposal
Disposal     : Disposal Option Chosen              =      landfill

Example>show disposal
Decision Disposal
Title: Disposal Option Chosen
Description: Waste Disposal control variable, valid values are 'ponding'~
             or 'landfill'
Definition: 'landfill'  Note that the single quotes are required.
check: if so2config = 'so2config' or so2config = 'base' then ~
      (disposal = 'ponding' or disposal = 'landfill') else ~
      (disposal = 'landfill')

Example>mixedctl
Mixedctl     : Flyash Mixing Control                =      yes

Example>ctl_global
Ctl_global   : Uncertainty Control Parameter        =      alloff

Example>bpsopt
Bpsopt       : Bypass Option Chosen                 =      no bypass

```

Furnacetype has three valid settings, 'wall', 'tangential', and 'cyclone'. Coolctl has three valid settings, 'tower', 'once through', and 'lake'. Disposal has two settings: 'landfill' and 'ponding'; however, it should be set to 'landfill' unless So2Config equals 'base' or 'wetfgd.' In these cases, it can be set to either value. Mixedctl can either equal 'yes' or 'no'. Ctl_global has three possible settings: 'alloff', 'allon', and 'on'. 'alloff' makes the analysis deterministic by setting all the uncertainty variables equal to 1. 'allon' makes the analysis probabilistic by setting all the uncertainty variables equal to their probabilistic distributions. 'on' allows the user to control the uncertainty variables by module. This will be explained more in Section 3.2.3. Bpsopt controls has two possible values 'bypass' and 'no bypass'.

2.4 Specifying Vectors and Tables

One of Demos's unique features are vectors and tables. This feature allows related data to be organized as one variable and for tables to be created to display results. There are several key vectors and tables in the IECM and all of them are listed in Appendix A. The most important vectors are described below.

Coalchar_table is the input table which contains the ultimate analysis data for the coal being used. It is created with two vectors, Coalindex and Coalchar_index. Coalchar_index can be visualized to be the labels of the columns in coalchar_table, while Coalindex are the labels for the rows. Coalchar_index is a vector of character strings, which corresponds to the ultimate analysis. Coalchar_index equals ['HHV','Carbon','Hydrogen','Oxygen','Sulfur','Nitrogen','Ash','Moisture']. The definition of Coalchar_index should not be changed since many variables depend upon its current definition. Coalindex is a sequence

of numbers from 1 to the number of rows in Coalchar_table. If there is one row in Coalchar_table, then Coalindex equals [1]. If there are two rows in Coalchar_table, then Coalindex equals [1 2]. When Coalchar_table has more than one row, it indicates that the coal has been washed with the Fortran coal cleaning program. The first row is always the raw coal, while the other rows contain the characteristics of the coal washed to various levels. The variable, Coals, is used to chose the set of data for analysis from Coalchar_table, by setting it equal to the row that you want. Currently Coals equals 1.

Any coal can be specified by the user by entering the ultimate analysis data into Coalchar_table; however, several coals are provided in files in the directory lec. The coal files have the extension "coal." More details about coalchar_table and how to use coal cleaning are in Section 2.7 and Chapter 4.

Example>**show coalindex**

Index Coalindex

Description: Index for the table coalchar_tab. Defined by Fortran coal ~ cleaning model if the conventional coal cleaning model is used.

Definition: [1]

Example>**show coalchar_index**

Index Coalchar_index

Description: Index of coal characteristics table

Definition: ['HHV', 'Carbon', 'Hydrogen', 'Oxygen', 'Sulfur', 'Nitrogen', '~ 'Ash', 'Moisture']

check: coalchar_index = array(coalchar_index, ['HHV', 'Carbon', 'Hydrogen', '~ 'Oxygen', 'Sulfur', 'Nitrogen', 'Ash', 'Moisture'])

Example>**show coalchar_table**

Variable Coalchar_table

Description: Table containing all the coal characteristics to be used

Definition: table(Coalindex, Coalchar_Index) (
13140. .7341 .0427 .0331 .0170 .0128 .1552 .0050
)

Example>**coals**

Coals : Coals chosen = 1

The vector, Cost_yr, is used to set the year in which costs are reported. It can vary between [1977] and [1989]. Since economic algorithms were developed from sources which assumed different year dollars, Cost_yr is used to scale costs for each module to a consistent mid-year using the Chemical Engineering cost indices. Changing Cost_yr to another year causes all of the economic costs to be scaled accordingly. Cost_yr is not restricted to integer values. If Cost_yr equaled 1987.5, it would be equivalent to December 1987 or January 1988 dollars. It also should be noted that almost all of the economic variables depend on Cost_yr.

Example>**cost_yr**

Cost_yr : Years Dollars Reported
[1988]

Comment: 1988 is the current default year for reporting costs.

Example>**tdcscr**

Tdcscr : Scr Total Direct Cost (M \$) = Table(Cost_yr)

Example>**mid tdcscr**

Cost_yr ~ 1988
[12.63]

Example>**cost_yr: [1989]** Changes Cost_yr to 1989. The "[]" are important.

Example>mid tdcscr

Cost_yr	1989
[	13.28]

Each module has two or more summary tables. Tables which have the suffix, "inputs," after the module name show the input assumptions for that module. Tables which have the suffix, "char," show the important performance characteristics that are calculated by the model. Those tables which have the suffix, "econchar," show the economic variables which are calculated. A complete list of these tables can be found in Appendix A. These tables are used for display purposes only and depend upon other variables in the model. Partial listings of three tables for the plant module are shown below for illustration. For these tables, the Mid command is needed to display them.

Example>mid plantinputs

Partial list of input values for power plant module.

Pltvalue	value
Pltinputlabe	
Gross Capacity, MW	[600]
Steam HR, Btu/kWh	[8000]
Capacity Factor, %	[75]
Excess Air Boiler, %	[20]
Inlet Air Leakage, %	[19]
Economizer Temp, R	[1160]
Air Heater Temp, R	[760]
Pulverizer Elect, %	[0.6]
Steam Pump Elect, %	[0.65]
Fan Elect, %	[3.15]
Cooling Elect, %	[1.8]
Misc. Elect, %	[1.3]
Misc Loss Boiler, %	[0.5]

Example>mid plantchar

Partial list of performance parameters for power plant module.

Plant_param	Value
Plant_index	
Boiler Efficiency, %	[90.08]
Cycle HR, Btu/kWh	[8881]
Coal Usage, tons/hr	[202.8]
Coal Credit, ton/hr	[0]
Energy Credit, MW	[0]
Adj Gross Cap, MW	[555]
Net Capacity, MW	[528.]
Net HR, Btu/kWh	[10.1K]
Annual Oper Hours	[6575]
Net Elec Gen, MWh/yr	[3.47M]

The summary of plant economic characteristics shown below represents results of an analysis in which many other model parameters not shown here also have been set. In particular, this analysis reports all costs in constant dollars from which effects of inflation are removed. (Had we used levelized costs in nominal dollars many of the numbers would be much higher.)

Example>mid planteconchar *Partial list of economic parameters for base power plant module, excluding pollution control systems*

Cost_yr	=	1989
Bpecon_param		Value
Bp_econ_ind		
Total Direct Cost M\$ [		382.5]
Indirect Costs, % [		50]
Tot Capital Cost, M\$ [		573.8]
Total O&M Cost, M\$ [		73.03]
Revenue w/o Util, M\$ [		132.4]
Utility Cost, M\$ [		-6.44]
Total Revenue, M\$ [		125.9]
Total Rev, mill's/kWh [		36.27]
Capital Cost, \$/kW [		1087]

Final_cost is the main table used for deterministic analyses. Each row represents a different process. If there are zeros in a row, this indicates that the module was not loaded. The columns represent the total direct capital cost (TDC) in millions of dollars (M\$), the total capital cost (TCC) in M\$, the non-utility O&M cost (O&M) in M\$, the utility cost (UTIL) in M\$, the total revenue requirement (TRR) in \$M, the total revenue requirement (ELECT) in mills/kWh, and finally the the total capital cost (TCC) in \$/kW for all the processes.

Example>tabwidth:7 *Sets the character width of columns for tables, so that Final_cost fits on the screen neatly.*

Example>mid final_cost *This is the main summary table for the economics.*

Cost_yr =	1989						
Costs	TDC,	TCC,	O&M,	UTIL,	TRR,	\$/MWH,	\$/kW
Process							
Base Pl [	382.5,	573.8,	73.03,	-6.44,	125.9,	36.27,	1087]
LIMB [	0,	0,	0,	0,	0,	0,	0]
SCR [	13.28,	37.49,	7.356,	1.028,	12.26,	3.531,	71.1]
Spray D [	0,	0,	0,	0,	0,	0,	0]
Ebeam [	0,	0,	0,	0,	0,	0,	0]
Cuo [	0,	0,	0,	0,	0,	0,	0]
Noxso [	0,	0,	0,	0,	0,	0,	0]
Cold Es [	24.49,	34.69,	0.13,	0.491,	4.208,	1.212,	65.7]
Fabric [	0,	0,	0,	0,	0,	0,	0]
Wet FGD [	52.17,	95.91,	9.378,	4.918,	24.21,	6.974,	181.6]
Solid W [	10.51,	17.21,	2.449,	0,	4.228,	1.218,	32.59]
Total [	483.,	759.1,	92.35,	0,	170.8,	49.21,	1438]

2.5 Typical Demos Commands

The examples so far showed some of the basic input and output operations of IECM. To fully utilize the model, however, user experience with Demos commands is required. (In future model developments we hope to implement a menu-based system that will minimize the need for Demos expertise; but for now it's necessary.) Some of the most common Demos commands needed to get and display results are described and demonstrated below. They are described in more detail in the Demos Manual [1], along with other useful commands the user should become familiar with.

Bye Used to exit Demos. This command will be demonstrated at the end of the tutorial.

Clock Gives current time, date, and memory usage. The maximum heapsize depends on the available memory, and can be set with the system variable heapsize. On workstations with a 16 Megabyte swap space, the maximum that the heapsize should be set to is 12 Megabytes. As the memory usage approaches this limit, Demos will

print out warnings. In the Macintosh version, the heapsize variable is set at startup by Demos and it cannot be changed while running Demos. Also, on the Macintosh version the amount of memory available is also displayed.

Help	For on-line Help about Demos.
Mid	Display the deterministic value of a variable regardless of the verbosity setting. This is useful for displaying tables, and has already been demonstrated.
Photo	Records everything displayed on the screen (except graphs) to a file. See the next section on graphing for creating files of graphs. Endphoto stops a photo session, while pausephoto and resumepphoto are used to pause and continue photo sessions.
Quit	Used to exit Demos. Only available on the Macintosh version.
Save	Saves the local variables in the current model into a file.
Show	Display all the attributes of a variable.
Update	Allows variable definitions to be overwritten when files are being read. This mode is turned off with the command Endupdate. The commands, Update and Endupdate, are used at the beginning and end of all source code files. It lets the new models redefine variables that have already been loaded by previous files. If Update was not used, an error would occur for every variable in the file, stating the variables are already defined. Demos would then ask for a new name for each variable.
Verbosity	Used to control the amount of feedback that Demos prints to the screen. The most common verbosity settings are 1, 2, and 3. When verbosity equals 1 it, prints various messages about the status of variables after files are read and when variables are being evaluated. This can be very useful for tracking down errors in files, but it is tedious for large models like the IECM. Another feature of verbosity equal to 1 is that the numeric value of variables is always displayed. When verbosity equals 2 (the default), Demos prompts for undeclared variables when variables are created in Demos, and array dependencies are displayed instead of numeric values. Setting verbosity to 3, cause the combined effects of 1 and 2. This was set to 2 in the "loading" files to prevent Demos from printing the status of every variable in the IECM to the screen. In general, it is recommended that verbosity be set to 2.
Why	Display the variable definition, its inputs, and the values of the inputs. If verbosity equals 1, the numeric values of the definitions will be displayed. If verbosity equals 2, the array dependencies are displayed.

Example>clock

Mon May 11 15:49:36

cpu	totalcpu
32.8660	32.8660

The following appears on the Unix version. Heapused should be less than maxheap.

walltime	totalwalltime	heapused	maxheap
5:49:36	5:49:36	2.0000M	8.0000M

The following appears on the Macintosh version. Free Memory is the amount of memory available and should be greater than 20K.

Mon, May 11, 1989 3:49 PM

Heap Used	Max Heap	Free Mem
1.073M	1.5296M	458.28K

Example>help

HELP:

The help text is organized hierarchically with Topics, subtopics, etc, corresponding to the Chapters, Sections and Subsections in the Users' Manual. After asking for Help on a Topic, it will print a list of its subtopics. From these you can choose one, none, all or any unlisted topic. Words that are capitalized (e.g. Kind, Topic, Session) in this text are Topics (or subtopics) with Help available for them.

Help prints this text on how to get help.
 Help ? prints a list of the main Help Topics.
 Help t prints help text for the Topic t or lists its subtopics.
 Help Topics Describes the main Help Topics.
 Help Intro prints some introductory information for new users.
 List k lists all the existing Objects of the given Kind k.
 MoreHelp continues printing Help text where it last left off.

Example>help ?

CONTENTS:

Help Topics and some subtopics:

Introduction	Basics	Prompts	Objects	Names
Numbers	Sessions	Special_Chars	Commands	Save
Bye	Variables	Dependencies	Attributes	Files
Photo	Functions	Distributions	Plotting	CDF
Framing	Arrays	Indexes	Sensitivity	Versions
System_Variables	Syntax	Statements	Expressions	Arithmetic

There is Help on (almost) every system-defined Object, Command, Kind, Function, Attribute, SystemVar.

Example>photo

The files example.pho will have a record of this tutorial from this point on, except for any graphs.

Please enter name [example.pho]:

Return key accepts default file name.

Example>save

Each % mark represents ten lines of code.

Please enter name [example.mod]:

Return key accepts default value.

saving ...

Opening example.mod

Since only one variable, Model Wetscresp, is currently in Model Example, Demos only writes a short file stating that it contains the model Wetscresp. Figure 2-7 shows the contents of the file Example.mod.

Closing example.mod
done

Example>show coalinputs

Results of using the Show command on a model.

Model Coalinputs

Description: contains all the variables needed to be defined when the ~ coal is changed

Contains: [Decision Coals, Variable Coalchar_tab, Variable Cc_table, Variable Raw_coal_cst, Variable Ctrans, Variable Clean_cost, Variable Minerbpccost]

Author: js04

Needs: [Model Indices, Model Coal_char]

Figure 2-7: Contents of the File, Example.mod

{ From Demos User js04 , Demos Project EXAMPLE at Fri Apr 14 15:19:43)

{ System Variables with non-default values:}

Model Example

Description: Example on how to use the IECM

Contains: Model Wetscresp

Author: John Salmento

Date: Fri Apr 14 11:02:28

Savedate: Fri Apr 14 15:19:38

Close Example

Example>**show emisconssso2** *Results of using the Show command on a variable.*

Variable Emisconssso2

Units: lb/MBtu

Description: sulfur dioxide emission constraint; ~

describes the Rev. NSPS (1978) emission constraints

Definition: if potemso2 < 2 then 0.3 * potemso2 ~

else if potemso2 >= 2 AND potemso2 < 6 then 0.6 ~

else if potemso2 >= 6 AND potemso2 < 12 then 0.1 * potemso2 ~

else 1.2

Check: 0 <= emisconssso2 and emisconssso2 <= 15

Now let's demonstrate the effect of verbosity. We'll use the Why command to see how a variable depends upon other variables.

Example>**verbosity**

Verbosity : = 2

Example>**why cd**

Cd : cost of as-fired coal (\$/wet ton) = Table(Cost_yr)

Description: cost of delivered coal on a wet ton basis

Cd = Raw_coal_cst + CTrans + Clean_cost + MinerPBcost

Raw_coal_cst: raw coal cost (\$/wet ton) = Table(Cost_yr)

Ctrans : Transportation Cost (\$/wet ton) = Table(Cost_yr)

Clean_cost : Coal Cleaning Cost (\$/wet ton) = 0

Minerpbcost : Miner Benefit Cost (\$/wet ton) = 2

Example>**verb:1**

With verbosity equal to 1 we get the results rather than the general relationships.

Example>**why cd**

Cd : cost of as-fired coal (\$/wet ton) =
Cost_yr 1989
[42.28]

Description: cost of delivered coal on a wet ton basis

Cd = Raw_coal_cst + CTrans + Clean_cost + MinerPBcost

Raw_coal_cst: raw coal cost (\$/wet ton) =
Cost_yr 1989
[38.01]

Ctrans : Transportation Cost (\$/wet ton) =
Cost_yr 1989
[2.267]

Clean_cost : Coal Cleaning Cost (\$/wet ton) = 0

Minerpbcost : Miner Benefit Cost (\$/wet ton) = 2

Example>**verb:2**

2.6 Graphing and Probabilistic Analysis

Graphs and probabilistic analysis are perhaps the most important features of Demos. Using the Andrew windowing environment or the Macintosh allows high resolution graphs to be displayed on the screen easily. The probabilistic features of Demos and the IECM are discussed more in Chapter 3. There are six basic command to understand, which are described below.

Graph Plots the deterministic values of one variable against another.

Ctl_global	This is an IECM decision variable which turns on or off the uncertainty functions in the IECM. It's default value is 'aloff', which only allows the median value of all variables to be evaluated. Setting it to 'allon' turns on all the uncertainties. This variable is describe in more detail in Section 3.2.3.
Samplesize	Number of points used to estimate the pdf and cdf's. Larger samplesizes produces more accurate results, but requires longer computation time and uses more memory. For development work, values around 50 are typically used.
Pdf	Plots the probability distribution function of a variable. Also affected by the sample size.
Cdf	Plots the cumulative function of a variable. The accuracy of this plot is directly related to the variable, samplesize.
Cdfnum	This is a function that is defined in the IECM. It prints a table which produces the numeric values of a cdf at 0%, 5%, 10%, 20%, 30%, 40%, 50%, 60%, 70%, 80%, 90%, 95%, and 100%. This function produces a table for those variables which are depended upon vectors.
Cdfperf	This does the same thing as Cdfnum; however, it produces a table for those variables which do not depend upon vectors.

The graph, cdf, and pdf commands produce their graphs in a separate window on the right side of the screen if the Andrew window manager is used. Figures 2-8, 2-10, and 2-12 show the picture of the screen after each command shown in the example below. The Andrew window manager automatically sizes the windows to take up any available space. The default number of graphs that are displayed on the right side is two. Demos overwrites the oldest graph if more that two graphs are requested. *In the Unix version, do not choose Zap as a menu selection in a graph window. This will cause the Demos program to crash.*

On the Macintosh version, a separate window pops up, which overlaps the current window. These windows can be moved to any place on the screen, or can be resized to any rectangular shape. Figures 2-9, 2-11, and 2-13 show the Macintosh screen after each of the commands below. After each window pops up, move it to a different part of the screen, so that they don't overlap. To close a graph window, click the little box in the upper left hand corner of the window. To get back to the Demos window, click on the Demos window and it will come to the foreground.

Let's do some simple parametric analysis to determine the affects of the plant size on pollution control costs. We've just changed the plant size from a scalar to a scalar.

Example>mwg:[250 300 350 400 450 500 550 600]

The variable, elecpc shows the total revenue requirement in mills/kWh for all the pollution control equipment excluding the effects of coal cleaning if it is used. The text strings enclosed single quotes on the next line produce labels for the Y and X axis, respectively. More details about graphs can be found in reference [1].

Example>graph elecpc mwg 'Pollution Control Cost (Constant 1989\$)'~
Continue:'Gross Electrical Output (MW)'

Each graph produces a separate window. For the following three graphs, the full page screen pictures are shown on the following pages.

Pollution Control Cost (Constant 1989\$)

Example>mwg:600

Example>ctl_global:'allon'

Turns on the probability functions. Selected parameter uncertainties have been assigned as part of the data inputs for this example. Details are discussed later in this report.

Example>samplesize

Sample size :

=

45

Example>pdf elecpc

Probability density

Figure 2-8: Picture of Screen after Graph Elecpc Mwg Command

Figure 2-9: Picture of Screen after Graph Elecpc Mwg Command on the Macintosh

Figure 2-10: Picture of Screen after Pdf Elecpc Command

Figure 2-11: Picture of Screen after Pdf Elecpc Command on the Macintosh

Example>cdf elecpc

Cumulative probability

Example>cdfnum(elecpc) *Since this is a probabilistic analysis, the exact values may not appear when you run the this tutorial.*

Cost_yr	1989
Cipct	
0%	[9.324]
5%	[10.51]
10%	[10.65]
20%	[11.56]
30%	[12.39]
40%	[12.66]
50%	[13.21]
60%	[13.47]
70%	[13.77]
80%	[14.51]
90%	[14.74]
95%	[16.37]
100%	[26.4]

Example>cdfperf(wet_cap) *Cdfperf or cdfnum do not have to follow a cdf command.*

Cdf_param	Value
Cipct	
0%	[9.105]
5%	[9.323]
10%	[9.404]
20%	[9.5]
30%	[9.58]
40%	[9.64]
50%	[9.71]
60%	[9.76]
70%	[9.82]
80%	[9.9]
90%	[10.]
95%	[10.08]
100%	[10.31]

Example>ctl_global:'alloff' *This turns off all the probabilistic functions.*

104

2.7 Changing Coals and Coal Cleaning

To change coals, six variables have to be redefined: Raw_coal_cst, Ctrans, Coalchar_table, Cc_table, coals, and coalindex. These are described below.

Raw_coal_cst	Cost of raw coal in current dollars per wet ton. The actual numeric value can be in any year's dollars as long as the definition also multiplies it by cost_index and divides it by the appropriate index for that year.
Ctrans	Transportation cost in current dollars per wet ton. It is also scaled by the cost index relative to the year initially specified.
CoalChar_table	The coal characteristics table. It requires at least one row of values. The default configuration is to have the first row represent a raw coal, and the other rows represent various levels of coal cleaning. (The coal cleaning module is described in more detail in Chapter 4.) Each column represents different coal characteristic: higher heating value (Btu/lb), carbon fraction, hydrogen fraction, oxygen fraction, sulfur fraction, nitrogen fraction, ash fraction, and moisture fraction.
Cc_table	The coal cleaning plant performance table. It contains information about the coal cleaning level, mass yield of the plant excluding the thermal driers, thermal drier yield, the fraction of cleaned coal dried, the amount of moisture evaporated, the moisture content of the refuse coal, the fraction of coal that was cleaned with froth flotation, and the retention time in the flotation cells. It has to have as many rows as CoalChar_table. The first row is for the raw coal, so all the values are zero, except for the mass yield of the plant and thermal drier.
Coals	This variable chooses the coal characteristics from the table Coalchar_table for the current run. The values of the elements can not exceed the total number of rows in coalindex. Usually this value is set to 1, (ie., the raw coal).
Coalindex	The index used in construction of the table Coalchar_table. It has to be a vector from [1] to the number of rows in Coalchar_table. For example, if Coalchar_table has five rows, then coalindex would be defined as [1, 2, 3, 4, 5].

There are several ways of changing these characteristics (see the the Demos Manual [1]). The easiest way is to create a file with all the changes in it and load it with the read command. The file, epri.coal in the current directory can be used as an example. This file can be loaded at any time; the new output results can be displayed by just retyping variable names.

Example>pausephoto *If a file is read into Demos while photo is on the contents of the file appears in the photo file, so it is better to pause photo.*

```
Example>read epri.coal
##
The definitions of all Variables and Functions are OK
```

Example>resumephoto

```
Example>coalindex
Coalindex      :                               = [                1]
```

```
Example>show coalchar_table
Variable Coalchar_tab
Title: Input Coal Characteristics
Description: Illinois No 6. from Epri "Technical Assessment Guide"
Definition: Table(Coalindex,Coalchar_index)(
10100. .575 .037 .058 .04 .009 .16 12
)
```

```
Example>mid raw_coal_cst
Cost_yr      1989
      [ 33.74]
```

```
Example>mid ctrans
Cost_yr      1989
      [ 3.748]
```

Example>coals:2 *An example of the error when Coals is set incorrectly.*

Example>hhv *Hhv is the variable which extracts the higher heating value for the coal chosen by Coals out of Coalchar_tab.*

Hhv : Higher Heating Value (btu/lb)
? Warning: *This first warning is telling you that coals is incorrectly defined. Type a return or yes for the question below.*

```
Decision Coals fails to satisfy Check: ((1<=Coals) AND (Coals<=
Max(Coalindex)))
Would you like to stop to try and fix the problem? [Yes]:
Decision Coals
Title: Coals chosen
Description: Coal being used by model
Definition: 2
Check: 1 <= coals and coals <= max(coalindex)
```

This error occurs since Demos is still trying to evaluate Hhv.

```
Argument number 1 of SysFunction Subscript must be a number or an array.
Error during evaluation of Hhv
Definition of Hhv is: if CCconfig = 'conventional' OR CCconfig = 'none' ~
    then coalchar[Coalchar_index = 'HHV'] ~
    else if CCconfig = 'hgms' then Hhv_hgms ~
    else if CCconfig = 'coal pyrite' then HHVclean ~
    else -1
```

Since this problem is caused by coals being incorrectly defined, type no to all the questions that ask if you want to redefine other variables. This error can be fixed by redefining Coals to 1. On the Macintosh version the questions that Demos asks below appear in little windows. Just click on the no button.

```
Do you want to (re)define it? [Yes]: no
? Warning:
Attribute unusable
```

Example>coals:1

An important point to remember is that the photo session will turn off after this type of error, so it is important to check it. The following warning indicates that photo has stopped. Since we are about to read in another file, we are not going to restart photo.

```
Example>pausephoto
? Warning: Photo not on.
```

Changing coals or coal cleaning module characteristics is similar as far as Demos is concerned. Both steps require defining the same six variables listed above; however, coal cleaning also requires working with the Fortran coal cleaning model and the Demos coal cleaning module. Because of some of the limitations of Demos, only the economic part of the coal cleaning model is written in Demos. The performance part of the coal cleaning model is in Fortran and is described in more detail in Chapter 4. The economic module is in the file, "srcpetc/coalclean.petc." It can be loaded at any time, as any other

module. It has its own input parameters and summary tables; however, all the input parameters are entered from a data file created by the Fortran model.

Running the coal cleaning module is thus a three step operation. First, the Fortran model is run, which creates a data file with all the input parameters for the economic module in Demos. Then the file created by the Fortran model is loaded into Demos. Finally, the coal cleaning economy module is loaded. Once the module is loaded various levels of coal cleaning are selected by setting the vector Coals to a new value. All the effects of cleaning the coal are correctly passed on to the rest of the IECM.

Washed coal data files from the Fortran module identical to other coal characteristic files except that they contain another input table, cc_table. Cc_table contains the coal cleaning plant's performance information, which is needed by the Demos coal cleaning module to calculate washed coal prices. There is one row in Cc_table for every row in coalchar_table. Each row represents a different washed coal. For the example, it is assumed that the Fortran model was run to create the file lec.coal. The contents of the file are shown in Figure 2-14. The text in italics on the right side of the page explains each variable or command. A more detailed explanation of the variables and their definitions is described in Chapter 4. The next steps are as follows:

Example>read lec.coal

###

The definitions of all Variables and Functions are OK

Example>read srcpetc/coalclean.petc

Loads the coal cleaning module.

#####

The definitions of all Variables and Functions are OK

Example>photo

Let's restart photo. Type no to the first question and yes to the second question.

example.pho: File already exists. Do you wish to replace it?

[Type Y or N]: no

File already exists. Do you wish to append to it? [Type Y or N]: yes

Example>coals:2

This picks the 2nd row of coal characteristics which corresponds to a 10% sulfur reduction by washing.

Example>tabwidth:20

Example>mid coalsummary

Coalsummary is a command which creates a table of the coal characteristics being used. For example, since Coals equals 2 the second row from Coalchar_table is chosen. The difference between Coalchar_table and Coalsummary is that Coalchar_table contains the information for all the washed coals, while Coalsummary contains only the information chosen with Coals.

Coalparamete	Value
Coalchar_ind	
HHV [	10.4K]
Carbon [	57.84]
Hydrogen [	3.83]
Oxygen [	7.66]
Sulfur [	3.98]
Nitrogen [	1.14]
Ash [	12.41]
Moisture [	13.14]

Figure 2-14: Contents of iec.coal File Created by the Fortran Coal Cleaning Program.

```

Update                                     This is to allow the variables defined in this file to overwrite
                                           the same variables currently loaded into Demos.
Model Ieccoal                             This defines the model name.

                                           The line below is the cost of raw coal adjusted by the cost_index and the
                                           moisture content.
Raw_coal_cst: 29.0000 * Cost_Index / 325.3 * (1 - H2ofrac)/(1 - h2ofr)

Coals: 1                                  This redefines coals to 1, to prevent potential errors from
                                           occuring, since coals could have equaled a value greater than 13 before
                                           this file was read.

                                           This indicates that there are 12 different washed coals to consider,
                                           plus the unwashed coal.
CoalIndex: Sequence(1, 13)

Coalchar_table: Table(Coalindex,Coalchar_Index) (
10194. .5695 .0370 .0719 .0436 .0112 .1438 .123
10354. .5784 .0383 .0766 .0398 .0114 .1241 .1314
10130. .5659 .0375 .0750 .0390 .0112 .1246 .1469
10293. .5750 .0388 .0798 .0352 .0113 .1045 .1553
10565. .5902 .0406 .0857 .0316 .0116 .0839 .1564
10385. .5802 .0384 .0768 .0400 .0114 .1281 .1250
10539. .5888 .0397 .0817 .0361 .0116 .1081 .1340
10838. .6055 .0416 .0879 .0324 .0119 .0868 .1338
11181. .6247 .0438 .0947 .0287 .0123 .0620 .1339
10352. .5783 .0383 .0766 .0398 .0114 .1276 .1280
10614. .5929 .0400 .0823 .0363 .0117 .1088 .1280
10914. .6097 .0419 .0885 .0327 .0120 .0871 .1280
11267. .6294 .0441 .0954 .0289 .0124 .0618 .1280
)

CC_table: Table(Coalindex,CC_Index) (
0 1.0000 1.0000 0.0000 0.0000 0.0000 0.0000 0.000
2 0.9634 1.0000 0.0000 0.0000 0.1380 0.0000 0.000
3 0.9699 1.0000 0.0000 0.0000 0.1880 0.0000 0.000
3 0.9320 1.0000 0.0000 0.0000 0.1694 0.0000 0.000
3 0.8751 1.0000 0.0000 0.0000 0.1558 0.0000 0.000
4 0.9703 0.9822 0.4124 0.1007 0.2031 0.0000 0.000
4 0.9338 0.9826 0.4093 0.1014 0.1816 0.0000 0.000
4 0.8856 0.9826 0.4316 0.1014 0.1638 0.0000 0.000
4 0.6943 0.9828 0.4126 0.1045 0.1654 0.0000 0.000
5 0.9722 0.9931 1.0000 0.0379 0.2008 0.0608 2.000
5 0.9357 0.9912 1.0000 0.0495 0.1805 0.0608 2.000
5 0.8882 0.9912 1.0000 0.0512 0.1645 0.0608 1.500
5 0.6996 0.9917 1.0000 0.0500 0.1669 0.0608 1.071
)

Variable MIBC                             MIBC usage for froth flotation circuit.
Units: lb/ton
Definition: 0.15

Variable Oil2                             #2 oil usage for froth flotation circuit.
Units: lb/ton
Definition: 0.15
Close ieccoal
endupdate

```

These are the properties of the raw coal and 12 washed levels.

The 12 washed coals correspond to several sulfur reduction levels for each of four prep plant configurations.

Example>mid ccsummary

Ccsummary is similar to Coalsummary, except that it contains the performance information of the coal cleaning plant for the coal chosen. The difference between Cc_table and Ccsummary is that Cc_table contains the information for all the washed coals, while Ccsummary contains only the information chosen by Coals.

Ccparameter	Value
Cc_index	
Cleaning Plant Level	[2]
Washer Mass Yield	[0.963]
Thermal Drier Yield	[1]
Coal Frac. to Drier	[0]
Moisture Evaporated	[0]
Moisture in Refuse	[0.138]
Coal Frac. to Flotat	[0]
Time in Flot. Cells	[0]

Example>tabwidth:6

Now let's determine which coal cleaning levels produce the lowest pollution control cost for a given % sulfur reduction. First, select all the coals from Coalchar_table.

Example>coalindex

The variable Coals can have more than one value. Coalindex shows all the valid values for the Coals.

Coalindex	:	=
[1, 2, 3, 4, 5, 6,		
7, 8, 9, 10, 11, 12, 13]		

Example>coals:sequence(1,13)

This chooses every washed coal for analysis, and changes Coals from a scalar to a vector.

Example>round(sulfur_red)

This variable shows the sulfur reduction on an energy basis achieved by the coal cleaning plant for the washed coals. The function round is used to make to output neater. There are duplicate levels of sulfur reductions because different coal cleaning plant configurations were used to wash the coal. The data are not formatted as in the tables above, though this could easily be done with other Demos commands.

Coals	1,	2,	3,	4,	5,	6,	7,	8,	9,
10, 11,	12,	13							
[0,	10,	10,	20,	30,	10,	20,	30,	40,	
10, 20,	30,	40]							

Example>mid clean_cost

This shows the coal cleaning cost in dollars per wet ton for each coal selected.

Cost_yr	1989
Coals	
1 [	0]
2 [	3.228]
3 [	3.544]
4 [	5.049]
5 [	7.568]
6 [	5.025]
7 [	6.475]
8 [	8.652]
9 [	19.98]
10 [	4.854]
11 [	6.492]
12 [	8.607]
13 [	19.66]

Example>mid elecpcc

Now let's see which value of coal produces the lowest pollution control cost. Elecpccc is similar to Elecpc, except that it includes the effects of coal cleaning. The only requirement is that the variable Coals be a vector which includes 1. As can be seen, the raw coal has the lowest Cost. Results for this case show that pollution control cost savings at the power plant are not sufficient to offset the higher cost of cleaned coal, so that the unwashed coal is most economical for this situation.

Cost_yr
Coals

1989

1	[	16.1]
2	[	17.]
3	[	17.73]
4	[	17.72]
5	[	17.94]
6	[	17.83]
7	[	17.81]
8	[	17.77]
9	[	21.85]
10	[	17.82]
11	[	17.63]
12	[	17.57]
13	[	21.45]

2.8 Redefining Variables

Redefining variables is fairly easy to do; it is similar to changing the value of input parameters. These changes do not get saved to a file until the model is saved. Since Demos is non procedural, the new definitions' values will be propagated through the IECM correctly. The example below shows how to redefine variables using two different methods. The first method uses a command called "Whatif," which does not change the definition of a variable. The second method shows how to redefine a variable. It also shows some common problems with summary tables when variables are redefined. Remember that none of these methods will change the source files until the model is saved.

Example>coals:2

Example>show xwet

Variable Xwet

Title: Wet FGD Energy Penalty

Units: fraction

Description: Energy penalty for steam and electricity usage

Definition: $(fgd_reheat * 1K/hrsteam + fgdm * uffgdm) / Mwg$

uffgdm is an uncertainty variable. It is described in section 3.2.3.

Example>xwet

Displays the value of xwet

Xwet : Wet FGD Energy Penalty (fraction) = 0.0411

Example>verb:1

Example>whatif xwet:0.02 *This only changes xwet temporary (to see the effect of reducing the energy use).*

Examine the effect on which Variable? [Xwet]: final_cost

```

Final_cost :
Cost_yr = 1989
Costs
Process
Base Plant [ 382.5, 573.8, 85.1, -8.05, 136.4, 39.58, 1095]
LIMB [ 0, 0, 0, 0, 0, 0, 0]
SCR [ 13.98, 39.49, 7.932, 1.291, 13.31, 3.862, 75.35]
Spray Drye [ 0, 0, 0, 0, 0, 0, 0]
Ebeam [ 0, 0, 0, 0, 0, 0, 0]
CuO [ 0, 0, 0, 0, 0, 0, 0]
Noxso [ 0, 0, 0, 0, 0, 0, 0]
Cold Esp [ 16.51, 23.39, 0.075, 0.344, 2.837, 0.823, 44.63]
Fabric Fil [ 0, 0, 0, 0, 0, 0, 0]
Wet FGD [ 60.8, 111.8, 13.97, 6.416, 31.94, 9.271, 213.2]
Solid Wast [ 17.55, 28.74, 3.104, 0, 6.075, 1.763, 54.84]
Total [ 491.4, 777.2, 110.2, 0, 190.5, 55.3, 1483]
Xwet is OK

```

```

would be changed to
Cost_ = 1989
Costs
Process
Base [382.5,573.8, 85.1,-4.76,139.7,39.58, 1069]
LIMB [ 0, 0, 0, 0, 0, 0, 0]
SCR [13.98,39.49,7.932,1.291,13.31,3.771,73.58]
Spray [ 0, 0, 0, 0, 0, 0, 0]
Ebeam [ 0, 0, 0, 0, 0, 0, 0]
CuO [ 0, 0, 0, 0, 0, 0, 0]
Noxso [ 0, 0, 0, 0, 0, 0, 0]
Cold [16.51,23.39,0.075,0.344,2.837,0.804,43.57]
Fabri [ 0, 0, 0, 0, 0, 0, 0]
Wet F [ 60.8,111.8,13.97,3.123,28.65,8.119,208.2]
Solid [17.55,28.74,3.104, 0,6.075,1.722,53.55]
Total [491.4,777.2,110.2, 0,190.5, 54., 1448]
Xwet is OK

```

Example>tabwidth:20

Example>xwet:[0.03 0.07] *Now let's change xwet to a vector of constants
This is one way of performing traditional sensitivity analysis.*

Example>mid trrwet *Shows the total revenue requirement of the scrubber as
a function of the energy penalty.*

```

Cost_yr
Xwet
1989
0.03 [ 30.21]
0.07 [ 36.46]

```

Weteconchar is a output table of economic characteristics for the wet FGD module. It depends upon the vectors wetecon_param and wet_econ_ind. Since we created a new vector, xwet, Demos will print out a table for each value of xwet.

Example>mid weteconchar

```

Xwet      = 0.03
Cost_yr   = 1989
Wetecon_para
Wet_econ_ind
Value
Material Handling M$ [ 9.56]
Train Cost, M$ [ 51.23]
Direct Capital, M$ [ 60.8]
Engineering Cost, M$ [ 4.256]
Architect Cost, M$ [ 1.216]
Construction Cost M$ [ 9.73]
Contractors Fees, M$ [ 3.04]
Contingencies, M$ [ 7.903]
Total Plant Cost, M$ [ 86.94]
Interest, M$ (curr) [ 8.22]
Total Plant Inv, M$ [ 95.16]
Startup Cost, M$ [ 13.37]
Royalties, M$ [ 0]
Working Capital, M$ [ 3.222]
Total Capital, M$ [ 111.8]
Indirect Cost Factor [ 0.838]
Total Capital, $/kW [ 210.6]
Reagent Cost, M$/yr [ 3.738]
Fixed Operate, M$/yr [ 10.24]
Total O&M Cost M$/yr [ 13.97]
Revenue wo Uti M$/yr [ 25.53]
Utilities, M$/yr [ 4.684]
Total Revenue, M$/yr [ 30.21]
Total Rev, mills/kWh [ 8.659]

```

```

Xwet      = 0.07
Cost_yr   = 1989
Wetecon_para
Wet_econ_ind
Value
Material Handling M$ [ 9.56]
Train Cost, M$ [ 51.23]
Direct Capital, M$ [ 60.8]
Engineering Cost, M$ [ 4.256]
Architect Cost, M$ [ 1.216]
Construction Cost M$ [ 9.73]
Contractors Fees, M$ [ 3.04]
Contingencies, M$ [ 7.903]
Total Plant Cost, M$ [ 86.94]
Interest, M$ (curr) [ 8.22]
Total Plant Inv, M$ [ 95.16]
Startup Cost, M$ [ 13.37]
Royalties, M$ [ 0]
Working Capital, M$ [ 3.222]
Total Capital, M$ [ 111.8]
Indirect Cost Factor [ 0.838]
Total Capital, $/kW [ 220.5]
Reagent Cost, M$/yr [ 3.738]
Fixed Operate, M$/yr [ 10.24]
Total O&M Cost M$/yr [ 13.97]
Revenue wo Uti M$/yr [ 25.53]
Utilities, M$/yr [ 10.93]
Total Revenue, M$/yr [ 36.46]
Total Rev, mills/kWh [ 10.94]

```

Example>weteconchar

It is possible to get Demos to print out the values of Xwet beside each other. We'll use the Reform command to rearrange the order the Demos prints out the arrays. First, let's find out what arrays weteconchar depends upon by typing its name.

Weteconchar :

Table(Xwet, Cost_yr, Wet_econ_ind, Wetecon_para)

(M \$)

=

The Reform command needs the names of the variables after the word, table, in the line above. The Reform command is illustrated below, notice that the variables enclosed in parenthesis are rearranged. The Reform command tells Demos the order in which to print out the arrays of tables. The last item in the list is corresponds to the column labels, while the second to the last column corresponds to the row labels.

Example>reform(weteconchar,[cost_yr,wetecon_param,wet_econ_ind,xwet])

Cost_yr	=	1988	
Coals	=	2	
Xwet		0.03,	0.07
Wet_econ_ind			
Material Handling M\$ [		9.0975,	9.0975]
Train Cost, M\$ [		49.582,	49.582]
Direct Capital, M\$ [		58.68,	58.68]
Engineering Cost, M\$ [		4.1076,	4.1076]
Architect Cost, M\$ [		1.1736,	1.1736]
Construction Cost M\$ [		9.3888,	9.3888]
Contractors Fees, M\$ [		2.934,	2.934]
Contingencies, M\$ [		7.6284,	7.6284]
Total Plant Cost, M\$ [		83.912,	83.912]
Interest, M\$ (curr) [		7.9344,	7.9344]
Total Plant Inv, M\$ [		91.847,	91.847]
Startup Cost, M\$ [		12.91,	12.91]
Royalties, M\$ [		0,	0]
Working Capital, M\$ [		3.11,	3.11]
Total Capital, M\$ [		107.87,	107.87]
Indirect Cost Factor [		0.8382,	0.8382]
Total Capital, \$/kW [		203.25,	212.87]
Reagent Cost, M\$/yr [		3.5559,	3.5559]
Fixed Operate, M\$/yr [		9.738,	9.738]
Total O&M Cost M\$/yr [		13.294,	13.294]
Revenue wo Uti M\$/yr [		24.446,	24.446]
Utilities, M\$/yr [		4.5408,	10.595]
Total Revenue, M\$/yr [		28.986,	35.041]
Total Rev, mills/kWh [		8.3075,	10.518]

Now let's change Xwet back to the original definition.

Example>xwet:(fgd_reheat*1K/hrsteam + fgdm * uffgdm)/Mwg

Example>endphoto

Stopping photo now.

2.9 Exiting and Saving the Model

This section shows how to save and exit Demos. The commands are **save** and **bye**. Save save the whole model into a file. Bye, first ask if you want to save this model, and then exits. These are shown below.

Example>**bye**

Incorporate the changes that you have made
in this session into the current Model? [yes]:**no**

Would you like to save the changes that you have made
in a version file ? [Yes]: **no**

Model Example not saved.

Goodbye js04

**DATE
FILMED**
8/11/92