ENGINEERING CHANGE NOTICE

Page 1 of 21. ECN **659096**Proj.
ECN

2. ECN Category (mark one)		3. Originator's Name, Organization, MSIN, and Telephone No.		4. USQ Required?	5. Date
Supplemental ☐		D. F. Smith, Project Definition, R3-73,		☐ Yes ☒ No	06/27/00
Direct Revision ☒		373-0861			
Change ECN ☐		6. Project Title/No./Work Order No.		7. Bldg./Sys./Fac. No.	8. Approval Designator
Temporary ☐		Functional Analysis for		N/A	N/A
Standby ☐		Double-Shell Tank Subsystems			
Supersedeure ☐		9. Document Numbers Changed by this ECN (includes sheet no. and rev.)		10. Related ECN No(s).	11. Related PO No.
Cancel/Void ☐		HNF-5136, Rev. <u>1</u>			N/A
12a. Modification Work		12b. Work Package No.	12c. Modification Work Completed		12d. Restored to Original Condition (Temp. or Standby ECNs only)
☐ Yes (fill out Blk. 12b)		N/A	N/A		N/A
☒ No (NA Blks. 12b, 12c, 12d)			Design Authority/Cog. Engineer Signature & Date		Design Authority/Cog. Engineer Signature & Date
13a. Description of Change		13b. Design Baseline Document? ☐ Yes ☒ No			
Complete revision of document.					
14a. Justification (mark one)		14b. Justification Details			
Criteria Change ☒		Allocation of functions to 3 additional systems; DST Monitor and Control			
Design Improvement ☐		Subsystem, DST Maintenance and Recovery Subsystem, and the DST Sampling			
Environmental ☐		Subsystem were added. In addition, responses to the detection of various			
Facility Deactivation ☐		off-normal conditions were added to the previous version.			
As-Found ☐					
Facilitate Const. ☐					
Const. Error/Omission ☐					
Design Error/Omission ☐					
15. Distribution (include name, MSIN, and no. of copies)				RELEASE STAMP	
Distribution sheet is attached.					

ENGINEERING CHANGE NOTICE

Page 2 of 2

1. ECN (use no. from pg. 1)

659096

16. Design Verification Required

☐ Yes
☒ No

17. Cost Impact

ENGINEERING

Additional ☐ \$ _____
Savings ☐ \$ _____

CONSTRUCTION

Additional ☐ \$ _____
Savings ☐ \$ _____

18. Schedule Impact (days)

Improvement ☐ _____
Delay ☐ _____

19. Change Impact Review: Indicate the related documents (other than the engineering documents identified on Side 1) that will be affected by the change described in Block 13. Enter the affected document number in Block 20.

SDD/DD	☐	Seismic/Stress Analysis	☐	Tank Calibration Manual	☐
Functional Design Criteria	☐	Stress/Design Report	☐	Health Physics Procedure	☐
Operating Specification	☐	Interface Control Drawing	☐	Spares Multiple Unit Listing	☐
Criticality Specification	☐	Calibration Procedure	☐	Test Procedures/Specification	☐
Conceptual Design Report	☐	Installation Procedure	☐	Component Index	☐
Equipment Spec.	☐	Maintenance Procedure	☐	ASME Coded Item	☐
Const. Spec.	☐	Engineering Procedure	☐	Human Factor Consideration	☐
Procurement Spec.	☐	Operating Instruction	☐	Computer Software	☐
Vendor Information	☐	Operating Procedure	☐	Electric Circuit Schedule	☐
OM Manual	☐	Operational Safety Requirement	☐	ICRS Procedure	☐
FSAR/SAR	☐	IEFD Drawing	☐	Process Control Manual/Plan	☐
Safety Equipment List	☐	Cell Arrangement Drawing	☐	Process Flow Chart	☐
Radiation Work Permit	☐	Essential Material Specification	☐	Purchase Requisition	☐
Environmental Impact Statement	☐	Fac. Proc. Samp. Schedule	☐	Tickler File	☐
Environmental Report	☐	Inspection Plan	☐		☐
Environmental Permit	☐	Inventory Adjustment Request	☐		☐

20. Other Affected Documents: (NOTE: Documents listed below will not be revised by this ECN.) Signatures below indicate that the signing organization has been notified of other affected documents listed below.

Document Number/Revision

Document Number/Revision

Document Number/Revision

21. Approvals

Signature

Date

Signature

Date

Design Authority

Cog. Eng. D. F. Smith

Cog. Mgr. T. J. Conrad

QA

Safety

Environ.

Other R. B. Bafus

D. G. Baide

A. F. Choho

G. P. Duncan

T. G. Goetz

C. E. Grenard

J. W. Hunt

M. W. Leonard

T. C. Oten

S. M. O'toole

Design Agent

PE

QA

Safety

Design

Environ.

Other

J. H. Basmann

F. A. Smith

DEPARTMENT OF ENERGY

Signature or a Control Number that tracks the Approval Signature

ADDITIONAL

DISTRIBUTION SHEET

To:	From:	Page 1 of 1
Distribution	Retrieval Engineering	Date 8/17/00
Project Title/Work Order:		EDT No.
Functional Analysis for Double-Shell Tank Subsystems		ECN No. 659096

Name	MSIN	Text With All Attach.	Text Only	Attach. Appendix Only	EDT/ECN Only
R. R. Bafus	R3-73	X			
D. G. Baide	S5-05	X			
T. M. Blaak	S5-13	X			
A. F. Choho	R3-73	X			
T. J. Conrads (4)	R3-73	4			
G. C. DeWeese	R3-73	X			
G. P. Duncan	R3-72	X			
D. P. Fassett	R3-73	X			
T. G. Goetz	R1-49	X			
C. E. Grenard	R3-73	X			
T. G. Halverson	R2-36	X			
B. J. Hendel	B1-45	X			
G. A. Hofferber	B1-45	X			
J. W. Hunt	R2-12	X			
M. W. Leonard	R3-73	X			
T. C. Oten	R3-83	X			
S. M. O'toole	R2-53	X			
J. H. Rasmussen	R2-12	X			
G. Senentz	R3-73	X			
D. F. Smith (4)	B1-45	4			
E. A. Smith	G3-15	X			

Functional Analysis for Double-Shell Tank Subsystems

Donald F. Smith
TRW Environmental Systems
Richland, WA 99352
U.S. Department of Energy Contract DE-AC06-99RL14047

EDT/ECN: 659096 UC: 2000
Cost Center: 6N100 Charge Code: 106457
B&R Code: EW3130000 Total Pages: 141

Key Words: Double-Shell Tank System DST functions Waste Feed Delivery WFD

Abstract: This analysis identifies the DST Subsystem functions for storing, transferring, receiving, and preparing waste in support of the Waste Feed Delivery mission.

TRADEMARK DISCLAIMER. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof or its contractors or subcontractors.

Printed in the United States of America. To obtain copies of this document, contact: Document Control Services, P.O. Box 950, Mailstop H6-08, Richland WA 99352, Phone (509) 372-2420; Fax (509) 376-4989.

8/21/00
Release Approval Date

Release Stamp

Approved For Public Release

Functional Analysis for Double-Shell Tank Subsystems

Prepared for the U.S. Department of Energy
Assistant Secretary for Environmental Management

CH2MHILL
Hanford Group, Inc.

Richland, Washington

Contractor for the U.S. Department of Energy
Office of River Protection under Contract DE-AC06-99RL14047

Approved for Public Release; Further Dissemination Unlimited

[illegible]

LEGAL DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, nor any of their contractors, subcontractors or their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or any third party's use or the results of such use of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof or its contractors or subcontractors. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

This report has been reproduced from the best available copy.

Available in paper copy and microfiche.

Available electronically at
<http://www.doe.gov/bridge>. Available for a processing fee to the U.S. Department of Energy and its contractors, in paper, from:
U.S. Department of Energy
Office of Scientific and Technical Information
P.O. Box 62
Oak Ridge, TN 37831-0062
phone: 865-576-8401
fax: 865-576-5728
email: reports@adonis.osti.gov(423) 576-8401

Available for sale to the public, in paper, from:
U.S. Department of Commerce
National Technical Information Service
5285 Port Royal Road
Springfield, VA 22161
Phone: 800-553-6847
fax: 703-605-6900
email: orders@ntis.fedworld.gov
online ordering:
<http://www.ntis.gov/ordering.htm>

Functional Analysis for Double-Shell Tank Subsystems

D. F. Smith

Date Published
August 2000

CH2MHILL

Hanford Group, Inc.

P. O. Box 1500
Richland, Washington

Contractor for the U.S. Department of Energy
Office of River Protection under Contract DE-AC06-99RL14047

Approved for Public Release; Further Dissemination Unlimited

CONTENTS

1.0	INTRODUCTION.....	1-1
1.1	BACKGROUND.....	1-1
1.2	PURPOSE AND SCOPE	1-2
1.3	DOCUMENT ORGANIZATION.....	1-2
2.0	FUNCTIONAL ANALYSIS	2-1
2.1	STORE WASTE FUNCTIONAL DECOMPOSITION	2-5
2.1.1	Third-Tier Store Waste Flows.....	2-5
2.1.2	Double-Shell Tank Store Waste Function Hierarchy.....	2-6
2.1.3	Third-Tier Function Definitions.....	2-6
2.1.4	Fourth-Tier Function Definitions	2-9
2.2	TRANSFER WASTE FUNCTIONAL DECOMPOSITION	2-36
2.2.1	Third-Tier Transfer Waste Flows.....	2-37
2.2.2	Double-Shell Tank Transfer Waste Function Hierarchy.....	2-37
2.2.3	Third-Tier Function Definitions.....	2-38
2.2.4	Fourth-Tier Function Definitions	2-41
2.3	PREPARE WASTE FUNCTIONAL DECOMPOSITION	2-78
2.3.1	Third- and Lower-Tier Prepare Double-Shell Tank Waste Functional Flows	2-78
2.3.2	Double-Shell Tank Prepare Waste Functional Hierarchy	2-79
2.3.3	Third- and Lower-Tier Function Definitions	2-79
2.4	DISTRIBUTE DOUBLE-SHELL TANK UTILITIES FUNCTIONAL DECOMPOSITION	2-102
2.4.1	Distribute Utilities Function Flows	2-102
2.4.2	Double-Shell Tank Distribute Utilities Function Hierarchy	2-102
2.4.3	Definitions for Distribute Utilities Within the Double-Shell Tank System	2-102
2.5	SUPPORT DOUBLE-SHELL TANK SYSTEM FUNCTIONAL DECOMPOSITION	2-106
2.5.1	Support System Function Flows	2-106
2.5.2	Support Double-Shell Tank System Function Hierarchy.....	2-106
2.5.3	Evaluate Equipment Status.....	2-106
2.5.4	Manage Spares	2-107
2.5.5	Supply Tooling.....	2-108
2.5.6	Perform Preventive Maintenance	2-108
2.5.7	Perform Corrective Maintenance	2-108
2.5.8	Remove Leaked Waste from Secondary Containment	2-108
2.5.9	Provide Auxiliary DST Ventilation.....	2-109
2.5.10	Adjust Chemical Composition	2-109
3.0	ALLOCATION OF FUNCTIONS TO DOUBLE-SHELL TANK COMPONENTS.....	3-1
4.0	REFERENCES.....	4-1

LIST OF FIGURES

Figure 2.0.	Double-Shell Tank System Functional Flow Block Diagram.....	2-3
Figure 2.1.1-1.	Double-Shell Tank Third-Tier Functional Flows for Store Waste.	2-19
Figure 2.1.1-2.	Double-Shell Tank Functional Flow, Control Double-Shell Tank Waste Composition for Store Waste.	2-20
Figure 2.1.1-2a.	Respond to Off-Normal Double-Shell Tank Waste Composition.	2-21
Figure 2.1.1-3.	Double-Shell Tank Functional Flow, Control Double-Shell Tank and Waste Temperature for Store Waste.	2-22
Figure 2.1.1-3a.	Respond to Off-Normal Double-Shell Tank Temperature.....	2-23
Figure 2.1.1-4.	Double-Shell Tank Functional Flow, Control Double-Shell Tank Hydrostatic Loads.	2-24
Figure 2.1.1-4a.	Response to Off-Normal Double-Shell Tank Hydrostatic Loads.	2-25
Figure 2.1.1-4b.	Response to Off-Normal Double-Shell Tank Waste Level.....	2-26
Figure 2.1.1-5.	Double-Shell Tank Functional Flow, Control Double-Shell Tank Primary Confinement Leaks.....	2-27
Figure 2.1.1-5a.	Response to Off-Normal Double-Shell Tank Leak in Primary Tank.....	2-28
Figure 2.1.1-6.	Double-Shell Tank Functional Flow, Control Double-Shell Tank Gaseous Discharge.	2-29
Figure 2.1.1-6a.	Respond to Off-Normal Double-Shell Tank Gaseous Discharge.	2-30
Figure 2.1.1-6b.	Respond to Off-Normal Double-Shell Tank Flammable Gas Concentration.	2-31
Figure 2.1.1-6c.	Respond to Off-Normal Double-Shell Tank Ventilation.	2-32
Figure 2.1.2-1.	Double-Shell Tank System Functional Hierarchy for Store Waste.	2-33
Figure 2.2.1-1.	Double-Shell Tank Transfer Waste Functional Flows.....	2-58
Figure 2.2.1-2.	Double-Shell Tank Functional Flow, Establish Transfer Route for Waste Transfer.	2-59
Figure 2.2.1-2a.	Respond to Off-Normal Transfer Valve Position.	2-60
Figure 2.2.1-3.	Double-Shell Tank Functional Flow, Provide Diluent During Transfers.....	2-61

Figure 2.2.1-3a.	Respond to Off-Normal Double-Shell Tank Waste Backflow.....	2-62
Figure 2.2.1-3b.	Respond to Off-Normal Diluent/Flush Water Parameters.	2-63
Figure 2.2.1-4.	Double-Shell Tank Functional Flow, Convey Waste.....	2-64
Figure 2.2.1-4a.	Respond to Off-Normal Waste Transfer Parameters.	2-65
Figure 2.2.1-4b.	Respond to Off-Normal Transfer Pump Operation.....	2-66
Figure 2.2.1-5.	Double-Shell Tank Functional Flow, Confine Waste Along Transfer Route.	2-67
Figure 2.2.1-6.	Double-Shell Tank Functional Flow, Confine Waste Leakage Along Transfer Route.....	2-68
Figure 2.2.1-6a.	Respond to Off-Normal Leak in Transfer-Associated Structures.	2-69
Figure 2.2.1-6b.	Respond to Off-Normal Double-Shell Tank Transfer Pipe Leak.	2-70
Figure 2.2.1-7.	Double-Shell Tank Functional Flow, Flush Transfer System.....	2-71
Figure 2.2.1-8.	Double-Shell Tank Functional Flow, Reconfigure Transfer Route.	2-72
Figure 2.2.2-1.	Double-Shell Tank System Function Hierarchy for Waste Transfer.	2-73
Figure 2.3.1-1.	Prepare Waste in East Area Double-Shell Tanks Functional Flow.	2-87
Figure 2.3.1-2.	Mobilize and Suspend Insoluble Waste Within East Area Double-Shell Tanks Functional Flow.....	2-88
Figure 2.3.1-3.	Mobilize High-Level Waste in Source Tank.....	2-89
Figure 2.3.1-3a.	Respond to Off-Normal Mixer Pump Operational Parameters.	2-90
Figure 2.3.1-4.	Add Diluent to Double-Shell Tank Functional Flow.	2-91
Figure 2.3.1-5.	Dissolve Soluble Waste in East Area Double-Shell Tanks Functional Flow.....	2-92
Figure 2.3.1-6.	Soften Crust Layer in Low-Activity Waste Source Tanks Functional Flow.....	2-93
Figure 2.3.1-7.	Dissolve Salts in Low-Activity Waste Source Tanks Functional Flow.	2-94
Figure 2.3.1-8.	Prepare Low-Activity Waste in Low-Activity Waste Staging Tanks Functional Flow.....	2-95
Figure 2.3.1-9.	Soften Crust Layer in Low-Activity Waste Staging Tanks Functional Flow.....	2-96

Figure 2.3.1-10.	Add Diluent to Low-Activity Waste Staging Tanks.....	2-97
Figure 2.3.1-11.	Dissolve Salts in Low-Activity Waste Staging Tanks Functional Flow.....	2-98
Figure 2.3.1-12.	Prepare High-Level Waste Sludges in High-Level Waste Staging Tanks Functional Flow.....	2-99
Figure 2.3.2-1.	Double-Shell Tank System Function Hierarchy for Prepare Waste.	2-100
Figure 2.4.2-1.	Double-Shell Tank System Function Hierarchy for Distribute Utilities....	2-105
Figure 2.5.1-1.	Support Double-Shell Tank System Functional Flows.....	2-110
Figure 2.5.2-1.	Support Double-Shell Tank System Functional Hierarchy.....	2-111
Figure 3.0-1.	Store Waste Function Applications to Double-Shell Tank Components.....	3-2
Figure 3.0-2.	Transfer Waste Functions Applicable to Double-Shell Tank Components.....	3-5
Figure 3.0-3.	Prepare Waste Functions Applicable to Double-Shell Tank Components.....	3-10
Figure 3.0-4.	Distribute Utilities Functions Applicable to Double-Shell Tank System Components.....	3-12
Figure 3.0-5.	Support Double-Shell Tank System Functional Applicable to Double- Shell Tank Components.	3-13

ACRONYMS

DST	double-shell tank
HLW	high-level waste
HSTD	Hanford Site Technical Baseline Database
LAW	low-activity waste
OSD	Operating Specification Documents
PFP	Plutonium Finishing Plant
SST	single-shell tank
WFD	Waste Feed Delivery

This page intentionally left blank.

1.0 INTRODUCTION

This functional analysis identifies the hierarchy and describes the subsystem functions that support the Double-Shell Tank (DST) System described in HNF-SD-WM-TRD-007, *System Specification for the Double-Shell Tank System*. Because of the uncertainty associated with the need for upgrades of the existing catch tanks supporting the Waste Feed Delivery (WFD) mission, catch tank functions are not addressed in this document. The functions identified herein are applicable to the Phase 1 WFD mission only.

1.1 BACKGROUND

HNF-SD-WM-TRD-007 provides the following first-tier DST System functions that support the Phase 1 WFD mission:

- Maintain Safe and Compliant Waste Within the DST System (tsd.1.2.5.1.1)¹
- Remove Waste from DSTs Phase 1 (tsd.2.2.6.1.1)
- Prepare High-Level Waste (HLW) Feed for Phase 1 Treatment (tsd.2.2.6.1.3)
- Prepare Low-Activity Waste (LAW) Feed for Phase 1 Treatment (tsd.2.2.6.1.2).

This document is a functional analysis of the second-tier functions defined in HNF-SD-WM-TRD-007. It includes the functions for storing, transferring, receiving, and preparing waste in support of the WFD mission. The following documentation was used to describe planned or expected waste preparation and transfer operations:

- HNF-SD-WM-SP-012, *Tank Waste Remediation System Operation and Utilization Plan*
- HNF-SD-WM-TRD-007, *System Specification for the Double-Shell Tank System*
- HNF-1939, *Waste Feed Delivery Technical Basis*, Vol. II, Rev. 0a, Addendum 1, "Waste Feed Delivery Flowsheet for Tank 241-AZ-101"
- HNF-1939, Vol. II, Rev. 0c, Addendum 3, "Waste Feed Delivery Flowsheet for Tank 241-AN-104"
- Letter No. 73600-99-006, "Interim Guidance on LAW Retrieval Strategy."

¹ Note: tsd = treat, store, and dispose. This prefix is on all Hanford Site Technical Baseline Database (HSTD) function numbers, as instituted by Site Systems Engineering.

1.2 PURPOSE AND SCOPE

This functional analysis describes the behavior of DST subsystems and their contribution to the Phase 1 WFD mission. This is the first step in quantifying DST subsystem performance, and the results of this functional analysis was used to construct the following DST subsystem specifications:

1. DST Transfer Pump Subsystem
2. DST Mixer Pump Subsystem
3. DST Ventilation Subsystem
4. DST Diluent and Flush Subsystem
5. DST Transfer Valving Subsystem
6. DST Transfer Piping Subsystem
7. DST Utilities Subsystems
8. DST Monitor and Control Subsystem
9. DST Maintenance and Recovery Subsystem
10. DST Process Waste Sampling Subsystem.

This functional analysis was performed to the level of detail needed to derive functions that are uniquely allocable to the above DST subsystems. Functional flows and functional descriptions capture the planned WFD processes and the resulting DST System behavior.

1.3 DOCUMENT ORGANIZATION

The remainder of this document is organized in two major sections as follows:

- Section 2.0 explains the methodology, rationale, and results of the functional analysis. More detail is presented in the subsections: Store Waste (Section 2.1), Transfer Waste (Section 2.2), Prepare Waste (Section 2.3), Distribute DST Utilities (Section 2.4), and Support DST System (Section 2.5).
- Section 3.0 identifies the allocation of the functions derived in Section 2.0 to 11 DST components.

2.0 FUNCTIONAL ANALYSIS

This section describes the functional decomposition of storing, receiving, transferring, and preparing waste; distributing utilities; and supporting the DST System. (The receive functions are addressed with the Transfer Waste functional decomposition [Section 2.2].)

This functional analysis was performed in accordance with the guidelines provided by HNF-IP-0842, *RPP Administration*, Vol. IV, Section 3.2, "Functions and Requirements Analysis Allocation and Development of Level 1 and 2 Specifications." This functional analysis was limited to decomposing the DST System functions down to the level at which the derived functions could be allocated to one of the subsystems identified in Section 1.0, thus supporting development of the Level 2 specifications for each of these subsystems.

The DST System functions identified in HNF-SD-WM-TRD-007, Figure 3-2, with the exceptions noted below, were used as the starting point for this functional analysis. These DST system functions are identified in Figure 2.0 of this document. The top-tier functions were decomposed into second-, third-, fourth-, and lower-tier functions. A function definition is provided along with the reference that establishes the need (basis) for the function. This provides traceability for the function set derived herein. Functional relationships were established through both functional hierarchy and functional flow block diagrams. Lastly, the functional hierarchy is annotated to identify the allocation of functions to one of the DST subsystems.

During the W-314 Project preconceptual design activities (fiscal year 1996), it was determined that the "store waste" functional decomposition can be characterized as a series of "control" tank/waste parameters. The definitions for "control" of a tank/waste parameter while storing tank waste were derived from brainstorming sessions with representatives from Plant Engineering and Tank Farm Operations. The same philosophy for "control" of tank/waste parameters was used herein for defining the Store East/West Area DST Waste functions. In summary, "control" was determined to include the following elements.

- "Monitor" means to measure, transmit (provide data to another function), receive (accept data from another function), record, and display data. Note that "measure" is synonymous with "detect" and "obtain" as used herein.
- "Compare" means to compare data received from the "measure" function to a set point and initiate the appropriate action.
- "Maintain" means to maintain parameters within operating/design limits.
- "Respond to off-normal" means to take actions to mitigate situations where a measured parameter is outside of system operating limits. These actions may include those necessary to mitigate a release of radiological or toxicological waste or protect personnel or the DST System.

Where appropriate for a subsystem architecture, the "compare" function was grouped under the "monitor" function herein. For example, Section 2.1.4.3.2.2, "Compare Double-Shell

Tank Structure Temperature" is grouped with "measure," "record," and "display" functions under Section 2.1.4.3.2, "Monitor Double-Shell Tank Structure Temperature." This supported allocation of functions between the DST Confinement Subsystem and the DST Monitor and Control Subsystem.

As applicable herein, the "transmit" function was combined with the "measure" function. For example, Section 2.1.4.3.2.1, "Measure Double-Shell Tank Structure Temperature" provides measured data (via the thermocouple interface) and therefore negates the necessity to specify a unique "transmit" function.

Figure 2.0. Double-Shell Tank System Functional Flow Block Diagram.
(Sheet 1 of 2)

Figure 2.0. Double-Shell Tank System Functional Flow Block Diagram.
(Sheet 2 of 2)

2.1 STORE WASTE FUNCTIONAL DECOMPOSITION

Store Waste functions shown in Figure 2.0 represent those functions required to store both existing waste and that waste received from external sources (i.e., 222-S Laboratory, Plutonium Finishing Plant [PFP], T Plant). Store Waste supports storing waste in a safe and compliant manner and maintaining the tank structural integrity. The DST System-level store functions shown in Figure 2.0 referred to herein as “second-tier” functions, are as follows:

- Store Waste in West Area DSTs
- Store Waste in East Area DSTs.

Note that the Store Waste functions are “multi-mode” and are performed continuously throughout the WFD process. For example, the Store Waste functions are performed *while* waste transfers are taking place. The functional decomposition presented herein accounts for the multi-moded nature of the Store Waste function.

2.1.1 Third-Tier Store Waste Flows

The function flow shown in Figure 2.1.1-1 represents the decomposition of the second-tier Store DST Waste functions¹. These “third-tier” functions were derived mainly from the *Tank Waste Remediation System Technical Safety Requirements* (HNF-SD-WM-TSR-006) and operating specification documents (OSD). Justification (i.e., basis) for each function is provided with the function definitions in Section 2.1.3. The basis documents listed for each function are not intended to be an exhaustive list of bases for the function identified. For example, environmental regulations cited in the DST System Specification (e.g., WAC 173-303-640) or other source documents listed in Section 1.1 also are identified; reviews were conducted to ensure that a complete set of functions had been identified herein. Further quantification of these functions (i.e., via requirements development) will entail reviewing these and other sources for applicable requirements and constraints on the system design.

Third-tier functions for DST waste storage, as shown in Figure 2.1.1-1, include the following functions, which are further decomposed as shown in Figures 2.1.1-2 through 2.1.1-6.

- Control DST Waste Composition (Figure 2.1.1-2)
- Control DST and Waste Temperature (Figure 2.1.1-3)
- Control DST Hydrostatic Loads (Figure 2.1.1-4)
- Control DST Primary Confinement Leaks (Figure 2.1.1-5)
- Control DST Gaseous Discharge (Figure 2.1.1-6)
- Direct Waste Additions Within Double-Shell Tanks.²

¹ Note: The functional flow diagrams identify “AND” and “OR” relationships between functions. The “AND” is used to indicate that all parallel functions leading into the circle must be accomplished before proceeding into the next function or that all paths emerging from the “AND” must be accomplished after the preceding function. The “OR” indicates alternative paths.

² Note: Decomposition of this function is not addressed herein.

2.1.2 Double-Shell Tank Store Waste Function Hierarchy

The hierarchy of functions representing a decomposition of the second-tier DST Store Waste functions is shown in Figure 2.1.2-1. This figure arranges the store waste functions derived in the flows of Figures 2.1.1-1 through 2.1.1-6 in a hierarchical fashion.

2.1.3 Third-Tier Function Definitions

Function definitions for the third-tier function set of Store Waste (see Figure 2.1.2-1) are provided in the following sections, along with a supporting basis as applicable.

2.1.3.1 Direct Waste Additions Within Double-Shell Tank

Direct waste additions within the DST by providing confinement between the transfer-associated structure and the desired location within the DST (i.e., distribute waste within the tank). No decomposition of this function is provided; however, Figure 2.2.1-2 shows the functional flow in relation to establishing the transfer route.

Basis: *Per HNF-2939, Table 4-1, Step 12.P2.1, a means to minimize aerosol generation is needed if waste is discharged into tank headspace for 241-AP Tanks.*

2.1.3.2 Control Double-Shell Tank Waste Composition

Control the DST waste composition to inhibit uniform corrosion and stress corrosion cracking in the DST steel liner. In addition, this function supports control of total fuel concentrations, organic salts, organic materials, flammable gases, vapors and criticality control parameters (see Figure 2.1.1-2, etc.) and other parameters as required. This function includes sampling for subsequent analysis by an external laboratory, maintaining the waste composition, and responding to off-normal waste compositions. The lower tier functions are described in Section 2.1.4.2.

Basis: *Per HNF-SD-WM-TRD-007, Section 3.3.6.2.1, corrosion prevention and control features shall be in accordance with WAC 173-303-640(3).*

Per HNF-SD-WM-TSR-006, Tank Waste Remediation System Technical Safety Requirements, Section 5.12.2.C, chemical compatibility (i.e., pH) prior to transfer is ensured.

Per OSD-T-151-00007, Operating Specifications for the 241-AN, AP, AW, AY, AZ, & SY Tank Farms, Section 7.2.1, nitrate, nitrite, and hydroxide concentrations are controlled.

Per OSD-T-151-00017, Operating Specifications for Aging Waste Operations in 241-AY and 241-AZ, Section 17.4.1.1.3, maximum hydroxide concentrations are controlled.

Per OSD-T-151-00017, Section 17.4.1.1.4, maximum nitrite and nitrate concentrations are controlled.

Per HNF-SD-WM-OCD-015, Tank Farm Waste Compatibility Program, controls are required to prevent the formulation of incompatible mixtures.

Per HNF-IP-1266, Tank Farms Operations Administrative Controls, Section 5.12, a waste compatibility assessment is required to compare composition of waste sources, the waste receivers, and transfer conditions as applied to safety, operational, regulatory, and programmatic decision criteria.

Per HNF-IP-0842, Vol. II, Section 5.10, "Response to Anomalous Sample Results," Rev. 2b, paragraph 1.0, sample data associated with tank samples pertains to tank composition (e.g., OH, pH, NO₂, NO₃), heat generation rate, total fuel concentration (e.g., energetics), organic salts, organic material (e.g., detachable separate organic phase), compounds with toxicological properties, flammable gases and vapors, and criticality control parameters (e.g., Pu density, solids/Pu ratio).

2.1.3.3 Control Double-Shell Tank and Waste Temperature

Control the DST tank and waste temperature to prevent structural damage to the DST and to maintain waste temperature limits established by accident analysis. This function includes monitoring, comparing temperature levels to limits, maintaining tank and waste temperature, and responding to off-normal temperatures. Figure 2.1.1-3 shows the functional flow for controlling DST and waste temperatures. The lower tier functions are described in Section 2.1.4.3.

Basis: *Per HNF-SD-WM-TRD-007, Section 3.3.6.2.2, waste and tank temperature limits are specified.*

Per HNF-SD-WM-TSR-006, Section 3.3.2, waste temperature limits are specified.

Per OSD-T-151-00007, Sections 7.2.6.a, 7.2.6.b, and 7.2.6.c, maximum temperature limits, temperature changes over time, and temperature gradients are applied to waste temperatures for AN, AP, AW, AY, AZ, and SY tanks to protect the tank structure.

Per OSD-T-151-00007, Sections 7.2.7.a and 7.2.7.b, maximum temperature limits and temperature gradients are applied to the DST concrete to protect the tank structure.

Per OSD-T-151-00017, Sections 17.2.6.a and 17.2.6.b, the maximum dome concrete temperature and temperature gradient allowed are specified.

2.1.3.4 Control Double-Shell Tank Hydrostatic Loads

Control the hydrostatic loads caused by DST vapor space pressures and liquid waste levels to prevent structural damage to the DST. This function includes monitoring waste levels, vapor space pressure, and annulus pressure, as shown in Figure 2.1.1-4. Lower tier functions are described in Section 2.1.4.4.

Basis: *Per HNF-SD-WM-TRD-007, Section 3.3.6.2.3, DST pressure limits are controlled.*

Per HNF-SD-WM-TRD-007, Section 3.3.6.2.5, hydrostatic loads for various fluid levels are specified.

Per OSD-T-151-00007, Section 7.2.3, the minimum hydrostatic head requirements for AY and AZ tanks are stated for preventing damage to the DSTs from uplifting the bottom of the tank by counter-balancing the vacuum within the tank with the weight of fluid in the tank. Hydrostatic head is defined as the sum of primary tank pressure and liquid level.

Per OSD-T-151-00017, Section 17.2.3, the minimum and maximum hydrostatic head at the DST primary tank walls are controlled.

2.1.3.5 Control Double-Shell Tank Primary Confinement Leaks

Control the DST primary confinement leaks. This function includes monitoring within the DST annulus for indication of leaks from the primary confinement space and responding to a detected leak. Figure 2.1.1-5 shows the functional flow for controlling leaks. Lower tier functions are described in Section 2.1.4.5.

Basis: *Per HNF-SD-WM-TRD-007, Section 3.3.6.3.1, the DST System is required to incorporate leak detection features in accordance with WAC 173-303-640.*

Per HNF-SD-WM-TSR-006, Section 3.2.6, either a continuity probe (liquid leak) or a continuous air monitor is required to be operable.

2.1.3.6 Control Double-Shell Tank Gaseous Discharge

Control the DST vapor space and annulus space to restrict emissions to the environment. This function includes monitoring the DST vapor space for flammable gas concentration, and monitoring the DST primary and annulus exhaust for ventilation system operation. Figure 2.1.1-6 shows the functional flow for controlling gaseous discharges to the environment. Lower tier functions are described in Section 2.1.4.6.

Basis: *Per HNF-SD-WM-TRD-007, Sections 3.3.6.3.3 and 3.3.6.3.4, design constraints that limit nonradioactive and radioactive airborne emissions are specified.*

Per HNF-SD-WM-TSR-006, Section 3.2.1.A.3, the primary tank flammable gas levels are monitored to ensure that concentrations are less than 25 percent of the lower flammability limit when the ventilation system is inoperable.

Per OSD-T-151-00017, Section 17.4.7, the 241-AY and 241-AZ primary tank active ventilation prevents tank vapors from escaping the tanks and thus releasing radionuclides to the atmosphere in excess of limits. Vapor releases may be caused by radiolytic heat converting water to steam, by displacement of air through natural breathing of the tank with changes in atmospheric pressure, by displacement of air from waste transfers...etc.

Per OSD-T-151-00007, Section 7.3.1.E, gaseous discharge limits for the annual, weekly, and instantaneous concentrations allowed for release at primary and annulus stacks are specified.

Per OSD-T-151-00017, Section 17.4.7, the averaged 4-hour and instantaneous radionuclide release requirements are specified.

2.1.3.7 Confine Waste Within Double-Shell Tanks

Enclose, hold, and isolate all waste received and/or stored in the double-shell storage tank, including solid, liquid, and gaseous waste.

Basis: Per HNF-SD-WM-TRD-007, Section 3.2.1.1, the DST System is required to store waste.

2.1.4 Fourth-Tier Function Definitions

Function definitions for the fourth-tier function set of Store Waste (see Figures 2.1.1-2 through 2.1.1-6) are given in this section following the applicable third-tier function heading.

2.1.4.1 Direct Waste Additions Within Double-Shell Tanks.

2.1.4.1.1 Reserved.

2.1.4.2 Control Double-Shell Tank Waste Composition

2.1.4.2.1 Sample Double-Shell Tank Waste Composition. Sample DST waste composition to determine if operational or safety limits are being exceeded. This function includes obtaining samples and transporting those samples to the 222-S Laboratory for analysis.

Basis: Per OSD-T-151-00017, Section 17.4.1.1.3, maximum hydroxide concentrations are controlled.

Per OSD-T-151-00017, Section 17.4.1.1.4, maximum nitrite and nitrate concentrations are controlled.

Per HNF-IP-1266, Section 5.12, a waste compatibility assessment is performed before waste transfer for both waste source and receiver tanks.

2.1.4.2.2 Maintain Double-Shell Tank Waste Composition. Maintain DST waste composition to within nominal operating limits.

Basis: See basis for Control Double-Shell Tank Waste Composition, Section 2.1.3.2.

2.1.4.2.2.1 Adjust Chemical Composition. Adjust chemical composition of the DST waste by adding bulk chemicals or diluent water.

Basis: Per OSD-T-151-007, Section 7.2.1, the nitrate, nitrite, and hydroxide concentrations are limited to inhibit uniform corrosion rates and stress corrosion cracking.

2.1.4.2.3 Respond to Off-Normal Double-Shell Tank Waste Composition. Respond to DST waste composition that exceeds operating limits. This function includes providing signals to equipment and personnel and taking action to restore the chemical composition to within operating limits. These actions may include adjusting the chemical composition of the waste, operating the mixer pump, recirculating waste within the DST using the transfer pump,

and transferring waste between DSTs. Figure 2.1.1-2a shows the functional flow for responding to off-normal DST waste composition. The sections describing these functions are as follows:

Function	Applicable Section
Adjust Chemical Composition	2.1.4.2.2.1
Operate Mixer Pump	2.3.3.1.1.1.1
Recirculate Waste Within DST	2.3.3.1.2.1.2
*Transfer Waste Between DSTs	2.2
*Note: This is a generic reference to the transfer functions of Section 2.2 where waste transfers are between DSTs.	

***Basis:** This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.1.4.3 Control Double-Shell Tank and Waste Temperature

2.1.4.3.1 Monitor Double-Shell Tank Waste Temperature. Monitor DST waste temperature to determine if operating limits are being exceeded. Monitoring includes obtaining, comparing, recording, and displaying the temperature data.

***Basis:** See basis for Control Double-Shell Tank and Waste Temperatures, Section 2.1.3.3.*

2.1.4.3.2 Monitor Double-Shell Tank Structure Temperature. Monitor DST tank structure temperatures to determine if operating limits are being exceeded.

***Basis:** Per HNF-SD-WM-TRD-007, Section 3.3.6.2.2, tank concrete structure temperature limits are specified.*

2.1.4.3.2.1 Measure Double-Shell Tank Structure Temperature. Measure the temperature of the DST structure. This function includes measuring the temperature of DST concrete structures (i.e., walls, dome, and foundation). This function includes providing the measured data to the Compare DST Structure Temperature function.

***Basis:** See basis for Monitor Double-Shell Tank Structure Temperature, Section 2.1.4.3.2.*

2.1.4.3.2.2 Compare Double-Shell Tank Structure Temperature. Compare the temperature of the DST waste received from the Measure DST Structure Temperature function to the operating limits. This function analyzes data and initiates a response to maintain temperatures within operating limits or initiates a response to off-normal DST temperatures. This function includes initiation of alarms.

***Basis:** See basis for Monitor Double-Shell Tank Structure Temperature, Section 2.1.4.3.2.*

2.1.4.3.2.3 Record Double-Shell Tank Structure Temperature. Record the temperature of the DST structure from the Measure Temperature of DST Structure function.

***Basis:** See basis for Monitor Double-Shell Tank Structure Temperature, Section 2.1.4.3.2.*

2.1.4.3.2.4 Display Double-Shell Tank Structure Temperature. Display the temperature of the DST structure from the Measure Temperature of DST Structure function.

Basis: See basis for Monitor Double-Shell Tank Structure Temperature, Section 2.1.4.3.2.

2.1.4.3.3 Maintain Double-Shell Tank Temperature. Maintain the DST structure and waste temperatures within nominal operating limits. This function may include operating the mixer pump to mix the waste, to reduce hot spots within the tank sludge waste; ventilating the primary and annulus spaces; and circulating air through the waste as needed via the airlift circulators.

Basis: See basis for Control Double-Shell Tank and Waste Temperatures, Section 2.1.3.3.

2.1.4.3.3.1 Ventilate Double-Shell Tank Primary Confinement System to Remove Heat. Ventilate the DST primary tank to remove heat during interim storage of waste.

Basis: Per HNF-1939, Vol. II, Rev. 0a, Addendum 1, Section 3.1.4, the waste is cooled using primary ventilation.

Per OSD-T-151-00007, Section 7.3, the primary ventilation is used to cool the primary tank.

2.1.4.3.3.2 Ventilate Double-Shell Tank Annulus to Remove Heat. Ventilate the DST annulus to remove heat from the stored waste.

Basis: Per OSD-T-151-00007, Section 7.3, the annulus ventilation is used to cool the waste.

2.1.4.3.3.3 Operate Mixer Pump. See Section 2.3.3.1.1.1.1 for description.

2.1.4.3.3.4 Circulate Air Through Waste to Remove Heat. Circulate air through the waste during interim storage to prevent the sludge from overheating.

Basis: Per HNF-1939, Vol. II, Rev. 0a, Addendum 1, Section 3.1.4, air lift circulators may be used to impede the heating rate of the sludge.

2.1.4.3.3.4.1 Route Service Air through Waste. Route service air through waste to remove heat.

Basis: Per HNF-1939, Vol. II, Rev. 0a, Addendum 1, Section 3.1.4, air lift circulators may be used to impede the heating rate of the sludge.

2.1.4.3.4 Respond to Off-Normal DST Temperature. Respond to DST waste and/or structure temperatures exceeding operating limits. This function includes providing signals to equipment and personnel and taking action to restore the waste and tank temperatures to within operating limits. These actions may include evaluating equipment status, performing corrective maintenance, shutting down mixer pump and transfer pumps, adding diluent to the DST, circulating air through the waste, or operating the mixer pump to reduce hot spots in the sludge waste. Figure 2.1.1-3a shows the functional flow for responding to off-normal DST waste

temperatures or DST structure temperatures. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Perform Corrective Maintenance	2.5.7
Add Diluent to DST	2.3.3.1.1.3
Operate Mixer Pump	2.3.3.1.1.1.1
Shut Down Transfer Pumps	2.1.4.4.9.1
Shut Down Mixer Pump	2.1.4.4.9.2
Circulate Air Through Waste to Remove Heat	2.1.4.3.3.4
Respond to Off-Normal DST Ventilation	2.1.4.6.9

Basis: *This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.1.4.4 Control Double-Shell Tank Hydrostatic Loads

2.1.4.4.1 Monitor Double-Shell Tank Waste Level. Monitor the DST liquid waste levels to obtain data to determine if operating limits are exceeded. Monitoring includes obtaining, recording, and displaying waste level data.

Basis: *Per HNF-SD-WM-TSR-006, Section 5.12.2.b, a material balance calculation is required during each transfer. To support this calculation, it is reasonable to expect that the waste levels must be known before the transfer. Also, tank levels for tanks physically connected to the waste transfer route are monitored for increasing levels.*

2.1.4.4.2 Monitor Double-Shell Tank Vapor Space Pressure. Monitor the DST vapor space pressure to obtain data to determine if operating limits are exceeded. Monitoring includes obtaining, recording, and displaying the vapor space pressure data.

Basis: *See basis for Control Double-Shell Tank Hydrostatic Loads, 2.1.3.4.*

2.1.4.4.3 Monitor Double-Shell Tank Annulus Pressure. Monitor the DST annulus pressure to determine if operating limits are exceeded. Monitoring includes obtaining, recording, and displaying the annulus pressure data.

Basis: *See basis for Control Double-Shell Tank Hydrostatic Loads, Section 2.1.3.4.*

2.1.4.4.4 Compare Double-Shell Tank Hydrostatic Loads to Operating Limits. Compare DST vapor space pressure data and DST waste level data received from the Monitor DST Vapor Space and Monitor DST Waste Level functions to operating limits. This function analyzes data and initiates systems for appropriate action and includes initiation of alarms.

2.1.4.4.5 Respond to Off-Normal Double-Shell Tank Hydrostatic Loads. Respond to DST hydrostatic loads exceeding operating limits. This function includes providing signals to equipment and personnel and taking action to restore the hydrostatic loads to within operating

limits. The response may include evaluation of equipment, performing corrective maintenance, shutdown of transfer operations into or out of the affected tank, shutdown of the mixer pump, shutdown of ventilation, and addition of diluent to the DST. Figure 2.1.1-4a shows the functional flow for responding to off-normal DST hydrostatic loads. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Perform Corrective Maintenance	2.5.7
Shut Down Transfer Pumps	2.1.4.4.9.1
Shut Down Mixer Pump	2.1.4.4.9.2
Shut Down Ventilation	2.1.4.4.5.1
Add Diluent to DST	2.3.3.1.1.3
Respond to Off-Normal DST Waste Level	2.1.4.4.9
*Transfer Waste Between DSTs	2.2

*Note: This is a generic reference to the transfer functions of Section 2.2 where waste transfers are between DSTs.

Basis: *This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.1.4.4.5.1 Shut Down Ventilation. Shut down ventilation air flow through the DST primary exhaust and annulus exhaust in response to off-normal conditions to mitigate the annulus condition and to allow for the appropriate response to resolve the off-normal condition.

Basis: *No documented basis found.*

2.1.4.4.6 Maintain Double-Shell Tank Vapor Space Pressure. Maintain the DST vapor space pressure within nominal operating limits by ventilating the primary DST vapor space.

Basis: *Per HNF-SD-WM-TRD-007, Section 3.3.6.2.3, DST pressure limits are specified to protect the system from damage.*

2.1.4.4.7 Maintain Double-Shell Tank Annulus Pressure. Maintain DST annulus space air pressure within nominal operating limits by ventilating the DST annulus.

Basis: *Per HNF-SD-WM-TRD-007, Section 3.3.6.2.3, DST pressure limits are specified to protect the system from damage.*

2.1.4.4.8 Compare Double-Shell Tank Waste Level to Operating Limits. Compare DST liquid waste level data received from Monitor DST Waste Level function to operating limits. This function analyzes data and initiates systems for appropriate action, including initiation of alarms.

Basis: *Per HNF-SD-WM-TSR-006, Section 5.12.2.b, a material balance calculation is required during each transfer. Also, tank levels for tanks physically connected to the waste transfer route are monitored for increasing level.*

2.1.4.4.9 Respond to Off-Normal Double-Shell Tank Waste Level. Respond to DST waste level exceeding operating limits. This function includes providing signals to equipment and personnel taking action to restore the waste levels to within operating limits. These actions may include evaluation or correction of equipment, shutdown of transfer pumps and mixer pumps, shutdown of diluent pump, shutdown of service water supply to the DST, transfer of waste between DSTs, and performing a material balance. Figure 2.1.1-4b shows the functional flow for responding to an off-normal DST waste level. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Perform Corrective Maintenance	2.5.7
Shut Down Transfer Pumps	2.1.4.4.9.1
Shut Down Mixer Pump	2.1.4.4.9.2
Shut Down Diluent Pump	2.1.4.4.9.3
Shut Down Service Water Supply to DST	2.1.4.4.9.4
Perform Material Balance for DST Transfers	2.2.3.10
Respond to Off-Normal DST Hydrostatic Loads	2.1.4.4.5
*Transfer Waste Between DSTs	2.2

*Note: This is a generic reference to the transfer functions of Section 2.2 where waste transfers are between DSTs.

Basis: *Per HNF-SD-WM-TRD-007, Section 3.3.6.2.5, waste levels are specified for each tank in terms of specific gravity.*

Per HNF-SD-WM-TSR-006, Section 5.12.2.b, the need to monitor tanks physically connected to a transfer route implies the need to respond to a misrouted waste transfer detected by monitoring waste levels.

This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.

2.1.4.4.9.1 Shut Down Transfer Pumps. Shut down transfer pumps in response to off-normal conditions to stop the transfer of waste into or out of DSTs, to mitigate the condition, and to allow for the appropriate response to resolve the off-normal condition.

Basis: *No documented basis found.*

2.1.4.4.9.2 Shut Down Mixer Pump. Shut down mixer pump in response to off-normal conditions to mitigate the anomalous condition and to allow for the appropriate response to resolve the off-normal condition.

Basis: No documented basis found.

2.1.4.4.9.3 Shut Down Diluent Pump. Shut down diluent pump in response to off-normal conditions to mitigate the anomalous condition and to allow for the appropriate response to resolve the off-normal condition.

Basis: No documented basis found.

2.1.4.4.9.4 Shut Down Service Water Supply to Double-Shell Tank. Shut down service water supply to the DST in response to off-normal conditions to mitigate the anomalous condition and to allow for the appropriate response to resolve the off-normal condition.

Basis: No documented basis found.

2.1.4.5 Control Double-Shell Tank Primary Confinement Leaks

2.1.4.5.1 Monitor Double-Shell Tank Annulus for Primary Leaks. Monitor the DST annulus to obtain data to determine if a liquid leak occurs in the primary tank. Monitoring includes obtaining, recording, and displaying the annulus liquid leak data.

Basis: See basis for Control Double-Shell Tank Primary Confinement Leaks, Section 2.1.3.5.

2.1.4.5.2 Monitor Double-Shell Tank Annulus Air for Primary Leaks. Monitor the DST annulus air to obtain data to determine if a liquid leak occurs in the primary tank. Monitoring includes obtaining, recording, and displaying the annulus liquid leak data.

Basis: See basis for Control Double-Shell Tank Primary Confinement Leaks, Section 2.1.3.5.

2.1.4.5.3 Contain Primary Confinement Leaks. Provide secondary containment of waste leaked from the DST primary shell for recovery by the DST Maintenance and Recovery Subsystem.

Basis: Per HNF-SD-WM-TRD-007, Section 3.3.6.3.1, secondary containment is required.

2.1.4.5.4 Respond to Off-Normal Double-Shell Tank Leak in Primary Tank. Respond to the detection of a DST primary leak. This function includes providing signals to equipment and personnel and taking action to contain and control the leakage and to restore the DST to a safe state. These actions may include evaluations of equipment, performing corrective maintenance, shutdown of transfer pumps and mixer pump, transfer of waste between DSTs, and removal of leaked waste collected in secondary containment. Figure 2.1.1-5a shows the

functional flow for responding to an off-normal DST leak. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Perform Corrective Maintenance	2.5.7
Shut Down Transfer Pumps	2.1.4.4.9.1
Shut Down Mixer Pump	2.1.4.4.9.2
Remove Leaked Waste From Secondary Containment	2.5.8
*Transfer Waste Between DSTs	2.2

*Note: This is a generic reference to the transfer functions of Section 2.2 where waste transfers are between DSTs.

Basis: *This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.1.4.6 Control Double-Shell Tank Gaseous Discharge

2.1.4.6.1 Monitor Double-Shell Tank Primary Exhaust Gaseous Discharge. Monitor the DST primary exhaust to determine if the gaseous discharge exceeds operating limits for allowable radioactive releases. Monitoring includes obtaining, comparing, recording, and displaying the gaseous discharge data. This function initiates systems and alarms if operating limits are exceeded.

Basis: *See basis for Control Double-Shell Tank Gaseous Discharge, Section 2.1.3.6.*

2.1.4.6.2 Monitor Double-Shell Tank Annulus Exhaust Gaseous Discharge. Monitor the DST annulus exhaust to obtain data to determine if the gaseous discharge exceeds operating limits for allowable radioactive releases. Monitoring includes obtaining, comparing, recording, and displaying the gaseous discharge data. This function initiates systems and alarms if operating limits are exceeded.

Basis: *See basis for Control Double-Shell Tank Gaseous Discharge, Section 2.1.3.6.*

2.1.4.6.3 Monitor Double-Shell Tank Flammable Gas Concentration. Monitor the DST flammable gas concentrations to obtain data to determine if operating limits are exceeded. Monitoring includes obtaining, comparing, recording, and displaying the flammable gas concentration data. This function initiates systems and alarms if operating limits are exceeded.

Basis: *Per HNF-SD-WM-TSR-006, Section 3.2.1.A.3, the primary tank flammable gas levels are monitored to ensure concentrations are no greater than 25 percent of the lower flammability limit when the ventilation system is inoperable.*

2.1.4.6.4 Maintain Double-Shell Tank Primary Exhaust Gaseous Discharge Within Limits. Maintain DST gaseous discharges from the primary exhaust to within operating limits by filtering the exhaust of the primary vapor space.

Basis: See basis for Control Double-Shell Tank Gaseous Discharge, Section 2.1.3.6.

2.1.4.6.5 Maintain Double-Shell Tank Annulus Exhaust Gaseous Discharge Within Limits. Maintain DST gaseous discharges from the annulus exhaust to within operating limits by filtering the exhaust of the annulus.

Basis: See basis for Control Double-Shell Tank Gaseous Discharge, Section 2.1.3.6.

2.1.4.6.6 Respond to Off-Normal Double-Shell Tank Gaseous Discharge. Respond to the detection of off-normal DST gaseous discharge. This function includes providing signals to equipment and personnel and taking actions to restore the DST gaseous discharge to within operating limits. These actions may include evaluating equipment, performing corrective maintenance, shutdown of transfer pumps and mixer pump, and shutdown of ventilation. Figure 2.1.1-6a shows the functional flow for responding to an off-normal DST gaseous discharge. The sections describing the functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Perform Corrective Maintenance	2.5.7
Shut Down Transfer Pumps	2.1.4.4.9.1
Shut Down Mixer Pump	2.1.4.4.9.2
Shut Down Ventilation	2.1.4.4.5.1

Basis: This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.

2.1.4.6.7 Respond to Off-Normal Double-Shell Tank Flammable Gas Concentration. Respond to the detection of anomalous DST flammable gas concentrations. This function includes providing signals to equipment and personnel and taking actions to restore the DST flammable gas concentration to within operating limits. These actions may include evaluation of equipment, performing corrective maintenance, shutdown of transfer pumps, and shutdown of mixer pump. Figure 2.1.1-6b shows the functional flow for responding to an off-normal DST flammable gas concentration. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Perform Corrective Maintenance	2.5.7
Shut Down Transfer Pumps	2.1.4.4.9.1
Shut Down Mixer Pump	2.1.4.4.9.2
Respond to Off-Normal DST Ventilation	2.1.4.6.9

Basis: *This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.1.4.6.8 Monitor Ventilation System Operation. Monitor ventilation system operation parameters to provide local, integrated status to the tank farm operator. This function includes obtaining, recording, and displaying parameters received from the ventilation system.

Basis: *No documented basis found.*

2.1.4.6.9 Respond to Off-Normal DST Ventilation. Respond to off-normal DST ventilation parameters measured. This function includes providing signals to equipment and personnel and taking actions to restore the ventilation system to operation within operating limits. These actions may include evaluating equipment status, performing corrective maintenance, shutdown of transfer pumps, shutdown of mixer pump, and providing auxiliary DST ventilation. Figure 2.1.1-6c shows the functional flow for responding to off-normal ventilation parameters. The sections describing these lower tier functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Shut Down Transfer Pumps	2.1.4.4.9.1
Perform Corrective Maintenance	2.5.7
Provide Auxiliary DST Ventilation	2.5.9
Shut Down Mixer Pump	2.1.4.4.9.2

Basis: *This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

Figure 2.1.1-1. Double-Shell Tank Third-Tier Functional Flows for Store Waste.

Figure 2.1.1-2. Double-Shell Tank Functional Flow, Control Double-Shell Tank Waste Composition for Store Waste.

Figure 2.1.1-2a. Respond to Off-Normal Double-Shell Tank Waste Composition.

Figure 2.1.1-3. Double-Shell Tank Functional Flow, Control Double-Shell Tank and Waste Temperature for Store Waste.

Figure 2.1.1-3a. Respond to Off-Normal Double-Shell Tank Temperature.

Figure 2.1.1-4. Double-Shell Tank Functional Flow, Control Double-Shell Tank Hydrostatic Loads.

Figure 2.1.1-4a. Response to Off-Normal Double-Shell Tank Hydrostatic Loads.

Figure 2.1.1.4b. Response to Off-Normal Double-Shell Tank Waste Level.

Figure 2.1.1-5. Double-Shell Tank Functional Flow, Control Double-Shell Tank Primary Confinement Leaks.

Figure 2.1.1-5a. Response to Off-Normal DST Leak in Primary Tank.

Figure 2.1.1-6. Double-Shell Tank Functional Flow, Control Double-Shell Tank Gaseous Discharge.

Figure 2.1.1-6a. Respond to Off-Normal DST Gaseous Discharge.

Figure 2.1.1-6b. Respond to Off-Normal Double-Shell Tank Flammable Gas Concentration.

Figure 2.1.1-6c. Respond to Off-Normal Double-Shell Tank Ventilation.

Second-Tier Functions

Figure 2.1.2-1. Double-Shell Tank System Functional Hierarchy for Store Waste.
(Sheet 1 of 3)

Figure 2.1.2-1. Double-Shell Tank System Functional Hierarchy for Store Waste.
(Sheet 2 of 3)

Figure 2.1.2-1. Double-Shell Tank System Functional Hierarchy for Store Waste.
(Sheet 3 of 3)

2.2 TRANSFER WASTE FUNCTIONAL DECOMPOSITION

The transfer and receive functions shown in Figure 2.0 describe the waste being transferred between DST facilities or waste being transferred between the DST System and facilities external to the DST System. Waste received from the evaporator and new waste received by DSTs are included in this set of functions. The second-tier transfer functions shown in Figure 2.0 are as follows:

- Transfer Waste from 204-AR Waste Unloading Facility to East Area DSTs (tsd.1.2.5.1.1.5)¹
- Receive New Liquid Waste into West Area DSTs (tsd.1.2.5.1.1)¹
- Transfer Supernatant to SST Retrieval System²
- Transfer Waste Between West Area DSTs (tsd.2.2.6.1.1.2)
- Transfer Waste Cross-Site (tsd.2.2.6.1.1.3)³
- Receive New Liquid Waste into East Area DSTs (tsd.1.2.5.1.3)¹
- Transfer Waste for Concentration (tsd.1.2.5.1.1.10)
- Receive Concentrated Waste from Evaporator (tsd.1.2.5.1.7)¹
- Receive Emergency Purge from Evaporator (tsd.1.2.5.1.6)¹
- Transfer Waste Between East Area DSTs (tsd.2.2.6.1.1.5)
- Transfer Waste to LAW Staging Tanks (tsd.2.2.6.1.1.6)
- Transfer Waste to HLW Staging Tanks²
- Transfer HLW Sludge to the Waste Treatment Plant (tsd.2.2.6.1.3.2)
- Transfer LAW Supernatant to the Waste Treatment Plant (tsd.2.2.6.1.2.2).

¹ Functions do not pertain to Phase 1 WFD. They are not decomposed herein. Assumption: Existing systems will suffice for performing these functions.

² New function added to HNF-SD-WM-TRD-007, Rev. 0.

³ Cross-site transfer functions are not decomposed herein. An assumption was made that the new Cross-Site Transfer System installed by Project W-058 will meet Phase 1 WFD needs.

The Transfer Waste to LAW Staging Tanks function was decomposed for transfer of the following two waste types identified in HNF-1939, Vol. II, , Rev. 0c, Addendum 3:

- Transfer LAW Supernatant to Staging Tanks—Remove existing clarified supernatant without disturbing the underlying settled solids (initial decant).
- Transfer LAW Salt Solution to Staging Tanks—Following dissolution of soluble salts via addition of water and mixing, remove supernatant.

2.2.1 Third-Tier Transfer Waste Flows

The function flow shown in Figure 2.2.1-1 represents the decomposition of the second-tier DST waste transfer functions of Figure 2.0. Figure 2.2.1-1 represents the functional flow for waste transfers in general (i.e., for each of the second-tier functions). Justification (i.e., basis) for each function is provided with the function definitions.

Figure 2.2.1-1 functions (third tier) for DST waste transfer include the following:

1. Establish Transfer Route for Waste Transfer (Figure 2.2.1-2)
2. Provide Diluent During Transfers (Figure 2.2.1-3)
3. Convey Waste (Figure 2.2.1-4)
4. Confine Waste Along Transfer Route (Figure 2.2.1-5)
5. Confine Waste Leakage Along Transfer Route (Figure 2.2.1-6)
6. Flush Transfer System (Figure 2.2.1-7)
7. Drain Transfer Piping
8. Perform Material Balance for Double-Shell Tank Transfers
9. Reconfigure Transfer Route (Figure 2.2.1-8).

These functions are further decomposed, as shown in the noted figures. No decompositions were deemed necessary for the Perform Material Balance for Double-Shell Tank Transfers or the Drain Transfer Piping functions.

2.2.2 Double-Shell Tank Transfer Waste Function Hierarchy

The hierarchy of transfer functions representing the decomposition of the second-tier DST waste transfer functions is shown in Figure 2.2.2-1 along with the third- and fourth-tier functions. Included in this hierarchy is the suite of waste transfer functions that represents the functions shown in Figures 2.2.1-1 through 2.2.1-8.

Function definitions for the third-tier and fourth-tier functions are provided in Sections 2.2.3 and 2.2.4, respectively.

2.2.3 Third-Tier Function Definitions

Function definitions for the third-tier function set of the Transfer Waste function (see Figure 2.2.1-1) are given below. Function definition bases also are provided.

2.2.3.1 Establish Transfer Route for Waste Transfer

Establish the transfer route between the source and destination tanks by positioning valves and verifying valve positions before waste transfers.

Basis: *Per HNF-SD-WM-TSR-006, Section 5.12.2, isolate waste transfer paths where valves exist, and this is feasible. Independently verify waste transfer route and valve status before transfer.*

2.2.3.2 Provide Diluent During Transfers

Provide heated diluent water at a prescribed temperature, flow rate, and chemical composition to the transfer pump suction intake to support preconditioning of the transfer route, initiation of waste transfers, and dilution of waste during the transfer. This function also directs the output of the transfer pump from a recirculation loop to the source DST to the transfer route if a recirculation loop was part of the initial valve setup.

Basis: *Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.5, the following process steps for waste transfer are described for LAW feed staging (i.e., Transfer LAW Supernatant to Staging Tanks). Initially, heated diluent water is provided at a prescribed flow rate and routed to the transfer pump suction intake. The transfer pump then is engaged and maintains the pump discharge flow rate at the prescribed flow rate for several minutes. (This transfer of heated diluent for several minutes before the waste is transferred was interpreted as a preconditioning of the transfer line.) The diluent water flow rate from the diluent source then is lowered, and the transfer pump makes up the flow rate loss from the diluent source with tank waste (i.e., supernatant).*

Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 2.0, diluent for Tank 241-AN-104 is heated water (no chemical adjustment required). The heated diluent lowers viscosity and helps to prevent in-line precipitation.

Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.13, decanting of diluted sludge liquors (sludge dissolute) may be suitable for transfer without in-line dilution; however, the transfer is initiated as per a diluted liquid transfer, and in-line dilution is available to adjust the temperature and density.

Per HNF-1939, Vol. II, Rev. 0a, Addendum 1, Section 2.0, dilution of the waste for transfer is not identified. Only mixer pump seal leakage of service water is accounted for in the transfer volume. Section 3.1.2 identifies a stick transfer pump and a slurry viscosity suitable for pumping without dilution.

2.2.3.3 Convey Waste

Provide motive force to convey liquid waste or diluent water or a combination of liquid waste and diluent water from the source tank to the destination tank. This function includes positioning of the transfer pump suction intake at various levels within the DST and confining waste within the transfer route.

Basis: Per HNF-SD-WM-SP-012, Section 3.4.3.1, the process for transfer of LAW from liquid and salt sludge tanks (e.g., waste feed preparation) involves transfer pumps with adjustable suctions to transfer the liquid layer; following salt dissolution, the adjustable suction is dropped to the top of the residual solids to transfer dissolved salts.

Per HNF-1939, Vol. II, Rev. 0a, Addendum 1, Section 3.1.2, the transfer pump is installed at a specific location above the bottom of the tank for all transfers.

Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.13, the transfer pump intake is positioned to decant diluted sludge liquors.

2.2.3.4 Confine Waste Along Transfer Route

Confine waste along the transfer route between the source and the destination DST (for intermediate feeds to DST staging tanks) or between the source DST and the Waste Treatment Plant.

Basis: HNF-SD-WM-SP-012 identifies the scenarios for routing feed staging and the subsequent HLW and LAW feed routing to the Waste Treatment Plant from the staging tanks. Per HNF-SD-WM-SP-012, Section 3.4.3.1, LAW feed routing includes lines, pump pits, and valve pits.

2.2.3.5 Confine Waste Leakage Along Transfer Route

Confine waste leakage along the transfer route between the source and the destination DST (for intermediate feeds to DST staging tanks) or between the source DST and the Waste Treatment Plant.

Basis: Per HNF-SD-WM-TRD-007, Section 3.3.6.3.1, which specifies secondary containment and leak-detection constraints.

2.2.3.6 Flush Transfer System

Following completion of a waste transfer, deliver and route the flush water through the transfer route from the source to the destination tank. Allow addition of flush water to the transfer pump discharge or the transfer pump suction inlet.

Basis: Per HNF-1939, Vol. II, Rev. 0a, Addendum 1, Section 3.1.3, the flush solution point of delivery (i.e., at the pump suction or at the pump discharge) is pending.

Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.5, for termination of the waste transfer, the diluent water input is chemically adjusted (i.e., adjust diluent water NaOH and NaNO₂ molality) and the diluent flow rate is increased to the prescribed flow rate to flush the transfer line. The heated water lowers the viscosity of the transferred liquid and helps to prevent in-line precipitation. The chemical adjustment at the end of the transfer provides protections against corrosion of the piping system.

Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 2.0, diluent for Tank 241-AN-104 is temperature-adjusted and flush water is composition-adjusted (NaOH and NaNO₂).

2.2.3.7 Drain Transfer Piping

Allow liquid that remains in the transfer route following termination of motive forces on the liquid to drain to the source tank and/or the destination tank.

Basis: Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.5, following the line flushing described by the Provide Diluent During Transfers function for LAW feed staging (i.e., transfer LAW supernatant to staging tanks), the transfer pump is turned off after pumping chemically adjusted diluent water, and the transfer line is allowed to drain back into the source tank.

Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.16, following transfer to Tank 241-AP-106, a flush is initiated; half of the flush volume drains to Tank 241-AP-106 and half to Tank 241-AP-104.

HNF-1939, Vol. II, Rev. 0a, Addendum 1, Section 3.1.3, describes the process for staging HLW that involves line flushing and identifies the flush volume allowed to drain back to the source tank.

2.2.3.8 Perform Material Balance for Double-Shell Tank Transfers

Perform material balance periodically during the waste conveyance to determine that the amount of waste being delivered to the destination agrees with the amount of waste being removed from the source tank.

Basis: Per HNF-SD-WM-TSR-006, Section 5.12.2.b, a material balance calculation is required during each waste transfer.

Per HNF-1939, Vol. II, Rev. 0a, Addendum 1, Section 1.1.4, the material balance includes mixer-pump seal-water leakage and flush water.

2.2.3.9 Reconfigure Transfer Route

Reconfigure the transfer route valves and jumpers before or after waste transfers.

Basis: Per HNF-SD-WM-TSR-006, Section 5.12.2, transfer system configuration management would isolate waste transfer paths connected to active waste transfer pumps.

2.2.3.10 Perform Material Balance Post Double-Shell Tank Transfer

Perform material balance following completion of waste transfer to determine that the amount of waste delivered to the destination agrees with the amount of waste removed from the source tank.

Basis: Per HNF-SD-WM-TSR-006, Section 5.12.2.b, a material balance calculation is required during each waste transfer.

Per HNF-SP-1224, Rev. 1, Interface Control Document Between the DOE and BNFL Inc. Phase 1 Privatization--High-Level Waste Feed, ICD-20, Section 4.1.3, after the HLW feed batch is received by the Waste Treatment Plant and the pipeline is flushed, differences between the volume of waste received and the volume of waste transferred will be reconciled.

Per HNF-SP-1223, Rev. 1, Interface Control Document Between the DOE and BNFL Inc. Phase 1 Privatization--Low-Activity Waste Feed, ICD-19, Section 4.1.3, after the LAW feed batch is received by the Waste Treatment Plant and the pipeline is flushed, differences between the volume of waste received and the volume of waste transferred will be reconciled.

2.2.4 Fourth-Tier Function Definitions

Function definitions for the fourth-tier set of Transfer Waste functions (see Figures 2.2.1-2 through 2.2.1-8) are given in this section following the applicable third-tier function.

2.2.4.1 Establish Transfer Route for Waste Transfer

2.2.4.1.1 Position Valves for Transfer. Position transfer valves as required to enable the routing of diluent to the transfer pump suction intake and to enable or disable the routing of diluent, waste, or diluent/waste combination across the waste transfer route between the source DST and the destination. This function includes positioning the source DST recirculation valve (1) to enable waste transfer between the source DST and the destination or (2) to enable a recirculation path between the transfer pump intake, through the pump and transfer-associated structure, and back to the DST.

Basis: See basis for Establish Transfer Route for Waste Transfer, Section 2.2.3.1.

2.2.4.1.1.1 Position Manually-Operated Valves. Position manually-operated transfer valves to enable or block waste flow from designated valve ports to achieve transfer routing objectives.

Basis: Per HNF-SD-WM-TSR-006, Section 5.12, Transfer Administrative Controls.

2.2.4.1.1.2 Position Motor-Operated Valves. Position the source DST recirculation valve and other motor-operated valves as needed to establish or reconfigure the waste transfer path between the source DST and the transfer destination for the diluent, waste, or diluent/waste combination. This function includes positioning the valves to establish or reconfigure a

recirculation path for waste and/or diluent to be pumped in a closed loop between the transfer pump suction intake and then back into the source DST.

Basis: *HNF-4553, Operations and Maintenance Philosophy, Section 3.2.*

2.2.4.1.1.2.1 Transmit Motor-Operated Valve Actuation. Transmit motor-operated valve actuation control signal for remote control of valves in the transfer pump pits. This function transmits a control signal to the Receive Motor-Operated Valve Actuation function.

Basis: *HNF-4553, Operations and Maintenance Philosophy, Section 2.0.*

2.2.4.1.1.2.2 Receive Motor-Operated Valve Actuation. Receive remote actuation signal for the motor-operated valves in the transfer pump pits. This function receives a control signal from the Transmit Motor-Operated Valve Actuation function.

Basis: *See basis for Establish Transfer Route for Waste Transfer, Section 2.2.3.1.*

2.2.4.1.1.2.3 Activate Valves for Transfer. Upon receipt of activation signal by the Receive Motor-Operated Valve Actuation function, operate the motor-operated valves to enable or block waste flow from designated valve ports to achieve waste transfer or recirculation routing objectives.

Basis: *See basis for Establish Transfer Route for Waste Transfer, Section 2.2.3.1.*

2.2.4.1.2 Monitor Valve Position. Provide positive local and remote indication of valve position to establish and provide confirmation of the transfer route.

Basis: *Per HNF-4553, Sections 2.1.2 and 3.2, describe local and remote monitoring of valve position.*

2.2.4.1.2.1 Measure Transfer Valve Position. Measure transfer valve positions to obtain transfer valve data.

2.2.4.1.2.2 Display Waste Transfer Valve Position Data (Local). Display transfer valve position indicated by Measure Transfer Valve Position locally.

2.2.4.1.2.3 Compare Transfer Valve Position Data. Compare transfer valve position data with desired position for selected route. This function receives data from the Measure Transfer Valve Position function, compares data, and initiates systems for appropriate action, including initiation of alarms.

2.2.4.1.2.4 Record Transfer Valve Position Data. Record transfer valve position data from Measure Transfer Valve Position function.

2.2.4.1.2.5 Display Transfer Valve Position Data (Remote). Display transfer valve position data from Measure Transfer Valve Position function.

2.2.4.1.3 Respond to Off-Normal Transfer Valve Position. Respond to off-normal transfer valve position indication during a waste transfer to prevent misrouting of waste. This

response may include shutdown of transfer pumps, evaluation of equipment, performing corrective maintenance, positioning valves, and performing a material balance. Figure 2.2.1-2a shows the functional flow for responding to an off-normal transfer valve position. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Shut Down Transfer Pumps	2.1.4.4.9.1
Perform Corrective Maintenance	2.5.7
Position Valves for Transfer	2.2.4.1.1
Perform Material Balance for DST Transfers	2.2.3.10

***Basis:** This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.2.4.2 Provide Diluent During Transfers

2.2.4.2.1 Carry Diluent/Flush Water to Transfer Pump Suction. Provide routing of diluent and/or flush water through the transfer pump to the transfer pump suction intake to support initiation of waste transfer, dilution of waste during the transfer, and subsequent termination of the waste transfer by flushing of the transfer route.

***Basis:** Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Sections 3.1.5, 3.1.8, and 3.1.9, identify diluent and/or flush water provided to the transfer pump.*

2.2.4.2.2 Deliver Diluent/Flush Water to Transfer-Associated Structures. Provide temperature-adjusted diluent at an adjustable flow rate to the transfer-associated structure to support initiation of waste transfer, dilution of waste during the transfer, and subsequent termination of the waste transfer. The initiation of waste transfer includes providing diluent at an increased flow rate, which serves to reduce or deny waste intake at the transfer pump suction intake to support transfer pump startup and preconditioning of the waste transfer route. The dilution of waste during the transfer includes providing diluent with flow rate and temperature adjusted to the levels required to support mobilization of the DST waste and to preclude precipitation of waste solids within the transfer route. The termination of the waste transfer includes providing diluent with flow rate increased to the transfer pump suction intake to reduce or deny waste intake at the transfer pump suction intake just before delivery of the flush water.

***Basis:** See basis for Provide Diluent During Transfers, Section 2.2.3.2.*

2.2.4.2.2.1 Control Diluent/Flush Water Temperature. Control diluent/flush water temperature remotely during waste transfers.

***Basis:** No documented basis found.*

2.2.4.2.2.1.1 Transmit Diluent/Flush Water Temperature Command. Transmit diluent/flush water temperature command as a remote output to control heating the diluent/flush water prior to delivery to the transfer-associated structure.

2.2.4.2.2.1.2 Receive Diluent/Flush Water Temperature Command. Receive diluent/flush water temperature command as a remote input to control heating the diluent/flush water prior to delivery to the transfer-associated structure.

2.2.4.2.2.1.3 Heat Diluent/Flush Water. Heat diluent/flush water in accordance with remote temperature command received.

2.2.4.2.2.2 Control Diluent/Flush Water Flow. Control diluent/flush water flow rate remotely during waste transfers.

Basis: No documented basis found.

2.2.4.2.2.2.1 Transmit Diluent/Flush Water Flow Command. Transmit diluent/flush water flow command as a remote output to control the diluent/flush water flow rate during delivery to the transfer-associated structure.

2.2.4.2.2.2.2 Receive Diluent/Flush Water Flow Command. Receive diluent/flush water flow command as a remote input to control the diluent/flush water flow rate during delivery to the transfer-associated structure.

2.2.4.2.2.2.3 Modulate Diluent/Flush Water Flow. Modulate diluent/flush water flow in accordance with remote water flow command received.

2.2.4.2.2.3 Pump Diluent/Flush Water. Pump diluent/flush water to the transfer-associated structure in support of waste transfers.

Basis: No documented basis found.

2.2.4.2.2.3.1 Transmit Diluent/Flush Water Pump Command. Transmit diluent/flush water pump command as a remote output to control the diluent/flush water pump during delivery to the transfer-associated structure.

2.2.4.2.2.3.2 Receive Diluent/Flush Water Pump Command. Receive diluent/flush water pump command as a remote input to control the diluent/flush water pump during delivery to the transfer-associated structure.

2.2.4.2.2.3.3 Operate Diluent/Flush Water Pump. Operate diluent/flush water pump to provide the motive force as needed to move diluent or flush water to the transfer-associated structure.

2.2.4.2.2.4 Control Diluent/Flush Water Chemical Supply. Control diluent/flush water chemical supply remotely during waste transfers.

Basis: No documented basis found.

2.2.4.2.2.4.1 Transmit Diluent/Flush Water Chemical Supply Command. Transmit diluent/flush water chemical supply command as a remote output to control the diluent chemical composition to support waste transfers.

2.2.4.2.2.4.2 Receive Diluent/Flush Water Chemical Supply Command. Receive diluent/flush water chemical supply command as a remote input to control the diluent chemical composition to support waste transfers.

2.2.4.2.2.4.3 Modulate Diluent/Flush Water Chemical Supply. Modulate diluent/flush water chemical supply in accordance with remote command to control the diluent chemical composition to support waste transfers.

2.2.4.2.3 Confine Diluent/Flush Water Within Valve Manifolds and Jumpers. Confine diluent and flush water within the valve manifolds and jumpers to provide the primary containment boundary for flush water or diluent routed through the pump and valve pits. Jumpers provide containment of flush water and diluent routed through diversion boxes.

Basis: See basis for Provide Diluent During Transfers, Section 2.2.3.2.

2.2.4.2.4 Confine Diluent/Flush Water Within Double-Shell Tank Transfer Piping. Confine diluent and/or flush water to provide primary containment boundary for diluent or flush water routed through DST transfer piping.

Basis: See basis for Provide Diluent During Transfers, Section 2.2.3.2.

2.2.4.2.5 Position Recirculation Valve. Position the source DST recirculation valve to enable or disable waste transfer between the source DST and the destination. If the waste transfer is disabled, the waste transfer path between the source DST and the destination is blocked and a recirculation path is established for waste and/or diluent to be pumped in a closed loop between the transfer pump suction intake, through the transfer pump, within the source DST transfer-associated structure, and back into the source DST. Otherwise, the waste transfer path is established between the source DST and the transfer destination for the diluent, waste, or diluent/waste combination.

Basis: No basis was found to support recirculating supernatant; however, the process control strategy for LAW describes this process.

2.2.4.2.6 Monitor Diluent/Flush Water Parameters. Monitor diluent and flush water parameters while providing diluent or flush water. This function monitors diluent and flush water temperature, pressure, flow rate, chemical composition, valve position, and monitors for diluent or flush water leakage.

Basis: No documented basis found.

2.2.4.2.6.1 Monitor Diluent/Flush Water Temperature. Monitor diluent/flush water temperature to obtain diluent/flush water parameters.

Basis: No documented basis found.

2.2.4.2.6.1.1 Measure Diluent/Flush Water Temperature. Measure diluent/flush water temperature to obtain temperature data.

2.2.4.2.6.1.2 Receive Diluent/Flush Water Temperature. Receive diluent/flush water temperature data from the Measure Diluent/Flush Water Temperature function.

2.2.4.2.6.1.3 Compare Diluent/Flush Water Temperature. Compare diluent/flush water temperature received to the operational limits. This function provides abnormal temperatures to the Respond to Off-Normal Diluent/Flush Water Parameters function.

2.2.4.2.6.1.4 Record Diluent/Flush Water Temperature. Record diluent/flush water temperature data received by the Receive Diluent/Flush Water Temperature function.

2.2.4.2.6.1.5 Display Diluent/Flush Water Temperature. Display diluent/flush water temperature received by the Receive Diluent/Flush Water Temperature function.

2.2.4.2.6.2 Monitor Diluent/Flush Water Pressure. Monitor diluent/flush water pressure to obtain diluent/flush water parameters.

Basis: No documented basis found.

2.2.4.2.6.2.1 Measure Diluent/Flush Water Pressure. Measure diluent/flush water pressure to obtain pressure data.

2.2.4.2.6.2.2 Receive Diluent/Flush Water Pressure. Receive diluent/flush water pressure data from the Measure Diluent/Flush Water Pressure function.

2.2.4.2.6.2.3 Compare Diluent/Flush Water Pressure. Compare diluent/flush water pressure received to the operational limits. This function provides abnormal pressures to the Respond to Off-Normal Diluent/Flush Water Parameters function.

2.2.4.2.6.2.4 Record Diluent/Flush Water Pressure. Record diluent/flush water pressure data received by the Receive Diluent/Flush Water Pressure function.

2.2.4.2.6.2.5 Display Diluent/Flush Water Pressure. Display diluent/flush water pressure received by the Receive Diluent/Flush Water Pressure function.

2.2.4.2.6.3 Monitor Diluent/Flush Water Flow Rate. Monitor diluent/flush water flow rate to obtain diluent/flush water parameters.

Basis: No documented basis found.

2.2.4.2.6.3.1 Measure Diluent/Flush Water Flow Rate. Measure diluent/flush water flow rate to obtain flow rate data.

2.2.4.2.6.3.2 Receive Diluent/Flush Water Flow Rate. Receive diluent/flush water temperature data from the Measure Diluent/Flush Water Flow Rate function.

2.2.4.2.6.3.3 Compare Diluent/Flush Water Flow Rate. Compare diluent/flush water temperature received to the operational limits. This function provides abnormal flow rates to the Respond to Off-Normal Diluent/Flush Water Parameters function.

2.2.4.2.6.3.4 Record Diluent/Flush Water Flow Rate. Record diluent/flush water temperature data received by the Receive Diluent/Flush Water Flow Rate function.

2.2.4.2.6.3.5 Display Diluent/Flush Water Flow Rate. Display diluent/flush water flow rate received by the Receive Diluent/Flush Water Flow Rate function.

2.2.4.2.6.4 Monitor Diluent/Flush Water Chemical Composition. Monitor diluent/flush water chemical composition to obtain diluent/flush water parameters.

Basis: No documented basis found.

2.2.4.2.6.4.1 Measure Diluent/Flush Water Chemical Composition. Measure diluent/flush water chemical composition rate to obtain chemical composition data.

2.2.4.2.6.4.2 Receive Diluent/Flush Water Chemical Composition. Receive diluent/flush water chemical composition data from the Measure Diluent/Flush Water Chemical Composition function.

2.2.4.2.6.4.3 Compare Diluent/Flush Water Chemical Composition. Compare diluent/flush water chemical composition received to the operational limits. This function provides abnormal chemical composition to the Respond to Off-Normal Diluent/Flush Water Parameters function.

2.2.4.2.6.4.4 Record Diluent/Flush Water Chemical Composition. Record diluent/flush water chemical composition data received by the Receive Diluent/Flush Water Chemical Composition function.

2.2.4.2.6.4.5 Display Diluent/Flush Water Chemical Composition. Display diluent/flush water chemical composition received by the Receive Diluent/Flush Water Chemical Composition function.

2.2.4.2.6.5 Monitor Diluent/Flush Water Valve Position. Monitor diluent/flush water valve position to obtain diluent/flush water valve parameters.

Basis: No documented basis found.

2.2.4.2.6.5.1 Measure Diluent/Flush Water Valve Position. Measure diluent/flush water valve position to obtain valve position data.

2.2.4.2.6.5.2 Receive Diluent/Flush Water Valve Position. Receive diluent/flush water valve position data from the Measure Diluent/Flush Water Valve Position function.

2.2.4.2.6.5.3 Compare Diluent/Flush Water Valve Position. Compare diluent/flush water valve position data received to the operational limits. This function provides abnormal valve position data to the Respond to Off-Normal Diluent/Flush Water Parameters function.

2.2.4.2.6.5.4 Record Diluent/Flush Water Valve Position. Record diluent/flush water valve position data received by the Receive Diluent/Flush Water Valve Position function.

2.2.4.2.6.5.5 Display Diluent/Flush Water Valve Position. Display diluent/flush water valve position received by the Receive Diluent/Flush Water Valve Position function.

2.2.4.2.6.6 Monitor for Diluent/Flush Water Leakage. Monitor for diluent/flush water leakage to obtain diluent/flush water leakage parameters.

Basis: No documented basis found.

2.2.4.2.6.6.1 Detect Diluent/Flush Water Leakage. Detect diluent/flush water leakage in the Diluent and Flush Subsystem.

2.2.4.2.6.6.2 Receive Diluent/Flush Water Leak Data. Receive diluent/flush water leak data from the Detect Diluent/Flush Water Leakage function.

2.2.4.2.6.6.3 Compare Diluent/Flush Water Valve Position. Compare diluent/flush water leak data to the operational limits. Provide results of the comparison indicating an off-normal leak detection to the Respond to Off-Normal Diluent/Flush Water Parameters function.

2.2.4.2.6.6.4 Record Diluent/Flush Water Valve Position. Record diluent/flush water leak data received by the Receive Diluent/Flush Water Leak Data function.

2.2.4.2.6.6.5 Display Diluent/Flush Water Valve Position. Display diluent/flush water leak data received by the Receive Diluent/Flush Water Leak Data function.

2.2.4.2.7 Respond to Off-Normal Diluent/Flush Water Parameters. Respond to off-normal DST diluent/flush water parameter indications received from the Compare Diluent/Flush Water Temperature, Pressure, Flow Rate, Chemical Composition, Valve Position, and Leakage functions. This function includes providing signals to equipment and personnel and taking action to restrict diluent/flush water leakage upon detection. This may include shutting down the diluent pump and other actions as required. Figure 2.2.1-3b shows the functional flow for responding to an off-normal DST Diluent/Flush Water Parameter. The sections describing these functions are as follows:

Function	Applicable Section
Shut Down Diluent Pump	2.1.4.4.9.3
Evaluate Equipment Status	2.5.3
Perform Corrective Maintenance	2.5.7

Basis: This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.

2.2.4.2.8 Prevent Waste Backflow. Prevent backflow of waste or contaminated flush or diluent from the transfer pump to the flush/diluent jumper.

Basis: Per HNF-SD-WM-TSR-006, Section 3.1.2, service water pressure detection systems are required during waste transfers.

2.2.4.2.9 Monitor Waste Backflow. Monitor to detect a backflow of waste or contaminated flush or diluent from the transfer pump to the flush/diluent jumper.

Basis: Per HNF-SD-WM-TSR-006, Section 3.1.2, service water pressure detection systems are required during waste transfers.

2.2.4.2.9.1 Detect Waste Backflow. Detect waste backflow of waste or contaminated flush or diluent from the transfer pump to the flush/diluent jumper by measuring backflow parameters and comparing measured data to operating limits. This function provides backflow data to the Compare Waste Backflow function.

2.2.4.2.9.2 Compare Waste Backflow. Compare waste backflow detected to waste backflow operating limits. This function receives data from the Detect Waste Backflow function, compares data to the operating limits, and initiates systems for appropriate action. This includes initiation of alarms.

2.2.4.2.9.3 Record Waste Backflow Detected. Record waste backflow data received by the Receive Waste Backflow Detected function.

2.2.4.2.9.4 Display Waste Backflow Detected. Display waste backflow detection received by the Receive Waste Backflow Detected function.

2.2.4.2.10 Respond to Off-Normal Double-Shell Tank Waste Backflow. Respond to off-normal DST waste backflow indications received from the Compare Waste Backflow function. This function includes providing signals to equipment and personnel and taking action to restrict waste backflow upon detection. This may include shutting down transfer pumps and mixer pumps and other actions, as required. Figure 2.2.1-3a shows the functional flow for responding to an off-normal DST waste backflow. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Shut Down Transfer Pumps	2.1.4.4.9.1
Perform Corrective Maintenance	2.5.7
Flush Transfer System	2.2.4.6
Provide Diluent During Transfers	2.2.4.2

Basis: Per HNF-SD-WM-TSR-006, Section 3.1.2, service water pressure detection systems are required during waste transfers.

This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.

2.2.4.3 Convey Waste

2.2.4.3.1 Position Transfer Pump Suction Intake. Position the transfer pump suction intake at the required height to support transfer of liquid waste at various levels within the DST.

Basis: See basis for Convey Waste, Section 2.2.3.3.

2.2.4.3.1.1 Transmit Pump Intake Position Command. Transmit pump intake position command as a control signal for moving the transfer pump suction intake to the desired height within the DST. The output of this function is provided to the Receive Pump Intake Position Command function.

2.2.4.3.1.2 Receive Pump Intake Position Command. Receive pump intake position command as a remote control input from the Transmit Pump Intake Position Command function.

2.2.4.3.1.3 Reposition Pump Intake. Reposition pump intake in response to the position command by changing pump intake position upon receipt of control input from the Receive Pump Intake Position Command function. This function moves the transfer pump suction intake to the specified height within the DST.

2.2.4.3.2 Pump Waste/Diluent. Provide the motive force to move liquid present at the source DST transfer pump suction intake, through the transfer pump, and along a specified waste transfer route to a transfer destination. The motive force will be adjustable to maintain the flow rate of the liquid through the transfer route.

Basis: See basis for Convey Waste, Section 2.2.3.3.

2.2.4.3.2.1 Transmit Operate Transfer Pump Command. Transmit operate transfer pump command as a control signal for initiating or halting the transfer pump operation or manually controlling pump speed to provide a desired flow or pressure. The output of this function is provided to the Receive Operate Transfer Pump Command function.

2.2.4.3.2.2 Receive Operate Transfer Pump Command. Receive operate transfer pump command as a remote control input from the Transmit Operate Transfer Pump Command function.

2.2.4.3.2.3 Operate Transfer Pump. Operate transfer pump in accordance with control input from the Receive Operate Transfer Pump Command function. This function causes initiation, modification, or halting of the transfer pump operation.

2.2.4.3.3 Confine Waste in Transfer Pump. Confine waste within the transfer pump casing and associated nozzles, flanges, and other pressure boundary connections.

Basis: See basis for Convey Waste, Section 2.2.3.3.

2.2.4.3.4 Monitor Position of Transfer Pump Suction Intake. Provide positive indication of the vertical position of the transfer pump suction intake within the DST.

Basis: See basis for Convey Waste, Section 2.2.3.3.

2.2.4.3.4.1 Measure Position of Transfer Pump Suction Intake. Measure position of transfer pump suction intake to obtain pump intake vertical position data relative to the DST. This function provides the position data to the Compare Transfer Pump Suction Intake Position function.

2.2.4.3.4.2 Compare Transfer Pump Suction Intake Position. Compare transfer pump suction intake position data received to the operational limits.

2.2.4.3.4.3 Record Transfer Pump Suction Intake Position. Record transfer pump suction intake position data from the Receive Transfer Pump Suction Intake Position function.

2.2.4.3.4.4 Display Transfer Pump Suction Intake Position. Display transfer pump suction intake position data from the Receive Transfer Pump Suction Intake Position function.

2.2.4.3.5 Monitor Waste Transfer Parameters. Monitor waste transfer parameters during waste transfer. This function monitors transfer stream flow rate, transfer stream density, pressure in the transfer lines, and transfer stream temperature.

Basis: Per HNF-5146, Rev. 0, Low-Activity Waste Feed Delivery Process Control Strategy, Section 2.3.1, instrumentation is needed for flow, mass flow, and pump outlet pressure in pit piping jumpers.

2.2.4.3.5.1 Monitor Waste Transfer Flow Rate. Monitor waste transfer flow rate during transfers to obtain process parameter data.

Basis: No documented basis found.

2.2.4.3.5.1.1 Measure Waste Transfer Flow Rate. Measure waste transfer flow rate at the transfer pump discharge to obtain waste transfer flow data.

2.2.4.3.5.1.2 Receive Waste Transfer Flow Rate Data. Receive waste transfer flow rate data from the Measure Waste Transfer Flow Rate function.

2.2.4.3.5.1.3 Compare Waste Transfer Flow Rate Data. Compare waste transfer flow rate data received by the Receive Waste Transfer Flow Rate function to the operational limits. Provide results of abnormal flow rates to the Respond to Off-Normal Waste Transfer Parameters function.

2.2.4.3.5.1.4 Record Waste Transfer Flow Rate. Record waste transfer flow rate data received by the Receive Waste Transfer Flow Rate function.

2.2.4.3.5.1.5 Display Waste Transfer Flow Rate. Display Waste Transfer flow rate received by the Receive Waste Transfer Flow Rate function.

2.2.4.3.5.2 Monitor Transfer Pump Discharge Pressure. Monitor transfer pump discharge pressure during transfers to obtain process parameter data.

Basis: No documented basis found.

2.2.4.3.5.2.1 Measure Transfer Pump Discharge Pressure. Measure transfer pump discharge pressure to obtain pump discharge pressure data.

2.2.4.3.5.2.2 Receive Transfer Pump Discharge Data. Receive transfer pump discharge data from the Measure Transfer Pump Discharge Pressure function.

2.2.4.3.5.2.3 Compare Transfer Pump Discharge Pressure Data. Compare waste transfer pump discharge pressure data received from the Receive Transfer Pump Discharge Pressure function to the operational limits. Provide results of abnormal discharge pressure to the Respond to Off-Normal Waste Transfer Parameters function.

2.2.4.3.5.2.4 Record Transfer Pump Discharge Pressure Data. Record transfer pump discharge pressure data from the Receive Transfer Pump Discharge Pressure function.

2.2.4.3.5.2.5 Display Transfer Pump Discharge Pressure Data. Display transfer pump discharge pressure data from the Receive Transfer Pump Discharge Pressure function.

2.2.4.3.5.3 Monitor Waste Transfer Density. Monitor waste transfer density during transfers to obtain waste density data.

Basis: No documented basis found.

2.2.4.3.5.3.1 Measure Waste Transfer Density. Measure waste density at transfer pump discharge to obtain temperature-corrected waste density data. Provide this waste density data to the Compare Waste Transfer Density/Temperature Data function.

2.2.4.3.5.3.2 Measure Waste Transfer Temperature. Measure waste transfer temperature at transfer pump discharge to obtain waste density-corrected temperature data. Provide this temperature data to the Compare Waste Transfer Density/Temperature Data function.

2.2.4.3.5.3.3 Receive Waste Transfer Density/Temperature Data. Receive waste density/temperature data from the Measure Waste Transfer Density and Measure Waste Transfer Temperature functions.

2.2.4.3.5.3.4 Compare Waste Transfer Density/Temperature Data. Compare waste density/temperature data received to the operational limits. If limits are exceeded, provide results to the Respond to Off-Normal Waste Transfer Parameters function. This function initiates systems for appropriate action.

2.2.4.3.5.3.5 Record Waste Transfer Density/Temperature Data. Record waste transfer density data received by the Receive Waste Transfer Density and the Temperature Data functions.

2.2.4.3.5.3.6 Display Waste Transfer Density/Temperature Data. Display waste transfer density/temperature data received by the Receive Waste Transfer Density and the Temperature Data functions.

2.2.4.3.6 Respond to Off-Normal Waste Transfer Parameters. Respond to off-normal waste transfer parameters measured for waste transfer flow rate, transfer pump discharge pressure, waste density, and waste temperature. Figure 2.2.1 4a shows the functional flow for responding to off-normal waste transfer parameters. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Shut Down Transfer Pumps	2.1.4.4.9.1
Perform Corrective Maintenance	2.5.7
Respond to Off-Normal Transfer Pump Operation	2.2.4.3.8
Add Diluent to DST	2.3.3.1.1.3
Operate Mixer Pump	2.3.3.1.1.1.1

Basis: *This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.2.4.3.7 Monitor Transfer Pump Operation. Provide indication of the transfer pump operational parameters. At a minimum, these parameters include measurements of rotational speed and motor power draw.

Basis: *Per WHC-SD-WM-DGS-006, Rev. 0, Tank Farms Pump Critical Characteristic and Specification Guide, Section 4.2.2, all pumps should be instrumented to provide a remote readout of pump motor amperage and pump shaft rotational speed.*

2.2.4.3.7.1 Measure Transfer Pump Operation. Measure transfer pump operation to obtain transfer pump operational data. Parameters measured may include pump rotational speed and motor power draw.

2.2.4.3.7.2 Receive Transfer Pump Operation Data. Receive transfer pump operation data from the Measure Transfer Pump Operation function.

2.2.4.3.7.3 Compare Transfer Pump Operation Data. Compare Transfer Pump Operational Data received by the Receive Transfer Pump Operation Data function to operating limits.

2.2.4.3.7.4 Record Transfer Pump Operation Data. Record transfer pump operation data received by the Receive Transfer Pump Operation Data function.

2.2.4.3.7.5 Display Double-Shell Tank Transfer Pump Operation Data. Display transfer pump operation data received by the Receive Transfer Pump Operation Data function.

2.2.4.3.8 Respond to Off-Normal Transfer Pump Operation. Respond to off-normal transfer pump operation. This may include initiating systems as appropriate (e.g., shutting down the transfer pump if seal pressure is low or motor current is too high). Figure 2.2.1-4b shows the functional flow for responding to off-normal transfer pump operation. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Shut Down Transfer Pumps	2.1.4.4.9.1
Perform Corrective Maintenance	2.5.7

***Basis:** This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.2.4.4 Confine Waste Along Transfer Route

2.2.4.4.1 Confine Waste Within Valve Manifolds and Jumpers. Confine waste within the valve manifolds and jumpers to provide a primary containment boundary for waste routed through the pump and valve pits. Jumpers provide containment of waste routed through diversion boxes.

***Basis:** See basis for Confine Waste Along Transfer Route, Section 2.2.3.4.*

2.2.4.4.2 Confine Waste Within Double-Shell Tank Transfer Piping. Provide primary containment boundary for waste routed through the DST transfer piping.

***Basis:** See basis for Confine Waste Along Transfer Route, Section 2.2.3.4.*

2.2.4.5 Confine Waste Leakage Along Transfer Route

2.2.4.5.1 Confine Waste Leakage Within Transfer-Associated Structures. Confine waste leakage occurring within the transfer-associated structures (i.e., valve pits, pump pits, clean out boxes, and diversion boxes) and waste leaked while in route to the associated DST.

***Basis:** See basis for Confine Waste Leakage Along Transfer Route, Section 2.2.3.5.*

2.2.4.5.2 Confine Waste Leakage Within Secondary Containment Piping. Confine waste leaked from the transfer piping primary containment within the transfer piping secondary containment.

***Basis:** See basis for Confine Waste Leakage Along Transfer Route, Section 2.2.3.5.*

2.2.4.5.3 Monitor for Leaks in Transfer-Associated Structures. Monitor to detect leaks within the transfer-associated structures.

***Basis:** Per HNF-SD-WM-TSR-006, Section 3.1.3, transfer leak detection systems are required.*

2.2.4.5.3.1 Detect Leaks in Transfer-Associated Structures. Detect leaks in transfer-associated structures.

2.2.4.5.3.2 Transmit Transfer-Associated Structure Leak Data. Transmit transfer-associated structure leak sensor data to the Receive Transfer-Associated Structure Leak Data function.

2.2.4.5.3.3 Receive Transfer-Associated Structure Leak Data. Receive transfer-associated structure leak sensor data from the Transmit Transfer-Associated Structure Leak Data function.

2.2.4.5.3.4 Compare Transfer-Associated Structure Leak Data. Compare leak data received by the Receive Transfer-Associated Structure Leak Data function to the operational limits. Provide results of the comparison indicating a waste leak to the Respond to Transfer-Associated Structure Leak function.

2.2.4.5.3.5 Record Transfer-Associated Structure Leak Data. Record transfer-associated structure leak sensor data received by the Receive Transfer-Associated Structure Leak Data function.

2.2.4.5.3.6 Display Transfer-Associated Structure Leak Data. Display transfer-associated structure leak sensor data received by the Receive Transfer-Associated Structure Leak Data function.

2.2.4.5.4 Respond to Off-Normal Leak in Transfer-Associated Structures. Respond to off-normal leak in transfer-associated structure leak indication from the Compare Transfer-Associated Structure Leak Data function. The immediate response is to shutdown the transfer pumps. Additional response actions may include evaluation of equipment, performing corrective maintenance, removing leaked waste from secondary containment, and establishing a new transfer route for waste transfer. Figure 2.2.1-6a shows the functional flow for responding to an off-normal leak in a transfer-associated structure. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Shut Down Transfer Pumps	2.1.4.4.9.1
Remove Leaked Waste From Secondary Containment	2.5.8
Perform Corrective Maintenance	2.5.7
Establish Transfer Route for Waste Transfer	2.2.3.1

Basis: *This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.2.4.5.5 Monitor for Double-Shell Tank Transfer Piping Leakage. Monitor to detect leaks from the transfer piping primary containment boundary drained into the transfer-associated structure via the encasement.

Basis: Per HNF-SD-WM-TSR-006, Section 3.1.3, transfer leak detection systems are required.

2.2.4.5.5.1 Detect Leaks from the Primary Confinement Piping. Detect leaks from the primary confinement piping into the secondary confinement piping.

2.2.4.5.5.2 Compare Primary Confinement Piping Leak Data. Compare primary confinement piping leak data received by the Receive Primary Confinement Piping Leak Detection Data function to the operational limits. Provide results of the comparison indicating a waste leak to the Respond to Primary Confinement Piping Leak function.

2.2.4.5.5.3 Record Primary Confinement Piping Leak Detection Data. Record primary confinement piping leak detection data from the Receive Primary Confinement Piping Leak Detection Data function.

2.2.4.5.5.4 Display Primary Confinement Piping Leak Detection Data. Display primary confinement piping leak detection data received by the Receive Primary Confinement Piping Leak Detection Data function.

2.2.4.5.6 Respond to Off-Normal Double-Shell Tank Transfer Pipe Leak. Respond to off-normal DST transfer pipe leak indication from the Compare Primary Confinement Piping Leak Data function. Figure 2.2.1-6b shows the functional flow for responding to an off-normal DST transfer pipe leak. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Shut Down Transfer Pumps	2.1.4.4.9.1
Remove Leaked Waste From Secondary Containment	2.5.8
Perform Corrective Maintenance	2.5.7
Establish Transfer Route for Waste Transfer	2.2.3.1

Basis: This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.

2.2.4.5.7 Restrict Leakage in Secondary Confinement Piping. Restrict leakage in secondary confinement piping to impede the flow of waste in the secondary confinement drain pipe and to support leak detection.

Basis: Per HNF-SD-WM-TRD-007, the DST System is required to incorporate leak detection features in accordance with WAC 173-303-640.

2.2.4.6 Flush Transfer System

2.2.4.6.1 Position Transfer Valves for Flush. Position transfer valves for flush to enable or block flow of flush solution from designated valve ports to achieve flush routing objectives within the waste transfer route.

Basis: See basis for Establish Transfer Route for Waste Transfer, Section 2.2.3.1.

2.2.4.6.2 Confine Diluent/Flush Water Within Valve Manifolds and Jumpers. Confine flush water within the valve manifolds and jumpers to provide a primary containment boundary for the flush solution routed through the pump and valve pits. Jumpers provide containment of flush water routed through diversion boxes.

Basis: Per HNF-SD-WM-TRD-007, Section 3.3.6.3.1, which specifies confinement.

2.2.4.6.3 Deliver Diluent/Flush Water to Transfer-Associated Structures. Provide temperature-adjusted and chemically adjusted water at an adjustable flow rate to transfer-associated structures to support termination of the waste transfer and corrosion protection of the transfer route. This function supports termination of the waste transfer by providing flush water with flow rate increased to the transfer pump suction intake to reduce or deny waste intake at the transfer pump suction intake, thus allowing the flush water to dilute and remove liquid waste from the transfer path between the source DST and the transfer destination.

Basis: See basis for Flush Transfer System, Section 2.2.3.6.

2.2.4.6.4 Confine Diluent/Flush Water Within Double-Shell Tank Transfer Piping. Confine diluent and/or flush water to provide primary containment boundary for diluent or flush water routed through DST transfer piping.

Basis: See basis for Provide Diluent During Transfers, Section 2.2.3.2.

2.2.4.6.5 Carry Diluent/Flush Water to Transfer Pump Suction. Provide routing of diluent and/or flush water through the transfer pump to the transfer pump suction intake to support initiation of waste transfer, dilution of waste during the transfer, and subsequent termination of the waste transfer by flushing of the transfer route.

Basis: Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Sections 3.1.5, 3.1.8, and 3.1.9, identify diluent and/or flush water provided to the transfer pump.

2.2.4.7 Reconfigure Transfer Route

2.2.4.7.1 Position Transfer Valves for Offline Service. Position transfer valves as required to disable the route for diluent to the transfer pump suction intake and to disable the route for diluent, waste, or diluent/waste combination across the waste transfer route between the source DST and the previous transfer destination. This function includes positioning the source DST recirculation valve to disable waste transfer between the source DST and the destination. This function includes monitoring valve position and responding to an off-normal valve position.

Basis: See basis for Reconfigure Transfer Route, Section 2.2.3.9.

Figure 2.2.1-1. Double-Shell Tank Transfer Waste Functional Flows.

Figure 2.2.1-2. Double-Shell Tank Functional Flow, Establish Transfer Route for Waste Transfer.

*Note: Defined in Section 2.1.3.1.

Figure 2.2.1-2a. Respond to Off-Normal Transfer Valve Position.

Figure 2.2.1-3. Double-Shell Tank Functional Flow, Provide Diluent During Transfers.

Figure 2.2.1-3a. Respond to Off-Normal Double-Shell Tank Waste Backflow.

Figure 2.2.1-3b. Respond to Off-Normal Diluent/Flush Water Parameters.

Figure 2.2.1-4. Double-Shell Tank Functional Flow, Convey Waste.

Figure 2.2.1-4a. Respond to Off-Normal Waste Transfer Parameters.

Figure 2.2.1-4b. Respond to Off-Normal Transfer Pump Operation.

Figure 2.2.1-5. Double-Shell Tank Functional Flow, Confine Waste Along Transfer Route.

Figure 2.2.1-6. Double-Shell Tank Functional Flow, Confine Waste Leakage Along Transfer Route.

Figure 2.2.1-6a. Respond to Off-Normal Leak in Transfer-Associated Structures.

Figure 2.2.1-6b. Respond to Off-Normal DST Transfer Pipe Leak.

Figure 2.2.1-7. Double-Shell Tank Functional Flow, Flush Transfer System.

Figure 2.2.1-8. Double-Shell Tank Functional Flow, Reconfigure Transfer Route.

Figure 2.2.2-1. Double-Shell Tank System Function Hierarchy for Waste Transfer.
(Sheet 1 of 5)

DST = double-shell tank.
HLW = high-level waste.
LAW = low-activity waste.
WTP = Waste Treatment Plant

Figure 2.2.2-1. Double-Shell Tank System Function Hierarchy for Waste Transfer.
(Sheet 2 of 5)

Figure 2.2.2-1. Double-Shell Tank System Function Hierarchy for Waste Transfer.
(Sheet 3 of 5)

Figure 2.2.2-1. Double-Shell Tank System Function Hierarchy for Waste Transfer.

Figure 2.2.2-1. Double-Shell Tank System Function Hierarchy for Waste Transfer.
(Sheet 5 of 5)

Legend

- = Function Block
- = External Function
- = Repeated Function
- DST = double-shell tank.

2.3 PREPARE WASTE FUNCTIONAL DECOMPOSITION

The Prepare Waste functions shown in Figure 2.0 represent those functions that capture operations performed on the stored waste that are needed to support preparing waste for transfer to a staging tank or for transfer to the Privatization Contractor. The Prepare Waste functions at this level (second tier) consist of the following:

- Prepare Waste in East Area Double-Shell Tanks
- Prepare Waste in West Area Double-Shell Tanks¹
- Prepare Low-Activity Waste in Low-Activity Waste Staging Tanks
- Prepare High-Level Waste Sludges in High-Level Waste Staging Tanks.

2.3.1 Third- and Lower-Tier Prepare Double-Shell Tank Waste Functional Flows

The functions described in Sections 2.3.3.1, 2.3.3.2, and 2.3.3.3 represent the decomposition of the second-tier Prepare Double-Shell Tank Waste functions. These “third-tier” and “lower-tier” functions were derived from a review of HNF-1939 and HNF-SD-WM-SP-012.

The functional flows for the third-tier and lower-tier functions are provided for each of the second-tier functions as follows:

- Prepare Waste in East Area Double-Shell Tanks (See Footnote 1) (Figure 2.3.1-1)
 - Mobilize and Suspend Insoluble Waste Within East Area Double-Shell Tanks (Figure 2.3.1-2)
 - Mobilize HLW in Source Tank (Figure 2.3.1-3)
 - Add Diluent to Double-Shell Tank (Figure 2.3.1-4)
 - Dissolve Soluble Waste in East Area Double-Shell Tanks (Figure 2.3.1-5)
 - Soften Crust Layer in Low-Activity Waste Source Tanks (Figure 2.3.1-6)
 - Dissolve Salts in Low-Activity Waste Source Tanks (Figure 2.3.1-7)
- Prepare Low-Activity Waste in Low-Activity Waste Staging Tanks (Figure 2.3.1-8)
 - Soften Crust Layer in Low-Activity Waste Staging Tanks (Figure 2.3.1-9)
 - Add Diluent to Low-Activity Waste Staging Tanks (Figure 2.3.1-10)
 - Dissolve Salts in Low-Activity Waste Staging Tanks (Figure 2.3.1-11)
- Prepare High-Level Waste Sludges in High-Level Waste Staging Tanks (Figure 2.3.1-12).

¹ Functions under Prepare Waste in West Area DSTs were assumed to be the same as those shown for Prepare Waste in East Area DSTs.

2.3.2 Double-Shell Tank Prepare Waste Functional Hierarchy

The hierarchy of Prepare Waste functions representing a decomposition of the second-tier Prepare Waste functions is shown in Figure 2.3.2-1. This figure arranges the Prepare Waste functions derived in the flows of Section 2.3.1 in a hierarchical fashion.

2.3.3 Third- and Lower-Tier Function Definitions

The following function definitions apply to the third-tier and lower-tier function set for preparing waste.

2.3.3.1 Prepare Waste in East Area Double-Shell Tanks

Prepare waste in East Area DSTs for transferring it to another East Area DST. Preparation includes both the mobilization and suspension of insoluble waste (HLW) and the dissolution of soluble waste (LAW) in an East Area DST before transferring it to another East Area DST or an intermediate waste feed staging tank.

2.3.3.1.1 Mobilize and Suspend Insoluble Waste Within East Area Double-Shell Tanks. Mobilize and put into suspension settled HLW solids in East Area DSTs.

Basis: Per HNF-SD-WM-SP-012, Rev. 1, Section 3.2.1.1.3, criteria are described for blending or pre-staging feed batches for Case 3.

2.3.3.1.1.1 Mobilize High-Level Waste in Source Tank. Mobilize existing source tank waste solids/sludge from the bottom of the tank to prepare the waste for transfer to other East Area DSTs.

Basis: Per HNF-SD-WM-SP-012, Rev. 1, Section 3.2.1.1.3, criteria are described for blending or pre-staging feed batches for Case 3.

2.3.3.1.1.1.1 Operate Mixer Pump. Operate mixer pump to provide the motive force to support waste preparation including those actions required to mobilize, suspend, mix, blend, dissolve, or homogenize DST waste. In addition, this function includes stirring the settled sludge layer to prevent overheating of the sludge during interim storage, if required.

Basis: Per HNF-1939, Vol. II, Rev. 0a, Addendum 1, Sections 2.0 and 3.1.4, the mixer pumps may be used to stir the sludge periodically during interim storage.

2.3.3.1.1.1.1.1 Transmit Operate Mixer Pump Command. Transmit operate mixer pump command as a control signal input for initiating, modifying or halting the mixer pump operation. The output of this function is provided to the Receive Operate Mixer Pump Command function.

2.3.3.1.1.1.2 Receive Operate Mixer Pump Command. Receive operate mixer pump command as a remote control input from the Transmit Operate Mixer Pump Command function.

2.3.3.1.1.1.3 Change Mixer Pump Operation. Change mixer pump operation upon receipt of control input from the Receive Operate Mixer Pump Command function. This function causes initiation, modification or halting of the mixer pump operation.

2.3.3.1.1.2 Sample Source Tank High-Level Waste. Collect samples of HLW present in the staging tank in sufficient quantities to support analysis.

Basis: See basis for Sample Staging Tank High-Level Waste, Section 2.3.3.3.5

2.3.3.1.1.3 Add Diluent to Double-Shell Tank. Adjust tank waste composition by adding diluent (heated water and/or heated inhibited water) to the source tank to prepare the waste for transfer or in response to an off-normal condition. Adding diluent to the DST consists of delivering the diluent to the appropriate transfer-associated structure and confining and routing the diluent to the DST.

Basis: Per HNF-1939, Vol. II, Rev 0a, Addendum 1, Section 3.0, Process Description, feed preparation includes maintaining the aqueous Na concentration to comply with the LAW feed specification of 2 M to 5 M Na. Water is added periodically to flush mixer pumps.

2.3.3.1.1.4 Mix/Blend High-Level Waste in Source Tank. Combine waste in the HLW source tank such that a homogenous batch of waste is created for transfer. Mixing of waste within the tank is performed simultaneously with the addition of waste and diluent.

Basis: See basis for Mix/Blend High-Level Waste in Staging Tank, Section 2.3.3.3.1.

Basis: See basis for Mobilize High-Level Waste in Staging Tank, Section 2.3.3.3.2.

2.3.3.1.1.5 Suspend High-Level Waste in Source Tank. Put source tank waste solids into a uniform suspension subsequent to mobilization, so that the waste transferred to other East Area DSTs contains the desired HLW solids.

Basis: See basis for Suspend HLW in Staging Tank, Section 2.3.3.3.3.

2.3.3.1.1.6 Monitor Mixer Pump Operation. Provide indication of the mixer pump operational parameters. At a minimum, these parameters include measurements of motor power draw, rotational speed, and nozzle orientation.

Basis: Per WHC-SD-WM-DGS-006, Rev. 0, Section 4.2.2, mixer pumps should be instrumented to provide a remote readout of pump motor amperage, pump shaft rotational speed, and nozzle orientation.

2.3.3.1.1.6.1 Measure Mixer Pump Operation. Measure mixer pump operation to obtain operational data. Parameters measured may include motor power draw, rotational speed, nozzle orientation, bearing temperature, motor winding temperature, seal water flow, vibration, nozzle rotational speed (in oscillating mode), and discharge pressure.

2.3.3.1.1.6.2 Receive Mixer Pump Operational Parameters. Receive mixer pump operational parameters from the Measure Mixer Pump Operational Parameters function.

2.3.3.1.1.6.3 Compare Mixer Pump Operational Parameters. Compare mixer pump operational parameters to operational limits. Provide results of comparison to the Respond to Off-Normal Mixer Pump Operational Parameters function. This function includes initiating systems and alarms.

2.3.3.1.1.6.4 Record Mixer Pump Operational Parameters. Record mixer pump operational parameters (including alarm status) received from the Receive Mixer Pump Operational Parameters function.

2.3.3.1.1.6.5 Display Mixer Pump Operational Parameters. Display mixer pump operational parameters (including alarm status) received from the Receive Mixer Pump Operational Parameters function.

2.3.3.1.1.7 Respond to Off-Normal Mixer Pump Operational Parameters. Respond to off-normal mixer pump operational parameters by initiating actions that may include evaluation of equipment, performing corrective maintenance, and shutdown of mixer pump. Figure 2.3.1-3a shows the functional flow for responding to off-normal mixer pump operational parameters. The sections describing these functions are as follows:

Function	Applicable Section
Evaluate Equipment Status	2.5.3
Shut Down Mixer Pump	2.1.4.4.9.2
Perform Corrective Maintenance	2.5.7

Basis: *This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.3.3.1.1.7.1 Deliver Diluent/Flush Water to Transfer-Associated Structures. Provide temperature-adjusted diluent at an adjustable flow rate to the transfer-associated structure to support initiation of waste transfer, dilution of waste during the transfer, and subsequent termination of the waste transfer. The initiation of waste transfer includes providing diluent at an increased flow rate, which serves to reduce or deny waste intake at the transfer pump suction intake to support transfer pump startup; and preconditioning of the waste transfer route. The dilution of waste during the transfer includes providing diluent with flow rate and temperature adjusted to the levels required to support mobilization of the DST waste and to preclude precipitation of waste solids within the transfer route. The termination of the waste transfer includes providing diluent with the flow rate increased to the transfer pump suction intake to reduce or deny waste intake at the transfer pump suction intake just before delivery of the flush water.

Basis: *See basis for Provide Diluent During Transfers, Section 2.2.3.2.*

2.3.3.1.1.7.2 Confine Diluent/Flush Water Within Valve Manifolds and Jumpers.

Confine caustic and diluent within the valve manifolds and jumpers to provide primary containment boundary for diluent and/or flush water routed through the pump and valve pits. Jumpers provide containment of diluent and/or flush water routed through diversion boxes.

Basis: See basis for Provide Diluent During Transfers, Section 2.2.3.2.

2.3.3.1.1.7.3 Confine Diluent/Flush Water Within Double-Shell Tank Transfer Piping. Confine diluent and/or flush water to provide a primary containment boundary for diluent or flush water routed through DST transfer piping.

Basis: See basis for Provide Diluent During Transfers, Section 2.2.3.2

2.3.3.1.2 Dissolve Soluble Waste in East Area Double-Shell Tank. Dissolve soluble waste in East Area DSTs for transfer to the LAW/HLW Plant, Phase 1. Dissolution includes the softening/dissolving existing crust layers, as necessary, dissolving the soluble salts in the nonconvective layers of waste, settling out the undissolved solids, and sampling the prepared LAW for analysis.

Basis: Per HNF-SD-WM-SP-012, Rev. 1, Section 3.4.1.2, salt sludges are dissolved.

2.3.3.1.2.1 Soften Crust Layer in Low-Activity Waste Source Tanks. Soften and partially dissolve the floating solids layer in the tank by adding diluent or by recirculating diluted supernatant from the convective layer in the tank to the top of the waste.

Basis: Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 2.0, the crust and salt sludge are dissolved with a bulk addition of diluent augmented by mixer pump agitation.

No basis was found to support recirculating supernatant; however, the process control strategy for LAW describes this process.

2.3.3.1.2.1.1 Add Diluent to Double-Shell Tank. Add diluent water (bulk addition) to adjust the waste composition and support dissolution of salt within the tank.

Basis: Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.9, Tank 241-AN-104 processes include dissolving crust and salt sludge with a bulk addition of diluent (heated water).

Per HNF-SD-WM-SP-012, Rev. 1, Section 3.4.1.2, following decanting of the liquid within the LAW feed tanks, salt sludge is dissolved in place with a bulk addition of water.

2.3.3.1.2.1.2 Recirculate Waste Within Double-Shell Tank. Recirculate waste within the DST using the transfer pump. This function supports initiating waste transfers and mixing tank contents in a closed loop within the DST.

Basis: No basis was found; however, HNF-5146 describes this process.

2.3.3.1.2.2 Dissolve Salts in Low-Activity Waste Source Tanks. Dissolve settled undissolved salts in the LAW source tank's nonconvective layer via dilution, waste mobilization, and mixing.

Basis: See basis for Dissolve Salts in Low-Activity Waste Staging Tanks, Section 2.3.3.2.4.

2.3.3.1.2.2.1 Add Diluent to Double-Shell Tank. Add diluent to the DST to support adjusting waste composition and dissolution of salt within the tank and in response to off-normal conditions.

Basis: Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.9, Tank 241-AN-104 processes include dissolving crust and salt sludge with a bulk addition of diluent (heated water).

Per HNF-SD-WM-SP-012, Rev. 1, Section 3.4.1.2, following decanting of the liquid within the LAW feed tanks, salt sludge is dissolved in place with a bulk addition of water.

2.3.3.1.2.2.2 Mobilize Solids in Low-Activity Waste Source Tanks. Mobilize waste in low-activity waste source tanks to facilitate dissolution.

Basis: Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.10, mixer pumps are operated subsequent to the addition of diluent water to dissolve salt sludge.

2.3.3.1.2.3 Settle Undissolved Solids. Stop mixer pump, transfer pump, and other LAW feed activities to allow undissolved solids to settle after the waste is dissolved to prepare for sampling and LAW transfer.

Basis: See basis for Settle Undissolved Solids, Section 2.3.3.2.3.

2.3.3.1.2.4 Sample Prepared Low-Activity Waste. Collect samples to verify that the waste meets waste compatibility requirements and to qualify waste being transferred directly to BNFL Inc.

Basis: See basis for Sample Staging Tank Low-Activity Waste, Section 2.3.3.2.5.

2.3.3.2 Prepare Low-Activity Waste in Low-Activity Waste Staging Tanks

Prepare LAW in LAW staging tanks for transfer to the LAW/HLW Plant, Phase 1. Preparation includes the initial dissolution of existing soluble staging tank waste, the mixing/blending of waste from various source tanks (including staging tank heel), the settling of undissolved solids, and sampling the prepared LAW for analysis.

2.3.3.2.1 Homogenize Waste Batches. Combine existing waste in the LAW staging tanks with waste being transferred to the LAW staging tank such that a homogenous batch of LAW is created for LAW feed. Mixing of waste within the staging tank is performed simultaneously with the addition of waste from source tanks.

Basis: Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.6, a single mixer pump is operated for a short duration for liquid-phase homogenization for Tank 241-AP-102.

Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.14, a mixer pump is operated for a short duration for liquid-phase homogenization for Tank 241-AP-104.

2.3.3.2.2 Soften Crust Layer in Low-Activity Waste Staging Tanks. Soften and partially dissolve the floating solids layer within the waste staging tanks by adding diluent or by recirculating diluted supernatant from the convective layer of waste in the tank to the top of the waste.

Basis: *See basis for Soften Crust Layer in Low-Activity Waste Source Tanks, Section 2.3.3.1.2.1.*

2.3.3.2.2.1 Add Diluent to Double-Shell Tank. Add diluent water (bulk addition) to adjust the waste composition and support dissolution of salt within the tank.

Basis: *Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.9, Tank 241-AN-104 processes include dissolving crust and salt sludge with a bulk addition of diluent (heated water).*

Per HNF-SD-WM-SP-012, Rev. 1, Section 3.4.1.2, following decanting of the liquid within the LAW feed tanks, salt sludge is dissolved in place with a bulk addition of water.

2.3.3.2.2.2 Recirculate Waste Within Double-Shell Tank. Recirculate waste in the tank using the transfer pump.

Basis: *No basis was found; however, HNF-5146 describes this process.*

2.3.3.2.3 Settle Undissolved Solids. Stop mixer pump, transfer pump, and other LAW feed activities to allow undissolved solids to settle after the waste is dissolved to prepare for sampling and LAW transfer.

Basis: *Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Sections 2.0 and 3.1.3, small amounts of insoluble solids that are mobilized during dissolution are allowed to settle out in Tank 241-AN-104.*

2.3.3.2.4 Dissolve Salts in Low-Activity Waste Staging Tanks. Dissolve settled undissolved salts in the waste staging tank's nonconvective layer via dilution and waste mobilization.

Basis: *Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Sections 2.0 and 3.10, Tank 241-AN-104 preparation involves processes that include dissolving crust and salt sludge with a bulk addition of diluent (heated water) augmented by mixer pump agitation.*

Per Letter No. 73600-99-006, Section 1.0, following removal of supernatant in Tanks 241-AN-103, 241-AN-104, 241-AN-105, and 241-AW-101, water is added and mixer pumps are used to mix the contents to dissolve the soluble salts.

2.3.3.2.4.1 Mobilize Solids in Low-Activity Waste Staging Tanks. Operate mixer pumps to facilitate dissolution.

Basis: *Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.10, mixer pumps are operated subsequent to the addition of diluent water to dissolve salt sludge.*

2.3.3.2.5 Sample Staging Tank Low-Activity Waste. Collect samples of LAW to monitor solids settling, salt dissolution, crust softening, or blending in the staging tank.

Basis: Per HNF-1939, Vol. II, Rev. 0c, Addendum 3, Section 3.1.11, process control samples are taken to track the status of the salt dissolution process step for Tank 241-AN-104.

2.3.3.3 Prepare High-Level Waste Sludges in High-Level Waste Staging Tanks

Prepare HLW Sludges in HLW staging tanks for transfer to the Waste Treatment Plant, Phase 1. Preparation includes the initial mobilization of existing staging-tank waste, the mixing/blending of waste from various source tanks (including staging-tank heel), sampling the mixed waste for analysis and resuspending the staging tank waste as necessary before transferring the staging-tank waste to the Waste Treatment Plant, Phase 1.

Basis: Per HNF-SD-WM-SP-012, Rev. 1, Section 3.2.1.3.3, reference is made to transfers needed to blend or pre-stage certain feed batches.

2.3.3.3.1 Mix/Blend High-Level Waste in Staging Tank. Combine existing waste in the high-level waste (HLW) staging tank with the waste being transferred to the HLW staging tank such that a homogenous batch of waste is created for HLW feed. Mixing of waste within the staging tank is performed simultaneously with the addition of waste from other source tanks.

Basis: Per HNF-SD-WM-SP-012, Vol. I, Section 2.4, waste from Tanks 241-AW-105 and 241-C-102 are both split then blended to make batches 8 and 9. Per Section 3.2, life-cycle cost is reduced by blending HLW source tanks, which increases waste oxide loading in glass and decreases the total amount of immobilized HLW canisters produced. Per Vol. II, Appendix A, Section 8.6, waste from Tanks 241-C-104 and 241-C-106/241-AY-102 will be blended to increase waste oxide loading in the HLW glass.

2.3.3.3.2 Mobilize High-Level Waste in Staging Tank. Mobilize existing settled staging-tank waste solids/sludge to prepare the first feed batches for transfer to the Waste Treatment Plant, Phase 1.

Basis: Per HNF-1939, Vol. II, Rev. 0a, Addendum 1, Section 3.1.1, staging HLW feed from Tank 241-AZ-101 is a matter of mobilizing the contents.

2.3.3.3.3 Suspend High-Level Waste in Staging Tank. Put staging-tank waste solids into a uniform suspension within the liquid phase of the waste subsequent to the initial mobilization or mix/blend step so that the waste transferred to the Waste Treatment Plant, Phase 1 contains the desired HLW solids.

Basis: Per HNF-SD-WM-SP-012, Rev. 1, Sections 3.2.1.1.3 and 3.4.1.1, feed preparation includes blending and mobilizing sludges.

2.3.3.3.4 Add Diluent to Double-Shell Tank. See Section 2.3.3.1.1.3.

2.3.3.3.5 Sample Staging Tank High-Level Waste. Collect samples of HLW present in the staging tank in sufficient quantities to support feed certification.

Basis: *Per HNF-SD-WM-SP-012, Rev. 1, Section 2.4, HLW retrieved from selected source tanks will be transferred to staging tanks and certified before delivery to the Waste Treatment Plant.*

Figure 2.3.1-1. Prepare Waste in East Area Double-Shell Tanks Functional Flow.

Figure 2.3.1-2. Mobilize and Suspend Insoluble Waste Within East Area Double-Shell Tanks Functional Flow.

Figure 2.3.1-3. Mobilize High-Level Waste in Source Tank.

Figure 2.3.1-3a. Respond to Off-Normal Mixer Pump Operational Parameters.

Figure 2.3.1-4. Add Diluent to Double-Shell Tank Functional Flow.

Figure 2.3.1-5. Dissolve Soluble Waste in East Area Double-Shell Tanks Functional Flow.

Figure 2.3.1-6. Soften Crust Layer in Low-Activity Waste Source Tanks Functional Flow.

Figure 2.3.1-7. Dissolve Salts in Low-Activity Waste Source Tanks Functional Flow.

Figure 2.3.1-8. Prepare Low-Activity Waste in Low-Activity Waste Staging Tanks Functional Flow.

Figure 2.3.1-9. Soften Crust Layer in Low-Activity Waste Staging Tanks Functional Flow.

Figure 2.3.1-10. Add Diluent to Low-Activity Waste Staging Tanks.

Figure 2.3.1-11. Dissolve Salts in Low-Activity Waste Staging Tanks Functional Flow.

Figure 2.3.1-12. Prepare High-Level Waste Sludges in High-Level Waste Staging Tanks Functional Flow.

Figure 2.3.2-1. Double-Shell Tank System Function Hierarchy for Prepare Waste.
(Sheet 1 of 2)

Figure 2.3.2-1. Double-Shell Tank System Function Hierarchy for Prepare Waste.
(Sheet 2 of 2)

2.4 DISTRIBUTE DOUBLE-SHELL TANK UTILITIES FUNCTIONAL DECOMPOSITION

The Distribute Utilities in Double-Shell Tank System function is identified in Figure 2.0. This function contains the system behavior regarding distribution of electricity, water (both raw and potable), service air, and instrument air to support the operation and maintenance of the DST System.

2.4.1 Distribute Utilities Function Flows

The function flows for distribution of utilities are not provided in this version.

2.4.2 Double-Shell Tank Distribute Utilities Function Hierarchy

The hierarchy of distribute utilities functions, representing a decomposition of the Distribute Utilities in DST System function, is shown in Figure 2.4.2-1.

2.4.3 Definitions for Distribute Utilities Within the Double-Shell Tank System

Function definitions for the Distribute Utilities function set are given below.

2.4.3.1 Distribute Double-Shell Tank Electrical Power

Transform, control, protect, and distribute electrical power to support the operations and maintenance of electrical loads of the DST System.

Basis: HNF-SD-WM-TRD-007, Section 3.2.1.5.a, Distribute Utilities in Double-Shell Tank System, and Section 3.2.3.8, Central Plateau Electrical System.

2.4.3.1.1 Distribute 480/277 V ac Electrical Power. Transform, control, protect, and distribute 480/277 V ac electrical power to DST System components.

Basis: No documented basis found.

2.4.3.1.2 Light Double-Shell Tank System. Light exterior portions of the DST System to facilitate backshift operations and maintenance.

Basis: DOE Order 6430.1A, General Design Criteria, Section 1650-1, External Lighting—General.

2.4.3.1.3 Distribute 240/120 V ac and/or 208/120 V ac Electrical Power. Transform, control, protect, and distribute 240/120 and/or 208/120 V ac electrical power to DST System components.

Basis: No documented basis found.

2.4.3.1.4 Provide Backup Electrical Power for the Double-Shell Tank System.

Generate, control, protect, and distribute backup electrical power for DST System components requiring electrical power, in the event of normal power loss.

Basis: DOE 6430.1A, Section 1660.1, Special Systems—General.

2.4.3.2 Distribute Water Within the Double-Shell Tank System

Strain, control, filter, and distribute raw and potable water within the DST System to support operations, including water needed for industrial safety and fire protection.

Basis: HNF-SD-SM-TRD-007, Section 3.2.1.5.c, Distribute Utilities in Double-Shell Tank System.

HNF-2938, Evaluation of 241-AN Tank Farm, Supporting Phase 1 Waste Feed Delivery, Appendix F.1.4, Calculation of Solids Deposition Velocity.

2.4.3.2.1 Distribute Raw Water Within the Double-Shell Tank System. Control and distribute raw water within the DST System to support operations, including water needed for industrial safety and fire protection.

Basis: HNF-2938, Appendix F.1.4, Calculation of Solids Deposition Velocity.

2.4.3.2.2 Distribute Potable Water Within the Double-Shell Tank System. Control and distribute potable water to the DST Diluent and Flush Subsystem.

Basis: DOE Order 6430.1A, Section 1540.15, Safety Devices.

2.4.3.2.3 Monitor Double-Shell Tank Service Water. Monitor service water usage to detect leaks that could fill and overflow tanks. Monitoring includes measuring, transmitting, receiving, comparing, displaying, and recording service water usage.

Basis: Per HNF-SD-WM-TSR-006, AC 5.21, "Tank Service Water Intrusion Monitoring Program," this monitoring is needed.

2.4.3.2.3.1 Measure Service Water Usage. Measure totalized flow to each tank farm connected to the service (raw) water system.

2.4.3.2.3.2 Transmit Service Water Totalized Flow. Transmit totalized flow data from the Measure Service Water Usage function.

2.4.3.2.3.3 Receive Service Water Totalized Flow. Receive service water totalized flow data from the Transmit Service Water Totalized Flow function.

2.4.3.2.3.4 Compare Service Water Totalized Flow Data. Compare service water totalized flow data to service water demand to detect any unsubstantiated service water flow.

2.4.3.2.3.5 Display Service Water Totalized Flow Data. Display total service water flow data and service water off-normal flow alarm.

2.4.3.2.3.6 Record Service Water Totalized Flow Data. Record service water totalized flow and off-normal flow alarm data.

2.4.3.2.4 Respond to Off-Normal Service Water Totalized Flow. Respond to off-normal service water totalized flow. Response actions may include evaluating equipment status, shutdown of service water supply to DST, and performing corrective maintenance.

***Basis:** This set of responses is intended to identify the appropriate response to an off-normal set of conditions and is the result of discussions with Project Definition and Tank Farm Operations.*

2.4.3.3 Distribute Service Air Within the Double-Shell Tank System

Condition and distribute service air to DST System components, including the DST instrument air system.

***Basis:** HNF-SD-SM-TRD-007, Section 3.2.1.5.c, Distribute Utilities in Double-Shell Tank System.*

2.4.3.4 Distribute Instrument Air Within the Double-Shell Tank System

Condition and distribute instrument air to the DST Monitor and Control Subsystem.

***Basis:** HNF-SD-SM-TRD-007, Section 3.2.1.5.c, Distribute Utilities in Double-Shell Tank System.*

Figure 2.4.2-1. Double-Shell Tank System Function Hierarchy for Distribute Utilities.

2.5 SUPPORT DOUBLE-SHELL TANK SYSTEM FUNCTIONAL DECOMPOSITION

The Support DST System function is identified in Figure 2.0. This function contains the system behavior regarding support services needed by the DST System and includes functions for evaluation of equipment status, management and tracking of spare parts, supply tooling, preventive and corrective maintenance, removing leaked waste, and providing auxiliary ventilation.

2.5.1 Support System Function Flows

The function flow listed below represents the decomposition of the second-tier Support DST System function into a set of third-tier functions (see Figure 2.5.1-1):

- Evaluate Equipment Status
- Manage Spares
- Supply Tooling
- Perform Preventive Maintenance
- Perform Corrective Maintenance
- Remove Leaked Waste from Secondary Containment
- Provide Auxiliary Ventilation.

The Support System function is a “floating” function and will be accessed as such during the operation of the DST System from many of the functions noted herein.

2.5.2 Support Double-Shell Tank System Function Hierarchy

The functional hierarchy representing the decomposition of the second-tier Support DST System functions is shown in Figure 2.5.2-1 along with the third tier functions.

Function definitions for the third-tier functions are provided in the following sections.

2.5.3 Evaluate Equipment Status

Evaluate equipment status by analyzing collected data to determine if equipment needs to be repaired, adjusted, or replaced. This function includes analysis of data and verification of equipment.

Basis: No documented basis found.

2.5.3.1 Assess Equipment Status

Assess equipment status to determine when a component requires maintenance or when additional data are required for further analysis. This function includes verification and testing of subsystems to determine equipment operability.

Basis: No documented basis found.

2.5.3.2 Analyze Equipment Status

Analyze equipment status and performance trends to detect failed equipment or pending equipment failure.

Basis: No documented basis found.

2.5.4 Manage Spares

Manage spares acquired as needed to support maintenance and recovery work on subsystems. This function includes acquiring, preparing, storing, issuing, and tracking spares.

Basis: No documented basis found.

2.5.4.1 Acquire Parts as Spares

Purchase and receive parts on Site and maintain spares inventory.

Basis: No documented basis found.

2.5.4.2 Prepare Parts for Spares

Prepare parts for storage and issuance as spares including, but not limited to, any packaging, testing, and equipment run-in.

Basis: No documented basis found.

2.5.4.3 Store Spares

Provide storage for spares. This function includes controlling the storage facility environment.

Basis: No documented basis found.

2.5.4.4 Issue Spares

Issue spares to maintenance personnel to support preventive and corrective maintenance.

Basis: No documented basis found.

2.5.4.5 Track Spares

Track spares including entry of the received parts, quantity on hand, required quantities, location, shelf time, and usage rate.

Basis: No documented basis found.

2.5.5 Supply Tooling

Supply tooling by fabricating, storing, and issuing, and by replacing damaged tools.

Basis: No documented basis found.

2.5.6 Perform Preventive Maintenance

Perform preventive maintenance as required to support DST operations. This function includes performing preventive maintenance on DST subsystems, including the DST Transfer Pump Subsystem, DST Mixer Pump Subsystem, DST Ventilation Subsystem, DST Diluent and Flush Subsystem, DST Transfer Valving Subsystem, DST Transfer Piping Subsystem, DST Utilities subsystems, DST Confinement Subsystem, DST Monitor and Control Subsystem, the DST Process Waste Sampling Subsystem, and the DST Maintenance and Recovery Subsystem.

Basis: Per HNF-SD-WM-TRD-007, Section 3.2.5.2.1, "Design Life," and Section 3.7.12 require or imply the need for logistical support of the DST System.

2.5.7 Perform Corrective Maintenance

Perform corrective maintenance (repair, adjustment, and/or replacement) of equipment as needed to support operations. This function includes performing preventive maintenance on DST subsystems, including the DST Transfer Pump Subsystem, DST Mixer Pump Subsystem, DST Ventilation Subsystem, DST Diluent and Flush Subsystem, DST Transfer Valving Subsystem, DST Transfer Piping Subsystem, DST Utilities subsystems, DST Confinement Subsystem, DST Monitor and Control Subsystem, and the DST Process Waste Sampling Subsystem.

Basis: Per HNF-SD-WM-TRD-007, Section 3.2.5.2.1, "Design Life," and Section 3.7.12 require or imply the need for logistical support of the DST System.

2.5.8 Remove Leaked Waste from Secondary Containment

Remove leaked waste from secondary containment that has been collected. This function removes the leaked waste in support of restoring the failed containment system.

Basis: No documented basis found.

2.5.9 Provide Auxiliary DST Ventilation

Provide auxiliary ventilation to maintain DST ventilation when the DST Ventilation Subsystem is not available. This function supports repairs of the DST Ventilation Subsystem by providing supplemental ventilation for removing heat from the waste, removing flammable gas, and maintaining the required tank pressure differentials with the atmosphere.

Basis: *No documented basis found.*

2.5.10 Adjust Chemical Composition

Adjust chemical composition of the DST waste by adding bulk chemicals or diluent water. This function supports maintaining the DST waste chemical composition or responding to an off-normal waste composition.

Basis: *Per OSD-T-151-00007, Operating Specifications for the 241-AN, AP, AW, AY, AZ, & SY Tank Farms, Section 7.2.1, nitrate, nitrite, and hydroxide concentrations are controlled.*

Per OSD-T-151-00017, Operating Specifications for Aging Waste Operations in 241-AY and 241-AZ, Section 17.4.1.1.3, maximum hydroxide concentrations are controlled.

Per OSD-T-151-00017, Section 17.4.1.1.4, maximum nitrite and nitrate concentrations are controlled.

Figure 2.5.1-1. Support Double-Shell Tank System Functional Flows.

Figure 2.5.2-1. Support Double-Shell Tank System Functional Hierarchy.

This page intentionally left blank.

3.0 ALLOCATION OF FUNCTIONS TO DOUBLE-SHELL TANK COMPONENTS

The traceability between DST System functions and DST components is provided for the following components:

- DST Transfer Pump Subsystem
- DST Mixer Pump Subsystem
- DST Ventilation Subsystem
- DST Diluent and Flush Subsystem
- DST Transfer Valving Subsystem
- DST Transfer Piping Subsystem
- DST Utilities Subsystems
- DST Confinement Subsystem
- DST Monitor and Control Subsystem
- DST Process Waste Sampling Subsystem
- DST Maintenance and Recovery Subsystem.

Traceability between these components and the Store Waste, Transfer Waste, Prepare Waste, Distribute Utilities, and Support DST System functions are provided as follows:

- Store Waste Functions (see Figure 3.0-1)
- Transfer Waste Functions (see Figure 3.0-2)
- Prepare Waste Functions (see Figure 3.0-3)
- Distribute Utilities Functions (see Figure 3.0-4)
- Support DST System (see Figure 3.0-5).

Second-Tier Functions

Figure 3.0-1. Store Waste Function Applications to Double-Shell Tank Components.
(Sheet 1 of 3)

Second-Tier Functions

Figure 3.0-1. Store Waste Function Applications to Double-Shell Tank Components.
(Sheet 2 of 3)

Figure 3.0-1. Store Waste Function Applications to Double-Shell Tank Components. (Sheet 3 of 3)

Second-Tier Functions

Store Waste in East and West Area DSTs

Third-Tier Functions

Control DST Primary Confinement Leaks
2.1.3.5

Control DST Gaseous Discharge
2.1.3.6

Confine Waste Within DSTs (8)
2.1.3.7

Fourth-Tier Functions

Monitor DST Annulus for Primary Leaks (9)
2.1.4.5.1

Monitor DST Annulus Air for Primary Leaks (9)
2.1.4.5.2

Contain Primary Confinement Leaks (8)
2.1.4.5.3

Respond to Off-Normal DST Leak in Primary Tank
2.1.4.5.4

Monitor DST Primary Gaseous Discharge (3)
2.1.4.6.1

Monitor DST Annulus Gaseous Discharge (3)
2.1.4.6.2

Monitor DST Flammable Gas Concentration (3)
2.1.4.6.3

Maintain DST Primary Gaseous Discharge Within Limits (3)
2.1.4.6.4

Maintain DST Annulus Gaseous Discharge Within Limits (3)
2.1.4.6.5

Respond to Off-Normal DST Gaseous Discharge
2.1.4.6.6

Respond to Off-Normal DST Flammable Gas Concentration
2.1.4.6.7

Monitor Ventilation System Operation
2.1.4.6.8

Respond to Off-Normal DST Ventilation
2.1.4.6.9

Evaluate Equipment Status (11)
2.5.3

Evaluate Equipment Status (11)
2.5.3

Evaluate Equipment Status (11)
2.5.3

Perform Corrective Maintenance (11)
2.5.7

Perform Corrective Maintenance (11)
2.5.7

Perform Corrective Maintenance (11)
2.5.7

Shut Down Transfer Pumps (9)
2.1.4.4.9.1

Shut Down Transfer Pumps (9)
2.1.4.4.9.1

Shut Down Transfer Pumps (9)
2.1.4.4.9.1

Shut Down Mixer Pump (9)
2.1.4.4.9.2

Shut Down Mixer Pump (9)
2.1.4.4.9.2

Shut Down Mixer Pump (9)
2.1.4.4.9.2

Shut Down Ventilation (3)
2.1.4.4.5.1

Respond to Off-Normal DST Ventilation
2.1.4.6.9

Provide Auxiliary DST Ventilation (11)
2.5.9

DST Component References

- (1) DST Transfer Pump Subsystem
- (2) DST Mixer Pump Subsystem
- (3) DST Ventilation Subsystem
- (4) DST Diluent and Flush Subsystem
- (5) DST Transfer Valving Subsystem
- (6) DST Transfer Piping Subsystem
- (7) DST Utilities Subsystems
- (8) DST Confinement Subsystem
- (9) DST Monitor and Control Subsystem
- (10) DST Process Waste Sampling Subsystem
- (11) DST Maintenance and Recovery Subsystem

Legend
[Solid Box] = Function Block
[Dashed Box] = External Function
[Dotted Box] = Repeated Function
DST = double-shell tank

Figure 3.0-2. Transfer Waste Functions Applicable to Double-Shell Tank Components.
(Sheet 1 of 5)

DST = double-shell tank.
HLW = high-level waste.
LAW = low-activity waste.
WTP = Waste Treatment Plant

Figure 3.0-2. Transfer Waste Functions Applicable to Double-Shell Tank Components.
(Sheet 3 of 5)

- DST Component References**
- (1) DST Transfer Pump Subsystem
 - (2) DST Mixer Pump Subsystem
 - (3) DST Ventilation Subsystem
 - (4) DST Diluent and Flush Subsystem
 - (5) DST Transfer Pumping Subsystem
 - (6) DST Transfer Piping Subsystem
 - (7) DST Utilities Subsystem
 - (8) DST Confinement Subsystem
 - (9) DST Monitor and Control Subsystem
 - (10) DST Process Waste Sampling Subsystem
 - (11) DST Maintenance and Recovery Subsystem

- Legend**
- Function Block
 - External Function
 - Repeated Function
 - DST = double-shell tank

Figure 3.0-2. Transfer Waste Functions Applicable to Double-Shell Tank Components.
(Sheet 4 of 5)

Figure 3.0-2. Transfer Waste Functions Applicable to Double-Shell Tank Components.
(Sheet 5 of 5)

DST Component References	
(1)	DST Transfer Pump Subsystem
(2)	DST Mixer Pump Subsystem
(3)	DST Ventilation Subsystem
(4)	DST Diluent and Flush Subsystem
(5)	DST Transfer Valving Subsystem
(6)	DST Transfer Piping Subsystem
(7)	DST Utilities Subsystems
(8)	DST Confinement Subsystem
(9)	DST Monitor and Control Subsystem
(10)	DST Process Waste Sampling Subsystem
(11)	DST Maintenance and Recovery Subsystem

Legend	
	Function Block
	External Function
	Repeated Function
DST = double-shell tank.

Figure 3.0-3. Prepare Waste Tank Functions Applicable to Double-Shell Tank Components.
 (Sheet 2 of 2)

Figure 3.0-4. Distribute Utilities Functions Applicable to Double-Shell Tank System Components.

- DST Component References**
- (1) DST Transfer Pump Subsystem
 - (2) DST Mixer Pump Subsystem
 - (3) DST Ventilation Subsystem
 - (4) DST Diluent and Flush Subsystem
 - (5) DST Transfer Valving Subsystem
 - (6) DST Transfer Piping Subsystem
 - (7) DST Utilities Subsystems
 - (8) DST Confinement Subsystem
 - (9) DST Monitor and Control Subsystem
 - (10) DST Process Waste Sampling Subsystem
 - (11) DST Maintenance and Recovery Subsystem

Legend

- [Solid Box] = Function Block
- [Dashed Box] = External Function
- [Dotted Box] = Repeated Function
- DST = double-shell tank.
- V ac = volts alternating current.

Figure 3.0-5. Support Double-Shell Tank System Functional Applicable to Double-Shell Tank Components.

This page intentionally left blank.

4.0 REFERENCES

- DOE Order 6430.1A, 1989, *General Design Criteria*, U.S. Department of Energy, Washington, D.C.
- HNF-1939, 1999, *Waste Feed Delivery Technical Basis*, Vol. II, Rev. 0a, Addendum 1, "Waste Feed Delivery Flowsheet for Tank 241-AZ-101," Numatec Hanford Corporation for Fluor Daniel Hanford, Inc., Richland, Washington
- HNF-1939, 1999, *Waste Feed Delivery Technical Basis*, Vol. II, Rev. 0c, Addendum 3, "Waste Feed Delivery Flowsheet for Tank 241-AN-104," Numatec Hanford Corporation for Fluor Daniel Hanford, Richland, Washington
- HNF-2939, 1999, *Evaluation of 241-AP Tank Farms Supporting Phase 1 Privatization Waste Feed Delivery*, Rev. 0, Numatec Hanford Corporation for Fluor Daniel Hanford, Richland, Washington.
- HNF-2938, 1998, *Evaluation of 241-AN Tank Farm, Supporting Phase 1 Waste Feed Delivery*, Rev. 0, Numatec Hanford Corporation for Fluor Daniel Hanford, Inc., Richland, Washington.
- HNF-3339, 1999, *Interface Control Document Between the Double-Shell Tank (DST) System and the Single-Shell Tank (SST) System*, Rev. 0, Numatec Hanford Corporation for Lockheed Martin Hanford Corporation, Richland, Washington.
- HNF-3350, 2000, *Engineering-Basis Document Review Supporting Double-Shell Tank System Specification Development*, Rev. 0, Numatec Hanford Corporation for CH2M HILL Hanford Group, Inc., Richland, Washington.
- HNF-4500, 1999, *Tank Farm System Interface Summary*, Rev. 0, Numatec Hanford Corporation for Lockheed Martin Hanford Corporation, Richland, Washington.
- HNF-4553, 1999, *Operations and Maintenance Philosophy*, Rev. 0, Lockheed Martin Hanford Corporation for Fluor Daniel Hanford, Inc., Richland, Washington.
- HNF-5146, 2000, *Low-Activity Waste Feed Delivery Process Control Strategy*, Rev. 0, Numatec Hanford Corporation for CH2M HILL Hanford Group, Inc., Richland, Washington.
- HNF-IP-0842, 2000, *RPP Administration*, CH2M HILL Hanford Group, Inc., Richland, Washington.
- HNF-IP-1266, 1999, *Tank Farms Operations Administrative Controls*, Rev. 2, DE&S Hanford, Inc., for Fluor Daniel Hanford, Inc., Richland, Washington.
- HNF-SD-WM-OCD-015, 2000, *Tank Farm Waste Compatibility Program*, Rev. 3, CH2M HILL Hanford Group, Inc., Richland, Washington.

HNF-SD-WM-SP-012, 1999, *Tank Waste Remediation System Operation and Utilization Plan*, Rev. 1, Numatec Hanford Corporation for Fluor Daniel Hanford, Inc., Richland, Washington.

HNF-SD-WM-TRD-007, 2000, *System Specification for the Double-Shell Tank System*, Rev. 0, Numatec Hanford Corporation for Fluor Daniel Hanford, Inc., Richland, Washington.

HNF-SD-WM-TSR-006, 1999, *Tank Waste Remediation System Technical Safety Requirements*, Rev 1, Lockheed Martin Hanford Corporation for Fluor Daniel Hanford, Inc., Richland, Washington.

HNF-SP-1223, 1999, *Interface Control Document Between the DOE and BNFL Inc. Phase 1 Privatization--Low-Activity Waste Feed*, ICD-19, Rev. 1, Lockheed Martin Hanford Corporation for Fluor Daniel Hanford, Inc., Richland, Washington.

HNF-SP-1224, 1999, *Interface Control Document Between the DOE and BNFL Inc. Phase 1 Privatization—High-Level Waste Feed*, ICD-20, Rev. 1, Lockheed Martin Hanford Corporation for Fluor Daniel Hanford, Inc., Richland, Washington.

Letter No. 73600-99-006, "Interim Guidance on LAW Retrieval Strategy," (R. L. Treat to A. F. Choho, Numatec Hanford Corporation, June 22, 1999), Lockheed Martin Hanford Corporation, Richland, Washington.

OSD-T-151-00007, *Operating Specifications for the 241-AN, AP, AW, AY, AZ & SY Tank Farms*, 9/23/98, Rev. H-21, Fluor Daniel Hanford, Inc., Richland, Washington.

OSD-T-151-00017, *Operating Specifications for Aging Waste Operations in 241-AY and 241-AZ*, 8/14/97, Rev. D-10, Fluor Daniel Hanford, Inc., Richland, Washington.

WAC 173-303-640, "Tank Systems," *Washington Administrative Code*, as amended.

WHC-SD-WM-DGS-006, 1997, *Tank Farms Pump Critical Characteristic and Specification Guide*, Rev. 0, ARES Corporation and Lockheed Martin Hanford Corporation for Fluor Daniel Hanford, Inc., Richland, Washington.

WHC-SD-WM-SP-004, 1995, *Tank Safety Screening Data Quality Objective*, Rev. 2, Westinghouse Hanford Company, Richland, Washington.