UNCLASSIFIED

Dec-1962

Processing of Nuclear Fuels

By

Edwin L. Zebroski and John F. Flagg*

*This copy submitted
to Section Branch, JES,
for deletion
J.F. Flagg 2/10/54*

Classification changed to Unclassified
by authority of E.B.R. (memo in master folder)
by H. Kinn date 1-24-12
and R.B. Borenstein date 1-24-12

DELETED VERSION

This report has been photostated to fill your request as our supply of copies was exhausted. If you should find that you do not need to retain this copy permanently in your files, we would greatly appreciate your returning it to TIS so that it may be used to fill future requests from other AEC installations.

* Members of the Knolls Atomic Power Laboratory, Schenectady, New York which is operated by the General Electric Company for the Atomic Energy Commission.

UNCLASSIFIED

U-74-1

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency Thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

DISCLAIMER

Portions of this document may be illegible in electronic image products. Images are produced from the best available original document.

Processing of Nuclear Fuels

By

Edwin L. Zebroski and John F. Flagg

Introduction.

Both nuclear reactors and coal furnaces are sources of heat. The analogy is rarely drawn any further except for contrast. The characteristics of critical mass, penetrating radiations, control by neutron absorbers, and precise shape and spacing of nuclear fuel have no counterparts in ordinary furnaces. The pattern of utilization of nuclear fuel presents an even greater contrast to ordinary fuels. A large part of the potential heat of combustion of coal, oil, or gas is actually realized in practical equipment. The waste products have no further value and are discarded. Nuclear fuels are only partially consumed in any practical reactor. The remaining material is still of considerable value. In a breeder reactor the remainder may even be of greater value than the original fuel charge.

The recovery of the values contained in spent nuclear fuel is accomplished by an unusually difficult, but technologically very interesting, type of chemical processing. Some of the important problems can be discussed outside the realm of security restrictions.

Why Reprocess?

As fuel is "burned" in the reactor by the fission chain reaction, it deteriorates in three ways. The fission products ("ashes") accumulate and, by absorbing neutrons, tend to stop or poison the reaction. The physical properties of the fuel and its containers deteriorate under the intense neutron bombardment, and such deterioration could eventually lead to mechanical failures with possible loss of control and escape of highly radioactive fission products. Finally, as

V-74-2

the fuel is depleted the amount present will eventually fall below the critical mass required to maintain the chain reaction.

A combination of the above effects requires that the pile be shut down and its fuel discharged for processing after only a small part, probably less than a fourth, has been fissioned. The fissionable material must then be recovered, separated from associated structural materials, and decontaminated from fission products sufficiently to permit whatever handling is necessary for refabrication into new fuel elements.

Fuels and Reactors.

In a nuclear chain reaction, the fission of nuclear fuel by neutrons liberates energy and provides additional neutrons for propagating the chain. The only fissionable isotope capable of supporting a chain reaction that is found in significant amounts in nature is U-235, which is accompanied by 140 times its weight of U-238. U-235, the primary nuclear fuel, is fissionable with slow neutrons; it may be used to produce the synthetic (secondary) nuclear fuels Pu-239 and U-233 in a reactor.

Figure 1

Primary Fission Reaction.

A U-235 atom struck by a slow neutron undergoes fission and produces about 2.5 fast neutrons. One of these neutrons is required to maintain the chain reaction - the remaining 1.5 are available for other nuclear reactions.

Figure 2

Capture Reactions.

The excess neutrons from the primary fission reaction, after being slowed down by a moderator like graphite or heavy water, can be captured in "fertile" material, U-238 or Th-232 (a gamma ray is emitted when the neutron is captured.) The product of the capture process is unstable in either case, and rapidly decays by emitting two successive beta particles (high energy electrons) to produce Pu-239 or U-233. Either of these in turn may be recovered and used in place of U-235 to carry out the primary fission reaction.

The fissionable isotopes U-235, Pu-239 and U-233 may be utilized in three types of reactors. For example, in the Hanford reactors U-235 in natural uranium is burned with the production of a nearly equal amount of Pu-239. Such reactors are called converters.

In a more sophisticated type of reactor, the amount of Pu-239 produced can exceed the U-235 consumed. While this may be regarded simply as a very efficient converter, the type of reactor to accomplish this is sufficiently distinct to warrant the term "breeder." Similarly a converter or breeder could be operated with thorium as the fertile material to produce U-233. Having available supplies of U-235, U-233, or Pu-239, any of them can in principle be burned with the accompanying production of more U-233 or Pu-239. These combinations are summarized in Table I.

Any of the foregoing types of reactors can produce large amounts of heat. It is only a matter of constructing the reactor so that the heat is available at a high enough temperature to run a turbine of practical size to make it a power reactor. A special category of power reactors is listed in Table I, namely mobile power plants, where limitations of weight and bulk ^{might} eliminate the blanket of fertile material necessary for breeding.

U-74-4

Chemical processing to recover some or possibly all the materials listed in Table I is necessary for any reactor.

These elements - thorium, uranium, and plutonium - may be used in the form of metals or compounds such as oxides. As there are many points of chemical similarity between them, rather subtle differences must often be used to effect their chemical separation. Furthermore, the amount of secondary fuel formed by breeding or conversion is likely to be small on a weight basis - perhaps a few hundredths of a percent - and consequently must be removed by reactions in which the much greater bulk of unchanged material will not interfere.

In addition to the constituents inherent in nuclear chain reactions, there may be structural and cladding materials, coolants, and moderator to be removed in processing. For example the aluminum jackets used on natural uranium slugs, or the corrosion resistant alloys such as zirconium or stainless steel required for high temperature piles, must be removed before the processing proper can begin. Similarly, coolants such as liquid metals or fused salts, must be eliminated. Heavy water can be used as a coolant, moderator, diluent for the fuel, or in all three capacities, (as in the Los Alamos "Water Boiler" [redacted])

[redacted] The decontamination and recovery of heavy water in pure form, while not necessarily a part of fuel processing, will probably be an important feature of the operation of heavy water reactors.

The Fission Products.

The presence of fission products in spent fuel introduces one of the most difficult problems in chemical processing. Upon being removed from the pile, fuel elements are usually stored ("cooled") to allow some of the intensely radioactive fission products to decay. Even aside from their radioactivity, the fission products pose a complex chemical problem since they constitute a mixture of thirty-four elements from zinc to europium in the periodic table. Xenon and

TABLE I

<u>Type of Reactor</u>	<u>Fuel</u>	<u>Blanket</u>	<u>Material to be Recovered</u>	
			<u>Bulk Constituent</u>	<u>Minor Constituent</u>
Converter (Hanford type)	Natural U	None	Depleted U	Pu
Power (submarine or aircraft)	U-233 or U-235 or Pu-239	None	U-233 or U-235 or Pu-239	
Breeder (experimental breeder reactor, Arco; power breeders)	U-233 or U-235 or Pu-239	Natural U or Th	Th or depleted U in blanket, U-233, U-235, or Pu-239 in core	Pu-239 or U-233 (in blanket)

U-74-6

krypton are inert gases, and generally escape from the processing solutions without introducing complications at that point. Iodine and tellurium formed in fission are easily volatile under proper conditions. The other fission products - rare earths, alkali metals, alkaline earths, zirconium, ruthenium, etc. - present problems at points where their reactions resemble those of the fuels being recovered.

The fission products are represented in the mixture by over two hundred isotopes with half-lives varying from hundredths of a second to many millions of years. The short lived ones remove themselves by their rapid decay, while the disintegration rates of the long lived ones are so small as to contribute a negligible fraction of the total activity. There remain about a dozen elements with isotopes which are important in processing operations because of their half-life (a few days to a year) and fission yield (.2% or more). Table II shows these.

Since even the few important fission products present such a varied array, the gross radioactivity associated with a given fuel element depends, in an involved way, on the percent burnup of the fuel and the irradiation and cooling time. As a rough approximation, however, the gross activity decays with a half time which at a given moment is equal to the cooling time. Accordingly there is little benefit in prolonging cooling more than a few months, since at that point it would require several years to reduce the activity by a factor of ten.

After several months cooling time, the amount of activity produced by fuel in which one pound of material has undergone fission is in the neighborhood of 100,000 curies - roughly equal in radioactivity to 200 pounds of radium. This produces a "dose rate" of 100,000 roentgens per hour at a distance of one meter, while the permissible human ^{exposure} [redacted] has been set at 0.012 roentgens per hour. The separation process must reduce the amount of fission products by a factor of ten million if the recovered fuel is to be handled by ^{non-remote} [redacted] techniques.

Amounts of Materials Processed.

Some appreciation for the demands made on a separations process may be gained by considering the relative amounts of materials involved in processing. In neutron irradiated uranium, plutonium and fission products will be present in roughly comparable amounts, and in total quantity that depends on the power level at which the reactor operates and for how long. One gram of U-235 is fissioned per megawatt day of reactor operation; roughly 1 gram of plutonium is produced at the same time. For each 1% fission of the U-235 that is achieved, in 100 megawatt days of irradiation, 100 grams of plutonium would have been produced. In a natural uranium reactor 1400 kg of uranium would be associated with the plutonium, or about 1/4 lb plutonium per 1.4 tons uranium. Irradiated thorium may contain a comparable fraction of U-233 to be recovered.

The reactor will also produce a total weight of fission products about equal to the weight of plutonium. The yields of individual elements vary from a few thousandths up to about six percent. The amounts of any of the radioactive fission products present at any time will depend on the individual decay characteristics. At the time of pile discharge, the weight of any individual fission product will be given by the product of fission yield, grams of U-235 fissioned, and the ratio of the atomic weight of the fission product to that of U-235, i.e.,

$$\text{Grams fission product} = (\text{fission yield})(\text{gm U-235 fissioned}) \frac{\text{at. wt.}}{235}$$

For example, 2.4 grams of zirconium-95 would be present at discharge in the above case.

TABLE II

Important Fission Products of U-235

<u>Isotopes</u>	<u>Half-Life</u>	<u>% Yield</u>	<u>Energy of Radiation - MEV</u>	
			<u>Beta</u>	<u>Gamma</u>
Sr ⁸⁹	53 d	4.6	1.5	--
Sr ⁹⁰	25 y	5	.6, 2.2	--
Y ⁹¹	57 d	5.9	1.53	--
Zr ⁹⁵	65 d	6.4	.4, .15	.73, .75
Ru ¹⁰³	42 d	3.7	.2	.56
Ru ¹⁰⁶	1 yr	.5	2.8, 3.9	.3, .8
Te ¹²⁷	90 d	.03	0.7	--
Te ¹²⁹	32 d	.19	1.8	.3, .8
I ¹³¹	8 d	2.8	0.6	.37
Xe ¹³³	5.3 d	6	.35	.08, .03
Cs ¹³⁷	33 y	6	.5, .8	0.75
Ba ¹⁴⁰	12.8 d	6.1	.4, 1.0, 1.4	.4, .8
Ce ¹⁴¹	28 d	6	.55	.2
Ce ¹⁴⁴	275 d	5.3	.3, .35	--
Pr ¹⁴³	13.8 d	6	1.0	--
Nd ¹⁴⁷	11 d	2.6	.4, .9	.6
Pm ¹⁴⁷	3.7 d	2.6	.2	--

V-74-9

Carrier Precipitation.

Let us consider now the details of some reprocessing methods. The chemical separation of a trace of an element from a large bulk of another element can often be done by carrier precipitation. The carrier, which may be a non-radioactive substance having properties similar to those of the element desired, is added in sufficient quantity to insure good recovery and handling. A classical example in the nuclear energy field is the recovery of traces of plutonium from large amounts of uranium by using lanthanum as carrier, and precipitating lanthanum fluoride (LaF_3). Plutonium carries with the LaF_3 , while uranium does not.

The diagram (Figure 3) shows such a process for the recovery of plutonium from uranium by carrier precipitation. First the uranium fuel must be dissolved; if oxidizing conditions are used, both uranium and plutonium will be in the +6 oxidation state as the ions UO_2^{++} and PuO_2^{++} . For the first precipitation a reducing agent such as sulfur dioxide or hydroxylamine is used to reduce the plutonium to the +3 or +4 oxidation state without affecting the uranium. Lanthanum fluoride is then precipitated, carrying plutonium but not uranium. For the second precipitation the plutonium is re-oxidized to the +6 state, but this time it is not carried with the lanthanum fluoride and fission products. The filtrate from this precipitation contains the plutonium, which may be subjected to further oxidation, reduction, and precipitation cycles as required to achieve decontamination.

Carrier precipitation may be used in the laboratory for separating traces of protactinium from irradiated thorium. In this case, a small precipitate of manganese dioxide formed in a solution of the thorium will carry protactinium quite efficiently. The protactinium (parent of fissionable U-233) is thus obtained in a concentrated form, separated from the bulk of the thorium.

Figure 3

Principal steps in the separation of uranium, plutonium, and fission products by carrier precipitation

Precipitation processes offer the advantages of working batchwise, in numerous distinctly separated steps and pieces of equipment. Flexibility for process change is great, and scale-up from laboratory to plant is not difficult. Precipitation processes may be unattractive from the stand point of obtaining recovery, owing to potential losses through equipment hold-up, and in requiring elaborate maintenance. Recovery of the bulk element by precipitation is not attractive because of the need for handling large tonnages in a batchwise manner.

Ion Exchange.

Ion exchange is somewhat similar in principle to carrier precipitation in that a phase change from liquid to solid is involved. As applied to nuclear fuel reprocessing in an ideal case, plutonium might be retained on the ion exchange resin while the greater bulk of uranium, and ^{some of} the fission products, would be more readily eluted. Subsequent adsorption and elution cycles would be designed to separate uranium and the fission products. Many chemical separations problems have been solved by use of ion exchange, including the fractionation of rare earths and trans-plutonium elements having markedly similar chemical properties.

Ion exchange as a separation method for nuclear fuels might offer the advantages of relative simplicity, both operationally and equipment-wise. Most resins may be regenerated for prolonged use, thus offering potential savings in chemical costs. Disadvantages might lie in the need for large volumes for washing and eluting, in the potential large hold-up of nuclear fuel on the resin beds, and in any instability of the resins toward the high radiation levels that would be present.

Solvent Extraction.

Like precipitation, solvent extraction is a unit operation applicable in the processing of nuclear fuels. Separation is achieved by transfer of the desired material between two immiscible liquids, in one of which the solubility is very high. These liquids, one of which is usually water, are mixed in an appropriate fashion and the layer containing the desired constituent separated. A common method of contacting consists of counter-current flow of the two liquids through a packed column. Long known in the petroleum and related industries, solvent extraction was first used in the nuclear field for the preparation of large tonnages of pure uranium for use in reactors. Briefly, the technique involves contacting an aqueous uranyl nitrate solution with ether. The uranyl nitrate dissolves in the ether phase; in the presence of a compound such as *magnesium* to act as a "salting agent," the concentration in the ether may be 10 or more times that in the aqueous phase. Recovery from the organic phase is affected by contacting with water in the absence of salting agents. Impurities initially accompanying the uranium are extracted only partially, or not at all. Hence, by repeated extraction and water strips a product of the desired purity may be obtained. Figure 4 shows the steps in such a process.

In applying solvent extraction to the processing of irradiated uranium containing plutonium and fission products, conditions may be established such that both uranium and plutonium will extract into the organic phase. Fission products will be distributed largely in favor of the aqueous phase, which may be sent to waste. The partially decontaminated uranium and plutonium may be recovered from the solvent by water stripping, followed by additional extraction and strip steps to achieve the desired decontamination. The possibility exists of uranium and plutonium being separated from each other at any desired stage in the process by reducing the plutonium to the ether - inextractible (+3 or +4) valence state.

Figure 1
Separation

Principal Steps in the [REDACTED] of Irradiated Uranium
By Continuous Countercurrent Extraction

Solvent extraction also offers the possibility of separating U-233 from irradiated thorium, taking advantage of the ether solubility of uranyl nitrate from a solution in which the salting agent is thorium nitrate. Protactinium likewise may be recovered from aqueous nitric acid solution by extraction with di-isopropyl ketone, and subsequently stripped by washing with water.

Solvent extraction as a separation method offers the advantages of easy adaptation to continuous operation, although batch operation may be used if desired. Other advantages are found in the rather sharp separations that are possible, and in potential savings in operating costs through re-use of the solvent. The use of volatile organic solvents in connection with highly radioactive and toxic materials constitutes a disadvantage, as do the large volumes of waste solution that require handling and storage.

beginning of the operations, and least at the point where decontaminated products are discharged. Concrete shielding against gamma radiation is required for the element used to dissolve the irradiated fuel, and for the first stages of decontamination. The final product may require little or no shielding from gamma radiation. Figure 5 shows a Hanford separations plant. Plutonium, however, even when decontaminated must be handled under rigidly controlled conditions to prevent bodily ingestion. Airborne contamination is best prevented by working in isolation of the type illustrated (Figure 6). In many respects the problems in handling purified plutonium are similar to those in handling purified uranium.

Since the efficiency of any separation method is limited, a combination of processing steps may prove necessary. Solvent extraction may be combined with carrier precipitation or ion exchange to give an over-all process that is more efficient than one composed of, say, only solvent extraction steps.

of such an amount by even remotely possible combinations of equipment failure and human error. While a "bomb" type explosion would not result, there would be serious effects from radiation and heating. These difficulties are avoided by working in appropriately small batches, and in solutions sufficiently dilute. These factors set limitations on maximum plant size. In addition, careful assaying and accounting must be done to detect accidental accumulation of fissionable material at any stage of the processing, and to maintain the material balance throughout the plant. The economies to be expected from the use of a large central processing plant for a number of reactors are definitely limited.

The disposal of the fission product wastes from fuel processing is both a technological and economic problem. One solution has been to store the wastes in immense leak-proof tanks near the processing plants. They must retain their integrity for long periods of time - perhaps several hundred years. The cost of such tanks, per unit of material processed, may well exceed the cost of the chemicals required in the process. One important criterion of the efficiency of any process is therefore the production of small waste volume. In order to make large scale atomic energy production feasible near densely populated areas, truly permanent waste disposal methods must be evolved. Possible objectives would be packaging the waste in highly concentrated form in small, very durable vessels, or converting the waste to a very stable "mineral" by incorporating it into a special concrete or ceramic.

Gaseous fission products such as xenon and krypton are discharged to the atmosphere during the dissolving of irradiated fuels. These isotopes decay quite rapidly, and present no long term health or contamination hazard. Radioactive iodine is likewise present in neutron irradiated uranium, and may be removed from nitric acid - uranyl nitrate solutions by air sparging when present initially as

either iodide, iodine or iodate if means for conversion of non-elemental iodine to the zero oxidation state are provided. Removal of a particular fission product such as this prior to the actual processing may result in later process simplifications.

The Economics of Processing.

The importance of chemical processing at all stages in nuclear fuel production and utilization is evident from Figure 7. Costs of fuel reprocessing are a substantial fraction of the direct costs of fissionable materials or power production. Plants are costly to build and operate, for reasons unique to the nuclear industry that have already been mentioned. As development proceeds, additional functions may be required of the plants. For example, the original Hanford plants recovered and decontaminated only plutonium; the uranium was sent to waste storage tanks along with the fission products. *To avoid this waste, it would be advantageous in* Later plants *to* recover and decontaminate both uranium and plutonium.

Another factor making for costly processing is the large economic value of the fuels, which makes high recovery imperative in the processing plant. The value of the electrical energy that can be produced from one pound of U-235 is ^{15,000} \$15,000 (based on the evolution of about ^{22,000} 22,000 kw-hrs of heat energy per gram of uranium fissioned, electricity at 5 mills/kw-hr, and 30% thermal efficiency of the generating plant). Highly efficient fuel recovery is required to capitalize fully on the potentialities of the new breeders. The fuel and fertile material in a breeder may go through the reactor-reprocessing cycle ^{many} times (on the average). A small loss in any stage of the process is therefore compounded and may have a serious effect on the over-all fuel economy.

Figure 7

The Role of Chemical Processing
in the Nuclear Fuel Utilization Cycle

In contrast with the fairly clear value which can be placed on nuclear fuels, there are two seemingly contradictory estimates of their cost. Shurr concludes that the cost of uranium fuel is negligible compared to coal - less than 0.02 mils per kw-hr of electric power generated. Hafstad, using an estimate of the cost of roughly one hundred fold higher of separated U-235, concludes that the cost of nuclear fuel is well over 1 mil per kw-hr, or about equal to coal. Shurr assumes complete utilization of the uranium, by conversion of the U-238 to plutonium. The repeated processing necessary to achieve this result is charged to the operating cost of the power plant, rather than fuel cost. While much of the disparity of these estimates can be reconciled in terms of the accounting basis, their difference is a measure of the economic import of fuel processing.

These and other factors indicate rather clearly that reprocessing may be one of the decisive factors in how soon economic atomic energy becomes available. Fields for future investigation will include the study of simplified processes, as well as reactors and reactor fuels that are especially suitable for simplified processing. The possibility of doing partial, or even no processing at all, is worth consideration for certain particular cases, although for reasons indicated the problems are formidable. In short, many opportunities lie ahead for the chemist and chemical engineer in the field of nuclear fuel reprocessing. The stakes are high.

JFF/awd
2/12/52

U-74-20

20

BIBLIOGRAPHY

1. Control of Radiation Hazards in the Atomic Energy Program, U.S.A.E.C., July 1950.
2. Atomic Energy and the Physical Sciences, U.S.A.E.C., January 1950.
3. Glasstone, S.: Sourcebook on Atomic Energy.
4. Goodman, C.: The Science and Engineering of Nuclear Power.

awd

75-74-2

75-74-2.1

21

FIGURE 5

AEC-48-198

U-74-22

AEC-48-198... Richland, Washington... One of the original chemical separation plants, built during the war to extract plutonium from the material discharged from the reactors. Entire process is remotely controlled. The structure, including radiation, shielding, uses enough concrete for a 30-mile highway. Stack for discharge of waste gases is 200 feet high.

Credit Johnson... Richland, Washington

23

Figure 6.

V-74-24

24

AEC-50-3905

LOS ALAMOS, N. MEXICO... When the chief potential radiation hazard is from contamination of the air and shielding can be relatively light "dry boxes" such as this are used.

Credit Los Alamos Photo Laboratory

V-74-25