WSRC-TR-92-488

**ITP.FOR: A CODE TO CALCULATE THERMAL
TRANSIENTS IN HIGH LEVEL WASTE TANKS (U)**

by A. L. Kielpinski

Westinghouse Savannah River Company
Savannah River Site
Aiken, South Carolina 29808

WSRC-TR--92-488

DE93 009895

Other Authors:

This paper was prepared in connection with work done under Contract No. DE-AC09-89SR18035 with the U. S. Department of Energy. By acceptance of this paper, the publisher and/or recipient acknowledges the U. S. Government's right to retain a nonexclusive, royalty-free license in and to any copyright covering this paper, along with the right to reproduce and to authorize others to reproduce all or part of the copyrighted paper.

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

WSRC-TR-92-488

NRTSC

**NUCLEAR REACTOR TECHNOLOGY
AND SCIENTIFIC COMPUTATIONS**

**KEYWORDS: ITP
TANK 48
HIGH LEVEL WASTE TANKS
CODE DEVELOPMENT**

RETENTION: PERMANENT

**ITP.FOR: A CODE TO CALCULATE THERMAL TRANSIENTS
IN HIGH LEVEL WASTE TANKS (U)**

By

A. L. KIELPINSKI

ISSUED: OCTOBER 1992

A. L. Kielpinski
Derivative Classifier

10/29/92
Date

**SRTC SAVANNAH RIVER TECHNOLOGY CENTER, AIKEN, SC 29808
Westinghouse Savannah River Corporation
Prepared for the U.S. Department of Energy under
Contract DE-AC09-76SR00001 875R18035**

MASTER

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

PROJECT:

DOCUMENT: WSRC-TR-92-488

TITLE: ITP.FOR: A CODE TO CALCULATE THERMAL TRANSIENTS IN
HIGH LEVEL WASTE TANKS (U)

QA TASK NUMBER: 92-059-1

APPROVALS

A. L. Kielpinski 10/23/92
A. L. Kielpinski, Author Date:

S. J. Hensel 10-23-92
S. J. Hensel, Technical Reviewer Date:

David A. Crowley 10/29/92
D. A. Crowley, NES Code Development Group Manager Date:

A. J. Garrett 10/29/92
A. J. Garrett, NES Manager Date:

Table of Contents

Nomenclature	2
Introduction	5
Summary	5
 <u>Discussion:</u>	
Derivation of Equation Set	5
Model Equation Set	8
Evaluation of the Mass and Energy Terms for the Liquid Phase	11
Evaluation of the Mass and Energy Equations for the Vapor Phase	15
Evaluation of the Energy Equation for the Tank	17
Evaluation of the Energy Equation for the Cooling Air	18
Heat Transfer Coefficient Modeling	18
Geometric Factors	21
Numerical Solution Method	22
Model Implementation	25
References	27

Nomenclature

A_i	normal cross-sectional area for flow of stream i
A_b	surface area of the bottom of the tank; this is also equal to interfacial area between liquid and vapor
A_{core}	wall surface area associated with the central core of the tank
c_p	heat capacity at constant pressure
c_v	heat capacity at constant volume
D_j	jet diameter (equal to nozzle diameter)
d	tube diameter
H	total tank height
H_l	height of liquid phase
$\Delta\dot{H}_a$	net sensible heat addition to air control volume
h	enthalpy
h_{fg}	latent heat of vaporization
h_i	convective heat transfer coefficient of cooling water inside cooling coils
h_s	convective heat transfer coefficient for the liquid slurry over a horizontal surface
h_{vap}	convective heat transfer coefficient of the vapor over a surface
k	thermal conductivity
L_l	length of cooling coils submerged in liquid phase
L_t	total length of cooling coils
$\overline{M}$	molecular weight
m	mass

$\dot{m}$	mass flowrate
$\dot{m}_{c.v.}$	time rate of change of mass in control volume
Nu_x	local Nusselt number
P	pressure
P_i	pressure of incoming or outgoing stream; vapor pressure
Pr	Prandtl number
$\vec{q}$	heat-flux vector
q'''	volumetric internal energy generation
$\dot{Q}$	rate of heat transfer
R_i	radius of influence for a jet
$\mathcal{R}_i$	gas constant for species i
Re	Reynolds number
T	temperature
T_{ref}	reference temperature for definition of energy and enthalpy
T_{sat}	saturation temperature
t	time
$\vec{t}$	stress vector at a point on the control surface
U_{ej}	centerline jet velocity
u	internal energy, energy per mass
V	volume
$v, \vec{v}$	magnitude of velocity; velocity vector
Δx	thickness of material for heat transfer by conduction
Y'_s	mass fraction of water vapor at saturated conditions

Greek

β	temperature coefficient of expansion
ε	radiative emissivity
ν	kinematic viscosity
ρ	density
ϕ	saturation fraction
σ	Stefan-Boltzmann constant

Subscripts

a	air
c	cooling water
f	fouling material
fc	forced convection
fo	outer fouling layer
i	inner
l	liquid
lb	liquid to tank bottom
lw	liquid to tank wall
nc	natural convection
o	outer
$refr$	refractory material
t	tank
w	wall
vap	vapor

INTRODUCTION

A variety of processing operations for high level radioactive waste occur or will occur in the High Level Waste Tanks in the H-Area of the Savannah River Site. Thermal design constraints exist on these processes, principally to limit the amount of corrosion inhibitor which must be added to protect the tank and cooling coil materials. The required amount of corrosion inhibitor, which must subsequently be removed prior to trapping the waste in borosilicate glass, increases exponentially with temperature over a fairly narrow range (some tens of degrees Celsius). For this reason, there is a need to model the thermal-hydraulic processes occurring in the waste tanks.

A FORTRAN computer code, called ITP.FOR, was written to provide a simple but reasonably accurate analysis tool for plant operation design. The code was specifically written to model Tank 48, in which the In-Tank Precipitation (ITP) process of precipitating radioactive cesium will be initiated. Although the ITP.FOR code was written as personal-use software for scoping design calculations for Tank 48, the current intent is to extend the code's applicability to other H-Area waste tanks, and to certify the code in accordance with the NRTSC Quality Assurance requirements for critical-use software (1Q-34, 1991). Since the code's capabilities have generated some interest to date, the present report is presented as interim documentation of the code's mathematical models. This documentation will eventually be supplanted by the formal documentation of the expanded and benchmarked code.

SUMMARY

ITP.FOR is a time-dependent, lumped thermal analysis code for High Level Waste Tanks. The basic purpose of the code is to compute an average temperature, as a function of time, for the liquid contents of the tank. The liquid in the tank, the vapor space above it, the tank material itself, and the circulating cooling air are each modeled as a lumped component in the analysis. This report describes the code, and presents derivations of the relevant forms of the mass and energy equations. This report also discusses the numerical solution method and the heat transfer coefficients implemented in the code. The code was written as personal-use software for ITP thermal scoping calculations, and the models it contains reflect that orientation. Improved models, extension to other waste tanks, and code certification will be pursued, and more formal code documentation will subsequently be generated.

DISCUSSION

Derivation of Equation Set

The analysis is based on solution of unsteady mass and energy equations for each of the following lumped components: (i) the liquid phase, or slurry; (ii) the vapor phase inside the tank, above the liquid; (iii) the primary tank itself; (iv) the cooling air which circulates around the tank. Each of these components is lumped, i.e., no spatial variation in temperature or properties is modeled. This is not necessarily an adequate assumption for all problems. It is insufficient for studying hot spots, for example.

Conservation of Mass

The unsteady mass equation is (Smith and Van Ness, 1975, p. 441-442):

$$\frac{d}{dt} \int_V \rho dV + \int_{A_i} \rho \vec{v} \cdot \vec{n} dA = 0 \quad (1)$$

The first term is the time rate of change of the mass in the control volume, i.e.,

$$\frac{d}{dt} \int_V \rho dV = \left(\frac{dm}{dt} \right)_{c.v.} \equiv \dot{m}_{c.v.} \quad (2)$$

For flow with uniform properties over the conduit cross-section, the second term can be written as a sum of terms for each inflow and outflow:

$$\int_{A_i} \rho \vec{v} \cdot \vec{n} dA = \sum_i \rho_i v_i A_i \quad (3)$$

where the terms in the summation are negative if the flow is in, and positive if the flow is out. Since

$$\dot{m}_i = \rho_i v_i A_i \quad (4)$$

equation (1) can be rewritten:

$$\left(\frac{dm}{dt} \right)_{c.v.} = \sum_{in} \dot{m}_i - \sum_{out} \dot{m}_j \quad (5)$$

where the sign convention is handled by explicitly summing positively-signed streams for each direction of flow. For the solid tank wall, of course, there are no input and output mass streams, and equation (5) does not apply. Equation (1) is applied to each species which enters or exits either the liquid or vapor phase, as well as to the liquid and vapor mixtures.

Conservation of Energy

Conservation of energy is expressed by the first law of thermodynamics for an unsteady control volume (Smith and Van Ness, 1975, p. 443-446):

$$\frac{d}{dt} \int_{c.v.} \rho u dV + \int_{A_i} \rho \left(u + \frac{v^2}{2} + gz \right) \vec{v} \cdot \vec{n} dA + \int_A \vec{q} \cdot \vec{n} dA - \int_A \vec{r} \cdot \vec{v} dA = 0 \quad (6)$$

Evaluating terms:

$$\frac{d}{dt} \int_{c.v.} \rho u dV = \frac{d}{dt} (mu)_{c.v.} \quad (7)$$

$$\int_A \vec{q} \cdot \vec{n} dA = \sum_j -\dot{Q}_j \quad (8)$$

$$\int_A \vec{t} \cdot \vec{v} dA = \dot{W}_{sh} + \sum_i P_i \frac{v_i A_i}{V_i} V_i \quad (9)$$

where

$$\frac{v_i A_i}{V_i} = \dot{m}_i \quad (10)$$

Recall the definition of enthalpy:

$$h \equiv u + Pv \quad (11)$$

In the absence of shaft work done by the fluid, with negligible kinetic and potential energy contributions, and considering the surfaces across which fluid moves to be normal to the flow direction, the second and fourth terms of equation (6) can be combined to introduce the enthalpy. Substituting for the other terms using equations (7) and (8), we have:

$$\frac{d}{dt}(mu)_{c.v.} = \sum_i \dot{m}_i h_i + \sum_j \dot{Q}_j \quad (12)$$

Note that influxes are positive in equation (12). From thermodynamics, for a system without phase change:

$$u = c_v (T - T_{ref}) \quad (13)$$

$$h = c_p (T - T_{ref}) \quad (14)$$

Expanding the left hand side of equation (12) and using equation (13):

$$\frac{d}{dt}(mu)_{c.v.} = m_{c.v.} \frac{du_{c.v.}}{dt} + u_{c.v.} \frac{dm_{c.v.}}{dt} = (mc_v)_{c.v.} \frac{dT}{dt} + [\dot{m}c_v (T - T_{ref})]_{c.v.} \quad (15)$$

where $\dot{m}_{c.v.}$ is the rate of change of mass in the control volume.

Substituting (14) and (15) into (12) and solving for the rate of change of temperature in the lumped control volume:

$$\frac{dT}{dt} = \frac{1}{(mc_v)_{c.v.}} \left[\sum_i \dot{m}_i c_{p,i} (T_i - T_{ref}) + \sum_j \dot{Q}_j - [\dot{m}c_v (T - T_{ref})]_{c.v.} \right] \quad (16)$$

Note that, for an incompressible material,

$$c_p \approx c_v \equiv c \quad (17)$$

but for a compressible fluid, the two different types of heat capacity are involved in equation (16).

Heats of vaporization and condensation must be accounted for in the energy equation for the liquid, since there are fluxes of vaporizing and condensing streams. When phase change occurs, equation (10) must be modified to:

$$h = c_p(T_{sat} - T_{ref})_{\phi_1} \pm h_{fg} + c_p(T - T_{sat})_{\phi_2} \quad (18)$$

where ϕ_j refers to the sensible enthalpy contribution of phase j. It will be convenient to

regard the second and third terms on the right hand side of (18) as a term in $\sum_j \dot{Q}_j$, so that

the term $\sum_i \dot{m}_i c_{p,i} (T_i - T_{ref})$ in equation (16) accounts for only sensible heat contributions from the influxes and outfluxes in their liquid phase. With this understanding, equation (16) expresses the unsteady temperature evolution of a fluid control volume having mass flux streams which may change phase upon entering or leaving.

For the solid tank wall, there are no mass fluxes nor change in tank mass, and (16) reduces to:

$$\frac{dT}{dt} = \frac{\sum_j \dot{Q}_j}{(mc)_{c.v.}} \quad (19)$$

Model Equation Set

A set of equations of the forms (5), (16), and (19) describes the evolution in time of the mass and energy of the four components. It is also necessary to solve equation (5) for each separate material stream of the liquid phase, in order to keep track of the material properties of the mixture. This set of ordinary differential equations is then solved numerically. The final equation set is listed below.

Liquid Phase

Mass equations are written for each component separately, and for the mixture as a whole. Because the mixture is treated as a dummy component, the extraction of mixture must be accounted for in the component mass equations. The explicit forms of these equations are:

$$\frac{dm_j}{dt} = \sum_{in} \dot{m}_{i,j} - \sum_{out} \dot{m}_{o,j} - \chi_j \dot{m}_{out,c.v.} \quad (20)$$

for each material component j . This form is convenient because the terms of the summations are the user-specified influxes and effluxes.¹ $\dot{m}_{out,c.v.}$ is likewise an externally-specified flowrate of mixture out of the tank, and should not be confused with $\dot{m}_{c.v.}$, the time rate of change of mixture mass inside the control volume. The mass equation for the mixture is simply equation (5), repeated here for completeness:

$$\frac{dm}{dt} = \dot{m}_{c.v.} = \sum_{in} \dot{m}_i - \sum_{out} \dot{m}_j \quad (5)$$

Given that the mass of each species component is known as a function of time via solution of equations (20), mixture properties are calculated at any point in time as:

$$\rho_{mix} = \frac{\sum_j m_j}{V} \quad (21)$$

$$c_{p,mix} = \frac{\sum_j m_j c_{p,j}}{\sum_j m_j} \quad (22)$$

where the summations in equations (21) and (22) include the original tank contents.

The energy equation for the liquid phase is simply equation (16):

$$\frac{dT}{dt} = \frac{1}{(mc_v)_{c.v.}} \left[\sum_i \dot{m}_i c_{p,i} (T_i - T_{ref}) + \sum_j \dot{Q}_j - [\dot{m} c_v (T - T_{ref})]_{c.v.} \right] \quad (16)$$

where the summation over i includes all streams of all component species. The individual heat transfer terms of the second summation are:

$$\sum_j \dot{Q}_j = \dot{Q}_{rad} + \dot{Q}_{pump} + \dot{Q}_{cond} - \dot{Q}_{conv} - \dot{Q}_{c,l} - \dot{Q}_{lt} - \dot{Q}_{vap} \quad (23)$$

where the signs indicate the assumed direction of heat transfer (inflow being positive). These will be derived in more detail in the next section of this report.

Vapor Phase

There are two components in the vapor phase: the purge gas (typically nitrogen or air or a mixture of the two), and water vapor. Equation (5), written for the vapor mixture, is formally included in the equation set, i.e.,

¹ Note that, while the number of components is arbitrary, the modeling of vaporization dictates that one component will be water, which will always have an efflux if the purge gas picks up moisture as it passes through the vapor space.

$$\left. \frac{dm}{dt} \right)_v = \sum_{j=1,2} \dot{m}_{in,j} - \sum_{j=1,2} \dot{m}_{out,j} \quad (24)$$

For the vapor phase, the flows in and out are not directly specified by the user. A nominal throughput of purge gas is specified. This would seem to imply that dm/dt for the purge gas is zero. The physical constraint is, however, that the pressure in the vapor space remains constant despite changes in vapor volume due to changes in liquid level. To solve equation (23), the individual terms in the summation must be determined. The detailed solution procedure is described later in this report; suffice to say that, while only equation (23) is included in the solution vector, conservation of mass on a species basis must also be tracked.

The energy equation for the vapor phase mixture is again equation (16). The heat transfer summation term is:

$$\sum_j \dot{Q}_j = \dot{Q}_{conv} - \dot{Q}_{c,v} - \dot{Q}_{vt} \quad (25)$$

Evaluation of terms for this equation is described later in this report.

Tank

No mass equation need be written for the tank. The energy equation in the form of equation (19) is solved for the tank mass:

$$\frac{dT}{dt} = \frac{\sum_j \dot{Q}_j}{(mc)_{c,v}} \quad (19)$$

where:

$$\sum_j \dot{Q}_j = \dot{Q}_u + \dot{Q}_{vt} - \dot{Q}_a - \dot{Q}_{gr} \quad (26)$$

Evaluation of terms for this equation is described later in this report.

Cooling Air

The mass flow is presumed constant at the user-specified value. The energy equation, equation (16), is solved for the cooling air, with:

$$\sum_j \dot{Q}_j = \dot{Q}_a + \dot{Q}_{gr} \quad (27)$$

Evaluation of terms for this equation is described later in this report.

Evaluation of the Mass and Energy Equations for the Liquid Phase

Mass Equations

Equation (5) is used to determine the mass of the liquid phase at any time. Each term of the summation on the right hand side of (5) is specified as a function of time by the input.

The composition, and therefore the material properties, of the liquid mixture change with the changes in component masses. The liquid phase is a mixture of:

- the original contents of the tank (itself a mixture, but described in a homogeneous manner by single values of density and heat capacity);
- the total amount of mass accumulated over the course of the simulation for each material component stream.

As an artifact of treating the original contents as a single species, mass accumulation in a component can be negative (e.g., water vaporizing out of the liquid phase with no corresponding influx of pure water). Given the flowrates of each subcomponent of the liquid phase, and the density and heat capacity of each subcomponent, the density and heat capacity of the liquid phase can be tracked as a function of time.

The component mass derivatives must be adjusted when a mass flowrate of mixture out of the tank is specified. The last term of equation (20) accounts for this.

Energy Equation for the Liquid Phase

For the liquid phase, the following energy transfer mechanisms are considered in evaluating equation (16):

- Internal heat generation due to radiolytic decay in the liquid phase,
- Addition of energy due to pump operation,
- Sensible heat transfer with incoming and outgoing mass fluxes,
- Heat of condensation of steam influxes,
- Heat of vaporization of evaporation efflux (to the vapor space),
- Heat transfer to the cooling coils in the tank,
- Heat transfer to the tank wall, and
- Heat transfer to the vapor space.

Each of these mechanisms is considered in the following.

Radiolytic decay

For each entering and exiting stream, as well as for the initial volume of liquid in the tank, the calculation requires as input the energy, per time, per volume, which is converted to thermal energy due to radiolytic decay. The radiolytic heat input is then

$$\dot{Q}_{rad} = \sum_j \dot{q}_j'' V_j \quad (28)$$

Pump Energy

The calculation requires the energy per unit time input to the liquid by the action of the pump. Pumps can be considered to be of two types: (i) mixing pumps; (ii) transfer pumps. For a mixing pump, where energy is put into a closed system which does no work, all of the pump energy (i.e., the brake horsepower) is eventually converted into thermal energy. For a transfer pump, energy is used to do work on the fluid by moving it through a distance. If this fluid leaves the system, this energy is "lost" to the control volume. Moreover, heat transfer through the external piping to the environment also dissipates the transfer pump energy.

For many applications of interest, however, the operation of the transfer pump is such that most of the fluid which is pumped is recirculated. This is the case in the washing phase of the ITP process, where several hundred gallons per minute are pumped, but only about 15 gpm are transferred out of the system. Given the shielding in place on the transfer piping, the energy loss through the piping is also relatively small. In lieu of more rigorous analysis, a simple and conservative approach is to specify the brake horsepower as the appropriate pump energy for transfer pumps as well as mixing pumps.

Sensible Heat Transfer with Mass Flux

The summation term $\sum_i \dot{m}_i c_{p,i} (T_i - T_{ref})$ was discussed in a previous section. The appropriate temperature in each term of the summation is the temperature of the stream as it crosses the control volume boundary. For an incoming stream, this is the externally specified temperature of that stream (the saturation temperature of a condensing stream). For an outgoing stream, the appropriate temperature is the transient temperature of the liquid mixture.

Heat of Condensation of Steam Influxes

As discussed previously, the enthalpy contribution due to cooling the steam to saturation temperature and then condensing it is treated as a heat input, i.e.,

$$\dot{Q}_{cond} = h_{fg} + c_p (T - T_{sat})_{\phi_2} \quad (29)$$

where ϕ_2 is the vapor phase and the second term represents the sensible cooling of superheated vapor to saturation temperature.

Heat of Vaporization Due to Evaporative Efflux

The energy transferred from the liquid due to evaporation of water into the unsaturated vapor phase is:

$$\dot{Q}_{vap} = \dot{m}_{vap} h_{fg}(T_{vap}) \quad (30)$$

The variation in the latent heat of vaporization with temperature is small enough over the range of interest that it can be conveniently represented by the Watson correlation (Smith and van Ness, 1975, p. 116):

$$h_{fg}(T_2) = h_{fg}(T_1) \left(\frac{1 - T_{r2}}{1 - T_{r1}} \right)^{0.38} \quad (31)$$

where the reduced temperature T_{ri} is given by

$$T_{ri} = \frac{T_i}{T_{critical}} \quad (32)$$

Evaluation of equation (30) then reduces to specifying the value of $\dot{m}_{vap}$. Determination of $\dot{m}_{vap}$ will be discussed later in this report.

Heat Transfer to the Cooling Coils

The convective/conductive heat transfer through fouled tubes can be considered as a series of resistances (e.g., Chapman, 1974; Kreith, 1986). Neglecting fouling on the inside of the tubes (through which chromated water flows) the expression is:

$$\dot{Q}_c = \frac{T - T_c}{\frac{1}{h_s A_{fo}} + \frac{\ln\left(\frac{d_{fo}}{d_o}\right)}{2\pi k_f L_t} + \frac{\ln\left(\frac{d_o}{d_i}\right)}{2\pi k_t L_t} + \frac{1}{h_i A_i}} \quad (33)$$

In equation (33), both T and T_c may be time-dependent. In the current formulation, the cooling water is not explicitly modeled, however, so no time dependence of T_c is considered, and an average value must be input. Implications of this choice of model will be discussed under **Model Implementation** later in this report.

The formulation requires experimental data to characterize fouling--thermal conductivity and thickness of the fouling layer. Such experiments are in progress (Hovis, 1992). The formulation also requires geometric factors which depend on the depth of submergence of the cooling coils. Determination of these quantities is described later in

this report. Models for the heat transfer coefficients used here and in the other heat transfer terms are also described later in this report.

Heat Transfer to the Tank

The convective/conductive heat transfer from the liquid to the tank is likewise a series of resistances, some of whose geometric parameters depend on depth of submergence. It is given by:

$$\dot{Q}_{lt} = (T_l - T_w) \left[\frac{1}{\frac{1}{h_{lb}A_b} + \frac{\Delta x_w}{2k_wA_b}} + \frac{(A_w + A_{core})_l}{\frac{1}{h_{lw}} + \frac{\Delta x_w}{2k_w}} \right] \quad (34)$$

where the two terms in brackets represent the resistance through the tank bottom and through the inner and outer walls of the annular tank, respectively. If the heat transfer coefficient from the slurry to the vertical surfaces of the tank is taken to be the same as that to the horizontal surfaces, then equation (34) is simply:

$$\dot{Q}_{lt} = (T_l - T_w) \left[\frac{A_b + (A_w + A_{core})_l}{\frac{1}{h_{lw}} + \frac{\Delta x_w}{2k_w}} \right] \quad (35)$$

This formulation considers convection from the liquid to the tank, and conduction through one-half the thickness of the tank wall (i.e. to the centerline temperature). It neglects conduction through any fouling layer which may be built up on the tank surface. Note that the vertical surface areas are only those portions of the inner and outer walls which are submerged, as indicated by the subscript *l*.

Heat Transfer to the Vapor Space

The convective heat transfer across an interface can be considered to be the sum of the resistances from the bulk liquid to the interface. This is analogous to heat transfer across a wall of zero thickness, bounded on either side by different fluids. That is,

$$\dot{Q}_{conv} = \frac{T_l - T_v}{\frac{1}{h_{lb}A_b} + \frac{1}{h_{vap}A_b}} \quad (36)$$

Evaluation of the Mass and Energy Equations for the Vapor Phase

Mass Equations

Evaluation of the summation terms on the right hand side of equation (1) is less straightforward for the vapor phase than for the liquid phase. Since the total tank volume is constant, as is the pressure in the vapor space, the nominally specified purge flow must adjust to accommodate the changing tank level governed by the liquid phase. From thermodynamics,

$$\frac{dm_i}{dt} = \left(\frac{\partial m_i}{\partial V} \right)_T \frac{dV}{dt} + \left(\frac{\partial m_i}{\partial T} \right)_V \frac{dT}{dt} \quad (37)$$

Since

$$m_i = \rho_i V \quad (38)$$

equation (37) can be expanded using the chain rule of calculus and simplified to:

$$\frac{dm_i}{dt} = \rho_i \frac{dV}{dt} + V \left(\frac{\partial \rho_i}{\partial T} \right)_V \frac{dT}{dt} \quad (39)$$

Finally, since

$$\rho_i = \rho_i(P_i, T) \quad (40)$$

equation (37) can be written as

$$\frac{dm_i}{dt} = \rho_i \frac{dV}{dt} + \frac{V}{T} \frac{dT}{dt} \left[-\rho_i + \frac{1}{\mathcal{R}_i} \frac{dP_i}{dT} \right] \quad (41)$$

where the change in vapor pressure with temperature can be expressed empirically by, e.g., Antoine's equation (Himmelblau, 1982).

Unfortunately, equation (41) expresses the component derivative in terms of other derivatives. In particular, the mass and temperature derivatives are strongly coupled. Moreover, solution of equation (39) for the mass derivative is not sufficient to specify the mass flowrate of water vaporized from the liquid phase; values for the input and output vapor streams are needed, not just their difference.

A rigorous solution to equation (39) and specification of the required flowrates requires a more complex model than developed here, one which includes dynamic effects by incorporating the momentum equation into the model. In lieu of this, an approximate scheme which was found to work well in practice was used.

In this scheme, the vapor phase is considered to have two components: water vapor and the purge gas. The latter could be a pure gas or a known mixture, e.g., of air and water. For the purge gas, a simplified form of equation (39) is used, i.e.,

$$\frac{dm_i}{dt} = \rho_i \frac{dv}{dt} \quad (42)$$

where

$$\left(\frac{dv}{dt} \right)_v = - \left(\frac{dv}{dt} \right)_l \quad (43)$$

since the total volume inside the tank is constant, and the rate of change of liquid volume is fixed by the mass flowrates of the (incompressible) liquid-phase streams. If the vapor volume increases, the incoming purge gas flowrate is increased over the nominal specification accordingly; if it decreases, the outgoing purge gas flowrate is increased over

the nominal flowrate. Knowing $\frac{dm_i}{dt}$ and either the incoming or outgoing flowrate, the other can be calculated straightforwardly.

With the purge flowrates thus fixed, and the incoming and outgoing humidities specified by input, the vaporization rate from the liquid phase can be calculated. The mass of water vapor, per mass of purge gas at saturated conditions, is calculated as (Treybal, 1980):

$$Y'_s = \frac{P_w}{P - P_w} \frac{\bar{M}_w}{\bar{M}_g} \quad (44)$$

where P is the constant pressure of the system (assumed to be 1 atm). The vapor pressure of the water, as a function of the vapor phase temperature, is given by Antoine's equation (Himmelblau, 1982, p. 591):

$$\ln P_w = 18.3036 - \frac{3816.44}{T_v [^\circ K] - 46.13} \quad (45)$$

The vaporization rate is the mass flowrate of water required to bring the purge gas influx from its initial fraction of saturation to the outgoing saturation fraction, i.e.,

$$\dot{m}_{vap} = \dot{m}_{g,in} Y'_s (\phi_o - \phi_i) \quad (46)$$

which is the mass flowrate of water into the vapor phase. The mass flowrate of water out of the vapor phase is simply

$$\dot{m}_{w,o} = \dot{m}_{g,o} Y'_s \phi_o \quad (47)$$

Energy Equation for the Vapor Phase

For the vapor phase, the following energy transfer mechanisms are considered:

- Sensible heat transfer with incoming and outgoing mass fluxes,

- Heat transfer to the cooling coils in the tank,
- Heat transfer to the tank wall, and
- Heat transfer from the liquid phase.

Each of these mechanisms is modeled in an analogous fashion to the corresponding heat transfer term for the liquid phase. For the vapor phase, there is no heat of vaporization or condensation considered. Heat transfer to the cooling coils and to the tank wall follows equations (33) and (34), using the surface areas of contact between the vapor and the coils or tank. Only the wall surface area is considered for the vapor-to-tank heat transfer. Convective heat transfer from the liquid phase is given by equation (36) (equal but opposite in sign to the corresponding term in the temperature equation for the liquid phase).

Evaluation of the Energy Equation for the Tank

The heat transfer terms for the tank energy equation are:

- Heat transfer from the liquid,
- Heat transfer from the vapor,
- Heat transfer to the cooling air, and
- Heat transfer to the ground.

The first two terms have already been discussed--they are equal but opposite in sign to the corresponding terms in the liquid and vapor energy equations.

Heat Transfer to the Air

The heat transfer to the air has three terms: (i) heat transfer to the air as it passes through the inner core; (ii) heat transfer to the air as it passes through the refractory grating; (iii) heat transfer to the air as it passes through the annulus between the primary and secondary liners. The heat transfer in the annulus is known from scoping calculations to be relatively low, since the cross-sectional area for flow is much larger than for the other two regions. On this basis, the addition of air at the bottom of this annulus is neglected, and only the air which traverses all three sections is considered in this lumped model. The three terms all have the same form:

$$\dot{Q}_{a,i} = \frac{T_i - T_a}{\frac{\Delta x_w}{2k_i A_{a,i}} + \frac{1}{h_{a,i} A_i}} \quad (48)$$

that is, conduction through one-half the thickness of the tank wall and convection to the air are considered. The heat transfer coefficients for each of the three parts will be discussed later in this report. The areas for each part are simply the surface areas of the tank in contact with the air for that portion of the air flowpath.

Heat Transfer to the Ground

A conduction path exists from the tank wall, through the refractory grating, and through the ground to the point where the ambient ground temperature is reached. This is a straightforward problem in conduction through multiple plane walls of unequal cross-section, i.e.,

$$\dot{Q}_g = \frac{T_t - T_{g,\infty}}{\frac{\Delta x_w}{2k_t A_{refrac}} + \frac{\Delta x_{refrac}}{k_{refrac} A_{refrac}} + \frac{\Delta x_{gr}}{k_{gr} A_b}} \quad (49)$$

Use of A_b in the third term in the denominator implies that the heat transfer is one-dimensional (no lateral spread). The ambient ground temperature, and the distance through the ground to reach this temperature, must be specified. In practice, this mode of heat transfer is found to be relatively quite small.

Evaluation of the Energy Equation for the Cooling Air

The energy transfer mechanisms for the air are:

- Sensible heat of incoming and outgoing streams,
- Heat transfer from tank, and
- Heat transfer from refractory grating.

Given a steady flow of air, the first of these terms is simply:

$$\Delta \dot{H}_a = \dot{m}_a c_{p,a} (T_a - T_{a,in}) \quad (50)$$

The heat transfer from the tank is as discussed in the previous section. The heat transfer from the refractory grating which forms the other three sides of the passages through which the air flows (the fourth side being the tank bottom) is approximated as being equal to the heat transfer from the tank bottom to the air, since the temperature of the grating will be similar to that of the tank. This is considered to be sufficiently accurate for this relatively small term.

Heat Transfer Coefficient Modeling

Liquid Coefficients h_i , h_{tube} , and h_{wall}

The simplistic models currently implemented reflect the lack of knowledge of mixing process for the non-Newtonian and non-homogenous liquid phase. The basic scheme is to assume natural convection occurs, in the absence of agitation, and forced convection occurs, when the liquid is agitated or mixed. Heat transfer will therefore be enhanced when agitation occurs. Although there will be movement of liquid during influxes and effluxes of material, for conservatism it is assumed that this movement is negligible.

Therefore, the enhanced heat transfer is governed solely by the operation of the agitation pumps; no enhancement is considered as a result of transfer pump operation.

A textbook value of $1.8 \text{ Btu/ft}^2/^\circ\text{C}$ (Chapman, 1974) is used for all natural convection processes in the liquid and vapor phases, i.e., no true modeling of natural convection has yet been implemented. When the agitation pumps are operated, an average forced convective heat transfer coefficient is computed for the region influenced by the pump (defined by a "radius of influence" which is an input parameter). The single, averaged heat transfer coefficient required by this lumped component formulation is then obtained as an area-weighted average of the forced and natural convection heat transfer coefficients. That is,

$$h = h_{fc} \frac{n\pi R_i^2}{A_b} + h_{nc} \frac{(A_b - n\pi R_i^2)}{A_b} \quad (51)$$

where n is the number of agitation pumps, and $n\pi R_i^2$ is less than or equal to the total surface area A_b .

The forced-convective component of equation (51) is determined as follows. It is assumed that standard heat transfer correlations for Newtonian flow are applicable.² The mode of operation of the agitation pumps is that of jet action; it is also assumed that the jet centerline velocity, a function of radial distance, is an appropriate measure of velocity for use in the correlations. Finally, it is assumed that the criterion for turbulence is based on consideration of the conditions as the jet emerges from the nozzle (cf. Tatterson, 1989).

For convection to the vapor and to the tank bottom, the Colburn equation is used to describe the heat transfer coefficient as a function of distance (Chapman, 1974):

$$Nu_x \equiv \frac{h(x)x}{k} = 0.0292 Re_x^{0.8} Pr^{1/3} \quad (52)$$

This equation applies to turbulent flow. From (Kielpinski, 1992), for the emergent jets of Tank 48's agitation pumps,

$$Re_o \approx 24,000$$

so the flow is turbulent. Substituting radial distance r for the variable x in equation (52), the average heat transfer coefficient over the radius of influence can be calculated as:

$$h_{fc} = \frac{1}{\pi R_i^2} \int_0^{R_i} \frac{Nu_r k}{r} 2\pi r dr \quad (53)$$

² The liquid phase in Tank 48, for which this model was originally developed, is considered to behave as a Bingham plastic (McLain and Goren, 1984). Such a non-Newtonian fluid behaves similarly to a Newtonian fluid when the applied shear stress exceeds its yield stress (Bird, Stewart, and Lightfoot, 1960), i.e., when it moves at all.

The jet centerline velocity as a function of radial distance can be modeled as (Tatterson, 1989):

$$U_{cj} = 1.41 U_o \text{Re}_o^{0.135} \frac{D_j}{r} \quad (54)$$

where U_o is the emergent velocity. Substituting (52) and (54) into equation (53) and evaluating gives:

$$h_{jc} = 0.0769 \frac{k}{R_i} \text{Re}_o^{0.908} \text{Pr}^{1/3} \quad (55)$$

At present, this same coefficient is used to model heat transfer between the liquid and the tank wall. This may need modification in future, since the walls are vertical instead of horizontal.

For convection to the cooling coils, the model is extrapolated from a model of flow across staggered tube bundles (Kakiç et al., 1987). The relation is:

$$\text{Nu}_x = 0.35 \left(\frac{X_t^*}{X_l^*} \right)^{0.2} \text{Re}^{0.6} \text{Pr}^{0.36} \left(\frac{\text{Pr}}{\text{Pr}_w} \right)^{0.25} \quad (56)$$

which includes a dependence on (X_t^* / X_l^*) , the ratio of the transverse and lateral distances between tubes, as well as a dependence on Prantdl numbers in the bulk and at the wall.

The orientation of the jet changes with respect to the coils as the jet rotates. The jet rotation means that the positions "lateral" and "transverse" change during the rotation; for the geometry of Tank 48, the factor $(X_t^* / X_l^*)^{0.2}$ varies between 0.87 and 1.15. For simplicity, then, this factor is set to unity. Given the lack of knowledge of liquid properties and of the tube wall temperature, and the weak dependence on the latter, the factor $(\text{Pr} / \text{Pr}_w)^{0.25}$ is likewise set to unity.

The spreading jet also gives a range of yaw angles between the flow and the coils. The non-normality of the flow reduces the heat transfer below that expected for normal flow. The fouling on the tubes gives a rough surface which would be expected to enhance heat transfer. These effects will compensate for one another to some extent.

With the above simplifications, equation (56) becomes:

$$\text{Nu}_x = 0.35 \text{Re}^{0.6} \text{Pr}^{0.36} \quad (57)$$

and the forced convective heat transfer coefficient can be evaluated in a manner similar to that outlined in equations (52)-(55) for the heat transfer coefficients to the vapor and tank. The average heat transfer coefficient is then weighted in accordance with equation (51).

Vapor Heat Transfer Coefficients

Some credit for enhanced heat transfer seems appropriate when the agitation pumps are operating in the liquid. Shear is exerted on the vapor phase when the liquid surface is in movement; the surface may also be deformed, thereby increasing the surface area. No rigorous attempt has yet been made to model the enhancement of the vapor phase heat transfer coefficient. Somewhat arbitrarily, the forced convective heat transfer coefficient for the vapor with the liquid and with the tank is taken to be 10% of that computed for the liquid.

For heat transfer to the cooling coils, a natural convection value is used at all times, including during agitation pump operation.

Cooling Water Heat Transfer Coefficient

The heat transfer coefficient inside of the cooling coils is given by standard correlations [Chapman]. For laminar flow, the Seider-Tate correlation is used:

$$Nu = 1.86 \left(Re Pr \frac{D}{L} \right)^{1/3} \quad (58)$$

where the viscosity ratio term has been dropped in view of its limited importance for water, a low-viscosity fluid. For turbulent flow, the Dittus-Boelter correlation is used:

$$Nu = 0.023 Re^{0.8} Pr^m \quad (59)$$

where m is 0.4 for heating and 0.3 for cooling of the fluid.

Air Heat Transfer Coefficients

Equation (59) is used to compute the heat transfer coefficient in the central core channel and in the refractory channels. The heat transfer coefficient in the annulus is similar to that used by Johnston (1991) to analyze waste tank temperature gradients, and is the sum of natural convective and radiative contributions. The radiative contribution is:

$$h_{rad} = \epsilon \sigma \frac{T_w^4 - T_a^4}{T_w - T_a} \quad (60)$$

while the natural convection contribution is a modified McAdams relationship developed by Steimke (1991):

$$h_{nc} = 0.12 k \left[\frac{Pr(T_w - T_{amb})\beta g}{\nu^2} \right]^{1/3} \quad (61)$$

Geometric Factors

A number of the surface areas which appear in the equations developed above are a function of the height of the liquid phase. This height is straightforwardly calculated at any

point in time, since the total mass of the liquid is a solution variable, and the mixture density is likewise tracked. The surface area of the tank wall which is in contact with the liquid is then simply:

$$A_{w,l} = A_w \frac{H_l}{H} \quad (62)$$

and similarly for the vapor. For the cooling coils, however, the surface area is not a linear function of height; the coils do not reach to the bottom or top of the tank, and "extra" area is associated with the coil bends.

The empirical coil surface area function implemented is based on the coil description given in Brewer (1977), i.e., 543 pipes with 272 bends at bottom and top, total distance (including bends) of 24.25 feet from bottom to top, with clearance of 0.75 feet from tank bottom. The radius of the bend is 1.5 feet. Based on these parameters, the function for total submerged coil length is:

$$\begin{aligned} L_l &= 0 & H_l &\leq 0.75 \\ L_l &= 89.46 + 1807.1 * (H_l - 0.75) - 1380.6 * (H_l - 0.75)^2 & 0.75 < H_l \leq 2.25 \\ L_l &= 1279.41 + 543 * (H_l - 0.75) & 2.25 < H_l \leq 23.5 \\ L_l &= 12791.49 + 890.0 * (H_l - 23.5) - 769.2 * (H_l - 23.5)^2 \\ &\quad + 477.7 * (H_l - 23.5)^3 & 23.5 < H_l \leq 25.0 \\ L_l &= 14097.0 & 25.0 < H_l \end{aligned} \quad (63)$$

with the area:

$$A_l = \pi D_{fo} L_l \quad (64)$$

which takes into account the increased area due to the fouling layer. This area is reduced if a cooling coil is valved off, assuming that each cooling coil has an equal number of bends and straight sections (which is not really the case). The corresponding length for the vapor heat transfer is the total coil length, minus equation (63), again prorated linearly with coil valve-off.

It is presumed that a new correlation for cooling coil length would have to be implemented for every configuration to which code ITP.FOR is applied.

Numerical Solution Method

All numerical solution methods have as their basis the use of the derivative to predict the future value of the dependent variable. Masses and temperatures are calculated as a function of time, i.e.,

$$m_i(t + dt) \approx m_i(t) + \frac{dm_i}{dt} \Delta t \quad (65)$$

$$T_i(t + dt) \approx T_i(t) + \frac{dT_i}{dt} \Delta t \quad (66)$$

The method of solution chosen for ITP.FOR utilizes a fourth-order Runge-Kutta solver with variable step size and is described fully in Press et al. (1986). For an assumed timestep, new values of the dependent variables are computed by a fourth-order Runge-Kutta solution over the timestep. These values are then compared with the solution obtained by halving the timestep and performing two Runge-Kutta solutions over the two halves. If the solution over the whole timestep is sufficiently close to that obtained by advancing the solution twice using the halved timestep, the new values are accepted. Otherwise, a smaller timestep is chosen and the process is repeated. The implementation of the stepsize control logic achieves fifth-order accuracy using the fourth-order solver.

The waste tank processes of interest involve step changes in heat addition and convective heat transfer coefficients. This presents numerical difficulties in that the size of an acceptable timestep changes drastically (i.e., by two or three orders of magnitude) as soon as the step occurs. To avoid these problems, the step changes are smoothed using a cubic polynomial function which satisfies the values and first derivatives at the ends of the smoothing interval (Connor and Brebbia, 1976). That is, given an initial constant value of mass or energy addition u_o , and a step change to u_1 at time t^* , the step is smoothed over the interval $2 \cdot \Delta t_s$ as

$$u(t) = u_o - 3\xi^2 + 2\xi^3 \quad (67)$$

where

$$\xi \equiv \frac{t - (t^* - \Delta t_s)}{2\Delta t_s} \quad (68)$$

This function yields the values u_o and u_1 at the endpoints of the interval, and preserves the zero derivatives at these points as well.

Outline of Code Logic

The overall structure of the ITP.FOR code is as follows:

1. The MAIN program has the following tasks:
 - call subroutine ZERO to zero out all arrays prior to starting the computation,
 - read the input deck (includes consistency checks), and
 - call subroutine ODEINT to integrate the set differential equations.
2. Subroutine ODEINT is the computational driver. Its functions are:
 - control the overall advance of the solution, by calling subroutine RKQC iteratively, and.

- print out the desired output files.
3. Subroutine RKQC is the stepper routine which takes "quality controlled" timesteps. Its functions include:

- call subroutine RK4 (a fourth-order Runge-Kutta solver),
- evaluate the solution accuracy, and
- repeat the calculation with an adjusted step-size if necessary.

4. Subroutine RK4 performs a standard fourth-order Runge-Kutta solution, i.e.,

$$y_{n+1} = y_n + \frac{k_1}{6} + \frac{k_2}{3} + \frac{k_3}{3} + \frac{k_4}{6} + O(h^5) \quad (69)$$

where:

$$k_1 = \Delta t \left. \frac{dy}{dt} \right|_{x_n, y_n} \quad (70a)$$

$$k_2 = \Delta t \left. \frac{dy}{dt} \right|_{x_n + \frac{\Delta t}{2}, y_n + \frac{k_1}{2}} \quad (70b)$$

$$k_3 = \Delta t \left. \frac{dy}{dt} \right|_{x_n + \frac{\Delta t}{2}, y_n + \frac{k_2}{2}} \quad (70c)$$

$$k_4 = \Delta t \left. \frac{dy}{dt} \right|_{x_n + \Delta t, y_n + k_3} \quad (70d)$$

The evaluation of derivatives is done by calling subroutine DERIVS.

5. Subroutine DERIVS calculates the time derivatives given by the set of equations described above. The flow of tasks performed by DERIVS (or by its calls to lower-level subroutines) is:

- evaluate the user-input mass and energy transients to establish mass and energy flowrates for the current timestep,
- calculate the change in slurry mass for the current timestep,
- calculate the average mass and volume for this timestep,
- adjust the slurry height and the other submergence-dependent geometric parameters,

- calculate the heat transfer resistances for the various modes, based on the current values of the area parameters,
- calculate the energy input terms, and
- calculate the time-derivatives of the output vector.

Model Implementation

A listing of ITP.FOR is contained in Appendix 1. Sample input and output are contained in Appendix 2.

Assumptions in the model are:

1. No spatial variation in temperature, composition, or physical properties.
2. The temperature rise of the cooling coil chromated water is sufficiently small that a constant average temperature is sufficient for calculating heat transfer.
3. The simplified purge gas mass model (which neglects the second term of equation (39)) is sufficiently accurate for the computation.
4. Area-weighted averaged heat transfer coefficients correctly describe the bulk mixing process.
5. Heat transfer coefficient correlations developed for Newtonian fluids in "standard" geometries are applicable.
6. Heat transfer in the vapor phase is enhanced by liquid agitation in direct proportion to the liquid heat transfer enhancement.
7. No time-dependence in temperatures of inflowing streams (although each stream has its own, constant inlet temperature). Likewise, pump energy input is a series of step changes.
8. No net condensation of water from the vapor back into the liquid.
9. All entering steam is presumed dry and goes fully into the liquid phase.
10. Air flow is constant through the entire flow path (in the actual configuration, additional air at the original inlet temperature is added at the bottom of the annulus between primary and secondary liners).

The most serious limitation in applying the model to a waste tank is the lack of spatial variation. In particular, the liquid phase is expected to be non-uniform in temperature, as the non-Newtonian fluid is stirred at four locations by the agitation pumps, and non-uniform in composition, as the liquid phase separates into distinct layers when mixing ceases. The liquid phase in Tank 48 is relatively homogeneous when compared to, e.g., the sludge in the Extended Sludge Processing (ESP) tanks. ITP.FOR is intended only to provide average temperatures for rapid design calculations; more detailed modeling is necessary to ensure that temperature criteria are satisfied locally.

An improved formulation would include an energy equation for the cooling water in the system of equations to be solved. The magnitude of the error in the present formulation can be estimated by considering the results of the present model for Tank 48. Except for brief periods during agitation, the heat transfer from the liquid to the cooling coils is no greater than 300,000 Btu/hr. Given the cooling water flowrate and residence time, the cooling water temperature would rise by about 2.5°C as it traverses through the coils. The temperature difference between the liquid and the cooling water is between 15 and 30°C, so the error is of the order of 10% in computing this heat transfer mechanism. Since this is one of several heat transfer mechanisms, the overall error would be less than 10%.

The lack of data for the liquid phase properties and behavior represent another limitation in obtaining useful results from the calculations. In applying the models, values appropriate for water were used for any liquid properties which were not available (e.g., Prandtl number). Data on humidity of the incoming and outgoing purge gas are scarce. Given that the vaporization of water from the liquid phase into the vapor space represents a significant heat removal mechanism, these data should be acquired.

Improved models of the cooling air heat transfer and ground conduction might be considered. Calculations to date indicate, however, that this is not a dominant heat transfer removal mechanism, so improvements in this area may not be warranted.

References

- Bird, R. B., Stewart, W. E., and Lightfoot, E. N., 1960, Transport Phenomena, John Wiley and Sons, New York.
- Brewer, J. G., 1977, "Thermal Analysis of Type III High-Level Waste Storage Tanks," DPE 3516, December.
- Chapman, A. J., 1974, Heat Transfer, 3rd ed., Macmillan, New York.
- Connor, J. J., and Brebbia, C. A., 1976, Finite Element Techniques for Fluid Flow, Newnes-Butterworths, London.
- Himmelblau, D. M., 1982, Basic Principles and Calculations in Chemical Engineering, 4th ed., Prentice-Hall, New Jersey.
- Hovis, G. L., 1992, "ITP Precipitate Thermal Conductivity Testing Program," NES-ETH-920359.
- Johnston, B. S., 1991, "Estimated Temperature Drop Across Wall of Type IIIA Tank," NES-ETH-910670.
- Kakiç, S., Shah, R. K., and Aung, R. K., 1987, Handbook of Single-Phase Convective Heat Transfer, John Wiley, New York.
- Kielpinski, A. L., 1992, "Extrapolation of In-Tank Test Data to Current Slurry Pump Operation in Tank 48," NES-CDG-920098.
- Kreith, F., and Bohn, M. S., 1986, Principles of Heat Transfer, 4th ed., Harper and Row, New York.
- McLain, M. A., and Goren, I. D., 1984, "Rheology of Non-Radioactive Simulant of Concentrated Tetraphenylborate Precipitate," DPST-84-401.
- Nuclear Reactor Technology and Scientific Computations Department Quality Assurance Manual (U), Procedure Manual 1Q-34, 1991.
- Press, W. H., Flannery, B. P., Teukolsky, S. A., and Vetterling, W. T., 1989, Numerical Recipes, Cambridge University Press, Cambridge.
- Smith, J. M., and Van Ness, H. C., 1975, Introduction to Chemical Engineering Thermodynamics, 3rd ed., McGraw-Hill, New York.
- Steimke, J. L., 1991, "Heat Transfer for Safety Rod and Thimble (U)," WSRC-TR-91-600.
- Tatterson, G., 1989, "Jet Mixing in In-Tank Processing (U)," DPST-89-380.
- Treybal, R. E., 1980, Mass-Transfer Operations, 3rd ed., McGraw-Hill, New York.

Appendix 1

```

c *****
c ***** itp.for *****
c
c      This code performs temperature transient calculations for the
c      in-tank precipitation process. The process involves mass transfers
c      into and out of the tank, changes in chemical composition, heat
c      generation via radiolytic chemical reaction, heat transfer via
c      mechanical agitation, mass transport, conduction, and convection.
c
c      The overall process consists of a number of steps involving changes
c      in total mass, etc. The user specifies the sequence of steps, the
c      duration of each step, the mass flowrate in or out, and the
c      composition of the mass flow.
c
c      Variable Names:
c      time          = time, hr
c      y             = vector of quantities to be integrated
c                    1 --> liquid temperature, deg C
c                    2 --> vapor temperature, deg C
c                    3 --> tank temperature, deg C
c                    4 --> liquid volume in tank, gallons
c                    5 to ncomp+(4-1) --> mass of component i in tank, lbm
c                    ncomp+4 --> mass of slurry in tank, lbm
c                    ncomp+5 --> mass of water vaporized from liquid
c                               phase, lbm
c                    ncomp+6 --> mass of vapor phase in tank, lbm
c                    ncomp+7 --> radiolytic heat, btu/hr
c                    ncomp+8 --> air temperature, deg C
c      maxprint      = maximum number of printout times (< or = maxtstep)
c      maxtstep      = maximum number of timesteps for whole process
c      maxstep       = maximum number of step changes for an input function
c      maxcomp       = maximum number of component streams
c                    Note the last component must be the slurry mixture
c      maxpump       = maximum number of pump heat input functions
c      ncomp         = number of component streams (input)
c      npump         = number of pumps (input)
c      itype_pump(npump) = type of pump (input parameter)
c                    1 --> agitation pump
c                    2 --> transfer pump
c      char_comp(ncomp) = character names of component streams
c      char_pump(npump) = character names of pump types
c
c      Component stream description variables:
c
c      mstep(ncomp) = number of step changes associated with stream i
c                    (max(mstep) < or = maxstep)
c      vdot(ncomp,max(mstep)) = array holding the value of the input volume
c                               stream for component i at step change j-1
c                               (note vdot(i,1) = value of volume stream i at time 0)
c      t_vdot(ncomp,max(mstep)) = times at which a step change occurs
c                               in component stream i
c      rho(ncomp) = density of component i (presumed constant over temp range)
c      cp(ncomp) = specific heat of component i (presumed constant over t)
c      mcp(ncomp) = rho*cp
c      irad(maxcomp) = array which holds a value of 1 if stream i has
c                    a radiolytic contribution, 0 otherwise
c                    Note: irad(ncomp) = 1 since slurry is radioactive
c      nrad = number of non-zero elements in irad
c      jrad(nrad) = array holding the positions of the non-zero elements

```

```

c          in irad (i.e., which components)
c      rad_stream(maxcomp) = radiolytic heat generation of component
c          i (constant) [btu/gal]
c      isteam(maxcomp) = array which holds a value of 1 if stream i will
c          condense when entering, 0 if no phase change, -1 if
c          vaporizes when entering (-1 not used at present)
c      nsteam = number of non-zero elements in isteam
c      jsteam(nsteam) = array holding the positions of the non-zero
c          elements in isteam (i.e., which components)
c
c
c      Pump input description variables:
c
c
c      nstep(npump) = number of step changes associated with pump i
c      qpump(npump,max(nstep)) = array holding the value of the input pump
c          heat function for pump i at step change j-1
c          (qpump(i,1) = value of pump heat input at time 0)
c      t_pump(npump,max(nstep)) = times at which a step change occurs in
c          pump heat input function i
c
c      Output and print variables:
c
c      print_time(maxprint) = times for printout
c      yp(ncomp+8,maxprint) = array holding transient output variables
c      qpump(npump,maxprint) = transient pump input function at print times
c      q_rad(maxprint) = array holding transient radiolytic heat
c          generation
c      q_cool(2,maxprint) = array holding transient heat removal contribution o
c          cooling water coils (1 = liquid phase, 2 = vapor phase)
c
c
c      program itp
c      implicit real*8(a-h,o-z)
c      parameter(maxtstep = 25000,maxstep = 200,
c      & maxcomp = 10,maxpump = 10,maxprint = 800)
c      parameter(in = 8,iout = 12,iex = 8,cv_air = 0.31)
c      parameter(kmax = 500,nmax = 25)
c      real*8 mass0,mtank,k_gr,k_refr,k_tk,k_foul,k_coil
c      real*8 rho_vap,rho_air
c
c      character*80 input          ! Name to read and write all input
c      character*6 chardum         ! Dummy name for reading non-data input
c      character*6 char_comp(maxcomp),char_pump(maxcomp)
c      common/char/char_comp
c      common/init/h_natconv,
c      & h_condens,cp_h2o,pi,tot_coil_length
c      common/param/ncomp,npump,itype_pump(maxpump)
c      common /props/rho(maxcomp),cp(maxcomp),cptank,
c      & k_gr,k_refr,k_tk,k_foul,k_coil
c      common /steps/mstep(maxcomp),nstep(maxpump),dtmin
c      common/times/t_vdot(maxcomp,maxstep),
c      & t_pump(maxpump,maxstep)
c      common /values/vdot(maxcomp,maxstep),tstream(maxcomp),
c      & qpump(maxpump,maxstep),
c      & nrad,irad(maxcomp),jrad(maxcomp),
c      & rad_stream(maxcomp),
c      & nsteam,isteam(maxcomp),jsteam(maxcomp)
c      common/ht/vn2,vair,tin_n2,tc,tin_air,

```



```

&      coils,tg_inf,cool_flow,air_mflow,air_mcv,
&      pump_rad,d_nozzle,discharge
common/dimensions/mtank,tk_vol,wall_area,dx_wall,
&      a_ann,a_slots,dx_refr,dx_gr,surf_area,
&      coil_od,coil_id,dx_foulo,dx_fouli,dslot,
&      tk_diam,tk_ht,foul_od,foul_id,
&      a_refr,ac_core,as_core,d_core
common/start/mass0,cp0,vol0
common/saturate/sat_frac_in,sat_frac_out

c
dimension ystart(nmax)

c
lcnt = 0

c
zero out all arrays

c
call zero(nmax,ystart)
call zero(maxcomp,rad_stream)
call zero2(maxcomp,maxstep,vdot)
call zero2(maxcomp,maxstep,t_vdot)
call zero2(maxpump,maxstep,qpump)
call zero2(maxpump,maxstep,t_pump)
call zero(maxcomp,mstep)
call zero(maxpump,nstep)
call zero(maxcomp,rho)
call zero(maxcomp,cp)
call zero(maxcomp,tstream)
do i = 1,maxcomp
  irad(i)=0
  jrad(i) = 0
  isteam(i) = 0
  jsteam(i) = 0
enddo

c
c
write out the input file as a matter of record

c
do while(lcnt.eq.0)
  read(in,'(a)')input
  write(iout,'(lx,a)')input
  if(input(1:4) .eq. '****')lcnt = 1
enddo
rewind in

c
c
read input

c
read(in,*) dtsav          ! print interval, hr
read(in,*) eps            ! desired accuracy of computation
read(in,*) endtime        ! end of computation time
read(in,*) dtmin          ! time increment for smoothing step fcns
read(in,*) d_core         ! inner diameter of central core
read(in,*) tk_diam        ! outer diameter of primary wall, ft
read(in,*) tk_ht          ! tank height, ft
read(in,*) rho_tk         ! density of tank, lbm/ft^3
read(in,*) cptank         ! heat capacity of tank,btu/lbm/deg C
read(in,*) k_tk           ! tank thermal conductivity,btu/hr/ft/deg C
read(in,*) wall_area      ! surface area of tank wall, ft^2
read(in,*) dx_wall        ! thickness of tank wall, ft
read(in,*) surf_area      ! cross-sectional area of tank, ft^2
read(in,*) tg_inf         ! ground temperature, deg C

```

```

      read(in,*) k_gr          ! ground thermal conductivity, btu/hr/ft/deg
      read(in,*) dx_gr        ! thickness of ground to tg_inf, ft
      read(in,*) cool_flow    ! total flow of coolant inside coils, gpm
      read(in,*) coils        ! no. of active coils (out of 23)
      read(in,*) coil_od      ! od of cooling coils, ft
      read(in,*) coil_id      ! id of cooling coils, ft
      read(in,*) k_coil       ! thermal conductivity of cooling coil,
                                ! Btu/hr/ft/deg C
      read(in,*) dx_foulo     ! thickness of fouling layer on coil od, ft
      read(in,*) dx_fouli     ! thickness of fouling layer on coil id, ft
      read(in,*) k_foul       ! thermal conductivity of coil fouling layer
                                ! Btu/hr/ft/deg C
      read(in,*) a_slots      ! cross-sectional area of slots, ft^2
      read(in,*) dslot        ! equivalent diameter of slots, ft
      read(in,*) a_ann        ! cross-sectional area of annulus, ft^2
      read(in,*) a_refr       ! area of tank bottom in contact
                                ! with slots, ft^2
      read(in,*) dx_refr      ! thickness of refractory slots
      read(in,*) k_refr       ! thermal conductivity of refractory matl
      read(in,*) dtstart      ! initial timestep size, hr
      read(in,*) vn2          ! volumetric flowrate of purge gas, acfm
      read(in,*) vair         ! volumetric flowrate of cooling air, acfm
      read(in,*) tin_n2       ! inlet temperature of purge gas, ?C
      read(in,*) sat_frac_in  ! saturation fraction of incoming purge gas
      read(in,*) sat_frac_out ! saturation fraction of outgoing purge gas
      read(in,*) tc           ! average cooling water temperature, ?C
      read(in,*) tin_air      ! inlet temperature of cooling air, ?C?
      read(in,*) vol0         ! initial volume of liquid in tank, gal
      read(in,*) rad0         ! initial heat generation in tank, btu/hr
      read(in,*) temp0_liq    ! initial temperature liquid, deg C
      read(in,*) temp0_vap    ! initial temperature of vapor, deg C
      read(in,*) temp0_tank   ! initial temperature of tank, deg C
      read(in,*) rho0         ! initial density (dummy value if vol0=0)
      read(in,*) cp0          ! initial specific heat (dummy if vol0=0)
      read(in,*) pump_rad     ! radius of influence of slurry pump, ft
      read(in,*) d_nozzle     ! diameter of slurry pump nozzle, inches
      read(in,*) discharge    ! slurry pump nozzle flowrate, gpm

c
      d_nozzle = d_nozzle/12.    ! change to ft
      vn2 = vn2*60.             ! change to ft^3/hr
      vair = vair * 60.         ! change to ft^3/hr
c
      tk_vol = pi*(tk_diam**2-d_core**2)/4.*tk_ht          ! ft^3
      tk_vol = surf_area*tk_ht
      write(*,*) ' tk_vol = ', tk_vol
      mtank = rho_tk*(pi*(tk_diam**2-(tk_diam-2.*dx_wall)**2)
& /4.*tk_ht + 2.*pi*tk_diam**2/4.*dx_wall)          ! lbm
      write(*,*) ' mtank = ', mtank
      ac_core = pi * d_core**2/4.
      as_core = pi * d_core*tk_ht
      air_mflow = vair*rho_air(tin_air)          ! lbm/hr
      air_mcv = air_mflow*cv_air

c
      mass0 = rho0*vol0/7.48          ! initial liquid mass, lbm
      foul_od = coil_od + 2. * dx_foulo
      foul_id = coil_id - 2. * dx_fouli
      cp(ncomp) = cp0

c
c
c
      read in component streams
c

```

```

      nrad = 0
      nsteam = 0
c
      read(in,*)ncomp
      do i = 1,ncomp
        read(in,*)char_comp(i),irad(i),isteam(i)
        write(*,10)char_comp(i)
10      format(' ',a6)
        if(irad(i).eq.1)then
          nrad=nrad+1
          jrad(nrad)=i
        endif
        if(isteam(i).eq.1)then
          nsteam=nsteam+1
          jsteam(nsteam)=i
        endif
c
c      i = ncomp is the slurry mixture
c      rho, cp are computed from the input streams
c
        if(i.lt.ncomp)then
          read(in,*)rho(i),cp(i),tstream(i)
          if(irad(i).eq.1)then
            read(in,*)rad_stream(i)
          else
            rad_stream(i)=0.
          endif
        else
          rho(i) = rho0
          cp(i) = cp0
          tstream(i) = temp0_liq
          rad_stream(i)=rad0/vol0
        endif
c
c      now read the step changes for component i
c      dtstep, t_vdot in hr, vdot in gal/hr
c
        read(in,*)mstep(i),t_vdot(i,1)
        do j = 1,mstep(i)
          read(in,*)dtstep,vdot(i,j)
          vdot(i,j) = vdot(i,j)/7.48
          t_vdot(i,j+1)=t_vdot(i,j)+dtstep
        enddo
      enddo
c
c      qpump in btu/hr
c
      read(in,*)npump
      do i = 1,npump
        read(in,*)char_pump(i),itype_pump(i)
        read(in,*)nstep(i),t_pump(i,1)
        do j = 1,nstep(i)
          read(in,*)dtstep,qpump(i,j)
          t_pump(i,j+1)=t_pump(i,j)+dtstep
        enddo
      enddo
c
      do i = 1,ncomp
      enddo

```

```

do i = 1,npump
enddo
if(endtime.eq.9999.)then
c max value of process transients fixes endtime
if(ncomp.eq.0.and.npump.eq.0)then
    endtime = 10.
else
    endtime = t_vdot(1,mstep(1)+1)
    do i = 2,ncomp
        if(t_vdot(i,mstep(i)+1).gt.endtime)then
            endtime = t_vdot(i,mstep(i)+1)
        endif
    enddo
    if(npump.gt.0)then
        do i = 1,npump
            if(t_pump(i,nstep(i)+1).gt.endtime)then
                endtime = t_pump(i,nstep(i)+1)
            endif
        enddo
    endif
endif
endtime = endtime + 0.1
endif
c
c set initial values for the dependent variables
c
ystart(1) = temp0_liq
ystart(2) = temp0_vap
ystart(3) = temp0_tank
ystart(4) = vol0/7.48          ! do computations in ft^3
do j = 5,ncomp + 3
    ystart(j) = 0.
enddo
ystart(ncomp+4) = mass0
ystart(ncomp+5) = 0.
call antoine(ystart(2),hfrac,pn2,ph2o)
rho_vap_start=(rho_h2ov(ph2o,temp0_vap)
& +rho_n2(pn2,temp0_vap))
ystart(ncomp+6) =(tk_vol - vol0/7.48)*rho_vap_start
ystart(ncomp+7) = rad0*vol0
tiny_air = 0.
do j=8,iex
    ystart(ncomp+j) = tin_air+(j-8)*tiny_air
enddo
c
c begin the calculation
c
c odeint drives the solution of the differential equation set
c
call odeint(dtsav,ystart,ncomp+iex,1.e-3,endtime,eps,
& dtstart,1.e-5,nok,nbad,kmax,tk_vol)
c
stop
end
c *****
c ***** odeint *****
c
SUBROUTINE ODEINT(dxsav,YSTART,NVAR,X1,X2,EPS,H1,HMIN,
& NOK,NBAD,kmax,tk_vol)

```

```

c
c      Runge-Kutta driver with adaptive stepsize control.  Integrates the
c      NVAR starting values YSTART from X1 to X2 with accuracy EPS,
c      storing and printing intermediate results.
c
c      H1      = initial guess at stepsize
c      HMIN    = minimum allowed stepsize
c      NOK     = number of good steps taken
c      NBAD    = number of bad steps tried (they are retried and fixed)
c      YSTART  = starting values, replaced with values at X2
c      DXSAV   = interval for saving intermediate results
c              (i.e., print interval)
c      KMAX    = maximum number of saves
c
c      Algorithm source: Numerical Recipes, W. H. Press et al., Cambridge U.
c
c      implicit real*8(a-h,o-z)
c      PARAMETER (NMAX=25,TWO=2.0,TINY=1.E-30)
c      parameter(maxtstep = 25000,maxstep = 200,
c      & maxcomp = 10,maxpump = 10,maxprint = 800)
c      parameter(iout=12)
c      DIMENSION YSTART(nmax), YSCAL(NMAX), Y(NMAX), DYDX(NMAX)
c      dimension xp(maxprint), yp(nmax,maxprint),
c      & q_pump(maxprint), q_rad(maxprint)
c      dimension q_tk_gr(maxprint),
c      & q_cool(2,maxprint), q_sl_tk(maxprint)
c      dimension q_conv(maxprint), q_vp_tk(maxprint)
c      dimension q_air(maxprint), q_steam(maxprint)
c      dimension q_vap(maxprint), rho_s(maxprint),
c      & cp_s(maxprint), height(maxprint), rho_v(maxprint)
c      dimension tout(maxprint), tot_qconv(maxprint)
c      dimension tot_q(maxprint), hsl(maxprint), h_wall(maxprint)
c      dimension h_tube(maxprint), h_vap(maxprint)
c      character*6 char_comp(maxcomp)
c
c      common/param/ncomp,npump,itype_pump(maxpump)
c      common/init/h_natconv,
c      & h_condens,cp_h2o,pi,tot_coil_length
c      common/trial/qgrad,qpump,qcool(2),qsl_tk,qvp_tk,
c      & qconv,qair,qtk_gr,qsteam,
c      & qvap,rhos,cps,ht,hs,htube,hvap,hwall,
c      & sum_mass,del_mass,sum_energy,del_mu,rhovap
c      common/char/char_comp
c      istop = 0
c
c      zero out all arrays
c
c      call zero(maxprint,h_tube)
c      call zero(maxprint,h_vap)
c      call zero(maxprint,h_wall)
c      call zero(maxprint,hsl)
c      call zero(nmax,yscal)
c      call zero(nmax,y)
c      call zero(nmax,dydx)
c      call zero(maxprint,q_tk_gr)
c      call zero(maxprint,q_pump)
c      call zero(maxprint,q_rad)
c      call zero(maxprint,q_conv)
c      call zero(maxprint,q_sl_tk)

```

```

      call zero(maxprint,q_vp_tk)
      call zero(maxprint,q_air)
      call zero(maxprint,q_steam)
      call zero(maxprint,q_vap)
      call zero(maxprint,rho_s)
      call zero(maxprint,cp_s)
      call zero(maxprint,height)
      call zero(maxprint,rho_v)
      call zero(maxprint,hout)
      call zero(maxprint,tot_qconv)
      call zero(maxprint,tot_q)
      call zero2(2,maxprint,q_cool)
      call zero(maxprint,yp)
      call zero2(maxprint,nvar,yp)
c
      istep=0
      energy = 0.
      total_q = 0.
      tot_q_conv = 0.
      tot_energy = 0.
      tmass = 0.
      tsum_mass = 0.
      X=X1
      H=SIGN(H1,X2-X1)
      NOK=0
      NBAD=0
      hdid = h1
      KOUNT=0
      DO 11 I=1,NVAR
        Y(I)=YSTART(I)
11      CONTINUE
c
c      Assure storage of first step
c
      XSAV=X-DXSAV*TWO
c
      DO 16 NSTP=1,maxtstep
        CALL DERIVS(X,Y,DYDX,h)
        DO 12 I=1,NVAR
c
c      Scaling to monitor accuracy
c
          YSCAL(I)=ABS(Y(I))+ABS(H*DYDX(I))+TINY
          if(i.gt.4.and.i.lt.ncomp+4)then
            if(yscal(i).lt.1.1e-30)yscal(i)=1.
          endif
12      CONTINUE
          IF(KMAX.GT.0) THEN
c
c      check if time to save intermediate results
c
            IF(ABS(X-XSAV).GT.ABS(DXSAV)) THEN
              IF(KOUNT.LT.KMAX-1) THEN
                KOUNT=KOUNT+1
                XP(KOUNT)=X
                DO 13 I=1,NVAR
                  YP(I,KOUNT)=Y(I)
                  if(i.eq.4)yp(i,kount) = yp(i,kount)*7.48
13      CONTINUE

```

```

XSAV=X
  q_rad(kount) = qrad
  q_conv(kount) = qconv
  q_pump(kount) = qpump
  q_steam(kount) = qsteam
  q_vap(kount) = qvap
  rho_s(kount) = rhos
  cp_s(kount) = cps
  height(kount) = ht
                    rho_v(kount) = rhovap
                    hout(kount) = hdid
  hsl(kount) = hs
  h_tube(kount) = htube
  h_vap(kount) = hvap
  h_wall(kount) = hwall
                    tot_qconv(kount) = tot_q_conv
                    tot_q(kount) = total_q
                    q_sl_tk(kount) = qsl_tk
                    q_vp_tk(kount) = qvp_tk
                    q_air(kount) = qair
                    q_tk_gr(kount) = qtk_gr

  do i = 1,2
    q_cool(i,kount) = qcool(i)
  enddo
ENDIF
ENDIF
ENDIF
C
C   If step can overshoot X2, then cut down size
C
  IF((X+H-X2)*(X+H-X1).GT.0.) H=X2-X
C
C   Take one "quality assured" step
C
  CALL RKQC(Y,DYDX,NVAR,X,H,EPS,YSCAL,HDID,HNEXT)
C

  if(x.gt.500.and.x.lt.500.5)write(*,*)' time ',x
  if(x.gt.1000..and.x.lt.1000.5)write(*,*)' time ',x
  if(x.gt.1500..and.x.lt.1500.5)write(*,*)' time ',x
  if(x.gt.2000..and.x.lt.2000.5)write(*,*)' time ',x
  if(x.gt.2500..and.x.lt.2500.5)write(*,*)' time ',x
  if(x.gt.3000..and.x.lt.3000.5)write(*,*)' time ',x
  if(x.gt.3500..and.x.lt.3500.5)write(*,*)' time ',x
  if(y(4).gt.tk_vol*0.98)then
    write(*,*)' liq vol exceeds 98% of tank capacity '
    write(*,*)' y(4),tk_vol,time = ',y(4),tk_vol,x
    istop=1
    go to 90
  endif
  istep=istep+1
  write(30,*)istep,x,hdid
  total_q = total_q + (qpump+qrad+qsteam)*hdid
  tot_q_conv = tot_q_conv + qconv*hdid
  tmass = tmass + (del_mass-sum_mass)*hdid
  tsum_mass = tsum_mass + sum_mass*hdid
  if(abs(tsum_mass).gt.1.e-2)then
    if(abs(tmass/tsum_mass).gt.0.05)then
      write(*,*)' global mass check failed at time ',x
      write(*,*)' tsum_mass = ',tsum_mass,

```

```

&          ' pct = ',tmass/tsum_mass
      endif
    endif
    energy = energy + (sum_energy - del_mu)*hdid
    tot_energy = tot_energy + sum_energy*hdid
c
c      if(abs(tot_energy).gt.0.)then
c      endif
c
c      check to see if the original stepsize guess was okay
c
c      IF (HDID.EQ.H) THEN
c        NOK=NOK+1
c      ELSE
c        NBAD=NBAD+1
c      ENDIF
c
c      if done...
c
c
90    continue
    IF ((X-X2)*(X2-X1).GE.0..or.istop.eq.1) THEN
      DO 14 I=1,NVAR
        YSTART(I)=Y(I)
        if(i.eq.4) ystart(i) = ystart(i)*7.48
14      CONTINUE
      IF (KMAX.NE.0) THEN
        KOUNT=KOUNT+1
        XP(KOUNT)=X
        DO 15 I=1,NVAR
          YP(I,KOUNT)=Y(I)
          if(i.eq.4) yp(i,kount) = yp(i,kount)*7.48
15        CONTINUE
        q_rad(kount) = qrad
        q_conv(kount) = qconv
        q_pump(kount) = qpump
        q_steam(kount) = qsteam
        q_vap(kount) = qvap
        rho_s(kount) = rhos
        cp_s(kount) = cps
        height(kount) = ht
        rho_v(kount) = rhovap
        tot_qconv(kount) = tot_q_conv
        hsl(kount) = hs
        h_tube(kount) = htube
        h_vap(kount) = hvap
        h_wall(kount) = hwall
        hout(kount) = hdid
        tot_q(kount) = total_q
        q_sl_tk(kount) = qsl_tk
        q_vp_tk(kount) = qvp_tk
        q_air(kount) = qair
        q_tk_gr(kount) = qtk_gr
        do i = 1,2
          q_cool(i,kount) = qcool(i)
        enddo
      ENDIF
      write(iout,*) ' nok = ',nok,' nbad = ',nbad
      write(iout,*) ' '
      write(iout,*) ' time          slurry temp          ',

```



```

& '    vap temp          tank temp'
do i = 1,kount
    write(iout,500)xp(i),(yp(j,i),j=1,3)
enddo
500 format(1x,f16.5,3f16.3)
write(iout,*)' '
write(iout,*)' '
icount = ncomp/3
irem = ncomp - 3*icount
if(icount.gt.0)then
    do k = 1,icount
        write(iout,100)
&        (char_comp(j),j=1+(k-1)*3,3+(k-1)*3)
        do i = 1,kount
            write(iout,500)xp(i),
&            (yp(j,i),j=5+(k-1)*3,7+(k-1)*3)
        enddo
        write(iout,*)' '
        write(iout,*)' '
        enddo
        write(iout,100) (char_comp(j),j=ncomp-irem+1,ncomp)
        do i = 1,kount
            write(iout,500)xp(i),
&            (yp(j,i),j=ncomp-irem+5,ncomp+4)
        enddo
    else
        write(iout,100) (char_comp(j),j=1,irem)
        do i = 1,kount
            write(iout,500)xp(i),(yp(j,i),j=5,4+irem)
        enddo
    endif
100 format(' time          ',3(a6,9x))
write(iout,*)' '
write(iout,*)' '
write(iout,*)' time          slurry vol    slurry dens',
& '    total Q'
do i = 1,kount
    write(iout,501)xp(i),yp(4,i),rho_s(i),tot_q(i)
enddo
write(iout,*)' '
write(iout,*)' '
write(iout,*)' time          h_tube          h_vap',
& '    h_wall'
do i = 1,kount
    write(iout,501)xp(i),h_tube(i),h_vap(i),h_wall(i)
enddo
501 format(1x,f16.5,f16.2,f16.4,f16.2)
write(iout,*)' '
write(iout,*)' '
write(iout,*)' time          tot vap"zd          ',
& 'vapor dens ',
& '    slurry cp'
do i = 1,kount
    write(iout,502)xp(i),yp(ncomp+5,i),rho_v(i),cp_s(i)
enddo
502 format(1x,f16.5,f16.2,f16.5,f16.5)
write(iout,*)' '
write(iout,*)' '
write(iout,*)' time          liq ht[ft]          vapor mass',

```

```

&      grad      '
      do i = 1,kount
          write(iout,503)xp(i),height(i),yp(ncomp+6,i),
&          yp(ncomp+7,i)
      enddo
503      format(1x,f16.5,f16.4,f16.2,f16.2)
      write(iout,*)' '
      write(iout,*)' '
      write(iout,*)' time          air temp          qconv ',
&      qsl-tk      '
      do i = 1,kount
          write(iout,504)xp(i),yp(ncomp+8,i),q_conv(i),q_sl_tk(i)
      enddo
504      format(1x,f16.5,f16.4,f16.2,f16.2)
      write(iout,*)' '
      write(iout,*)' '
      write(iout,*)' time          qvap-tk          q_cool_1',
&      qtk-gr      '
      do i = 1,kount
          write(iout,505)xp(i),q_vp_tk(i),q_cool(1,i),
&      q_tk_gr(i)
      enddo
505      format(1x,f16.5,3f16.3)
      write(iout,*)' '
      write(iout,*)' '
      write(iout,*)' time          q_vap          qpump ',
&      qsteam      '
      do i = 1,kount
          write(iout,505)xp(i),q_vap(i),q_pump(i),q_steam(i)
      enddo
      write(iout,*)' '
      write(iout,*)' '
      write(iout,*)' time          q_air',
&      '          tot Qconv'
      do i = 1,kount
          write(iout,506)xp(i),q_air(i),
&      tot_qconv(i)
      enddo
506      format(1x,f16.5,3f16.2)
      write(iout,*)' '
      write(iout,*)' '
      write(iout,*)' time          q_cool_v',
&      delta t      hslurry'
      do i = 1,kount
          write(iout,507)xp(i),q_cool(2,i),hout(i),hsl(i)
      enddo
507      format(1x,f16.5,2f16.2,f16.7)
      RETURN          ! Normal exit
      ENDIF
      IF (ABS(HNEXT).LT.HMIN) write(*,*)
&      'Stepsize smaller than minimum',
&      ' at time ',x
      H=HNEXT
16      CONTINUE
      PAUSE 'Too many steps.'
      RETURN
      END
C
C *****

```

```

C ***** rkqc *****
C
C      SUBROUTINE RKQC(Y,DYDX,N,X,HTRY,EPS,YSCAL,HDID,HNEXT)
C
C      Fifth-order Runge-Kutta step with monitoring of local truncation
C      error to ensure accuracy and adjust stepsize.
C
C      Input:
C      Y              = dependent variable vector of length N, evaluat
C      DYDX           = derivative of Y with respect to X
C      X              = starting value of independent variable
C      HTRY           = stepsize to be attempted
C      EPS            = required accuracy
C      YSCAL          = vector against which the error is scaled
C      q              = vector of q terms calculated by 1st call to derivs (1st
C                      call of 1st step of 1st call to rk4)
C
C      Output:
C      Y              = dependent variable vector, evaluated at X+HDID
C      X              = X+HDID
C      HDID           = stepsize actually accomplished
C      HNEXT          = estimate of next stepsize
C
C      Algorithm source: Numerical Recipes, W. H. Press et al., Cambridge U.
C
C      implicit real*8(a-h,o-z)
C      PARAMETER (NMAX=25,FCOR=.0666666667,
C      *      ONE=1.,SAFETY=0.9,ERRCON=6.E-4)
C      parameter(maxtstep = 25000,maxstep = 200,
C      & maxcomp = 10,maxpump = 10,maxprint = 800)
C      EXTERNAL DERIVS
C      DIMENSION Y(nmax),DYDX(nmax),YSCAL(nmax),YTEMP(NMAX),
C      & YSAV(NMAX),DYSAV(NMAX),dm(maxcomp),dv(maxcomp)
C      common/param/ncomp,npump,itype_pump(maxpump)
C      common/init/h_natconv,
C      & h_condens,cp_h2o,pi,tot_coil_length
C      PGROW=-0.20
C      PSHRNK=-0.25
C
C      Save initial values of X, Y, and DYDX
C
C      XSAV=X
C      DO 11 I=1,N
C          YSAV(I)=Y(I)
C          DYSAV(I)=DYDX(I)
C11. CONTINUE
C
C      Set stepsize to initial trial value
C
C      H=HTRY
C
C      Take two half steps
C
C1      HH=0.5*H
C      CALL RK4(YSAV,DYSAV,N,XSAV,HH,YTEMP)
C      X=XSAV+HH
C      CALL DERIVS(X,YTEMP,DYDX,HH)
C      CALL RK4(YTEMP,DYDX,N,X,HH,Y)
C      X=XSAV+H

```

```

      IF(X.EQ.XSAV)write(*,*)
&  'Stepsize not significant in RKQC at time ',x
c
c    Now take the large step
c
      CALL RK4(YSAV,DYSAV,N,XSAV,H,YTEMP)
      ERRMAX=0.
      DO 12 I=1,N
c
c        Put error estimate in YTEMP
c
c        YTEMP(I)=Y(I)-YTEMP(I)
c        if(i.eq.ncomp+6)then
c          else
c            ERRMAX=MAX(ERRMAX,ABS(YTEMP(I)/YSCAL(I)))
c          endif
12    CONTINUE
c
c        Scale relative to required tolerance
c
      ERRMAX=ERRMAX/EPS
c
c        If truncation error is too large, reduce stepsize
c
      IF(ERRMAX.GT.ONE) THEN
        H=SAFETY*H*(ERRMAX**PSHRNK)
        GOTO 1
c
c        The stepsize was successful, so estimate the size of the next step
c
      ELSE
        HDID=H
        IF(ERRMAX.GT.ERRCON) THEN
          HNEXT=SAFETY*H*(ERRMAX**PGROW)
        ELSE
          HNEXT=4.*H
        ENDIF
      ENDIF
c
c        Mop up fifth-order truncation error
c
      DO 13 I=1,N
        Y(I)=Y(I)+YTEMP(I)*FCOR
13    CONTINUE
      RETURN
      END
c
c *****
c ***** rk4 *****
c
      SUBROUTINE RK4(Y,DYDX,N,X,H,YOUT)
c
c        Fourth-order Runge-Kutta method of solving a set of ODE's over one
c        independent-variable step of size H.
c
c        Input:
c          Y              = dependent variable vector, evaluated at X
c          DYDX           = derivative of Y wrt X, evaluated by forward Euler over
c          X              = value of independent variable at beginning of

```

```

c      H                      = stepsize
c      N                      = length of Y vector
c
c      Output:
c      YOUT                   = dependent variable vector, evaluated at X+H
c
c      Algorithm source: Numerical Recipes, W. H. Press et al., Cambridge U.
c
c      implicit real*8(a-h,o-z)
c      PARAMETER (NMAX=25)
c      parameter(maxtstep = 25000,maxstep = 200,
& maxcomp = 10,maxpump = 10,maxprint = 800)
c      DIMENSION Y(nmax),DYDX(nmax),YOUT(nmax)
c      dimension YT(NMAX),DYT(NMAX)
& ,DYM(NMAX)
c      common/param/ncomp,npump,itype_pump(maxpump)
c      common/init/h_natconv,
& h_condens,cp_h2o,pi,tot_coil_length
c      HH=H*0.5
c      H6=H/6.
c      XH=X+HH
c
c      First step
c
c      DO 11 I=1,N
c          YT(I)=Y(I)+HH*DYDX(I)
11  CONTINUE
c
c      Second step: over half the stepsize
c
c      CALL DERIVS(XH,YT,DYT,hh)
c      DO 12 I=1,N
c          YT(I)=Y(I)+HH*DYT(I)
12  CONTINUE
c
c      Third step: over half the stepsize
c
c      CALL DERIVS(XH,YT,DYM,hh)
c      DO 13 I=1,N
c          YT(I)=Y(I)+H*DYM(I)
c          DYM(I)=DYT(I)+DYM(I)
13  CONTINUE
c
c      Fourth step: over the whole stepsize
c
c      CALL DERIVS(X+H,YT,DYT,h)
c
c      Accumulate increments with proper weight
c
c      DO 14 I=1,N
c          YOUT(I)=Y(I)+H6*(DYDX(I)+DYT(I)+2.*DYM(I))
14  CONTINUE
c
c      RETURN
c      END
c
c      *****
c      ***** derivs *****
c
c      subroutine derivs(time,y,dydt,delt)

```

```

c
c   Routine to drive the computation of derivatives of temperature
c   with respect to time.
c   y      = vector of quantities to be integrated
c           1 --> liquid temperature
c           2 --> vapor temperature
c           3 --> tank temperature
c           4 --> liquid volume in tank
c           5 to ncomp+(4-1) --> mass of component i in tank
c           ncomp+4 --> mass of slurry in tank
c           ncomp+5 --> mass of water vaporized from liquid
c                   phase
c           ncomp+6 --> mass of vapor phase in tank
c           ncomp+7 --> radiolytic heat, btu/hr
c           ncomp+8 --> air temperature
c   vstream(ncomp) = the element of vdot(i,j) which pertains to
c                   the derivative interval
c   mdot_tot      = total mass flow into liquid phase (negative
c                   means outflow) at time of deriv evaluation
c   tot_vstream   = total volume flow into liquid phase at time
c                   of deriv evaluation
c   q_rad         = rate of radiolytic heating, btu/hr
c
c   implicit real*8(a-h,o-z)
c   parameter(maxtstep = 25000,maxstep = 200,
& maxcomp = 10,maxpump = 10,maxprint = 800)
c   parameter(nmax = 25,iex = 8)
c   parameter(cp_air = 0.432, cv_air = 0.31)      ! btu/lbm/deg c
c   parameter(cp_h2ov = 0.893)
c   parameter(tref = 0.0)
c   parameter(a = 18.3036,b = 3816.44,c = -46.13)
c   parameter(rh = 154.40,rn=99.27)              ! ft-lbf/lbm-deg c
c   real*8 watson,cp_vap,cp_n2,rho_n2,rho_h2ov,rho_air
c   real*8 rho_h2o,xi(maxcomp),mdot_vap,n2_mdot0,n2_mdot_out0
c   real*8 n2_mdot1,n2_mdot_out1,n2_in_corr
c   real*8 y(nmax),dydt(nmax),yold(nmax),mdot_tot0,mdot_tot1
c   real*8 vstream(maxcomp),pump_heat(maxpump)
c   real*8 k_gr,k_refr,k_tk,k_foul,k_coil
c   real*8 mtank,mdot_tot,mcp,n2_mdot,n2_mdot_out,mass0
c   common/init/h_natconv,
& h_condens,cp_h2o,pi,tot_coil_length
c   common/param/ncomp,npump,itype_pump(maxpump)
c   common /props/rho(maxcomp),cp(maxcomp),cptank,
& k_gr,k_refr,k_tk,k_foul,k_coil
c   common /steps/mstep(maxcomp),nstep(maxpump),dtmin
c   common/times/t_vdot(maxcomp,maxstep),
& t_pump(maxpump,maxstep)
c   common /values/vdot(maxcomp,maxstep),
& tstream(maxcomp),
& qpump(maxpump,maxstep),
& nrad,irad(maxcomp),jrad(maxcomp),
& rad_stream(maxcomp),
& nsteam,isteam(maxcomp),jsteam(maxcomp)
c   common/trial/q_rad,q_pump,q_cool(2),qsl_tk,qvp_tk,
& q_conv,q_air,qtk_gr,q_steam,q_vap,
& rhos,cps,height,h_slurry,h_tube,h_vap,h_slurry_w,
& sum_mass,del_mass,sum_energy,del_mu,rhovap
c   common/ht/vn2,vair,tin_n2,tc,tin_air,
& coils,tg_inf,cool_flow,air_mflow,air_mcv,

```

```

&      pump_rad,d_nozzle,discharge
common/dimensions/mtank,tk_vol,awall,dx_wall,
&      a_ann,a_slots,dx_refr,dx_gr,surf_area,
&      coil_od,coil_id,dx_foulo,dx_fouli,dslot,
&      tk_diam,tk_ht,foul_od,foul_id,
&      a_refr,ac_core,as_core,d_core
common/start/mass0,cp0,vol0
common/saturate/sat_frac_in,sat_frac_out

c
nvar=ncomp+ix
tot_vstream = 0.
mdot_tot = 0.
q_steam = 0.
q_pump = 0.
q_rad =y(ncomp+7)

c
do i = 1,nvar
    yold(i) = y(i)
enddo

c
c
c***** establish system conditions at this point in time *****
sum_xi = 0.

c
do i = 1,ncomp

c
c      compute component mass fractions (for use in accounting during
c      mixture outflows)
c
    if(i.lt.ncomp)then
        xi(i) = yold(i+4)/yold(ncomp+4)
        sum_xi = sum_xi+xi(i)
    endif

c
c      establish inflows and outflows
c      step changes smoothed over period 2*dtmin
c
        vstream(i)=0.
        do j = 1,mstep(i)
            delta = time - t_vdot(i,j)
            if(abs(delta).le.dtmin)then
                ! near a step c
                if(j.eq.1)then
                    ! 1st step
                    if(t_vdot(i,1).eq.0.)then
                        vstream(i) = vdot(i,1)
                    else
                        call hermite(0.,vdot(i,1),dtmin,
&                                t_vdot(i,1),vstream(i),
&                                fraction)
                        endif
                else
                    call hermite(vdot(i,j-1),vdot(i,j),dtmin
&                                time,t_vdot(i,j),vstream(i),
&                                fraction)
                    endif
                elseif(time.gt.t_vdot(i,j)+dtmin)then
                    vstream(i)=vdot(i,j)
                endif
            endif
        enddo
    enddo
c

```

```

        if(time.ge.t_vdot(i,mstep(i)+1)+dtmin)then
            vstream(i) = 0.
        endif
c
        tot_vstream = tot_vstream + vstream(i)      ! ft^3/hr
        mdot_tot = mdot_tot + rho(i)*vstream(i)     ! lbm/hr
c
c   determine heat contribution from all condensing components
c
        if(isteam(i).eq.1)then
            q_steam = q_steam + vstream(i)*rho(i)*
                (h_condens + 100 - yold(1))
        endif
c   enddo
c
c   determine properties for the slurry
c
        if(yold(4).gt.0.)then
            rho(ncomp) = yold(ncomp+4)/yold(4)
            rad_stream(ncomp) = q_rad/yold(4)/7.48
        else
            rho(ncomp) = 0.
            rad_stream(ncomp) = 0.
        endif
        rhos = rho(ncomp)
        sum_streams = 0.
        do j = 1,ncomp-1
            sum_streams = sum_streams+yold(j+4)
        enddo
        deltam = yold(ncomp+4)+yold(ncomp+5)-sum_streams
        diff = mass0 - deltam
        mcp = deltam*cp0
        do i = 1,ncomp-1
            mcp = mcp + yold(i+4)*cp(i)
        enddo
        mcp = mcp - yold(ncomp+5)*cp_h2o
        if(mcp.lt.1.e-3)mcp = 1.e-3
        if(yold(ncomp+4).gt.0.)then
            cp(ncomp) = mcp/yold(ncomp+4)
        else
            cp(ncomp) = 1.8
        endif
        cps = cp(ncomp)
c
c   specify pump heat inputs
c
        dt_pump = 2.*dtmin
        enhance = 0.
        do i = 1,npump
            pump_heat(i)=0.
            fraction = 0.
            do j = 1,nstep(i)
                delta = time - t_pump(i,j)
                if(abs(delta).le.dt_pump)then
                    if(j.eq.1)then
                        ! near a step
                        ! 1st step
                        if(t_pump(i,1).eq.0.)then
                            pump_heat(i) = qpump(i,1)
                            fraction = 1.
                        else

```



```

                                call hermite(0.,qpump(i,1),dt_pu
&                                time,t_pump(i,1),pump_heat(i),
&                                fraction)
                                endif
                                else
&                                call hermite(qpump(i,j-1),qpump(i,j),
&                                dt_pump,time,t_pump(i,j),pump_heat(i),
&                                fraction)
                                endif
                                go to 22
                                elseif(time.ge.t_pump(i,j)+dt_pump)then
                                pump_heat(i)=qpump(i,j)
                                if(qpump(i,j).gt.0.)then
                                fraction=1.
                                else
                                fraction=0.
                                endif
                                endif
                                endif
                                enddo
c
                                if(time.ge.t_pump(i,nstep(i)+1)+dt_pump)then
                                pump_heat(i) = 0.0
                                fraction = 0.
                                endif
22                                continue
                                if(itype_pump(i).eq.1)
&                                enhance = enhance + fraction
                                q_pump = q_pump + pump_heat(i)
                                enddo
                                if(enhance.gt.4.)then
                                write(*,*)' enhance = ',enhance,' at time,delt = ',
&                                time,delt
                                stop
                                endif
c
c                                compute proration of wall and coil areas between phases
c
                                call areas(coils,tk_d,yold(4),                                ! input
&                                height,afo_cool_liq,ao_cool_liq,afi_cool_liq,
&                                ai_cool_liq,afo_cool_vap,ao_cool_vap,
&                                afi_cool_vap,ai_cool_vap,coil_length,
&                                coil_length_vap,awall_liq,awall_vap,
&                                acore_liq,acore_vap)                                ! output
c
c
c***** evaluate heat transfer coefficients, resistances *****
c
c                                Evaluate convective heat transfer coefficients...
c
                                call convec(enhance,tk_diam,d_core,h_slurry,
&                                h_tube,coil_od,dx_foulo,h_vap,h_slurry_w)
c
                                call air(time,delt,tin_air,a_slots,yold(ncomp+8),
&                                yold(1),yold(3),                                !input
&                                hann,hab,hcore)                                !output
c
c                                Evaluate heat transfer resistances...
c
c                                between slurry and vapor--

```

```

C      rconv = 1./h_slurry/surf_area+1./h_vap/surf_area
C
C      between slurry and tank bottom--
C
C      rsl_tkb = 1./h_slurry/surf_area
&      + dx_wall/2./kTk/surf_area
C
C      between slurry and tank wall (including inner core)--
C
C      if(awall_liq.lt.1.e-3)then
C          rsl_tkw = 1.e10
C      else
C          rsl_tkw = (1./h_slurry_w+dx_wall/2./kTk)*
&          (awall_liq+acore_liq)
C      endif
C
C      between vapor and tank wall (including inner core)--
C
C      if(awall_vap.lt.1.e-3)then
C          rvpTk = 1.e10
C      else
C          rvpTk = (1./h_slurry_w+dx_wall/2./kTk)*
&          (awall_vap+acore_vap)
C      endif
C
C      between liquid and cooling coils, vapor and coils--
C
C      call cool(yold(1),h_tube,coil_length_vap,
&      afo_cool_liq,ao_cool_liq,afi_cool_liq,
&      ai_cool_liq,afo_cool_vap,ao_cool_vap,
&      afi_cool_vap,ai_cool_vap,coil_length,      ! input
&      rcool_liq,rcool_vap)                      ! output
C
C      tank to annulus air (including inner core)--
C
C      rann = 1./(1./(dx_wall/2./kTk/awall+1./hann/awall)
&      +1./(1./hcore/as_core+dx_wall/2./kTk/as_core))
C
C      tank to refractory grating air--
C
C      rab = dx_wall/2./kTk/a_slots + 1./hab/a_slots
C
C      tank to refractory and ground--
C
C      rtkGr = dx_wall/2./kTk/a_refr + dx_refr/k_refr/a_refr
&      +dxGr/kGr/surf_area
C
C      ***** compute heat transfer terms *****
C
C      q_conv = (yold(1)-yold(2))/rconv
C      q_cool(1) = (yold(1)-tc)/rcool_liq
C      q_cool(2) = (yold(2)-tc)/rcool_vap
C      qsl_tkb = (yold(1)-yold(3))/rsl_tkb
C      qsl_tkw = (yold(1)-yold(3))/rsl_tkw
C      qvpTk = (yold(2)-yold(3))/rvpTk
C      qann = (yold(3)-yold(ncomp+8))/rann

```

```

      qab = (yold(3)-yold(ncomp+8))/rab
      qtk_gr = (yold(3)-tg_inf)/rtk_gr
c
      q_air = qab + qann
      qsl_tk = qsl_tkb + qsl_tkw
c
c
c***** Compute tank and air temperature derivatives *****
c
c      wall temperature derivative:
c
      dydt(3) = (qsl_tkb + qsl_tkw + qvp_tk - qtk_gr - qann)
&              /mtank/cptank
c
c      air temperature derivative
c
      air_mass = rho_air(yold(ncomp+8))*(tk_ht*ac_core
&              +183.42 +24053.)

      dydt(ncomp+8)=(air_mflow*cp_air*(tin_air-yold(ncomp+8))
&              + 2.*qab + qann)
&              /air_mass/cv_air
      if(abs(dydt(ncomp+8)).gt.2.*yold(ncomp+8))then
          small = yold(ncomp+8)/5.
          dydt(ncomp+8)=dsign(small,dydt(ncomp+8))
      endif
      if(abs(dydt(ncomp+8)).gt.10.*yold(ncomp+8))then
          write(*,*)' air deriv: ',time,dydt(ncomp+8)
      endif
c      dydt(ncomp+8) = 0.
c
c***** Compute radiolytic derivative *****
c
      dydt(ncomp+7) = 0.
      do j = 1,ncomp
          dydt(ncomp+7)=dydt(ncomp+7)
&              +vstream(j)*7.48*rad_stream(j)
      enddo
c
c***** evaluation of liquid and vapor volume, mass, *****
c***** and temp derivatives *****
c
c      component mass derivatives:
c
      do j = 1,ncomp-1
          dydt(j+4)=vstream(j)*rho(j)
          if(vstream(ncomp).lt.0.)then
              dydt(j+4) = dydt(j+4)+rho(j)*xi(j)*vstream(ncomp)
          endif
          ynew = yold(j+4)+dydt(j+4)*delt
      enddo
c
c      first approximation to liquid volume derivative
c
      dydt(4) = tot_vstream
c
c      compute current vapor properties
c
      hfg = watson(yold(2),time)

```

```

call antoine(yold(2),hfrac,pn2,ph2o)
rho_n2_in = rho_n2(14.696,tin_n2)
rho_n2_out = rho_n2(pn2,yold(2))

c
c compute approximations to mass flows in and out in order
c to compute vapor temperature derivative
c

dot_n2 = -tot_vstream*rho_n2_out
if(tot_vstream.gt.0.)then
    n2_mdout0 = (vn2 - tot_vstream)*rho_n2_in
    n2_mdout0 = n2_mdout0-dot_n2
else
    n2_mdout0 = (vn2 - tot_vstream)*rho_n2_out
    n2_mdout0 = dot_n2+n2_mdout0
endif
if(n2_mdout0.lt.0.)then
    n2_mdout0=0.
    n2_mdout0 = -dot_n2
endif
qmost_vap=q_conv-q_cool(2)-qvp_tk
qtot_vap = qmost_vap
vap_mcv = yold(ncomp+6)*cv_vap(yold(2))
mdot_tot0 = mdot_tot
h2o_in = n2_mdout0*hfrac*sat_frac_in
h2o_evap = n2_mdout0*hfrac*(sat_frac_out-sat_frac_in)
h2o_leave = n2_mdout0 * hfrac * sat_frac_out
mdot_vap=n2_mdout0-n2_mdout0+h2o_in+h2o_evap-h2o_leave

c
c vapor temperature derivative:
c

vap_enth_in = n2_mdout0*cp_n2(tin_n2)
&      *(tin_n2-tref)+h2o_in*cp_h2ov*(tin_n2-tref)
&      +h2o_evap * cp_h2ov * (yold(2)-tref)
vap_enth_out = n2_mdout0*cp_n2(yold(2))
&      *(yold(2)-tref)+h2o_leave
&      *cp_h2ov*(yold(2)-tref)
cv_enth = mdot_vap*cv_vap(yold(2))*
&      (yold(2)-tref)
dydt(2) = (vap_enth_in - vap_enth_out-cv_enth
&      +qtot_vap)/vap_mcv

c

vol_vap = surf_area*(tk_ht-height)
rhovap = yold(ncomp+6)/vol_vap
vol_vap_new = vol_vap+dydt(4)*delt
vap_temp_new = yold(2)+dydt(2)*delt
vap_mass_new = vol_vap_new*(rho_n2(pn2,vap_temp_new)+
& rho_h2ov(ph2o,vap_temp_new))
dydt_ncomp_6=(vap_mass_new-yold(ncomp+6))/delt
dydt(ncomp+6)=mdot_vap
dot_h2o = (vol_vap_new*rho_h2ov(ph2o,vap_temp_new)
& -vol_vap*rho_h2ov(ph2o,yold(2)))/delt
dot_n2 = (vol_vap_new*rho_n2(pn2,vap_temp_new)-
& vol_vap*rho_n2(pn2,yold(2)))/delt
h2o_evap_corr = dot_h2o+h2o_leave-h2o_in
n2_in_corr = dot_n2+n2_mdout0
dydt(4)=dydt(4)-h2o_evap/rho_h2o(yold(1))
dydt(ncomp+4) = mdot_tot-h2o_evap
y_ncomp4 = yold(ncomp+4)+dydt(ncomp+4)*delt
dydt(ncomp+5) = h2o_evap

```

```

      q_vap_liq = h2o_evap * hfg
      q_vap_vap = 0.
      if(q_vap_liq.lt.0.)then
        write(*,*)' condensation: q_vap_liq = ',q_vap_liq,
& ' at time, delt = ',time,delt
      endif
c
c
c***** liquid temperature derivative *****
c
c      first, compute input/output enthalpies
c
      stream_enth = 0.
      do i = 1,ncomp
        if(vstream(i).gt.0.)then
          tcross = tstream(i)
        else
          tcross = yold(1)
        endif
        stream_enth = stream_enth + vstream(i)*
& rho(i)*cp(i)*(tcross-tref)
      enddo
c
c      Include the vaporization stream, which leaves at the vapor temp
c
      q_purge = h2o_evap*cp_h2o*(yold(2)-tref)
      stream_enth = stream_enth - q_purge
      delm_term = mdot_tot*cp(ncomp)*(yold(1)-tref)
      diff = stream_enth - delm_term
c
c
& dydt(1) = (diff + q_pump+q_rad+q_steam-q_vap_liq
      -q_conv-q_cool(1)-qsl_tkb-qsl_tkw)/mcp
c
c***** quantities for mass and energy conservation checks *****
c
c      global mass check
c
      del_mass = dydt(ncomp+4)+dydt(ncomp+6)
      sum_mass = 0.
      do i = 1,ncomp
        sum_mass = sum_mass + rho(i)*vstream(i)
      enddo
      sum_mass = sum_mass+n2_mdot0-n2_mdot_out0
& +h2o_in-h2o_leave
c
c      global energy check
c
      sl_mass_new = yold(ncomp+4)+dydt(ncomp+4)*delt
      vap_mass_new = yold(ncomp+6)+dydt(ncomp+6)*delt
c
      sl_mcp = cp0*mass0
      do i = 1,ncomp-1
        sl_mcp=sl_mcp+cp(i)*(yold(i+4)+dydt(i+4)*delt)
      enddo
      cps_new = sl_mcp/sl_mass_new
c
      sl_temp_new = yold(1)+dydt(1)*delt
      vap_temp_new = yold(2)+dydt(2)*delt

```

```

    tank_temp_new=yold(3)+dydt(3)*delt
    sl_vol_new = yold(4)+dydt(4)*delt
    air_temp_new = yold(ncomp+8)+dydt(ncomp+8)*delt
c
c    liquid phase:
c
    sum_energy = 0.
    do i = 1,ncomp
        if(vstream(i).gt.0.)then
            tcross = tstream(i)
        else
            tcross = yold(1)
        endif
        sum_energy = sum_energy + vstream(i)*
&        rho(i)*cp(i)*(tcross-tref)
    enddo
c
    sum_energy = sum_energy+q_pump+q_rad+q_steam-
&    q_cool(1)-q_cool(2)+n2_mdout0*cp_n2(tin_n2)*
&    (tin_n2-tref)-n2_mdout0*cp_n2(yold(2))*
&    (yold(2)-tref)-h2o_leave*cp_h2ov*(yold(2)-tref)
&    -qtk_gr+air_mflow*cp_air*(tin_air-yold(ncomp+8))
&    +qab+h2o_in*cp_h2ov*(tin_n2-tref)
c
    del_mu = (yold(ncomp+4)*cp(ncomp)*(sl_temp_new-
&    yold(1))+cp(ncomp)*yold(1)*(sl_mass_new-
&    yold(ncomp+4)))/delt
    del_mu = del_mu + (yold(ncomp+6)*cp_vap(yold(2))*
&    (vap_temp_new-yold(2))+cp_vap(yold(2))*yold(2)*
&    (vap_mass_new-yold(ncomp+6)))/delt
    del_mu=del_mu+mtank*cptank*
&    (tank_temp_new-yold(3))/delt
    del_mu=del_mu+air_mass*cv_air*
&    (air_temp_new-yold(ncomp+8))/delt
c
    if(abs(del_mu).lt.1.e-4)then
        if(abs(sum_energy).lt.1.e-4)then
            pct = 0.
        else
            pct = (sum_energy-del_mu)/sum_energy
        endif
    else
        pct = (sum_energy-del_mu)/del_mu
    endif
    if(abs(delt).lt.1.e-5)then
        pct=0.
    endif
c
c    for reporting the total amount of energy removed from the system
c    due to vaporization, want to include the enthalpy of adjusting
c    the temperature
c
    q_vap = q_vap_liq + h2o_evap*cp_h2o*(yold(2)-yold(1))
c
    return
end
c
c*****
c*****

```

```

c
      subroutine hermite(u1,u2,dxmin,x,xstep,u,frac)
c
c      smoothing function for step change from u1 to u2 at value
c      xstep of independent variable.  user specifies smoothing interval
c      2*dxmin, which is centered around xstep.
c
      implicit real*8(a-h,o-z)
      amp = u2 - u1
      x1 = xstep - dxmin
      x2 = xstep + dxmin
      xi = (x-x1)/(x2-x1)
      u = u1 + amp * (3.*xi**2-2.*xi**3)
      frac = abs(u/amp)
      if(frac.lt.0..or.frac.gt.1.)then
        write(*,*)' frac = ',frac,' at time ',x
      endif
      return
      end

c
c*****
c*****
c
      real*8 function watson(t_c,time)
c
c      computes the heat of vaporization of water as a function of
c      temperature
c      Ref: Smit. and Van Ness, Intro to Chem. Eng. Thermodynamics,
c      3rd ed., p. 116
c
      implicit real*8(a-h,o-z)
      parameter(h_ref = 970., t_ref = 212.)
c
c      reading in temperature in C, but need it in F
c
      if(t_c.lt.0.)then
        write(*,*)' watson temp = ',t_c,' at time ',time
        watson = h_ref
        return
      endif
      t = t_c*1.8+32.
      tr_ref = (t_ref+460.)/1165.
      tr = (t+460.)/1165.
      ratio = (1.-tr)/(1.-tr_ref)
      if(ratio.lt.0.)then
        write(*,*)' watson ratio = ',ratio,' at time ',time
        watson = h_ref
        return
      endif
      watson = h_ref*((1.-tr)/(1.-tr_ref))**0.38
      return
      end

c
c*****
c*****
c
      subroutine areas(coils,tk_d,tvol,                                ! input
&      height,afo_cool_liq,ao_cool_liq,afi_cool_liq,
&      ai_cool_liq,afo_cool_vap,ao_cool_vap,

```

```

&      afi_cool_vap,ai_cool_vap,coil_length,
&      coil_length_vap,awall_liq,awall_vap,
&      acore_liq,acore_vap)                                ! output
C
      implicit real*8(a-h,o-z)
      parameter(tot_coil_length = 14097.572,pi=3.14159)
      real*8 k_gr,k_refr,k_tk,k_foul,k_coil,mtank
      common/dimensions/mtank,tk_vol,awall,dx_wall,
&      a_ann,a_slots,dx_refr,dx_gr,surf_area,
&      coil_od,coil_id,dx_foulo,dx_fouli,dslot,
&      tk_diam,tk_ht,foul_od,foul_id,
&      a_refr,ac_core,as_core,d_core
C
      height = tvol/surf_area
      foul_od = coil_od + 2.*dx_foulo
      foul_id = coil_id - 2.*dx_fouli
C
C      compute length of submerged portion of coils
C      (2" sch. 40 carbon steel, 1.5 feet radius bend)
C
      if(height.le.0.75)then
         coil_length=0.
      elseif(height.le.2.25)then
         coil_length=89.4585+1807.10*(height-0.75)
&      -1380.6*(height-0.75)**2
&      +477.729*(height-0.75)**3
      elseif(height.le.23.5)then
         coil_length=1279.41+543.*(height-2.25)
      elseif(height.le.25.)then
         coil_length=12791.49+890.0*(height-23.5)
&      -769.2*(height-23.5)**2+477.7*(height-23.5)**3
      else
         coil_length = tot_coil_length      ! totally submerged in liqui
      endif
C
C      Compute areas, accounting for reduced number of active coils
C
      coil_length = coil_length * coils / 23.
      afo_cool_liq = coil_length * foul_od * pi
      ao_cool_liq = coil_length * coil_od * pi
      ai_cool_liq = coil_length * coil_id * pi
      afi_cool_liq = coil_length * foul_id* pi
      coil_length_vap = tot_coil_length * coils / 23.
&      - coil_length
      afo_cool_vap = coil_length_vap * foul_od * pi
      ao_cool_vap = coil_length_vap * coil_od * pi
      ai_cool_vap = coil_length_vap * coil_id * pi
      afi_cool_vap = coil_length_vap * foul_id* pi
C
      awall_liq = pi*tk_diam*height
      awall_vap = pi*tk_diam*tk_ht-awall_liq
C
      acore_liq = pi*d_core*height
      acore_vap = pi*d_core*tk_ht - acore_liq
C
      return
      end
C
C

```



```

C*****
C*****
C
      subroutine air(time,delt,tin,a_slot,tair,tliq,twall,      ! input
& hann,hab,hcore)      !output
C
C      Routine to calculate heat transfer coefficients in core, slots,
C      and in annulus
C
      implicit real*8(a-h,o-z)
      real*8 k_gr,k_refr,k_tk,k_foul,k_coil
      real*8 k_air,kvisc_air,n,mtank
      common/dimensions/mtank,tk_vol,awall,dx_wall,
&          a_ann,a_slots,dx_refr,dx_gr,surf_area,
&          coil_od,coil_id,dx_foulo,dx_fouli,dslot,
&          tk_diam,tk_ht,foul_od,foul_id,
&          a_refr,ac_core,as_core,d_core
      common/ht/vn2,vair,tin_n2,tc,tin_air,
&          coils,tg_inf,cool_flow,air_mflow,air_mcv,
&          pump_rad,d_nozzle,discharge
      parameter(emiss = 0.8,steph_boltz = 0.000000001712,
& pr = 0.7,g = 32.2)
C
C      compute heat transfer coefficient for air in central core
C
      if(tair.lt.10..or.tair.gt.200.)then
        write(*,*)' tair = ',tair,' at time,delt ',time,delt
        tair = 35.
      endif
      n = 0.4
      if(tair.gt.tliq)n = 0.3
      re = vair/3600./ac_core*d_core/kvisc_air(tair)
      hcore = k_air(tair)/d_core*0.023*re**0.8*pr**n
      if(hcore.lt.1.e-3)hcore = 1.e-3
C
C      compute heat transfer coefficient in annulus
C
      if(abs(twall-tair).lt.1.e-6)then
        hrad = 0.
      else
        hrad = emiss * steph_boltz * ((twall+273.16)**4 -
& (tair+273.16)**4)/(twall - tair)
      endif
      if(abs(twall-tair).lt.1.e-6)then
        hconv_ann = 0.
      else
        hconv_ann = 0.12 * k_air(tair)*(pr*(twall - tair)
& /(tair+273.16)
& *g/kvisc_air(tair)**2)**(1/3)
      endif
      hann = hrad + hconv_ann
      if(hann.lt.1.e-3)hann=1.e-3
C
C      compute heat transfer coefficient along tank bottom
C
      n = 0.4
      if(tair.gt.twall)n = 0.3
      re = vair/3600./a_slot*dslot/kvisc_air(tair)
      hab = k_air(tair)/dslot * 0.023*re**0.8 * pr**n

```

```

      if(hab.lt.1.e-3)hab=1.e-3
c
      return
      end
c
c*****
c*****
c
      subroutine antoine(t,h2ov_frac,pn2,ph2o)
c
c      routine to calculate the mass flow of water vapor leaving the
c      slurry and entering the vapor phase as the nitrogen purge gas
c      (assumed dry) enters and exits.
c      Calculate partial pressure of water vapor using Antoine's
c      equation (Himmelblau, p. 591) and convert to psi.
c      Assume ambient pressure of 14.696 psi.
c
      implicit real*8(a-h,o-z)
      parameter(wt_n2 = 28.,wt_h2o = 18.)
      if(t.lt.0.)then
         write(*,*)' antoine temp = ',t
         return
      endif
      ph2o = 0.01934*exp(18.3036-3816.44/(t+273.16-46.13))
      pn2 = 14.696-ph2o
      h2ov_frac = ph2o/pn2/wt_n2*wt_h2o
      if(h2ov_frac.lt.0.)h2ov_frac=0.
      return
      end
c
c*****
c*****
c
      subroutine cool(t,h_tube,coil_length_vap,
&      afo_liq,ao_liq,afi_liq,
&      ai_liq,afo_vap,ao_vap,
&      afi_vap,ai_vap,coil_length,      ! input
&      rcool_liq,rcool_vap)            ! output
c
      implicit real*8(a-h,o-z)
      parameter(tot_coil_length = 14097.572)
      parameter(pi = 3.14159,hfi = 900.6)
      parameter(h_nat_conv = 1.8)
      parameter(maxtstep = 25000,maxstep = 200,
&      maxcomp = 10,maxpump = 10,maxprint = 800)
      real*8 kvisc_h2o,pr_h2o,k_h2o
      real*8 k_gr,k_refr,k_tk,k_foul,k_coil,mtank
      common/dimensions/mtank,tk_vol,awall,dx_wall,
&      a_ann,a_slots,dx_refr,dx_gr,surf_area,
&      coil_od,coil_id,dx_foulo,dx_fouli,dslot,
&      tk_diam,tk_ht,foul_od,foul_id,
&      a_refr,ac_core,as_core,d_core
      common/ht/vn2,vair,tin_n2,tc,tin_air,
&      coils,tg_inf,cool_flow,air_mflow,air_mcv,
&      pump_rad,d_nozzle,discharge
      common /props/rho(maxcomp),cp(maxcomp),cptank,
&      k_gr,k_refr,k_tk,k_foul,k_coil
c
      vel = cool_flow/coils/7.48/60./pi*4./foul_id**2

```

```

      re = vel * foul_id/kvisc_h2o(tc)
c
c      calculate h for cooling water inside tube
c
      if(re.lt.2000)then
        hi = k_h2o(tc)/foul_id*1.86*(re*pr_h2o(tc)
&        *foul_id/(tot_coil_length*coils/23.))**(1/3)
      else
        if(t.ge.tc)then
          n = 0.4
        else
          n = 0.3
        endif
        hi = k_h2o(tc)/foul_id*0.023*re**0.8
&        *pr_h2o(tc)**n
      endif
c
      if(afo_liq.lt.1.e-3)then
        rcool_liq = 1.e6
      else
        rcool_liq = 1./h_tube/afo_liq
&      + log(foul_od/coil_od)/2./pi/k_foul/coil_length
&      + log(coil_od/coil_id)/2./pi/k_coil/coil_length
&      + 1./hfi/afi_liq + 1./hi/ai_liq
      endif
c
      if(afo_vap.lt.1.e-3)then
        rcool_vap = 1.e6
      else
        rcool_vap = 1./h_nat_conv/afo_vap
&      + log(foul_od/coil_od)/2./pi/k_foul/coil_length_vap
&      + log(coil_od/coil_id)/2./pi/k_coil/coil_length_vap
&      + 1./hfi/afi_vap + 1./hi/ai_vap
      endif
c
      return
      end

c
c*****
c*****
c
      real*8 function rho_h2o(t)
      implicit real*8(a-h,o-z)
      if(t.lt.0..or.t.gt.200.)then
        write(*,*)' rho_h2o temp = ',t
        rho_h2o = 62.2
      else
        rho_h2o = 6.2483e1 - 5.7955e-3*t -2.0848e-4*t**2
      endif
      return
      end

c
c*****
c*****
c
      real*8 function kvisc_h2o(t)
      implicit real*8(a-h,o-z)
      kvisc_h2o = 6.3355e-2 - 1.4876e-3*t
&      + 1.6112e-5*t**2 - 6.4340e-8 * t**3

```

```

        return
    end

C
C*****
C*****
C
    real*8 function k_h2o(t)
    implicit real*8(a-h,o-z)
    units: btu/hr/ft/deg C
    k_h2o = (3.2776e-1 + 1.1259e-3 * t
    &         -4.6874e-6 * t**2)*1.8
    return
    end

C
C*****
C*****
C
    real*8 function pr_h2o(t)
    implicit real*8(a-h,o-z)
    pr_h2o = 1.1962e1 - 3.0670e-1 * t + 3.4371e-3 * t**2
    &         -1.3928e-5 * t**3
    return
    end

C
C*****
C*****
C
    real*8 function k_air(t)
    implicit real*8(a-h,o-z)
    units: btu/hr/ft/deg C
    k_air = (1.3993e-2 + 4.3718e-5 * t)*1.8
    return
    end

C
C*****
C*****
C
    real*8 function kvisc_air(t)
    implicit real*8(a-h,o-z)
    units: ft^2/s
    kvisc_air = (5.0764e-1 + 3.7944e-3 * t)/3600.
    return
    end

C
C*****
C*****
C
    real*8 function cp_n2(t)
    implicit real*8(a-h,o-z)
    units: btu/lbm/deg C
    cp_n2 = 0.4464
    return
    end

C
C*****
C*****
C
    subroutine convec(enhance,tk_diam,d_core,h_slurry,
    & h_tube,coil_od,dx_foulo,h_vap,h_slurry_w)

```

```

c
c      Routine to compute the convective heat transfer coefficients
c      between the liquid slurry and the tank (h_slurry), the liquid
c      slurry and the vapor phase (h_slurry), the
c      liquid slurry and the cooling coils (h_tube), vapor and core
c      (h_vap), and vapor and wall (h_vap).
c      Units of h_slurry and h_tube are Btu/hr-ft^2-deg C
c
      implicit real*8(a-h,o-z)
      parameter(slurry_visc = 2.771e-4, slurry_cond = 0.655)
      parameter(slurry_pr = 4.52)
      common/ht/vn2,vair,tin_n2,tc,tin_air,
&          coils,tg_inf,cool_flow,air_mflow,air_mcv,
&          pump_rad,d_nozzle,discharge
      common/init/h_natconv,h_condens,
&          cp_h2o,pi,tot_coil_length
c
      pct_influ = 4.*pump_rad**2/(tk_diam**2-d_core**2)
      u0 = discharge/60./7.48/pi*4./d_nozzle**2
      re0 = u0*d_nozzle/slurry_visc
      re_clear = 1.41*u0*re0**0.135*d_nozzle/slurry_visc
      h_agitate = 2.*slurry_cond*0.0292/pump_rad
&      *re_clear**0.8*slurry_pr**(1./3.)
c
      tube_od = coil_od + 2.*dx_foulo
      re_tube = 2.*1.41*u0*re0**0.135*d_nozzle*
&      tube_od/pump_rad/slurry_visc
      h_tube_bank = slurry_cond/tube_od*0.35*re_tube**0.6
&      *slurry_pr**0.36
c
      pct = enhance*pct_influ
      if(pct.gt.1.)pct = 1.
      h_slurry = pct* h_agitate+ (1. - pct) * h_natconv
      h_slurry_w = h_slurry
      h_tube = pct* h_tube_bank+ (1. - pct) * h_natconv
      h_vap = pct*h_agitate*0.1+(1.-pct)*h_natconv
      return
      end
c
c*****
c*****
c
      block data initial
      implicit real*8(a-h,o-z)
c      real*8 h_agitate /42.0/,h_natconv /1.8/,h_tube_bank /224./
      real*8 h_natconv /1.8/
      real*8 h_condens /1170./,cp_h2o /1.8/,pi /3.14159/
      real*8 tot_coil_length /14097.572/
      common/init/
&      h_natconv,h_condens,
&      cp_h2o,pi,tot_coil_length
      end
c
c*****
c*****
c
c      real*8 function rho_vap(t,pn2,ph2o)
c      implicit real*8(a-h,o-z)
c      real*8 rho_n2,rho_h2ov

```

```

c      call antoine(t,h2o,pn2,ph2o)
c      totmass = 1. + h2o
c      rho_vap = rho_n2(pn2,t)/totmass+
c      & rho_h2ov(ph2o,t)*h2o/totmass
c      return
c      end
c
c*****
c*****
c
c      real*8 function cp_vap(t)
c      implicit real*8(a-h,o-z)
c      parameter(cp_h2ov = 0.893)
c      real cp_n2
c      call antoine(t,h2o,pn2,ph2o)
c      totmass = 1. + h2o
c      cp_vap = cp_n2(t)/totmass + cp_h2ov*h2o/totmass
c      return
c      end
c
c*****
c*****
c
c      real*8 function cv_vap(t)
c      implicit real*8(a-h,o-z)
c      parameter(cv_n2 = 0.3186,cv_h2o = 0.6048)
c      call antoine(t,h2o,pn2,ph2o)
c      totmass = 1. + h2o
c      cv_vap = cv_n2/totmass + cv_h2o*h2o/totmass
c      return
c      end
c
c*****
c*****
c
c      real*8 function rho_n2(p,t)
c      implicit real*8(a-h,o-z)
c      assume perfect gas; p in psi; t read in in deg C
c      rho_n2 = 1.4506*p/(t+273.16)
c      return
c      end
c
c*****
c*****
c
c      real*8 function rho_h2ov(p,t)
c      implicit real*8(a-h,o-z)
c      assume perfect gas; p in psi; t read in in deg C
c      rho_h2ov = 0.9326*p/(t+273.16)
c      return
c      end
c*****
c*****
c
c      real*8 function rho_air(t)
c      implicit real*8(a-h,o-z)
c      assume perfect gas at 1 atm; t read in in deg C
c      rho_air = 22.041/(t+273.16)
c      return

```

```
      end
C *****
C ***** ZERO *****
C
      subroutine zero(n,array)
      implicit real*8(a-h,o-z)
      dimension array(n)
      do i = 1,n
      array(i) = 0.
      enddo
      return
      end
C
C *****
C ***** ZERO2 *****
C
      subroutine zero2(m,n,array)
      implicit real*8(a-h,o-z)
      dimension array(m,n)
      do i = 1,n
      do j = 1,m
      array(j,i) = 0.
      enddo
      enddo
      return
      end
C
```

Appendix 2

```

0.1      ! dtsav, print interval, hr
5.e-4    ! eps, desired accuracy of computation
1.0      ! endtime, hr
0.5      ! dtmin, smoothing interval for step changes, hr
6.0      ! d_core, diameter of tank core, ft
85.104   ! tk_diam, outer diameter of primary tank, ft
33.      ! tk_ht, height of tank, ft
489.     ! rho_tk, density of tank mat'l, lbm/ft^3
0.2      ! cptank, specific heat of tank mat'l, btu/lbm/deg C
47.7     ! k_tk, tank thermal conductivity, btu/hr/ft/deg C
8812.    ! wall_area, surface area of tank wall, ft^2
0.0521   ! dx_wall, tank wall thickness, ft
5527.    ! surf_area, cross-sect'l area of tank (surf area of slurry)
22.      ! tg_inf, ground temperature, deg C
0.792    ! k_gr, ground thermal conductivity, btu/hr/ft/deg C
4.0      ! dx_gr, thickness of ground to ambient temp, ft
125.     ! cool_flow, total flow of coolant inside coils, gpm
22.      ! coils, number of active cooling coils
0.19792  ! coil_od, ft
0.17225  ! coil_id, ft
47.7     ! k_coil, thermal conductivity of coil, btu/hr/ft/deg C
0.0208   ! dx_foulo, outer fouling layer thickness on coil, ft
0.       ! dx_fouli, inner fouling layer thickness on coil, ft
0.486    ! k_foul, thermal conductivity of outer fouling
3.89     ! a_slots, avg cross-sect'l area of slotted region, ft^2
0.222    ! dslot, equiv diam of one slot, ft
664.5    ! a_ann, cross-sectional area of outer annulus, ft^2
1162.    ! a_refr, area of tank bottom in contact with cooling air
0.3333   ! dx_refr, thickness of cooling slots, ft
.378     ! k_refr, thermal conductivity of refractory mat'l
0.05     ! dtstart, initial timestep size, hr
500.     ! vn2, volume flow of N2 purge gas, acfm
1650.    ! vair, volume flow of cooling air, acfm
25.      ! tin_n2, inlet temperature of purge gas, deg C
0.       ! sat_frac_in, saturation fraction of incoming purge gas
1.       ! sat_frac_out, saturation fraction of exiting purge gas
40.      ! tc, average cooling water temperature, deg C
35.      ! tin_air, inlet temperature of cooling air, deg C
425000.  ! vol0, initial volume of liquid in tank, gallons
0.7      ! rad0, initial heat generation in tank, btu/hr/gal
75.      ! temp0_liq, initial temperature liquid, deg C
75.      ! temp0_vap, initial temperature of vapor, deg C
75.      ! temp0_tank, initial temperature of tank, deg C
64.9     ! rho0, initial density of liquid in tank, lbm/ft^3
1.8      ! cp0, initial specific heat of liquid in tank, btu/lbm/deg C
25.      ! pump_rad, radius of slurry pump influence, ft
3.0      ! d_nozzle, slurry pump nozzle diameter, inches
4000.    ! discharge, nozzle flowrate, gpm
1        ! ncomp, number of material components

'slurry' 1 0
          1 0.0
          .2 -3510.

4
'slurry' 1
          1 0.0
          .1 560000.
'slurry' 1
          1 0.0

```



```

      .1 560000.
'slurry' 1
      1 0.0
      .1 560000.
'slurry' 1
      1 0.0
      .1 560000.

```

```

*****

```

```

nok =          11 nbad =          7

```

time	slurry temp	vap temp	tank temp
0.00100	75.000	75.000	75.000
0.12124	75.022	72.074	74.930
0.23835	75.042	72.060	74.920
0.33920	75.059	72.073	74.928
0.52955	75.090	72.100	74.957
0.68475	75.116	72.122	74.984
0.81930	75.139	72.147	75.008
0.92651	75.157	72.164	75.028
1.00000	75.169	72.175	75.044

time	slurry
0.00100	3687500.000
0.12124	3683787.247
0.23835	3680172.219
0.33920	3677059.253
0.52955	3671183.763
0.68475	3666392.795
0.81930	3666019.919
0.92651	3665976.815
1.00000	3665947.252

time	slurry vol	slurry dens	total Q
0.00100	425000.00	64.9000	0.00
0.12124	424571.70	64.9001	305085.08
0.23835	424154.69	64.9001	602203.08
0.33920	423795.59	64.9002	858023.26
0.52955	423117.81	64.9003	1340770.05
0.68475	422565.15	64.9003	1734344.62
0.81930	422521.76	64.9004	2075526.09
0.92651	422516.46	64.9004	2347393.37
1.00000	422512.83	64.9005	2533754.04

time	h_tube	h_vap	h_wall
0.00100	671.08	18.0755	180.76
0.12124	671.08	18.0755	180.76
0.23835	671.08	18.0755	180.76
0.33920	671.08	18.0755	180.76
0.52955	671.08	18.0755	180.76
0.68475	671.08	18.0755	180.76
0.81930	671.08	18.0755	180.76
0.92651	671.08	18.0755	180.76
1.00000	671.08	18.0755	180.76

time	tot vap"zd	vapor dens	slurry cp
------	------------	------------	-----------

0.00100	0.00	0.05290	1.80000
0.12124	50.93	0.05290	1.80000
0.23835	99.30	0.05291	1.80000
0.33920	140.97	0.05291	1.80000
0.52955	219.67	0.05291	1.80000
0.68475	283.91	0.05291	1.80000
0.81930	338.09	0.05291	1.80000
0.92651	381.20	0.05291	1.80000
1.00000	410.76	0.05291	1.80000

time	liq ht[ft]	vapor mass	grad
0.00100	10.2801	6643.38	297500.00
0.12124	10.2698	6646.43	297204.57
0.23835	10.2597	6649.42	296916.81
0.33920	10.2510	6651.99	296669.02
0.52955	10.2346	6656.84	296201.32
0.68475	10.2212	6660.80	295819.95
0.81930	10.2202	6661.06	295794.24
0.92651	10.2200	6661.06	295794.24
1.00000	10.2200	6661.06	295794.24

time	air temp	qconv	qsl-tk
0.00100	35.0000	0.00	0.00
0.12124	35.8519	267775.24	84033.25
0.23835	36.7015	270858.31	110876.72
0.33920	37.4493	271121.09	118687.75
0.52955	38.9024	271594.69	121381.11
0.68475	40.1290	271943.79	120222.26
0.81930	41.2235	271749.60	118776.13
0.92651	42.1169	271825.45	117396.01
1.00000	46.6666	271912.99	114309.24

time	qvap-tk	q_cool_l	qtk-gr
0.00100	0.000	576979.117	31678.191
0.12124	-0.072	576767.169	31636.147
0.23835	-0.072	576532.418	31630.344
0.33920	-0.072	576325.847	31635.264
0.52955	-0.072	575932.474	31652.389
0.68475	-0.072	575610.663	31668.566
0.81930	-0.072	575923.517	31683.059
0.92651	-0.072	576212.761	31694.774
1.00000	-0.072	576411.279	31704.222

time	q_vap	qpump	qsteam
0.00100	464996.348	2240000.000	0.000
0.12124	413749.485	2240000.000	0.000
0.23835	413499.153	2240000.000	0.000
0.33920	413718.794	2240000.000	0.000
0.52955	414135.561	2240000.000	0.000
0.68475	414482.629	2240000.000	0.000
0.81930	402294.725	2240000.000	0.000
0.92651	402561.181	2240000.000	0.000
1.00000	402737.809	2240000.000	0.000

time	q _{air}	tot Qconv
0.00100	79698.31	0.00
0.12124	78075.02	29630.06
0.23835	76586.74	61526.42
0.33920	75308.08	88887.64
0.52955	72831.79	140529.69
0.68475	70726.72	182611.93
0.81930	68831.61	219687.88
0.92651	67272.20	248824.77
1.00000	58968.16	268806.54

time	q _{cool_v}	delta t	hslurry
0.00100	266230.35	0.05	180.7551279
0.12124	244133.47	0.04	180.7551279
0.23835	244183.81	0.07	180.7551279
0.33920	244425.95	0.10	180.7551279
0.52955	244884.14	0.19	180.7551279
0.68475	245261.26	0.16	180.7551279
0.81930	245467.06	0.13	180.7551279
0.92651	245600.78	0.02	180.7551279
1.00000	245689.57	0.01	180.7551279

END

DATE
FILMED
5/13/93