240
9/10/84 DS ①

DR-0378-6

Energy

F
O
S
S
I
L

DOE/SF/11564-7
(DE84012761)

SEMI-ANALYTIC APPROACH TO ANALYZE SINGLE
WELL TRACER TESTS

By
Emilio Uribe Antunez
William E. Brigham

Work Performed Under Contract No. AC03-81SF11564

Stanford University Petroleum Research Institute
Stanford, California

Technical Information Center
Office of Scientific and Technical Information
United States Department of Energy

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

This report has been reproduced directly from the best available copy.

Available from the National Technical Information Service, U. S. Department of Commerce, Springfield, Virginia 22161.

Price: Printed Copy A12
Microfiche A01

Codes are used for pricing all publications. The code is determined by the number of pages in the publication. Information pertaining to the pricing codes can be found in the current issues of the following publications, which are generally available in most libraries: *Energy Research Abstracts (ERA)*; *Government Reports Announcements and Index (GRA and I)*; *Scientific and Technical Abstract Reports (STAR)*; and publication NTIS-PR-360 available from NTIS at the above address.

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency Thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

DISCLAIMER

Portions of this document may be illegible in electronic image products. Images are produced from the best available original document.

SEMI-ANALYTIC APPROACH TO ANALYZE
SINGLE WELL TRACER TESTS
TR-44

By
Emilio Uribe Antunez

William E. Brigham, Principal Investigator
Stanford University Petroleum Research Institute
Stanford, California 94305
415/497-0691

H. J. Lechtenberg, Technical Project Officer
San Francisco Operations Office
Fossil, Geothermal and Solar Division
1333 Broadway
Oakland, California 94612
415/273-7951

Work Performed for the Department of Energy
Under Contract No. DE-AC03-81SF-11564

BARTLESVILLE PROJECT OFFICE
DEPARTMENT OF ENERGY
BARTLESVILLE, OKLAHOMA

ACKNOWLEDGEMENTS

This research was carried out at the Stanford University Petroleum Research Institute under Department of Energy Contract No. DE-AC03-81SF11564. Partial support was provided by Instituto Mexicano del Petroleo and the Mexican National Council for Science and Technology.

ABSTRACT

Residual oil saturation is one of the most important parameters to be considered when analyzing a prospective field for enhanced oil recovery.

Traditionally, residual oil saturation has been estimated from cores or well logs. These methods have a small radius of investigation, evaluating saturations in a region close to the wellbore. This region is often affected by injection or production operations. Single well tracer tests have proven to be a better alternative to estimate residual oil saturation since they cover a substantially larger volume of the reservoir, and thus measure a more representative residual oil saturation of the target formation.

The method consists of the injection of a reactive tracer that is soluble in oil and water. This tracer slowly hydrolyzes forming a secondary tracer as a product of an irreversible chemical reaction. After injection, the well is shut in to allow the formation of a detectable amount of secondary tracer, which is soluble only in water. When the well is open to production, each tracer arrives to the well at different times. From the separation between the concentration peaks, residual oil saturation is estimated. However, the determination of the residual oil saturation through the analysis of single well tracer test production data, in the past, has required: 1) the use of finite difference simulators, 2) five fitting parameters and 3) considerable man-computer interaction time. In addition finite difference simulators give results that are affected by numerical dispersion. This, and the fitting parameters, add uncertainty to the uniqueness of the solution.

In this work, a new approach is presented. The test is analyzed

TABLE OF CONTENTS

	Page
ACKNOWLEDGEMENTS	ii
ABSTRACT	iii
LIST OF TABLES	vi
LIST OF FIGURES	vii
1. INTRODUCTION	1
2. LITERATURE REVIEW	4
2.1 Dispersion	5
2.1.1 Dispersion, Literature Review	5
2.2 Single Well Tracer Test, Literature Review	17
3. THEORETICAL BASIS	29
4. MODELING THE SINGLE WELL TRACER TEST	33
4.1 Formulation of the Problem	33
5. SOLVING THE SINGLE WELL TRACER TEST FORMULATION	38
5.1 Attempted Methods of Solution	38
5.2 Linear Case	40
5.2.1 Injection Period Calculations	40
5.2.1.1 Solution for the Primary Tracer	40
5.2.1.2 Solution for the Secondary Tracer	48
5.2.2 Shut In Period Calculations	52
5.2.3 Production Period Calculations	56
5.2.3.1 Primary Tracer, Production Calculations ...	56
5.2.3.2 Secondary Tracer, Production Calculations .	59
6. DISCUSSION OF RESULTS	72
6.1 Discussion on the Use of the Charts for a Radial System ...	73
6.2 Results	81
6.3 Procedure to Use the Residual Oil Correlation Charts	129
6.4 Examples	132
7. CONCLUSIONS	143

	Page
8. RECOMMENDATIONS	145
NOMENCLATURE	151
REFERENCES	156
APPENDIX A .- DERIVATION OF THE COMPONENT CONTINUITY EQUATION IN CYLINDRICAL COORDINATES	160
APPENDIX B .- SOLUTION TO THE COMPONENT CONTINUITY EQUATION IN LINEAR COORDINATES FOR THE PRIMARY TRACER	165
APPENDIX C .- SOLUTION TO REACTIVE-CONVECTIVE SYSTEM BY THE METHOD OF CHARACTERISTICS	173
APPENDIX D .- LAPLACE SPACE SOLUTION FOR THE SECONDARY TRACER	178
APPENDIX E .- APPROXIMATE SOLUTION FOR THE PRIMARY TRACER IN A RADIAL SYSTEM	185
APPENDIX F .- DERIVATION OF THE COMPLEX FLOW SYSTEM OF A WELL AFFECTED BY DRIFT	200
APPENDIX G .- COMPUTER PROGRAMS	219

LIST OF TABLES

<u>Table</u>		<u>Page</u>
2.1	Compilation of the Published Data on the Single Well Tracer Test where Ethyl Acetate was Used as the Primary Tracer.	28
5.1	Comparison Between Approximate and Exact Solutions for the Primary Tracer.	45
5.2	Check of Material Balance and the Stehfest Algorithm of Inversion from Laplace Space for the Secondary Tracer at the End of Injection.	51
6.1	Input and Processed Data to Simulate a Single Well Tracer Test.	75
6.2	Simulation Results for the Data of the Linear Flow Example.	134
6.3	Interpretation of Figures for Oil Saturation; Linear Example.	135
6.4	Interpretation of Figures for Oil Saturation; Radial Example.	141

LIST OF FIGURES.

<u>Figure</u>		<u>Page</u>
1. 1	Schematic Representation of the Single Well Chemical Tracer Test.	2
2. 1	Concentration Profile of a Dispersed System.	6
4. 1	Equilibrium Data from Partition Coefficient Determination.	36
5. 1	Comparison Between the Exact Solution Given by Eq. 5-7 and the Approximate Solution Given by Eq. 5-11.	46
5. 2	Check of Material Balance and Stehfest Algorithm of Inversion from Laplace Space for the Secondary Tracer at End of Injection.	50
5. 3	Schematic Representation of the Change in Concentration of the Primary and Secondary Tracers, from the End of Injection to the End of Shut In, as a Result of Chemical Reaction of the Primary Tracer.	53
5. 4	Graphical Representation of the Calculation of the Fictitious Initial Concentration (C_o).	57
5. 5	Schematic Representation of the Primary Tracer Production Period.	58
5. 6	Schematic Representation of the Return to the Well of the Secondary Tracer Formed During Injection and Shut In.	60
5. 7	Check of the Secondary Tracer Fit at the End of Injection, Using an Equation of the Form: $\ln C = a + bx + cx^2$.	63
5. 8	Primary and Secondary Tracer Profiles Obtained if Process is Initiated Injecting Primary Tracer at a Concentration C_o and no Shut In Time is Involved.	66
5. 9	Schematic Representation of the Calculation of the Additional Secondary Tracer Formed During a Given Production Time Uncorrected in Position.	68

<u>Figure</u>		<u>Page</u>
5.10	Schematic Representation of the Location of the Additional Secondary Tracer Formed by Chemical Reaction During a Given Production Time.	69
5.11	Position of the Primary and Secondary Tracer Profiles at an Intermediate Stage of Production.	70
6. 1	Typical Primary and Secondary Tracer Production Concentration Profiles, Obtained with this Work Test Simulator.	74
6. 2	Equivalent Areas: a) Linear and b) Radial Outward Systems for Length of Dispersion Zone Calculations.	76
6. 3	Equivalent Areas: a) Linear and b) Radial Outward-Inward Systems for Length of Dispersion Zone Calculations.	79
6. 4	Residual Oil Correlation Chart for Single Well Tracer Tests:	
	$T_{SID} = 0.5714, V_D = 2, \alpha_D = 0.0122$	84
6. 5	 : $T_{SID} = 0.4444, V_D = 3, \alpha_D = 0.0095$	85
6. 6	 : $T_{SID} = 0.3636, V_D = 4, \alpha_D = 0.0080$	86
6. 7	 : $T_{SID} = 0.7273, V_D = 2, \alpha_D = 0.0122$	87
6. 8	 : $T_{SID} = 0.6154, V_D = 3, \alpha_D = 0.0095$	88
6. 9	 : $T_{SID} = 0.5333, V_D = 4, \alpha_D = 0.0080$	89
6.10	 : $T_{SID} = 0.8000, V_D = 2, \alpha_D = 0.0122$	90
6.11	 : $T_{SID} = 0.7059, V_D = 3, \alpha_D = 0.0095$	91
6.12	 : $T_{SID} = 0.6316, V_D = 4, \alpha_D = 0.0080$	92
6.13	 : $T_{SID} = 0.5714, V_D = 2, \alpha_D = 0.0244$	93
6.14	 : $T_{SID} = 0.4444, V_D = 3, \alpha_D = 0.0189$	94
6.15	 : $T_{SID} = 0.3636, V_D = 4, \alpha_D = 0.0160$	95
6.16	 : $T_{SID} = 0.7273, V_D = 2, \alpha_D = 0.0244$	96
6.17	 : $T_{SID} = 0.6154, V_D = 3, \alpha_D = 0.0189$	97
6.18	 : $T_{SID} = 0.5333, V_D = 4, \alpha_D = 0.0160$	98
6.19	 : $T_{SID} = 0.8000, V_D = 2, \alpha_D = 0.0244$	99

<u>Figure</u>		<u>Page</u>
6.20	Residual Oil Correlation Chart for Single Well Tracer Tests: $T_{SID} = 0.7059, V_D = 3, \alpha_D = 0.0189$	100
6.21	 : $T_{SID} = 0.6316, V_D = 4, \alpha_D = 0.0160$	101
6.22	 : $T_{SID} = 0.5714, V_D = 2, \alpha_D = 0.0366$	102
6.23	 : $T_{SID} = 0.4444, V_D = 3, \alpha_D = 0.0284$	103
6.24	 : $T_{SID} = 0.3636, V_D = 4, \alpha_D = 0.0240$	104
6.25	 : $T_{SID} = 0.7273, V_D = 2, \alpha_D = 0.0366$	105
6.26	 : $T_{SID} = 0.6154, V_D = 3, \alpha_D = 0.0284$	106
6.27	 : $T_{SID} = 0.5333, V_D = 4, \alpha_D = 0.0240$	107
6.28	 : $T_{SID} = 0.8000, V_D = 2, \alpha_D = 0.0366$	108
6.29	 : $T_{SID} = 0.7059, V_D = 3, \alpha_D = 0.0284$	109
6.30	 : $T_{SID} = 0.6316, V_D = 4, \alpha_D = 0.0240$	110
6.31	 : $T_{SID} = 0.5714, V_D = 2, \alpha_D = 0.0489$	111
6.32	 : $T_{SID} = 0.4444, V_D = 3, \alpha_D = 0.0378$	112
6.33	 : $T_{SID} = 0.3636, V_D = 4, \alpha_D = 0.0320$	113
6.34	 : $T_{SID} = 0.7273, V_D = 2, \alpha_D = 0.0489$	114
6.35	 : $T_{SID} = 0.6154, V_D = 3, \alpha_D = 0.0378$	115
6.36	 : $T_{SID} = 0.5333, V_D = 4, \alpha_D = 0.0320$	116
6.37	 : $T_{SID} = 0.8000, V_D = 2, \alpha_D = 0.0489$	117
6.38	 : $T_{SID} = 0.7059, V_D = 3, \alpha_D = 0.0378$	118
6.39	 : $T_{SID} = 0.6316, V_D = 4, \alpha_D = 0.0320$	119
6.40	 : $T_{SID} = 0.5714, V_D = 2, \alpha_D = 0.0611$	120
6.41	 : $T_{SID} = 0.4444, V_D = 3, \alpha_D = 0.0473$	121
6.42	 : $T_{SID} = 0.3636, V_D = 4, \alpha_D = 0.0400$	122
6.43	 : $T_{SID} = 0.7273, V_D = 2, \alpha_D = 0.0611$	123
6.44	 : $T_{SID} = 0.6154, V_D = 3, \alpha_D = 0.0473$	124

<u>Figure</u>		<u>Page</u>
6.45	Residual Oil Correlation Chart for Single Well Tracer Tests: $T_{SID} = 0.5333, V_D = 4, \alpha_D = 0.0400$	125
6.46	 : $T_{SID} = 0.8000, V_D = 2, \alpha_D = 0.0611$	126
6.47	 : $T_{SID} = 0.7059, V_D = 3, \alpha_D = 0.0473$	127
6.48	 : $T_{SID} = 0.6316, V_D = 4, \alpha_D = 0.0400$	128
6.49	Field Test Production Profiles for the Primary Tracer.	139
6.50	Field Test Production Profiles for the Secondary Tracer.	140
8. 1	Residual Oil Correlation Chart for Single Well Tracer Tests: $T_{SID} = 0.5714, V_D = 2, \alpha_D = 0.0163$	146
8. 2	Injection, Shut-In, Production Path Followed by a Particle Along a Given Streamchannel in the Presence of Drift.	147
8. 3	Injection Path of the Primary and Secondary Tracers in the Presence of Drift.	148
8. 4	Shut In Paths of the Primary and Secondary Tracers in the Presence of Drift.	149
8. 5	Production Paths of the Primary and Secondary Tracers in the Presence of Drift.	150
C. 1	Schematic Representation of the Space Characteristic Solution of a Reactive-Convective System.	177

1. INTRODUCTION

The importance of knowing the residual oil saturation (S_{or}), relies on the fact that the residual oil saturation is a parameter necessary for many reservoir engineering calculations; to name a few: material balance calculations, economic analysis of a reservoir candidate for enhanced oil recovery, calibration of logs, and estimation of reserves. Of these, the application for enhanced oil recovery is particularly important.

The single well tracer method is mainly used to calculate residual oil saturation (S_{or}) in a reservoir with a high water saturation after waterflooding. It has the advantage over the other widely used S_{or} determination techniques, core analysis and well logging, in that it gives an average residual oil saturation over a much larger volume of reservoir. Around a single well, the volume covered in the test could be well over several thousand barrels of pore space. This implies that the measurement will not be affected by any sharp saturation changes that often occur adjacent to the wellbore

The concept behind the method is to inject a slug of a primary tracer such as ethyl acetate which will dissolve in water and oil, (Fig. 1a), followed by a bank of tracer free water, (Fig. 1b). The next step is shut in the well, (Fig. 1c) to allow a fraction of the tracer to react, forming another compound (ethyl alcohol) commonly called the secondary tracer. As the product of an irreversible chemical reaction; this secondary tracer has different oil/water solubility characteristics. Finally, the well is opened to production, (Fig. 1d) and the producing concentration profiles of the two tracers are tracked. The basic information for the analysis of the method is obtained from the separation seen on the two production concentration profiles.

INJECTION

(a) Primary Tracer Bank

Primary Tracer

Secondary Tracer

(b) Primary Tracer + Brine Banks

(c) REACTION

(d) PRODUCTION

Fig. 1.1 - Schematic Representation of the Single Well Chemical Tracer Test (After Tomich, et al, 1973).

The tracer to be chosen as a primary tracer could be any organic acid ester having a significant solubility in both water and oil (Braggs, et al 1976). Once the secondary tracer is formed and the well is opened to production, since the primary tracer is soluble in both oil and water and the secondary tracer is only soluble in water, the two tracers will travel toward the well at different velocities, creating a lag in arrival times. The magnitude of this lag depends on the residual oil saturation, being greater at higher oil saturations. The same process can be operated in reverse to determine the irreducible water saturation in a formation which has high oil saturation.

The equations used to simulate the process as described by Tomich, et al (1973) have heretofore been solved using finite differences simulators. The disadvantage of this kind of solution is that the results are invariably affected by numerical dispersion. In addition, since there are five fitting parameters: 1) dispersion constant, D , 2) constant of reaction, k_r , 3) time step, Δt , 4) grid separation, Δr and 5) residual oil saturation, S_{or} , to match the numerical model to the field data, the uniqueness of the results is questionable. In addition the man-computer interaction time involved in analyzing such test data is large.

The motivation to pursue this work was to present a set of correlating charts that could be used for the practicing engineer to speed up the process of estimating the residual oil saturation when using a single well chemical tracer test for this purpose.

In this work, a new approach is presented. The test is analyzed using approximate analytic solutions that have proven to be quite accurate, and which avoid the numerical dispersion problem. The results of the analysis are presented in a set of charts covering the usual range of: 1) the ratio of the total volume of fluid injected to the volume of the slug containing the primary tracer, 2) dimensionless shut-in time, 3) dimensionless dispersion and, 4) residual oil saturation. The rate of reaction was also analyzed but it exhibited a negligible effect on the results.

2. LITERATURE REVIEW

Tracer tests have proven to be a useful techniques to evaluate certain reservoir parameters. In general, tracer tests could be divided into two types:

- 1.- Well to well tests. In these tests, tracers are injected into the well and are produced in offset wells. The data on concentration versus volume produced are used to detect heterogeneities, to analyze fluid flow trends, and for the evaluation of fluid sweep efficiency.
- 2.- Single well tracer test. In these tests a tracer is injected into a well and is moved out into the reservoir where it reacts to form a secondary tracer. The well is then produced, and the concentration history of the two tracers is used to estimate immobile fluid saturation, S_{or} or S_{wc} , to determine waterflood conformance and to evaluate the potential of chemical enhanced oil recovery processes.

This work is involved only with the second kind of test, the single well tracer test. Depending on how it is designed, such a test can be used to determine connate water or residual oil saturation; in either case the saturation of the fluid to be evaluated has to be immobile. Of the two cases, the determination of the residual oil saturation is the most important and will be the only one covered in this work. However, the theory developed here will also be applicable for the determination of connate water saturation.

This chapter will be divided in two sections: 1) a discussion of

dispersion, which is not meant to be an exhaustive review of the literature on the topic but rather is a review of papers relevant to the development of the semi-analytic solutions presented later, and 2) a review of the literature published to date on single well tracer tests.

2.1 Dispersion.

When two miscible fluids are flowing through a porous medium, they mix due either to uneven fluid flow or due to concentration gradients resulting from the movement of the fluids. The effect of distributing one component into the second is called dispersion.

If a fluid were to immiscibly displace another fluid with the same physical properties (viscosity and density), neglecting capillary and gravitational effects the interface between the two fluids would be a sharp front (line a-a' in Fig. 2.1). But one miscible fluid displacing another of the same characteristics in a porous medium develops a transition zone due to the dispersion of one into the other. This results in an S-shaped concentration profile, which is typical of a dispersed system.

2.1.1 Dispersion, Literature Review.

According to Perkins and Johnston, (1963) and Greenkorn and Kessler, (1969), the microscopic mechanisms that lead to observable macroscopic dispersion are:

- a. Molecular diffusion. When time involved in a displacement process is long, two miscible fluids in contact, originally with a sharp interface, will diffuse one into the other by molecular diffusion, creating a transition zone of smoothly changing concentration between them.

Fig. 2.1 - Concentration Profile of a Dispersed System.

- b. Eddies. Turbulent flow in individual flow channels results in dispersion from eddy migration.
- c. Mixing due to tortuosity. Tortuosity in porous media causes fluids flowing through different porous channels to arrive at a given location at different times.
- d. Incomplete connectivity of the porous medium. Due to the presence of flow channels of different sizes, fluids could be trapped in small pores while flow continues in bigger pores, leaving behind some material to be diffused into the flow stream later on during the displacement. This is particularly noticeable in vugular systems.
- e. Recirculation caused by local regions of reduced pressure. A venturi effect created by throats in the porous system can create zones of low pressure which will promote the recirculation of fluids.

- f. Hydrodynamic dispersion. The adhesion of fluids to the grain surfaces (adsorption), creates velocity profiles within the pore channels. These velocity profiles are cup shaped. Therefore, they originate concentration gradients, creating dispersion. This phenomenon is often called Taylor (1953) dispersion.

g. Macroscopic dispersion. Created by non-idealities which change gross streamlines.

Of all these mechanisms the most important in most porous systems is the mixing due to tortuosity, mechanism "c" above.

According to Blackwell, Rayne and Terry (1959), molecular diffusion perpendicular to flow tends to decrease convective dispersion due to velocity variations.

Blackwell (1962), subdivided the mixing process (dispersion) into two terms, longitudinal and lateral (transverse) mixing. He found that both kinds of mixing are functions of molecular diffusion at low rates and functions of convection at high rates. He found that at high reservoir rates the lateral dispersion coefficient was about 1/24th of the longitudinal dispersion.

Aronofsky and Heller (1957), based on an analogy with Fick's law of diffusion with a mass transport term, presented a mathematical expression to calculate the mixing and diffusion for the flow of two miscible liquids of equal viscosity and density in a linear porous medium.

$$K \frac{\partial^2 C}{\partial x^2} - v \frac{\partial C}{\partial x} = \frac{\partial C}{\partial t} \quad (2- 1)$$

With the following initial and boundary conditions:

$$C(0,t) = 1 \quad (2- 2)$$

$$C(x,0) = 0 \quad (2- 3)$$

$$C(x,t) = 0 \quad (2- 4)$$

$x \rightarrow \infty$

Where,

C = Displacing fluid concentration

K = Dispersion coefficient

v = Microscopic velocity

Concentration (C) goes from zero for pure initial fluid to one for pure injected fluid.

The solution to Eq. 2-1, was given as:

$$C(x,t) = \frac{1}{2} \left[\operatorname{erfc} \left(\frac{x - v t}{\sqrt{4 K t}} \right) + e^{\frac{v x}{K}} \operatorname{erfc} \left(\frac{x + v t}{\sqrt{4 K t}} \right) \right] \quad (2- 5)$$

In general, the second term in the right hand side of Eq. 2-5 could be neglected except, 1) for a short distance from the inlet face at small values of time or 2) when K is very large. Aronofsky and Heller also established that the dispersion coefficient, K , was directly proportional to velocity. This is what would be expected if tortuosity were the dominant mixing mechanism.

Ogata and Banks (1961) showed that neglecting the second term in the RHS of Eq. 2-5, implied an assumption of symmetrical front around the 50 % concentration point, instead of the actual asymmetrical front obtained in miscible displacements. They showed that errors of the order of magnitude equivalent to experimental errors ($\sim 3\%$), are made due to this assumption. They agreed with Aronofsky and Heller that the second term in the RHS of Eq. 2-5, is important only when calculations close to the source are to be considered. They gave the expression $x > 500 \alpha$, where α is the constant of dispersion, as the limit where

this second term becomes negligible.

Raimondi, et al (1959), showed that the mixing coefficient was a function of molecular diffusion and a dispersion constant determined according to the porous medium, as follows:

$$K = D' + \alpha v \quad (2- 6)$$

Where:

K = Effective mixing coefficient

D' = Mixing constant, depending on the diffusion coefficient and the cementation factor in the porous medium.

v = Velocity of flow

α = Dispersion constant, depending on the porous medium. This constant is due to variations in velocity of individual flow paths.

Handy (1958), working with sugar-methanol experimental floods at rates and diffusion coefficients similar to those expected in field solvent floods, concluded that diffusional mixing was less important than mechanical mixing (α). Even in the case of adverse viscosity ratio, where fingering was present, molecular diffusion still was not important. He did not find any appreciable rate effect on determining the mixing zone size, which led him to the conclusion that miscible liquid displacement is better described by the dispersion theory (the α in Eq. 2-6) than with molecular diffusion theory (the D' in Eq. 2.6).

From these results it can be seen that for most purposes, Eq. 2-5 can be written as,

$$C(x,t) = \frac{1}{2} \operatorname{erfc} \left(\frac{x - v t}{\sqrt{4 K t}} \right) \quad (2-7)$$

And Eq. 2-6, as,

$$K = \alpha v \quad (2-8)$$

Baldwin (1966), presented a method to predict dispersion in a diverging-converging radial system and introduced the similarity between Eq. 2-7 and the equation of a normal distribution. Defining Eq. 2-7 in terms of the standard deviation, and redefining B.C. (Eq.2-2) as $C(0,t) = C_0$, Eq. 2-7 becomes,

$$\frac{C}{C_0} = \frac{1}{2} \operatorname{erfc} \left(\frac{x - \bar{x}}{\sqrt{2\sigma^2}} \right) \quad (2-9)$$

Where:

σ = Standard deviation

$\bar{x} = v t$,Average distance traveled by front

Also,

$$\sigma^2 = 2 K t = 2 \alpha v t = 2 \alpha \bar{x} \quad (2-10)$$

Representing Eq. 2-7 in terms of statistical parameters, standard deviation can be thought as a measure of the width of the dispersed front or the length of the dispersed zone.

The change in the length of the dispersion zone was defined by Baldwin as the result of two effects:

a.- Dispersion due to distance traveled $(d\sigma)_1$

b.- Dispersion due to radial geometry $(d\sigma)_2$

Then,

$$d\sigma = (d\sigma)_1 + (d\sigma)_2 \quad (2-11)$$

He showed that the length of the dispersion zone for the radial case, was of the form,

$$\sigma^2 = \frac{2}{3} \alpha r \quad (2-12)$$

Brigham (1973) extended Baldwin's work for radial flow to a generalized form useful in any geometry, where the width of the system varies linearly with distance and the flow rate is constant. This is,

$$\sigma_2^2 = \sigma_1^2 \left(\frac{W_1}{W_2} \right)^2 + K \pm \left[1 + \left(\frac{W_1}{W_2} \right)^2 \right] + \frac{2 \alpha L}{3} \left[\frac{1 - (W_1 / W_2)^3}{1 - (W_1 / W_2)} \right]$$

(2-13)

Where,

σ = Length of the dispersion zone

σ_1 = Length of the dispersion zone at inlet

W_1 = Width of the inlet face

W_2 = Width of the outlet face

L = Length of the porous medium

He showed that, when making the appropriate substitutions, Eq. 2-13 will reproduce Baldwin's radial and linear cases.

Abbaszadeh and Brigham (1982) showed that when molecular diffusion and transverse dispersion are neglected Eq. 2-13 can be expressed in an integral form and the resulting equation can be used for a system with an arbitrary shape:

$$\sigma^2(\bar{s}) = 2 \alpha v^2(\bar{s}) \int_0^{\bar{s}} \frac{ds}{v^2(s)} \quad (2-14)$$

Where,

v = Velocity of fluid at location s or $\bar{s}$

α = Mixing constant

ds = Incremental path along the streamline

In these derivations it is implied that modifying σ in such a way that any change in geometry is taken into account, the linear solution given by Eq. 2-9 could be transformed to handle any geometry as was shown by Brigham (1973) and Abbaszadeh and Brigham (1982).

For a purely dispersive system, Taylor (1953) showed that the dispersion coefficient (K) could be estimated, by graphing the experimental data on arithmetic - probability paper and reading from the graph the required values to apply the equation,

$$K = \frac{1}{t} \left(\frac{x_{90} - x_{10}}{3.625} \right)^2 \quad (2-15)$$

Where,

x_{10} = Distance to the point where the concentration is 10 per cent displacing fluid

x_{90} = Distance to the point where the concentration is 90 per cent displacing fluid

K = Dispersion coefficient

Eqs. 2-7 and 2-15 are useful when calculations of concentrations vs. distance are required at different times as the dispersion front moves within the porous medium. But in practice, a miscible displacement or tracer test is carried out by measuring fluid concentrations at fixed locations, which can be at the outlet face of a core or at a production well. For that purpose, Brigham, et al (1961) presented a method which starts by modifying the argument of the complementary error function in Eq. 2-7 as follows,

$$\frac{x - v t}{\sqrt{4 K t}} = \frac{L U}{\sqrt{4 K t_{pv}}} \quad (2-16)$$

Where,

$$U = \frac{V_p - V}{\sqrt{V_p V}} \quad (2-17)$$

L = Length of the porous medium

t_{pv} = Time required to inject one pore volume

V = Volume of fluids recovered at time of sample

V_p = Pore volume of the porous medium

Plotting U vs per cent of displacing fluids on arithmetic - probability paper and passing the best straight line through the plotted experimental data, Brigham, et al showed that using an equation similar to the one derived by Taylor,

$$K = \frac{1}{t_{pv}} \left[\frac{L (U_{90} - U_{10})}{3.625} \right]^2 \quad (2-18)$$

and data extracted from the arithmetic - probability plot, the dispersion coefficient (K), can be estimated.

In Eq. 2-18, U_{10} and U_{90} are values read from the plot at 10 and 90 per cent concentrations intersecting the straight line passed through the experimental data.

What has been discussed so far, has been related to the continuous miscible displacement of one fluid by another fluid. But in miscible displacements and in tracer studies, where cost is an important consideration, it is more common to inject small slugs containing the chemicals to be applied; for the chemicals in general are expensive.

When a slug is being displaced into a reservoir, the concentration can be expressed mathematically as the difference between two dispersed fronts which are commonly called the leading and trailing edges. For a linear case,

$$\frac{C}{C_0} = \frac{1}{2} \operatorname{erfc} \left(\frac{x - \bar{x}_1}{\sqrt{2} \sigma_1^2} \right) - \frac{1}{2} \operatorname{erfc} \left(\frac{x - \bar{x}_2}{\sqrt{2} \sigma_2^2} \right) \quad (2-19)$$

As always is the case, Eq. 2-19 is valid for small slugs compared to the size of the reservoir and when adsorption and reaction are not present as part of the process. Eq. 2-19 at the limit of a small slug, can be expressed by differentiation, as,

$$C = \frac{(\bar{x}_1 - \bar{x}_2) C_0}{\sqrt{2 \pi} \sigma^2} \exp \left[- \frac{(x - \bar{x})^2}{2 \sigma^2} \right] \quad (2-20)$$

Where,

$\bar{x}$ = Location of peak of concentration, $\bar{x} = 1/2 (x_1 + x_2)$

$\bar{x}_1$ = Location of the point of 50 per cent concentration on the leading front.

$\bar{x}_2$ = Location of the point of 50 per cent concentration on the trailing front.

$\bar{x}_1 - \bar{x}_2$ = Width of slug injected.

σ_1 = Length of the mixing zone of the leading front.

σ_2 = Length of the mixing zone of the trailing front.

σ = Length of the dispersion zone of the slug. For a small slug $\sigma = \sigma_1 = \sigma_2$

All these findings play an important role in the development of the present work as will be shown later on.

2.2 Single Well Tracer Tests, Literature Review.

The first attempt to measure S_{or} from a single well was proposed by Cooke (1971). He used two tracers with different oil/water distribution coefficients in a well with two perforated intervals. The difficulty with this method is evident from the fact that two tracers with different distribution coefficients will separate as they move further from the well, but this separation will be reversed when the well is open to production, so by the time the tracers are produced, no separation is seen in the tracer peaks.

Cooke (1971) also reported another method based on tracers with different dispersion coefficients rather than different velocities. This method was not sensitive enough to measure a correct residual oil saturation.

Deans (1971) patented a method based on the injection of a reactive chemical tracer, that once injected in the reservoir forms a second tracer in situ as a product of an irreversible chemical reaction. This method evolved into the single well tracer test method that is being studied herein.

Tomich, et al (1973) treated this method in depth, explaining the theoretical basis and the formulation of the test in a very comprehensive way. Limitations and advantages of this test and assumptions on the derivation of the equations are also included in the paper. This document is the most important contribution to the understanding of the single well tracer test and is cited frequently in the present work.

From experience gained through laboratory studies Tomich, et al outlined the following scheme for this test:

- 1).- The primary tracer solution, prepared with water from the formation and a tracer concentration between 0.5 and two percent by volume, is injected into the reservoir as a slug (Fig. 1a), along with another inert tracer (methanol or methyl alcohol) for material balance verification and dispersion estimation.
- 2).- The slug is displaced in the reservoir with brine (Fig. 1b).
- 3).- The well is shut in for at least twice the injection time to allow the reaction of the primary tracer with the reservoir fluids (water or oil, depending on the primary tracer), thus forming the secondary tracer (Fig. 1c). It should be borne in

mind that for an extremely large shut in time not enough primary tracer would be left to analyze the test, while too short a shut in time will not allow enough secondary tracer to be formed.

- 4).- The well is opened to production for the recovery of the injected fluids. When the well is produced one of the two tracers will flow to the wellbore at a higher velocity, developing the lag between the tracers. It has been mentioned in the literature, Tomich et al (1973), that a velocity ratio between tracers of 2:1 is an optimal velocity difference. A smaller ratio would result in a poor separation of the tracers and a larger difference would result in a smaller coverage around the wellbore.

During this production stage a number of samples are taken, sealing and preserving them at low temperature to avoid any loss by evaporation or further reaction.

The samples are analyzed by means of gas chromatography determining their primary and secondary tracer contents; with this information production profiles for the tracers are defined. See Sheely (1976) for some chromatographic details.

- 5).- The difference between the arrival times of the two tracers is dependent on the residual oil saturation.

The accuracy of the method was checked against laboratory tests (Tomich et al, 1973), using a limestone core which was waterflooded to residual oil saturation. By volumetric material balance the core

S_{or} was determined to be 30 PV percent. Performing a linear tracer test on the core, the calculated oil saturation was 29 ± 2 PV percent, which was an excellent agreement.

The method was proven to be effective in measuring the residual oil saturation under several conditions:

- 1).- Could be used in sandstone and limestone formations.
- 2).- Temperatures investigated 100 to 200 °F.
- 3).- Salinities investigated 400 to 120,000 ppm.
- 4).- Any of the following artificial lift methods could be effectively utilized: a) gas lift, b) rod pump and c) submersible electrical pump.

Another advantage of the method is that it covers a substantial volume of the reservoir compared with the other standard S_{or} determination methods.

For S_{or} determination purposes, Tomich, et al (1973) reported that stratification could be handled either as multiple layers or as a single layer, obtaining identical results, but in any case the calculated S_{or} must be considered to be more representative of the most permeable layer.

To detect heterogeneities different from stratification, Tomich, et al (1973) suggested that a buildup or fall-off test be run along with the tracer test in order to detect any gross heterogeneity that could alter the validity of the S_{or} determination.

The limitations of the method are:

- 1).- The equations describing the process as defined in this work are valid only when the oil or water are immobile.
- 2).- The method is not practical when there are large intervals open to the wellbore or when the storage of fluids in the wellbore is excessive. This implies that in some cases the well has to be reconditioned prior to running a tracer test.

Tomich, et al reported that when the concentration of the primary tracer was increased, in an attempt to make analysis easier, some non-linear effects resulted:

- a.- The distribution coefficients were found to be concentration dependent at high concentrations and in addition there was a dependence on temperature and brine salinity.
- b.- The higher tracer concentration caused the oil to swell.

They concluded that including the non-linear effects in the simulation improved the fit of the field data, but that the calculated saturations were not significantly affected by including these effects.

In some field applications, injection or production in neighboring wells or the presence of pressure gradients in the reservoir, caused the injection fluids to follow a preferential direction of flow and deformed the radial geometry of injection. This effect is called drift. The presence of drift complicates the simulation process and also complicates the analysis of the data.

It was recommended by these authors that all injection fluids should be tagged with a non-reactive tracer such as methanol to help estimate dispersion and for material balance verification.

The importance of drift, well injectivity, productivity, and shut in time in a given field could be estimated by running a mini test prior to the main test and the authors highly recommended this practice to design the main test.

They present details of four field tests in which the method was successfully applied.

The application of the single well tracer test to a field to determine its connate water saturation is described by Deans and

Shallenberger (1974). The formulation of the process presented in this paper is similar to the one presented by Tomich, et al (1973), with some modifications to account for the difference in the nature of the test.

The procedure is similar to the one used to determine residual oil saturation, with the difference that a slug of tracer (propyl formate) dissolved in reservoir oil was injected in the reservoir, followed by tracer free oil. After shut in, to allow propyl alcohol to form, the well was opened to production. The primary tracer arrived faster at the wellbore due to its low affinity for water, and the secondary tracer (propyl alcohol) lagged behind due to its high water solubility. The greater the lag, the larger the connate water saturation. They concluded that the method is useful for determining connate water saturation.

Sheely (1976) presented two field cases where the single well tracer test was applied. Both tests were limited in the amount of fluids that could be injected as a result of tight formations. In one of the tests, temperature (around 90⁰ F) was too low to use ethyl acetate, since at this temperature not enough secondary tracer (ethyl alcohol) could be formed. Instead n-propyl formate was used as the primary tracer since this tracer hydrolyzes at lower temperature. In the second test, ethyl acetate was used in spite of the low temperature (118⁰ F). Dilution of the produced fluids was present in both cases due to production from zones that did not take any tracer during injection.

Sheely presents in his paper some considerations in the design of a test:

- 1.- Injection of 50 barrels per foot of pay, was quoted as a good design size, but higher volumes are desirable, up to 90 barrels of injection per foot of pay.
- 2.- Temperature could be a limiting factor in the selection of the primary tracer.
- 3.- To run the test in a reasonable time, expected injectivity

and productivity of the well have to be taken into account.

4.- Shut in time should be approximately twice the injection time in order to form detectable amounts of secondary tracer.

5.- The total time to run the test should be such that enough primary tracer is left to analyze the data considering the rate of reaction involved in the test.

A detailed description of the field experience, the in situ sampling and analysis equipment to measure the production tracer concentrations and the partitioning coefficients, as well as a thorough discussion of the results are included in this paper. Sheely also emphasized the importance of using an inert tracer for material balance verification and the use of a minitest prior to the main test.

Braggs, Carlson and Atterbury (1976) discussed the application of the single well tracer test in eleven fields. The residual oil saturation for each of the eleven cases was estimated by feeding a two dimensional mathematical model with the production concentration profiles of both primary and secondary tracers from each test. Concentrations were determined by taking wellhead samples and determining their tracer concentrations with a chromatograph. Equilibrium distribution coefficients (k_1) defined as the ratio of the concentration of primary tracer in oil to the concentration of the primary tracer in water, were also determined in the laboratory.

Varying the following parameters: reservoir fluid velocity, v , dispersion coefficient, α , reaction rate constant, k_r , and residual oil saturation, S_{or} , a best fit was obtained by trial and error. The set of parameters defined in this way had to match three curves, the primary and secondary tracers' profiles and the inert tracer curve, used for material balance verification and estimation of dispersion coefficient.

Braggs, et al reported using gas lift as a production method, which volatilized ethyl acetate. They estimated primary tracer losses of about 30 per cent. Secondary tracer (ethanol) and inert tracer (methanol) were not affected by gas stripping.

A gas stripping effect was also noticed when producing by rod pump. This was explained to be due to the effect of gas dissolved in formation brine. Another well under rod pump production with formation brine that was free of dissolved gas did not show the gas stripping effects.

Braggs, et al strongly recommended that the single well tracer test should be not applied in fractured reservoirs, because fractures add uncertainty to the interpretation of the test.

The residual oil saturation calculated by material balance often disagrees with the one obtained with the single well tracer test. Using these differences they suggest a way to estimate waterflood conformance as follows:

If the single well test is in close agreement with the residual oil saturation (S_{or}) calculated by material balance, then conformance is good and infill drilling will not help to recover more oil; but depending on the magnitude of the S_{or} calculated, improved recovery methods could be applied.

If the S_{or} calculated with the single well test is considerably lower than the one calculated by material balance, then vertical conformance around the well could be good, but areal conformance is not. In this case infill drilling could help to recover additional oil.

Deans and Majoros (1979) presented what they called a direct method to analyze the field data obtained from a single well test. This method is mathematically different from the one presented by Tomich, et al (1973). They based their method on a chromatographic equation for equilibrium flow in the presence of residual oil (see Section 3 for

derivation). This equation is,

$$\bar{V}_i = \bar{V}_w \frac{1}{1 + \frac{k_i S_{or}}{1 - S_{or}}} \quad (2-21)$$

They assumed that after injection of the primary tracer and after shut in, both primary and secondary tracers are together at a given location from the wellbore and at that moment they are at time, t_0 . When the well is opened to production, concentration profiles are measured as they arrive to the well. Then, if Eq. 2-21 holds for both the primary (A) and the secondary (B) tracers, and if k_B is assumed to be zero,

$$\frac{\bar{V}_A}{\bar{V}_B} = 1 + \frac{k_A S_{or}}{1 - S_{or}} \quad (2-22)$$

Where the retention volume of either tracer, i , ($\bar{V}_i$) is defined as,

$$\bar{V}_i = \frac{\int_0^\infty C_i V dV}{\int_0^\infty C_i dV} \quad (2-23)$$

These volumes are calculated by direct integration of the measured production profiles. Deans and Majoros showed that from Eq. 2-22 it is possible to obtain a relationship between S_{or} and the retention volumes of the tracers. Under ideal test conditions, this is

$$S_{or} = \frac{\bar{V}_A - \bar{V}_B}{\bar{V}_A + (k_A - 1) \bar{V}_B} \quad (2-24)$$

The method assumes that all secondary tracer is formed during shut in time and no additional secondary is formed during production time. Empirical corrections are made to the basic equations presented to make them applicable to real cases. This formulation was applied to a field case, presented by Braggs, et al (1976), getting a very good agreement with the S_{or} reported by Braggs.

Equations to consider layering and semi-empirical correlations to consider moderately drifting systems are also included in the paper.

Sheely and Baldwin (1980) discussed the application of the single well tracer test to evaluate chemical enhanced oil recovery processes. The large depth of investigation from the wellbore of the single well tracer test and the controllability of this depth of investigation were considered properties that make the single well tracer test suitable for this kind of evaluation.

The procedure for this modification of the single well test as define by Sheely and Baldwin is:

- a. Run a standard single well test to determine the residual oil saturation of the waterflooded reservoir.
- b. Inject a small slug of the oil recovery chemical to create an oil bank of higher saturation around the well.
- c. Inject a mobility control bank. If required.
- d. Inject brine to displace the mobile banked oil away from the test area and, if one was used, to flush the mobility control slug

further into the reservoir.

- e. Run another single well tracer test, using several different esters, each with a different partitioning coefficient, so that residual oil could be determined at several distances from the wellbore.

The advantage of this kind of testing is that curves of oil saturation could be determined as a function of contacted pore volume and hence, the projected oil recovery, could be estimated. This information could be useful to scale up to a larger test and to select the most appropriate fluids for the improved recovery process.

Finally, a compilation of all the data on single well tracer tests using ethyl acetate as the primary tracer, that has been published in the literature to date, is presented in Table 2.1. This table does not include the data on 59 field applications of the test compiled by Majoros and Deans (1980). Their publication is mainly dedicated to the presentation of field data in tabular and graphical form; no analysis is made of any of the field cases, nor is information given about the source of the reported data.

Table 2.1.- Compilation of the Published Data on the Single Well Tracer Test where Ethyl Acetate was Used as the Primary Tracer.

Test No.	k md	ϕ %	h ft	T °F	μ cp	B _o RB/STB	Salinity ppm	V _{drift} ft/D	α ft	k _r 1/t	k _I	$\tilde{C}=aC/(1-bC)$ a	C _o % V
1	490		20	170	0.6	1.27	120,000					7.4	1.0
2	490		20	170	0.6	1.27	120,000					7.4	1.5
3			70	118				0.20	0.1			2.771	1.0
4													1.0
5	1000	25	20	140			63,000	1.00					2.0
6	800	34	20	164			100,000	0.10					1.0
7	500	32	20	170			75,000	0.10					1.0
8	50	10	17	210			4,000	2.00					1.0
9	200	24	19	157			20,000	0.30					0.9
10	1000	33	50	145			80,000	0.90					0.88
11	800	31	37	141			10,000	0.30					0.51
12	1000	25	37	172			100,000	0.00					0.9
13	1000	28	72	170			100,000	0.00					0.97
14		30	20										
15			13						0.14	0.006477	2.786		
16			13						0.7343	0.00974	2.786		

Q _{inj} BPD	Q _{prod} BPD	V _{slug} bbl	V _{push} bank b	V _{total} inj b.	t _{sh} D	S _{or} % PV	C MeOh % v	Reference
995	752	85	85	170	3.0	18.0 +/- 3.0	0.5	Tomich (1973)
999	857	550	1370	1920	12.0	19.0 +/- 2.0	0.5	"
40	148	97	372	400	11.0	30.0	0.5	Sheely (1976)
50-44	150	38		131	4.17			"
		300		800	9.0	10.0 +/- 4.0	0.1	Braggs (1976)
		1000		1980	12.0	12.5 +/- 1.5	0.5	"
		550		1920	12.0	19.0 +/- 1.0	0.5	"
		500		1664	3.0	15.0 +/- 5.0	0.48	"
		200		605	10.0	22.0 +/- 3.0	0.4	"
		314		1000	5.5	12.0 +/- 4.0	0.48	"
		330		1100	9.5	25.0 +/- 2.0	0.5	"
		400		1600	10.5	12.0 +/- 1.5	0.5	"
		900		3000	12.3	12.0 +/- 2.0	0.49	"
2000					9.0	13.0		Deans (1979)
14-24.88	23-32.3					31.4		Sheely (1980)
15-27.57	34-34.5					26.2		"

3. THEORETICAL BASIS

The single well chemical tracer tests are based on chromatographic separation principles (Tomich, et al (1973) and Deans (1974)). Since the tracer to be chosen must be soluble in oil and water, the typical tracer molecule will travel through the formation at a velocity affected by both water and oil velocities. The definitions of such velocities are obtained considering a local mass average velocity:

$$\vec{v} = \frac{\sum_{i=1}^n \rho_i \vec{v}_i}{\sum_{i=1}^n \rho_i} \quad (3-1)$$

or

$$\vec{v} \sum_{i=1}^n \rho_i = \sum_{i=1}^n \rho_i \vec{v}_i \quad (3-2)$$

Since the tracer is soluble in both water and oil, part of the tracer is going to be in the water and part in the oil, then from Eq. 3-2,

$$\vec{v} (\rho_i S_w + \bar{\rho}_i S_o) = \vec{v}_w \rho_i S_w + \vec{v}_o \bar{\rho}_i S_o \quad (3-3)$$

In this equation, for immobile residual oil saturation (S_{or}), $\vec{v}_o = 0$, for immobile connate water saturation (S_{wc}), $\vec{v}_w = 0$.

Working the case for residual oil saturation,

$$\vec{v} (\rho_i S_w + \bar{\rho}_i S_o) = \vec{v}_w \rho_i S_w \quad (3- 4)$$

Dividing by the tracer's molecular weight and from the molecular concentration definition, $C_i = \rho_i / M_i$, Eq. 3-4 becomes,

$$\vec{v} (C_i S_w + \tilde{C}_i S_o) = \vec{v}_w C_i S_w \quad (3- 5)$$

Rearranging Eq. 3-5, gives,

$$\vec{v} = \vec{v}_w \frac{1}{1 + \frac{\tilde{C}_i S_o}{C_i S_w}} \quad (3- 6)$$

Using the nomenclature common in the literature (Tomich, et al (1973) and Deans (1974)), for distribution of a tracer between oil and water, as follows,

$$k_i = \frac{\tilde{C}_i}{C_i} \quad (3- 7)$$

where,

k_i = Equilibrium distribution coefficient for tracer i

then from Eq. 3-6, the following equation results,

$$\vec{v}_i = \vec{v}_w \frac{1}{1 + \frac{k_i S_{or}}{1 - S_{or}}} \quad (3-8)$$

where,

$$\frac{1}{1 + \frac{k_i S_{or}}{1 - S_{or}}}, \text{ is the retardation factor for tracer i.}$$

The distribution coefficient, k_i , can be obtained using samples of reservoir fluids at reservoir conditions. In general the use of tracers for saturation determination consists of the evaluation of the retardation factors. If these retardation factors can be measured in the field; then from, Eq. 3-8, the saturation is defined as follows

$$S_{or} = \frac{1}{1 + \frac{k_i v_i}{v_w - v_i}} \quad (3-9)$$

but the measurement of these factors requires knowledge of the tracer velocity relative to the injected fluid velocity. This could be done by measuring the time needed for the tracer to pass between two points of

known separation (direct method); but in the case of the single well test, only one observation point is available. Deans and Majoros (1979) proposed a direct method, see the literature review, Section 2.2, for details about this method. However the method can only be used in certain idealized conditions. Thus an indirect method (single observation point) is normally used and will be used in this work.

4. MODELING THE SINGLE WELL TRACER TEST

Due to the fact that reaction and dispersion occur throughout the test, simple calculations would not correctly represent the process. Thus more rigorous mathematical modeling of the process is required.

In order to derive the single well tracer method formulation, the following assumptions are made:

- 1).- The fluids are incompressible.
- 2).- The oil phase is immobile.
- 3).- Chemical reaction occurs in the brine and in the oil phases.
- 4).- Equilibrium mass transfer is achieved.
- 5).- The tracer mass flux is small compared with the mass flow rate of the water.
- 6).- The formation is homogeneous and isotropic.
- 7).- Flow is radial.

4.1 Formulation of the problem.

The equation that describes the process is the following:

$$\frac{1}{r} \frac{\partial}{\partial r} \left[r S_w K \frac{\partial C_1}{\partial r} \right] - \frac{1}{r} \frac{\partial}{\partial r} (r S_w v C_1) - k_r (C_1 S_w + \tilde{C}_1 S_o) =$$

$$\frac{\partial}{\partial t} (C_1 S_w + \tilde{C}_1 S_w) \quad (4-1)$$

where,

K = Dispersion coefficient, ft/D

k_r = Constant of reaction, 1/D

C_1 = Concentration of component i in the water phase

$\tilde{C}_1$ = Concentration of component i in the oil phase

Eq. 4-1 is the basic model equation and can be applied to both primary and secondary tracers (See appendix A for derivation). Along with this equation, the following additional equations are required:

a).- The water velocity in radial flow is evaluated at any time by material balance,

$$v_{wr} = \frac{5.615 Q}{2 \pi r h \phi S_w} \quad (4-2)$$

where,

Q = Flow rate, BPD

b).- The dispersion coefficient is assumed to be proportional to the local water velocity.

$$K = \alpha \left| v_{wr} \right| = \frac{5.615 \left| Q \right|}{2 \pi r h \phi S_w} \quad (4-3)$$

where,

α = Dispersion constant, ft

c).- The equation relating the equilibrium tracer concentration in the oil and water phases $\tilde{C}_i = f(C_i)$ is evaluated from data obtained in the laboratory, using formation water and oil samples to determine the equilibrium distribution coefficients for a given component at reservoir conditions. An example of a resulting curve is the one presented in Fig. 4.1

The shape of the curve defined by the experimental data points is most accurately given by a relation of the form,

$$\tilde{C}_i = \frac{aC_i}{1 - bC_i} \quad (4-4)$$

This equation, when included in the basic continuity equation, Eq. 4-1, produces a non-linear differential equation.

Fig. 4.1 is representative of the type of relation usually seen between the concentration of the tracer in oil ($\tilde{C}_i$) and the concentration of the tracer in water (C_i). However a straight line

Fig. 4.1 - Equilibrium Data from Partition Coefficient Determination.
(After Sheely, 1976).

passing through the origin gives a good approximation to the trend of the experimental data, especially at the lower concentration usually used in such tests. With this assumption, the non-linearity in Eq. 4-1 is removed. In this work, it is assumed that the relation between the concentration of the tracer in oil and the concentration of the tracer in water is linear. Thus Eq. 4-4 becomes,

$$\tilde{C}_i = a C_i \quad (4-5)$$

5. SOLVING THE SINGLE WELL TRACER TEST FORMULATION

This chapter will be divided in two sections. The first treats the attempts to solve the single well tracer test formulation for a radial system. The second gives details about the solutions developed for the single well tracer test formulation for a linear system

5.1 Attempted Methods of Solution

Several attempts were made to solve Eq. 4-1 analytically, but all of them failed. The prime reason for including this section is merely for information to those who may be interested in solving this type of problem. The methods attempted, were:

a).- Laplace transformation. Once the differential equation was linearized, an attempt was made to solve Eq. 4-1 using Laplace transformation. The transformed equation is of the following form,

$$\frac{d^2 \bar{C}_i}{dr^2} + A \frac{d\bar{C}_i}{dr} + (B - Es) r_i \bar{C}_i = 0 \quad (5-1)$$

where,

A, B, E are constants

s = Laplace space constant

$\bar{C}_i$ = Transformed concentration in Laplace space

Eq. 5-1 is a linear, homogeneous ordinary differential equation with variable coefficients. Some of the attempted methods to solve this equation were:

Bessel functions. Suggested by the form of Eq. 5-1, solutions in terms of Bessel Functions were tried, but the lack of the factor $-r-$ in the second order term and the coefficient $-A-$ in the first order term, did not allow a solution to be found in terms of these functions.

Frobenius method. This method is suitable for solving ordinary differential equations with variable coefficients. It was not possible to obtain a generalized equation for the coefficients that could facilitate the inversion from Laplace space.

Since there was no exact or approximate solution to this differential equation, then the Laplace transformation method fails.

b).- Sturm Liouville transformation. In this case the form of the coefficient of the second and first order partial differential terms in $-r-$ in Eq. 4-1, did not fit in the type of equation that can be solved using this theorem.

c).- Change of variable. Several attempts to solve Eq. 4-1 by means of a change of variable were attempted without success.

After failing to solve Eq. 4-1 analytically, the equation was solved numerically. In the numerical solution a logarithmically distributed grid and two finite differences schemes were used: 1).- an implicit central finite difference and 2).-Crank-Nicholson. The solutions of the numerical model were compared with Raimondi's (1959) approximate radial analytic solution for the case where no reaction takes place.

Both numerical solutions were considered unreliable due to numerical dispersion in the results. They were both impractical, since considerable trial and error was involved in the matching of the numerical to the analytic solution. The fitting parameters are grid spacing (Δr), time step sizes (Δt), constant of dispersion (α), constant of reaction (k), and residual oil saturation (S_{or}).

Then a new approach to the solution of the problem was tried. This is presented next.

5.2 Linear Case

The single well tracer test can be divided into three stages: a) the injection period, b) the shut in time and c) the production period. In each period the simulation of the process was carried out in a different way. Next is presented a description of the simulation of each stage of the test.

5.2.1 Injection Period Calculations.

The two basic equations to describe the process are developed during this period, as presented in Section four. One of the equations describes the behavior of the primary tracer and another the behavior of the secondary tracer.

5.2.1.1 Solution for the Primary Tracer.

The approach is based in the solution of an equation of the same general form as Eq. 4-1, except it is for a linear flow system. This equation is,

$$\begin{aligned}
& \frac{\partial}{\partial x} (S_w v_x C_i) - \frac{\partial}{\partial x} (K S_w \frac{\partial C_i}{\partial x}) + k_r (C_i S_w + \tilde{C}_i S_o) = \\
& - \frac{\partial}{\partial t} (C_i S_w + \tilde{C}_i S_o) \quad (5- 2)
\end{aligned}$$

with the initial and boundary conditions,

$$C_i (x, 0) = 0 \quad (5- 3)$$

$$C_i (0, t) = C_o \quad (5- 4)$$

$$C_i (x, t) \rightarrow 0 \quad \text{as } x \rightarrow \infty \quad (5- 5)$$

The solution to Eq. 5-2, considering the initial and boundary conditions (See Appendix B for derivation), is given by :

$$\begin{aligned}
\frac{C(x,t)}{C_0} = & \frac{1}{2} e^{\frac{x v_x}{2K}} \left\{ e^{-\frac{x}{2K} \sqrt{v_x^2 + \frac{4 k_r K [S_w + a(1 - S_w)]}{S_w}}} \right. \\
& \cdot \operatorname{erfc} \left[\frac{x - t \sqrt{\frac{v_x^2 S_w^2}{[S_w + a(1 - S_w)]^2} + \frac{4 k_r K S_w}{S_w + a(1 - S_w)}}}{2 \sqrt{\frac{K t S_w}{S_w + a(1 - S_w)}}} \right] \\
& + e^{\frac{x}{2K} \sqrt{v_x^2 + \frac{4 k_r K [S_w + a(1 - S_w)]}{S_w}}} \\
& \cdot \operatorname{erfc} \left[\frac{x + t \sqrt{\frac{v_x^2 S_w^2}{[S_w + a(1 - S_w)]^2} + \frac{4 k_r K S_w}{S_w + a(1 - S_w)}}}{2 \sqrt{\frac{K t S_w}{S_w + a(1 - S_w)}}} \right] \Bigg\}
\end{aligned}$$

(5-6)

This solution is similar to the one presented by Aronofsky and Heller (1957), with the difference that Eq. 5-6 includes adsorption and reaction. The second term in the RHS is only relevant at short distance from the inlet at small values of time, which agrees with the findings of Aronofsky and Heller and Ogata and Banks (1961). Thus for practical purposes Eq. 5-6 can be written,

$$\frac{C(x,t)}{C_0} = \frac{1}{2} e^{-\frac{x}{2K} \left[v_x - \sqrt{v_x^2 + \frac{4 k_r K [S_w + a(1 - S_w)]}{S_w}} \right]} \cdot \operatorname{erfc} \left[\frac{x - t \sqrt{\frac{v_x^2 S_w^2}{[S_w + a(1 - S_w)]^2} + \frac{4 k_r K S_w}{S_w + a(1 - S_w)}}}{2 \sqrt{\frac{K t S_w}{S_w + a(1 - S_w)}}} \right] \quad (5-7)$$

Even though Eq. 5-6 is the rigorous exact solution to the PDE that represents the miscible displacement of fluid A by fluid B, when the process is affected by reaction and adsorption of fluid B; it can be shown that Eq. 5-7 adequately represents the solution to Eq. 5-2 for the reservoir flow problem of interest here,

Initially Eq. 5-2 was solved having in mind that the solution procedure might lead to a solution for the radial case. When analyzing the solution given by Eq. 5-7, it was observed that although the reaction term was included in the argument of the complementary error function the effect of that term was small at the conditions typical of field operations. This suggested that Eq. 5-7 could be approximated by using the result of the combination of two independent solutions, one for reaction only and one for mixing only. The two solutions tried were:

- a). The solution to a reactive-dispersive system. The PDE is obtained by neglecting the dispersion term in Eq. 5-2. The solution to the resulting PDE was obtained by the method of characteristics. This method gives two different solutions (see Appendix C for derivation), these solutions are,

$$\frac{C(x,t)}{C_0} = e^{-\frac{k_r x}{v_x} \left[1 + \frac{a(1 - S_w)}{S_w} \right]} \quad (5-8)$$

(space solution)

$$\frac{C(x,t)}{C_0} = e^{-k_r t} \quad (\text{time solution}) \quad (5-9)$$

b). The solution to a dispersive system with adsorption. The PDE for this kind of system is obtained by neglecting the reaction term in Eq. 5-2. The solution to this PDE is the standard complementary error function solution,

$$\frac{C(x,t)}{C_0} = \frac{1}{2} \operatorname{erfc} \left[\frac{x - \frac{v_x t S_w}{S_w + a(1 - S_w)}}{2 \sqrt{\frac{K t S_w}{S_w + a(1 - S_w)}}} \right] \quad (5-10)$$

Multiplying Eq. 5-8 by Eq. 5-10 results in the following equation,

$$C(x,t) = \frac{1}{2} C_0 e^{-\frac{k_r x}{v_x} \left[1 + \frac{a(1 - S_w)}{S_w} \right]} \operatorname{erfc} \left[\frac{x - \frac{v_x t S_w}{S_w + a(1 - S_w)}}{2 \sqrt{\frac{K t S_w}{S_w + a(1 - S_w)}}} \right] \quad (5-11)$$

The error involved in using Eq. 5-11 (approximate solution) instead of Eq. 5-7 (exact solution) is negligible as can be observed in Table 5.1 or in Fig. 5.1 .

**Table 5.1.- Comparison Between Approximate and Exact Solutions
for the Primary Tracer**

	Distance ft	Conc. reactive convective,% V	Conc. dispersion with adsorp.,% V	Conc. approx. solution, % V	Conc. exact sol'n., % V
1	2.00	0.979370	1.0	0.97937	0.979385
2	4.00	0.959165	1.0	0.959165	0.959195
3	6.00	0.939378	1.0	0.939378	0.939421
4	8.00	0.919999	1.0	0.919999	0.920054
5	10.00	0.901019	1.0	0.901019	0.901087
6	12.00	0.882431	1.0	0.882431	0.882511
7	14.00	0.864226	0.999998	0.864225	0.864317
8	16.00	0.846397	0.999752	0.846188	0.846304
9	18.00	0.828936	0.990536	0.821091	0.821581
10	20.00	0.811835	0.887003	0.7201	0.723031
11	22.00	0.795087	0.529701	0.421158	0.427024
12	24.00	0.778684	0.144185	0.112274	0.115568
13	26.00	0.76262	0.013977	0.010659	0.111697E-01
14	28.00	0.746887	0.427853E-03	0.319558E-03	0.341347E-03
15	30.00	0.731479	0.390755E-05	0.285829E-05	0.311427E-05
16	32.00	0.716388	0.103446E-07	0.741076E-08	0.823876E-08
17	34.00	0.701609	0.781082E-11	0.548014E-11	0.621765E-11
18	36.00	0.687135	0.166550E-14	0.114443E-14	0.132530E-14
19	38.00	0.672959	0.996430E-19	0.670557E-19	0.792672E-19
20	40.00	0.659076	0.	0.	0.

Area under approximate solution curve = 17.7754

Area under exact solution curve = 17.8026

Fig. 5.1 - Comparison between the exact solution given by eq. 5-7 and the approximate solution given by eq. 5-11.

Equation 5-11 has the advantage that it is simpler to use. The reason that this procedure works is that the term v_x^2 in Eq. 5-7 is large compared to the term, $4 k_r K [S_w + a(1 - S_w)]/S_w$. Thus the square root terms in Eq. 5-7 simplify to the result seen in Eq. 5-11.

Eq. 5-11 has important characteristics that make it especially useful for solving the reactive tracer problem in radial flow. The problem of defining the concentration profile can be separated into two problems 1) reaction and 2) dispersion. The reaction portion of the solution, Eq. 5-8 or 5-9, is completely independent of geometry; it depends only on the time necessary to flow to a given location. The mixing portion of the solution, Eq. 5-10, is the classic dispersion equation for linear flow, as discussed in Section 2, however, this same equation form can also be used for radial systems. To do this, Eqs. 2-9 through 2-14 can be used. Thus the splitting procedure used to generate Eq. 5-11 allows calculation of an approximate solution for a radial case, which will be discussed in Section 6.

Eq. 5-11 is the equation to use to represent the miscible displacements taking place both at the front and at the tailing edge of the slug containing the primary tracer. Thus the distribution of primary tracer in the reservoir is given by the difference between the two solutions.

$$C(x,t) = \frac{1}{2} C_o e^{-\frac{k_r x}{v_x} \left[1 + \frac{a(1 - S_w)}{S_w} \right]} \cdot \left\{ \operatorname{erfc} \left[\frac{x - \frac{v_x t_1 S_w}{S_w + a(1 - S_w)}}{2 \sqrt{\frac{K t_1 S_w}{S_w + a(1 - S_w)}}} \right] - \operatorname{erfc} \left[\frac{x - \frac{v_x t_2 S_w}{S_w + a(1 - S_w)}}{2 \sqrt{\frac{K t_2 S_w}{S_w + a(1 - S_w)}}} \right] \right\} \quad (5-12)$$

5.2.1.2 Solution for the Secondary Tracer.

The partial differential equation representing the secondary tracer is obtained in a similar way as for the primary tracer (see Appendix A for derivation of the primary tracer equation). The resulting equation is,

$$\frac{\partial}{\partial t} (S_w C') + S_w v_x \frac{\partial C'}{\partial x} + k_r (C_i S_w + \tilde{C}_i S_o) = \frac{\partial}{\partial x} (S_w K \frac{\partial C'}{\partial x}) \quad (5-13)$$

Where,

C = Primary tracer concentration

C' = Secondary tracer concentration

For solution of the equation, the following initial and boundary conditions were used,

$$C'(x, 0) = 0 \quad (5-14)$$

$$C'(0, t) = 0 \quad (5-15)$$

$$C'(x, t) \rightarrow 0 \quad (5-16)$$

$$x \rightarrow \infty$$

Eq. 5-13 has the following solution in Laplace space, (see Appendix D for derivation):

$$\frac{\bar{C}'(x,s)}{C_o} = k_r e^{\frac{x v_x}{2K}} \frac{e^{-\frac{x}{2K} \sqrt{v_x^2 + 4Ks}} - e^{-\frac{x}{2K} \sqrt{v_x^2 + 4K(k_r + s)}}}{s \left(1 + \frac{S_w}{S_w + a(1-S_w)} \right) + k_r} \left(1 + \frac{a(1-S_w)}{S_w} \right)$$

(5-17)

It is possible to invert Eq. 5-17 to real space, but the inverted solution is not in closed form. It is in terms of eight integrals, which makes that solution difficult to handle. It was decided to use the Stehfest (1970) algorithm for the inversion of Laplace transforms to invert Eq. 5-17. The algorithm was tried in single precision using eight terms in the numerical algorithm of inversion, and also in double precision using 16 terms. Considerable deviations and oscillations were observed in the single precision case and excellent results were obtained with double precision, as was confirmed by material balance check. Fig. 5.2 and Table 5.2 present the results from this checking procedure.

Integrating the area under the primary and secondary tracer concentration profiles and combining them, the resulting area should be equal to the area ABCDA on Fig. 5.2. Area ABCDA corresponds to the area that would be contacted by the primary tracer if the displacement were piston like and no reaction occurred.

Eq. 5-17 represents the secondary tracer resulting from the reaction of the primary tracer with the reservoir water during a continuous miscible displacement. For a slug of primary tracer generating secondary tracer, it is necessary to superpose Eq. 5-14 in time as was done with the primary tracer. The result, in Laplace space is,

Fig. 5.2 - Check of Material Balance and Stehfest Algorithm of Inversion from Laplace Space for the Secondary Tracer at End of Injection.

TABLE 5.2 - Check of Material Balance and the Stehfest Algorithm of Inversion from Laplace Space for the Secondary Tracer at the End of Injection.

	x feet	Primary tracer conc., % Vol.	Secondary tracer conc., % Volume
1	2.0	0.999359	0.000641
2	4.0	0.998719	0.001282
3	6.0	0.998078	0.001921
4	8.0	0.997434	0.002557
5	10.0	0.996709	0.003197
6	12.0	0.99502	0.00385
7	14.0	0.986337	0.004501
8	16.0	0.946971	0.005101
9	18.0	0.829061	0.005575
10	20.0	0.60487	0.005858
11	22.0	0.335836	0.005913
12	24.0	0.132309	0.005743
13	26.0	0.035303	0.005387
14	28.0	0.006195	0.0049
15	30.0	0.000702	0.00434
16	32.0	0.000051	0.003757
17	34.0	0.000002	0.003187
18	36.0		0.002653
19	38.0		0.002165
20	40.0		0.001728
21	42.0		0.001342
22	44.0		0.001006
23	46.0		0.000717
24	48.0		0.000475
25	50.0		0.000276

**Material balance distance,
assuming piston like displacement = 20.7963 ft.**

**Material balance by integration
and addition of the areas under
the primary and secondary tracer
profiles = 20.8818 ft.**

$$\frac{\bar{C}'(x,s)}{C_o} = k_r e^{\frac{x v_x}{2K}} \frac{e^{-\frac{x}{2K} \sqrt{v_x^2 + 4Ks_1}} - e^{-\frac{x}{2K} \sqrt{v_x^2 + 4K(k_r + s_1)}}}{s_1 s_1 \left(1 + \frac{S_w}{S_w + a(1-S_w)} + k_r \right) + \frac{a(1-S_w)}{S_w}} - \frac{e^{-\frac{x}{2K} \sqrt{v_x^2 + 4Ks_2}} - e^{-\frac{x}{2K} \sqrt{v_x^2 + 4K(k_r + s_2)}}}{s_2 s_2 \left(1 + \frac{S_w}{S_w + a(1-S_w)} + k_r \right) + \frac{a(1-S_w)}{S_w}} \quad (5-18)$$

5.2.2 Shut In Period Calculations.

Eqs. 5-12 and 5-18 are the equations to solve to simulate the single well tracer test. The application of these equations during injection is straight forward and they would be applicable up to the end of the process if shut in time were not involved in the test. But since the rate of reaction of the primary tracer is very slow (0.005 to 0.01 D^{-1}), the shut in time is a must in order to generate a detectable amount of secondary tracer. As a rule of thumb, shut in time should be at least twice the total injection time or it should be a reasonable time to allow enough secondary tracer to be formed but still leave enough primary tracer for the analysis of the test.

The net effect at the end of the shut in time is a lower concentration of primary tracer and a redistributed higher concentration of secondary tracer as shown in Fig. 5.3 . The reasons for these various peaks at the end of injection and after shut in is discussed in the following paragraphs.

It is necessary to evaluate the amount of primary tracer that is

Fig. 5.3 - Schematic Representation of the Change in Concentration of the Primary and Secondary Tracers, from the End of Injection to the End of Shut In, as a Result of Chemical Reaction of the Primary Tracer.

transformed to secondary tracer as a result of the chemical reaction of the tracer during the shut in period. This calculation is accomplished using the solution in time obtained when solving the convective-reactive system using the method of characteristics, Eq. 5-9.

Eq. 5-9 is superposed on Eq. 5-12 in time. Since Eq. 5-9 is a solution depending only on shut in time and is independent of distance, during shut in it becomes a constant factor affecting all the concentrations obtained with Eq. 5-12. Thus it does not affect the location of the primary tracer slug, it merely causes lower concentrations at all points as shown in Fig. 5.3 . Superposing Eqs. 5-9 and 5-12 , results in,

$$C_{sh}(x, t_{sh}) = C_I(x, t_I) e^{-k_r t_{sh}} \quad (5-19)$$

where $C_I(x, t_I)$ is the primary tracer concentration calculated at the end of injection time (t_I) and $C_{sh}(x, t_{sh})$ is the primary tracer at the end of shut in time (t_{sh}).

During shut in the source of convection is annulled, thus the tracer profiles at the end of injection will remain static. The peak of concentration for the primary tracer remains at the same location. But the peak of concentration of the secondary tracer is relocated due to the formation of additional secondary tracer during shut in. The additional secondary tracer is centered at the same location as the primary tracer. When this additional tracer is combined with the secondary tracer that was formed during injection, the secondary is redistributed with the peak of concentration lying at a location intermediate between the primary and secondary tracer peaks obtained at the end of injection, as shown on Fig. 5.3.

The amount of secondary tracer formed during shut in time, is:

$$\begin{aligned}
\Delta C'_{sh}(x, t_{sh}) &= C_I(x, t_I) - C_{sh}(x, t_{sh}) \\
&= C_I(x, t_I) \left[1 - e^{-k_r t_{sh}} \right] \quad (5-20)
\end{aligned}$$

The total secondary tracer at the end of the shut in time is:

$$C'_{sh}(x, t_{sh}) = C'_I(x, t_I) + \Delta C'_{sh}(x, t_{sh}) \quad (5-21)$$

Where,

$C_I(x, t_I)$ = Primary tracer concentration profile at the end of injection.

$C'_I(x, t_I)$ = Secondary tracer concentration profile at the end of injection

$C_{sh}(x, t_{sh})$ = Primary tracer concentration profile at the end of shut in.

$C'_{sh}(x, t_{sh})$ = Secondary tracer concentration profile at the end of shut in.

$\Delta C'_{sh}(x, t_{sh})$ = Incremental secondary tracer formed during shut in.

On Fig. 5.3 the solid lines represent the primary and secondary tracer concentration profiles at the end of shut-in time. From the end of shut in onwards the concentration distribution of both tracers can no longer be calculated from Eq. 5-12 (primary) or Eq. 5-18 (secondary) since the system has been disturbed and the concentration profiles have

been redistributed. Thus when these tracers are moved during production, it is necessary to make some adjustments to continue the calculations and return the tracers to the well.

5.2.3 Production Period Calculations.

The return of the tracers to the well is calculated by assuming that there is injection of fluids after shut in rather than production, up to any given time interval. During this time increment, the fluids continue adsorbing, dispersing and reacting. The distance traveled by the tracers during this time is then back calculated in the opposite direction (toward the well), using as a pivot for each tracer, the location of each respective peak of concentration that exists at the end of the shut in time. The details of these calculation concepts are discussed next.

5.2.3.1 Primary Tracer, Production Calculations.

To continue using Eq. 5-12 to calculate the concentration distribution of primary tracer after shut in, it must be remembered that the concentration at the end of shut in is lower than it was at the end of the injection period. A simple way to account for this lower concentration is to treat the system as if there had been no shut in period and as if the initial injected concentration was lower than the actual concentration, (Fig. 5.4). This will be called the "fictitious initial concentration", C_{of} . Eq. 5-12 can then be used to calculate the concentration during production by using only the injection and production times and by using the fictitious initial concentration, C_{of} .

The return of the primary tracer to the well is graphically described on Fig. 5.5 . Once the fictitious concentration is calculated and the location of the peak is recorded (point A on Fig. 5.5) the injection of tracer free water is assumed to continue, and calculations

Fig. 5.4 - Graphical Representation of the Calculation of the Fictitious Initial Concentration (C_{0f}).

Fig. 5.5 - Schematic Representation of the Primary Tracer Production Period.

are performed at discrete time intervals. At constant rate in a homogeneous linear system, the distance traveled by the slug of primary tracer after shut in is the same regardless of whether shut in is followed by injection or by production. Thus, if injection continues during a time interval, the peak of concentration travels from point A to point B. An equal opposite distance $\overline{AC}$ will actually be covered by the peak if the well is open to production after shut in. Thus the production period can be treated as a pseudo injection process after shut in.

The calculation of the return of the primary tracer is made at discrete intervals of time. At every time increment, a production concentration value is obtained at the well, point D on Fig 5.5 . The calculations are stopped when tracer production reaches a concentration equal to 0.001 of C_o .

5.2.3.2 Secondary Tracer, Production Calculations.

The return of the secondary tracer to the well is considerably more complicated since the secondary tracer peak was relocated during the shut in period (Fig. 5-3). This relocation invalidates the use of Eq. 5-18 to calculate $C'(x,t)$. The profile of the additional secondary tracer formed during shut in (Fig. 5.3) is calculated using Eq. 5-20, and the total secondary tracer is obtained from Eq. 5-21. However Eq. 5-21 is not adequate to use during the production stage.

To properly define the return of the secondary tracer to the well, it is necessary to break the movement of the old secondary tracer and the additional generation of secondary tracer into two parts. One part considers the movement and dispersion, after shut in, of the secondary tracer generated up to the end of shut in time, as indicated in Fig. 5.6. The other part deals with the additional secondary tracer formed during production, as will be indicated later on in Figs. 5.8 - 5.11 .

On Fig. 5.6, the dashed line with the peak at A represents the total

Fig. 5.6 - Schematic Representation of the Return to the Well of the Secondary Tracer Formed During Injection and Shut In.

amount of secondary tracer formed during the injection and shut in periods. This is the same as the solid line for secondary tracer, shown in Fig. 5.3. Assuming that injection continues after shut in and no further secondary tracer is added by chemical reaction (reaction will be considered separately), the secondary tracer slug will continue moving and dispersing. At the end of a given time increment, the secondary tracer peak will have moved and dispersed to position B. Since there is actually production rather than injection the position can be back calculated toward the well ($\overline{AC}$ in Fig. 5-6) by an amount equal to the calculated distance traveled $\overline{AB}$, taking point A as a pivot. Note that the pivot point for this secondary tracer is different than the pivot that was used for the primary tracer.

To move and further disperse this slug of secondary tracer from its position at the end of shut in to a position where the peaks is at B, it is assumed that the secondary tracer slug is dispersed as represented by an equation of the following form,

$$C'(x,t) = \frac{(x_1 - x_2) C_o}{2 \sqrt{\pi \sigma^2}} \exp - \frac{(x - \overline{x})^2}{2 \sigma^2} \quad (5-22)$$

Equation 5-22 is the differential representation of a slug that is small compared to the size of the reservoir. (See Literature Review, Section 2.1.2).

Rearranging Eq. 5-22, it can be written as

$$\ln C'(x,t) = AA + BB x + CC x^2 \quad (5-23)$$

Where,

$$AA = \ln \frac{(x_1 - x_2) C_o}{\sqrt{2 \pi \sigma^2}} - \frac{\overline{x}^2}{2 \sigma^2} \quad (5-24)$$

$$BB = \frac{\bar{x}}{\sigma^2} \quad (5-25)$$

$$CC = - \frac{1}{2\sigma^2} \quad (5-26)$$

The coefficients of Eq. 5-23 are obtained by fitting Eq. 5-23 to the secondary tracer data calculated at the end of shut in, using the weighted least squares method.

Rearranging Eq. 5-23,

$$C'(x,t) = \exp(AA + BB x + CC x^2) \quad (5-27)$$

Eq. 5-27 was checked against the input data in Fig. 5.7. The equation fits the general form of the shape of the concentration data; however, it does not accurately match the concentrations at the end of the curve. The important point, however, is that the equation fit closely matches the location of the peak of the curve, the concentration at the peak, and the total volume under the curve. Thus it can be used to predict the future movement of this secondary tracer. It is the location of the peak which is used later as the major correlating factor for defining the saturation.

Eq. 5-27 reproduces the secondary tracer concentration profile obtained at the end of shut in. The length of the mixing zone (σ) is obtained from coefficient CC, the location of the 50 per cent concentration ($\bar{x}$) is estimated from coefficient BB.

Eq. 5-27 reproduces the static position of the secondary tracer at the end of shut in, but in order to move the secondary tracer from its location after shut in, it is necessary to calculate the length of the

Fig. 5.7 - Check of the Secondary Tracer Fit at the End of Injection, Using an Equation of the Form
 $\ln C = a + b x + c x^2$

mixing zone (σ_{sh}) and the location of the peak ($\bar{x}$) at the end of shut in, and recalculate them as they change position due to production (pseudo injection).

According to the definition given in Eq. 2-13, for a linear system $\sigma_2^2 = \sigma_1^2 + 2 K t$. If t is the total injection time and Δt the additional time of injection after shut in (production), then,

$$\sigma_{prod}^2 = \sigma_1^2 + 2 K \Delta t \quad (5-28)$$

where, σ_1^2 is estimated from the Eq. 5-26 coefficient, CC, from the secondary tracer fit after shut in.

To modify $\bar{x}$, one must consider the distance that the secondary tracer has moved from the end of shut in to the new position after producing for a time equal to Δt . This is accomplished by assuming that the secondary tracer moves at the same velocity as the water. This is a valid assumption since the secondary tracer is soluble only in water. Thus

$$\bar{x}_{prod} = \bar{x}_{sh} + v_x \Delta t \quad (5.29)$$

where, $\bar{x}_{sh}$ is estimated from Eq. 5-25.

These two modified parameters are used in Eq. 5-22 to calculate the new distribution of the "shut in" secondary tracer after any increment of production time. The net effect of modifying the parameters is that the secondary tracer will continue moving and dispersing during production. The same process of back calculation that was used for the primary tracer is used for back calculating the secondary tracer and pivoting on the secondary tracer is based on the location of its concentration peak at the end of shut in (location A in Fig. 5.6).

during production time is considered to be tracer independently formed during this stage. It is handled independently of the "shut in" secondary tracer. The mechanics of its formation and production is explained next.

First it is necessary to emphasize that the "shut in" secondary tracer is handled independently (not neglected). The formation of additional secondary tracer during production will start as if no secondary tracer had been formed in the system prior to that time. Later on, the "injection-shut in" and the "production" secondary tracer profiles will be superposed to obtain the net secondary tracer formed up to a given production time.

The calculation of a fictitious initial concentration, C_{of} , allows for the calculation of the "shut in" primary tracer concentration profile using Eq. 5-12 as if no shut in time were involved in the process. This is the solid line in Fig. 5.8 and it is the same as the solid line in Fig. 5.4, discussed earlier. This procedure of recalculation with no shut in time also allows for the use of Eq. 5-18 to calculate what will be called the "false secondary tracer" (dashed line profile in Fig. 5.8), and which later will be used to estimate the actual secondary tracer formed during production. This "false secondary tracer" is secondary tracer that does not exist at the end of shut in. Remember that the actual secondary tracer at the end of shut in has already been accounted for and calculated as discussed in the paragraph above. There is, however, additional secondary tracer. To accomplish this, it is necessary to calculate the tracer profile predicted by Eq. 5-18 and then subtract the false secondary tracer from it. This leaves only the additional secondary tracer that is formed during production. This false secondary tracer is fitted with an equation of the form given by Eq. 5-27. In this way, the false secondary tracer can be moved and dispersed without modifying its volume.

When production starts (pseudo injection), the total time of

Fig. 5.8 - Primary and Secondary Tracer Profiles Obtained if Process is Initiated Injecting Primary Tracer at a Concentration C_{of} and no Shut In Time is Involved.

injection is increased by Δt and a new position for the secondary tracer is calculated using Eq. 5-18, upper dashed line on Fig. 5.9. The false secondary tracer is also moved a distance proportional to Δt in the same way as the slug of "shut in" secondary tracer is moved, lower dashed profiles on Fig. 5.9. The difference between these two dashed profiles is the additional secondary tracer formed during a Δt of production.

To back calculate this additional secondary tracer towards the well, it is necessary to correct the position of the concentration profile. At zero production time, no additional secondary tracer is present in the system. Then immediately after opening the well to production the source of formation of the additional secondary tracer is from the primary tracer concentration profile. Thus to calculate the location of the additional secondary tracer, it must be back calculated using point A of Fig. 5.8 as a pivot point. The calculated additional secondary tracer will be in a location as indicated by the crosshatched area of Fig. 5.9 and the actual location will be as shown in Fig. 5.10.

At a given intermediate time during production, the location of the concentration profiles of (1) the primary tracer, (2) the secondary tracer formed up to and including shut in and (3) the additional secondary tracer formed during production, are shown on Fig. 5.11 .

The slugs of shut in secondary tracer and production secondary tracer are superposed in distance, giving the total amount of secondary tracer formed up to a given production time.

Production time is divided into small time increments. At each time increment, both the primary and secondary tracer profiles are evaluated to locate the advance of both tracers towards the well. Calculations at the well ($x = 0$) are made to obtain the production concentration profiles.

All the figures in this section are showing profiles of concentration vs. distance. They are shown in this way since they are

Fig. 5.9 - Schematic Representation of the Calculation of the Additional Secondary Tracer Formed During a Given Production Time, Uncorrected in Position.

Fig. 5.10 - Schematic Representation of the Location of the Additional Secondary Tracer Formed by Chemical Reaction During a Given Production Time.

Fig. 5.11 - Position of the Primary and Secondary Tracer Profiles at an Intermediate Stage of Production.

easier to explain but profiles can be given as concentration vs. volume injected or produced; in any case, they are equivalent.

The final product from this section is a pair of production vs. fluids produced profiles; which are discussed in Section 6.

6. DISCUSSION OF RESULTS.

In this section are presented in graphical form the results obtained from the computer program developed to simulate a single well tracer test. The program was fed with data covering the range of values found in the literature for:

1. The ratio of the total volume injected to volume of the slug containing the primary tracer. $(2 < V_{tot}/V_{slug} < 4)$
2. Constant of dispersion. $(0.2 < \alpha < 1.0)$
3. Equilibrium constant. $(1.375 < a < 10)$
4. Residual oil saturation. $(0.1 < S_{or} < 0.4)$
5. Shut in time. $(4 < t_{sh} < 12)$

These variables were transformed to dimensionless terms, using the following definitions

$$V_D = \frac{V_{tot}}{V_{slug}} \quad (6-1)$$

$$\alpha_D = \frac{\alpha}{r} \quad (6-2)$$

where :

$$\bar{r} = \sqrt{\frac{5.615 (V_{tot} - \frac{1}{2} V_{slug})}{\pi h \phi}} \quad (6-3)$$

$$t_{SID} = \frac{t_{sh}}{\frac{2 V_{tot} - V_{slug}}{Q} + t_{sh}} \quad (6-4)$$

The simulator was tested using sets of data within the given ranges. A set of production concentration profiles from this checking procedure is presented in Fig. 6.1, the input and processed data is presented on Table 6.1.

The information that has been presented so far has been for a linear case but a discussion on the validity of these concepts and these charts for the radial case is included in Section 6.1.

6.1 Discussion on the Use of the Charts, for a Radial System.

The reader will likely have noticed that all discussion, equations, figures and calculations to this point have been related only to the linear system. The actual flow geometry for the single well tracer test, however, is radial; not linear. The discussion and equations in this subsection will be centered on the adjustments needed to change the calculations from the linear to the radial geometry.

To discuss the logic of this process, it is necessary to turn back to Section 5.2.1 and to the approximate concentration equation, Eq. 5-11. It was shown that this equation is remarkably accurate in its ability to calculate the concentration profile for a linear system. Eq. 5-11 can be thought of as the product of two independent processes; the exponential term in the equation is due only to reaction, and the error function term is due only to mixing. The reaction term (the exponential term) is a function only of reaction rate and time, or reaction rate and volume, depending in how it is written. As such it is completely independent of geometry, thus it is not affected when changing from a linear to a radial system.

Fig. 6.1 - Typical Primary and Secondary Tracer
Production Concentration Profiles,
Obtained With This Work Test Simulator.

Table 6.1 - Input and Processed Data to Simulate a Single Well Tracer Test.

SIMULATION OF THE SINGLE WELL TRACER TEST
DEPARTMENT OF PETROLEUM ENGINEERING
STANFORD UNIVERSITY

RUN No. 1

DATA :

INJECTED CONC. % Vol.	PRIMARY TRACER SLUG, bbl	TOTAL VOL. INJEC., bbl	MAX. RADIUS OF INVESTIG., feet	DISPERSION CONST, feet	CONSTANT OF REACTION 1/D	EQUILIBRIUM CONSTANT	SHUT IN TIME, D	INJECTION RATE, BPD	PRODUCTION RATE, BPD
1.0	460.0	1380.0	25.4	0.27	0.0075	2.300	10.7	276.0	276.0

RESERVOIR CHARACTERISTICS :

POROSITY fraction	THICKNESS feet	WIDTH feet	WATER SATURATION fraction
0.18	17.0	57.0	0.65

MATERIAL BALANCE CHECK : (Slug of concentr.
Co of undiluted, undispersed primary tracer)

VOLUME INJECTED bbl	VOLUME CALCULATED @ END OF SIMULATION, bbl
460.000	458.965

CALCULATED PRODUCTION PROFILES :

	FLUIDS PRODUCED bbl	PRIMARY TRACER CONCENT., % Vol	SECONDARY TRACER CONCENT., % Vol	PRIMARY CUMULATIVE CONCENTRATION, %	SECONDARY CUMULATIVE CONCENTRATION, %
1	69.00	0.000000	0.030119	0.0	0.0
2	136.00	0.000001	0.039766	0.0000	2.6068
3	207.00	0.000008	0.050201	0.0001	5.9627
4	276.00	0.000074	0.060540	0.0008	10.0936
5	345.00	0.000483	0.069986	0.0056	14.9624
6	414.00	0.002274	0.077870	0.0295	20.4776
7	483.00	0.008168	0.083608	0.1200	26.5010
8	552.00	0.023312	0.086918	0.3929	32.8619
9	621.00	0.054667	0.087728	1.0688	39.3765
10	690.00	0.108356	0.086199	2.4820	45.8642
11	759.00	0.185908	0.082672	5.0327	52.1633
12	828.00	0.281714	0.077589	9.0862	58.1413
13	897.00	0.383476	0.071430	14.8522	63.7000
14	966.00	0.475569	0.064673	22.2987	68.7768
15	1035.00	0.543568	0.057723	31.1328	73.3423
16	1104.00	0.577953	0.050878	40.8545	77.3933
17	1173.00	0.575848	0.044367	50.8559	80.9461
18	1242.00	0.540716	0.038339	60.5346	84.0311
19	1311.00	0.480605	0.032875	69.3877	86.6875
20	1380.00	0.405756	0.028029	77.8709	88.9593
21	1449.00	0.326296	0.023774	83.4165	90.8917
22	1518.00	0.250526	0.020077	88.4165	92.5274
23	1587.00	0.184032	0.016895	92.1834	93.9065
24	1656.00	0.129591	0.014177	94.9020	95.0655
25	1725.00	0.087636	0.011870	96.7850	96.0371
26	1794.00	0.057814	0.009923	98.0388	96.8500
27	1863.00	0.035745	0.008287	98.8429	97.5293
28	1932.00	0.021632	0.006922	99.3402	98.0966
29	2001.00	0.012657	0.005781	99.6375	98.5704
30	2070.00	0.007172	0.004830	99.8094	98.9662
31	2139.00	0.003941	0.004039	99.9057	99.2971
32	2208.00	0.002103	0.003380	99.9581	99.5738
33	2277.00	0.001091	0.002833	99.9856	99.8056
34	2346.00	0.000552	0.002379	100.0000	100.0000

The error function term is affected by geometry. However, this part of the equation is identical in form to the equation obtained when only mixing occurs; and although this part of the equation depends on the geometry, the theories developed by Brigham (1973) and Abbaszadeh and Brigham (1982) can be used to find out how to adjust for this geometric effect.

For comparison the following systems are used; as seen in Figs. 6.2a and 6.2b

Fig. 6.2 - Equivalent Areas, a).- Linear and b).- Radial Outward Systems, for Length of Dispersion Zone Calculations.

In the two cases shown in Fig. 6.2 the lengths of the dispersion zone (σ) are different from each other, but if the same amount of fluid is injected into both systems, i.e., same size of the slug containing the tracer and same size of pusher volume, then the volume contacted by the slug of tracer is the same in both systems. Thus, if a comparison is made between system a. and system b. in Fig. 6.2, assuming that both have the same formation thickness and porosity, the product of the length of the dispersion zone (σ) times the width of the cross-sectional area at the time shown in the figure, is a measure of the mixed volume of each system.

We would like to know what mixing characteristics would cause these two mixed volumes, the product $\sigma_1 W$ for the linear case and the product $\sigma_2 W_2$ for the radial case, to be the same. Further, since the area contacted by the primary tracer is the same in both systems, the following equation can be written when this condition holds true.

$$\frac{\sigma_1 W}{\text{area}} = \frac{\sigma_2 W_2}{\text{area}} \quad (6- 5)$$

Next, the mixing characteristics of each of these geometries will be explored to find what mixing conditions in a linear system will give this equality with mixing conditions in the radial system.

According to Brigham (1973) the length of the dispersion zone can be evaluated using Eq. 2.13 . For the linear case, Fig. 6.2a ,

$\sigma_1 = 0$, $W_1 = W_2 = W$. . The term, K , can be considered negligible. Substituting these values into Eq. 2-13, reduces it to:

$$\sigma_2^2 = 2 \propto L \quad (6. 6)$$

Using the nomenclature of Fig. 6.2a and Eq. 6.5, Eq. 6.6 is written;

$$\sigma_1^2 = 2 \propto L \quad (6. 7)$$

Multiplying both sides by W^2 , and taking the square root;

$$\sigma W = W \sqrt{2 \propto L} \quad (6. 8)$$

But area = $W L$. Dividing by area;

$$\frac{\sigma W}{W L} = \sqrt{2 \frac{\alpha}{L}} \quad (6.9)$$

For the radial case, considering the geometry presented in Fig. 6.2b, $\sigma_1 = 0$, $W_1 = 0$, $W_2 = W_2$. . Again K is considered negligible. Substituting into Eq. 2.13, reduces it to,

$$\sigma_2^2 = \frac{2 \alpha L}{3} \quad (6.10)$$

Multiplying both sides by W_2^2 , and taking the square root,

$$\sigma_2 W_2 = W_2 \sqrt{\frac{2 \alpha L}{3}} \quad (6.11)$$

Now considering that the area = $W_2 L / 2$ for the radial system, and dividing by area;

$$\frac{2 \sigma_2 W_2}{W_2 L} = \sqrt{\frac{4}{3}} \left(\frac{2 \alpha}{L} \right) \quad (6.12)$$

Thus it can be seen, by comparing Eq. 6.9 with Eq. 6.12, that if it is required that the same relative volume of mixed zone occurs in the linear case as the one obtained in a "radial-outward" system, the constant of dispersion (α) in a linear system must be 4/3 as big as the α of a radial system.

As production is simulated by using a pseudo injection period, the mixing in the linear system can be considered to be over a distance $2L$ (Fig.6.3a), and the equivalent counterpart in a radial system is an "outward-inward" system of length $2L$ as shown in Fig. 6.3b.

Fig. 6.3 - Equivalent Areas: a).- Linear and b).- Radial Outward-Inward Systems, for Length of Dispersion Zone Calculations.

For a linear system, the resulting equation is the same as Eq. 6.6 but with the length of the system doubled, thus;

$$\sigma_2^2 = 4 \alpha L \quad (6.13)$$

Multiplying both sides by W, dividing by area (area = 2 W L) and taking the square root,

$$\frac{\sigma_2 W}{2 W L} = \sqrt{\frac{\alpha}{L}} \quad (6.14)$$

For the radial "outward-inward" system, the length of the dispersion zone for the radial "outward" portion is given by Eq. 6.10. Applying Eq. 2.13, and neglecting K as before, to estimate the length of the dispersion zone in the "inward" part of the the radial system, the equation becomes

$$\sigma_3^2 = \sigma_2^2 \left(\frac{W_2}{W_3} \right)^2 + \frac{2 \alpha L}{3} \left[\frac{1 - (W_2/W_3)^3}{1 - (W_2/W_3)} \right] \quad (6.15)$$

Substituting Eq. 6.10 into 6.15 and rearranging,

$$\sigma_3^2 = \frac{2 \alpha L}{3} \frac{(2 W_2^2 + W_2 W_3 + W_3^2)}{W_3^2} \quad (6.16)$$

For the inward radial system $W_3 = 0$, which makes Eq. 6.16 infinite, but the product $\sigma_3 W_3$ is finite. Thus, Eq. 6.16 can be rearranged, the square root can be taken, and it can be written as,

$$\sigma_3 W_3 = W_2 \sqrt{\frac{4 \alpha L}{3}} \quad (6.17)$$

Dividing both sides by the area of the "outward-inward" system (area = $W_2 L$) it becomes,

$$\frac{\sigma_3 W_3}{W_2 L} = \sqrt{\frac{4}{3} \left(\frac{\alpha}{L} \right)} \quad (6.18)$$

By comparing Eqs. 6.14 and 5.18, we conclude that, if we wish the linear system to have the same relative volume of mixed zone as found in a "radial-outward-followed-by-a-radial-inward" system, the α we use in the linear system must again be $4/3$ as large as the radial α of the system. Note that this constant of $4/3$ is identical to the constant found when only going radially outward. Thus we come to a remarkable conclusion. When primary tracer is moving radially outward, the system can be treated as though it were a linear system with a higher dispersion coefficient. All else is the same since geometry does not affect the reaction rate. When the tracer is later produced, again the

geometry affects the mixing, but again it is by a constant of $4/3$. So that a simple correction on α is all that is needed to change from radial to linear geometry.

6.2 Results

During the process of checking the simulator, it was observed that the rate of reaction, as also pointed out by Deans and Majoros (1979), is important to determine the time that the well has to remain closed to allow the generation of a measurable amount of secondary tracer. Due to the slow rate of reaction, its effect on the separation of the production concentration profiles is negligible. For this reason it was not included as a parameter in the correlating charts. Also, due to the slow rate of reaction the flow rate has no effect on the results, as would be expected.

Once the checking procedure was satisfactorily completed, the program was run with all the data required to construct the residual oil correlating charts presented here.

It is worth noticing that the plots were constructed using a general set of data covering the entire range of variables mentioned at the beginning of this section. Due to this fact in some cases when the slope of the correlating saturation curves was very steep and the partitioning coefficient large, although the simulator ran, the resulting data have no physical meaning. This is specially true for the curves of 30 and 40 percent oil saturation. Thus, care must be taken when feeding the simulator with data in those regions. The curves may be used as criteria to select the conditions to use when running a test.

Since it is more likely to get field data for a radial flow system than it is for a linear system, the simulator was run using constants of dispersion (α) $4/3$ higher than the labeled dimensionless constant of dispersion (α_D) values. This means that the correlating charts, as

labeled, can be directly used for radial cases.

Next, sets of charts are presented, they cover the ranges of the above mentioned values. They are ordered in the following way:

Figs. 6.4-6.12 correspond to a constant of dispersion (α) of 0.2 ft, transformed to α_D using Eq. 6-2, covering the range of S_{or} , a , V_D , t_{SID} .

Figs. 6.13-6.21 correspond to a constant of dispersion (α) of 0.4 ft, transformed to α_D using Eq. 6-2, covering the range of S_{or} , a , V_D , t_{SID} .

Figs. 6.22-6.30 correspond to a constant of dispersion (α) of 0.6 ft, transformed to α_D using Eq. 6-2, covering the range of S_{or} , a , V_D , t_{SID} .

Figs. 6.31-6.39 correspond to a constant of dispersion (α) of 0.8 ft, transformed to α_D using Eq. 6-2, covering the range of S_{or} , a , V_D , t_{SID} .

Figs. 6.40-6.48 correspond to a constant of dispersion (α) of 1.0 ft, transformed to α_D using Eq. 6-2, covering the range of S_{or} , a , V_D , t_{SID} .

In these correlation charts it is observed that the separation between the primary and secondary tracer peaks of concentration is primarily dependent on the residual oil saturation (S_{or}) and the partitioning coefficient (a). Separation also depends, but to lesser degree, on the ratio of total volume injected to volume of the slug (V_D), the dimensionless constant (α_D) and the dimensionless shut in time (t_{SID}).

The general trend of the curves indirectly reflects the flowing conditions of the system. That is, considering that the oil phase is immobile, as saturation increases the effective area to water flow

decreases, consequently the displaceable volume within the system decreases. This allows the injection fluids to travel deeper into the formation, promoting a larger peak separation. The primary tracer will take more time to arrive at the well due to its affinity to both oil and water. The secondary tracer will return faster to the well travelling at water velocity since it is only soluble in water. This explains the increase in slope with an increase in residual oil saturation.

Even though no values were given to the program to perform calculations at partitioning coefficient equal to zero, it is observed in the charts that the origin or common point for all of them is $a = 0$ and $V_{pp}/V_{ps} = 1$. This is the end point to be expected when the reacted tracer has the same solubility as the primary tracer.

Judging by the behavior of the saturation curves, it is observed that better definition is obtained for the correlating curves corresponding to small values of the constant of dispersion (α), and at low values of V_D .

At large values of the constant of dispersion ($\alpha > 0.8$) a large shut in time leads to a better definition of the correlating curves. In some cases a small shut in time combined with a large value of V_D ($V_D = 4$) posed very severe limitations on the simulation of the process, and would cause innaccurate analysis of results (see Figs. 6.15, 6.23, 6.24, 6.32, 6.33, 6.41, 6.42 and 6.45).

In some charts it was observed that there was a small oscillation on the curves. This was attributed to the Stehfest (1970) numerical algorithm used to invert the secondary tracer equation from Laplace space.

Fig.6.4 - Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.5714$, $V_D = 2$,
 $\alpha_D = 0.0122$

Fig.6.5 - Residual Oil Correlation Chart For Single Well
 Tracer Tests : $T_{SID} = 0.4444$, $V_D = 3$,
 $\alpha_D = 0.0095$

Fig.6.6 - Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.3636$, $V_D = 4$,
 $\alpha_D = 0.0080$

Fig.6.7 - Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.7273$, $V_D = 2$,
 $\alpha_D = 0.0122$

Fig.6.8 - Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.6154$, $V_D = 3$,
 $\alpha_D = 0.0095$

Fig.6.9 - Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.5333$, $V_D = 4$,
 $\alpha_D = 0.0080$

Fig.6.10 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.8000$, $V_D = 2$,
 $\alpha_D = 0.0122$

Fig.6.11 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.7059$, $V_D = 3$,
 $\alpha_D = 0.0095$

Fig.6.12 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.6316$, $V_D = 4$,
 $\alpha_D = 0.0080$

Fig.6.13 -Residual Oil Correlation Chart for Single Well

Tracer Tests : $T_{SID} = 0.5714$, $V_D = 2$,

$\alpha_D = 0.0244$

Fig.6.14 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.4444$, $V_D = 3$,
 $\alpha_D = 0.0189$

Fig.6.15 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.3636$, $V_D = 4$,
 $\alpha_D = 0.0160$

Fig.6.16 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.7273$, $V_D = 2$,
 $\alpha_D = 0.0244$

Fig.6.17 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.6154$, $V_D = 3$,
 $\alpha_D = 0.0189$

Fig.6.18 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.5333$, $V_D = 4$,
 $\alpha_D = 0.0160$

Fig.6.19 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.8000$, $V_D = 2$,
 $\alpha_D = 0.0244$

Fig.6.20 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.7059$, $V_D = 3$,
 $\alpha_D = 0.0189$

Fig.6.21 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.6316$, $V_D = 4$,
 $\alpha_D = 0.0160$

Fig.6.22 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.5714$, $V_D = 2$,
 $\alpha_D = 0.0366$

Fig.6.23 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.4444$, $V_D = 3$,
 $\alpha_D = 0.0284$

Fig.6.24 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.3636$, $V_D = 4$,
 $\alpha_D = 0.0240$

Fig.6.25 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.7273$, $V_D = 2$,
 $\alpha_D = 0.0366$

Fig.6.26 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.6154$, $V_D = 3$,
 $\alpha_D = 0.0284$

Fig.6.27 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.5333$, $V_D = 4$,
 $\alpha_D = 0.0240$

Fig.6.28 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.8000$, $V_D = 2$,
 $\alpha_D = 0.0366$

Fig.6.29 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.7059$, $V_D = 3$,
 $\alpha_D = 0.0284$

Fig.6.30 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.6316$, $V_D = 4$,
 $\alpha_D = 0.0240$

Fig.6.31 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.5714$, $V_D = 2$,
 $\alpha_D = 0.0489$

Fig.6.32 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.4444$, $V_D = 3$,
 $\alpha_D = 0.0378$

Fig.6.33 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.3636$, $V_D = 4$,
 $\alpha_D = 0.0320$

Fig.6.34 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.7273$, $V_D = 2$,
 $\alpha_D = 0.0489$

Fig.6.35 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.6154$, $V_D = 3$,
 $\alpha_D = 0.0378$

Fig.6.36 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.5333$, $V_D = 4$,
 $\alpha_D = 0.0320$

Fig.6.37 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.8000$, $V_D = 2$,
 $\alpha_D = 0.0489$

Fig.6.38 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.7059$, $V_D = 3$,
 $\alpha_D = 0.0378$

Fig.6.39 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.6316$, $V_D = 4$,
 $\alpha_D = 0.0320$

Fig.6.40 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.5714$, $V_D = 2$,
 $\alpha_D = 0.0611$

Fig.6.41 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.4444$, $V_D = 3$,
 $\alpha_D = 0.0473$

Fig.6.42 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.3636$, $V_D = 4$,
 $\alpha_D = 0.0400$

Fig.6.43 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.7273$, $V_D = 2$,
 $\alpha_D = 0.0611$

Fig.6.44 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.6154$, $V_D = 3$,
 $\alpha_D = 0.0473$

Fig.6.45 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.5333$, $V_D = 4$,
 $\alpha_D = 0.0400$

Fig.6.46 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.8000$, $V_D = 2$,
 $\alpha_D = 0.0611$

Fig.6.47 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.7059$, $V_D = 3$,
 $\alpha_D = 0.0473$

Fig.6.48 -Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.6316$, $V_D = 4$,
 $\alpha_D = 0.0400$

6.3 Procedure to Use the Residual Oil Correlation Charts.

To use these charts, the following data are required:

1. Total volume injected, bbl.
2. Volume of the slug containing the reactive tracer, bbl.
3. Equilibrium constant (a).
4. Production concentration profiles for the primary and secondary tracer.
5. The ratio of separation of the peaks (V_{pp}/V_{ps}), where V_{pp} is the volume of fluid produced to get the peak of concentration for the primary tracer and V_{ps} the volume of fluid produced to get the peak for the secondary tracer.
6. In addition it is necessary to estimate the constant of dispersion (α) of the system. This estimation is made by fitting the produced concentration profile of the primary tracer with a computer program that was called ALPHA. This program provides an estimation of the actual constant of dispersion of the system.

The procedure to estimate the residual oil saturation (S_{or}) through the use of the charts for a linear case, is as follows,

The following information is supplied to the ALPHAL program (This program is ALPHA for the linear case): V_{slug} , V_{tot} , a , t_{sh} , Q , h , w , and ϕ . In addition the data on fluid produced vs the primary tracer concentration are provided for the program to estimate the dispersion constant (α). This program fits an equation to the primary

tracer concentration profile data. This equation is of the same form as the one used to move the "shut in" secondary tracer, Eq. 5-22. This equation is slightly modified to consider that in this case concentrations are not measured in terms of position and time, but rather, are concentrations passing through a fixed point, in this case the wellbore. (The derivation for the linear case is not included since it is very similar to the radial case derivation, Appendix E).

- a. Assume an initial value for the residual oil saturation. The ALPHAL program will deliver an estimation of the constant of dispersion (α) and the dimensionless variables V_D , t_{SID} and α_D , which is corrected from linear to radial geometry. This correction is made due to the fact that the graphs are for the radial case.
- b. With these dimensionless variables enter the appropriate chart/s. If interpolation is required, note that separation between curves is not linear, as can be seen in Fig. 8.1. Keeping this in mind, a good estimation of the residual oil saturation can be made by eye. When checking the program a more elaborate scheme for the estimation of the residual oil saturation was made. For practical purposes, interpolation by eye between curves is adequate.
- c. Compare the originally assumed S_{or} with the estimated S_{or} from Step b. If they differ by more than the desired tolerance, then use the estimated S_{or} as the new assumed S_{or} and repeat from Step a. Once they agree the iteration procedure ends. In general two iterations are enough to reach the solution.

Note that in general for a specific problem the information read from the charts needs to be done only once.

A discussion to validate the use of the linear solutions to analyze a radial case was presented in Section 6.1. Once the validation is established, the evaluation of the residual oil saturation for a radial system is performed using a similar procedure. The only difference in the radial system is that the ALPHAR program (The ALPHA program for the radial case) is used to calculate the constants.

For the radial case it was possible to develop an "approximate" solution for the primary tracer, similar to Eq. 5-11 for the linear case. This was done so that field data can be used to estimate the constant of dispersion (α). The details of the derivation are presented in Appendix E. In this appendix are also included the details of the fitting procedure for the primary tracer production concentration profile. From one of the coefficients of the fitting equation, α is estimated.

6.4 Examples.

Next, two examples on the use of the charts are presented, one for the linear flow case and other for radial flow.

For the linear flow example, two computer programs were used. These computer programs are included in Appendix G, and these are:

- 1.- The Single Well Tracer Test Simulator Program. This program provides production concentration profiles for the primary and secondary tracers.
- 2.- ALPHAL Program. This program provides an estimation of the dispersion constant (α) of the primary tracer.

For the linear system example there were no field or experimental data available, so the Single Well Tracer Test Simulator Program was used to generate simulated data to test the ALPHAL program and the iterative procedure.

The following data were used:

C_o	=	1.0	% Vol.
V_{slug}	=	460.0	bb1
V_{tot}	=	1380.0	bb1
ϕ	=	0.18	
w	=	57.0	ft
h	=	17.0	ft
S_w	=	0.65	
α	=	0.27	ft
k_r	=	0.0075	1/D
a	=	2.300	
t_{sh}	=	10.7	D

These data are the input data required to run the Single Well Tracer Test program. The results of this run are presented in Table 6.2.

In a normal field situation, the constant of dispersion (α) is unknown and so is the saturation (S_o). The objective of the ALPHAL (Linear Alpha) program is to provide an estimation of the constant of dispersion (α) along with the following dimensionless variables: V_D , t_{SID} and α_D required to enter the correlating charts.

In order to run the ALPHAL program, the following data is required: V_{slug} , V_{tot} , a , t_{shin} , Q , h , w , V_{pp}/V_{ps} , ϕ and set of data of fluid produced vs primary tracer concentration.

Even though the dispersion constant (α) and the residual oil saturation (S_{or}) data were provided to the Single Well Tracer Test Simulator in order to obtain the primary tracer concentration profile required as input data in the ALPHAL program, the ALPHAL program was run assuming that neither the dispersion constant, nor the residual oil saturation were known; which corresponds to a normal field situation.

Following the procedure to use the charts outlined in Section 6.3:

- a.- A value of 20 percent residual oil saturation was assumed. The ALPHAL program gave an estimation of $\alpha = 0.32$ ft (linear). The constant of dispersion (α) was transformed to radial equivalent since the dimensionless constant of dispersion (α_D) in the S_{or} charts are for radial systems. Thus, $(3/4) 0.32 = 0.24$ (radial equivalent) and

$$\begin{aligned}\alpha_D &= 0.009254 \\ V_D &= 3.0 \\ t_{SID} &= 0.5622\end{aligned}$$

- b.- The charts were entered corresponding to the following dimensionless variables:

Table 6.2 .- Simulation Results for the Data of the Linear Flow Example.

SIMULATION OF THE SINGLE WELL TRACER TEST
DEPARTMENT OF PETROLEUM ENGINEERING
STANFORD UNIVERSITY

RUN No. 2

DATA :

INJECTED CONC. % Vol.	PRIMARY TRACER SLUG, bbl	TOTAL VOL. INJEC., bbl	MAX. RADIUS OF INVESTIG., feet	DISPERSION CONST., feet	CONSTANT OF REACTION 1/D	EQUILIBRIUM CONSTANT	SHUT IN TIME, D	INJECTION RATE, BPD	PRODUCTION RATE, BPD
1.0	500.0	1500.0	33.4	0.40	0.0075	3.000	0.0	500.0	500.0

RESERVOIR CHARACTERISTICS :

POROSITY fraction	THICKNESS feet	WIDTH feet	WATER SATURATION fraction
0.25	20.0	30.0	0.80

MATERIAL BALANCE CHECK : (Slug of concentrat.
Co of undiluted, undispersed primary tracer)

VOLUME INJECTED bbl	VOLUME CALCULATED @ END OF SIMULATION, bbl
500.000	499.516

CALCULATED PRODUCTION PROFILES :

	FLUIDS PRODUCED bbl	PRIMARY TRACER CONCENT., % Vol	SECONDARY TRACER CONCENT., % Vol	PRIMARY CUMULATIVE CONCENTRATION, %	SECONDARY CUMULATIVE CONCENTRATION, %
1	75.00	0.000000	0.000281	0.0	0.0
2	150.00	0.000002	0.000759	0.0000	0.0023
3	225.00	0.000024	0.001938	0.0002	0.0056
4	300.00	0.000180	0.004248	0.0019	0.0049
5	375.00	0.000958	0.008378	0.0114	1.7834
6	450.00	0.003839	0.014467	0.0511	3.5901
7	525.00	0.012095	0.022203	0.1830	6.4902
8	600.00	0.031075	0.030738	0.5405	10.6771
9	675.00	0.067069	0.038912	1.3531	16.1854
10	750.00	0.124653	0.045578	2.9406	22.0674
11	825.00	0.203696	0.049976	5.6594	30.4245
12	900.00	0.297811	0.051777	9.8119	38.4718
13	975.00	0.395292	0.051094	15.5509	46.6076
14	1050.00	0.482159	0.048361	22.8163	54.4732
15	1125.00	0.545876	0.044173	31.3285	61.7915
16	1200.00	0.578303	0.039175	40.6368	68.3832
17	1275.00	0.577053	0.033875	50.2033	74.1605
18	1350.00	0.545193	0.028678	59.4957	79.1076
19	1425.00	0.489764	0.023852	68.0652	83.2620
20	1500.00	0.419767	0.019552	75.5962	86.6947
21	1575.00	0.344229	0.015839	81.9222	89.4937
22	1650.00	0.270742	0.012711	87.0143	91.7516
23	1725.00	0.204674	0.010127	90.9508	93.5578
24	1800.00	0.149007	0.008025	93.8793	94.9935
25	1875.00	0.104655	0.006342	95.9796	96.1298
26	1950.00	0.071033	0.005004	97.4344	97.0272
27	2025.00	0.046666	0.003945	98.4089	97.7349
28	2100.00	0.029719	0.003110	99.0414	98.2928
29	2175.00	0.018374	0.002455	99.4396	98.7329
30	2250.00	0.011044	0.001941	99.6832	99.0806
31	2325.00	0.006462	0.001539	99.8281	99.3559
32	2400.00	0.003685	0.001225	99.9121	99.5745
33	2475.00	0.002051	0.000978	99.9596	99.7487
34	2550.00	0.001115	0.000784	99.9859	99.8880
35	2625.00	0.000593	0.000632	100.0000	100.0000

$$\begin{aligned}
V_{pp}/V_{ps} &= 1.854 && \text{(from the simulation run)} \\
a &= 2.3 && \text{(from given data)} \\
V_D &= 3.0 \\
t_{SID} &= 0.5622 \\
\alpha_D &= 0.009254
\end{aligned}$$

No graph gave an exact match for the dimensionless parameters of interest, thus interpolation between figures was required, as seen in the following table.

Table 6.3 .- Interpretation of Figures for Oil Saturation; Linear Example.

Figure	t_{SID}	α_D	S_{or} (from graphs)
6.5	0.4444	0.0095	0.35
6.8	0.6154	0.0095	0.35
6.14	0.4444	0.0189	0.39
6.17	0.6154	0.0189	0.38

Figure 6.5 is reproduced here to illustrate how the saturation (S_{or}) entries in Table 6.3 were obtained.

In this case, the α_D was slightly below the smallest value of 0.0095, thus the figures were extrapolated as follows: for $t_{SID} = 0.5622$ and $\alpha = 0.009254$: $S_{or} = 0.349$

c.- Comparing the assumed S_{or} (20 %) with the estimated S_{or} (34.9 %) it can be noticed that they are considerably different, thus the estimated S_{or} is the new assumed S_{or} and ALPHAL was run again giving this time an estimation of the

Fig.6.5 - Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{SID} = 0.4444$, $V_D = 3$,
 $\alpha_D = 0.0095$

constant of dispersion (α) equal to 0.271 ft (linear) or 0.203 ft (radial equivalent), and

$$\alpha_D = 0.007831 , V_D = 3 , t_{SID} = 0.5622$$

extrapolating from Table 6.3 in Step b. for $t_{SID} = 0.5622$ and $\alpha_D = 0.007831$: $S_{or} = 0.344$.

Note that this time no further information needed to be read from the graphs. Repeating Step c.

Comparing the assumed S_{or} (34.9 %) with the estimated S_{or} (34.4 %), they are closer but not within an acceptable tolerance. Then $S_{or} = 34.4$ percent was the new assumed S_{or} . The ALPHAL program gave an estimation of $\alpha = 0.272$ which transformed to radial equivalent is 0.204, the dimensionless variables were:

$$\alpha_D = 0.007872 , V_D = 3 , t_{SID} = 0.5622$$

extrapolating from Table 6.3 in Step b. for $t_{SID} = 0.5622$ and $\alpha_D = 0.007872$: $S_{or} = 0.3443$. This time both, estimated and assumed residual oil saturation are close enough, then the best estimate of S_{or} for the system is 34.4 percent, compared to 35 percent used in the simulation run, which is a good agreement.

For the radial flow example actual field data was used. The field data was provided by a company as confidential, for that reason the name of the field is not revealed.

From the field test report the following data were obtained:

h	=	18.0	ft
ϕ	=	0.20	
C_o	=	0.95	% Vol.
V_{slug}	=	150.0	bb1
V_{tot}	=	322.0	bb1
Q	=	650.0	BPD
a	=	5.02	
t_{sh}	=	3.06	D

Figures 6.49 and 6.50 represent the primary and secondary production concentration profiles for this field test. These figures are from the confidential report. The triangles and crosses are the actual field data and the lines labeled "Simulated Results" are from the computer simulation made by the company. From these figures the ratio of the volume produced up to the tracers' peaks, was

$$V_{pp} / V_{ps} = 188/110 = 1.709$$

The residual oil saturation obtained by the company analyzing the field data with a finite difference simulator was estimated to be: $S_{or} = 0.22$. By measurement, it was determined that nine per cent of ethyl acetate was converted to ethyl alcohol.

The curve labeled "Simulated Results" for the primary tracer concentration profile (Fig. 6.49) was digitized. The digitized data along with the additional field data was provided to the ALPHAR program (see program in Appendix G for details about required input data).

Following the procedure delineated in Section 6.3:

Fig. 6.49 - Field Test Production Profiles for the Primary Tracer.

Fig. 6.50 - Field Test Production Profiles for the Secondary Tracer.

- a. The ALPHAR program was provided with the required information along with a first assumed residual oil saturation of 15 percent. The ALPHAR program gave the following data:

$$\alpha = 0.296 \text{ D}^{-1}, \quad V_D = 2.147, \quad t_{SID} = 0.801, \\ \alpha_D = 0.0267$$

- b. The charts were entered corresponding to the following dimensionless terms:

$$\begin{aligned} V_{pp} / V_{ps} &= 1.709 \\ a &= 5.02 \\ V_D &= 2.147 \\ t_{SID} &= 0.801 \\ \alpha_D &= 0.0267 \end{aligned}$$

Since no graph gave an exact match for the dimensionless parameters, interpolation between figures was required, as shown in Table 6.4.

Table 6.4 .- Interpretation of Figures for
Oil Saturation; Radial Example.

Fig.	V_D	t_{SID}	α_D	S_{or}
6.19	2	0.8	0.0244	0.22
6.28	2	0.8	0.0366	0.22
6.29	3	0.7059	0.0284	0.22

In this specific case no change in saturation was seen from any of the graphs, so as a first estimate, $S_{or} = 0.22$.

- c. Comparing the assumed S_{or} (15 %) with the estimated S_{or} (22 %), it can be seen that an iteration was required using the estimated S_{or} as the new assumption

A second run with the ALPHAR program gave a constant of dispersion (α) of 0.309 and $\alpha_D = 0.0279$, which according to Table 6.4 in Step b. again gave a residual oil saturation of 0.22. In this iteration, assumed and estimated residual oil saturation had the same value, then the residual oil saturation of the system is 22 percent.

The residual oil saturation obtained from the interpretation of the test using a finite difference simulator and the value estimated using the correlating charts are identical. It is worth remarking that use of the correlating charts is much faster and simpler.

Also comparing the constant of dispersion reported in the field test ($\alpha = 0.28$) and the one estimated with the ALPHAR program ($\alpha = 0.309$) it is observed that they are quite close and there is no reason to prefer one answer to the other. The point in favor of the constant of dispersion (α) obtained with the ALPHAR program is that it is simpler to calculate. The one obtained with the finite difference simulator is the result of a trial and error procedure which also involves other fitting parameters.

7. CONCLUSIONS

1. The component continuity equation in cylindrical coordinates that describes the single well tracer test, has no analytic solution.
2. Numerical solutions using finite differences, gave results that were affected by numerical dispersion. In addition this method is time consuming since trial and error is involved in the S_{or} determination process. Also this method causes questions of uniqueness.
3. For the primary tracer, the equation in linear coordinates was decomposed into two systems: 1).- a reactive-convective system and 2).- a dispersive system with adsorption. A simple multiplication of these solutions produces a result that is quite accurate, and is simpler and easier to use than the exact analytic solution. In addition, this solution allows the linear system to be transformed to radial geometry by using a simple multiplying factor of $4/3$ on the mixing coefficient α .
4. A back calculating technique was developed which allows the fluids to continue moving, dispersing, adsorbing and reacting during production. This removes the assumption used by other methods that all the secondary tracer is generated only during shut in time. The back calculating technique proved to be accurate and eased the simulation of return of the tracers to the well.
5. A computer program was developed using the semi-analytic solutions and the results are presented in a set of charts that

cover the most common ranges of the following terms: a). the ratio of the total volume of fluids injected to the volume of the slug containing the reactive tracer, b). the dimensionless dispersion, c). dimensionless shut in time, d). equilibrium constant and e). residual oil saturation.

From these results, it is seen that the oil saturation and equilibrium constant have the greatest effect on the results, while the other variables have a smaller effect.

6. The constant of reaction was also analyzed and, though it is important to determine the shut in time required to generate a detectable amount of secondary tracer, it did not affect the position of the concentration peaks. For this reason it was not included as a parameter in the charts.
7. Flow rate had no effect on the results, as expected.
8. The estimation of the S_{or} is made by fitting the production data to an equation which can be used to calculate a constant of dispersion. This in turn, is used to enter specific charts to estimate the residual oil saturation. This is an iterative process which converges rapidly.
9. This formulation does not handle a drifting system, however the complete formulation for the streamlines of a drifting system, along with suggestions on how to continue this topic are included in this work.

8. RECOMMENDATIONS

The correlating charts in Section 6, present curves of 10, 20, 30 and 40 per cent residual oil saturation. The separation between curves is not linear, as can be seen in Fig. 8.1. Thus, when making a reading from the charts, this non linearity between curves should be kept in mind in order to obtain an acceptable interpolation value. Considerable computer time would be involved in running the program to include intermediate saturation curves in all the charts, as presented in Fig. 8.1, but certainly this would lead to more accurate readings from the correlating charts.

The present work was developed under assumptions that restrict its applicability to certain special conditions, thus to make this work more general the following effects need to be taken into account:

1. Drift effects.
2. Stratification.
3. Dilution corrections.
4. Mobility different than unity.
5. Two phase flow.

Of these effects the most important next step which ought to be included in the single well tracer test simulation is the effect of a drifting system. The presence of drift causes a distortion of the radial geometry of flow, rendering useless the models for radial geometry. It is not possible to reproduce, with a radial geometry model, the long

Fig.8.1.- Residual Oil Correlation Chart for Single Well
 Tracer Tests : $T_{STO} = 0.5714$, $V_D = 2$,
 $\alpha_D = 0.0163$

tails of production that are characteristic of a drifting system. Therefore, it is necessary to consider a flow system that takes into consideration the distorted geometry of flow.

The derivation of the streamlines that describe the geometry of flow in a drifting system is presented in Appendix F. Equations for the streamlines as presented in Appendix F, in general, represent the skeleton of a drifting system. To use this skeleton to simulate a single well tracer test affected by drift, it is necessary to include the following considerations:

Let us start analyzing the path followed by a fluid particle along a given streamchannel. Locating the well at point A, during injection a non-reactive fluid particle will move along path AB on Fig. 8.2 at a velocity which will depend on the geometry of the streamchannel and the rate of injection. During shut in time, the fluid particle will move at the same velocity as the parallel flow originating the drift, path BC. When the well is opened to production, the particle will return to the well along path CA at a velocity that will depend on the geometry of the streamchannel and the rate of production.

Fig. 8.2 - Injection, Shut-In, Production Path Followed by a Particle Along a Given Streamchannel in the Presence of Drift.

The thin dashed lines that are moved to the right in the figure represent the position of the injection streamchannel after shut in. The shape of the streamchannel is not modified since, during shut in, all the particles forming the streamchannel are transported at the drift velocity.

Now, consider the injection of primary tracer reacting and adsorbing as it is being injected. At the end of injection, concentration profiles for the primary and secondary tracers are presented at different locations in the "injection" streamchannel, Fig. 8.3.

Fig. 8.3 - Injection Path of the Primary and Secondary Tracers in the Presence of Drift.

During shut in time, the primary and secondary tracers will move along different streamlines due to their difference in position at the end of injection. The secondary tracer will continue dispersing as it is transported during shut in time. For simulation purposes, it is

convenient to independently move this "injection" secondary tracer separately from that secondary tracer that is being generated during shut in. Thus the situation at the end of shut in can be presented as separate tracer slugs as indicated in Fig. 8.4.

Fig. 8.4 - Shut In Paths of the Primary and Secondary Tracers in the Presence of Drift.

When the well is opened to production, due to their differences in position, the primary tracer, the "injection" secondary tracer and the "shut in" secondary tracer will each return to the well along different streamlines. Again for simulation purposes, it is convenient to handle each of them as moving separately from each other. At a given stage during production, a picture of the process is as presented on Fig. 8.5.

Note that there are four separate tracer locations and concentrations that must be accounted for: (1) the "injection" secondary tracer, (2) the "shut in" secondary tracer, (3) the "production" secondary tracer, and (4) the primary tracer. And there are three

separate flow paths that these tracers will follow.

The drifting system is symmetric with respect to the abscissa axis, that is, the flow below the axis is identical to that above. However, each of the streamlines on one side are different from each other; which means that a large number of individual primary and secondary tracer peaks have to be evaluated into and out of each of the streamlines forming one side of the symmetric system. This involves a considerable volume of computational work. The total amount of primary and secondary tracer is double the amount obtained by integration of the contribution of each streamline on one side of the axis of symmetry.

Fig. 8.5 - Production Paths of the Primary and Secondary Tracers in the Presence of Drift.

NOMENCLATURE

a, b	Constants in the partition coefficient group
A	Area, L^2
A_0	Coefficient zero of a zero degree polynomial
A, B, E, F	Coefficients used in the Laplace space derivations
$\bar{A}, \bar{B}$	Coefficients of the method of characteristics solution
AA, BB, CC	Coefficients of the least squares fitting procedure
B_o	Oil volume factor, RB/STB
C	Concentration of the primary tracer in water
C_1, C_2	Arbitrary constants
$\bar{C}$	Laplace tranform of the primary tracer concentration
$\tilde{C}$	Primary tracer concentration in oil
C_d	Displacing fluid concentration
C_1	Concentration of component 1.
C_I	Primary tracer concentration, calculated at the end of injection
C_o	Initial concentration
C_o^f	Fictitious initial concentration
C_{sh}	Primary tracer concentration, calculated at the end of shut in
C'	Secondary tracer concentration
$\bar{C}'$	Laplace transform of the secondary tracer concentration
$\bar{C}'_h$	Laplace transform of the secondary tracer homogeneous solution
$\bar{C}'_p$	Laplace transform of the secondary tracer particular solution
C'_{sh}	Secondary tracer concentration, calculated at the end of shut in

$\Delta C'_{sh}$	Additional secondary tracer generated during shut in
D'	Mixing constant, depending on the diffusion coefficient and the cementation factor in the porous medium, L^2/t
dS	Incremental path along a streamline, L
g	Gravitational acceleration, L/t^2
h	Formation thickness, L
k_r	Constant of reaction, t^{-1}
K	Dispersion coefficient, L^2/t
K'	Diffusional mixing coefficient, L^2/t
K_1	Equilibrium distribution coefficient
L	Length of the porous medium, L
m	Independent variable in the characteristic equation to solve ordinary differential equations (ODE)
m_1, m_2	Roots of the characteristic equation to solve ODE's.
M	Molecular weight
N	Number of terms used in the Laplace space algorithm of inversion
p	Pressure, $m L/t^2$
P_n	Polynomial of degree n
q_D	Dimensionless rate
q_o	Average constant specific discharge in the $+x$ direction, L^3/t
Q	Injection or production rate, L^3/t
$\bar{r}$	Front location in radial flow, L
$\bar{r}'$	Front location with adsorption in radial flow, L
Δr	Grid spacing, L
R_1	Rate of reaction, t^{-1}
s	Laplace transform variable for time
s	Distance from inlet to any point traveling along a streamline, L
$\bar{s}$	Average distance traveled by the front along a streamline, L
s_D	Dimensionless distance along any streamline

$\bar{s}_D$	Dimensionless average distance traveled by a particle along a streamline
S_o	Oil saturation, fraction
S_{or}	Residual oil saturation, fraction
S_w	Water saturation, fraction
S_{wc}	Connate water saturation, fraction
t	Time, t
Δt	Time step, t
t_o	Initial time, t
t_1	Elapsed time to position the leading front at $\bar{x}_1$, t
t_2	Elapsed time to position the trailing front at $\bar{x}_2$, t
t_D	Dimensionless time
t_I	Injection time, t
t_{pv}	Time to inject one pore volume, t
t_{sh}	Shut in time, t
t_{SID}	Dimensionless shut in time
T	Temperature
U	Dimensionless group $(V_p - V) / \sqrt{V_p V}$
U_{10}	U at ten percent concentration
U_{90}	U at ninety percent concentration
v	Velocity of flow, L/t
$\vec{v}$	Local mass average velocity, m/t
v_D	dimensionless velocity
$\vec{v}_1$	Velocity of component 1, L/t
$\vec{v}_o$	Local velocity of the oil, L/t
v_w	Water velocity, L/t
$\vec{v}_w$	Local velocity of the water, L/t
v_x	Velocity in the x direction, L/t
V	Volume recovered at time of sample, L ³
$\bar{V}$	Specific volume, L ³ /m
V_D	Dimensionless volume ratio
V_{drift}	Drift velocity, L/t
V_1	Retention volume of tracer 1, L ³
V_p	Pore volume of the porous medium, L ³

V_{pd}	Twice the displaceable pore volume up to location r , L^3
$\bar{V}'_{pd}$	Variable calculated as $(V_{tot} + V_{prod})$, L^3
V_{pp}	Volume of fluid produced to get the peak of concentration for the primary tracer, L^3
V_{prod}	Produced volume, L^3
V_{ps}	Volume of fluid produced to get the peak of concentration for the secondary tracer, L^3
V_{slug}	Volume of the slug containing the diluted primary tracer, L^3
V_{tot}	Total volume injected, L^3
w	Width of the linear system, L
w_1	Width of the inlet face, L
w_2	Width of the outlet face, L
w_3	Width of the outlet face in a diverging, converging system, L
x	Distance, L
$\bar{x}$	Average distance traveled by the front, L
$\bar{x}_1$	Average distance traveled by the leading edge, L
$\bar{x}_2$	Average distance traveled by the trailing edge, L
x_{10}	Distance to the point of ten percent displacing fluid, L
x_{90}	Distance to the point of ninety percent displacing fluid, L
x_D	Dimensionless distance in the x direction
$\bar{x}_D$	Average dimensionless distance in the x direction
y	Ordinate, L
y_D	Dimensionless distance in the y direction
$\bar{y}_D$	Average dimensionless distance in the y direction
y_{pf}	Width of the zone where parallel flow is occurring, L
Δz	Increment in the z -direction, cylindrical coordinates, L

Subscripts

D	Dimensionless
i	Injection
p	Production
r	Radial
sh	Shut in

Greek Letters

α	Constant of dispersion, L
α_D	Dimensionless constant of dispersion
β	Dummy variable used in the secondary tracer solution
γ_1, γ_2	Coefficients of the solution of an ODE
μ	Viscosity, cp
π	Constant equal to 3.14157....
ρ_i	Density of component i, m/L ³
$\bar{\rho}_i$	Density of component i in the oil phase, m/L ³
σ	Standard deviation or length of the mixing zone, L
σ_1	Length of the mixing zone at inlet, L
σ_D	Dimensionless length of the mixing zone
$\Delta\theta$	Increment in the θ direction, cylindrical coordinates
ϕ	Porosity, fraction
Φ	Potential
ψ	Streamline
ψ_D	Dimensionless streamline
ψ_{pf}	Streamline in parallel flow
ψ_w	Streamline in a well

REFERENCES

- Abbaszadeh-D, M. and Brigham, W.E.: "Analysis of Well to Well Tracer Flow to Determine Reservoir Heterogeneity", Paper SPE 10760 presented at California Regional Meeting of the SPE, San Francisco Calif., (Mar. 24-26, 1982).
- Abramowitz, M. and Stegun, I.: Handbook of Mathematical Functions, National Bureau of Standards, Applied Mathematics Series 55, 9th Ed., 1970.
- Aronofsky, J.S. and Heller, J.P.: "A Diffusion Model to Explain Mixing of Flowing Miscible Fluids in Porous Media", Petroleum Transactions, AIME, 210, (1957), pp. 345-349.
- Baldwin, D.E.: "Prediction of Tracer Performance in a Five-Spot Pattern", Jour. of Pet. Tech., (Apr. 1966), pp. 513-517.
- Bear, J. and Jacobs, M.: "On the Movement of Water Bodies Injected into Aquifers", J. of Hydrology, 3, (1965), pp. 37-57.
- Blackwell, R.J.: "Laboratory Studies of Microscopic Dispersion Phenomena" Soc. of Pet. Eng. J., (Mar. 1962), pp. 1-8.
- Blackwell, R.J., Rayne, J.R. and Terry, W.M.: "Factors Influencing the Efficiency of Miscible Displacement", Petroleum Transactions, AIME, 216, (1959), pp. 1-8.

- Braggs, J.R., Carlson, L.O. and Atterbury, J.H.: "Recent Applications of the Single Well Tracer Method for Measuring Residual Oil Saturation", Paper SPE 5805 presented at SPE Symposium on Improved Oil Recovery, Tulsa Okla., (Mar. 22-24, 1976).
- Brigham, W.E.: "Mixing Equations in Various Geometries", Paper SPE 4585, presented at SPE 48th Annual Fall Meeting, Las Vegas Nevada, (Sept. 30-Oct. 3, 1973).
- Brigham, W.E., Reed, P.W. and Dew, J.N.: "Experiments on Mixing During Miscible Displacement in Porous Media", Soc. of Pet. Eng. J., (Mar. 1961), pp. 1-8.
- Brigham, W.E. and Smith, D.H.: "Prediction of Tracer Behavior in Five-Spots", Paper SPE 1130 presented at SPE 40th Annual Fall Meeting, Denver Colo., (Oct. 1965).
- Chase, C.A., Jr.: "Finite Element Analysis of Single Well Backflow Tracer Test in a Homogeneous Reservoir", Paper SPE 3485 presented at SPE 46th Annual Fall Meeting, New Orleans La., (Oct. 3-6, 1971).
- Cooke, C.E. Jr.: "Method of Determining Residual Oil Saturation in Reservoirs", U.S. Patent 3,590,923 (July 6, 1971).
- Deans, H.A. and Majoros, S.: "The Single-Well Chemical Tracer Test, Direct Calculation of Residual Oil Saturation from Field Data", Proceedings of Fifth Annual DOE Symposium on Enhanced Oil Recovery and Improved Drilling Technology, Tulsa Okla., (Aug. 22-24, 1979), pp F6/1-F6/14.
- Deans, H.A. and Shallenberger, L.K.: "Single-Well Chemical Tracer Method to Measure Connate Water Saturation", Paper SPE 4755 presented at SPE Symposium on Improved Oil Recovery, Tulsa Okla., (Apr. 22-24, 1974).

De Wiest, R.J.M.:Geohydrology, John Wiley & Son, Inc. (1963), pp. 252.

Greenkorn, R.A. and Kessler, D.P.: "Dispersion in Heterogeneous Non-Uniform Anisotropic Porous Media", Flow Thorough Porous Media, Symposium on Flow Through Porous Media, (1969). American Chemical Society Publication, Washington, D.C.

Handy, L.L.: "An Evaluation of Diffusion Effects in Miscible Displacement", Petroleum Transactions, AIME, 216, (1959), pp. 382-384.

Majoros, S. and Deans, H.A.: "Single-Well Chemical Tracer Tests Since 1968", DOE report, DOE/BC/20006-17, (July 1980).

Ogata, A. and Banks, R.B.: "A Solution of the Differential Equation of Longitudinal Dispersion in Porous Media", U.S. Geological Survey, Professional Paper 41-A, (1961).

Perkins, T.K. and Johnston, O.C.: "A Review of Diffusion and Dispersion in Porous Media", Soc. of Pet. Eng. J., (Mar. 1963), pp. 70-84.

Raimondi, P., Gardner, G.H.F. and Petrick, C.B.: "Effect of Pore Structure and Molecular Diffusion on the Mixing of Miscible Liquids Flowing in Porous Media", Paper 43, AIChE-SPE Joint Symposium, National AIChE Meeting, San Francisco Calif., (Dec. 6-9, 1959).

Raimondi, P. and Torcaso, M.A.: "Mass Transfer Between Phases in a Porous Medium: a Study of Equilibrium", Soc. Pet. Eng. J., (Mar. 1965), pp. 51-59.

Roberts, G.E - Kaufman, H.: Table of Laplace Transforms, W.B. Saunders Company, Philadelphia, (1966), Eq. 80, pp. 255.

Sheely, C.Q.: "Description of Field Test to Determine Residual Oil Saturation by Single Well Tracer Method", Paper SPE 5840 presented

at SPE Symposium on Improved Oil Recovery, Tulsa Okla., (Mar. 22-24, 1976).

Sheely, C.Q. and Baldwin, D.E.: "Single Well Test for Evaluating Chemical Enhanced Oil Recovery Processes Using Single Well Tracer Tests", paper SPE 8838 presented at SPE 55th Annual Fall Meeting, Dallas Texas, (Sept. 21-24, 1980).

Stehfest, H.: "Numerical Inversion of Laplace Transforms", Algorithm 368, Communications of the ACM, (Jan. 1970), Vol. 3, No. 1, pp. 47-49. Errata, (Oct., 1970), Vol. 13, No. 10, pp. 624.

Tomich, J.F., et al : "Single-Well Tracer Method to Measure Residual Oil Saturation", Journal of Pet. Tech., (Feb. 1973), pp. 211-218.

APPENDIX A

DERIVATION OF THE COMPONENT CONTINUITY EQUATION IN CYLINDRICAL COORDINATES.

This appendix includes the assumptions and derivation of the basic component continuity equation to simulate a single well chemical tracer test. The final equation in this appendix, Eq. A.11, is the same as the one presented by Tomich, et al (1973) for radial case.

Assumptions

- 1). The fluids are incompressible.
- 2). The oil phase is immobile.
- 3). Chemical reaction occurs in both the oil and the brine phases.
- 4). Equilibrium mass transfer is achieved.
- 5). The tracer mass flux is small compared with the mass flow rate of the water.
- 6). The formation is homogeneous and isotropic.
- 7). Radial flow.

Component continuity equation

By material balance in a volume element,

$$\text{INPUT} = \text{OUTPUT} + \text{DISAPPEARANCE BY REACTION} + \text{ACCUMULATION} \quad (\text{A. 1})$$

For a given component $-i-$, where S_{or} is immobile and considering an effective area to flow,

the moles of $-i-$ entering by bulk flow

$$= C_i v_w S_w \phi r \Big|_r \Delta\theta \Delta z \quad (\text{A. 2})$$

moles of $-i-$ leaving by bulk flow,

$$= C_i v_w S_w \phi r \Big|_{r+\Delta r} \Delta\theta \Delta z \quad (\text{A. 3})$$

entering by dispersion,

$$= - \left[r \phi S_w K \nabla C_i \right]_r \Delta\theta \Delta z \quad (\text{A. 4})$$

leaving by dispersion,

$$= - [r \phi S_w K \nabla C_i]_{r+\Delta r} \Delta \theta \Delta z \quad (\text{A. 5})$$

disappearance by reaction,

$$- k_r (C_i S_w + \tilde{C}_i S_o) (r + \Delta r/2) \phi \Delta r \Delta \theta \Delta z \quad (\text{A. 6})$$

accumulation,

$$\frac{\partial}{\partial t} (C_i S_w + \tilde{C}_i S_o) \phi (r + \Delta r/2) \Delta r \Delta \theta \Delta z \quad (\text{A. 7})$$

Entering all these terms in Eq. A.1 and rearranging,

$$\begin{aligned} & - (C_i v_w S_w \phi r \Big|_{r+\Delta r} - C_i v_w S_w \phi r \Big|_r) \Delta \theta \Delta z \\ & + [(r \phi S_w K \nabla C_i)_{r+\Delta r} - (r \phi S_w K \nabla C_i)_r] \Delta \theta \Delta z \\ & + k_r (C_i S_w + \tilde{C}_i S_o) (r + \Delta r/2) \phi \Delta r \Delta \theta \Delta z \\ & - \frac{\partial}{\partial t} (C_i S_w + \tilde{C}_i S_o) (r + \Delta r/2) \phi \Delta r \Delta \theta \Delta z = 0 \end{aligned} \quad (\text{A. 8})$$

Dividing through all the equation by $(r + \Delta r/2) \Delta r \Delta \theta \Delta z$,
considering a homogeneous porous medium $\phi = \text{const.}$ and taking limits,
then

$$\begin{aligned}
& \frac{1}{r} \frac{\partial}{\partial r} (r S_w v_w C_i) - \frac{1}{r} \frac{\partial}{\partial r} (r S_w K \nabla C_i) \\
& - k_r (C_i S_w + \tilde{C}_i S_o) + \frac{\partial}{\partial t} (C_i S_w + \tilde{C}_i S_o) = 0 \quad (\text{A. 9})
\end{aligned}$$

In general Eq. A.9 for any component $-i-$ in vectorial notation,

$$\begin{aligned}
& \frac{\partial}{\partial t} (C_i S_w + \tilde{C}_i S_o) + \nabla \cdot (S_w \vec{v}_w C_i) \\
& - k_r (C_i S_w + \tilde{C}_i S_o) = \nabla \cdot (S_w K \nabla C_i) \quad (\text{A.10}) \\
& i = 1, \dots, N
\end{aligned}$$

Then, for a radial case, rearranging Eq. A.10,

$$\begin{aligned}
& \frac{1}{r} \frac{\partial}{\partial r} (r S_w K \frac{\partial C_i}{\partial r}) - \frac{1}{r} \frac{\partial}{\partial r} (r S_w v_w C_i) \\
& + k_r (C_i S_w + \tilde{C}_i S_o) = \frac{\partial}{\partial t} (C_i S_w + \tilde{C}_i S_o) \quad (\text{A.11})
\end{aligned}$$

where,

K = dispersion coefficient

k_r = constant of reaction

C_i = concentration of component -i- in the water phase

$\tilde{C}_i$ = concentration of component -i- in the oil phase

APPENDIX B

SOLUTION TO THE COMPONENT CONTINUITY EQUATION IN A LINEAR COORDINATE SYSTEM, FOR THE PRIMARY TRACER.

It was not possible to obtain an analytic solution for the radial case, then an alternate semi-analytic solution was developed in terms of a linear system. In this appendix is presented the assumptions and solution to the component continuity equation in a linear coordinate system, for the primary tracer.

Assumptions:

1. Homogeneous and isotropic porous medium.
2. Reservoir is at residual oil saturation.

$$S_o = 1 - S_w = \text{const.} \quad (\text{B. 1})$$

3. The source term is a first order chemical reaction.
4. Dispersion is proportional to the local velocity.

$$K = \alpha \left| v_x \right| \quad (\text{B. 2})$$

5. Tracer is soluble, both, in water and oil. The concentration of tracer in oil, $\tilde{C}_1$, is related to the tracer concentration in water, C_1 , by means of a linear relation.

$$\tilde{C}_1 = a C_1 \quad (\text{B. 3})$$

Solution to the component continuity equation

From material balance, the average velocity is:

$$v_x = \frac{Q}{A \phi S_w} = \text{const.} \quad (\text{B. 4})$$

The component continuity equation for a linear system is obtained in a similar way to the one presented for the radial case in Appendix A, then from material balance in a volume element,

$$\begin{aligned} \frac{\partial}{\partial x} (S_w v_x C_1) - \frac{\partial}{\partial x} (K S_w \frac{\partial C_1}{\partial x}) \\ + k_r (C_1 S_w + \tilde{C}_1 S_o) = - \frac{\partial}{\partial t} (C_1 S_w + \tilde{C}_1 S_o) \end{aligned} \quad (\text{B. 5})$$

Considering Eqs. B.1-B.4, Eq. B.5 reduces to,

$$S_w v_x \frac{\partial C_1}{\partial x} - K S_w \frac{\partial^2 C_1}{\partial x^2} + k_r C_1 (S_w + a S_o) = - (S_w + a S_o) \frac{\partial C_1}{\partial t} \quad (\text{B. 6})$$

Dividing by $S_w K$ and rearranging,

$$\begin{aligned} \frac{\partial^2 C_1}{\partial x^2} - \frac{v_x}{K} \frac{\partial C_1}{\partial x} - \frac{k_r}{K} C_1 \frac{S_w + a(1 - S_w)}{S_w} \\ = \frac{S_w + a(1 - S_w)}{K S_w} \frac{\partial C_1}{\partial t} \end{aligned} \quad (\text{B. 7})$$

Defining,

$$A = \frac{v_x}{K} ; \quad B = \frac{k_r}{K} \frac{S_w + a(1 - S_w)}{S_w} = k_r E ; \quad E = \frac{S_w + a(1 - S_w)}{K S_w} \quad (\text{B. 8})$$

Then,

$$\frac{\partial^2 C_1}{\partial x^2} - A \frac{\partial C_1}{\partial x} - B C_1 = E \frac{\partial C_1}{\partial t} \quad (\text{B. 9})$$

Equation B.9 will be solved using the following initial and boundary conditions.

$$C_1 (x, 0) = 0 \quad (\text{B.10})$$

$$C_1 (0, t) = C_0 \quad (\text{B.11})$$

$$C_1 (x, t) \rightarrow 0 \quad \text{as } x \rightarrow \infty \quad (\text{B.12})$$

Applying the Laplace transform to Eq. B.9,

$$\frac{d^2 \bar{C}_1}{dx^2} - A \frac{d \bar{C}_1}{dx} - B \bar{C}_1 = E [s \bar{C}_1 + C_1 (x, 0)] \quad (\text{B.13})$$

Using I.C., Eq. B.10 and rearranging,

$$\frac{d^2 \bar{C}_1}{dx^2} - A \frac{d\bar{C}_1}{dx} - F \bar{C}_1 = 0 \quad (\text{B.14})$$

where, $F = B + E s$

Equation B.14 is an ordinary, linear and homogeneous differential equation. Solving its characteristic equation:

$$m^2 - A m - F = 0$$

then,

$$m = \frac{A \pm \sqrt{A^2 + 4F}}{2} \quad \left\{ \begin{array}{l} m_1 = (A + \sqrt{A^2 + 4F}) / 2 \\ m_2 = (A - \sqrt{A^2 + 4F}) / 2 \end{array} \right. \quad (\text{B.15})$$

$$(\text{B.16})$$

The general solution to Eq. B.14 is :

$$\bar{C}_1 = \gamma_1 e^{m_1 x} + \gamma_2 e^{m_2 x} \quad (\text{B.17})$$

Substituting Eqs. B.15 and B.16 into B.17

$$C_1 = \gamma_1 e^{\frac{1}{2} (A + \sqrt{A^2 + 4F}) x} + \gamma_2 e^{\frac{1}{2} (A - \sqrt{A^2 + 4F}) x}$$

In order to keep valid B.C., Eq. B.12,

$$C_1(x, t) \rightarrow 0 \quad \text{as} \quad x \rightarrow \infty \quad + \quad \bar{C}(x, s) \rightarrow 0 \quad \text{as} \quad x \rightarrow \infty$$

$\gamma_1(s)$ has to be zero, then

$$\bar{C}_1 = \gamma_2 e^{Ax/2} e^{-x\sqrt{A^2 + 4F/2}} \quad (\text{B.18})$$

Transforming B.C., Eq. B.11,

$$\bar{C}_1(0, s) = \frac{C_0}{s} \quad (\text{B.19})$$

$\gamma_2 = \frac{C_0}{s}$, is obtained. Substituting Eq. B.19 into B.18,

$$\bar{C}_1 = C_0 e^{Ax/2} \frac{e^{-x\sqrt{A^2 + 4F/2}}}{s} \quad (\text{B.20})$$

Substituting relations B.8 into Eq. B.20 and rearranging,

$$\frac{\bar{C}_1(x, s)}{C_0} = e^{\frac{x v_x}{2K}} e^{-\sqrt{E} x \sqrt{\frac{v_x^2}{4EK^2} + k_r + s}} \quad (\text{B.21})$$

From Roberts - Kaufman (1966)

$$\mathcal{L}^{-1} \left\{ \frac{e^{-a(s+b^2)^{1/2}}}{s} \right\} = \frac{e^{-ab}}{2} \operatorname{erfc} \left(\frac{a}{2t^{1/2}} - b t^{1/2} \right) +$$

$$\frac{ab}{2} \operatorname{erfc} \left(\frac{a}{2t^{1/2}} + b t^{1/2} \right)$$

with the following equivalences

$\operatorname{Re} s > 0$

$$a = \sqrt{E} x \quad ; \quad b^2 = \frac{v_x^2}{4EK^2} - k_r \quad + \quad b = \sqrt{\frac{v_x^2 + 4k_r EK^2}{4EK^2}}$$

Inverting Eq. B.21,

$$\frac{C_1(x,t)}{C_0}$$

$$= \frac{1}{2} e^{\frac{x v_x}{2K}} e^{-\frac{x}{2K} \sqrt{v_x^2 + 4k_r EK^2}}$$

$$\cdot \operatorname{erfc} \left[\frac{x}{2} \sqrt{\frac{E}{t}} - \sqrt{\frac{(v_x^2 + 4k_r EK^2)t}{4EK^2}} \right]$$

$$+ \frac{1}{2} e^{\frac{x v_x}{2K}} e^{\frac{x}{2K} \sqrt{v_x^2 + 4k_r EK^2}}$$

$$\cdot \operatorname{erfc} \left[\frac{x}{2} \sqrt{\frac{E}{t}} + \sqrt{\frac{(v_x^2 + 4k_r EK^2)t}{4EK^2}} \right]$$

Rearranging and substituting $E = \frac{S_w (1 - a) + a}{K S_w} = \frac{S_w + a (1 - S_w)}{K S_w}$

$$\frac{C_1(x,t)}{C_0} = \frac{1}{2} e^{\frac{x v_x}{2 K}} \left\{ e^{-\frac{x}{2 K} \sqrt{v_x^2 + 4 k_r K \left[\frac{S_w + a(1 - S_w)}{S_w} \right]}} \right. \\ \cdot \operatorname{erfc} \left[\frac{x \frac{S_w + a(1 - S_w)}{S_w} - t \sqrt{v_x^2 + 4 k_r K \left[\frac{S_w + a(1 - S_w)}{S_w} \right]}}{2 \sqrt{K t} \frac{S_w + a(1 - S_w)}{S_w}} \right] \\ + e^{\frac{x}{2 K} \sqrt{v_x^2 + 4 k_r K \left[\frac{S_w + a(1 - S_w)}{S_w} \right]}} \\ \cdot \operatorname{erfc} \left[\frac{x \frac{S_w + a(1 - S_w)}{S_w} + t \sqrt{v_x^2 + 4 k_r K \left[\frac{S_w + a(1 - S_w)}{S_w} \right]}}{2 \sqrt{K t} \frac{S_w + a(1 - S_w)}{S_w}} \right] \left. \right\}$$

(B.22)

For long time solutions, the second summand in the RHS becomes negligible, in such a case, Eq. B.22 can be reduced to:

$$\frac{C_1(x,t)}{C_0} = \frac{1}{2} e^{-\frac{x}{2K} \left[v_x - \sqrt{v_x^2 + 4k_r K \left[\frac{S_w + a(1-S_w)}{S_w} \right]} \right]} \cdot \operatorname{erfc} \left[\frac{x - t \sqrt{\left[\frac{v_x S_w}{S_w + a(1-S_w)} \right]^2 + 4k_r K \left[\frac{S_w}{S_w + a(1-S_w)} \right]}}{2 \sqrt{K t \frac{S_w}{S_w + a(1-S_w)}}} \right]$$

(B.23)

Equation B.23 is the exact analytic solution that represents the distribution, dispersion, reaction and adsorption of the primary tracer in a single well tracer test.

APPENDIX C

SOLUTION TO A CONVECTIVE-REACTIVE SYSTEM BY THE METHOD OF CHARACTERISTICS.

In this appendix is presented the solution to a convective-reactive system by the method of characteristics. This solution is combined with the solution for a dispersive system with adsorption to reduce the exact analytic solution given by Eqs. 5-7 or B.23 to an approximate solution, Eq. 5-11. This last equation is simpler and easier to handle, and allows the linear system to be related directly to radial geometry

The equation representing a convective-reactive system is obtained neglecting the dispersion term in Eq. 5-2,

$$-v S_w \frac{\partial C}{\partial x} - k_r (C S_w + \tilde{C} S_o) = \frac{\partial}{\partial t} (C S_w + \tilde{C} S_o) \quad (C. 1)$$

Considering,

$$v = \frac{Q}{A \phi S_w} = \text{const.} \quad (C. 2)$$

$$\tilde{C} = a C \quad (C. 3)$$

$$S_o = 1 - S_w \quad (C. 4)$$

Substituting Eqs. C.2 to C.4 into C.1 and rearranging,

$$- \frac{Q}{A \phi} \frac{\partial C}{\partial x} - k_r C [S_w + a(1 - S_w)] = [S_w + a(1 - S_w)] \frac{\partial C}{\partial t} \quad (C. 5)$$

Calling:

$$\bar{A} = - \frac{Q}{A \phi} \quad (C. 6)$$

$$\bar{B} = - [S_w + a(1 - S_w)] \quad (C. 7)$$

Then, Eq. C.5 can be written as,

$$\bar{A} \frac{\partial C}{\partial x} + \bar{B} \frac{\partial C}{\partial t} + k_r \bar{B} C = 0 \quad (C. 8)$$

$$- k_r C = \frac{\bar{A}}{\bar{B}} \frac{\partial C}{\partial x} + \frac{\partial C}{\partial t} \quad (C. 9)$$

The initial and boundary conditions for Eq. C.9 are:

$$C(x, 0) = 0 \quad (C.10)$$

$$C(0, t) = C_0 \quad (C.11)$$

Now, the total derivative of $C = C(x, t)$ is,

$$d C(x, t) = \left(\frac{\partial C}{\partial x} \right)_t dx + \left(\frac{\partial C}{\partial t} \right)_x dt \quad (C.12)$$

Dividing by dt and rearranging,

$$\frac{dC}{dt} = \frac{dx}{dt} \left(\frac{\partial C}{\partial x} \right)_t + \left(\frac{\partial C}{\partial t} \right)_x \quad (C.13)$$

By similitude between Eqs. C.9 and C.13,

$$\frac{dx}{dt} = \frac{\bar{A}}{\bar{B}} \quad (C.14)$$

$$\frac{dC}{dt} = -k_r C \quad (C.15)$$

Eqs. C.14 and C.15 are the characteristic equations.

Integrating Eqs. C.14 and C.15,

$$x = \frac{\bar{A}}{\bar{B}} t + C_1 \quad (C.16)$$

$$C = C_2 e^{-k_r t} \quad (C.17)$$

C_1 and C_2 are arbitrary constants that give rise to a two parameter family of curves.

Picking $C_1 = 0$ since x is zero at $t = 0$, and solving for t in Eq. C.16,

$$t = \frac{\bar{B}}{\bar{A}} x \quad (C.18)$$

Substituting Eq. C.18 into C.19,

$$C = C_2 e^{-\frac{k_r \bar{B}}{\bar{A}} x} \quad (C.19)$$

$$\text{Using B.C. C.11 @ } x = 0, C = C_0 \longrightarrow C_2 = C_0 \quad (C.20)$$

Substituting Eq. C.20 into C.19 and considering Eqs. C.2, C.6 and C.7,

$$C(x,t) = C_0 e^{-\frac{k_r x}{v} \left[1 + \frac{a(1 - S_w)}{S_w} \right]} \quad (\text{Space solution}) \quad (C.21)$$

Substituting Eq. C.20 into C.17,

$$C(x,t) = C_0 e^{-k_r t} \quad (\text{Time solution}) \quad (C.22)$$

The representation of the space solution is given in Fig. C.1

Fig. C.1 - Schematic Representation of the Space Characteristic Solution of a Reactive - Convective System.

APPENDIX D

LAPLACE SPACE SOLUTION FOR THE SECONDARY TRACER.

This appendix covers the solution in Laplace space for the PDE in linear geometry representing the generation and distribution of the secondary tracer from the chemical reaction of the primary tracer. The solution is presented in Laplace space; it can be inverted to real space but the inverted solution is too impractical to handle. Instead the solution presented in this appendix has been inverted numerically using the Stehfest Algorithm (1970).

From material balance it can be shown that the generation and distribution in the porous medium of the secondary tracer as a product of chemical reaction of the primary tracer is given by,

$$\frac{\partial}{\partial t} (S_w C') + S_w v_x \frac{\partial C'}{\partial x} + k_r (C S_w + \tilde{C} S_o) = \frac{\partial}{\partial x} \left(S_w K \frac{\partial C'}{\partial x} \right) \quad (D. 1)$$

Rearranging,

$$\frac{\partial}{\partial x} \left(S_w K \frac{\partial C'}{\partial x} \right) - S_w v_x \frac{\partial C'}{\partial x} + k_r C [S_w + a(1 - S_w)] = \frac{\partial}{\partial t} (S_w C') \quad (D. 2)$$

Assuming,

$$K = \alpha v_x \quad (D. 3)$$

By material balance,

$$v_x = \frac{Q}{A \phi S_w} = \frac{Q}{w h \phi S_w} = \text{const.} \quad (\text{D. 4})$$

Assuming constant water saturation,

$$K \frac{\partial^2 C'}{\partial x^2} - v_x \frac{\partial C'}{\partial x} + k_r C \left[\frac{S_w + a(1 - S_w)}{S_w} \right] = \frac{\partial C'}{\partial t} \quad (\text{D. 5})$$

Rearranging,

$$\frac{\partial^2 C'}{\partial x^2} - \frac{v_x}{K} \frac{\partial C'}{\partial x} + \frac{k_r C}{K} \left[\frac{S_w + a(1 - S_w)}{S_w} \right] = \frac{1}{K} \frac{\partial C'}{\partial t} \quad (\text{D. 6})$$

Defining,

$$A = \frac{v_x}{K} \quad (\text{D. 7})$$

$$B = \frac{k_r}{K} \left[\frac{S_w + a(1 - S_w)}{S_w} \right] \quad (\text{D. 8})$$

$$E' = \frac{1}{K} \quad (\text{D. 9})$$

Then,

$$\frac{\partial^2 C'}{\partial x^2} - A \frac{\partial C'}{\partial x} + B C = E' \frac{\partial C'}{\partial t} \quad (\text{D. 10})$$

Eq. D.10 is solved using the following initial and boundary conditions:

$$C'(x,0) = 0 \quad (D.11)$$

$$C'(0,t) = 0 \quad (D.12)$$

$$C'(x,t) \rightarrow 0 \quad (D.13)$$

$$x \rightarrow \infty$$

Taking the Laplace transformation of Eq. D.10,

$$\frac{d^2 \bar{C}'}{dx^2} - A \frac{d \bar{C}'}{dx} + B \bar{C} = E' [s \bar{C}' - \bar{C}'(x,0)] \quad (D.14)$$

Considering B.C., Eq. D.11 and rearranging,

$$\frac{d^2 \bar{C}'}{dx^2} - A \frac{d \bar{C}'}{dx} - E' s \bar{C}' = -B \bar{C} \quad (D.15)$$

Eq. D.15 is an inhomogeneous ordinary differential equation. Its solution is given in terms of an homogeneous solution ($\bar{C}'_h$) and a particular solution ($\bar{C}'_p$),

$$\bar{C}' = \bar{C}'_h + \bar{C}'_p \quad (D.16)$$

The solution to the homogeneous equation is given by

$$\bar{C}'_h = C_1 e^{m_1 x} + C_2 e^{m_2 x} \quad (D.17)$$

where, C_1 and C_2 are arbitrary constants and

$$m_1 = \frac{1}{2} (A + \sqrt{A^2 + 4 E' s}) \quad (D.18)$$

$$m_2 = \frac{1}{2} (A - \sqrt{A^2 + 4 E' s}) \quad (D.19)$$

The particular solution is, $\bar{C}'_p = -B \bar{C}$, where $\bar{C}$ is the concentration of the primary tracer in Laplace space. Then the coupling of the primary to the secondary tracer is performed by substituting Eq. B.21, the solution for the primary tracer, into the particular solution. Thus,

$$\bar{C}'_p = -\frac{B C_o}{s} e^{x \left[A - \sqrt{A^2 + 4(B + E s)} \right] / 2} \quad (D.20)$$

Defining,

$$\beta = A - \sqrt{A^2 + 4(B + E s)} \quad (D.21)$$

$$p_n(x) = -\frac{B C_o}{s} \quad (\text{zero degree polynomial}) \quad (D.22)$$

Then Eq. D.20 can be written as,

$$\bar{C}'_p = e^{\beta x / 2} p_n(x) \quad (D.23)$$

Assuming that Eq. D.23 has a solution of the form,

$$\bar{C}'_p = A_o e^{\beta x / 2} \quad (D.24)$$

The first and second derivative of Eq. D.24 are,

$$\frac{d \bar{C}'_p}{d x} = \frac{1}{2} A_o \beta e^{\beta x / 2} \quad (D.25)$$

$$\frac{d^2 \bar{C}'_p}{d x^2} = \frac{1}{4} A_o \beta^2 e^{\beta x / 2} \quad (D.26)$$

Substituting Eqs. D.25 and D.26 into D.15, and rearranging,

$$A_o \left(\frac{1}{4} \beta^2 - \frac{1}{2} A \beta - E' s \right) = - \frac{B C_o}{s} \quad (D.27)$$

Solving for A_o and substituting it into Eq. D.24,

$$\bar{C}'_p = - \frac{4 B C_o e^{\beta x / 2}}{s(\beta^2 - 2 A \beta - 4 E' s)} \quad (D.28)$$

Substituting the homogeneous solution, Eq. D.20, and the particular solution, Eq. D.28, into Eq. D.16

$$\bar{C}' = C_1 e^{m_1 x} + C_2 e^{m_2 x} - \frac{4 B C_o e^{\beta x / 2}}{s(\beta^2 - 2 A \beta - 4 E' s)} \quad (D.29)$$

Substituting Eqs. D.17, D.18 and D.21 into Eq. D.29, and rearranging,

$$\begin{aligned} \bar{C}' = & C_1 e^{x(A + \sqrt{A^2 + 4E's})/2} + C_2 e^{x(A - \sqrt{A^2 + 4E's})/2} \\ & - \frac{B C_0 e^{x[A - \sqrt{A^2 + 4(B + E's)}]/2}}{s[(E - E')s + B]} \end{aligned} \quad (D.30)$$

According to B.C. Eq. D.13, C_1 has to be zero, then Eq. D.30 is written as,

$$\bar{C}' = C_2 e^{x(A - \sqrt{A^2 + 4E's})/2} - \frac{B C_0 e^{x[A - \sqrt{A^2 + 4(B + E's)}]/2}}{s[(E - E')s + B]} \quad (D.31)$$

Using B.C., Eq. D.12,

$$C_2 = \frac{B C_0}{s[(E - E')s + B]} \quad (D.32)$$

Substituting Eq. D.32 into D.31, and rearranging,

$$\bar{C}' = B C_0 e^{Ax/2} \left\{ \frac{-e^{x\sqrt{A^2 + 4E's}/2} - e^{x\sqrt{A^2 + 4(B + E's)}/2}}{s[(E - E')s + B]} \right\} \quad (D.33)$$

Substituting the definitions for terms, Eqs. D.7, D.8 and D.9 into D.33, and rearranging,

$$\bar{C}' = k_r C_o e^{\frac{x v_x}{2 K}}$$

$$\bullet \left\{ \frac{e^{-\frac{x v_x}{2 K} \sqrt{v_x^2 + 4 K s}} - e^{-\frac{x}{2 K} \sqrt{v_x^2 + 4 K (k_r + s)} \left[1 + \frac{a(1 - S_w)}{S_w} \right]}}{s \left\{ s \left[1 + \frac{S_w}{S_w + a(1 - S_w)} \right] + k_r \right\}} \right\} \quad (D.34)$$

Eq. D.34 is the solution in Laplace space to the PDE representing the generation and distribution of the secondary tracer in a system of linear geometry.

APPENDIX E

APPROXIMATE SOLUTION FOR THE PRIMARY TRACER IN A RADIAL SYSTEM.

In this appendix is presented the derivation of the approximate solution for a radial system. This solution, like in the linear case, is obtained by combining two solutions: 1), the solution to a reactive-convective system by the method of characteristics and 2), the solution to a dispersive system with adsorption. This last solution was obtained using the approximate method of solution presented by Brigham and Smith (1965). In this appendix is also included the derivation of the equation to fit the primary tracer concentration profile and, from one of the coefficients of the fitted equation, to estimate the constant of dispersion (α) of the system. The fitted equation is the basic equation of the ALPHA program.

Reactive-Convective System.

The PDE representing a reactive-convective system in cylindrical coordinates is obtained neglecting the dispersion term in Eq. 4-1, the resulting equation is,

$$-\frac{1}{r} \frac{\partial}{\partial r} (r S_w v_{wr} C) - k_r (C S_w + \tilde{C} S_o) = \frac{\partial}{\partial t} (C S_w + \tilde{C} S_o)$$

(E. 1)

Considering,

$$v_{wr} = \frac{Q}{2 \pi r h \phi S_w} \quad (\text{E. 2})$$

$$\tilde{C} = a C \quad (\text{E. 3})$$

$$S_o = 1 - S_w \quad (\text{E. 4})$$

Substituting Eqs. E.2 - E.4 into E.1 and considering that in Eq. E.2, the product $v_{wr} r = \text{const.}$, Eq. E.1 can be written as follows,

$$- \frac{Q}{2 \pi h \phi S_w} \frac{1}{r} \frac{\partial C}{\partial r} - k_r C \left[\frac{S_w + a(1 - S_w)}{S_w} \right] = \left[\frac{S_w + a(1 - S_w)}{S_w} \right] \frac{\partial C}{\partial t} \quad (\text{E. 5})$$

Calling,

$$\bar{A} = - \frac{Q}{2 \pi h \phi S_w} \quad (\text{E. 6})$$

$$\bar{B} = - \left[\frac{S_w + a(1 - S_w)}{S_w} \right] \quad (\text{E. 7})$$

Substituting Eqs. E.6 and E.7 into E.5 and rearranging,

$$\frac{\bar{A}}{r\bar{B}} \frac{\partial C}{\partial r} + \frac{\partial C}{\partial t} = - k_r C \quad (\text{E. 8})$$

Equation E.8 is solved using the method of characteristics and the following initial and boundary conditions,

$$C(r,0) = 0 \quad (E. 9)$$

$$C(0,t) = C_0 \quad (E.10)$$

Since $C = C(r,t)$, the total derivative is,

$$dC = \left(\frac{\partial C}{\partial r} \right)_t dr + \left(\frac{\partial C}{\partial t} \right)_r dt \quad (E.11)$$

Dividing by dt and rearranging,

$$\frac{dC}{dt} = \frac{dr}{dt} \left(\frac{\partial C}{\partial r} \right)_t + \left(\frac{\partial C}{\partial t} \right)_r \quad (E.12)$$

By similitude between Eqs. E.8 and E.12,

$$\frac{dr}{dt} = \frac{\bar{A}}{r \bar{B}} \quad (E.13)$$

$$\frac{dC}{dt} = -k_r C \quad (E.14)$$

Integrating Eqs. E.13 , E.14 and rearranging them,

$$r^2 = \frac{2\bar{A}}{\bar{B}} t + C_1 \quad (E.15)$$

$$C = C_2 e^{-k_r t} \quad (\text{E.16})$$

C_1 and C_2 are arbitrary constants that give origin to a two parameter family of curves. Since $r = 0$ when $t = 0$, $C_1 = 0$ and, from Eq. E.15,

$$t = \frac{1}{2} \frac{\bar{B}}{\bar{A}} r^2 \quad (\text{E.17})$$

substituting Eq. E.17 into E.16,

$$C = C_2 e^{-\frac{1}{2} \frac{k_r \bar{B}}{\bar{A}} r^2} \quad (\text{E.18})$$

Using B.C. given by Eq. E.10, @ $r = 0$, $C = C_0$ therefore $C_2 = C_0$. Considering Eqs. E.6 and E.7 and by rearranging, Eqs. E.18 and E.16 can be written as:

$$C = C_0 e^{-\frac{1}{2} \frac{r k_r}{v_{wr}} \left[\frac{S_w + a(1 - S_w)}{S_w} \right]} \quad (\text{Space solution}) \quad (\text{E.19})$$

$$C = C_0 e^{-k_r t} \quad (\text{Time solution}) \quad (\text{E.20})$$

Equations E.19 and E.20 are the solutions to a reactive-convective system

Dispersive System with Adsorption

The PDE representing the system with dispersion and adsorption only is obtained by neglecting the reaction term in Eq. 4-1,

$$\frac{1}{r} \frac{\partial}{\partial r} \left(r S_w K \frac{\partial C}{\partial r} \right) - \frac{1}{r} \frac{\partial}{\partial r} \left(r S_w v_{wr} C \right) = \frac{\partial}{\partial t} \left(C S_w + \tilde{C} S_o \right) \quad (E.21)$$

In addition to expressions E.2 to E.4 the dispersion coefficient (K) is defined as,

$$K = \alpha v_{wr} \quad (E.22)$$

substituting Eqs E.2 - E.4, and E.22 into E.21 and considering that the product $v_{wr} r = \text{const.}$, Eq. E.21 can be written as,

$$\alpha \frac{\partial^2 C}{\partial r^2} - \frac{\partial C}{\partial r} = \frac{2 \pi r h \phi S_w}{Q} \left[\frac{S_w + a(1 - S_w)}{S_w} \right] \frac{\partial C}{\partial t} \quad (E.23)$$

defining,

$$Q' = \frac{Q}{2 \pi h \phi \left[S_w + a(1 - S_w) \right]} \quad (E.24)$$

substituting Eq. E.24 into Eq. E.23 and rearranging,

$$\frac{\partial C}{\partial r} + \frac{r}{Q'} \frac{\partial C}{\partial t} = \alpha \frac{\partial^2 C}{\partial r^2} \quad (E.25)$$

Equation E.25 is the same equation presented by Brigham and Smith (1965). They solved the equation using the following initial and boundary conditions, which are the same conditions to be used here:

$$C(r,t) = 0 \quad (E.26)$$

$$C(0,t) = C_o \quad (E.27)$$

$$C(x,t) \rightarrow 0 \quad (E.28)$$

$$x \rightarrow \infty$$

Brigham and Smith followed a technique suggested by Raimondi (1959) to obtain the following solution to Eq. E.25,

$$\frac{C}{C_o} = \frac{1}{2} \operatorname{erfc} \left[\frac{r^2 / 2 - Q't}{2 \sqrt{\frac{\alpha r^3}{3}}} \right] \quad (E.29)$$

substituting Eq. E.24 into Eq. E.29,

$$\frac{C}{C_o} = \frac{1}{2} \operatorname{erfc} \left\{ \frac{r^2/2 - \frac{Q t}{2 \pi h \phi [S_w + a(1 - S_w)]}}{2 \sqrt{\frac{\alpha r^3}{3}}} \right\} \quad (E.30)$$

but volume injected is,

$$Q t = \pi \bar{r}^2 h \phi S_w \quad (E.31)$$

substituting Eq. E.31 into Eq. E.30 and rearranging,

$$\frac{C}{C_o} = \frac{1}{2} \operatorname{erfc} \left\{ \frac{r^2 - \bar{r}^2 \frac{S_w}{[S_w + a(1 - S_w)]}}{2 \sqrt{\frac{4}{3} \alpha r^3}} \right\} \quad (E.32)$$

Equation E.32 is the solution to a dispersive system with adsorption, where $\bar{r}$ is the material balance average radius. The combination of Eq. E.32 which defines the effects of adsorption and dispersion with the space solution of a reactive-convective, system Eq. E.19, results in the approximate solution for a radial system as follows,

$$\frac{C(r,t)}{C_o} = \frac{1}{2} e^{-\frac{r k_r}{2 v_{wr}} \left[\frac{S_w + a(1 - S_w)}{S_w} \right]} \operatorname{erfc} \left\{ \frac{r^2 - \bar{r}^2 \left[\frac{S_w}{S_w + a(1 - S_w)} \right]}{2 \sqrt{\frac{4}{3} \alpha r^3}} \right\}$$

(E.33)

Equation to fit the Primary Tracer Production Concentration Profile

In this section is presented the derivation of the basic equation to estimate the dispersion constant (α) through the fitting of this equation to the primary tracer production concentration profile.

Defining,

$$\bar{r}'^2 = \bar{r}^2 \left[\frac{S_w}{S_w + a(1 - S_w)} \right] \quad (E.34)$$

substituting Eq. E.34 into E.33, the argument of the complementary error function becomes,

$$\frac{r^2 - \bar{r}'^2}{2 \sqrt{\frac{4}{3} \alpha r^3}} = \frac{(r - \bar{r})(r + \bar{r})}{2 \sqrt{\frac{4}{3} \alpha r^3}} \quad (E.35)$$

Now if $\bar{r}'$ is very close to r , then $\bar{r}' + r \approx 2r \approx 2\bar{r}'$. This assumption reduces Eq. E.35 to,

$$\frac{r^2 - \bar{r}'^2}{2\sqrt{\frac{4}{3}\alpha r^3}} = \frac{r - \bar{r}'}{\sqrt{\frac{4}{3}\alpha r}} \quad (\text{E.36})$$

This equation was presented by Lau (1959) and Brigham (1973). Substituting Eq. E.36 into E.34 and superposing the resulting equation in time and space, to simulate the injection of a slug,

$$\frac{C(r,t)}{C_o} = \frac{1}{2} e^{-\frac{r k_r}{2 v_w r} \left[\frac{S_w + a(1-S_w)}{S_w} \right]} \left\{ \operatorname{erfc} \left[\frac{r - \bar{r}_1}{\sqrt{\frac{4}{3}\alpha r}} \right] - \operatorname{erfc} \left[\frac{r - \bar{r}_2}{\sqrt{\frac{4}{3}\alpha r}} \right] \right\} \quad (\text{E.37})$$

Which can be expressed in terms of a differential of slug as follows, defining

$$z = \frac{r - \bar{r}'}{\sqrt{\frac{4}{3}\alpha r}} \quad (\text{E.38})$$

substituting Eq. E.38 into E.37, The difference of the complementary error functions can be approximated as,

$$\operatorname{erfc}(z_1) - \operatorname{erfc}(z_2) = \frac{\Delta \operatorname{erfc}(z)}{\Delta z} \Delta z \quad (\text{E.39})$$

but

$$\Delta z = \frac{r - \bar{r}_1}{\sqrt{\frac{4}{3}\alpha_1 r}} - \frac{r - \bar{r}_2}{\sqrt{\frac{4}{3}\alpha_2 r}} \quad (\text{E.40})$$

considering that $\alpha_1 = \alpha_2$

$$\Delta z = \frac{\bar{r}_2 - \bar{r}_1}{\sqrt{\frac{4}{3} \alpha r}} \quad (\text{E.41})$$

now

$$\lim_{\Delta z \rightarrow 0} \frac{\Delta \operatorname{erfc}(z)}{\Delta z} = \frac{d \operatorname{erfc}(z)}{d z} = - \frac{2}{\sqrt{\pi}} e^{-z^2} \quad (\text{E.42})$$

substituting Eqs. E.41 and E.42 into Eq. E.37, considering Eqs. E.38 and E.39,

$$C(r,t) = \frac{(\bar{r}_1' - \bar{r}_2') C_0}{\sqrt{\frac{4}{3} \alpha \pi r}} \exp \left\{ - \left[\frac{r k}{2v_{wr}} \left[\frac{S_w + a(1 - S_w)}{S_w} \right] + \frac{(r - \bar{r}')^2}{\frac{4}{3} \alpha r} \right] \right\} \quad (\text{E.43})$$

Equation E.43 is for an "outward" system. To consider an "outward-inward" system, the length of the dispersion (σ) can be defined as

$$\sigma^2 = \frac{2}{3} \alpha r = \frac{2}{3} \alpha \bar{r} \quad (\text{E.44})$$

or in general, it can be defined according to the equation derived by Abbaszadeh and Brigham (1982),

$$\sigma^2 = 2 \alpha v^2(\bar{s}) \int_0^{\bar{s}} \frac{ds}{v^2(s)} \quad (\text{E.45})$$

Expressing Eq. E.43 in terms of σ .

$$C(r,t) = \frac{\Delta \bar{r}' C_0}{\sqrt{2 \pi \sigma^2}} \exp \left\{ - \left[\frac{r k_r}{2 v_{wr}} \left[\frac{S_w + a(1 - S_w)}{S_w} \right] + \frac{(r - \bar{r}')^2}{2 \sigma^2} \right] \right\} \quad (E.46)$$

The length of the dispersion zone, σ , for an "outward-inward" system is calculated using Eq. E.45, thus

$$\sigma^2 = 2 \alpha v_{wr}^2 (2 \bar{r}_I) \int_0^{2 \bar{r}_I} \frac{dr}{v_{wr}^2(r)} = 2 \alpha v_{wr}^2 (2 \bar{r}_I) \left[\underbrace{\int_0^{\bar{r}_I} \frac{dr}{v_{wr}^2(r)}}_{I_1} + \underbrace{\int_{\bar{r}_I}^{2 \bar{r}_I} \frac{dr}{v_{wr}^2(r)}}_{I_2} \right] \quad (E.47)$$

The outward region of an "outward-inward" system is represented by integral I_1 in Eq. E.47. The velocity given by Eq. E.2 is valid for $0 < r < \bar{r}_I$ in the outward region, thus substituting Eq. E.2 in integral I_1 , and integrating,

$$I_1 = \left(\frac{2 \pi h \phi S_w}{Q} \right)^2 \frac{\bar{r}_I^3}{3} \quad (E.48)$$

for the inward region, the velocity is defined as follows,

$$v_{wr} = \frac{Q}{2 \pi h \phi S_w (2 \bar{r}_I - r)} \quad (E.49)$$

The inward region in Eq. E.47 is represented by integral I_2 . Velocity in this region is given by Eq. E.49 which is valid for $\bar{r}_I < r < 2\bar{r}_I$, substituting Eq. E.49 into integral I_2 and integrating,

$$I_2 = \left(\frac{2 \pi h \phi S_w}{Q} \right)^2 \frac{\bar{r}_I^3}{3} \quad (E.50)$$

substituting Eqs. E.48 and E.50 into Eq. E.47,

$$\sigma^2 = \frac{4}{3} \alpha \frac{v_{wr}^2 (2\bar{r}_I)}{Q^2} (2 \pi h \phi S_w)^2 \bar{r}_I^3 \quad (E.51)$$

substituting Eq. E.51 into Eq. E.46,

$$C(r,t) = \frac{Q \Delta \bar{r} C_o}{2 \pi v_{wr} (2\bar{r}_I) h \phi S_w \sqrt{\frac{8}{3} \pi \alpha \bar{r}_I^3}} \cdot \exp \left\{ - \left[\frac{r k_r}{2 v_{wr}} \left[\frac{S_w + a(1 - S_w)}{S_w} \right] + \frac{(r - \bar{r}')^2}{\frac{v_{wr}^2 (2\bar{r}_I)}{Q^2} (2 \pi h \phi S_w)^2 \frac{8}{3} \alpha \bar{r}_I^3} \right] \right\} \quad (E.52)$$

It is convenient to express Eq. E.52 in volumetric terms. To perform that conversion, the actual location of the tracer slug will be approximated by a rectangle, since the slug size is small compared to the size of the volume of reservoir contacted by the tracer, this approximation is,

$$(r - \bar{r}') w h \phi S_w = V_{pd} - \bar{V}'_{pd} \quad (E.53)$$

where:

w = width of the system at location $\bar{r}'$

h = thickness of the system

ϕ = porosity

S_w = displaced fluid saturation in the system

V_{pd} = displaceable pore volume up to location r

$\bar{V}'_{pd}$ = displaceable pore volume up to location $\bar{r}'$

also,

$$\Delta \bar{r}' w h \phi S_w = \Delta \bar{V}'_{pd} \quad (E.54)$$

The width of the system at $\bar{r}'$ is related to velocity of the fluid at that point by,

$$w = \frac{Q}{v_{wr} \phi h S_w} \quad (E.55)$$

Considering Eqs. E.2, E.53 - E.55 and rearranging,

$$C(r,t) = \frac{\Delta \bar{V}'_{pd} C_o}{2 \pi \bar{r}_I h \phi S_w \sqrt{\frac{8}{3} \alpha \pi \bar{r}_I}} \cdot \exp \left\{ - \left[\frac{k_r V_{pd}}{2 Q} \left[\frac{S_w + a(1 - S_w)}{S_w} \right] + \frac{(V_{pd} - \bar{V}'_{pd})^2}{(2 \pi \bar{r}_I h \phi S_w)^2 \frac{8}{3} \alpha \bar{r}_I} \right] \right\} \quad (E.56)$$

where,

$$\bar{r}_I = \sqrt{\frac{V_{tot}}{\pi h \phi S_w}} \quad (E.57)$$

Calling A_I the total area contacted by the injection fluids,

$$A_I = 2 \pi \bar{r}_I h \phi S_w \quad (E.58)$$

substituting Eq. E.58 into E.56

$$C(r,t) = \frac{\Delta \bar{V}'_{pd} C_o}{A_I \sqrt{\frac{8}{3} \alpha \pi \bar{r}_I}} \exp \left\{ - \left[\frac{k_r V_{pd}}{2 Q} \left[\frac{S_w + a(1 - S_w)}{S_w} \right] + \frac{(V_{pd} - \bar{V}'_{pd})^2}{\frac{8}{3} \alpha \bar{r}_I A_I^2} \right] \right\} \quad (E.59)$$

This equation gives the concentration distribution of a tracer as a function of distance and time. But for the purpose of this work, we require the equation of the tracer concentration arriving at the well at

a specific time. To transform Eq. E.59, the following definitions are required,

$$V_{pd} = 2 V_{tot} = 2 \pi \bar{r}_I^2 h \phi S_w \quad (E.60)$$

and,

$$\bar{V}'_{pd} = V_{tot} + V_{prod} \quad (E.61)$$

where V_{prod} is the produced volume.

It is necessary to consider V_{pd} as twice the displaceable pore volume and $\bar{V}'_{pd}$ according to Eq. E.61 due to two reasons 1). the pseudo injection procedure used to develop the method, discussed in Section 5.2.3 and 2). the primary tracer reacts, adsorbes and disperses during injection and also during production

Substituting Eqs. E.60 and E.61 into E.59 and rearranging

$$C(r,t) = \frac{\Delta \bar{V}'_{pd} C_o}{A_I \sqrt{\frac{8}{3} \alpha \pi \bar{r}_I}} \exp \left\{ - \left[\frac{k_r V_{tot}}{Q} \left[\frac{S_w + a(1 - S_w)}{S_w} \right] + \frac{(V_{tot} - V_{prod})^2}{\frac{8}{3} \alpha \bar{r}_I A_I^2} \right] \right\} \quad (E.61)$$

This equation is fitted to the primary tracer production concentration profile to estimate the constant of dispersion (α). Rearranging this equation into a suitable form to be used with the weighted least squares method, it can be written as follows,

$$\ln C(r,t) = AA + BB V_{prod} + CC V_{prod}^2 \quad (E.62)$$

where,

$$AA = \ln \left[\frac{\Delta \bar{V}'_{pd} C_o}{A_I \sqrt{\frac{8}{3} \alpha \pi \bar{r}_I}} \right] - \frac{k_r V_{tot}}{Q} \left[\frac{S_w + a(1 - S_w)}{S_w} \right] - \frac{V_{tot}^2}{\frac{8}{3} \alpha \bar{r}_I A_I^2} \quad (E.63)$$

$$BB = \frac{2 V_{tot}}{\frac{8}{3} \alpha \bar{r}_I A_I^2} \quad (E.64)$$

$$CC = - \frac{1}{\frac{8}{3} \alpha \bar{r}_I A_I^2} \quad (E.65)$$

Coefficients AA, BB, CC are obtained from the fitting procedure. Thus, the coefficient of dispersion (α) is obtained from Eq. E.65,

APPENDIX F

DERIVATION OF THE COMPLEX FLOW SYSTEM OF A WELL AFFECTED BY DRIFT.

In some field applications, the injection or production in neighboring wells or the presence of pressure gradients in the reservoir, causes the injection fluids to follow a preferential direction of flow. This effect that deforms the radial geometry of injection is called drift. When drift is present in a reservoir, its effect is reflected in the production concentration profiles, both the primary and secondary tracers present long tails that can not be reproduced with a radial system formulation. A special formulation based in a flow geometry that considers drift is necessary to correctly simulate the single well tracer test in this kind of system.

In this appendix is presented the formulation that describes the geometry of flow of a drifting system in terms of complex potential theory.

According to Darcy's law, for a linear system,

$$q = - \frac{k A}{\mu} \frac{dp}{dx} \quad (F. 1)$$

or

$$v_x = - \frac{k}{\mu \phi S_w} \frac{dp}{dx} \quad (F. 2)$$

By definition the potential is,

$$\phi = \int \bar{V} dp + \rho g z \quad (\text{F. 3})$$

where $\bar{V}$ is specific volume.

Differentiating Eq. F.3 and since the flow is horizontal $z = 0$

$$\frac{d\phi}{dx} = \bar{V} \frac{dp}{dx} \quad (\text{F. 4})$$

Rearranging and substituting Eq. F.4 in F.2

$$v_x = \frac{k}{\mu \phi S_w \bar{V}} \frac{d\phi}{dx} \quad (\text{F. 5})$$

Using Cauchy- Riemann conditions, in Cartesian coordinates,

$$\frac{\partial \phi}{\partial x} = \frac{\partial \psi}{\partial y} \quad (\text{F. 6})$$

$$\frac{\partial \phi}{\partial y} = - \frac{\partial \psi}{\partial x} \quad (\text{F. 7})$$

in polar coordinates,

$$\frac{\partial \phi}{\partial r} = \frac{1}{r} \frac{\partial \psi}{\partial \theta} \quad (\text{F. 8})$$

$$\frac{1}{r} \frac{\partial \phi}{\partial \theta} = - \frac{\partial \psi}{\partial r} \quad (\text{F. 9})$$

Considering a linear flow system, (this is the drift effect) from Eq. F.5, taking into account Eq. F.6 and solving for $\partial \psi / \partial y$,

$$\frac{\partial \psi_{pf}}{\partial y} = - \frac{v \mu \phi S_w \bar{V}}{k} \quad (\text{F.10})$$

Separating variables in Eq. F.10 and integrating

$$\psi_{pf} = - \frac{\mu \phi S_w \bar{V}}{k} v y + c \quad (\text{F.11})$$

Now, considering a cylindrical system with a source or sink,

$$q = 2 \pi r h \phi S_w v_r \quad (\text{F.12})$$

where,

$$v_r = - \frac{k}{\mu \phi S_w \bar{V}} \frac{\partial \phi}{\partial r} \quad (\text{F.13})$$

Substituting Eq. F.13 into F.12, considering Eq. F.8 and solving for $\partial \psi / \partial \theta$

$$\frac{\partial \psi}{\partial \theta} = - \frac{q \mu \bar{V}}{2 \pi k h} \quad (\text{F.14})$$

Separating variables in Eq. F.14, integrating and calling this the solution of the well,

$$\psi_w = - \frac{q \mu \bar{V}}{2 \pi k h} \theta + c \quad (F.15)$$

Thus, by superposition of Eqs. F.11 and F.15, the solution for a well in a uniform flow field (drift) is obtained, (De Wiest (1963), and Bear and Jacobs (1965)).

$$\psi = \psi_{pf} + \psi_w \quad (F.16)$$

Substituting Eqs. F.11 and F.15 in Eq. F.16 and assuming the respective constants of integration equal to zero; which implies both solutions laying on the abscissa axis.

$$\psi = - \frac{\mu \phi S_w \bar{V}}{k} v y - \frac{q \mu \bar{V}}{2 \pi k h} \theta \quad (F.17)$$

The first term in the right hand side, can be written as,

$$\frac{\mu \phi S_w \bar{V}}{k} v y = \frac{\mu \phi S_w \bar{V}}{k} \frac{q_o}{A \phi S_w} y \quad (F.18)$$

but the total area exposed to linear flow is,

$$A = y_{pf} h \quad (F.19)$$

where,

y_{pf} = width of the zone where linear flow is occurring.
This could be a known or fitting parameter.

q_o = average constant specific discharge in the
+x direction.

then,

$$\frac{\mu \phi S_w \bar{V}}{k} v y = \frac{\mu \bar{V} q_o}{k h y_{pf}} y \quad (\text{F.20})$$

substituting Eq. F.20 into F.17,

$$\psi = - \frac{\mu \bar{V} q_o}{k h y_{pf}} y - \frac{q \mu \bar{V}}{2 \pi k h} \theta \quad (\text{F.21})$$

The second term in the RHS, is a radial term, then

$$\theta = \tan^{-1} \left(\frac{y}{x} \right) \quad (\text{F.22})$$

Equation F.21, becomes

$$\psi = - \frac{\mu \bar{V} q_o}{k h y_{pf}} y - \frac{q \mu \bar{V}}{2 \pi k h} \tan^{-1} \left(\frac{y}{x} \right) \quad (\text{F.23})$$

Injection Period

The streamline of an injection well affected by drift, is given by Eq. F.23.

Multiplying Eq. F.23 by $\frac{2 \pi k h}{\mu \bar{V} q_o}$,

$$\frac{2 \pi k h \psi}{\mu \bar{V} q_o} = - \frac{2 \pi}{y_{pf}} y - \frac{q}{q_o} \tan^{-1} \left(\frac{y}{x} \right) \quad (\text{F.24})$$

Defining the following dimensionless groups,

$$\psi_D = \frac{2 \pi k h}{\mu \bar{V} q_o} \psi \quad (F.25)$$

$$x_D = \frac{2 \pi}{y_{pf}} x \quad (F.26)$$

$$y_D = \frac{2 \pi}{y_{pf}} y \quad (F.27)$$

$$q_D = \frac{q}{q_o} \quad (F.28)$$

Substituting Eqs. F.25, F.26, F.27 and F.28 into Eq. F.24, the following dimensionless expression is obtained,

$$\psi_D = -y_D - q_D \tan^{-1} \left(\frac{y_D}{x_D} \right) \quad (F.29)$$

solving for x_D

$$x_D = -y_D \cot \left(\frac{\psi_D + y_D}{q_D} \right) \quad (F.30)$$

According to Abbaszadeh and Brigham (1982), in general the length of the mixing zone could be obtained as

$$\sigma^2 = 2 \alpha v(\bar{s})^2 \int_0^{\bar{s}} \frac{ds}{v(s)^2} \quad (F.31)$$

to evaluate the integral, the following substitutions are made,

$$ds = \sqrt{(dx)^2 + (dy)^2} = dy \sqrt{\left(\frac{dx}{dy}\right)^2 + 1} \quad (F.32)$$

$$v^2 = v_x^2 + v_y^2 \quad (F.33)$$

$$\frac{dx}{dy} = \frac{v_x}{v_y} \quad (F.34)$$

Using these expressions the line integral in Eq. F.31 becomes

$$I = \int_0^{\bar{s}} \frac{ds}{v^2(s)} = \int_0^{\bar{y}} \frac{dy}{v_y \sqrt{v_x^2 + v_y^2}} \quad (F.35)$$

Using Darcy's law and Cauchy-Riemann relationships, the velocities can be expressed as

$$v_x = - \frac{k}{\mu \phi S_w \bar{V}} \frac{\partial \psi}{\partial y} \Big|_y = y(\psi, x) \quad (F.36)$$

$$v_y = \frac{k}{\mu \phi S_w \bar{V}} \frac{\partial \psi}{\partial x} \Big|_x = x(\psi, y) \quad (F.37)$$

Using the dimensionless definitions and the chain rule

$$\frac{\partial \psi}{\partial y} = \frac{q_o \mu \bar{V}}{k h y_{pf}} \frac{\partial \psi_D}{\partial y_D} \quad (F.38)$$

Substituting in the velocity equation (F.36), and rearranging

$$v_x = - \frac{q_o}{\phi h S_w y_{pf}} \frac{\partial \psi_D}{\partial y_D} \quad (F.39)$$

Defining the dimensionless velocity as

$$v_{x_D} = \frac{\phi h S_w y_{pf}}{q_o} v_x \quad (F.40)$$

then,

$$v_{x_D} = - \frac{\partial \psi_D}{\partial y_D} \Big|_{y_D = y_D(\psi_D, x_D)} \quad (F.41)$$

similarly,

$$v_{y_D} = \frac{\partial \psi_D}{\partial x_D} \Big|_{y_D = y_D(\psi_D, x_D)} \quad (F.42)$$

Modifying the dimensionless streamline, Eq. F.29 and differentiating it with respect to x_D and y_D

$$\frac{\partial \psi_D}{\partial x_D} = - q_D \frac{\partial}{\partial x_D} \left[\cot^{-1} \left(\frac{x_D}{y_D} \right) \right] = \frac{q_D}{1 + \left(\frac{x_D}{y_D} \right)^2} \frac{\partial}{\partial x_D} \left(\frac{x_D}{y_D} \right)$$

$$\text{for } \left[0 < \cot^{-1} \left(\frac{x_D}{y_D} \right) < \pi \right]$$

$$= \frac{q_D y_D}{x_D^2 + y_D^2} \quad (F.43)$$

$$\frac{\partial \psi_D}{\partial y_D} = -1 - q_D \frac{\partial}{\partial y_D} \left[\cot^{-1} \left(\frac{x_D}{y_D} \right) \right] = -1 + \frac{q_D}{1 + \left(\frac{x_D}{y_D} \right)^2} \left(\frac{x_D}{y_D} \right)$$

$$\text{for } \left[0 < \cot^{-1} \left(\frac{x_D}{y_D} \right) < \pi \right]$$

$$= -1 - \frac{q_D x_D}{x_D^2 + y_D^2} \quad (\text{F.44})$$

Substituting in the dimensionless velocity equations,

$$v_{x_D} = 1 + \frac{q_D y_D}{x_D^2 + y_D^2} \quad (\text{F.45})$$

$$v_{y_D} = \frac{q_D y_D}{x_D^2 + y_D^2} \quad (\text{F.46})$$

Now according to the dimensionless definitions given so far, the integral given by Eq. F.35, will be transformed to

$$I = \int_0^{\bar{y}_D} \frac{dy_D}{v_y \sqrt{v_x^2 + v_y^2}}$$

$$= \int_0^{\bar{y}_D} \frac{\frac{y_{pf}}{2\pi} dy_D}{\left(\frac{q_o}{\phi h s_w y_{pf}} \right)^2 \frac{\partial \psi_D}{\partial x_D} \sqrt{\left(-\frac{\partial \psi_D}{\partial y_D} \right)^2 + \left(\frac{\partial \psi_D}{\partial x_D} \right)^2}} \quad (\text{F.47})$$

Substituting Eqs. F.43 and F.44 into Eq. F.47

$$I = \frac{\frac{y_{pf}}{2\pi}}{\left(\frac{q_o}{\phi h S_w y_{pf}}\right)^2} \int_0^{\bar{y}_D} \frac{dy_D}{\frac{q_D y_D}{x_D^2 + y_D^2} \sqrt{\left(1 + \frac{q_D x_D}{x_D^2 + y_D^2}\right)^2 + \left(\frac{q_D y_D}{x_D^2 + y_D^2}\right)^2}} \quad (F.48)$$

Rearranging,

$$I = \frac{y_{pf}}{2\pi} \left(\frac{\phi h S_w y_{pf}}{q_o}\right)^2 \int_0^{\bar{y}_D} \frac{(x_D^2 + y_D^2) dy_D}{q_D y_D \sqrt{(x_D^2 + y_D^2)^2 + 2 q_D x_D (x_D^2 + y_D^2) + q_D^2 (x_D^2 + y_D^2)}} \quad (F.49)$$

Considering Eq. F.30 along a given streamline, and the following trigonometric expressions,

$$\csc^2 a = \cot^2 a + 1 \quad (F.50)$$

$$\csc a = \frac{1}{\sin a} \quad (F.51)$$

$$\sin 2a = 2 \sin a \cos a \quad (F.52)$$

Equation F.49 is transformed to,

$$I = \frac{y_{pf}}{2\pi} \left(\frac{\phi h S_w y_{pf}}{q_o} \right)^2 \cdot$$

$$\int_0^{\bar{y}_D} \frac{y_D^2 dy_D}{q_D \sin^2\left(\frac{\psi_D + y_D}{q_D}\right) \sqrt{y_D^2 - q_D y_D \sin\left[2\left(\frac{\psi_D + y_D}{q_D}\right)\right] + q_D^2 \sin^2\left(\frac{\psi_D + y_D}{q_D}\right)}}$$

(F.53)

To calculate $v(\bar{s})^2$ in terms of the dimensionless variables, first, the dimensionless distance traveled by particle along a specific streamline $\bar{s}_D$ has to be evaluated, and from its components x_D and y_D , the velocity is calculated. Then, approximating Eq. F.32 by increments and using the x and y dimensionless definitions Eqs. F.26 and F.27,

$$\Delta s = \frac{y_{pf}}{2\pi} \sqrt{\Delta x_D^2 + \Delta y_D^2} \quad (F.54)$$

Defining,

$$s_D = \frac{2\pi}{y_{pf}} s \quad (F.55)$$

Then Eq. F.54 can be written as,

$$\Delta s_D = \sqrt{\Delta x_D^2 + \Delta y_D^2} \quad (F.56)$$

and,

$$\bar{s}_D = \sum_{i=1}^n \Delta s_D \quad (\text{F.57})$$

substituting Eqs. F.40 and a similar expression for v_y into F.33, using definitions given by Eq. F.45 and F.46 and rearranging,

$$[v(s_D)]^2 = \left(\frac{q_o}{\phi h S_w y_{pf}} \right)^2 \frac{(\bar{x}_D^2 + q_D)^2 + \bar{y}_D^2}{\bar{x}_D^2 + \bar{y}_D^2} \quad (\text{F.58})$$

defining,

$$\sigma_D^2 = \left(\frac{2 \pi}{y_{pf}} \right) \sigma^2 \quad (\text{F.59})$$

$$\alpha_D = \frac{2 \pi}{y_{pf}} \alpha \quad (\text{F.60})$$

Substituting Eq. F.53 and F.58 into the length of the mixing zone equation (Eq. F.31), and considering definitions given by Eq. F.59 and F.60, the length of the mixing zone is given by,

$$\sigma_D^2 = 2 \alpha_D \frac{(\bar{x}_D + q_D)^2 + y_D^2}{\bar{x}_D^2 + \bar{y}_D^2} \cdot \int_0^{\bar{y}_D} \frac{y_D^2 dy_D}{q_D \sin^2\left(\frac{\psi_D + y_D}{q_D}\right) \sqrt{y_D^2 - q_D y_D \sin\left[2\left(\frac{\psi_D + y_D}{q_D}\right)\right] + q_D^2 \sin^2\left(\frac{\psi_D + y_D}{q_D}\right)}} \quad (\text{F.61})$$

Equation F.61 is the main equation to calculate the length of the dispersion zone in any streamline during injection, except those along the abscissa axis. For the streamlines laying on the axis a special formulation is required.

Along the abscissa axis, for both cases $-x_D$ and x_D the ordinates are $y_D = 0$. Considering Eqs. F.45 and F.29, the dimensionless velocity can be written as,

$$v_{x_D} = 1 + \frac{q_D}{x_D} \cos^2\left(\frac{\psi_D}{q_D}\right) \quad (F.62)$$

According to the previously given definitions, Eq. F.31 can be expressed in dimensionless form as,

$$\sigma_D^2 = 2 \alpha_D v_D^2(\bar{s}_D) \int_0^{\bar{s}_D} \frac{ds_D}{v^2(s_D)} \quad (F.63)$$

Considering that along the abscissas axis Eq. F.56 and the dimensionless version of Eq. F.33 are simplified to:

$$\Delta s_D = \Delta x_D \quad (F.64)$$

$$v_D(s_D) = v_{x_D} \quad (F.65)$$

Substituting Eqs. F.62 and F.64 in F.63, the dimensionless length of the mixing zone for the streamlines lying on the abscissas axis, can be written as,

$$\sigma_{D_1}^2 = 2 \alpha_D v_D^2 (\bar{x}_D)$$

$$\bullet \left\{ \bar{x}_D + \cos^2\left(\frac{\psi_D}{q_D}\right) - \frac{\cos^4\left(\frac{\psi_D}{q_D}\right)}{\bar{x}_D + \cos^2\left(\frac{\psi_D}{q_D}\right)} + 2 \cos^2\left(\frac{\psi_D}{q_D}\right) \ln \left[\frac{\cos^2\left(\frac{\psi_D}{q_D}\right)}{\bar{x}_D + \cos^2\left(\frac{\psi_D}{q_D}\right)} \right] \right\}$$

(F.66)

Shut-In Period

During shut in, every particle in the front will be translated in position according to the velocity of the linear flow without losing the shape of the front.

From the linear flow equation (Eq. F.11),

$$\psi_u = - \frac{\mu \phi S_w \bar{V}}{K} v \bar{y}_1$$

where, $v = \frac{dx}{dt}$, substituting into Eq. F.11, solving for dt and integrating,

$$t_{sh} - t_1 = - \frac{\mu \phi S_w \bar{V} \bar{y}_1}{K \psi_u} (x_{sh} - \bar{x}_1) \quad (F.67)$$

Multiplying both sides by $\frac{2 \pi q_o}{\phi S_w h y_{pf}^2}$ and defining dimensionless time as,

$$t_D = \frac{2 \pi q_o}{\phi h S_w y_{pf}^2} t \quad (F.68)$$

Using the dimensionless definitions F.25, F.26, F.27 and F.68, the following dimensionless equation is obtained.

$$(t_{D_{sh}} - t_{D_i}) = - \frac{y_{D_i}}{\psi_{D_{pf}}} (x_D - \bar{x}_{D_i}) \quad (F.69)$$

where subindex, i , stands for injection and, sh , for shut in. Solving for x_D ,

$$x_{D_{sh}} = \bar{x}_{D_i} - \frac{\psi_{D_{pf}}}{\bar{y}_{D_i}} (t_{D_{sh}} - t_{D_i}) \quad (F.70)$$

but according to Eqs. F.29 and F.28 for $q = 0$ (no injection rate),

$\psi_{D_u} = -\bar{y}_{D_i}$, then

$$\frac{x_{D_{sh}} - \bar{x}_{D_i}}{t_{D_{sh}} - t_{D_i}} = v_D(s_D) = 1 \quad (F.71)$$

In a linear system (drifting flow), the length of the dispersion zone will be calculated according to Eq. 2-10, which in dimensionless form is

$$\sigma_D^2 = 2 \alpha_D v_D t_D \quad (F.72)$$

then, the total combined length of the dispersion zone up to the end of the shut in time, considering Eq. F.71 is given by

$$\sigma_{D_{sh}}^2 = \sigma_{D_i}^2 + 2 \alpha_D t_D \quad (F.73)$$

where $\sigma_{D_i}^2$ is calculated using Eq. F.66. Equation F.73 is the equation required to calculate the length of the dispersion zone at the end of shut in along any streamline.

Production Period

At this point, the coordinates of every particle forming the peak concentration ring at a given distance around the wellbore are known; but due to the distortion of the geometry of flow caused by the drift, the peak concentration in every streamline will be arriving at the well at different time. Taking into account that during production $q < 0$, the arrival time of those particles to the well can be estimated as follows,

$$\text{by definition} \quad dt_D = \frac{dy_D}{v_{y_D}} \quad (F.74)$$

where v_{y_D} is given by Eq. F.42, which in this period is written as

$$v_{y_D} = - \frac{\partial \psi_D}{\partial x_D} \quad (F.75)$$

ψ_D is given by Eq. F.29,

$$\psi_D = -y_D + q_D \tan^{-1}\left(\frac{y_D}{x_D}\right) \quad (\text{F.76})$$

the differences in sign by comparison with to Eqs. F.29 and F.42 is due to production rather than injection.

Differentiating Eq. F.76 with respect to x_D and substituting into Eq. F.75, the dimensionless velocity can be expressed as,

$$v_{y_D} = \frac{q_D y_D}{x_D^2 + y_D^2} \quad (\text{F.77})$$

similarly

$$v_{x_D} = -1 - \frac{q_D x_D}{x_D^2 + y_D^2} \quad (\text{F.78})$$

Substituting Eq. F.77 into Eq. F.74 and integrating, the dimensionless production time is expressed as,

$$t_{D_p} = \bar{y}_{D_{sh}} \cot\left(\frac{\psi_D + \bar{y}_{D_{sh}}}{q_D}\right) - y_D \cot\left(\frac{\psi_D + y_D}{q_D}\right) + q_D \ln \left[\frac{\sin\left(\frac{\psi_D + y_D}{q_D}\right)}{\sin\left(\frac{\psi_D + \bar{y}_{D_{sh}}}{q_D}\right)} \right] \quad (\text{F.79})$$

The length of the dispersion zone during production is obtained as follows

$$\sigma_{D_p}^2 = \sigma_{D_{sh}}^2 + 2 \alpha_D v_D^2(\bar{s}_D) \int_{\bar{s}_{D_{sh}}}^{\bar{s}_{D_p}} \frac{ds_D}{v_D^2(s_D)} \quad (F.80)$$

where $\sigma_{D_{sh}}^2$ is given by Eq. F.73. The second summand in the RHS is transformed in a similar way to the one used to obtain the length of the dispersion zone in the injection case. Considering the limits of integration and that during production $q_D < 0$, thus

$$\sigma_{D_p}^2 = \sigma_{D_{sh}}^2 + 2 \alpha_D \frac{(x_D + q_D)^2 + y_D^2}{x_D^2 + y_D^2} \cdot$$

$$\int_{\bar{y}_{D_{sh}}}^{\bar{y}_{D_p}} \frac{y_D^2 dy_D}{q_D \sin^2\left(\frac{\psi_D + y_D}{q_D}\right) \sqrt{y_D^2 + q_D y_D \sin\left[2\left(\frac{\psi_D + y_D}{q_D}\right)\right] + q_D^2 \sin^2\left(\frac{\psi_D + y_D}{q_D}\right)}} \quad (F.81)$$

Equation F.81 is the equation to apply in order to calculate the length of the dispersion zone along any production streamline, except for those laying on the abscissa axis; for those streamlines, the following modified equations are required, since in this case $y_D = 0$,

$$t_{D_p} = x_{D_{sh}} - x_D + q_D \cos^2\left(\frac{\psi_D}{q_D}\right) \ln \left[\frac{x_D + q_D \cos^2\left(\frac{\psi_D}{q_D}\right)}{x_{D_{sh}} + q_D \cos^2\left(\frac{\psi_D}{q_D}\right)} \right] \quad (F.82)$$

The length of the dispersion zone is given by Eq. F.80, but on the

abscissa axis $y_D = 0$. Considering this fact, the length of the dispersion zone for a streamline converging to the well along the abscissa axis is given by:

$$\sigma_{D_p}^2 = \sigma_{D_{sh}}^2 + 2 q_D \frac{(x_D + q_D)^2}{x_D^2} \cos^4\left(\frac{\psi_D}{q_D}\right) \left\{ x_D - x_{D_{sh}} \right. \\ \left. - \frac{q_D^2 \cos^4\left(\frac{\psi_D}{q_D}\right)}{x_D + q_D \cos^2\left(\frac{\psi_D}{q_D}\right)} + \frac{q_D^2 \cos^4\left(\frac{\psi_D}{q_D}\right)}{x_{D_{sh}} + q_D \cos^2\left(\frac{\psi_D}{q_D}\right)} \right. \\ \left. + 2 q_D \cos^2\left(\frac{\psi_D}{q_D}\right) \ln \left[\frac{x_{D_{sh}} + q_D \cos^2\left(\frac{\psi_D}{q_D}\right)}{x_D + q_D \cos^2\left(\frac{\psi_D}{q_D}\right)} \right] \right\} \quad (F.83)$$

This concludes Appendix F. As was mentioned in Section 8, the formulation presented in this appendix represents the skeleton of a drifting system, but in order to apply this formulation to simulate a single well tracer test affected by drift, considerable calculation effort is required. If interested, refer to Section 8 for suggestions on continuation of this work.

APPENDIX G

COMPUTER PROGRAMS

In this appendix are presented the three computer programs developed as part of this work.

The first is the Single Well Tracer Test Simulator Program. This program is the main program and was utilized to construct the residual oil correlation charts. Every point marked with a symbol in the graphs represent a run of the simulator for specific conditions. This program has two output printing options: 1.) printing all the output from a single run on one or more pages, as an example of this printing option see Tables 6.1 and 6.2, and 2.) printing the output of a single run on one line. The second option is used when several runs of the program are required and printing option number one would produce excessive output. The second printing option was used to obtain the information to construct the residual oil correlation charts.

The second program was called ALPHAL and it was used to obtain an estimation of the constant of dispersion (α) and all the additional required information to enter the residual oil correlation charts. The program was mainly utilized to check the charts and the procedure to estimate the residual oil saturation in a linear flow system through the use of these residual oil correlation charts. An example of the use of this program is included in Section 6.4.

The third program was called ALPHAR and it is equivalent to the ALPHAL program with the difference that it was developed to handle radial systems. This program is fed with the required field data and it

provides an estimation of the constant of dispersion (α) of the fluids and all the required information to enter the residual oil correlation charts. An example of the use of this program is included in Section 6.4.

The information required to run each program is included in their respective printouts presented in this appendix.

 * PROGRAM TO SIMULATE A SINGLE WELL TRACER TEST TO DETERMINE THE *
 * RESIDUAL OIL SATURATION IN WATERFLOODED RESERVOIRS. *
 *
 * THIS PROGRAM IS USED TO GENERATE PRODUCTION CONCENTRATION PRO- *
 * FILES FOR THE PRIMARY AND SECONDARY TRACERS AS A FUNCTION OF *
 * A GIVEN RESIDUAL OIL SATURATION. THE RATIO OF THE VOLUME PRO- *
 * DUCED UP TO THE ARRIVAL OF THE TRACERS' PEAK CONCENTRATION TO *
 * THE WELL, THE PARTITIONING COEFFICIENT AND THE GIVEN RESIDUAL *
 * OIL SATURATION FROM MULTIPLE RUNS OF THIS PROGRAM VARYING THE *
 * DATA WERE USED TO CONSTRUCT THE RESIDUAL OIL CORRELATING CHARTS *

STANFORD UNIVERSITY
 PETROLEUM ENGINEERING DEPARTMENT
 STANFORD UNIVERSITY PETROLEUM RESEARCH INSTITUTE

EMILIO URIBE ANTUNEZ

NOVEMBER 1983

NOMENCLATURE:

AAP,BBP,CCP COEFFICIENTS OF THE FITTING ROUTINES -FIT AND FIT2-
 AAS,BBS,CCS COEFFICIENTS OF THE FITTING ROUTINES -FIT AND FIT2-
 ADS DIMENSIONLESS ADSORPTION GROUP
 AEF ARRAY CONTAINING THE COEFFICIENTS OF THE ERROR FUNCTION
 ROUTINE. SEE ABRAMOWITZ & STEGUN.
 ALPHA COEFFICIENT OF DISPERSION, FT
 AP DIMENSIONLESS PARTITIONING COEFFICIENT
 AREAP1 PARTIAL AREA UNDER THE PRIMARY TRACER CONCENTRATION PROFILE
 AREAP2 PARTIAL AREA UNDER THE SECONDARY TRACER CONCENTRAT. PROFILE
 AREAT1 TOTAL AREA UNDER THE PRIMARY TRACER CONCENTRATION PROFILE
 AREAT2 TOTAL AREA UNDER THE SECONDARY TRACER CONCENTRATION PROFILE
 AREA1 TOTAL AREA UNDER THE PRIMARY TRACER CONCENTRATION PROFILE
 AT THE END OF INJECTION
 AREA2 TOTAL AREA UNDER THE PRIMARY TRACER CONCENTRATION PROFILE
 AT THE END OF SHUT IN
 ARG ARGUMENT OF THE COMPLEMENTARY ERROR FUNCTION.
 C CONCENTRATION OF PRIMARY TRACER AT TIME T.
 C2 CONCENTRATION OF PRIMARY TRACER AT TIME T2.
 CFIT DUMMY ARRAY TO HOST THE CONCENTRATION ARRAYS INTO THE
 FITTING ROUTINES -FIT AND FIT2-
 CK DISPERSION COEFFICIENT, FT²/D
 CKR CONSTANT OF REACTION, 1/D
 CMAXP VARIABLE USED TO DETECT THE PEAK CONCENTRATION FOR THE
 PRIMARY TRACER
 CO INITIAL CONCENTRATION INJECTED
 COF FICTITIOUS INITIAL CONCENTRATION, (SEE SECTION 5 FOR
 EXPLANATION ABOUT THE MEANING OF THIS VARIABLE)
 CP CONCENTRATION OF SECONDARY TRACER AT TIME T.
 CPDIS AUXILIARY VARIABLE THAT CONTAINS THE TRANSPORTED AND

C		DISPERSED SECONDARY TRACER FORMED UP TO SHUT IN, DURING
C		PRODUCTION PERIOD CALCULATIONS.
C	CPF1	AUXILIARY VARIABLE THAT CONTAINS THE TRANSPORTED AND
C		DISPERSED FALSE SECONDARY TRACER FORMED UP TO THE END OF
C		INJECTION, DURING PRODUCTION PERIOD CALCULATIONS.
C	CPF2	AUXILIARY VARIABLE THAT CONTAINS THE SECONDARY TRACER
C		FORMED DURING PRODUCTION, WHEN CALCULATIONS ARE CARRIED
C		OUT USING -COF-.
C	CPMAXP	VARIABLE USED TO DETECT THE PEAK CONCENTRATION FOR THE
C		SECONDARY TRACER.
C	CP2	CONCENTRATION OF SECONDARY TRACER AT TIME T2.
C	CPFIT	DUMMY ARRAY TO HOST THE CONCENTRATION ARRAYS INTO THE
C		FITTING ROUTINES -FIT AND FIT2-
C	CPSUPF	FALSE SECONDARY TRACER CONCENTRATION
C	CPSUPP	SECONDARY TRACER CONCENTRATION
C	CPWELL	PRODUCTION SECONDARY TRACER CONCENTRATION
C	CPWELM	VARIABLE USED TO DETECT THE PEAK CONCENTRATION FOR THE
C		SECONDARY TRACER PRODUCTION CONCENTRATION PROFILE.
C	CSUPP	PRIMARY TRACER CONCENTRATION
C	CSUPPI	PRIMARY TRACER CONCENTRATION AT THE END OF INJECTION
C	CWELL	PRODUCTION PRIMARY TRACER CONCENTRATION
C	D	THICKNESS, FT
C	DELTAT	TIME INCREMENT, D
C	DELTAX	INCREMENT IN THE X DIRECTION, FT
C	DX	VARIABLE USE TO EVALUATE THE DECREMENT OF PRIMARY TRACER
C		DURING SHUT IN
C	ERFC	COMPLEMENTARY ERROR FUNCTION VALUE RETURNED BY ROUTINE
C		-ERRFUN-
C	ERRFUN	COMPLEMENTARY ERROR FUNCTION ROUTINE
C	FA	ARGUMENT OF ROUTINE -STHFST- THAT CONTAINS THE NUMERICAL
C		INVERSION ESTIMATION OF THE LAPLACE SPACE SOLUTION FOR THE
C		SECONDARY TRACER.
C	FACTOR	MULTIPLIER TO CONTROL THE MAXIMUM LENGTH OF THE RADIUS OF
C		INVESTIGATION.
C	FIT	ROUTINE TO FIT THE CONCENTRATION PROFILES OBTAINED DURING
C		THE INJECTION AND PSEUDO-INJECTION PERIODS.
C	FIT2	ROUTINE TO FIT THE PRODUCTION CONCENTRATION PROFILES.
C	FLPRD	FLUIDS PRODUCED, BBL
C	IRUN	RUN IDENTIFICATION NUMBER
C	M	CONSTANT TO CONTROL THE CALCULATION OF THE ARGUMENTS OF THE
C		STHFEST ALGORITHM OF INVERSION OF LAPLACE SPACE SOLUTIONS.
C	N	VARIABLE TO CONTROL THE NUMBER OF SUMMANDS TO CONSIDER IN
C		THE STEHFEST ALGORITHM OF INVERSION OF LAPLACE SPACE
C		SOLUTIONS.
C	NDAT	NUMBER OF DATA POINTS TO CONSIDER IN THE CALCULATIONS
C	NOCAL	ERROR INDICATOR FROM ROUTINE -FIT2-
C	NOCALC	ERROR INDICATOR FROM ROUTINE -FIT-
C	PHI	POROSITY, FRAC.
C	Q	RATE, BPD
C	SGMF2	SQUARED LENGTH OF THE DISPERSION ZONE OF THE SEC. TRACER
C	SGMP	PARAMETER FROM THE FITTING ROUTINES -FIT- AND- FIT2-
C	SGMS	PARAMETER FROM THE FITTING ROUTINES -FIT- AND- FIT2-
C	SGMS2	SQUARED LENGTH OF THE DISPERSION ZONE OF THE SECONDARY
C		TRACER FORMED UP TO SHUT IN

C	SGM2FS	SQUARED LENGTH OF THE DISPERSION ZONE OF THE FALSE
C		SECONDARY TRACER
C	SGM2SH	SQUARED LENGTH OF THE DISPERSION ZONE OF THE SECONDARY
C		TRACER FORMED UP TO SHUT IN
C	SOR	RESIDUAL OIL SATURATION, FRAC.
C	STHFST	ROUTINE TO NUMERICALLY INVERT LAPLACE SPACE SOLUTIONS
C	SW	WATER SATURATION, FRAC.
C	T	TIME OF INJECTION OF THE LEADING EDGE, D
C	TP	PRODUCTION TIME, D
C	T2	TIME OF INJECTION OF THE TAILING EDGE, D
C	TSHIN	SHUT IN TIME, D
C	VADS	VELOCITY AFFECTED BY ADSORPTION, FT/D
C	VMB	MATERIAL BALANCE VOLUME, BBL
C	VMB2	INTEGRATION MATERIAL BALANCE VOLUME. BBL
C	VP	TWICE THE PORE VOLUME, CALCULATED USING THE MAXIMUM
C		RADIUS OF INVESTIGATION, BBL
C	VPP	VOLUME PRODUCED UP TO THE BREAKTHROUGH OF THE
C		CONCENTRATION PEAK OF THE PRIMARY TRACER, BBL
C	VPR	RATIO OF VPP/VPS
C	VPS	VOLUME PRODUCED UP TO THE BREAKTHROUGH OF THE
C		CONCENTRATION PEAK OF THE SECONDARY TRACER, BBL
C	VSLUG	VOLUME OF THE SLUG OF CHEMICAL TRACER OF CONCENTRATION
C		-CO-, BBL
C	VTOT	TOTAL VOLUME INJECTED (SLUG + PUSHER), BBL
C	VTSR	RATIO OF VTOT/VPS
C	VX	VELOCITY, FT/D
C	X	DISTANCE, FT
C	XBARFS	DISTANCE FROM THE INLET TO THE PEAK CONCENTRATION OF THE
C		FALSE SECONDARY TRACER, FT
C	XBARP1	DISTANCE FROM THE INLET TO THE 50 % CONCENTRATION OF THE
C		LEADING EDGE, DURING THE PSEUDO-INJECTION PERIOD, FT
C	XBARP2	DISTANCE FROM THE INLET TO THE 50 % CONCENTRATION OF THE
C		TAILING EDGE, DURING THE PSEUDO-INJECTION PERIOD, FT
C	XBARSH	DISTANCE FROM THE INLET TO THE PEAK CONCENTRATION OF THE
C		SECONDARY TRACER FORMED UP TO SHUT IN, FT
C	XBARS	DISTANCE FROM THE INLET TO THE PEAK CONCENTRATION OF THE
C		SECONDARY TRACER, FT
C	XBAR1	DISTANCE FROM THE INLET TO THE 50 % CONCENTRATION OF THE
C		LEADING EDGE, FT
C	XBAR2	DISTANCE FROM THE INLET TO THE 50 % CONCENTRATION OF THE
C		TAILING EDGE, FT
C	XCORP	ACTUAL X COORDINATE POINT CALCULATED ONCE THE BACK
C		CORRECTION HAS BEEN MADE, FOR THE PRIMARY TRACER, FT
C	XCORS	ACTUAL X COORDINATE POINT CALCULATED ONCE THE BACK
C		CORRECTION HAS BEEN MADE, FOR THE SECONDARY TRACER, FT
C	XE	MAXIMUM RATIO OF INVESTIGATION, FT
C	XFIT	DUMMY ARRAY TO HOST THE DISTANCE ARRAYS INTO THE
C		FITTING ROUTINES -FIT AND FIT2-, FT
C	XIPBAS	PIVOT DISTANCE FOR THE PRIMARY TRACER AT THE END OF THE
C		INJECTION/SHUT-IN PERIOD, FT
C	XISBAS	PIVOT DISTANCE FOR THE SECONDARY TRACER AT THE END OF THE
C		INJECTION/SHUT-IN PERIOD, FT
C	XMBFS	DISTANCE COVERED BY MATERIAL BALANCE BY THE FALSE SECONDARY
C		TRACER ASSUMING PISTON LIKE DISPLACEMENT, FT

XMBP **PARAMETER FROM THE FITTING ROUTINES -FIT- AND- FIT2-**
XMBPD **VOLUME PRODUCED OF PRIMARY TRACER BY MATERIAL BALANCE, BBL**
XMBS **PARAMETER FROM THE FITTING ROUTINES -FIT- AND- FIT2-**
XMBSH **DISTANCE COVERED BY MATERIAL BALANCE BY THE SECONDARY**
 TRACER FORMED UP TO SHUT IN ASSUMING PISTON LIKE
 DISPLACEMENT, FT
XPFBAS **LOCATION OF THE PEAK CONCENTRATION OF SECONDARY TRACER**
 (FALSE + ADDITIONAL FORMED DURING PRODUCTION) DURING ANY
 STAGE OF PSEUDO-INJECTION, FT
XPPBAS **LOCATION OF THE PEAK CONCENTRATION OF PRIMARY TRACER**
 DURING ANY STAGE OF PSEUDO-INJECTION, FT
XPSBAS **LOCATION OF THE PEAK CONCENTRATION OF TOTAL SECONDARY**
 TRACER FORMED UP TO ANY STAGE OF PSEUDO-INJECTION, FT
X50P **PARAMETER FROM THE FITTING ROUTINES -FIT- AND- FIT2-**
X50S **PARAMETER FROM THE FITTING ROUTINES -FIT- AND- FIT2-**
W **WIDTH OF THE LINEAR SYSTEM, FT**

INPUT DATA:

TO RUN THE PROGRAM, THE FOLLOWING INFORMATION IS REQUIRED:

```

10 READ(5,200) IRUN,NDAT,NPRT
   READ(5,300) ALPHA,AP,CO,CKR,D,PHI,Q
   READ(5,300) SOR,TSHIN,VSLUG,VTOT,W
  
```

NOTE.-TO STOP READING DATA ASSIGN A VALUE OF NDAT = 0 TO THE LAST INPUT CARD.

THE INFORMATION HAVE TO BE PROVIDED USING THE FOLLOWING FORMATS:

```

200 FORMAT(3I3)
300 FORMAT(7F10.0)
  
```

WHERE:

IRUN **RUN IDENTIFICATION NUMBER**
NDAT **NUMBER OF DATA POINTS TO USE IN THE SIMULATION PROCESS**
NPRT **CONTROL TO CHOOSE:**
 1 - SINGLE RUN PRINTOUT PER PAGE
 2 - MULTIPLE RUNS PRINTOUT PER PAGE

ALPHA **COEFFICIENT OF DISPERSION, FT**
AP **DIMENSIONLESS PARTITIONING COEFFICIENT**
CO **INITIAL CONCENTRATION INJECTED**
CKR **CONSTANT OF REACTION, 1/D**
D **THICKNESS, FT**
PHI **POROSITY, FRAC.**
Q **RATE, BPD**

SOR **RESIDUAL OIL SATURATION, FRAC.**
TSHIN **SHUT IN TIME, D**
VSLUG **VOLUME OF THE SLUG OF CHEMICAL TRACER OF CONCENTRATION**
 -CO-, BBL

```

C      VTOT      TOTAL VOLUME INJECTED (SLUG + PUSHER), BBL
C      W          WIDTH OF THE LINEAR SYSTEM, FT
C      *****
C
      IMPLICIT REAL*8 (A-H,O-Z)
      DIMENSION AEF(6),X(101),C(100),C2(100),CP(100),CP2(100),
*      CSUPP(100),CPSUPP(100),CSUPPI(100),CPSUPF(100),
*      CFIT(100),CPFIT(100),XFIT(100),
*      CWELL(50),CPWELL(50),FLPRD(50),AREAP1(50),AREAP2(50)
      COMMON /BLKSFT/ADS,AP,CK,CKR,DLOGTH,M,N,PI,SW,VX
      COMMON /BLKF/AAP,BBP,CCP,AAS,BBS,CCS,X50P,SGMP,XMBP,X50S,SGMS,XMBS
      COMMON /BLKSF2/G(25),H(25),V(25)
      COMMON /BLKFT/NOCALC
      COMMON /BLKFT2/GAMMA,VP,VSLUG,CO,VTOT,DX,VPP,VPS,NOCAL,NH
      DLOGTH = .69314718056
      KPRT = 0
      PI = 3.141592654
      M = 27
      N = 16

C
C      INPUT DATA
C
10  READ(5,200)IRUN,NDAT,NPRT
    IF(NDAT.EQ.0)GO TO 195
    READ(5,300)ALPHA,AP,CO,CKR,D,PHI,Q
    READ(5,300)SOR,TSHIN,VSLUG,VTOT,W

C
    IF(NPRT.EQ.1.OR.KPRT.GT.0)GO TO 12
    KPRT = KPRT+1
    WRITE(6,7000)
12  SW = 1.-SOR
    ADS = SW + AP*(1-SW)
    ADS = SW/ADS
    IF(AP.GT.10)GO TO 10
    FACTOR = 1.
    GAMMA = W*D*PHI*SW
    VX = 5.615*Q/GAMMA
    CK = ALPHA*DABS(VX)
    T = VTOT/Q
    T2 = (VTOT-VSLUG)/Q
    Q = 5.615*Q
    VADS = VX*ADS
15  XE = (4./SW)*VADS*T*DSQRT(ALPHA)*FACTOR
    DELTAX = XE/DFLOAT(NDAT)
    DO 20 JX = 1,NDAT
20  X(JX) = DFLOAT(JX)*DELTAX
    DIFP1 = 0
    DIFP2 = 0

C
C      INJECTION PERIOD CALCULATIONS
C
    XBAR1 = VADS*T
    XBAR2 = VADS*T2
    SIGM = CK*ADS

```

```

    SIGM1 = DSQRT(4.*T*SIGM)
    SIGM2 = DSQRT(4.*T2*SIGM)
    DO 30 I=1,NDAT
        C(I) = 0.
        C2(I) = 0.
        CP(I) = 0.
        CP2(I) = 0.
        CSUPP(I) = 0.
        CSUPPI(I) = 0.
        CPSUPF(I) = 0.
        CPSUPP(I) = 0.
30    CMAX = 0.
    CPMAX = 0.
    CPMINA = 1.
    INDI1 = 1.
    DO 60 JX = 1,NDAT
        N = 16
        TA = T2
        CALL STHFST(X(JX),TA,FA)
        CP2(JX) = CKR*CO*FA
        IF(CP2(JX).LT.0.) CP2(JX) = 0.
        TA = T
        CALL STHFST(X(JX),TA,FA)
        CP(JX) = CKR*CO*FA
        IF(CP(JX).LT.0.) CP(JX) = 0.
        CPSUPF(JX) = CP(JX)-CP2(JX)
        IF(CPSUPF(JX).LT.0.) CPSUPF(JX) = 0.
        ARG = (X(JX)-XBAR2)/SIGM2
        CALL ERRFUN(ARG,ERFC)
        C2(JX) = CO*DEXP(-CKR*X(JX)/VADS)*ERFC/2.
        IF(C2(JX).LT.0.) C2(JX) = 0.
        ARG = (X(JX)-XBAR1)/SIGM1
        CALL ERRFUN(ARG,ERFC)
        C(JX) = CO*DEXP(-CKR*X(JX)/VADS)*ERFC/2.
        IF(C(JX).LT.0.) C(JX) = 0.
        CSUPPI(JX) = C(JX)-C2(JX)
        CC1 = C(JX)
        CC2 = C2(JX)
        CCEXP = DEXP(-CKR*TSHIN)
        C(JX) = C(JX)*CCEXP
        C2(JX) = C2(JX)*CCEXP
        CC1SH = CC1 - C(JX)
        CC2SH = CC2 - C2(JX)
        CP(JX) = CP(JX) + CC1SH
        CP2(JX) = CP2(JX) + CC2SH
        CSUPP(JX) = C(JX) - C2(JX)
        IF(CSUPP(JX).LT.0.) CSUPP(JX) = 0.
        CPSUPP(JX) = CP(JX) - CP2(JX)
        IF(CPSUPP(JX).LT.0.) CPSUPP(JX) = 0.
        IF(CSUPP(JX).GT.CMAX) GO TO 40
        GO TO 50
40    CMAX = CSUPP(JX)
    INDI1 = JX
50    IF(CPSUPP(JX).GT.CPMAX) CPMAX = CPSUPP(JX)

```

```

        IF(JX.GT.1.) CPMINA = CPSUPP(JX-1)
        IF(CMAX.GT.CO/10.AND.CPMAX.GT.CPSUPP(JX).AND.CPMINA.LT.
*      CPSUPP(JX)) GO TO 55
        GO TO 60
55      CPSUPP(JX) = 0.
        GO TO 65
60 CONTINUE

C
C      CALCULATING THE DECREMENT IN PRIMARY TRACER DUE TO REACTION; WHICH
C      HAS TO BE TAKEN INTO ACCOUNT FOR MATERIAL BALANCE VERIFICATION.
C
65 IF(INDI1.LT.6) GO TO 66
    GO TO 67
66 FACTOR = FACTOR*0.75
    GO TO 15
67 AREA1 = 0.
    AREA2 = 0.
    DO 70 I = 2,NDAT
        AREA1 = AREA1+(X(I)-X(I-1))*(CSUPPI(I-1)+CSUPPI(I))/2.
70  AREA2 = AREA2+(X(I)-X(I-1))*(CSUPP(I-1)+CSUPP(I))/2.
    DX = AREA1-AREA2
    CONC1 = CO
    IF(TSHIN.EQ.0.) GO TO 80

C
C      CALCULATING THE FICTITIOUS CONCENTRATION FOR THE PRIMARY TRACER
C
    ARG = (X(INDI1)-XBAR1)/SIGM1
    CALL ERRFUN(ARG,ERFC)
    CONC1 = C(INDI1)/(DEXP(-CKR*X(INDI1)/VADS)*ERFC/2.)

C
C      CALCULATING THE PIVOTS AT THE END OF THE INJECTION/SHUT IN PERIODS
C
80 XIPBAS = (XBAR1+XBAR2)/2.
    VP = 2*XIPBAS*GAMMA
    CALL FIT(X,CPSUPP,CSUPP,NDAT,1,1)
    IF(NOCALC.EQ.1)GO TO 10
    XISBAS = X50P

C
C      FITTING THE SEC. TRACER DATA @ END OF SHUT IN PERIOD AND THE DATA
C      FOR THE FALSE SEC. TRACER. THE FITTED CURVES NEGLECT REACTION.
C
    DO 90 I = 1,NDAT
90  CPSUPF(I) = CONC1*CPSUPF(I)/CO
    CALL FIT(X,CPSUPF,CPSUPP,NDAT,0,0)
    IF(NOCALC.EQ.1)GO TO 10
    SGM2FS = SGMP*SGMP
    XBARFS = X50P
    XMBFS = XMBP
    SGM2SH = SGMS*SGMS
    XBARSH = X50S
    XMBSH = XMBS

C
C      PRODUCTION PERIOD CALCULATIONS
C

```

```

IPEAKS = 0
CPWELM = 0.
DELTAT = T/20.
DO 160 MX = 1,50
    TP = DFLOAT(MX)*DELTAT
    XE = (4./SW)*VADS*(T+TP)*DSQRT(ALPHA)*FACTOR
    DELTAX = XE/DFLOAT(NDAT)
    DO 100 I=1,NDAT
        X(I) = DFLOAT(I)*DELTAX
        C(I) = 0.
        C2(I) = 0.
        CP(I) = 0.
        CP2(I) = 0.
        CSUPP(I) = 0.
100    CPSUPP(I) = 0.
    CMAXP = 0.
    CPMAXP = 0.
    CPMINA = 1.
    XBARP1 = VADS*(T+TP)
    XBARP2 = VADS*(T2+TP)
    SIGMP1 = DSQRT(4.*(T+TP)*SIGM)
    SIGMP2 = DSQRT(4.*(T2+TP)*SIGM)
    SGMF2 = SGM2FS+2.*ALPHA*VX*TP
    SGMS2 = SGM2SH+2.*ALPHA*VX*TP
    DO 120 JX = 1,NDAT
        N = 16
        TA = T2+TP
        CALL STHFST(X(JX),TA,FA)
        CP2(JX) = CKR*CONC1*FA
        IF(CP2(JX).LT.0.) CP2(JX) = 0.
        TA = T+TP
        CALL STHFST(X(JX),TA,FA)
        CP(JX) = CKR*CONC1*FA
        IF(CP(JX).LT.0.) CP(JX) = 0.
        ARG = (X(JX)-XBARP2)/SIGMP2
        CALL ERRFUN(ARG,ERFC)
        C2(JX) = CONC1*DEXP(-CKR*X(JX)/VADS)*ERFC/2.
        IF(C2(JX).LT.0.) C2(JX) = 0.
        ARG = (X(JX)-XBARP1)/SIGMP1
        CALL ERRFUN(ARG,ERFC)
        C(JX) = CONC1*DEXP(-CKR*X(JX)/VADS)*ERFC/2.
        IF(C(JX).LT.0.) C(JX) = 0.
        CSUPP(JX) = C(JX) - C2(JX)
        IF(CSUPP(JX).LT.0.) CSUPP(JX) = 0.
        CPSUPP(JX) = CP(JX) - CP2(JX)
        IF(CPSUPP(JX).LT.0.) CPSUPP(JX) = 0.
        IF(CSUPP(JX).GT.CMAXP) CMAXP = CSUPP(JX)
        IF(CPSUPP(JX).GT.CPMAXP) GO TO 102
        GO TO 104
102    CPMAXP = CPSUPP(JX)
        INDP2 = JX
104    IF(JX.GT.1) CPMINA = CPSUPP(JX-1)
        IF(CMAXP.GT.CONC1/10.0.AND.CPMAXP.GT.CPSUPP(JX).AND.
*       CPMINA.LT.CPSUPP(JX)) GO TO 110

```

```

      GOTO 120
110      CPSUPP(JX) = 0.
      GO TO 125
120      CONTINUE
C
C      CALCULATING THE LOCATION OF THE PEAK CONCENTRATIONS DURING
C      THE PSEUDO-INJECTION PERIOD (PRODUCTION).
C
125      XPPBAS = (XBARP1+XBARP2)/2.
      CALL FIT(X,CPSUPP,CSUPP,NDAT,1,1)
      IF(NOCALC.EQ.1)GO TO 10
      XPFBAS = X50P
C
C      FITTING THE SECONDARY TRACER TO SUBTRACT THE FALSE SECONDARY
C      TRACER AND DEFINE THE INCREMENT IN SECONDARY TRACER FORMED
C      DURING PRODUCTION.
C
      CPMAXP= 0.
      CPMINA= 1.
      XBARF = XPFBAS
      XBARSH = XBARSH+(XPFBAS-XBARFS)
      DO 140 I = 1,NDAT
        CPF2 = DEXP(AAP+BBP*X(I)+CCP*X(I)*X(I))
        CPF1 = XMBFS/DSQRT(2.*PI*SGMF2)*DEXP(-(X(I)-XBARF)**2/
*          (2.*SGMF2))
        CPDIS= XMBSH/DSQRT(2.*PI*SGMS2)*DEXP(-(X(I)-XBARSH)**2/
*          (2.*SGMS2))
        CPSUPP(I) = CPDIS+(CPF2-CPF1)
        IF(CPSUPP(I).LT.0.) CPSUPP(I) = 0.
        IF(CPSUPP(I).GT.CPMAXP) CPMAXP = CPSUPP(I)
        IF(I.GT.1) CPMINA = CPSUPP(I-1)
        IF(I.GT.INDP2.AND.CPMAXP.GT.CPSUPP(I).AND.CPMINA.LT.
*          CPSUPP(I)) GO TO 130
        GO TO 140
130      CPSUPP(I) = 0.
        GO TO 150
140      CONTINUE
150      CALL FIT(X,CSUPP,CPSUPP,NDAT,0,1)
      IF(NOCALC.EQ.1)GO TO 10
      XPSBAS = X50S
C
C      BACK CORRECTING THE PRIMARY AND SECONDARY TRACERS AND CALCULATING
C      THEIR PRODUCTION CONCENTRATION PROFILE.
C
      DIFP1 = XPPBAS-XIPBAS
      DIFP2 = XPSBAS-XISBAS
      XCORP = 2.*DIFP1
      XCORS = 2.*DIFP2
      ARG = (XCORP-XBARP2)/SIGMP2
      CALL ERRFUN(ARG,ERFC)
      CW2 = CONC1*DEXP(-CKR*XCORP/VADS)*ERFC/2.
      IF(CW2.LT.0.) CW2 = 0.
      ARG = (XCORP-XBARP1)/SIGMP1
      CALL ERRFUN(ARG,ERFC)

```

```

      CW1 = CONC1*DEXP(-CKR*XCORP/VADS)*ERFC/2.
      IF(CW1.LT.0.) CW1 = 0.
      CWELL(MX) = CW1 - CW2
      IF(CWELL(MX).LT.0.) CWELL(MX) = 0.
      CPWELL(MX) = DEXP(AAS+BBS*XCORS+CCS*XCORS*XCORS)
      IF(CPWELL(MX).LT.0.) CPWELL(MX) = 0.
      FLPRD(MX) = TP*Q/5.615
      IF(MX.EQ.1) GO TO 160
      IF(CPWELL(MX).GT.CPWELM) GO TO 155
      GO TO 156
155  CPWELM = CPWELL(MX)
      IPEAKS = MX
156  IF(CPWELL(MX).GT.CPWELL(MX-1).AND.CPWELM.GT.CPWELL(MX))
      *    CPWELL(MX) = 0.
      IF(CWELL(MX).LT.CWELL(MX-1).AND.CWELL(MX).LT.0.001) GO TO 165
160  CONTINUE
165  IF(MX.GT.50) MX = 50
      NFIT2 = 2*IPEAKS
      IF(NFIT2.GT.MX) NFIT2 = MX
      CALL FIT2(FLPRD,CWELL,CPWELL,IRUN,MX,NFIT2)
      IF(NOCAL.EQ.1) GO TO 10
      XMBPD = XMBP

```

C
C
C

INTEGRATING THE AREAS UNDER THE PRODUCTION PROFILES

```

      INTLB1 = 0
      INTLB2 = 0
      DO 170 I = 1,MX
        AREAP1(I) = 0.
170  AREAP2(I) = 0.
175  AREA1 = 0.
      DO 180 I = 2,MX
        AREA1 = AREA1+(FLPRD(I)-FLPRD(I-1))*(CWELL(I-1)+CWELL(I))/2.
        IF(INTLB1.EQ.0) GO TO 180
        AREAP1(I) = AREA1/AREAT1*100.
180  CONTINUE
      AREAT1 = AREA1
      INTLB1 = INTLB1+1
      AREA2 = 0.
      DO 190 I = 2,MX
        AREA2 = AREA2+(FLPRD(I)-FLPRD(I-1))*(CPWELL(I-1)+CPWELL(I))/2.
        IF(INTLB2.EQ.0) GO TO 190
        AREAP2(I) = AREA2/AREAT2*100.
190  CONTINUE
      AREAT2 = AREA2
      INTLB2 = INTLB2+1
      IF(INTLB2.EQ.1) GO TO 175

```

C
C
C

PRINTING THE PROGRAM OUTPUT

```

      VMB2 = (XMBPD*ADS+DX)*GAMMA/(5.615*CO*ADS)
      Q = Q/5.615
      VMB = VTOT - VSLUG/2.
      VTSR = VTOT/VSLUG

```



```

VPR = VPP/VPS
IF(NPRT.EQ.1) GO TO 192
WRITE(6,8000)IRUN,W,D,PHI,SOR,AP,CO,Q,VSLUG,VTOT,
*          VPP,VPS,VMB,CKR,TSHIN,ALPHA,NN,ADS,VTSR,VPR
GO TO 10
192 WRITE(6,2000)
WRITE(6,3000)IRUN,CO,VSLUG,VTOT,XIPBAS,ALPHA,CKR,AP,TSHIN,Q,Q
WRITE(6,4000)PHI,D,W,SW,VSLUG,VMB2
WRITE(6,5000)
WRITE(6,6000)(JX,FLPRD(JX),CWEILL(JX),CPWEILL(JX),AREAP1(JX),
*          AREAP2(JX),JX = 1,MX)
GO TO 10
195 WRITE(6,400)

C
C   FORMATS
C
200 FORMAT(3I3)
300 FORMAT(7F10.0)
400 FORMAT(1H1)
2000 FORMAT(1H1,45X,'SIMULATION OF THE SINGLE WELL TRACER TEST',/,
*          48X,'DEPARTMENT OF PETROLEUM ENGINEERING',/,
*          56X,'STANFORD UNIVERSITY',//)
3000 FORMAT(5X,'RUN No.',13,/,5X,'DATA :',/,5X,128('-'),/,5X,
*          'INJECTED CONC. PRIMARY TRACER TOTAL VOL. MAX. RADIUS ',
*          'OF DISPERSION CONSTANT OF EQUILIBRIUM SHUT IN ',
*          'INJECTION PRODUCTION',/,5X,' X Vol. SLUG, bbl',
*          ' INJEC.,bbl INVESTIG.,feet CONST,feet REACTION 1/',
*          'D CONSTANT TIME, D RATE, BPD RATE, BPD',/,5X,
*          128('-'),/,11X,F3.1,11X,F6.1,8X,F6.1,9X,F5.1,10X,F4.2,
*          7X,F6.4,6X,F7.3,6X,F4.1,7X,F5.1,6X,F5.1,/,5X,128('-'),//)
4000 FORMAT(73X,'MATERIAL BALANCE CHECK : ( Slug of concentr.',
*          /,18X,'RESERVOIR CHARACTERISTICS :',
*          28X,'Co of undiluted, undispersed primary tracer )',
*          /,18X,48('-'),7X,45('-'),/,18X,'POROSITY THICKNESS',
*          ' WIDTH WATER SATURATION VOLUME INJECTED ',
*          ' VOLUME CALCULATED @ END',/,19X,'ifraction feet ',
*          'feet fraction bbl OF',
*          ' SIMULATION, bbl',/,18X,48('-'),7X,45('-'),/,21X,F4.2,
*          6X,F4.1,5X,F5.1,8X,F4.2,19X,F9.3,16X,F9.3,/,18X,48('-'),7X,
*          45('-'),//)
5000 FORMAT(18X,'CALCULATED PRODUCTION PROFILES :',/,18X,100('-'),/,
*          23X,'FLUIDS PRODUCED PRIMARY TRACER SECONDARY TRACER',
*          ' PRIMARY CUMULATIVE SECONDARY CUMULATIVE',/,
*          29X,'bbl CONCENT.,X Vol CONCENT., X Vol ',
*          'CONCENTRATION, X CONCENTRATION, X',/,18X,100('-'),/)
6000 FORMAT(19X,I2,4X,F9.2,10X,F8.6,10X,F8.6,11X,F8.4,14X,F8.4)
7000 FORMAT(1H1,' Run W H Phi Sor a Co Q',
*          ' Vslug Vtot Vpp Vps Vmb kr tsh ',
*          'Alpha NN ADS Vtot/Vslug Vpp/Vps',//)
8000 FORMAT(I6,F6.1,F5.1,2F5.2,F7.3,F4.1,2F6.1,4F7.1,F7.4,
*          F5.1,F5.2,2X,I2,3X,F7.3,2F9.3)
STOP
END

```

C

```

C      SUBROUTINE ERRFUN(ARG,ERFC)
C      *****
C      COMPLEMENTARY ERROR FUNCTION ROUTINE
C      *****
C      REF.: ABRAMOWITZ, M. AND STEGUN, J.A.: HANDBOOK OF MATHEMATICAL
C      FUNCTIONS. DOVER PUB., INC., NEW YORK, FIRST ED., 9TH
C      PRINTING, 1970, P. 229, EQ. 7.1.26.
C
C      IMPLICIT REAL*8 (A-H,O-Z)
C      DIMENSION AEF(6)
C      DATA AEF/0.254829592,-0.284496736,1.421413741,
C      *      -1.453152027,1.061405429,0.3275911/
C      IF(ARG.GT.12.0)GO TO 20
C      IF(ARG.LT.-12.0)GO TO 30
C      P = 1./(1.+AEF(6)*DABS(ARG))
C      SUMAX = 0.
C      DO 10 JEF = 1,5
10      SUMAX = SUMAX+AEF(JEF)*P**JEF
C      ARG2 = ARG*ARG
C      IF(ARG2.GT.88.) GO TO 20
C      ERFC = SUMAX*DEXP(-ARG2)
C      IF(ERFC.LE.1E-20) ERFC = 0.
C      IF(ARG.GT.0.) GO TO 40
C      ERFC = 2.-ERFC
C      GO TO 40
20      ERFC = 0.
C      GO TO 40
30      ERFC = 2.
40      RETURN
C      END
C
C      SUBROUTINE STHFST(X,TA,FA)
C      *****
C      STEHFEST ALGORITHM FOR NUMERICAL INVERSION OF LAPLACE TRANSFORMS
C      *****
C
C      STEHFEST, H.: "NUMERICAL INVERSION OF LAPLACE TRANSFORMS",
C      ALGORITHM 368, COMMUNICATIONS OF THE ACM, (JAN, 1970),
C      VOL 3, No. 1, PP 47-49. ERRATA, (OCT, 1970), VOL 13,
C      No. 10, PP. 624.
C
C      IMPLICIT REAL*8 (A-H,O-Z)
C      COMMON /BLKSFT/ADS,AP,CK,CKR,DLOGTH,M,N,PI,SW,VX
C      COMMON /BLKSF2/G(25),H(25),V(25)
C      IF(M.EQ.N) GO TO 80
C
C      CALCULATE V ARRAY
C
C      M = N
C      G(1) = 1.
C      NH = N/2.
C      DO 10 I = 2,N

```

```

10   G(I) = G(I-1)*DFLOAT(I)
    H(1) = 2./G(NH-1)
    DO 30 I = 2,NH
        FI = DFLOAT(I)
        IF(I.EQ.NH) GO TO 20
        H(I) = FI*NH*G(2*I)/(G(NH-I)*G(I)*G(I-1))
        GO TO 30
20   H(I) = FI*NH*G(2*I)/(G(I)*G(I-1))
30  CONTINUE
    SN = 2.*(NH-NH/2.*2.)-1.
    DO 70 I = 1,N
        V(I) = 0.
        K1 = (I+1)/2.
        K2 = I
        IF(K2.GT.NH) K2 = NH
        DO 60 K = K1,K2
            KK = 2*K-I
            IF(KK.EQ.0) GO TO 40
            IF(I.EQ.K) GO TO 50
            V(I) = V(I)+H(K)/(G(I-K)*G(2*K-I))
            GO TO 60
40   V(I) = V(I)+H(K)/G(I-K)
            GO TO 60
50   V(I) = V(I)+H(K)/G(KK)
60   CONTINUE
        V(I) = SN*V(I)
        SN = -SN
70  CONTINUE
80  FA = 0.
    A = DLOGTH/TA
    CPC = VX*X/(2.*CK)
    DO 90 I = 1,N
        ARG = DFLOAT(I)*A
        S1 = CPC-X*DSQRT(VX*VX+4.*CK*ARG)/(2.*CK)
        IF(DABS(S1).GT.88.) S1 = S1*88./DABS(S1)
        S1 = DEXP(S1)
        S2 = CPC-X*DSQRT(VX*VX+4.*CK*(CKR+ARG)/ADS)/(2.*CK)
        IF(DABS(S2).GT.88.) S2 = S2*88./DABS(S2)
        S2 = DEXP(S2)
        S3 = ARG*(ARG*(1.+ADS)+CKR)
        P = (S1-S2)/S3
        FA = FA+V(I)*P
90  CONTINUE
    FA = A*FA
    RETURN
    END

```

C

SUBROUTINE FIT(XFIT,CFIT,CPFIT,NFIT,KBYPAS,KCKR)

C

C

LEAST SQUARES FITTING ROUTINE FOR THE EQUATION: $LN C = A + BX + CX^2$

C

C

IMPLICIT REAL*8 (A-H,O-Z)

DIMENSION XFIT(NFIT),CFIT(NFIT),CPFIT(NFIT)

```

COMMON /BLKF/AAP,BBP,CCP,AAS,BBS,CCS,X50P,SGMP,XMBP,X50S,SGMS,XMBS
COMMON /BLKSFT/ADS,AP,CK,CKR,DLOGTH,M,N,PI,SW,VX
COMMON /BLKFT/NOCALC
NOCALC = 0
SC = 0
SCX = 0
SCX2 = 0
SCX3 = 0
SCX4 = 0
SCLNC = 0
SCXLNC = 0
SCX2LN = 0
DO 10 I = 1,NFIT
  IF(CFIT(I).EQ.0.) GO TO 10
  SC = SC+CFIT(I)
  SCX = SCX+CFIT(I)*XFIT(I)
  SCX2 = SCX2+CFIT(I)*XFIT(I)*XFIT(I)
  SCX3 = SCX3+CFIT(I)*XFIT(I)*XFIT(I)*XFIT(I)
  SCX4 = SCX4+CFIT(I)*XFIT(I)*XFIT(I)*XFIT(I)*XFIT(I)
  SCLNC = SCLNC+CFIT(I)*DLOG(CFIT(I))
  SCXLNC = SCXLNC+CFIT(I)*XFIT(I)*DLOG(CFIT(I))
  SCX2LN = SCX2LN+CFIT(I)*XFIT(I)*XFIT(I)*DLOG(CFIT(I))
10 CONTINUE
  CCNUM2 = SCLNC*SCX2/SC
  CCNUM3 = (SCXLNC-SCLNC*SCX/SC)*(SCX3-SCX*SCX2/SC)/
  * (SCX2-SCX*SCX/SC)
  DEN2 = SCX2*SCX2/SC
  DEN3 = (SCX3-SCX2*SCX/SC)*(SCX3-SCX*SCX2/SC)/(SCX2-SCX*SCX/SC)
  CCP = (SCX2LN-CCNUM2-CCNUM3)/(SCX4-DEN2-DEN3)
  BBP = (SCXLNC-SCLNC*SCX/SC-CCP*(SCX3-SCX2*SCX/SC))/
  * (SCX2-SCX*SCX/SC)
  AAP = (SCLNC-BBP*SCX-CCP*SCX2)/SC
  SGM2P = -1./(2.*CCP)
  IF(SGM2P.LT.0) GO TO 12
  GO TO 14
12 NOCALC = 1
  GO TO 30
14 SGMP = DSQRT(SGM2P)
  X50P = SGM2P*(BBP+DFLOAT(KCKR)*CKR/(VX*ADS))
  XMBP = DSQRT(2.*PI*SGM2P)*DEXP(X50P*X50P/(2.*SGM2P)+AAP)/ADS
  IF(KBYPAS.EQ.1) GO TO 30
  SC = 0
  SCX = 0
  SCX2 = 0
  SCX3 = 0
  SCX4 = 0
  SCLNC = 0
  SCXLNC = 0
  SCX2LN = 0
  DO 20 I = 1,NFIT
    IF(CPFIT(I).EQ.0.) GO TO 20
    SC = SC+CPFIT(I)
    SCX = SCX+CPFIT(I)*XFIT(I)
    SCX2 = SCX2+CPFIT(I)*XFIT(I)*XFIT(I)

```

```

        SCX3 = SCX3+CPFIT(I)*XFIT(I)*XFIT(I)*XFIT(I)
        SCX4 = SCX4+CPFIT(I)*XFIT(I)*XFIT(I)*XFIT(I)*XFIT(I)
        SCLNC = SCLNC+CPFIT(I)*DLOG(CPFIT(I))
        SCXLNC = SCXLNC+CPFIT(I)*XFIT(I)*DLOG(CPFIT(I))
        SCX2LN = SCX2LN+CPFIT(I)*XFIT(I)*XFIT(I)*DLOG(CPFIT(I))
20  CONTINUE
        CCNUM2 = SCLNC*SCX2/SC
        CCNUM3 = (SCXLNC-SCLNC*SCX/SC)*(SCX3-SCX*SCX2/SC)/
        *      (SCX2-SCX*SCX/SC)
        DEN2 = SCX2*SCX2/SC
        DEN3 = (SCX3-SCX2*SCX/SC)*(SCX3-SCX*SCX2/SC)/(SCX2-SCX*SCX/SC)
        CCS = (SCX2LN-CCNUM2-CCNUM3)/(SCX4-DEN2-DEN3)
        BBS = (SCXLNC-SCLNC*SCX/SC-CCS*(SCX3-SCX2*SCX/SC))/
        *      (SCX2-SCX*SCX/SC)
        AAS = (SCLNC-BBS*SCX-CCS*SCX2)/SC
        SGM2S = -1./(2.*CCS)
        IF(SGM2S.LT.0)GO TO 22
        GO TO 24
22  NOCALC = 1
        GO TO 30
24  SGMS = DSQRT(SGM2S)
        X50S = SGM2S*(BBS+DFLOAT(KCKR)*CKR/(VX*ADS))
        XMBS = DSQRT(2.*PI*SGM2S)*DEXP(X50S*X50S/(2.*SGM2S)+AAS)/ADS
30  RETURN
    END

```

C

C

C

C

C

```

SUBROUTINE FIT2(FLPRD,CWELL,CPWELL,IRUN,NFIT,NFIT2)
*****
LEAST SQUARES FITTING ROUTINE FOR THE EQ.  $\ln(C*\text{SQRT}(V)) = A + B/V + CV$ 
*****
IMPLICIT REAL*8 (A-H,O-Z)
DIMENSION FLPRD(NFIT),CWELL(NFIT),CWELLC(50),CPWELL(NFIT),
*          CPWELC(50),VFIT(50)
COMMON /BLKSFT/ADS,AP,CK,CKR,DLOGTH,M,N,PI,SW,VX
COMMON /BLKFT2/GAMMA,VP,VSLUG,CO,VTOT,DX,VPP,VPS,NOCAL,NN
DVMB = DX*GAMMA/(CO*ADS)
DETECT = 0.
INDX = 0
NOCAL = 0
DO 1 I = 1,NFIT
    CPWELC(I) = 0.
1    CWELLC(I) = 0.
DO 4 I = 1,NFIT
    IF(DETECT.LE.CWELL(I))GO TO 2
    GO TO 5
2    DETECT = CWELL(I)
    INDX = I
4  CONTINUE
5  IF(INDX.EQ.0)GO TO 51
    GO TO 52
51 NOCAL = 1
    GO TO 6000
52 IND1 = INDX - 5

```

```

      IF(IND1.LT.1) IND1 = 1
      IND2 = INDX + 5
      IF(IND2.GT.NFIT)IND2 = NFIT
      NN = IND2-IND1+1
      SV = 0.
      SC = 0.
      SV2 = 0.
      SCV = 0.
      SV3 = 0.
      SCV2 = 0.
      SV4 = 0.
      DO 10 I = IND1,IND2
        IF(CWELL(I).EQ.0.) GO TO 10
        SV = SV+FLPRD(I)
        SC = SC+CWELL(I)
        SV2 = SV2+FLPRD(I)*FLPRD(I)
        SCV = SCV+CWELL(I)*FLPRD(I)
        SV3 =SV3+FLPRD(I)*FLPRD(I)*FLPRD(I)
        SCV2 = SCV2+CWELL(I)*FLPRD(I)*FLPRD(I)
        SV4 = SV4+FLPRD(I)*FLPRD(I)*FLPRD(I)*FLPRD(I)
10    CONTINUE
      CCNUM2 = SV2*SC/NN
      CCNUM3 = (SCV-SV*SC/NN)*(SV3-SV*SV2/NN)/(SV2-SV*SV/NN)
      DEN2 = SV2*SV2/NN
      DEN3 = (SV3-SV2*SV/NN)*(SV3-SV*SV2/NN)/(SV2-SV*SV/NN)
      CC = (SCV2-CCNUM2-CCNUM3)/(SV4-DEN2-DEN3)
      BB = (SCV-SV*SC/NN-CC*(SV3-SV2*SV/NN))/(SV2-SV*SV/NN)
      AA = (SC-BB*SV-CC*SV2)/NN
      VPP = - BB/(2.*CC)
      NOCAL = 0
      IF(NFIT2.LT.7) GO TO 21
      GO TO 22
21    NOCAL = 1
      GO TO 6000
22    DETECT = 0.
      DO 24 I = 1,NFIT2
        IF(DETECT.LE.CPWELL(I))GO TO 23
        GO TO 24
23      DETECT = CPWELL(I)
        INDX = I
24    CONTINUE
      IND1 = INDX - 3
      IND2 = INDX + 3
      DO 27 I=IND1,IND2
        IF(CPWELL(I).LE.0.)GO TO 28
        IF(I.LT.INDX.AND.CPWELL(I).LT.CPWELL(I-1))GO TO 28
        IF(I.GT.INDX.AND.CPWELL(I).GT.CPWELL(I-1))GO TO 28
27    CONTINUE
      GO TO 29
28    NOCAL = 1
      GO TO 6000
29    NN = IND2-IND1+1
      SV = 0.
      SC = 0.

```

```

SV2 = 0.
SCV = 0.
SV3 = 0.
SCV2 = 0.
SV4 = 0.
DO 30 I = IND1,IND2
  IF(CPWELL(I).EQ.0.) GO TO 30
  SV = SV+FLPRD(I)
  SC = SC+CPWELL(I)
  SV2 = SV2+FLPRD(I)*FLPRD(I)
  SCV = SCV+CPWELL(I)*FLPRD(I)
  SV3 = SV3+FLPRD(I)*FLPRD(I)*FLPRD(I)
  SCV2 = SCV2+CPWELL(I)*FLPRD(I)*FLPRD(I)
  SV4 = SV4+FLPRD(I)*FLPRD(I)*FLPRD(I)*FLPRD(I)
30 CONTINUE
CCNUM2 = SV2*SC/NN
CCNUM3 = (SCV-SV*SC/NN)*(SV3-SV*SV2/NN)/(SV2-SV*SV/NN)
DEN2 = SV2*SV2/NN
DEN3 = (SV3-SV2*SV/NN)*(SV3-SV*SV2/NN)/(SV2-SV*SV/NN)
CCS = (SCV2-CCNUM2-CCNUM3)/(SV4-DEN2-DEN3)
BBS = (SCV-SV*SC/NN-CCS*(SV3-SV2*SV/NN))/(SV2-SV*SV/NN)
AAS = (SC-BBS*SV-CCS*SV2)/NN
VPS = - BBS/(2.*CCS)
6000 RETURN
END

```

```

C *****
C *
C *          ( A L P H A L )
C *          LINEAR FLOW SYSTEM.
C *
C * PROGRAM TO FIT THE PRIMARY TRACER PRODUCTION CONCENTRATION
C *          PROFILE FROM A SINGLE WELL TRACER TEST.
C *
C * THIS PROGRAM PROVIDES AN ESTIMATION OF THE CONSTANT OF DIS-
C * PERSION (ALPHA), A CORRECTED BY GEOMETRY DIMENSIONLESS CONS-
C * TANT OF DISPERSION, A DIMENSIONLESS VOLUME RATIO AND A DIMEN-
C * SIONLESS SHUT IN TIME. ALL THESE DIMENSIONLESS VARIABLES ARE
C * REQUIRED TO ENTER THE RESIDUAL OIL CORRELATION CHARTS PRESEN-
C * TED IN SECTION 6.2.
C *
C *****
C
C          STANFORD UNIVERSITY
C          PETROLEUM ENGINEERING DEPARTMENT
C          STANFORD UNIVERSITY PETROLEUM RESEARCH INSTITUTE
C
C          EMILIO URIBE ANTUNEZ
C
C          NOVEMBER 1983
C
C *****
C
C          NOMENCLATURE:
C
C          ADS          DIMENSIONLESS ADSORPTION GROUP
C          ALPHA        CONSTANT OF DISPERSION, FT
C          ALPHAD        DIMENSIONLESS CONSTANT OF DISPERSION
C          AP           DIMENSIONLESS PARTITIONING COEFFICIENT
C          CO           INITIAL CONCENTRATION INJECTED
C          CWELL        PRODUCED PRIMARY TRACER CONCENTRATION
C          CWELLC        FITTED PRIMARY TRACER CONCENTRATION
C          D            THICKNESS, FT
C          FLPRD        FLUID PRODUCED, BBL
C          NDATA        NUMBER OF DATA POINTS FROM THE PRODUCTION PRIMARY TRACER
C                      CONCENTRATION PROFILE
C          PHI          POROSITY, FRAC.
C          Q            RATE, BPD
C          RBAR         EQUIVALENT MAXIMUM DISTANCE COVERED BY THE PEAK CONCEN-
C                      TRATION IN A RADIAL FLOW SYSTEM, FT
C          SOR          RESIDUAL OIL SATURATION, FRAC
C          SW           WATER SATURATION, FRAC.
C          TSHIN        SHUT IN TIME, D
C          TSID         DIMENSIONLESS SHUT IN TIME
C          VD           DIMENSIONLESS VOLUME RATIO
C          VSLUG        VOLUME OF THE SLUG OF CHEMICAL TRACER OF CONCENTRATION
C                      -CO-, BBL
C          VFIT         ARRAY USED IN THE FITTING ROUTINE
C          VTOT         TOTAL VOLUME INJECTED (SLUG + PUSHER), BBL
C          W            WIDTH OF THE LINEAR SYSTEM, FT

```

INPUT DATA:

TO RUN THE PROGRAM, THE FOLLOWING INFORMATION IS REQUIRED:

```
10 READ(5,100)NDAT
   READ(5,200)SOR,AP,D,PHI,Q
   READ(5,200)TSHIN,VSLUG,VTOT,W
   READ(5,300)(FLPRD(I),CWELL(I),I=1,NDAT)
```

NOTE.-TO STOP READING DATA ASSIGN A VALUE OF NDAT = 0 TO THE
LAST INPUT CARD.

THE INFORMATION HAVE TO BE PROVIDED USING THE FOLLOWING FORMATS:

```
100 FORMAT(I3)
200 FORMAT(5F10.0)
300 FORMAT(2F10.0)
```

```
IMPLICIT REAL*8 (A-H,O-Z)
DIMENSION CWELL(100),FLPRD(100)
COMMON ADS,GAMMA,VTOT,FACTOR,KPASS
DATA B0,B1,B2/0.6896217053,0.6130170337,-0.2758489916/
PI = 3.141592654
```

INPUT DATA

```
10 READ(5,100)NDAT
   IF(NDAT.EQ.0)GO TO 195
   READ(5,200)SOR,AP,D,PHI,Q
   READ(5,200)TSHIN,VSLUG,VTOT,W
   READ(5,300)(FLPRD(I),CWELL(I),I=1,NDAT)
```

```
SW = 1.-SOR
WRITE(6,400)SW
ADS = SW+AP*(1.-SW)
ADS = SW/ADS
GAMMA = W*D*PHI*SW
FACTOR = 1.
KPASS = 0
```

```
15 CALL FIT2(FLPRD,CWELL,NDAT,ALPHA)
   IF(KPASS.GT.1) GO TO 10
   FACTOR = B0 + B1*ALPHA + B2*ALPHA*ALPHA
   GO TO 15
```

```
195 VD = VTOT/VSLUG
   TSID = TSHIN/((2.*VTOT-VSLUG)/Q+TSHIN)
   RBAR = DSQRT(5.615*(VTOT-VSLUG/2.)/(PI*D*PHI))
   ALPHAD = 3.*ALPHA/(4.*RBAR)
   WRITE(6,500)VD,TSID,ALPHAD
   WRITE(6,600)
```

```

C
C      FORMATS
C
100 FORMAT(I3)
200 FORMAT(5F10.0)
300 FORMAT(2F10.0)
400 FORMAT(20X,'SW = ',F10.6)
500 FORMAT(/,13X,'VD      = ',F10.6,/,13X,'TSID  = ',F10.6,/,
*      13X,'ALPHAD= ',F10.6)
600 FORMAT(1H1)
      STOP
      END

C
SUBROUTINE FIT2(FLPRD,CWELL,NDAT,ALPHA)
*****
C      LEAST SQUARES FITTING ROUTINE FOR THE EQ.  $\ln(C*\text{SQRT}(V)) = A + B/V + CV$ 
C      *****
C
      IMPLICIT REAL*8 (A-H,O-Z)
      DIMENSION FLPRD(NDAT),CWELL(NDAT),CWELLC(100),VFIT(100)
      COMMON ADS,GAMMA,VTOT,FACTOR,KPASS
      KPASS = KPASS + 1

C
      SC = 0.
      SCX = 0.
      SCX2 = 0.
      SCDX = 0.
      SCDX2 = 0.
      SCLNC = 0.
      SCXLNC = 0.
      SCDXLN = 0.
      DO 10 I = 1,NDAT
        VFIT(I) = 5.615*(FLPRD(I)+VTOT)*ADS*FACTOR
        IF(CWELL(I).EQ.0.) GO TO 10
        SC = SC+CWELL(I)
        SCX = SCX+CWELL(I)*VFIT(I)
        SCX2 = SCX2+CWELL(I)*VFIT(I)*VFIT(I)
        SCDX = SCDX+CWELL(I)/VFIT(I)
        SCDX2 = SCDX2+CWELL(I)/(VFIT(I)*VFIT(I))
        SCLNC = SCLNC+CWELL(I)*DLOG(CWELL(I)*DSQRT(VFIT(I)))
        SCXLNC = SCXLNC+CWELL(I)*VFIT(I)*DLOG(CWELL(I)*
*      DSQRT(VFIT(I)))
        SCDXLN = SCDXLN+CWELL(I)/VFIT(I)*DLOG(CWELL(I)*
*      DSQRT(VFIT(I)))
10 CONTINUE
      CNUM2 = SCLNC*SCX/SC
      CNUM3 = (SCDXLN-SCLNC*SCDX/SC)*(SC-SCDX*SCX/SC)/
*      (SCDX2-SCDX*SCDX/SC)
      DEN2 = SCX*SCX/SC
      DEN3 = (SC-SCX*SCDX/SC)*(SC-SCDX*SCX/SC)/(SCDX2-SCDX*SCDX/SC)
      CC = (SCXLNC-CNUM2-CNUM3)/(SCX2-DEN2-DEN3)
      BB = (SCDXLN-SCLNC*SCDX/SC-CC*(SC-SCX*SCDX/SC))/
*      (SCDX2-SCDX*SCDX/SC)
      AA = (SCLNC-BB*SCDX-CC*SCX)/SC

```

```

      ALPHA = -1./(.5GAMMA*CC)
      IF(KPASS.EQ.1) RETURN
C
C      CHECKING THE FITTED EQUATION
C
      DO 20 I = 1,NDAT
20  CWELLC(I) = DEXP(AA+BB/VFIT(I)+CC*VFIT(I))/DSQRT(VFIT(I))
C
      WRITE(6,1000)
      WRITE(6,2000)(I,FLPRD(I),CWELL(I),CWELLC(I),I=1,NDAT)
      WRITE(6,3000)ALPHA,AA,BB,CC
1000  FORMAT(1H1,/,/,10X,'FlPrd(bbl)          Cwell          Cwellic',/)
2000  FORMAT(3X,13,2X,3F12.6)
3000  FORMAT(/,/,13X,'ALPHA = ',F10.6,/,13X,'AA      = ',D14.6,/
*      13X,'BB      = ',D14.6,/,13X,'CC      = ',D14.6)
      RETURN
      END

```

```

*****
*
*           ( A L P H A R )
*         RADIAL FLOW SYSTEM.
*
* PROGRAM TO FIT THE PRIMARY TRACER PRODUCTION CONCENTRATION
*         PROFILE FROM A SINGLE WELL TRACER TEST.
*
* THIS PROGRAM PROVIDES AN ESTIMATION OF THE CONSTANT OF DIS-
* PERSION (ALPHA), A DIMENSIONLESS CONSTANT OF DISPERSION, A
* DIMENSIONLESS VOLUME RATIO AND A DIMENSIONLESS SHUT IN TIME.
* ALL THESE DIMENSIONLESS PARAMETERS ARE REQUIRED TO ENTER THE
* RESIDUAL OIL CORRELATION CHARTS PRESENTED IN SECTION 6.2.
*
*****

```

STANFORD UNIVERSITY
 PETROLEUM ENGINEERING DEPARTMENT
 STANFORD UNIVERSITY PETROLEUM RESEARCH INSTITUTE

EMILIO URIBE ANTUNEZ

NOVEMBER 1983

NOMENCLATURE:

AI	CROSS SECTIONAL AREA AT -RIBAR-, FT ²
ALPHA	CONSTANT OF DISPERSION, FT
ALPHAD	DIMENSIONLESS CONSTANT OF DISPERSION
CO	INITIAL CONCENTRATION INJECTED
CWELL	PRODUCED PRIMARY TRACER CONCENTRATION
CWELLC	FITTED PRIMARY TRACER CONCENTRATION
D	THICKNESS, FT
FLPRD	FLUID PRODUCED, BBL
NDAT	NUMBER OF DATA POINTS FROM THE PRODUCTION PRIMARY TRACER CONCENTRATION PROFILE
PHI	POROSITY, FRAC.
Q	RATE, BPD
RBAR	MAXIMUM DISTANCE COVERED BY THE PEAK CONCENTRATION, FT
RIBAR	MATERIAL BALANCE AVERAGE RADIUS, FT
SOR	RESIDUAL OIL SATURATION, FRAC
SW	WATER SATURATION, FRAC.
TSHIN	SHUT IN TIME, D
TSID	DIMENSIONLESS SHUT IN TIME
VD	DIMENSIONLESS VOLUME RATIO
VSLUG	VOLUME OF THE SLUG OF CHEMICAL TRACER OF CONCENTRATION -CO-, BBL
VFIT	ARRAY USED IN THE FITTING ROUTINE
VTOT	TOTAL VOLUME INJECTED (SLUG + PUSHER), BBL

```

C      INPUT DATA:
C
C      TO RUN THE PROGRAM, THE FOLLOWING INFORMATION IS REQUIRED:
C
C          10 READ(5,100)NDAT
C             READ(5,200)SOR,D,PHI,Q
C             READ(5,200)TSHIN,VSLUG,VTOT
C             READ(5,300)(FLPRD(I),CWELL(I),I=1,NDAT)
C
C      NOTE.-TO STOP READING DATA ASSIGN A VALUE OF NDAT = 0 TO THE
C             LAST INPUT CARD.
C
C      THE INFORMATION HAVE TO BE PROVIDED USING THE FOLLOWING FORMATS:
C
C          100 FORMAT(I3)
C          200 FORMAT(4F10.0)
C          300 FORMAT(2F10.0)
C
C      *****
C      IMPLICIT REAL*8 (A-H,O-Z)
C      DIMENSION CWELL(100),FLPRD(100)
C      COMMON VTOT,RIBAR,AI
C      PI = 3.141592654
C
C      INPUT DATA
C
C      10 READ(5,100)NDAT
C         IF(NDAT.EQ.0)GO TO 195
C         READ(5,200)SOR,D,PHI,Q
C         READ(5,200)TSHIN,VSLUG,VTOT
C         READ(5,300)(FLPRD(I),CWELL(I),I=1,NDAT)
C
C      SW = 1.-SOR
C      WRITE(6,400)SW
C      CTE1 = PI*D*PHI*SW
C      RIBAR = DSQRT(5.615*VTOT/CTE1)
C      AI = 2.*CTE1*RIBAR
C      15 CALL FIT2(FLPRD,CWELL,NDAT,ALPHA)
C      VD = VTOT/VSLUG
C      TSID = TSHIN/((2.*VTOT-VSLUG)/Q+TSHIN)
C      RBAR = DSQRT(5.615*(VTOT-VSLUG/2.)/(PI*D*PHI))
C      ALPHAD = ALPHA/RBAR
C      WRITE(6,500)VD,TSID,ALPHAD
C      195 WRITE(6,600)
C
C      FORMATS
C
C      100 FORMAT(3I3)
C      200 FORMAT(4F10.0)
C      300 FORMAT(2F10.0)
C      400 FORMAT(20X,'SW = ',F10.6)
C      500 FORMAT(//,13X,'VD      = ',F10.6,/,13X,'TSID   = ',F10.6,/,
C      *           13X,'ALPHAD= ',F10.6)

```

```

600 FORMAT(1H1)
STOP
END

C
SUBROUTINE FIT2(FLPRD,CWELL,NDAT,ALPHA)
*****
C LEAST SQUARES FITTING ROUTINE FOR THE EQ.  $\ln(C*\sqrt{V}) = A+B*V+C*V*V$ 
C *****
C
IMPLICIT REAL*8 (A-H,O-Z)
DIMENSION FLPRD(NDAT),CWELL(NDAT),CWELLC(100),VFIT(100)
COMMON VTOT,RIBAR,AI

C
SC = 0
SCX = 0
SCX2 = 0
SCX3 = 0
SCX4 = 0
SCLNC = 0
SCXLNC = 0
SCX2LN = 0
DO 10 I = 1,NDAT
  VFIT(I) = 5.615*(FLPRD(I)+VTOT)
  IF(CWELL(I).EQ.0.)GO TO 10
  SC = SC+CWELL(I)
  SCX = SCX+CWELL(I)*VFIT(I)
  SCX2 = SCX2+CWELL(I)*VFIT(I)*VFIT(I)
  SCX3 = SCX3+CWELL(I)*VFIT(I)*VFIT(I)*VFIT(I)
  SCX4 = SCX4+CWELL(I)*VFIT(I)*VFIT(I)*VFIT(I)*VFIT(I)
  SCLNC = SCLNC+CWELL(I)*DLOG(CWELL(I))
  SCXLNC = SCXLNC+CWELL(I)*VFIT(I)*DLOG(CWELL(I))
  SCX2LN = SCX2LN+CWELL(I)*VFIT(I)*VFIT(I)*DLOG(CWELL(I))
10 CONTINUE
CCNUM2 = SCLNC*SCX2/SC
CCNUM3 = (SCXLNC-SCLNC*SCX/SC)*(SCX3-SCX*SCX2/SC)/
* (SCX2-SCX*SCX/SC)
DEN2 = SCX2*SCX2/SC
DEN3 = (SCX3-SCX2*SCX/SC)*(SCX3-SCX*SCX2/SC)/(SCX2-SCX*SCX/SC)
CC = (SCX2LN-CCNUM2-CCNUM3)/(SCX4-DEN2-DEN3)
BB = (SCXLNC-SCLNC*SCX/SC-CC*(SCX3-SCX2*SCX/SC))/
* (SCX2-SCX*SCX/SC)
AA = (SCLNC-BB*SCX-CC*SCX2)/SC
ALPHA = -1./(8.*RIBAR*AI*AI*CC/3.)

C
C CHECKING THE FITTED EQUATION
C
DO 20 I = 1,NDAT
20 CWELLC(I) = DEXP(AA+BB*VFIT(I)+CC*VFIT(I)*VFIT(I))

C
WRITE(6,1000)
WRITE(6,2000)(I,FLPRD(I),CWELL(I),CWELLC(I),I=1,NDAT)
WRITE(6,3000)ALPHA,AA,BB,CC
1000 FORMAT(1H1,/,10X,'FlPrd(bbl)          Cwell          Cwelle',/)
2000 FORMAT(3X,13,2X,3F12.6)
3000 FORMAT(/,13X,'ALPHA = ',F10.6,/,13X,'AA      = ',D14.6,/,
* 13X,'BB      = ',D14.6,/,13X,'CC      = ',D14.6)
RETURN
END

```