CONCEPTUAL MODULAR DESCRIPTION OF THE
HIGH-LEVEL WASTE MANAGEMENT SYSTEM
FOR SYSTEM STUDIES MODEL DEVELOPMENT

R. W. McKee
J. R. Young
G. J. Konzek

August 1992

Prepared for
the U.S. Department of Energy
under Contract DE-AC06-76RLO 1830

Pacific Northwest Laboratory
Richland, Washington 99352

MASTER

SUMMARY

This document presents modular descriptions of possible alternative components of the federal high-level radioactive waste management system and the procedures for combining these modules to obtain descriptions for alternative configurations of that system. The 20 separate system component modules presented here can be combined to obtain a description of any of the 17 alternative system configurations (i.e., scenarios) that were evaluated in the MRS Systems Studies program (DOE 1989a). First-approximation descriptions of other yet-undefined system configurations could also be developed for system study purposes from this database.

The descriptions include, in a modular format, both functional descriptions of the processes in the waste management system, plus physical descriptions of the equipment and facilities necessary for performance of those functions. The level of detail of these descriptions corresponds to the level of detail needed for the projected systems analysis studies. Three levels of functional description detail identified as Level 0, 1, and a combined Level 2 and 3, and two levels of physical description detail identified as Level 1 and 2 are provided.

Most of the 20 modules (i.e., 18) are needed to describe possible alternative configurations and alternative allocation of functions for the MRS facility and the geologic repository. The major configuration variables include:

- four potential waste interim surface storage systems (transportable storage casks, vaults, drywells, and sealed storage casks)
- two spent fuel storage and disposal modes (consolidated or intact assemblies)
- alternative allocations in the system for the major waste processing functions (consolidation, canistering, and containerizing at either the MRS facility or the repository)
- several phased-construction and operation alternatives for the MRS facility and repository.

The functional and physical descriptions are intended to provide sufficient descriptive information on the activities, facilities, and equipment to provide a basis for systems integration model development and systems engineering studies. The level of detail in the descriptions is limited to that foreseen as needed for systems engineering studies that consider the entire federal high-level radioactive waste management system.

The information in this report is based on preliminary conceptual designs.

CONTENTS

SUMMARY	iii
1.0 INTRODUCTION	1.1
1.1 ORGANIZATION OF THIS DOCUMENT	1.4
1.2 SYSTEM CONFIGURATIONS COVERED	1.5
1.3 MODULAR COMPONENTS AND COMBINATIONS	1.15
1.4 HOW TO USE THIS DOCUMENT	1.18
2.0 LEVEL 1 FUNCTIONAL DESCRIPTION	2.1
2.1 LEVEL 1 FUNCTIONAL DESCRIPTION FOR THE WASTE GENERATORS	2.3
2.2 LEVEL 1 FUNCTIONAL DESCRIPTION FOR TRANSPORTATION.	2.4
2.3 LEVEL 1 FUNCTIONAL DESCRIPTION FOR THE MRS FACILITY	2.5
2.4 LEVEL 1 FUNCTIONAL DESCRIPTION FOR THE GEOLOGIC REPOSITORY FACILITY	2.7
3.0 COMBINED LEVEL 2 AND 3 FUNCTIONAL DESCRIPTION	3.1
3.1 LEVEL 2 AND 3 FUNCTIONAL DESCRIPTION FOR THE WASTE GENERATORS (MODULE 1A)	3.2
3.2 LEVEL 2 AND 3 FUNCTIONAL DESCRIPTION FOR TRANSPORTATION (MODULE 2A)	3.10
3.2.1 Transportation of Casks	3.10
3.2.2 Major Cask Servicing	3.13
3.3 LEVEL 2 AND 3 FUNCTIONAL DESCRIPTION FOR THE MRS MODULES	3.16
3.3.1 Level 2 and 3 Functional Description for the MRS Transfer Facility (Module 3A)	3.16
3.3.2 Level 2 and 3 Functional Description for the Spent Fuel Handling Building (SFHB) (Module 3B)	3.27

3.3.3	Level 2 and 3 Functional Description for the MRS Receiving and Handling Building Without Consolidation (Module 3C)	3.27
3.3.4	Level 2 and 3 Functional Description for the MRS Receiving and Handling Building with Consolidation (Module 3D)	3.33
3.3.5	Level 2 and 3 Functional Description for the MRS Transportable Storage (S/T) Cask Storage (Module 3E)	3.37
3.3.6	Level 2 and 3 Functional Description for the MRS Vault Storage (Module 3F)	3.40
3.3.7	Level 2 and 3 Functional Description for the MRS Drywell Storage (Module 3G)	3.43
3.3.8	Level 2 and 3 Functional Description for the MRS Sealed Storage Cask Storage (Module 3H)	3.45
3.4	COMBINED LEVEL 2 AND 3 FUNCTIONAL DESCRIPTION FOR THE REPOSITORY MODULES	3.48
3.4.1	Combined Level 2 and 3 Functional Description for the Transportable Storage Cask Interim Storage (Module 4A)	3.48
3.4.2	Combined Level 2 and 3 Functional Description for the Repository Pass-Through WHB-1 for Containerized Intact Spent Fuel (Module 4B)	3.48
3.4.3	Combined Level 2 and 3 Functional Description for the Repository Pass-Through WHB-1 for Containerized Consolidated Spent Fuel (Module 4C)	3.57
3.4.4	Combined Level 2 and 3 Functional Description for the Repository Low-Volume WHB-1 for Containerizing Intact Spent Fuel (Module 4D)	3.57
3.4.5	Combined Level 2 and 3 Functional Description for the Repository WHB-1 for Containerizing Intact Fuel Without an MRS (Module 4E)	3.61
3.4.6	Combined Level 2 and 3 Functional Description for the Repository WHB-1 for Containerizing Intact Fuel with an MRS (Module 4F)	3.65
3.4.7	Level 2 Functional Description for the Repository WHB-1 for Containerizing Consolidated Fuel from an MRS (Module 4G)	3.65

3.4.8	Combined Level 2 and 3 Functional Description for the Repository WHB-2 with Consolidation and Containerization and Without an MRS (Module 4H)	3.65
3.4.9	Level 2 Functional Description for the Repository WHB-2 with Consolidation and Containerization and with an MRS (Module 4I)	3.69
3.4.10	Level 2 Functional Description for the Repository Underground Facilities (Module 4J)	3.69
4.0	PHYSICAL DESCRIPTIONS OF THE SYSTEM MODULES	4.1
4.0.1	Power Reactor Wastes	4.10
4.0.2	Research and Test Reactor Fuel	4.12
4.0.3	General Waste Flows in the Waste Management System	4.14
4.1	WASTE GENERATORS	4.22
4.1.1	Level 1 Physical Description (Module 1A)	4.23
4.1.2	Level 2 Physical Description (Module 1A).	4.30
4.2	WASTE TRANSPORTATION	4.49
4.2.1	Cask Transportation	4.49
4.2.2	Cask Servicing.	4.63
4.3	MONITORED RETRIEVABLE STORAGE FACILITY	4.68
4.3.1	Transfer Facility (Module 3A)	4.71
4.3.2	Spent Fuel Handling Building (Module 3B)	4.81
4.3.3	Receiving and Handling Building Without Consolidation (Module 3C)	4.114
4.3.4	Receiving and Handling Building with Consolidation (Module 3D)	4.127
4.3.5	Transportable Storage Cask Storage Area (Module 3E)	4.145
4.3.6	Vault Storage (Module 3F)	4.153
4.3.7	Drywell Storage (Module 3G)	4.160

4.3.8	Sealed Storage Cask Storage (Module 3H)	4.163
4.4	TUFF REPOSITORY	4.170
4.4.1	Transportable Storage Cask Storage (Module 4A)	4.172
4.4.2	Pass-Through WHB-1 for Containerized Intact SFAs (Module 4B)	4.172
4.4.3	Pass-Through WHB-1 for Containerized Consolidated SFAs (Module 4C)	4.184
4.4.4	Low-Volume Intact Fuel WHB-1 (Module 4D)	4.208
4.4.5	Intact Fuel WHB-1 Without an MRS (Module 4E)	4.216
4.4.6	Intact Fuel WHB-1 with an MRS (Module 4F)	4.224
4.4.7	The WHB-1 for Containerizing Canistered Wastes (Module 4G)	4.232
4.4.8	The Consolidation and Containerization WHB-2 Without an MRS (Module 4H)	4.240
4.4.9	The Consolidation and Containerization WHB-2 with an MRS (Module 4I)	4.249
4.4.10	The Repository Underground Facilities (Module 5J)	4.258
5.0	REFERENCES	5.1
APPENDIX A	- ALPHANUMERIC SYMBOLS FOR IDENTIFICATION OF WASTE RECEPTACLES AND RADIOACTIVE WASTE MATERIALS	A.1
APPENDIX B	- GLOSSARY	B.1
APPENDIX C	- PROCEDURE FOR COMPILING A SPECIFIC SYSTEM DESCRIPTION	C.1

FIGURES

1.1	Level 0 Flow Diagrams of No-MRS Scenarios with Spent Fuel Consolidation (Case 1)	1.8
1.2	Level 0 Flow Diagrams of No-MRS Scenarios with Intact Spent Fuel Containerization (Case 2)	1.9
1.3	Level 0 Flow Diagrams of Storage-Only MRS with Spent Fuel Consolidation at a Two-Phase Repository (Case 3)	1.10
1.4	Level 0 Flow Diagrams of Storage-Only MRS with Intact Spent Fuel Containerization at a Single-Phase Repository (Case 4)	1.12
1.5	Level 0 Flow Diagram of Canistering or Containerization at a Single-Phase MRS (Cases 5, 6, and 7).	1.13
1.6	Level 0 Flow Diagram of Canistering or Containerization at a Two-Phase MRS (Cases 5, 6, and 7)	1.14
1.7	Level 0 Flow Diagram of Canistering or Containerization at a Three-Phase MRS (Cases 5, 6, and 7)	1.16
1.8	Modular Flow Diagram for All Waste Management System Modules	1.17
2.1	Level 1 Universal Functional Flow Diagram for the Waste Management System	2.10
3.1	Level 1 Functional Flow Diagram for the Waste Generators (Module 1A)	3.3
3.2	Combined Level 2 and 3 Functional Flow Diagram for the Waste Generators (Module 1A)	3.9
3.3	Level 1 Functional Flow Diagram for Cask Transportation	3.10
3.4	Level 2 Functional Flow Diagram for Cask Transportation	3.12
3.5	Level 1 Functional Flow Diagram for Major Cask Servicing	3.13
3.6	Level 2 Functional Flow Diagram for the Cask Servicing Facility.	3.15
3.7	Level 1 Functional Flow Diagram for the MRS Transfer Facility and the SFHB (Modules 3A and 3B)	3.17
3.8	Combined Level 2 and 3 Functional Flow Diagram for the Transfer Facility (Module 3A) and SFHB (Module 3B)	3.25

3.9	Level 1 Functional Flow Diagram for the RHB Without Consolidation (Module 3C) and with Consolidation (Module 3D)	3.28
3.10	Combined Level 2 and 3 Functional Flow Diagram for the RHB Without Consolidation (Module 3C)	3.31
3.11	Combined Level 2 and 3 Functional Flow Diagram for the RHB With Consolidation (Module 3D)	3.35
3.12	Level 1 Functional Flow Diagram for the MRS Transportable Storage Cask Interim Storage Area (Module 3E)	3.37
3.13	Level 2 and 3 Functional Flow Diagram for the Transportable Storage Cask Interim Storage (Module 3E)	3.39
3.14	Level 1 Functional Flow Diagram for the MRS Vault Interim Storage Facility (Module 3F), Drywell Interim Storage Facility (Module 3G) and Sealed Storage Cask Interim Storage Facility (Module 3H)	3.40
3.15	Level 2 and 3 Functional Flow Diagram for Vault Storage (Module 3F)	3.42
3.16	Level 2 and 3 Functional Flow Diagram for Drywell Storage (Module 3G)	3.44
3.17	Level 2 and 3 Functional Flow Diagram for Sealed Storage Cask Storage (Module 3H)	3.47
3.18	Level 1 Functional Flow Diagram for the Waste Handling Building (Modules 4B, 4C, 4D, 4E, 4F, 4G, 4H, and 4I)	3.49
3.19	Level 2 and 3 Functional Flow Diagram for the Containerized Intact Spent Fuel Pass-Through WHB-1 (Modules 4B and 4C)	3.55
3.20	Level 2 and 3 Functional Flow Diagram for Low-Volume Intact Fuel WHB-1 (Module 4D)	3.59
3.21	Level 2 and 3 Functional Flow Diagram for High-Volume Containerizing WHB-1s Without Consolidation at the Repository (Modules 4E, 4F, and 4G)	3.63
3.22	Level 2 and 3 Functional Flow Diagram for WHB-2s for Consolidating and Containerizing Wastes (Modules 4H and 4I)	3.67
3.23	Level 1 Functional Flow Diagram for the Repository Underground Facilities (Module 4J)	3.69
3.24	Level 2 and 3 Functional Flow Diagram for Repository Underground Facilities (Module 4J)	3.73

4.1	MRS Canisters Containing Spent Fuel Rods or Assemblies	4.10
4.2	Typical Repository Containers	4.11
4.3	Scenario 1 - Waste Management System Canister, Container, Drum and Waste Symbols	4.15
4.4	Scenario 2 - Waste Management System Canister, Container, Drum and Waste Symbols	4.16
4.5	Scenario 3 - Waste Management System Canister, Container, Drum and Waste Symbols	4.17
4.6	Scenario 4 - Waste Management System Canister, Container, Drum and Waste Symbols	4.18
4.7	Scenario 5 - Waste Management System Canister, Container, Drum and Waste Symbols	4.19
4.8	Scenario 6 - Waste Management System Canister, Container, Drum and Waste Symbols	4.20
4.9	Scenario 7 - Waste Management System Canister, Container, Drum and Waste Symbols	4.21
4.10	Typical LWR Fuel Assemblies	4.24
4.11	Plan View of Generic Waste Generator Yard Facilities	4.25
4.12	Elevation View of Generic PWR Spent Fuel Pool	4.26
4.13	Plan View of Generic PWR Spent Fuel Pool	4.26
4.14	Water Pool for Storage of Spent Fuel at the Morris, Illinois, Facility	4.27
4.15	Savannah River Plant HLW Canister	4.29
4.16	Dry Vault Storage System	4.31
4.17	Typical Dry Vault Cask Loading Facilities	4.32
4.18	Typical Transport Cask Designs	4.55
4.19	Fleet Service Facility	4.65
4.20	Plan View of Integrated Fleet Service Facility	4.66
4.21	Example MRS Facility Layout	4.69
4.22	First-Level Plan for the Transfer Facility	4.72

4.23	Second-Level Plan for the Transfer Facility	4.73
4.24	Receiving, Inspection and Shipping Area	4.75
4.25	Cask Unloading Area	4.77
4.26	Sealed Storage Cask Loadout and Decontamination Room	4.78
4.27	First-Level Plan for the SFHB	4.104
4.28	Second-Level Plan for the SFHB	4.105
4.29	Third-Level Plan for the SFHB	4.106
4.30	Receiving, Inspection and Shipping Area.	4.108
4.31	Cask Unloading Area	4.109
4.32	Sealed Storage Cask Loadout and Decontamination Room	4.111
4.33	Cutaway View of One-Half of Typical MRS RHB	4.115
4.34	Schematic First-Level Plan for the MRS RHB Without Consolidation.	4.116
4.35	Schematic Second-Level Plan for the MRS RHB Without Consolidation.	4.117
4.36	Schematic Third-Level Plan for the MRS RHB Without Consolidation.	4.118
4.37	Receiving, Inspection and Shipping Area.	4.121
4.38	Cask Unloading Area.	4.121
4.39	Container Closure Area	4.123
4.40	Canyon Cell In-Process Lag Storage	4.124
4.41	Sealed Storage Cask Loadout and Decontamination Room	4.124
4.42	Transport Cask in Lidding Position	4.126
4.43	Cutaway View of One-Half of Typical MRS RHB	4.131
4.44	Schematic First-Level Plan for the RHB with Consolidation. . .	4.132
4.45	Schematic Second-Level Plan for the MRS RHB with Consolidation.	4.133

4.46	Schematic Third-Level Plan for the MRS RHB with Consolidation	4.134
4.47	Receiving, Inspection and Shipping Area.	4.137
4.48	Cask Unloading Area.	4.138
4.49	Disassembly and Consolidation Area	4.140
4.50	Fuel Hardware Shredding and Packaging.	4.140
4.51	Canister and Container Closure Area.	4.141
4.52	Canyon Cell In-Process Lag Storage	4.142
4.53	Sealed Storage Cask Loadout and Decontamination Room	4.142
4.54	Transport Cask in Lidding Position	4.143
4.55	Floor Plan and Cross Section of RB	4.151
4.56	Transportable Storage Casks in Storage	4.151
4.57	Plan View of Typical Interim Cask Storage Facility	4.152
4.58	Cutaway View of Typical Vault Storage Building	4.156
4.59	Schematic First-Level Plan for Vault Storage Building	4.156
4.60	Schematic Second-Level Plant for Vault Storage Building.	4.157
4.61	Longitudinal Section of Vault Storage Building	4.157
4.62	Lateral Section of Vault Storage Building	4.158
4.63	Typical Vault Storage Position	4.159
4.64	Typical Drywell Installation	4.162
4.65	Sealed Storage Cask.	4.164
4.66	Placing Sealed Storage Casks in Storage.	4.165
4.67	Plan View of Typical Interim Cask Storage Facility	4.165
4.68	Location of Yucca Mountain Repository Site in Southern Nevada	4.171
4.69	Typical Tuff Repository Perspective View	4.173
4.70	Plan View of Typical Repository Central Surface Facilities	4.174

4.71	Conceptual Schematic Process Flow Diagram for the WHB.	4.177
4.72	General Plan View of the Module 4B WHB Main Floor	4.178
4.73	General Plan View of the Module 4B WHB Basement.	4.179
4.74	Typical WHB Cask Receiving Facilities.	4.181
4.75	Cask Unloading Cell Lag Storage.	4.183
4.76	Conceptual Schematic Process Flow Diagram for the WHB.	4.201
4.77	General Plan View of the Module 4C WHB Main Floor.	4.202
4.78	General Plan View of the Module 4C WHB Basement.	4.203
4.79	Typical WHB Cask Receiving Facilities.	4.205
4.80	Cask Unloading Cell Lag Storage.	4.207
4.81	Conceptual Schematic Process Flow Diagram for the WHB.	4.209
4.82	General Plan View of the Module 4D WHB Main Floor.	4.210
4.83	General Plan View of the Module 4D WHB Basement.	4.211
4.84	Typical WHB Cask Receiving Facilities.	4.213
4.85	Cask Unloading Cell Lag Storage.	4.215
4.86	Conceptual Schematic Process Flow Diagram for the WHB.	4.217
4.87	General Plan View of the Module 4E WHB Main Floor.	4.218
4.88	General Plan View of the Module 4E WHB Basement.	4.219
4.89	Typical WHB Cask Receiving Facilities.	4.221
4.90	Cask Unloading Cell Lag Storage.	4.223
4.91	Conceptual Schematic Process Flow Diagram for the WHB.	4.225
4.92	General Plan View of the Module 4F WHB Main Floor.	4.226
4.93	General Plan View of the Module 4F WHB Basement.	4.227
4.94	Typical WHB Cask Receiving Facilities.	4.230
4.95	Cask Unloading Cell Lag Storage.	4.231

4.96	Conceptual Schematic Process Flow Diagram for the WHB.	4.233
4.97	General Plan View of the Module 4G WHB Main Floor.	4.234
4.98	General Plan View of the Module 4G WHB Basement.	4.234
4.99	Typical WHB Cask Receiving Facilities.	4.237
4.100	Cask Unloading Cell Lag Storage.	4.238
4.101	Conceptual Schematic Process Flow Diagram for the WHB.	4.241
4.102	General Plan View of the Module 4H WHB Main Floor.	4.242
4.103	General Plan View of the Module 4H WHB Basement.	4.243
4.104	Typical WHB Receiving Facilities	4.246
4.105	Cask Unloading Cell Lag Storage.	4.247
4.106	Conceptual Schematic Process Flow Diagram for the WHB.	4.250
4.107	General Plan View of the Module 4I WHB Main Floor.	4.251
4.108	General Plan View of the Module 4I WHB Basement.	4.252
4.109	Typical WHB Cask Receiving Facilities.	4.254
4.110	Cask Unloading Cell Lag Storage.	4.256
4.111	Plan View of Repository Underground Facilities	4.259
4.112	Repository Underground Mining Activities	4.260
4.113	Conceptual Design of Vertical Borehole	4.261
4.114	Waste Transporter.	4.262
4.115	Borehole Preparation	4.263
4.116	Container Transfer to Underground Borehole	4.263
4.117	Emplacement of Container in Borehole	4.264
4.118	Closure of Borehole.	4.265

TABLES

1.1	Seven Basic System Configuration Alternatives	1.6
1.2	Modules Contained in System Scenario Descriptions	1.18
4.1	Descriptions of the Wastes and Receptacles Handled in the Waste Management System	4.3
4.2	Physical Descriptions of Different Fuel Assembly Configurations.	4.6
4.3	Sources of Waste Requiring Disposal	4.32
4.4	Major Waste Handling Equipment at Pool Storage Sites (Module 1A) - Listed in Process Step Order	4.33
4.5	Major Waste Handling Equipment at Pool Storage Sites (Module 1A) - Listed by Equipment Item	4.37
4.6	Major Waste Handling Equipment at Dry-Vault Storage Sites (Module 1A)- Listed in Process Step Order	4.42
4.7	Major Waste Handling Equipment at Dry-Vault Storage (Module 1A) Sites - Listed by Equipment Item	4.44
4.8	Reactor Plant Spent Fuel Pool Information and Shipping Crane Capacities	4.46
4.9	Typical Waste Transport Cask Descriptions	4.54
4.10	Potential Contents in Transport Casks	4.56
4.11	Transportation Distances for Waste Shipments	4.59
4.12	General Characteristics of Truck Transport of Loaded Casks . . .	4.62
4.13	General Characteristics of Rail Transport of Loaded Casks . . .	4.62
4.14	General Characteristics of Barge Transport of Loaded Casks . . .	4.63
4.15	General Characteristics of Rail Transport of Empty Casks . . .	4.63
4.16	Support Services Facility Process Room Dimensions	4.67
4.17	Major Process Equipment in Fleet Servicing Facility	4.67
4.18	MRS Primary Support Facilities	4.70
4.19	TF Process Area Dimensions.	4.74

4.20	TF Primary Process Support Facilities	4.74
4.21	Descriptions of the Wastes Received at the TF	4.80
4.22	Major Waste Handling Equipment at the TF, SFHB and RHB - Listed in Process Step Order.	4.82
4.23	Major Waste Handling Equipment at the TF, SFHB, and RHB - Listed by Equipment Item.	4.94
4.24	SFHB Process Area Dimensions	4.107
4.25	SFHB Primary Process Support Facilities	4.108
4.26	Descriptions of the Wastes Received at the SFHB	4.113
4.27	Building Process Area Dimensions for RHB Without Consolidation	4.119
4.28	Primary Process Support Facilities for RHB Without Consolidation	4.120
4.29	Waste Packages Handled at the RHB Without Consolidation (Module 3C)	4.128
4.30	Process Room Dimensions for RHB with Consolidation	4.135
4.31	Primary Process Support Facilities for RHB with Consolidation (Module 3D)	4.136
4.32	Waste Packages Handled at the RHB with Consolidation	4.146
4.33	Descriptions of the Wastes Handled in the Receiving Building	4.154
4.34	Major Waste Handling Equipment for the S/T Cask Module	4.155
4.35	Process Areas in Vault Storage Building	4.158
4.36	Process Support Facilities in Vault Storage Building	4.159
4.37	Major Equipment for the Vault Storage Module	4.161
4.38	Major Equipment for the Drywell Storage Module	4.163
4.39	Major Waste Handling Equipment for SSC Storage Module	4.167
4.40	Sealed Storage Cask Description	4.168
4.41	Tuff Repository Primary Support Facilities	4.175

4.42 Module 4B WHB Process Room Dimensions	4.179
4.43 Module 4B WHB Process Support Facilities.	4.180
4.44 Wastes Handled by Module at the Repository WHB	4.185
4.45 Major Waste Handling Equipment for the WHBs - Listed in Process Step Order	4.189
4.46 Major Waste Handling Equipment for the WHBs - Listed by Equipment Item	4.195
4.47 Module 4C WHB Process Room Dimensions	4.203
4.48 Module 4C WHB Process Support Facilities	4.204
4.49 Module 4D WHB Process Room Dimensions	4.211
4.50 Module 4D WHB Process Support Facilities	4.212
4.51 Module 4E WHB Process Room Dimensions	4.220
4.52 Module 4E WHB Process Support Facilities	4.221
4.53 Module 4F WHB Process Room Dimensions	4.228
4.54 Module 4F WHB Process Support Facilities	4.229
4.55 Module 4G WHB Process Room Dimensions	4.235
4.56 Module 4G WHB Process Support Facilities	4.235
4.57 Module 4H WHB Process Room Dimensions	4.244
4.58 Module 4H WHB Process Support Facilities	4.244
4.59 Module 4I WHB Process Room Dimensions	4.253
4.60 Module 4I WHB Process Support Facilities	4.253
4.61 Repository Underground Excavations for Vertical Borehole Storage	4.268
4.62 Major Process Equipment for Waste Emplacement at the Repository - Listed in Process Step Order	4.269
4.63 Major Process Equipment for Waste Emplacement at the Repository - Listed by Equipment Item	4.274
4.64 Reference Repository Characteristics and Data	4.278

1.0 INTRODUCTION

During the FY 1988 to FY 1990 time period, the Systems Engineering Branch of the Office of Systems and Compliance within the U.S. Department of Energy's (DOE) Office of Civilian Radioactive Waste Management (OCRWM) sponsored the development of a suite of computer models to be used in analyzing various possible alternatives for the configuration and operation of the federal high-level radioactive waste management system. The descriptions presented in this document were developed to provide a description of the federal waste management system sufficiently comprehensive to be used as a reference basis for these system model developments and for system performance studies using these models.

The suite of computer models that were being developed included 1) the Waste Stream Analysis (WSA), 2) the System Operations/Logistics Model (SOLMOD), 3) the System Engineering Cost Analysis Model (SECAM), and 4) the System Engineering Dose Analysis Model (SEDAM). These models tend to be complex and a well-defined and fairly detailed system description was needed to insure a consistent basis for the system modeling and systems study efforts.

Previous system descriptions were based on earlier system concepts. These previous descriptions provided an appropriate format and contained the information components needed to meet the modeling and analysis requirements, but they either described only one of several possible different system configurations that systems integration studies might need to address, or they did not organize all the functions into useful categories for the systems integration studies.

Recognizing that the system integration studies might need to consider a number of different but related system configurations, and recognizing the desirability of consistent system integration studies reporting categories, a broader, more comprehensive approach for system descriptions was developed and is presented in this document.

A series of analyses referred to as the MRS System Studies (DOE 1989a), designed to re-examine the overall waste system configuration and the role of a monitored retrievable storage (MRS) facility in the federal waste management system, was performed in FY 1988 and 1989. Altogether, 17 alternative system configurations and four alternative storage concepts were considered in these studies. To meet the need for a description document that can be used to describe any one of these alternative systems (as well as reasonable variations) and to also employ any of four alternative storage concepts, a modular system description approach was conceived. By describing 20 separate system component modules, for example a specific repository or MRS receiving building concept or one of the storage concepts, and by defining the procedures for combining these to describe an entire system, any of the 17 alternative system configurations can be described. Descriptions of other variations of these configurations can also be prepared using these modules as a starting point but may require a little more time and effort to assemble and modify.

The system descriptions are presented in three levels of functional description detail. These are identified as Level 0, 1, and a combined Level 2 and 3; and two levels of physical description detail identified as Level 1 and 2. The functional description levels can be defined as follows:

- Level 0 defines just the basic elements of the system and shows primary waste stream routings.
- Level 1 defines only the basic system functions and will generically apply to any waste type requiring repository disposal.
- The combined Level 2 and 3 defines additional functional details and operations for each Level 1 function. The Level 2 represents the lowest level of detail at which all of the system computer models should report results.

To provide the functional details needed for analyzing work crew and equipment resources that must serve multiple functions, some of the Level 2 functions are further subdivided into Level 3 functions. However, this detail is all included as a part of the combined Level 2 and 3 functional description and a separate Level 3 functional description is not provided.

The Level 2 functions are identified by a 3-digit, 2-decimal number, while the Level 3 functions are identified by a 4-digit, 3-decimal number.

The Level 1 physical description provides a general overall description of the conceptual facilities needed, and the Level 2 physical description provides additional descriptive details primarily with respect to equipment needed to carry out each of the functions.

A function and equipment numbering system has been adopted such that the same functions or equipment items appearing in any two specific system descriptions always retain the same identification numbers. For example, transport cask loading at the MRS facility always retains the same function number regardless of the number of functions that precede it at the MRS.

The modular system description approach is intended to provide for

- rapid preparation of alternative system descriptions
- uniform descriptions and consistent component identification numbering for alternative system concepts
- assurance of consistency in analysis of alternative system configurations.

A draft revision 1 of this modular system description report was issued for comments in July 1989. That draft report was used to prepare two study-specific system descriptions documents (R. W. McKee et al. 1991a, 1991b) for the FY 1990-91 Reference System Performance Evaluation and the Aggregate Receipt Rate Studies. This final report has been prepared to utilize the lessons learned in preparing the two study-specific system descriptions and to simplify the format. It provides essentially the same information as the previous draft revision 1 but in a revised and simplified format.

The principal source documents used to develop this modular system description report include those detailing conceptual design studies for the MRS facility (Parsons 1985), the Tuff Repository (Sandia 1987b), the Transportation System (DOE 1987a), two MRS Systems Studies Task B reports: Woods et al. (1988, 1990) and Weston (1989), and the MRS System Study Summary Report (DOE 1989a).

1.1 ORGANIZATION OF THIS DOCUMENT

This report is organized in four primary sections. These include an introduction and three sections that present, in turn, the Level 1 functional descriptions for the entire waste management system, the Level 2 and 3 functional description for each of the system modules, and a Level 1 and 2 physical description of each of the system modules. Three appendixes are included. Appendix A presents the symbolic system for describing the wastes, waste packages and casks, Appendix B contains the Glossary, and Appendix C provides a detailed procedure for compiling a specific system description using this modular description information.

This introduction describes the basis for preparing the systems descriptions and outlines the contents of the document. The alternative system configurations that this modular description was specifically designed to describe are covered in Section 1.2. Section 1.3 identifies the Level 0 component system modules and describes how they can be combined to produce a complete description for any of the alternative configurations described in Section 1.2. In Section 1.4 the procedure for using the information presented in this document to produce specific system descriptions is described.

Section 2.0 presents a description of the Level 1 functions in the federal high-level radioactive waste management system. The Level 1 description presents the major functions required from waste acceptance to final disposal. It describes all functions needed considering all of the scenarios evaluated in the MRS Systems Studies. These functions are presented sequentially for each of the four major system elements, and a universal functional flow diagram is presented at the end of the section to illustrate the general relationship between the major system elements and the flow of wastes and casks through the system.

Section 3.0 presents the Level 2 and 3 functional descriptions of the operations within each of the system modules. The Level 2 and 3 functional descriptions break each of the major functions into operations and provide a brief description of the activities necessary for accomplishing each operation. The Level 2 and 3 functions and associated operations and activities are presented separately for each of the 20 system modules, and this provides

the bases for subsequent preparation of the physical descriptions for those modules in Section 4.0. The text for each Level 2 and 3 functional description for a module is preceded by a modified Level 1 functional flow diagram (corresponding to the applicable portion of the universal functional flow diagram presented in Section 2.0) that highlights the functions required for the specific module. The text for a Level 2 and 3 functional description for a specific module is followed by a Level 2 and 3 functional flow diagram that illustrates the flow of wastes and casks through all of the operations for that module.

Section 4.0 presents a Level 1 and Level 2 physical description of the facilities and equipment needed for each of the system modules. The general contents are keyed to the functional activities described in Sections 2.0 and 3.0 so that persons performing operational, reliability, and economic analyses can identify the equipment and facilities corresponding to each of the functions. Emphasis is placed on describing the facilities and equipment that can have significant effects on differences in operational times and economics between alternative system designs.

Because of the variety in the potential types of wastes that might be handled and the several potential alternative methods for processing and reworking those wastes, flow sheets are simplified and by-pass and return paths generally are not shown on the figures in this document. The consideration of all potential by-pass and return paths would unreasonably complicate illustration of the principal process flows.

1.2 SYSTEM CONFIGURATIONS COVERED

The 1989 MRS System Studies project (DOE 1989a) originally considered nine basic concepts for configuring the federal radioactive waste management system and a number of variations for phasing in the allocation of its functions. However, two were later dropped from consideration as not being significant alternatives, leaving seven that are considered here. These seven alternatives are briefly described here, along with simplified flow sheets to illustrate them.

The major variation in these configuration concepts relates to the role of the MRS facility in the packaging of spent fuel and the allocation of functions between the MRS and repository. The seven basic alternatives are identified in Table 1.1.

TABLE 1.1. Seven Basic System Configuration Alternatives

<u>Case</u>	<u>MRS Facility Functions</u>	<u>Repository Packaging Functions</u>
1	None	Consolidate and Containerize Spent Fuel
2	None	Containerize Intact Spent Fuel
3	Store Only	Consolidate and Containerize Spent Fuel
4	Store Only	Containerize Intact Spent Fuel
5	Consolidate and Canister Spent Fuel	Containerize Spent Fuel
6	Containerize Intact Spent Fuel	Check and Repair Containers
7	Consolidate and Containerize Spent Fuel	Check and Repair Containers

The principal features of the seven basic alternatives can be summarized as follows:

1. There is no MRS facility and the repository provides all of the packaging of spent fuel. The repository is assumed to consolidate and containerize the spent fuel, except for 5% that is containerized intact.
2. Same as 1, except the repository is assumed to package intact spent fuel without consolidation.
3. The MRS facility provides storage capabilities only and the repository provides all of the packaging functions. The repository is assumed to consolidate and containerized the spent fuel as in 1 above.
4. Same as 3, except the repository is assumed to package intact spent fuel without consolidation.
5. The MRS facility provides storage capabilities and also consolidates and places the spent fuel in canisters. The repository then places the canisters in the final disposal containers.

6. The MRS facility packages intact spent fuel assemblies into the final disposal containers. At the repository, the containers are inspected and if any are found defective, they are repaired at the repository.
7. The MRS facility consolidates and packages the spent fuel into final disposal containers. At the repository, the containers are inspected and if any are found defective, they are repaired at the repository.

Other key variables include:

1. The role of the MRS facility in packaging defense high-level waste (DHLW) and West Valley high-level waste (WVHLW).
2. The effect of the MRS facility location on its receipts. Specifically, for an eastern MRS location spent fuel originating west of 100 degrees longitude is shipped directly to the repository (after it opens) while other spent fuel is sent first to the MRS facility.
3. Facility construction and operation phasing. One-, two-, or three-phase construction concepts are defined for the MRS facility, as well as for the repository.

The 17 specific configurations that this modular description is designed to accommodate are described briefly in the following paragraphs. The scenario numbering system is similar to the numbering system defined for the MRS Action Plan(a) Task B report (Woods et al. 1988). A three-character, two-decimal system is used here. The first character (1 through 7) identifies the basic alternative case as in Table 1.1. The second character is a 0, I, II, or III. The 0 identifies no-MRS, and the I, II, or III indicate a one-, two-, or three-phase MRS. The third character is a I, II, or III and indicates a one-, two-, or three-phase repository. It is possible to assemble other configurations in addition to the 17 described here by using the system modules described in this document. However, these 17 scenarios are the ones for which design studies were completed for the MRS System Study Task B report (Weston 1989).

Figure 1.1 provides overview Level 0 flow diagrams illustrating the distinguishing features of the two alternatives for the No-MRS scenarios

---

(a) Subsequently renamed the MRS System Studies project.

Scenario 1.0. II , No-MRS and Two-Phase Repository System with Spent Fuel Consolidation

Scenario 1.0. III , No-MRS and Three-Phase Repository System with Spent Fuel Consolidation

- Waste Handling Building 1 Containerizes Intact SFA Until Building 2 Starts up and then Accepts and Containerizes HLW Canisters
- Waste Handling Building 2 Consolidates and Containerizes SFA
- SFA = Spent Fuel Assemblies

FIGURE 1.1. Level 0 Flow Diagrams of No-MRS Scenarios with Spent Fuel Consolidation (Case 1)

where spent fuel is consolidated for disposal at the repository. In Scenario 1.0.II, initial spent fuel shipments are received at a low-capacity repository Phase 1 Waste Handling Building 1, where they are containerized intact for disposal. After the large-capacity Phase 2 Waste Handling Building 2 reaches full capacity, all spent fuel is received and consolidated for disposal there and the Phase 1 building is then used to containerize DHLW and WVHLW canisters. In Scenario 1.0.III, a more limited Phase 1 Receiving Building, designed to receive transportable storage (S/T) casks for interim storage precedes the Waste Handling Buildings associated with Phases 2 and 3. The previous Phase 1 and 2 buildings then become Phases 2 and 3.

Figure 1.2 provides overview Level 0 flow diagrams illustrating the distinguishing features of the two alternatives for the No-MRS Scenario where spent fuel assemblies are containerized intact for disposal at the repository. In Scenario 2.0.I, a single-phase Waste Handling Building 1 receives all of the spent fuel and HLW and containerizes the waste for disposal without spent fuel consolidation. In Scenario 2.0.II, a low-capacity Phase 1 Receiving Building designed to receive S/T casks for interim storage precedes the operation of the Waste Handling Building 1. (Note that Waste Handling Building 1 here has approximately eight times the capacity of Waste Handling Building 1 in the Scenario 1 alternatives.)

Figure 1.3 provides overview Level 0 flow diagrams illustrating the distinguishing features of the two alternatives for a storage-only MRS where spent fuel is consolidated at a two-phase repository. Most of the spent fuel is shipped first to the MRS facility. Prior to repository startup, spent fuel is sent to the MRS. Following repository startup, the MRS provides a staging function for spent fuel shipments, transfers spent fuel from truck

Scenario 2.0. I , No-MRS and Single-Phase Repository System with Intact Spent Fuel Containerization

Scenario 2.0. II , No-MRS and Two-Phase Repository System with Intact Spent Fuel Containerization

- Waste Handling Building 1 Containerizes Intact SFA and HLW Canisters

FIGURE 1.2. Level 0 Flow Diagrams of No-MRS Scenarios with Intact Spent Fuel Containerization (Case 2)

Scenario 3. I . II , Single-Phase Storage-Only MRS System with Spent Fuel Consolidation at a Two-Phase Repository

Scenario 3. II . II , Two-Phase Storage-Only MRS System with Spent Fuel Consolidation at a Two-Phase Repository

- MRS Spent Fuel Handling Building Transfers SFA from Shipping Casks to Storage, and after Repository Startup, Transfers SFA from Storage to Rail Casks and from Incoming Truck Casks to Rail Casks
- Repository Waste Handling Building 1 Containerizes Intact SFA Until Building 2 Starts up and then Accepts and Containerizes HLW Canisters After Building 2 Startup
- Repository Waste Handling Building 2 Consolidates and Containerizes SFA

FIGURE 1.3. Level 0 Flow Diagrams of Storage-Only MRS with Spent Fuel Consolidation at a Two-Phase Repository (Case 3)

casks to rail casks, and organizes rail shipments into dedicated train shipments for shipment to the repository. Spent fuel from western locations and HLW canisters are shipped directly to the repository. The two-phase repository is set up as in Scenario 1.0.II. In Scenario 3.I.II, the MRS has a single-phase Spent Fuel Handling Building that can transfer spent fuel in and out of any one of three alternative storage facility concepts (sealed storage

casks, drywells, or open-cycle vaults). In Scenario 3.II.II, the MRS has a Phase 1 Receiving Building that can transfer dual-purpose S/T casks to an S/T cask storage area. This precedes construction and operation of the Phase 2 Spent Fuel Handling Building that can also transfer spent fuel in and out of any one of the three alternative storage facility concepts listed above for Scenario 3.I.II.

Figure 1.4 provides overview Level 0 flow diagrams illustrating the distinguishing features of the two alternatives for a storage-only MRS where spent fuel is containerized intact at a single-phase repository. In Scenario 4.I.I, the MRS is identical to the MRS in Scenario 3.I.II, and in Scenario 4.II.I the MRS is identical to the MRS in Scenario 3.II.II. In both Scenarios 4.I.I and 4.II.I spent fuel from western locations and HLW canisters are shipped directly to the repository.

Figure 1.5 provides an overview Level 0 flow diagram illustrating the distinguishing features of three scenarios in which spent fuel is either sealed in canisters at a single-phase MRS or sealed into the final disposal container at a single-phase MRS. The MRS also provides any needed interim storage (three alternatives available). The repository is also constructed and operated in a single-phase. In Scenario 5.I.I, western spent fuel and HLW canisters are sent directly to the repository where both are containerized for disposal (this spent fuel is not consolidated). Most of the spent fuel is sent to the MRS where it is consolidated and canistered. The canistered spent fuel is sealed in the final disposal containers at the repository.

In Scenarios 6.I.I and 7.I.I, both the HLW canisters and all of the spent fuel are sent to the MRS where they are processed into their final disposal containers. In Scenario 6.I.I, spent fuel assemblies are containerized intact. In Scenario 7.I.I, spent fuel assemblies are first consolidated before they are containerized.

Figure 1.6 provides an overview Level 0 flow diagram illustrating a set of scenarios similar to those in Figure 1.5 except that a two-phase MRS is utilized. An early Phase 1 Spent Fuel Handling Building provides the ability to accept rail or truck cask shipments of spent fuel for transfer into

Scenario 4.1.1, Single-Phase Storage-Only MRS System with Intact Spent Fuel Containerization at a Single-Phase Repository

Scenario 4.1.2, Two-Phase Storage-Only MRS System with Intact Spent Fuel Containerization at a Single-Phase Repository

- Repository Waste Handling Building 1 Containerizes Intact SFA and HLW Canisters
- MRS Spent Fuel Handling Building Transfers SFA from Shipping Casks to Storage, and After Repository Startup, Transfers SFA from Storage to Rail Casks and from Incoming Truck Casks to Rail Casks

FIGURE 1.4. Level 0 Flow Diagrams of Storage-Only MRS with Intact Spent Fuel Containerization at a Single-Phase Repository (Case 4)

FIGURE 1.5. Level 0 Flow Diagram of Canistering or Containerization at a Single-Phase MRS (Cases 5, 6, and 7)

Scenario 5. II. 1, Two-Phase MRS with SFA Consolidation and Canistering
 Scenario 6. II. 1, Two-Phase MRS with Intact-SFA Containerization
 Scenario 7. II. 1, Two-Phase MRS with SFA Consolidation and Containerization
 (HLW Also Containerized at the MRS in Scenarios 6-7)

FIGURE 1.6. Level 0 Flow Diagram of Canistering or Containerization at a Two-Phase MRS
 (Cases 5, 6, and 7)

interim storage (using any of three available alternative storage concepts). The later Phase 2 Receiving and Handling Building provides a capability for final containerization either as intact assemblies (Scenario 6.II.I) or after consolidation (Scenario 7.II.I).

Figure 1.7 illustrates a third set of related scenarios similar to those in Figure 1.6 except that a three-phase MRS facility is utilized. The only differences from Figure 1.6 are that Phases 1 and 2 become Phases 2 and 3, and a Phase 1 Receiving Building provides an earlier ability to accept dual-purpose S/T casks for interim storage. Otherwise, the Figure 1.7 set is identical to the Figure 1.6 set.

1.3 MODULAR COMPONENTS AND COMBINATIONS

The modular flow diagram that identifies the separate modules described in this document and that shows where they fit into the system is presented in Figure 1.8. The system is divided into four main elements, including 1) the waste generators, 2) waste transportation, 3) the MRS facility, and 4) the repository. System modules are identified within each element and numbered with the element number and a letter to distinguish separate modules within each element. For example, M3A identifies Module A in element 3, the MRS. In later use of the module identification, the M is not used when the word "module" is used, and this module would be referenced simply as Module 3A.

Most of the separate modules are found in either the MRS or the repository elements. Possible branching flow paths and alternative modules for related functions are indicated by the flow lines in the Figure 1.8 diagram.

Several of the scenarios described by the Level 0 flow diagrams illustrate a phased MRS concept where the first phase consists of a facility for storing transportable storage (S/T) casks. The concept for handling dual-purpose S/T casks in the MRS System Studies project called for a Receiving Building to transfer the S/T casks from a rail car to the MRS transporter. In this modular description document, this minimum-facility MRS Receiving Building has been incorporated into a single module (3E) that includes both the Receiving Building and the S/T storage component.

Scenario 5. III. 1, Three-Phase MRS with SFA Consolidation and Canistering
 Scenario 6. III. 1, Three-Phase MRS with Intact SFA Containerization
 Scenario 7. III. 1, Three-Phase MRS with SFA Consolidation and Containerization
 (HLW Also Containerized at the MRS in Scenarios 6-7)

FIGURE 1.7. Level 0 Flow Diagram of Canistering or Containerization at a Three-Phase MRS (Cases 5, 6, and 7)

FIGURE 1.8. Modular Flow Diagram for All Waste Management System Modules

Since the MRS System Studies project was completed, the concept of a simplified MRS spent fuel handling building, called an MRS Transfer Facility (TF), has evolved. This facility would replace the MRS Spent Fuel Handling Building (SFHB) and can be considered as an alternate to the SFHB. It is also conceivable, but unlikely however, that both a TF and an SFHB might be included in a single scenario. Either a TF or an SFHB could be considered as the first phase of the MRS or as a follow-on addition to a first phase that provided for only S/T cask receiving and storage.

The combinations of modules that are needed to describe each of the 17 scenarios described previously in Section 1.2 are defined in Table 1.2.

Other combinations are conceivable.

1.4 HOW TO USE THIS DOCUMENT

The major complexity in module alternatives is associated with the MRS facility and the repository descriptions. When a specific system

TABLE 1.2. Modules Contained in System Scenario Descriptions

Element: Waste Generators	Trans- porta- tion	Modules Needed to Describe Scenario															
		MRS										Repository					
		(a)	(b)	(b)	(b)	(b)	(b)	(b)	(b)	(b)	(b)	(b)	(b)	(b)	(b)	(b)	(b)
Scenarios	1A	2A	3A	3B	3C	3D	3E	3F	3G	3H	4A	4B	4C	4D	4E	4F	4G
1.0.II	x	x												x			x
1.0.III	x	x									x			x			x
2.0.I	x	x													x		x
2.0.II	x	x									x			x			x
3.1.II	x	x	x	x										x			x
3.II.II	x	x	x	x			x							x			x
4.1.I	x	x	x	x										x			x
4.II.I	x	x	x	x			x							x			x
5.1.I	x	x				x									x		x
6.1.I	x	x			x						x						x
7.1.I	x	x				x						x					x
5.II.I	x	x	x	x		x							x				x
6.II.I	x	x	x	x	x						x				x		x
7.II.I	x	x	x	x		x							x				x
5.III.I	x	x	x	x		x	x								x		x
6.III.I	x	x	x	x	x		x				x						x
7.III.I	x	x	x	x		x	x						x				x

(a) See Section 1.2 for additional details concerning the three-character, two-decimal scenarios system shown in the table.

(b) Modules 3A and 3B are alternatives for minimum MRS receiving facilities. However, both could conceivably be included in a single scenario.

configuration alternative description is needed for a specific system study, the appropriate components can be selected and the functional and physical description can be assembled as a separate document, if desired. Much of the descriptive information required for different scenarios will not change or will change very little. These components include:

- the waste generator functions and descriptions
- the MRS support facilities
- the transportation functions and functional descriptions
- the repository support facilities
- the repository underground facilities and functions.

For each alternative system requiring evaluation, the major system description information that may change includes:

- functional diagrams for the MRS and repository
- functional descriptions for the MRS and repository
- components in the transportation physical description
- components in the MRS physical description
- components in the repository physical description.

Level 1 and combined Level 2 and 3 functional flow diagrams have been developed for each of the system components. When a particular system scenario has been selected for analysis, the required Level 1 and combined Level 2 and 3 functional flow diagrams and textual descriptions can be assembled from the module descriptions. These can then be used to prepare the functional diagrams and textual descriptions for the specific system. Likewise, the physical description information for the included modules can be selected and consolidated to prepare a physical description for the specific system.

When using this document to prepare a study-specific system description, it is intended that the same sectional organization be retained. However, figure and table identifications will have to be changed when incorporated into a study-specific description. The flowsheets, text, and tables have all

been prepared using PC capabilities and can thus be easily modified. To limit duplication of information, the Level 2 functional descriptions and both the Level 1 and Level 2 physical descriptions have been prepared in the order of least complex to most complex. Thus, depending on the modules selected, some merging and editing of information is required when specific descriptions are prepared. A step-by-step procedure for compiling a scenario-specific system description can be found in Appendix C.

2.0 LEVEL 1 FUNCTIONAL DESCRIPTION

The Level 1 description in this section presents the major functions within the federal high-level radioactive waste management system.

The Level 1 universal functional flow diagram (Figure 2.1) is presented at the end of this section for convenience in referencing textual descriptions. This diagram contains all functions expected to occur in the seven primary alternative system configurations for the waste management system. Separate subsections in this section describe the functions in each major system element in numerical order, with a brief text devoted to each function shown in the related flow diagram. As shown by the upper Level 0 flow diagram in Figure 2.1, the wastes are transported from the generators to either the MRS facility or the repository. If they are transported to the MRS facility, they may be handled there in several alternative ways. For example, they may go 1) directly to storage, 2) to the repository after transfer to larger casks, 3) to canistering or containerizing and then to storage or to the repository, or 4) to consolidation before canistering or containerizing and then to storage or to the repository. In the third and fourth alternatives, the wastes may also be stored before processing or they may be shipped directly to the repository without storage after processing. The MRS storage period could range in length from a few days to years. The wastes received at the repository without containers are sealed in repository containers and all containerized wastes are emplaced in the repository. They may also be stored for a period in dual-purpose storage/transportation (S/T) casks prior to final processing at the repository. In accordance with the scenario being evaluated, the wastes may be received consolidated or they may be consolidated at the repository or containerized intact without consolidation. Emplaced wastes may be retrieved from the repository during a caretaker period (up to 50 years after initiation of emplacement) or they may remain there permanently.

In the text describing the Level 1 functions, the modules that contain each function are identified by the module identification numbers that are shown as superscripts following the function titles.

The descriptions in this document include all operational activities necessary for receipt, shipment, processing, and emplacement of the wastes, plus closure of the repository. No initial surface facility construction activities are included in these descriptions, nor are the initial mining operations for shafts, ramps, and common area development that must be completed before waste emplacement functions can start. However, the underground repository activities related to extension of ventilation drifts, common areas, and emplacement panels that continue after waste emplacement is initiated are included. These functions are part of the functional activities during the repository operating and waste emplacement period and must be considered in cost, safety, and operations analyses.

2.1 LEVEL 1 FUNCTIONAL DESCRIPTION FOR THE WASTE GENERATORS

<u>Functional Steps</u>	<u>Functional Description</u>
1.1	Primary Storage Operations (M1A) The wastes are moved into the storage facility, stored in that facility, and moved within that facility as necessary for waste processing operations, storage operations, transfer to secondary storage, and preparation for shipment.
1.2	Waste Processing (M1A) The wastes are processed as necessary to permit shipment to secondary storage or offsite.
1.3	Secondary Storage (M1A) The wastes are stored in the secondary storage facilities and monitored to detect changes in the storage conditions.
1.4	Transport Cask Loading (M1A) The empty cask is washed, inspected, moved to the process building, prepared for loading, loaded with waste, prepared for shipment, and moved to the holding area.
1.5	Transport Cask Unloading (M1A) The full cask is washed, inspected, decontaminated, moved to the process building, prepared for unloading, unloaded, prepared for shipment, and moved to the holding area.
1.6	Transport Cask Receipt (M1A) A cask is received at the waste generator, surveyed for radioactivity, inspected, and moved inside the facility perimeter fence to the cask and vehicle holding area.
1.7	Transport Cask Lag Storage (M1A) The cask and vehicle are stored in the holding area until scheduled for loading, unloading or shipment.
1.8	Cask Preshipment Inspection and Servicing (M1A) The cask and vehicle are inspected to determine if they are ready for shipment and repaired and serviced as needed.

2.2 LEVEL 1 FUNCTIONAL DESCRIPTION FOR TRANSPORTATION

<u>Functional Steps</u>	<u>Functional Description</u>
2.1	Inspection and Acceptance (M2A) DOE and the commercial carrier inspect and accept the shipment.
2.2	Cask Shipment (M2A) The full casks are transported by a dedicated train, (a) by a rail/barge combination or by a continuous truck shipment from the waste generator's site to the MRS or repository or from the MRS to the repository. Empty casks are shipped as normal rail freight shipments or by continuous truck shipments.
2.3	Major Cask Servicing (M2A) The support services facility at the MRS (or the repository if there is no MRS) provides non-routine servicing, dispatching, preventative maintenance, requalification license compliance tests and inspections, major repairs, and decontamination of both the transport casks and their associated railcars or truck-trailers. After this servicing, the casks are returned to service.

-
- (a) A dedicated train for this document is defined as a train containing only an engine, buffer cars, cask cars, and a caboose for the escort personnel. Also see Glossary.

2.3 LEVEL 1 FUNCTIONAL DESCRIPTION FOR THE MRS FACILITY

<u>Functional Steps</u>	<u>Functional Description</u>
3.1	Transport Cask Receipt (M3A, M3B, M3C, M3D, M3E) A cask is received at the MRS, surveyed for radioactivity, inspected and moved inside the facility perimeter fence to the cask lag storage or to a process building.
3.2	Transport Cask Lag Storage (M3A, M3B, M3C, M3D, M3E) The casks on vehicles are stored in the holding area until scheduled for unloading, loading or shipment offsite.
3.3	Cask Preshipment Inspection and Servicing (M3A, M3B, M3C, M3D) The cask and vehicle are inspected to determine if they are ready for shipment, and repaired and serviced as needed.
3.4	Transport Cask Unloading (M3A, M3B, M3C, M3D) The full cask and vehicle are moved to the process building, washed, inspected and decontaminated. The cask is prepared for unloading, connected to a process or transfer cell and unloaded. The empty cask is disconnected from the process or transfer cell; prepared for shipment, loaded onto the transport vehicle, and moved with the vehicle to the cask and vehicle holding area for storage prior to shipment. The empty cask may also be diverted for maintenance, decontamination, or recertification at the support services facility. The empty casks are shipped to the waste generators as needed.
3.5	Waste Lag Storage (M3A, M3B, M3C, M3D) The incoming wastes may be placed in the waste lag storage in the process or transfer cell for storage before further handling or processing.
3.6	Waste Processing (M3C, M3D) Depending on the condition of the wastes and the scenario being evaluated, the wastes may be processed to prepare them for disposal. These processed materials and all other wastes are placed in canisters or containers and lids are welded on the canisters or containers.
3.7	Process Lag Storage (M3C, M3D) The canned wastes may be placed in one of the in-process lag storage facilities for storage prior to shipment or transfer to the MRS interim storage facility.

2.3 LEVEL 1 FUNCTIONAL DESCRIPTION FOR THE MRS FACILITY (contd)

<u>Functional Steps</u>	<u>Functional Description</u>
3.8	Interface to Long-Term Storage (M3A, M3B, M3C, M3D) An empty sealed storage cask or transfer cask is connected to a transfer cell or canyon cell loadout port. The wastes are placed in the cask for transfer to the long-term storage facility. The cask is prepared for movement to the storage facility. After storage, the cask containing the wastes is connected to either a transfer or canyon cell and unloaded.
3.9	Transport Cask Loading (M3A, M3B, M3C, M3D) An empty transport cask is received at the process building, unloaded from the transport vehicle, prepared for loading and connected to a transfer or canyon cell. Wastes from other casks connected to the cell or from the cell lag storages are transferred to the transport cask. The vehicle and cask are prepared for shipment.
3.10	Long-Term Storage (M3E, M3F, M3G, M3H) The wastes are moved to and stored in the long-term storage facility. A representative sample of the storage units is monitored. The wastes are returned to the process building after storage.
3.16	Balance of Plant Operations and Support (M3A, M3B, M3C, M3D, M3E) The MRS supporting departments provide the operations and support activities necessary for safe and efficient performance of the primary waste handling activities.

2.4 LEVEL 1 FUNCTIONAL DESCRIPTION FOR THE GEOLOGIC REPOSITORY FACILITY

<u>Functional Steps</u>	<u>Functional Description</u>
4.1	Transport Cask Receipt (M4A, M4B, M4C, M4D, M4E, M4F, M4G, M4H, M4I) A cask of waste is received at the repository, surveyed for radioactivity, inspected and moved inside the facility perimeter fence to the cask lag storage or to a process building.
4.2	Transport Cask Lag Storage (M4A, M4B, M4C, M4D, M4E, M4F, M4G, M4H, M4I) The casks on vehicles are stored in the cask lag storage area until scheduled for unloading, loading or shipment offsite.
4.3	Cask Preshipment Inspection and Servicing (M4B, M4C, M4D, M4E, M4F, M4G, M4H, M4I) After unloading, the empty cask and vehicle are inspected to determine if they are ready for shipment and repaired and serviced as needed.
4.4	Transport Cask Unloading (M4B, M4C, M4D, M4E, M4F, M4G, M4H, M4I) Prior to unloading, the full cask and vehicle are moved into the process building, washed, inspected and decontaminated. The cask is prepared for unloading, connected to a process cell and unloaded. The empty cask is then disconnected from the process cell, prepared for shipment, loaded onto the transport vehicle, and moved with the vehicle to the cask and vehicle holding area for lag storage prior to shipment. The empty cask may also be diverted for maintenance, decontamination, or recertification at the MRS support services facility. The empty casks are shipped to the waste generators or to the MRS as needed.
4.5	Waste Lag Storage (M4B, M4C, M4D, M4E, M4F, M4G, M4H, M4I) The incoming wastes may be placed in the waste lag storage in the process cell before further handling or processing.
4.6	Waste Processing (M4D, M4E, M4F, M4G, M4H, M4I) Depending on the condition of the wastes and the scenario being evaluated, the wastes may be processed to prepare them for disposal. These processed materials and all other wastes are placed in containers, the containers are inerted, and lids are welded on the containers.

2.4 LEVEL 1 FUNCTIONAL DESCRIPTION FOR THE GEOLOGIC REPOSITORY FACILITY (contd)

<u>Functional Steps</u>	<u>Functional Description</u>
4.7	Container Vault Storage (M4B, M4C, M4D, M4E, M4F, M4G, M4H, M4I) The filled containers are transported to the vault storage building and may be placed in the surface vault storage and stored until scheduled for emplacement.
4.8	Interface to Cask Storage (M4A) The S/T cask and vehicle are washed, moved to the Receiving Building, inspected and decontaminated. The cask is moved from the vehicle to the cask transporters. The vehicle is returned to the vehicle storage area.
4.10	Transport Cask Storage (M4A) The cask is transported to the storage area, where it is placed in storage. After storage, it is placed back on the transporter and moved to the process building.
4.11	Interface to Waste Emplacement (M4B, M4C, M4D, M4E, M4F, M4G, M4H, M4I) A container is placed in a waste transporter.
4.12	Waste Emplacement Operations (M4J) The disposal containers are transferred to an underground emplacement area and emplaced in the boreholes. The repository performance is monitored during the caretaker period for 50 years after emplacement of the first container.
4.13	Performance Testing (M4J) Periodically during the caretaker period, a representative sample of the emplaced containers is retrieved from the repository and tested in the performance confirmation building. The wastes in those containers are placed in new containers and returned to the underground repository.
4.14	Mining (M4J) The underground facilities for disposal of the wastes are extended by excavation of the necessary tunnels, common areas, emplacement rooms, and boreholes followed by installation of the borehole liners and equipment. The mined rock is transported to the surface and stored until needed for the repository decommissioning.

2.4 LEVEL 1 FUNCTIONAL DESCRIPTION FOR THE GEOLOGIC REPOSITORY FACILITY
(contd)

<u>Functional Steps</u>	<u>Functional Description</u>
4.15	Final Waste Isolation (M4J) Following this caretaker phase, a closure and decommissioning plan will be initiated during which the repository will be closed by filling all underground excavations with crushed rock and closing all points of access to the underground (i.e., boreholes, shafts, and ramps) with seals designed to retain their integrity for thousands of years. The surface facilities will be decommissioned and permanent markers will be erected at the site.
4.16	Balance-of-Plant Operations and Support (M4J) Balance-of-Plant activities such as water and sewage system operations, maintenance, and security functions are provided for both the process and facility operations.

FIGURE 2.1. Level 1 Universal Functional Flow Diagram for the Waste Management System

3.0 COMBINED LEVEL 2 AND 3 FUNCTIONAL DESCRIPTION

The combined Level 2 and 3 functional description in this section presents the operations necessary to accomplish the major functions described in the Level 1 functional description. The combined Level 2 and 3 functions are described in terms of the facility modules (see Figure 1.8).

This combined Level 2 and 3 functional description is presented in four sections, corresponding to the major system elements. Each section in turn contains subsections for each module related to that section. A modified Level 1 functional flow diagram, corresponding to a section of Figure 2.1, is presented at the beginning of each subsection for the corresponding module. On that flow diagram, the Level 1 functions for that module are highlighted and the Level 1 functions that do not apply are suppressed (i.e., cross-hatched). A complete combination Level 2 and 3 flow diagram for the corresponding module is presented at the end of each subsection. A brief description is presented in numerical order in each subsection for each function shown on the combined Level 2 and 3 flow diagram.

Routine balance-of-plant activities necessary for operation of the system (e.g., maintenance, facility decontamination, low-level waste collection and disposal) are not included in a combined Level 2 or 3 description. This function is included at Level 1 primarily to provide a functional location to store cost data in the Systems Integration Database (SIDB). The emphasis in this document is only on operations directly related to the wastes scheduled for disposal in the repository, the waste canisters and containers, the casks used to transport the wastes, the transportation activities and mining activities that immediately precede waste emplacement.

Some of the Level 2 functions are subdivided into Level 3 functions. This additional functional detail was provided as a result of needs identified in engineering analyses concerned with the allocation of work crew and scarce equipment resources that must serve multiple functions. Whereas the Level 2 functions are identified with a two-decimal number designation (e.g., 1.3.1), the Level 3 functions have a three-decimal number designation (e.g., 1.3.1.1). On the functional flowsheets, the Level 3 functions may be shown

enclosed in a larger box having a Level 2 designation. The distinction between Level 2 and Level 3 functions has been maintained for the purposes of organizing and storing data in the SIDB. The Level 2 functions represent the lowest level of detail at which all models can report results and the lowest level of detail that can be defined generically with respect to any waste type that might be processed through the DOE high-level waste management system (e.g., consolidated spent fuel, activated metals, etc.)

It should be noted that these functional descriptions conservatively include all potential functions that may be included in the final design for the waste management systems. As an example, the transport casks are assumed to have two lids. If the final transport cask designs have only one lid or if the outer lid is removed when the impact limiters are removed, the separate functions for handling the outer lid would not occur and should not be included in the system analyses.

3.1 LEVEL 2 AND 3 FUNCTIONAL DESCRIPTION FOR THE WASTE GENERATORS (MODULE 1A)

The Level 2 functional description for the waste generators is included entirely within one module. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.1.

1.0 Waste Generators

FIGURE 3.1. Level 1 Functional Flow Diagram for the Waste Generators (Module 1A)

A description of each Level 2 and 3 function for this activity follows, and the combined Level 2 and 3 functional flow diagram for the waste generators is presented in Figure 3.2 at the end of this subsection.

Functional Steps	Functional Description(a)
1.1	Primary Storage Operations
1.1.1	Move Wastes to Primary Storage The wastes are moved from the primary source, the internal waste processing operations, the cask unloading operations, or temporary waste storage to the primary storage.
1.1.2	Primary Storage The wastes are stored and monitored in the primary storage facility, which is a water pool at power reactors, a dry vault at reprocessing plants, and either a pool or a vault at other waste generators.
1.1.3	Place Wastes in Temporary Storage The wastes are moved from the primary storage, the primary source, or cask unloading to a temporary storage location, which normally is a portion of the primary

**Functional
Steps**

Functional Description(a)

storage facility adjacent to a cask loading and unloading facility. (Not all waste generators have a temporary storage facility.)

1.2

Waste Processing

1.2.1

Move Wastes to Waste Processing

The wastes are moved from the primary waste storage to the waste processing facility.

1.2.2

Waste Processing

The wastes may be placed in canisters to prevent spread of radionuclides from the wastes or to facilitate the waste handling. These operations may include dismantling and volume reduction before the wastes are placed in the canisters.

1.3

Secondary Storage

1.3.1

Move Wastes to Secondary Storage

1.3.1.1

Prepare Transfer or Storage Cask for Loading

The cask is moved to the vehicle loading area at the process building. The cask is upended, removed from the vehicle and placed on a service pad or cart, and a work platform is installed around it. The vehicle is moved out of the vehicle loading area and stored until needed. The outer lid of the cask is removed. A radiation survey is made. The inner lid bolts on storage casks are loosened, and most are removed. The cask is filled with water if the loading station is a pool. The work platform is removed and the cask is moved to the loading position. The inner lid is removed or the cask shield plug is opened. The interior of the cask and the lid seals are inspected, and defective seals are replaced.

1.3.1.2

Load Wastes into Transfer or Storage Cask

The wastes are moved from the temporary waste storage facility to the transfer or storage cask as appropriate for the secondary storage design. The cask shield plug or inner lid is replaced.

1.3.1.3

Place Wastes in Secondary Storage

The transfer or storage cask is moved from the cask loading station to a service pad. The cask is drained, decontaminated, and filled with an inert gas, as appropriate, the outer lid is installed and sealed, and the cask is inspected and picked up by a transporter. The cask is transported to the secondary storage facility

**Functional
Steps**

Functional Description(a)

where storage casks are placed on a storage pad and the wastes in transfer casks are transferred into the secondary storage facility. The transfer casks are returned to the cask storage area or to the process building.

1.3.2

Secondary Storage

The wastes are stored and monitored in the secondary storage facility.

1.3.3

Remove Wastes from Secondary Storage

1.3.3.1

Move Wastes to Process Building

A transporter and transfer cask or an empty transporter is moved to the secondary storage facility where a full storage cask is picked up. If a transfer cask is used, wastes in the secondary storage facility are transferred into the transfer cask. The loaded cask is then transported to the process building and placed on a service pad or cart.

1.3.3.2

Remove Wastes from Cask

The outer lids are removed and the inner lids or shield plugs are loosened. The cask is filled with water, as appropriate, and placed in the cask loading station. The inner shield plugs or lids are removed. The wastes are transferred from the cask to the temporary waste storage facility.

1.3.3.3

Store Empty Storage/Transfer Casks

The interior of the empty cask is inspected and the inner lids or shield plugs are replaced. The cask is moved to the service pad or cart where it is drained and the outer lids are installed and sealed, as appropriate. The cask is decontaminated and placed on a transporter, moved to the empty cask storage facility and stored.

1.4

Transport Cask Loading

1.4.1

Prepare Transport Cask for Waste Loading

The cask is moved to the vehicle loading area by either a commercial driver or an onsite drive unit. The personnel barrier, impact limiters and cask tiedowns are removed from the cask. The cask is upended, removed from the vehicle and placed on a service pad or cart, and a work platform is installed around it. The vehicle is moved out of the vehicle loading area and stored until needed.

**Functional
Steps**

Functional Description(a)

The outer lid of the cask is removed. A radiation survey is made. The inner lid bolts are loosened, and most are removed. The cask is filled with water if the loading station is a pool. The work platform is removed and the cask is moved to the loading position. The inner lid is removed and the interior of the cask and the lid seals are inspected. Defective seals are replaced.

1.4.2

Place Wastes in Cask. Replace Lid

The waste is placed in the cask and the inner lid is replaced.

1.4.3

Prepare Full Cask for Shipment

The cask is moved to the service pad or cart and a work platform is placed around it. The cask is surveyed and decontaminated. As appropriate, the cask is drained and dried. The inner lid bolts are tightened. The cask is filled with an inert gas, a leak-test is made, the cask is sealed and the outer lid is installed. The work platform is removed, the cask is moved to the vehicle loading area and loaded on a vehicle.

A final radiation survey and decontamination is performed. Cask tiedowns, impact limiters and personnel barriers are installed, and a final inspection is made.

The vehicle is moved from the vehicle loading area to the cask and vehicle holding area.

1.5

Transport Cask Unloading

1.5.1

Prepare Transport Cask for Waste Unloading

The cask is moved to the vehicle loading area by either a commercial driver or an onsite drive unit. The personnel barrier, impact limiters and cask tiedowns are removed from the cask. The cask is upended, removed from the vehicle and placed on a service pad or cart, and a work platform is installed around it. The vehicle is moved out of the vehicle loading area and stored until needed.

The outer lid of the cask is removed. A radiation survey is made. The inner lid bolts are loosened, and most are removed. The cask is filled with water if the loading station is a pool. The work platform is removed and the cask is moved to the loading position. The inner lid is removed and the interior of the cask and the lid seals are inspected. Defective seals are replaced.

**Functional
Steps**

Functional Description(a)

1.5.2

Remove Wastes from Cask. Replace Lid

The wastes are removed from the cask and placed in the temporary or primary waste storage. The cask inner lid is replaced.

1.5.3

Prepare Empty Cask for Shipment

The cask is moved to the service pad or cart and a work platform is placed around it. The cask is surveyed and decontaminated. As appropriate, the cask is drained and dried. The inner lid bolts are tightened. The cask is filled with an inert gas, a leak-test is made, the cask is sealed and the outer lid is installed. The work platform is removed and the cask is moved to the vehicle loading area.

A final radiation survey and decontamination is performed. Cask tiedowns, impact limiters and personnel barriers are installed, and a final inspection is made.

The vehicle is moved from the vehicle loading area to the cask and vehicle holding area.

1.6

Transport Cask Receipt

1.6.1

Empty Transport Cask Receipt

Transport vehicles carrying empty transport casks are received at the waste source facility. A security inspection is made. The cask is moved to the washdown area, washed, surveyed for contamination, and moved to the vehicle holding area. The personnel barrier is retracted during the washing.

1.6.2

Full Transport Cask Receipt

Transport vehicles carrying full transport casks are received at the waste source facility. A security inspection is made. The cask is moved to the washdown area, washed, surveyed for contamination and moved to the vehicle holding area. The personnel barrier is retracted during the washing.

1.7

Transport Cask Lag Storage

1.7.1

Empty Transport Cask and Vehicle Holding

Before being shipped or loaded with wastes, vehicles containing empty casks may be placed in an onsite dispatch holding area until shipment or loading with wastes is scheduled.

**Functional
Steps**

Functional Description(a)

1.7.2

Full Transport Cask and Vehicle Holding

Before being shipped or transferred to a process building for waste unloading, vehicles containing full casks may be placed in an onsite holding area until shipment or the scheduled waste unloading.

1.8

Cask Preshipment Inspection and Servicing

1.8.1

Empty Cask Preshipment Inspection and Servicing

The casks and transport vehicles are inspected and serviced to assure proper conditions immediately prior to shipment.

1.8.2

Full Cask Preshipment Inspection and Servicing

The casks and transport vehicles are inspected and serviced to assure proper conditions immediately prior to shipment.

-
- (a) These operations are expected to occur for both transport and storage transportation casks. The wastes may be stored in water pools or in dry vaults.

FIGURE 3.2. Combined Level 2 and 3 Functional Flow Diagram for the Waste Generators (Module 1A)

3.2 LEVEL 2 AND 3 FUNCTIONAL DESCRIPTION FOR TRANSPORTATION (MODULE 2A)

The Level 2 functional description for transportation includes both transportation of casks and the major cask servicing activities. No Level 3 functional details are currently required for this element.

3.2.1 Transportation of Casks

The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in the cask transportation activity are illustrated in the Level 1 flow diagram in Figure 3.3.

FIGURE 3.3. Level 1 Functional Flow Diagram for Cask Transportation

A description of each Level 2 function for this activity follows, and the Level 2 functional flow diagram for this transportation activity is presented in Figure 3.4 at the end of this subsection.

Functional Steps	Functional Description
2.1	<u>Inspection and Acceptance</u>
2.1.1	DOE Acceptance of Shipment When a cask is ready for shipment, a radiological inspection is made. DOE inspects the shipment, accepts it and transfers it to the commercial carrier.
2.1.2	Commercial Carrier Accepts Cask and Vehicle The commercial carrier inspects the casks and vehicles to be certain that they are ready and safe for movement.

Functional Steps	Functional Description
2.2	<u>Cask Shipment</u>
2.2.1	Truck Transport for Waste Generators The empty truck casks are transported to the waste generators. The trailer supporting the full cask is connected to a drive unit. The cask is transported to the destination as a continuous normal freight shipment. Travel will occur primarily on interstate highways.
2.2.2	Rail/Barge Transport for Waste Generators The empty rail casks are transported to the waste generators. The vehicles supporting the full casks are connected to a dedicated commercial train. The dedicated train hauls the cars to the destination or to a barge dock. If transported by barge, the train cars are loaded on the barge, the barge transports the cars to a dock near the destination and the cars are moved by a dedicated train to the destination.
2.2.3	Rail Transport for the MRS The empty rail casks are transported to the MRS. The vehicles supporting the full casks are connected to a dedicated commercial train. The dedicated train hauls the cars to the repository.

FIGURE 3.4. Level 2 Functional Flow Diagram for Cask Transportation

3.2.2 Major Cask Servicing

The major cask servicing facilities provide dispatching, maintenance, inspection and servicing for the waste management system transport casks. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) for the cask servicing are illustrated in the Level 1 flow diagram in Figure 3.5.

FIGURE 3.5. Level 1 Functional Flow Diagram for Major Cask Servicing

A description of each Level 2 function for this activity follows, and the Level 2 functional flow diagram for this activity is presented in Figure 3.6 at the end of this subsection.

Functional Steps	Functional Description
2.3	Major Cask Servicing
2.3.1	Receive and Inspect Cask The cask/vehicle system arrives at the cask maintenance facility, is visually checked for damage and a radiological survey is performed.
2.3.2	Washdown Cask The cask and vehicle are thoroughly washed.
2.3.3	Decontaminate Cask A radiation survey is performed, and any cask with an excessively contaminated interior is decontaminated.
2.3.4	Repair Damaged Cask Damaged casks are repaired.

Functional Steps	Functional Description
2.3.5	Test and Inspect Cask The casks are tested and inspected as needed for recertification.
2.3.6	Maintain and Repair Vehicle Routine maintenance checks, tests and maintenance are performed.
2.3.7	Release Authorization The cask system is released from the cask maintenance facility and sent to the dispatch area for reuse (dispatch area is shared with normal MRS or repository empty cask dispatching).

S9004165.3

FIGURE 3.6. Level 2 Functional Flow Diagram for the Cask Servicing Facility

3.3 LEVEL 2 AND 3 FUNCTIONAL DESCRIPTION FOR THE MRS MODULES

The Level 2 and 3 functional description for the MRS facility includes descriptions for eight separate modules. These are identified as Modules 3A, 3B, 3C, 3D, 3E, 3F, 3G, and 3H. Each of the modules is described in a separate subsection. These modules describe four waste handling building designs and four waste storage facilities. Selection of various combinations of these modules will provide a description of any of the MRS facility designs being evaluated in the current waste management system scenarios.

3.3.1 Level 2 and 3 Functional Description for the MRS Transfer Facility (Module 3A)

The MRS Transfer Facility (TF) (Woods et al. 1990) is a temporary cask handling facility that could be used if wastes are stored without processing at the MRS facility in drywells, vaults or sealed storage casks. The primary activities at the TF are transfer of wastes from transport casks to storage or transfer casks and from storage or transfer casks to transport casks. The TF may also be used to transfer wastes from truck to rail casks. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.7. (It should be noted that Module 3B also is shown in Figure 3.7, since the functional descriptions for that module is the same as for Module 3A.) A description of the Level 2 and 3 functions for this activity follows, and Figure 3.8 at the end of this subsection presents the Level 2 and 3 functional flow diagram for this module.

3.0 MRS

FIGURE 3.7. Level 1 Functional Flow Diagram for the MRS Transfer Facility and the SFHB (Modules 3A and 3B)

Functional Steps	Functional Description
3.1	<u>Transport Cask Receipt</u>
3.1.1	Full Transport Cask Receipt When a full cask arrives at the MRS, a security inspection is made of the cask and transport vehicle and the bill of lading is reviewed to determine the cask contents. A survey of the cask and transport vehicle is taken for radiation and contamination. The transport vehicle is disconnected from the commercial drive unit and connected to an onsite drive unit.
3.1.2	Empty Transport Cask Receipt When an empty cask arrives at the MRS, a security inspection is made of the cask and transport vehicle and the bill of lading is reviewed to determine the cask contents. A survey of the cask and transport vehicle is taken for radiation and contamination. The transport vehicle is disconnected from the commercial drive unit and connected to an onsite drive unit.
3.2	<u>Transport Cask Lag Storage</u>
3.2.1	Full Cask and Vehicle Holding The full cask and vehicle may be stored in an onsite holding area if a problem is detected or until the scheduled unloading or shipment time.
3.2.2	Empty Cask and Vehicle Holding The empty cask and vehicle may be stored in an onsite holding area if a problem is detected or until the scheduled loading or shipment time.
3.3	<u>Cask Preshipment Inspection and Servicing</u>
3.3.1	Full Cask Preshipment Inspection and Servicing The casks and transport vehicles are inspected and serviced to assure proper conditions immediately prior to transfer to commercial carriers for shipment.
3.3.2	Empty Cask Preshipment Inspection and Servicing The casks and transport vehicles are inspected and serviced to assure proper conditions immediately prior to transfer to commercial carriers for shipment.

Functional Steps	Functional Description
3.4	Transport Cask Unloading
3.4.1	Prepare Transport Cask for Unloading
3.4.1.1	Wash Cask The cask and vehicle are moved to the washdown area and washed. The personnel barrier is retracted during the washing.
3.4.1.2	Prepare Cask for Removal from Vehicle The cask and vehicle are moved to the receiving, inspection and shipping area where the impact limiters and tiedowns are removed from the cask. A contamination and radiation survey of the cask exterior is made and it is decontaminated as necessary. Damaged casks are diverted to the support services facilities (Step 2.3), if necessary, before unloading.
3.4.1.3	Unload Cask from Vehicle The cask is removed from the transport vehicle and placed on a cart. Restraints are installed. The cart and cask are moved to the cask handling, preparation and decontamination room. The vehicle remains parked at the dock.
3.4.1.4	Remove Cask Outer Lid The cask outer lid is removed.
3.4.1.5	Vent and Sample Cask Gases. Remove Inner Lid Fasteners. The cask internal pressure is checked and vented to the ventilation system. The vent gas radioactivity is measured and appropriate precautions are adopted to reduce radiation exposure of personnel, if high radioactivity is measured. The fasteners on the cask inner lid are loosened and the cask contamination barrier adapter is installed.
3.4.1.6	Move Cask to Unloading Room. Engage Shields. The cask is moved to the cask unloading room where it is positioned for the removal of the wastes. The cask contamination barrier and shadow shields are engaged.
3.4.1.7	Remove Cell Plugs and Cask Inner Lid The shield plugs are removed from the transfer cell entry port. The cask inner lid is removed.
3.4.2	Remove Contents of Cask The interior of the cask is inspected to determine the contents of the cask. The contents of the cask are removed. DOE reverifies the cask contents.

**Functional
Steps**

Functional Description

3.4.3

Prepare Empty Transport Cask for Shipment

3.4.3.1

Inspect Cask Interior. Install Cask Inner Lid. Install Cell Port Plug.

The cask is inspected to verify that it is clear of waste material. The inner lid is replaced and the cell entry port plug is replaced.

3.4.3.2

Remove Contamination Shields

The cask contamination barrier and shadow shields are disengaged.

3.4.3.3

Decontaminate Cask

The empty cask and cart are moved into the cask handling, preparation and decontamination room. The contamination barrier adapter is removed. The cask is surveyed for contamination and decontaminated if necessary, and the inner lid is secured.

3.4.3.4

Install Cask Outer Lid

The outer lid is replaced.

3.4.3.5

Load Cask on Transport Vehicle

The cask is moved to the cask receiving, inspection and shipping area, and loaded onto a transport vehicle. It might be transferred to the support services facilities for repairs, internal decontamination or recertification (Step 2.3).

3.4.3.6

Prepare Loaded Vehicle for Shipment

The impact limiters, cask shipping restraints and personnel barriers are installed. Minor or routine maintenance is performed.

3.4.4

Move Loaded Vehicle to Holding Area

The loaded vehicle is moved to the empty cask holding area.

3.5

Waste Lag Storage

After being unloaded, the fuel assemblies and other wastes may be placed in the waste lag storage in the transfer or process cell. Some wastes may be transferred directly out of the cell for placing in storage, transport or transfer casks. The wastes being returned from storage also may be placed in this lag storage.

Functional Steps	Functional Description
3.8	<u>Interface to Long-Term Storage</u>
3.8.1	Prepare Cask for Loading Wastes
3.8.1.1	Remove Cask Lid.(a) Move Cask to Hot Cell Port. Engage Shields The storage cask lid is removed. The cask is moved to the loadout area. Contamination barriers and shadow shields are installed between the cask and the canyon or transfer cell exit port.
3.8.1.2	Remove Port Plug and Cask Shield Plug The cell exit port plug is removed, and the shield plug is removed from the cask or the gate is opened.
3.8.2	Place Wastes in Cask The wastes are loaded into the cask.
3.8.3	Prepare Full Cask for Transport to Storage
3.8.3.1	Install Cask Shield Plug and Port Plug The cask shield plug is installed or the gate is closed and the canyon or transfer cell exit port plug is replaced.
3.8.3.2	Disengage shields. Move Cask to Discharge Corridor. Survey Cask The contamination barrier and shadow shields are removed. The cask is decontaminated if necessary. A radiation scan of the cask and a contamination survey of the cask top are made.
3.8.3.3	Decontaminate and Inert Cask. Install Cask Lid.(a) The cask and transporter are moved to the transfer/discharge corridor. The cask is filled with inert gas and the lid is installed on the cask.
3.8.3.4	Weld Lid and Inspect Weld(a) The lid is welded to the cavity liner flange. The weld is inspected and rewelded as necessary to assure a seal.
3.8.4	Prepare Cask for Waste Removal

(a) Lid activities apply only to sealed storage casks. Transfer casks do not have lids, they have shield gates.

**Functional
Steps**

Functional Description

- 3.8.4.1 Remove Cask Lid. (a) Move Cask to Cell Port. Engage Cask Shields**
The welds on the storage cask lid are cut and the lid is removed. The transporter and cask are moved to the cask loadout and decontamination room. The contamination barrier and shadow shield are engaged.
- 3.8.4.2 Remove Port Plugs and Cask Shield Plug**
The transfer cell exit port plug and the cask shield plug are removed or the gate is opened.
- 3.8.5 Remove Wastes from Cask**
The wastes are lifted out of the cask, inspected, and decontaminated if necessary for transfer to a transport cask.
- 3.8.6 Disconnect Empty Cask and Prepare for Storage**
- 3.8.6.1 Inspect Cask Interior. Install Cask Shield and Port Plugs**
The cask interior is inspected. The cask shield plug is replaced or the gate is closed and the transfer cell exit port plug is replaced.
- 3.8.6.2 Disengage Shields. Disconnect Cask from Port and Decontaminate Cask**
The contamination barrier and shadow shield are disengaged and the cask is decontaminated. The cask is moved to the discharge corridor where the lid is installed on storage casks.
- 3.9 Transport Cask Loading**
- 3.9.1 Prepare Transport Cask for Loading**
- 3.9.1.1 Wash Cask**
The cask is moved to the washdown area and washed. The personnel barrier is retracted during the washing.
- 3.9.1.2 Prepare Cask for Removal from Vehicle**
The cask is moved to the receiving, inspection and shipping area. The impact limiters and cask tiedowns are removed from the cask. A contamination and radiation survey of the cask exterior is made and it is decontaminated as necessary. Damaged casks are diverted to the support services facilities (Step 2.3) if necessary before loading.

Functional Steps	Functional Description
3.9.1.3	Unload Cask from Vehicle The cask is upended, removed from the vehicle, and placed on a cart. Restraints are installed. The cart and cask are moved to the cask preparation room and a work platform is positioned around the cask. The vehicle remains parked near the dock.
3.9.1.4	Remove Cask Outer Lid. Vent Cask. Remove Inner Lid Fasteners. Move Cask to Unloading Room. Engage Shields The outer lid of the cask is removed. A radiation survey is made. The inner lid bolts are loosened. The work platform is removed and the cask is moved to the unloading room where it is positioned under the transfer or canyon cell entry port. The cask contamination barrier and shadow shields are engaged.
3.9.1.5	Remove Cell Plugs and Cask Inner Lid The shield plugs are removed from the transfer or canyon cell port. The cask inner lid is removed and the cask interior is inspected to determine that the cask is empty and contains the correct insert for the wastes to be shipped.
3.9.2	Place Wastes in Transport Cask The waste is transferred into the transport cask.
3.9.3	Prepare Full Transport Cask for Shipment
3.9.3.1	Inspect Cask Interior. Install Cask Inner Lid and Port Plugs The cask interior is inspected to determine if it is properly loaded and the inner lid is installed. The transfer or canyon cell port plug is replaced.
3.9.3.2	Remove Shields. Decontaminate Cask. Install Cask Outer Lid The contamination barrier and shadow shields are disengaged. The cask cart and cask are moved to the cask preparation room. The cask outer surface is surveyed and decontaminated if necessary. The cask is filled with inert gas, sealed and leak-tested. The outer lid is installed.
3.9.3.3	Load Transport Cask onto Vehicle The cask cart with the cask is moved to the receiving, inspection and shipping area. The cask is removed from the cask cart and loaded onto the railcar.

**Functional
Steps**

Functional Description

3.9.3.4

Prepare Loaded Vehicle for Shipment

The impact limiters, cask shipping restraints and personnel barriers are installed. Minor or routine maintenance is done.

3.9.4

Move Loaded Vehicle to Cask Holding Area

The loaded vehicle is moved from the process building to the full cask holding area.

3.16

Balance-of-Plant Operations and Support

Balance-of-plant activities such as water and sewage system operations, maintenance, and security functions are provided for both the process and facility operations.

Note: Waste flow is shown by heavy lines. Cask lid activities occur only for sealed storage and transport casks.

FIGURE 3.8. Combined Level 2 and 3 Functional Flow Diagram

for the Transfer Facility (Module 3A) and SFHB (Module 3B)

3.3.2 Level 2 and 3 Functional Description for the Spent Fuel Handling Building (SFHB) (Module 3B)

The SFHB (Woods, et al. 1988) is a permanent waste transfer facility that could be used if wastes are stored in vaults, drywells or sealed storage casks without processing at the MRS facility. The primary activities in the SFHB are transfer of wastes from transport casks to sealed storage or transfer casks and then from the storage or transfer casks back to transport casks. The SFHB may also be used to transfer wastes from truck transport casks to rail transport casks. The MRS portion of the overall waste management system Level 1 functional flow diagram (Figure 2.1) and the functional descriptions for this module are the same as for Module 3A. Figure 3.8 at the end of Subsection 3.3.1 presents the Level 2 and 3 functional flow diagram for this module.

3.3.3 Level 2 and 3 Functional Description for the MRS Receiving and Handling Building (RHB) Without Consolidation (Module 3C)

The RHB (Woods et al. 1988) without consolidation is a facility that would be required if the wastes are packaged at the MRS facility and then stored before shipment to the repository. (They may also be packaged and shipped directly to the repository without storage.) The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.9. Figure 3.10 at the end of this subsection presents the Level 2 and 3 functional flow diagram for this module.

This description includes all functional steps described above in Section 3.3.1 for Module 3A (Transfer Facility) plus the following steps for processing in the receiving and handling building. In the RHB, the hot cell activities that occurred in the transfer cell at the TF will occur in the process or canyon cells.

<u>Functional Steps</u>	<u>Functional Description</u>
3.6.4.3	Weld Lid on Container The container is moved to the canyon cell weld station where it is evacuated and backfilled with an inert gas and the lid is welded on.
3.6.4.4	Decontaminate and Test The container is decontaminated and a leak-test is performed. A contamination survey is performed and the container is decontaminated if necessary. An ultrasonic weld inspection is performed and the lid is removed and rewelded on the container if necessary.
3.7	<u>Process Lag Storage</u>
3.7.1	Process Lag Storage The canister or container may be stored for long periods of time in the large process lag storage in the canyon cells.
3.7.2	Outgoing Lag Storage The canisters or containers may be temporarily stored in the small outgoing lag storage in the canyon cells while awaiting transfer to the interim storage or shipment offsite.

FIGURE 3.10. Combined Level 2 and 3 Functional Flow

Diagram for the RHB Without Consolidation (Module 3C)

3.3.4 Level 2 and 3 Functional Description for the MRS Receiving and Handling Building (RHB) with Consolidation (Module 3D)

The RHB (Woods et al. 1988) with consolidation is a facility that would be required if the wastes are consolidated and then packaged and stored at the MRS facility before shipment to the repository. (They may also be packaged and shipped directly to the repository without storage.) The packaging may be in either canisters or containers. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.9, and Figure 3.11 at the end of this subsection presents the Level 2 and 3 functional flow diagram for this module. This module includes all functional steps described above in Sections 3.3.1 and 3.3.3 for Modules 3A and 3C plus the following steps for consolidating and placing wastes in canisters in the receiving and handling building.

<u>Functional Steps</u>	<u>Functional Description</u>
3.6	<u>Waste Processing</u>
3.6.1	Move Wastes to Processing The wastes are moved to a processing station in the process cell.
3.6.2.1	Remove Fuel Rods and Reconfigure The fuel assembly nozzles are separated from the assembly and the fuel rods are removed and reconfigured into a closely packed bundle corresponding to the MRS canisters or repository-specific containers.
3.6.2.2	Shred Activated Metals In the process cell, activated metals from the fuel disassembly station are moved to the volume-reduction station, where they are shredded.
3.6.2.3	Load Activated Metals into Storage Drum The volume-reduced activated metals and other wastes too massive for shredding are loaded into a storage drum and a lid is secured on the drum.
3.6.2.4	Decontaminate Drum The drums of shredded metals are decontaminated.

**Functional
Steps**

Functional Description

3.6.3.1

Load Waste into Canister

An empty, clean canister in the canyon cell is aligned with one of the loadout ports in the canyon cell shield wall. The wastes in the process or decontamination cell are loaded through that port in the shield wall into the canister. Other wastes in drums or canisters are loaded into the canisters by the bridge cranes.

3.6.4.1

Weld Lid on Canister

The canister is moved to the canyon cell weld station where it is evacuated and backfilled with an inert gas and the lid is welded on.

3.6.4.2

Decontaminate and Test

The canister is decontaminated and a leak-test is performed. A contamination survey is performed and the canister is decontaminated if necessary. An ultrasonic weld inspection is performed and the lid is removed and rewelded on the canister if necessary.

Note: Waste flow is shown by heavy lines.

FIGURE 3.11. Combined Level 2 and 3 Functional Flow

S9101032.17

Diagram for the RHB With Consolidation (Module 3D)

3.3.5 Level 2 and 3 Functional Description for the MRS Transportable Storage (S/T) Cask Storage (Module 3E)

The S/T cask storage (Woods et al. 1988) is a facility that would be required for storage of wastes in S/T casks at the MRS facility. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.12.

FIGURE 3.12. Level 1 Functional Flow Diagram for the MRS Transportable Storage Cask Interim Storage Area (Module 3E)

A description of the Level 2 and 3 functions for this activity follows. Figure 3.13 at the end of this subsection presents the Level 2 and 3 functional flow diagram for this module.

Functional Steps	Functional Description (a)
3.10.1	S/T Cask Storage
3.10.1.1	Prepare S/T Cask for Removal from Vehicle The cask and vehicle are moved to the receiving building where the impact limiters and tiedowns are removed from the cask. A contamination and radiation survey of the cask exterior is made and it is decontaminated as necessary. Damaged casks are diverted to the support services facilities (Step 2.3) if necessary before unloading.
3.10.1.2	Unload S/T Cask from Vehicle The cask is removed from the transport vehicle and placed on an onsite transporter.
3.10.1.3	Move S/T Cask to Storage Yard The cask is moved by the transporter from the receiving building to the storage yard.
3.10.1.4	Place S/T Cask in Storage The cask is lifted off the transporter and placed on a pair of storage saddles. The transporter is returned to the receiving building.
3.10.1.5	Store and Monitor S/T Casks The wastes are stored in the interim storage facility. A representative sample of the casks is monitored to determine the storage conditions.
3.10.1.6	Place S/T Cask on Transporter A transporter is driven to the location of a cask. The cask is lifted off the storage saddles and placed on the transporter.
3.10.1.7	Transport S/T Cask to Process Building The transporter carries the cask to the process building.

- (a) Functions 3.1, 3.2, 4.1, and 4.2 also are applicable for S/T casks. Those functions are described in the modules for the process buildings and will not be repeated. A process building (SFHB, RHB, TF or WHB) is expected to be included in any facility containing an S/T cask storage activity.

FIGURE 3.13. Level 2 and 3 Functional Flow Diagram for the Transportable Storage Cask Interim Storage (Module 3E)

3.3.6 Level 2 and 3 Functional Description for the MRS Vault Storage (Module 3F)

The vault storage facility (Woods et al. 1988) would be required if wastes are stored in vaults at the MRS facility. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.14.

FIGURE 3.14. Level 1 Functional Flow Diagram for the MRS Vault Interim Storage Facility (Module 3F), Drywell Interim Storage Facility (Module 3G) and Sealed Storage Cask Interim Storage Facility (Module 3H)

A description of the Level 2 and 3 functions for this activity follows, and Figure 3.15 at the end of this subsection presents the Level 2 and 3 functional flow diagram for this module.

Functional Steps	Functional Description
3.10.2	<u>Vault Storage</u>
3.10.2.1	Transfer Waste to Fuel Handling Machine (FHM) The loaded transfer cask is moved to the vault building and connected to the bottom of a transfer port in the vault storage hall. The FHM travels to the transfer port. The port plug is removed, the FHM is connected to the transfer port, the transfer cask gate is opened, the FHM gate is opened, the waste is lifted into the FHM, the transfer cask gate is closed, the FHM gate is closed, the transfer cask is disconnected from the transfer port, and the plug is placed in the transfer port.
3.10.2.2	Place Wastes in Storage The FHM carries the wastes to the vault storage location. The FHM is connected to the vault storage location, the FHM gate is opened, the vault plug is removed, the wastes are lowered into the storage position, the vault plug is replaced, the storage location is filled with inert gas and sealed, the FHM gate is closed, and the FHM is disconnected from the storage location.
3.10.2.3	Store and Monitor Wastes The wastes are stored in the vault storage position. A representative sample of the storage positions is monitored to determine the storage conditions.
3.10.2.4	Transfer Wastes to Transfer Cask A transfer cask is connected to the bottom of a transfer port in the vault storage hall. The FHM is stationed over the vault storage location. The FHM gate is opened, the vault plug is removed, the wastes are lifted into the FHM, the vault plug is replaced, the FHM gate is closed, the FHM is disconnected from the storage location, the FHM moves to the vault transfer port, the port plug is removed, the FHM is connected to the port, the FHM and transfer cask gates are opened, the wastes are lowered into the transfer cask, the transfer cask gate is closed, the transfer cask is disconnected from the port, the FHM gate is closed, the FHM is disconnected from the port, and the port plug is replaced.
3.10.2.5	Transport to Process Building The transporter carries the cask and wastes to the process building (SFHB, RHB, or TF).

FIGURE 3.15. Level 2 and 3 Functional Flow Diagram for Vault Storage (Module 3F)

3.3.7 Level 2 and 3 Functional Description for the MRS Drywell Storage (Module 3G)

The drywell storage facility (Woods et al. 1988) would be required if wastes are stored in drywells at the MRS facility. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.14. A description of the Level 2 and 3 functions for this activity follows, and Figure 3.16 at the end of this subsection presents the Level 2 and 3 functional flow diagram for this module.

<u>Functional Steps</u>	<u>Functional Description</u>
3.10.3	<u>Drywell Storage</u>
3.10.3.1	Transfer Wastes to Drywell The transfer cask is moved to and stationed over the drywell. The transfer cask is connected to the drywell, the transfer cask gate is opened, the drywell plug is removed, the wastes are lowered into the drywell, the plug is replaced, the transfer cask gate is closed, the transfer cask is disconnected from the drywell, the drywell is filled with inert gas, and the drywell plug is sealed.
3.10.3.2	Store and Monitor Wastes The wastes are stored in the drywell. A representative sample of the drywells is monitored to determine the storage conditions.
3.10.3.3	Transfer Wastes to Transfer Cask The drywell plug is unsealed and the transfer cask is stationed over the drywell. The transfer cask is connected to the drywell, the cask gate is opened, the drywell plug is removed, the wastes are lifted into the cask, the drywell plug is replaced, the cask gate is closed, and the cask is disconnected from the drywell.
3.10.3.4	Transport to Process Building The transporter carries the cask and wastes to the process building.

FIGURE 3.16. Level 2 and 3 Functional Flow Diagram for Drywell Storage (Module 3G)

3.3.8 Level 2 and 3 Functional Description for the MRS Sealed Storage Cask Storage (Module 3H)

The sealed storage cask storage facility would be required if wastes were stored in sealed storage casks at the MRS facility. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.14. A description of the Level 2 and Level 3 functions for this activity follows, and Figure 3.17 at the end of this subsection presents the Level 2 and 3 functional flow diagram for this module.

<u>Functional Steps</u>	<u>Functional Description</u>
3.10.4	<u>Sealed Storage Cask</u>
3.10.4.1	Place Empty Storage Cask on Transporter An empty storage cask is picked up from the storage pad by a transporter.
3.10.4.2	Move Empty Cask to Process Building The empty cask on a transporter is moved into the transfer/discharge corridor.
3.10.4.3	Move Loaded Cask to Storage Facility The transporter carries the loaded cask to the long-term storage facility.
3.10.4.4	Place Wastes in Long-Term Storage The filled cask is removed from the transporter and placed in storage. All activities required to prepare and seal the storage area are included.
3.10.4.5	Store and Monitor Long-Term Storage The wastes are stored in the long-term storage facility. A representative sample of the waste is monitored to detect any change in the storage conditions.
3.10.4.6	Place Wastes on Transporter The filled cask is removed from the long-term storage and placed on the transporter.
3.10.4.7	Move Wastes to Process Building The transporter carries the loaded cask to the process building.

Functional Steps	Functional Description
3.10.4.8	Move Empty Cask to Storage Yard The empty cask is moved from the process building to the empty cask storage yard.
3.10.4.9	Place Empty Cask in Storage The empty cask is lifted off the transporter and placed on a storage pad.
3.10.4.10	Store and Monitor Empty Casks The used empty casks are monitored for radioisotope releases during storage.

FIGURE 3.17. Level 2 and 3 Functional Flow Diagram for Sealed Storage Cask Storage (Module 3H)

3.4 COMBINED LEVEL 2 AND 3 FUNCTIONAL DESCRIPTION FOR THE REPOSITORY MODULES

The combined Level 2 and 3 functional description for the repository includes descriptions for 10 separate modules. These are identified as Modules 4A, 4B, 4C, 4D, 4E, 4F, 4G, 4H, 4I, and 4J. Each of these modules is described in a separate subsection. These modules describe one waste surface storage facility, eight waste handling building designs, and one underground repository design. Selection of various combinations of these modules will provide a description of a specific repository facility design.

3.4.1 Combined Level 2 and 3 Functional Description for the Transportable Storage Cask Interim Storage (Module 4A)

This module provides a description of the receiving building and S/T cask storage facility (Woods et al. 1988) if wastes were stored temporarily in S/T casks at the repository before being processed and placed in the underground repository. This module has not been designed and is assumed to be identical to Module 3E at the MRS facility (Section 3.3.5).

3.4.2 Combined Level 2 and 3 Functional Description for the Repository Pass-Through WHB-1 for Containerized Intact Spent Fuel (Module 4B)

This pass-through WHB-1 (Weston 1989) is required if intact spent fuel is received from the MRS facility in repository containers and is emplaced in the underground repository with no processing. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.18. A description of the Level 2 and 3 function for this module follows, and Figure 3.19 at the end of this subsection presents the Level 2 and 3 functional flow diagram for this module.

S9101032.1

3.49

**Functional
Steps**

Functional Description

4.1	<u>Full Transport Cask Receipt</u> When a cask arrives at the repository, a security inspection is made of the cask and transport vehicle and the bill of lading is reviewed to determine the cask contents. A survey of the cask and transport vehicle is taken for radiation and contamination. The transport vehicle is disconnected from the commercial drive unit and connected to an onsite drive unit.
4.2	<u>Transport Cask Lag Storage</u>
4.2.1	<u>Full Cask and Vehicle Holding</u> The full cask and vehicle may be stored in an onsite holding area if a problem is detected or until the scheduled unloading or shipment time.
4.2.2	<u>Empty Cask and Vehicle Holding</u> The empty cask and vehicle may be stored in an onsite holding area if a problem is detected or until the scheduled loading or shipment time.
4.3	<u>Cask Preshipment Inspection and Servicing</u> The cask and vehicle are inspected to determine if they are ready for shipment and repaired and serviced as needed.
4.4	<u>Transport Cask Unloading</u>
4.4.1	<u>Prepare Transport Cask for Unloading</u>
4.4.1.1	<u>Wash Cask</u> The cask and vehicle are moved to the washdown area and washed. The personnel barrier is retracted during the washing.
4.4.1.2	<u>Prepare Cask for Removal from Vehicle</u> The cask and vehicle are moved to the receiving, inspection and shipping area where the impact limiters and tie-downs are removed from the cask. A contamination and radiation survey of the cask exterior is made and it is decontaminated as necessary. Damaged casks are diverted to the support services facilities (Step 2.3), if necessary, before unloading.
4.4.1.3	<u>Unload Cask from Vehicle</u> The cask is removed from the transport vehicle and placed on a cart. Restraints are installed. The cart and cask are moved to the cask handling, preparation and decontamination room. The vehicle remains parked at the dock.

Functional Steps	Functional Description
4.4.1.4	Remove Cask Outer Lid The cask outer lid is removed.
4.4.1.5	Vent and Sample Cask Gases. Loosen Inner Lid. The cask internal pressure is checked and vented to the ventilation system. The vent gas radioactivity is measured and appropriate precautions are adopted to reduce radiation exposure of personnel, if high radioactivity is measured. The fasteners on the cask inner lid are loosened.
4.4.1.6	Install Contamination Barrier Adapter The cask contamination barrier adapter is installed.
4.4.1.7	Move Cask to Unloading Room. Engage Shields. The cask is moved to the cask unloading room where it is positioned for the removal of the wastes. The cask contamination barrier and the shadow shield are engaged.
4.4.1.8	Remove Cell Plugs and Cask Inner Lid The shield plugs are removed from the cask unloading cell entry port. The cask inner lid is removed.
4.4.2	Remove Contents of Cask The interior of the cask is inspected to determine the contents of the cask. The contents of the cask are removed. DOE reverifies the cask contents.
4.4.3	Prepare Empty Transport Cask for Shipment
4.4.3.1	Inspect Cask Interior. Install Cask Inner Lid. Install Cell Port Plug. The cask is inspected to verify that it is clear of waste material. The inner lid is replaced. The cask unloading cell entry port plug is replaced.
4.4.3.2	Remove Shields and Move Cask to Preparation Room The cask contamination barrier and shadow shield are disengaged. The empty cask and cart are moved into the cask handling, preparation and decontamination room.
4.4.3.3	Decontamination Cask and Secure Inner Lid The contamination barrier adapter is removed. The cask is surveyed for contamination and decontaminated if necessary and the inner lid is secured.
4.4.3.4	Install Cask Outer Lid The outer lid is replaced.

<u>Functional Steps</u>	<u>Functional Description</u>
4.4.3.5	Load Cask on Transport Vehicle The cask is moved to the cask receiving, inspection and shipping area and loaded onto a transport vehicle. It might be transferred to the support services facilities for repairs, internal decontamination or recertification (Step 2.3).
4.4.3.6	Prepare Loaded Vehicle for Shipment The impact limiters, cask shipping restraints and personnel barriers are installed. Minor or routine maintenance is done.
4.4.4	Move Loaded Vehicle to Holding Area The loaded vehicle is moved to the empty cask holding area.
4.5	<u>Waste Lag Storage</u> After being unloaded, the fuel assemblies and other wastes are normally placed in the incoming lag storage in the cask unloading cell. Some wastes may be transferred directly to the process or testing activities.
4.6	<u>Waste Processing</u>
4.6.4	Prepare Wastes for Storage
4.6.4.2	Move Wastes to Weld Inspection Station The container is placed in the inspection station.
4.6.4.3	Inspect Weld The weld is inspected at the inspection station.
4.6.4.4	Move Wastes to Leak Test Station The container is lifted out of the inspection station and moved to the leak test station.
4.6.4.5	Leak Test Container The container is tested for leaks at the leak test station.
4.6.4.6	Move Wastes to Decontamination and Transfer Station The container is lifted out of the leak test station and moved to the decontamination and transfer station.
4.6.4.7	Decontaminate Container The container is decontaminated in the decontamination chamber.

<u>Functional Steps</u>	<u>Functional Description</u>
4.6.4.8	Move Container to Inspection Cell The container is moved to the inspection cell by moving the decontamination chamber to that cell.
4.6.4.9	Survey Container The surface contamination on the container is determined by taking surface swabs and measuring the radioactivity collected by the swabs. If the radioactivity is above the permissible level, the container is decontaminated again.
4.6.4.10	Rework Defective Containers If the container tests defective, the lid is cut off and a new lid is welded on.
4.7	<u>Container Vault Storage</u>
4.7.1	Place Wastes in Vault Storage
4.7.1.1	Transfer Container to Transfer Cart The container is lifted out of the decontamination chamber and placed in a transfer cart.
4.7.1.2	Transfer Container to Vault Building The transfer cart carries the containers through the transfer tunnel to the vault building.
4.7.1.3	Place Container in Vault The container transfer machine lifts the container out of the transfer cart, transports it to the vault storage position and places it in that position.
4.7.2	Store and Monitor Wastes in Vault Storage The container is stored in the vault storage position until scheduled for placement in the repository.
4.7.3	Remove Wastes from Vault Storage The container transfer machine lifts the container out of the vault storage position, transports it to the transfer bay and places it in a transfer cart.
4.11	<u>Interface to Waste Emplacement</u>
4.11.1	Load Container into Transporter
4.11.1.1	Prepare Transporter for Loading An empty transporter at the ramp portal or at the transporter holding area is moved to the vault building and parked in the transfer bay over a waste transfer port.

**Functional
Steps**

Functional Description

4.11.1.2

Load Transporter

A container of waste is lifted out of the transfer cart and into the waste transporter.

4.16

Balance-of-Plant Operations and Support

Balance-of-Plant activities such as water and sewage system operations, maintenance, and security functions are provided for both the process and facility operations.

FIGURE 3.19. Level 2 and 3 Functional Flow Diagram for the Containment Process

Note: Waste flow is indicated by heavy lines.

inerized Intact Spent Fuel Pass-Through WHB-1 (Modules 4B and 4C)

3.4.3 Combined Level 2 and 3 Functional Description for the Repository
Pass-Through WHB-1 for Containerized Consolidated Spent Fuel
(Module 4C)

This pass-through WHB-1 (Weston 1989) is required if consolidated spent fuel is received from the MRS facility in repository containers and is emplaced in the underground repository without processing.

The functional description for this module is identical to the description for Module 4B.

3.4.4 Combined Level 2 and 3 Functional Description for the Repository
Low-Volume WHB-1 for Containerizing Intact Spent Fuel (Module 4D)

This WHB-1 (Weston 1989) is required if small quantities (~400 MTU/yr) of spent fuel must be received and emplaced at the repository before operation of a consolidation and containerization WHB-2 (Modules 4H or 4I) begins. (After Module 4H or 4I starts operating, the Module 4D facilities will be used for containerizing HLW canisters.) The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.18, and Figure 3.20 at the end of this subsection presents the combined Level 2 and 3 functional flow diagram for this module. This module includes all functional steps described above in Section 3.4.2 for Module 4B (Pass-Through Waste Handling Building), plus the following steps.

<u>Functional Steps</u>	<u>Functional Description</u>
4.6.3	Load Wastes into Container The wastes are placed in a disposal container. The wastes may pass through the waste inspection station if inspection is necessary before placing in a container.
4.6.4.1	Weld Lid to Container The container is backfilled with an inert gas and the lid is welded on.

FIGURE 3.20. Level 2 and 3 Functional Flow Diagram for Low-Volume Intact

t Fuel WHB-1 (Module 4D)

3.4.5 Combined Level 2 and 3 Functional Description for the Repository WHB-1 for Containerizing Intact Fuel Without an MRS (Module 4E)

This WHB-1 (Weston 1989) is required if large quantities of intact spent fuel assemblies and other wastes are received directly from the waste generators, containerized and emplaced in the repository. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.18, and Figure 3.21 at the end of this subsection presents the combined Level 2 and 3 functional flow diagram for this module. This module includes all functional steps described above in Sections 3.4.2 and 3.4.4 for Modules 4B and 4D, plus the following steps for preprocessing for containerization.

<u>Functional Steps</u>	<u>Functional Description</u>
4.6.1	Move Wastes to Processing The wastes are moved to a process operation.
4.6.2	Process Wastes
4.6.2.3	Preprocessing for Containerizing Some of the wastes received at the repository may have to be processed to permit containerizing. The processing will depend on the condition and packaging of the wastes as received at the repository. This processing has not yet been defined.

FIGURE 3.21. Level 2 and 3 Functional Flow Diagram for High-Volume Container

S9101032.11

zing WHB-1s Without Consolidation at the Repository (Modules 4E, 4F and 4G)

3.4.6 Combined Level 2 and 3 Functional Description for the Repository WHB-1 for Containerizing Intact Fuel with an MRS (Module 4F)

This WHB-1 (Weston 1989) is required if bare spent fuel assemblies are received from the MRS facility, containerized and emplaced in the repository.

The functional description for this module is identical to the description for Module 4E.

3.4.7 Level 2 Functional Description for the Repository WHB-1 for Containerizing Consolidated Fuel from an MRS (Module 4G)

This WHB-1 (Weston 1989) is required if large quantities of consolidated and canistered wastes are received, containerized and emplaced in the repository. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in Figure 3.18, and Figure 3.21 at the end of the previous subsection presents the Level 2 and 3 functional flow diagram for this module. The functional description for this module is identical to the functional steps in Sections 3.4.2, 3.4.4, and 3.4.5 for Modules 4B, 4D, and 4E.

3.4.8 Combined Level 2 and 3 Functional Description for the Repository WHB-2 with Consolidation and Containerization and Without an MRS (Module 4H)

This WHB-2 (Weston 1989) is required if large quantities of intact spent fuel assemblies are received directly from the waste generators at the repository, consolidated, containerized and emplaced in the underground repository. The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in the Level 1 flow diagram in Figure 3.18, and Figure 3.22 at the end of this subsection presents the Level 2 and 3 functional flow diagram for this module. This description includes all functional steps described above in Sections 3.4.2, 3.4.4, and 3.4.5 for Modules 4B, 4D, and 4E, plus the following steps for consolidation.

**Functional
Steps**

Functional Description

4.6.2.1

Remove Fuel Rods and Reconfigure

The fuel assembly nozzles are separated from the assembly and the fuel rods are removed and reconfigured into a closely packed bundle corresponding to the repository-specific containers.

4.6.2.2

Shred Activated Metals

In the consolidation cell, activated metals from the fuel disassembly station are moved to the volume-reduction station, where they are shredded.

FIGURE 3.22. Level 2 and 3 Functional Flow Diagram for WHB-2s for Consolidation

(a) There is no MRS for Module 4 H.

S9101032.8

ing and Containerizing Wastes (Modules 4H and 4I)

3.4.9 Level 2 Functional Description for the Repository WHB-2 with Consolidation and Containerization and with an MRS (Module 4I)

This WHB-2 (Weston 1989) is required if bare spent fuel assemblies are received from the MRS facility, consolidated, containerized and emplaced in the repository.

The functional description for this module is identical to the description for Module 4H.

3.4.10 Level 2 Functional Description for the Repository Underground Facilities (Module 4J)

This module describes the underground activities at the repository (Weston 1989). The portions of the overall waste management system Level 1 functional flow diagram (Figure 2.1) that are included in this module are illustrated in Figure 3.23.

FIGURE 3.23. Level 1 Functional Flow Diagram for the Repository Underground Facilities (Module 4J)

A description of the Level 2 and 3 functions for this module follows, and Figure 3.24 at the end of this subsection presents the Level 2 and 3 functional flow diagram for this module.

Functional Steps	Functional Description
4.12	<u>Waste Emplacement Operations</u>
4.12.1	Transport and Emplace Wastes
4.12.1.1	Move Transporter to Ramp Portal The loaded transporter is moved from the transfer bay in the vault building to the ramp portal.
4.12.1.2	Move Transporter to Disposal Area The container transporter is moved through the underground ramps and tunnels to the emplacement location, where a borehole has been prepared.
4.12.1.3	Emplace Container At the emplacement site, the cask is rotated to a vertical position or aligned horizontally with the borehole, depending on its emplacement orientation. The cask is connected to the borehole, the borehole shielding cover is opened for container insertion, and the container is deposited into the borehole. The shielding cover is closed.
4.12.1.4	Return Transporter to Surface Facility The transporter is released and moved to the surface facility.
4.12.1.5	Seal Emplacement Borehole The shielding plug is installed in the borehole, the shielding cover is removed and the lock cover is installed on the borehole.
4.12.2	Monitor Emplaced Wastes The wastes are stored in the repository and monitored for 50 years after the initial emplacement.
4.12.3	Waste Removal A representative sample of the emplaced containers is removed from the repository and transported to the Performance Confirmation Building.

Functional Steps	Functional Description
4.13	<u>Performance Testing</u> The containers and wastes transported to the Performance Confirmation Building are tested. The wastes are placed in a new container that is prepared for emplacement. The container is loaded into a container transporter.
4.14	<u>Mining</u>
4.14.1	<u>Excavation Operations</u>
4.14.1.1	<u>Extend Common Underground Passageways and Facilities</u> The tunnels and support facility rooms are extended by use of conventional mining techniques.
4.14.1.2	<u>Excavate Emplacement Drifts and Rooms</u> The emplacement drifts and rooms are excavated by use of conventional mining techniques as needed for the waste emplacement.
4.14.2	<u>Waste Emplacement Borehole Development</u>
4.14.2.1	<u>Drill Emplacement Boreholes</u> The emplacement boreholes are drilled with conventional rock-boring machines.
4.14.2.2	<u>Prepare Boreholes for Emplacement</u> The borehole liners, other borehole equipment and shielding covers are installed.
4.14.3	<u>Mined Rock Handling</u>
4.14.3.1	<u>Transport Rock to Surface</u> The rock removed during excavation of the tunnels, emplacement rooms and boreholes is transported to the surface storage pile.
4.14.3.2	<u>Store Rock</u> The rock excavated from the tunnels, rooms and boreholes is stored until needed for backfilling.

**Functional
Steps**

4.15

Functional Description

Final Waste Isolation

After a decision has been made to store the wastes permanently in the repository, or after the wastes have been retrieved, the emplacement rooms and access drifts will be backfilled and sealed. Then the underground common facilities, tunnels, shafts, and ramps will be backfilled and sealed in that sequence. The surface facilities will be demolished and the surface will be restored to near natural conditions. Appropriate monuments will be installed to identify the nature and location of the stored material.

4.0 PHYSICAL DESCRIPTIONS OF THE SYSTEM MODULES

A physical description is presented in this section for each of the modules described in the Introduction and Section 3.0. The modules are presented in alphanumeric order by module number.

The description for each module is presented first at Level 1 and then at Level 2. The Level 1 module descriptions provide a general physical description of the facilities and equipment needed for the activities described in the Level 1 and combined Level 2 and 3 functional descriptions. The descriptions cover 1) waste generator sites, 2) the transportation system, 3) the MRS facility, and 4) the geologic repository.

The Level 2 physical descriptions contain facility and equipment descriptions consistent with the combined Level 2 and 3 functional descriptions. This includes descriptions of the waste materials handled, process equipment, facility operations, equipment capacities, and other facility characteristics. The combination of physical and functional descriptions is intended to provide sufficient descriptive information on the activities, facilities and equipment to provide a basis for comprehensive system model development and system engineering studies.

This Level 2 and 3 information is presented primarily as tables keyed to the functional steps in the functional description. These tables provide brief descriptions of the equipment and facilities and are supplemented by illustrations as appropriate.

Before describing the facilities it is useful to describe how the waste forms may transition from one form to another as they are processed through the federal high-level radioactive waste management system. For example, spent fuel assemblies (SFAs) may be shipped from a reactor as intact assemblies, as canistered intact but failed SFAs, or as consolidated and canistered fuel rods. In the latter case, additional canisters will be required for the hardware from the SFA disassembly. At the MRS facility, the bare intact SFAs may be consolidated before being canistered or placed in

containers, or they may be placed directly in seal-welded canisters or containers for storage or shipment to the repository. Finally, all waste forms that have not been placed in containers before shipment to the repository are sealed into a final disposal container at the repository. The contents of the final disposal container might range from only bare intact SFAs to canistered SFAs nested inside another canister.

Because of the variety and different combinations of waste types, canisters, containers, and casks that may be used in the waste management system, an alphanumeric symbolic system was developed to provide a short-hand representation method to identify the various possible combinations. This symbolic system is described in Appendix A and used in the tables and figures in this section which identify various characteristics of these waste types, canisters, containers, and casks.

The waste canisters and containers are designed such that the mobile surface contamination on the wastes cannot migrate from the wastes and contaminate equipment and facilities. The canisters also generally are designed to conform to the shape of the wastes and do not add significantly to the volume occupied by the wastes. The basic descriptions of the wastes, canisters and containers and the generic types of wastes placed in the canisters and containers are listed in Tables 4.1 and 4.2.

The fuel assembly classification presented in the left-hand column of Table 4.2 is based on length as developed in ORNL (1988). This provides the basis for the length groups shown in the table, except for Other Power Reactors and Other Reactor Assemblies - Fuel Types 2, 3, and 4 (see Section 4.0.2 for additional details concerning the research and test reactor fuel type categories shown in the table). Similarly, the far right-hand column of the table is extracted from an ORNL (1988) classification for LWR fuel assemblies based on the physical configuration of the fuel rods. The canisters and containers are illustrated in Figures 4.1 and 4.2, respectively.

TABLE 4.1. Descriptions of the Wastes and Receptacles Handled in the Waste Management System

Generic Waste Form	Outer Canister or Container Symbol (d)	Cross Section		Typical Lengths (a)		Source	Contents (c)		Symbol (d)
		Geometry (e)	Dimension (in.) (b)	Outer Item (in.)	Contents (in.)		Waste		
PWR SFA	None	Square	<9	160 to 180	--	PWR	PWR SFA (f)	SFA_P	
BWR SFA	None	Square	<6	170 to 180	--	BWR	BWR SFA (f)	SFA_B	
At-Reactor PWR Canister	AR9	Square	~9	186	160 to 180	PWR	PWR SFA	SFA_P	
					162	PWR	PWR Fuel Rods	CON_P	
					180	PWR	PWR SFA Hardware	NFB_P	
					180	PWR	PWR Misc. Wastes	GTC_P	
At-Reactor BWR Canister	AR6	Square	~6	186	170 to 180	BWR	BWR SFA	SFA_B	
					164	BWR	BWR Fuel Rods	CON_B	
					180	BWR	BWR SFA Hardware	NFB_B	
					180	BWR	BWR Misc. Wastes	GTC_B	
HLW Canister	CRP	Circular	24	118	--	Commercial Reprocessing Plant Defense Reprocessing Plant Commercial Reprocessing Plant Defense Reprocessing Plant	Commercial HLW	HLW_W	
							Defense HLW	HLW_D	
							Misc. Wastes	GTC_W	
							Misc. Wastes	GTC_D	
Other Facility (g) Canister	Unknown	Unknown	Unknown	Unknown	Unknown	Other Reactors (h) Other Facility	Fuel Assemblies (f)	SFA_O	
							Misc. Wastes	GTC_O	
55-Gallon Drums	DRM	Circular	23	36	--	MRS MRS MRS	Misc. MRS Wastes	GTC_M	
					Chopped		PWR SFA Hardware	NFB_P	
					Chopped		BWR SFA Hardware	NFB_B	
MRS PWR Canister	M9	Square	>9	192	160 to 180	PWR	PWR SFA	SFA_P	
					149 to 161	MRS	PWR Fuel Rods	CON_P	
					155 to 170	MRS	BWR Fuel Rods	CON_B	
MRS BWR Canister	M6	Square	>6	192	170 to 180	BWR	BWR SFA	SFA_B	

TABLE 1. (contd)

Generic Waste Form	Outer Canister or Container Symbol (d)	Cross Section		Typical Lengths (a)		Source	Contents (c)		Symbol (d)		
		Geometry (e)	Dimension (in.) (b)	Outer Item (in.)	Contents (in.)		Waste				
MRS Cylindrical Canister	MC	Circular	26	192	180	MRS	Drummed PWR SFA Hardware	MORM_NFB_P			
					180	MRS	Drummed BWR SFA Hardware	MORM_NFB_B			
					180	MRS	Drummed MRS Misc. Wastes	MORM_GTC_M			
				TBD	Other Facilities (g)	Canned Other Facility	CU_GTC_O				
Repository Hybrid Container	Y28BP	Circular	28	204	160 to 180	Other Reactors (h)	Misc. Wastes	CU_SFA_O			
					170 to 180				Canned Other Reactor SFAs (f)		
									PWR	PWR SFA	SFA_P
									BWR	BWR SFA	SFA_B
Repository BWR Intact Fuel Container	Y28110	Circular	28	204	170 to 180	BWR	BWR SFA	SFA_B			
Repository Canned PWR Container	Y2613 or Y2814	Circular	26 or 28	204	160 to 180	PWR	PWR SFA	SFA_P			
					155 to 167	PWR	Canned PWR Fuel Rods	AR9_CON_P			
					186	PWR	Canned PWR SFA Hardware	AR9_NFB_P			
					186	PWR	Canned PWR Misc. Wastes	AR9_GTC_P			
					166 to 186	PWR	Canned PWR SFA	AR9_SFA_P			
					192	MRS	Canned PWR SFA	M9_SFA_P			
					192	MRS	Canned BWR Fuel Rods	M9_CON_B			
					192	MRS	Canned PWR Fuel Rods	M9_CON_P			
Repository Canned BWR Container	Y2616 or Y2819	Circular	26 or 28	204	170-180	BWR	BWR SFA	SFA_B			
					160-176	BWR	Canned BWR Fuel Rods	AR6_CON_B			
					186	BWR	Canned BWR SFA Hardware	AR6_NFB_B			
					186	BWR	Canned BWR Misc. Wastes	AR6_GTC_B			
					186	BWR	Canned BWR SFA	AR6_SFA_B			
					192	MRS	Canned BWR SFA	M6_SFA_B			
					149-161	MRS	PWR Fuel Rods	CON_P (i)			
					155-170	MRS	BWR Fuel Rods	CON_B (i)			
					Chopped	MRS	PWR NFBC	NFB_P (i)			
					Chopped	MRS	BWR NFBC	NFB_B (i)			

TABLE 4.1. (contd)

Generic Waste Form	Outer Canister or Container Symbol (d)	Cross Section		Typical Lengths (a)		Contents (c)	
		Geometry (e)	Dimension (b) (in.)	Outer Item (in.)	Contents (in.)	Waste	Symbol (d)
Repository HLW Container	Y26H	Circular	26	130	118	Commercial Reprocessing Plant	CRP_W
					118	Commercial Reprocessing Plant	GTC_W
					118	Defense Reprocessing Plant	CRP_D
					118	Defense Reprocessing Plant	GTC_D
Repository Cylindrical Container	Y28C	Circular	28	204	192	MRS	MC MDRHGC_M
					192	MRS	MC MDFMFB_P
					192	MRS	MC MDRHFB_B
					192	Repository	YDRM_GTC_R
					TBD	Other Reactors	OU SFA_O
					TBD	Other Facilities	OU_GTC_O

(a) Lengths accommodate most wastes, canisters and containers. Other lengths needed for a few exceptions.

(b) Approximate dimensions. Canister and container dimensions are selected such that they can be nested.

(c) Wastes listed are the basic waste form inserted into the canister or container identified in column 2. The symbol identifies any canisters that contained the waste prior to insertion into the canister or container identified in column 2. The symbol does not include the outer canister or container listed in the first two columns.

(d) See Appendix A for further explanation of symbols.

(e) See Figure 4.1 for square cross section and Figure 4.2 for circular cross section.

(f) Physical descriptions of these fuels are presented in Table 4.2.

(g) Other facilities include possible not yet identified sources of waste that may require repository disposal.

(h) Other reactors include Peach Bottom and Ft. St. Vrain HTGRs and various research and test reactors.

(i) Placed only in the Y2616 container.

TABLE 4.2. Physical Descriptions of Different Fuel Assembly Configurations(a)

Assembly Length Class and Assembly Description (b,c)	Assembly Length (inches)	Assembly Width (inches)	Rod Diameter (inches)	Assembly Weight (pounds)	Initial Heavy Metal (MTU)	Cled Material (d)	ORNL Assembly Configuration Class (e)
<u>Light Water Reactors</u>							
<u>Length Group A</u>							
AC 5 x 5 Elk River	81.6	3.5	-(f)	-	-	-	Elk River
<u>Length Group B</u>							
Exxon 9 x 9 Big Rock Point	82	6.5	0.563	-	-	Zr-2/304 SS	Big Rock Pt.
GE 9 x 9 GE-1, Vers. 5	(82)	6.5	0.563	465	0.138	Zr-2/304 SS	Big Rock Pt.
GE 11 x 11 GE-1, Vers. 6	(82)	6.5	0.449	-	-	Zr-2/304 SS	Big Rock Pt.
Exxon 11 x 11 Gen. Electric	83.970	6.515	0.449	457.3	0.132	Zr-2/304 SS	Big Rock Pt.
<u>Length Group C</u>							
GE 6 x 6 GE-1, Vers. 2	95	4.662	0.563	-	-	Zr-2/304 SS	Humboldt Bay
Exxon 6 x 6 Humboldt Bay	95	-	0.565	-	-	Zr-2/304 SS	Humboldt Bay
GE 7 x 7 GE-1, Vers. 3	95	4.662	0.486	276	0.076	Zr-2	Humboldt Bay
<u>Length Group D</u>							
Allis Chalmers 10 x 10	102.34	5.61	0.396	-	-	348H SS	LaCrosse
Exxon 10 x 10 AC	102.45	5.614	0.394	376.6	0.108	348H SS	LaCrosse
<u>Length Group E</u>							
Exxon 15 x 16 Westinghouse	111.775	7.614	0.365	796.6	0.236	Zr-4	Yankee Rowe
CE 15 x 16 Yankee Rowe	111.785	7.6	-	720	0.231	Zr-4	Yankee Rowe
WE 17 x 18 Yankee Rowe	(112)	7.11	0.365	-	-	348 SS	Yankee Rowe
<u>Length Group F</u>							
Exxon 6 x 6 Gen. Electric	134.32	4.275	0.565	328.4	0.095	Zr-2	Dresden 1
GE 6 x 6 GE-1, Vers. 1	(134)	4.27	0.562	-	0.107	Zr-2	Dresden 1
<u>Length Group G</u>							
WE 14 x 14 Std/SC	137.06	7.76	0.422	1233-1247	0.373	Zr; 304 SS	San Onofre 1
WE 15 x 15 Std/SC	137.06	8.42	0.422	1233-1247	0.373	304 SS	Haddam Neck
B&W 15 x 15 St. Steel	137.06	8.466	0.422	1255	0.410	304 SS	Haddam Neck
<u>Length Group H</u>							
B&W 13 x 14 Indian Point 1	(138)	-	-	-	-	Zr-4	Indian Pt. 1
WE 13 x 14 Indian Point 1	137.752	6.2675	-	-	-	Zr-4	Indian Pt. 1
<u>Length Group I</u>							
CE 14 x 14 Fort Calhoun	146	8.1	0.440	1220	0.376	Zr-4	Fort Calhoun
Exxon 14 x 14 Fort Calhoun	147	-	0.440	-	-	Zr-4	Fort Calhoun
CE 15 x 15 Palisades	147.5	8.2	0.418	1360	0.413	Zr-4	Palisades
Exxon 15 x 15 Comb. Eng.	148.852	8.250	0.418	1439	0.401	Zr-4	Palisades

TABLE 4.2. (contd)

Assembly Length Class and Assembly Description (b,c)	Assembly Length (inches)	Assembly Width (inches)	Rod Diameter (inches)	Assembly Weight (pounds)	Initial Heavy Metal (MTU)	Cled Material (d)	ORNL Assembly Configuration Class (e)
Light Water Reactors (contd)							
Length Group J							
CE 14 x 14 Standard	157.00	8.10	0.440	1270	0.366	Zr-4	CE 14 x 14
WE 14 x 14 Model C	157.238	8.03	0.440	1283	0.397	Zr-4	CE 14 x 14
Exxon 14 x 14 Comb Eng.	157.24	8.110	0.440	1282	0.381	Zr-4	CE 14 x 14
Length Group K							
CE 16 x 16 Lucie 2	158.129	8.1	0.382	1300	0.390	Zr-4	St. Lucie 2
Exxon 15 x 15 Westinghouse	159.7	8.426	0.424	1433	0.432	Zr-4	WE 15 x 15
WE 14 x 14 OFA	159.71	7.76	0.400	1096-1177	0.356-0.358	Zr-4	WE 14 x 14
WE 14 x 14 Std/ZCA	159.71	7.76	0.422	1242-1302	0.389-0.407	Zr-4	WE 14 x 14
WE 14 x 14 Std/ZCB	159.71	7.76	0.422	1242-1302	0.389-0.407	Zr-4	WE 14 x 14
WE 15 x 15 Std/ZC	159.71	8.434	0.422	1449-1472	0.456-0.469	Zr-4	WE 15 x 15
Exxon 17 x 17 Westinghouse	159.71	8.426	0.360	1348	0.401	Zr-4	WE 17 x 17
WE 15 x 15 OFA	159.765	8.424	0.422	1448-1459	0.463	Zr-4	WE 15 x 15
WE 17 x 17 Standard	159.765	8.434	0.374	1482	0.464	Zr-4	WE 17 x 17
WE 17 x 17 OFA	159.765	8.434	0.360	1373	0.426	Zr-4	WE 17 x 17
WE 17 x 17 Vantage 5	160.1	8.426	0.360	1365	0.423	Zr-4	WE 17 x 17
Exxon 14 x 14 Westinghouse	160.13	7.763	0.424	1271	0.379	Zr-4	WE 14 x 14
Exxon 14 x 14 Top Rod	160.13	7.763	0.417	1215	0.365	Zr-4	WE 14 x 14
Length Group L							
B&W 15 x 15 Mark B	165.625	8.536	0.430	1515	0.464	Zr-4	B&W 15 x 15
B&W 15 x 15 Mark B2	165.625	8.536	0.430	-	-	Zr-4	B&W 15 x 15
B&W 17 x 17 Mark C	165.71875	8.536	0.379	1505	0.456	Zr-4	B&W 17 x 17
Length Group M							
GE 7 x 7 GE-1, Vers. 4	171.125	5.438	-	-	-	Zr-2	GE BWR/2,3
GE 7 x 7 GE-2, Vers. 1	171.2	5.438	0.563	679	0.192-0.197	Zr-2	GE BWR/2,3
GE 7 x 7 GE-3, Vers. 1	171.125	5.438	0.570	-	-	Zr-2	GE BWR/2,3
GE 8 x 8 GE-4, Vers. 1	171.125	5.438	0.493	-	0.183	Zr-2	GE BWR/2,3
GE 8 x 8 GE-5, Vers. 1	171.125	5.438	0.483	-	0.177	Zr-2	GE BWR/2,3
GE 8 x 8 GE-6, Vers. 1	171.125	5.438	-	-	-	Zr-2	GE BWR/2,3
GE 8 x 8 GE-7, Vers. 1	171.125	5.438	-	-	-	Zr-2	GE BWR/2,3
GE 8 x 8 GE-8, Vers. 1	(171)	-	-	-	-	Zr-2	GE BWR/2,3
GE 8 x 8 GE-9, Vers. 1	(171)	-	-	-	-	Zr-2	GE BWR/2,3
Exxon 7 x 7 Gen. Electric	171.25	5.247	0.570	619.1	0.184	Zr-2	GE BWR/2,3
Exxon 8 x 8 JP-3	171.29	5.251	0.484	562	0.174	Zr-2	GE BWR/2,3
Exxon 9 x 9 JP-3	171.29	5.251	0.424	556.9	0.168	Zr-2	GE BWR/2,3
Length Group N							
GE 7 x 7 GE-2, Vers. 2	175.87	5.438	0.563	682.5	0.193-0.196	Zr-2	GE BWR/4,5,6
GE 7 x 7 GE-3, Vers. 2	175.87	5.438	0.563	674-681	0.188-0.190	Zr-2	GE BWR/4,5,6
GE 7 x 7 GE-3, Vers. 3	175.87	5.438	-	-	-	Zr-2	GE BWR/4,5,6
GE 8 x 8 GE-4, Vers. 2	175.87	5.478	0.493	-	0.184	Zr-2	GE BWR/4,5,6
GE 8 x 8 GE-4, Vers. 3	175.87	5.438	-	-	-	Zr-2	GE BWR/4,5,6

TABLE 4.2. (contd)

Assembly Length Class and Assembly Description(b,c)	Assembly Length (inches)	Assembly Width (inches)	Rod Diameter (inches)	Assembly Weight (pounds)	Initial Heavy Metal (MTU)	Clad Material(d)	ORNL Assembly Configuration Class(e)
Light Water Reactors (contd)							
GE 8 x 8 GE-5, Vers. 2	175.87	5.478	-	-	-	Zr-2	GE BWR/4, 5, 6
GE 8 x 8 GE-6, Vers. 2	175.87	5.438	-	-	-	Zr-2	GE BWR/4, 5, 6
GE 8 x 8 GE-7, Vers. 2	175.87	5.438	-	-	-	Zr-2	GE BWR/4, 5, 6
GE 8 x 8 GE-8, Vers. 2	(176)	-	-	-	-	Zr-2	GE BWR/4, 5, 6
GE 8 x 8 GE-9, Vers. 2	(176)	-	-	-	-	Zr-2	GE BWR/4, 5, 6
Length Group M (contd)							
Exxon 8 x 8 JP-4, 5	176.05	5.251	0.424	575.3	0.173	Zr-2	GE BWR/4, 5, 6
Exxon 9 x 9 JP-4, 5	176.058	5.251	0.424	575.3	0.173	Zr-2	GE BWR/4, 5, 6
Length Group O							
CE 16 x 16 ANO2	176.803	8.1	0.382	1430	0.426	Zr-4	CE 16 x 16
CE 16 x 16 Onofre	176.803	8.1	0.382	1430	0.426	Zr-4	CE 16 x 16
Length Group P							
CE 16 x 16 System-80	178.250	8.1	0.382	1430	0.426	Zr-4	CE 16 x 16
Length Group Q							
WE 17 x 17 XLR	199	8.43	0.374	-	-	Zr-4	S. Texas 1 & 2
Other Power Reactors							
General Atomic Co. 1 x 1 Ft. St. Vrain	31.22	14.2 (across flats)	-	282.2	-	-	-
General Atomic Co. 1 x 1 Peach Bottom 2	144	3.5	-	-	-	-	-
Other Reactor Assemblies - Fuel Type 2(g)							
GA Technologies; Single Pin; TRIGA; U-Zr hydride	28.401	1.468	1.468	-	-	SS, Al	-
GA Technologies; Single Pin; TRIGA; U-Zr hydride	28.000-28.425	1.468-1.471	1.468-1.471	-	-	Al	-
GA Technologies; Single Pin; TRIGA; U-Zr hydride	26.890-30.000	1.490-1.476	1.409-1.476	-	-	SS	-
GA Technologies; 4-rod cluster; TRIGA; U-Zr hydride	29.88	-	1.414	-	-	SS	-
GA Technologies; Single Pin; Fuel Followup Control Rod; TRIGA; U-Zr hydride	45.0-66.5	1.5	1.5	-	-	-	-

TABLE 4.2. (contd)

Assembly Length Class and Assembly Description (b,c)	Assembly Length (inches)	Assembly Width (inches)	Rod Diameter (inches)	Assembly Weight (pounds)	Initial Heavy Metal (WTU)	Clad Material (d)	ORNL Assembly Configuration Class (e)
Other Reactor Assemblies - Fuel Type 2(g) (contd)							
GA Technologies; Single Pin; TRIGA; U-Zr hydride	30	0.54	0.54	-	-	Incoloy 800	-
Other Reactor Assemblies - Fuel Type 3(g)							
Aerojet General Nucleonics; AGN; UO ₂ - Polyethylene Disks	0.393-1.969(h)	10.138	-	-	-	-	-
Aerojet General Nucleonics; AGN; UO ₂ - Polyethylene Blocks	27.625	3.063	-	-	-	-	-
Other Reactor Assemblies - Fuel Type 4(g)							
Westinghouse Canada 5 x 5 PULSTAR	37.980-38.000	See footnote (i)	0.472	-	-	Zr-2	-

- (a) Sources of information are DOE (1987b), EIA (1988), ORNL (1988) and ORNL (1991).
 (b) Fuel assembly classification based on length as developed in ORNL (1988). This provides the basis for the length groups shown in the table, except for Other Power Reactors and Other Reactor Assemblies - Fuel Types 2, 3, & 4 [also see footnote (g)].
 (c) AC = Allis Chalmers; B&W = Babcock & Wilcox; CE = Combustion Engineering; GE = General Electric; WE = Westinghouse.
 (d) SS is stainless steel, Zr is Zircaloy, Zr-2 is Zircaloy-2, Zr-4 is Zircaloy-4 and Al is aluminum.
 (e) ORNL (1988) classification for LWR fuel assemblies based on physical configuration of the fuel rods.
 (f) A dash means that no information was obtained on this item.
 (g) See text, Section 4.0.2, for additional details concerning fuel type categories.
 (h) The thickness of the disks varies from 0.393 to 1.969 inches.
 (i) Each 5 x 5 array is enclosed in a Zr-2 box with outside dimensions of 2.756 x 3.150 x 32.284 inches.

FIGURE 4.1. MRS Canisters Containing Spent Fuel Rods or Assemblies

4.0.1 Power Reactor Wastes

Because of the variety of power reactor waste forms to be accommodated (e.g., intact SFAs, consolidated SFAs, a variety of different PWR and BWR designs, spent fuel hardware wastes, miscellaneous and non-fuel-bearing wastes, etc.), a variety of canister and container sizes must be accommodated. In preparing the listing of power reactor wastes, canisters and containers in Table 4.1, it was assumed that the number of canisters and containers would be minimized by standardizing on a few basic canister and container sizes and by accommodating a variety of different-length waste forms in standard-length canisters and containers. (The final repository container

FIGURE 4.2. Typical Repository Containers

is referred to as a "container." Other containers are referred to as canisters or drums.) Collectively, the canisters, containers, and drums are referred to as receptacles.

The lengths of canisters and containers in Table 4.1 are illustrative and approximate, since designs have not been fixed. If a better match between contents and outer lengths than shown in the table is desired, a variety of canister and container lengths would be required.

The cross-section dimensions of the final spent fuel containers are representative of current waste package concepts. However, other sizes may have to be considered to accommodate different waste loadings because of heat characteristics of the SFAs as received at the repository. The SFA heat characteristics are a function of SFA exposure and age. These, in turn, are a function of the specific logistics and heat management scenario that is assumed. Further details of MRS and repository canister and container loadings are presented in Sections 4.3 and 4.4, respectively.

4.0.2 Research and Test Reactor Fuel

These fuels are categorized into seven basic types that are employed in reactors used at universities or educational facilities, privately owned research and development (R&D) facilities, DOE-owned laboratories, and government-owned laboratories. There are 50 educational, 11 commercial research, 6 government-owned non-DOE, and 52 DOE reactors, for a total of 119 reactors. Most of these are either MTR-plate type or hydride-fueled TRIGA reactors.

The research and test reactors use a wide variety of fuel types, which require different handling, treatment, and disposal procedures. Some of the spent fuels will be reprocessed at government-owned plants such as SRP or INEL; if so the resulting wastes become part of the defense high-level waste stream. Some of the fuels, however, are not planned to be reprocessed, and for others the decision to reprocess or not reprocess has not been made. Those fuels that are not reprocessed may eventually require disposal in a repository as canistered spent fuel.

Since the disposal requirements are expected to be sensitive to the characteristics of the fuel, it is logical to categorize the fuels into different types based on their physical and chemical properties. The fuels are divided into the following eight categories:

1. MTR plate-type, highly enriched, U-Al alloy fuels
2. TRIGA (uranium-zirconium hydride fuels), stainless steel or aluminum clad, 19 to 20% enriched
3. Homogeneous UO_2 -polyethylene disks or blocks, 19 to 20% enriched
4. PULSTAR and other low-enriched (4 to 6%) UO_2 -pin array types
5. Liquid fuels
6. Uranium-molybdenum alloy highly enriched fuels
7. FFTF UO_2 - PuO_2 fuel
8. Miscellaneous types.

The latter category includes a variety of fuels from a wide assortment of reactors. Most of these are at DOE-owned national laboratories; small amounts are at Babcock & Wilcox facilities in Lynchburg and the Battelle-Columbus laboratories.

Similar to the ORNL report (DOE 1987b) from which the fuel information in this section was extracted, it was assumed that fuel in categories 1, 5, 6, 7, and 8 will be reprocessed at SRP, HANF, or INEL and will become part of defense HLW; and that fuel in categories 2, 3, and 4 will be packaged for emplacement in a repository. No attempt was made to design packages or to estimate repository volume requirements. Thus, the task of this section is to list the various fuel types in categories 2, 3, and 4 and to characterize these fuels with regard to dimensions.

The existing fuels in categories 2, 3, and 4 are given in Table 4.2 under the heading of "Other Reactor Assemblies," together with their physical descriptions.

4.0.3 General Waste Flows in the Waste Management System

Figures 4.3 to 4.9 illustrate the flow of the wastes, canisters and containers in the waste management system for the scenarios currently being evaluated. The upper boxes represent the waste generators. The circled symbols are the symbols for the wastes that must be disposed of. The uncircled symbols are the symbols for the canisters and containers in which the wastes are packaged. As an example, the SFA_P waste at the extreme upper left in Figure 4.3 is placed in an AR9_P canister at a PWR. The waste and canister are then shipped to the repository, where they are placed in a Y26I3 container. For details on the canister and container sizes, see Table 4.1. Seven figures for the flow of wastes, canisters and containers are needed because each waste management system scenario has a unique flow.

Information included in the physical descriptions that follow is based on available conceptual design references. In situations where design information is incomplete or not available, the type of facility or equipment that appears to be needed is described and identified as preliminary. The physical descriptions are keyed to the function numbers presented in Sections 2.0 and 3.0.

Only outer canisters and containers are identified. See Appendix A for definitions of symbols.

FIGURE 4.3. Scenario 1 - Waste Management System Canister, Container, Drum and Waste Symbols

Note: Symbols in circles identify wastes before
 Symbols without circles identify canisters or containers.
 Only outer canisters and containers are identified. See Appendix A for definitions of symbols.

FIGURE 4.4. Scenario 2 - Waste Management System Canister, Container, Dru... and Waste Symbols

2801053.D1
2801053.D2
2801053.D3

Note: Symbols in circles identify wastes before
Symbols without circles identify canisters or containers.
Only outer canisters and containers are identified. See Appendix A for definitions of symbols.

FIGURE 4.5. Scenario 3 - Waste Management System Canister, Container, Drum and Waste Symbols

Note: Symbols in circles identify wastes before placement in canisters or containers.
 Symbols without circles identify canisters or containers.
 Only outer canisters and containers are identified. See Appendix A for definitions of symbols.

FIGURE 4.6. Scenario 4 - Waste Management System Canister, Container, Drum and Waste Symbols

S9901026 SE
20004185.18

Note: Symbols in circles identify wastes before placement in canisters or containers.
 Symbols without circles identify canisters or containers.
 Only outer canisters and containers are identified. See Appendix A for definitions of symbols.

FIGURE 4.7. Scenario 5 - Waste Management System Canister, Container, Drum and Waste Symbols

FIGURE 4.8. Scenario 6 - Waste Management System Canister, Container, Drum and Waste Symbols

FIGURE 4.9. Scenario 7 - Waste Management System Canister, Container, Drum and Waste Symbols

4.1 WASTE GENERATORS (Module 1A)

The waste generator facilities and equipment are described as a single module that provides a general description of the typical waste generator facilities.

The wastes to be disposed of in the geologic repositories generally will originate from four sources: 1) nuclear reactor plants, 2) spent fuel reprocessing plants, 3) nuclear research and development facilities, and 4) miscellaneous sources. They include both private industry and government facilities. Prior to delivery to the waste management system, these wastes are expected to be stored in either of two types of facilities: pools or dry storage facilities. Although the design details for these hundreds of storage facilities will vary, the general shipment procedures and facility designs for each of these two basic types of storage facilities will be similar among the facilities of each type. Descriptions of the physical facilities for shipments of wastes from the waste generators are presented for only two generic facilities: 1) waste shipments from pools at nuclear power reactors, and 2) solidified high-level waste shipments from dry vaults. Descriptions of the shipment facilities for most sources are not expected to vary significantly from these generic descriptions except for dimensions of facilities and capacities of equipment.

The waste description and waste generator facility description information contained in this subsection was obtained primarily from DOE (1987a) and DOE (1987b). Only a brief generic description is presented for the facilities utilized at nuclear plants. This generic description illustrates the operations that interface with the waste management system. The information presented for the dry vault operations is conceptual and is based on Sandia (1987b) and Bechtel (1985).

4.1.1 Level 1 Physical Description (Module 1A)

Spent Fuel Storage in Pools(a)

The primary wastes shipped from pools will be spent fuel assemblies (SFAs) stored in the spent fuel storage pools that are an integral part of the nuclear reactor buildings. The major waste shipment requirements for the reactor plant operators will be to provide for safe and efficient loading of transport casks and for the preparation of the loaded casks and their transport vehicles for shipment. Typical reactor plant wastes are described in Table 4.1. Typical reactor fuel assemblies are illustrated in Figure 4.10.

Waste shipments from reactor plants require use of three components:

- 1) the yard facilities for receiving and shipping trucks and train cars,
- 2) the reactor building facilities for preparing shipments of radioactive materials from the spent fuel pools, and 3) the yard facilities for secondary storage of SFAs.

Figure 4.11 presents a generic plan view of the yard facilities used for waste shipments. The components involved in waste shipments include the railroad tracks and roads to the reactor building, the perimeter fence guard-house, a washdown area where road dirt is washed off both the cask and the vehicle, the gate in the inner security fence, and parking areas for both railcars and trucks.

The reactor building facilities used for waste storage and shipments are illustrated in Figures 4.12 and 4.13. Figure 4.14 illustrates a storage pool. There are three general types of shipment facilities in the reactor building: 1) a vehicle loading area, 2) a cask service pad and 3) a cask loading pit. These facilities are illustrated in Figures 4.12 and 4.13 for a generic PWR plant. The facilities at a BWR plant are similar except that the service pad and spent fuel pool are at the elevation of the top of the reactor, up to 100 feet above the ground level. As a result the cask has to be lifted from the ground level to the service pad through a vertical passageway. Typical reactor plant facilities and equipment needed for the

---

(a) Primary storage at reactor sites.

Typical BWR Fuel Assembly

Typical PWR Fuel Assembly

FIGURE 4.10. Typical LWR Fuel Assemblies

NOTE: Letters and numbers relate facility locations to descriptions in text and Tables 4.4 and 4.5.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.

FIGURE 4.11. Plan View of Generic Waste Generator Yard Facilities

reactor plant functional activities are described below. The activities are described in the functional description section of this document. The locations of these activities in the reactor building are shown on Figures 4.11 to 4.13 as circles containing the functional activity numbers.

The vehicle loading area typically is a large hall with a parking area for either trucks or a single railroad car. The hall is serviced by a bridge crane with auxiliary hooks for handling lighter loads such as the cask lids.

The cask service pad is a flat concrete floor area large enough for a cask standing on end. It has curbs and a sloping floor such that decontamination fluids drain into the plant radioactive waste system. It is serviced by the bridge crane identified above.

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.4 and 4.5.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.

FIGURE 4.12. Elevation View of Generic PWR Spent Fuel Pool

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.4 and 4.5.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.

FIGURE 4.13. Plan View of Generic PWR Spent Fuel Pool

FIGURE 4.14. Water Pool for Storage of Spent Fuel at the Morris, Illinois, Facility (Courtesy of General Electric Company)

The cask loading pit is a deep water pool connected to or part of the fuel storage pool. It is large enough for a cask and deep enough that wastes in the pool can be placed in a cask standing on end without a significant increase in the radiation doses at the surface of the water. The pit is serviced by both the bridge crane described above and the spent fuel pool bridge crane.

Secondary Spent Fuel Storage

In those cases where a power reactor plant does not have sufficient room in its spent fuel pool for all wastes that must be stored before shipment, a secondary storage facility may be built in the plant yard. This secondary storage is often referred to simply as dry storage. The technology for dry storage has been demonstrated and several options are available. These include metal storage casks, concrete storage casks, horizontal concrete modules and modular concrete vaults. If substantial secondary storage requirements develop, it is anticipated that different storage options will be employed at different reactor sites. These alternatives are described and compared in some detail in DOE (1989b). In the preparation of the functional description section of this document, it was assumed that use of secondary storage will require use of either a transport cask for waste movements between the spent fuel pool and the secondary storage or a storage cask that is loaded in the pool and then placed in storage.

Solidified High-Level Wastes Stored in Dry Vaults

The major waste shipment equipment and facility requirements for plants shipping solidified high-level wastes (HLW) parallel the requirements above for reactor plant operators.

Figure 4.15 illustrates a typical high-level waste canister. The solidified high-level wastes are expected to be stored at the reprocessing plants that created the wastes. None of the shipping facilities at these plants have been built. It is assumed that these wastes will be stored in dry vaults and shipped dry. (If pools are used, the shipping facilities and

Estimated Weight: 4260 lbs

Source: DuPont report DP-1720, April 1986

FIGURE 4.15. Savannah River Plant HLW Canister

procedures probably would be the same as described above for pool shipments.) Figure 4.16 illustrates the general design of a dry vault.

The shipment facilities and procedures essentially are the same as for the reactor plants except for the attachment of the cask to the dry vault for loading. It is assumed that for this activity the cask is placed on a cask cart when it is moved to the cask preparation area. Then, after the cask has been prepared for loading, it is carried to the cask loading position by the cask cart and attached to a port in the floor of the room containing the stored wastes (see Figure 4.17). The wastes are loaded into the cask using a bridge crane in the waste storage vault. The cask is then carried by the cask cart back to the preparation area where it is prepared for shipment.

4.1.2 Level 2 Physical Description (Module 1A)

The primary waste generators are the commercial nuclear power plants, the reprocessing plants, and the research reactors. In addition, there are a number of other sources of miscellaneous radioactive materials that may require disposal in the geologic repositories. Table 4.3 identifies the number of these sources. Tables 4.4 to 4.7 show equipment requirements for the Level 2 functions. Table 4.8 contains a description of the reactor plant spent fuel pool and spent fuel and transport-cask handling crane characteristics.

FIGURE 4.16. Dry Vault Storage System

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.6 and 4.7.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.

FIGURE 4.17. Typical Dry Vault Cask Loading Facilities

TABLE 4.3. Sources of Waste Requiring Disposal

Source	Number of Facilities
Nuclear Power Plants	120
Reprocessing Plants	4
Research Reactors(a)	119
Miscellaneous Waste Sources	TBD(b)

(a) Includes Ft. St. Vrain and Peach Bottom 1.

(b) TBD means to be determined.

**TABLE 4.4. Major Waste Handling Equipment at Pool Storage Sites (Module 1A) -
Listed in Process Step Order(a)**

Function Reference Number	Equipment Title	Equipment Identification (b)	Function/Activity	Number of Units	Size or Capacity	Locations (Figures 4.11 to 4.13)
1.1 +	Fuel Handling Bridge Crane	4	Move SFAs in spent fuel pool	1	1 SFA	E
1.2						
1.3.1.1	Cask Transporter	5	Move cask into vehicle loading area	1	150 ton	A
	Mobile Crane	6	Load cask onto transporter	1	150 ton	A
	Bridge Crane	2	Move cask to service pad	1	Main Hook (24 to 185 ton)	D
	Bridge Crane	2	Install service platform around cask	1	Auxiliary Hook (5 to 25 ton)	C
	Cask Service Platform	3	Support personnel working on cask	1	1 to 5 ton	C
	Bridge Crane	2	Move cask outer lid to service pad	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move service platform away from cask	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move cask to loading area	1	Main Hook (24 to 185 ton)	C
	Bridge Crane	2	Move cask inner lid to service pad	1	Auxiliary Hook (5 to 25 ton)	C
1.3.1.2 +	Fuel Handling Bridge Crane	4	Load SFAs into cask	1	1 SFA	E to D
1.4.2	Bridge Crane	2	Move cask inner lid to cask	1	Auxiliary Hook (5 to 25 ton)	C to D
1.3.1.3	Bridge Crane	2	Move cask to service pad	1	Main Hook (24 to 185 ton)	D to C
	Bridge Crane	2	Install service platform around cask	1	Auxiliary Hook (5 to 25 ton)	C
	Cask Service Platform	3	Support personnel working on cask	1	1 to 5 ton	C
	Bridge Crane	2	Move cask outer lid to cask	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move service platform away from cask	1	Auxiliary Hook (5 to 25 ton)	C

TABLE 4.4. (contd)

Function Reference Number	Equipment Title	Equipment Identification (b)	Function/Activity	Number of Units	Size or Capacity	Locations (Figures 4.11 to 4.13)
1.3.1.3	Bridge Crane	2	Move cask to vehicle loading area	1	Main Hook (24 to 185 ton)	C to B
	Bridge Crane	2	Load cask onto transporter	1	Main Hook (24 to 185 ton)	B
	Cask Transporter	5	Move vehicle and cask to secondary storage area	1	150 ton	B to A
1.3.3.1	Mobile Crane	6	Transfer cask from transporter to storage pad or support transfer cask during transfer of wastes into secondary storage	1	150 ton	A
	Mobile Crane	6	Transfer storage cask from storage pad to transporter or support transfer cask during removal of wastes from secondary storage	1	150 ton	A
	Cask Transporter	5	Transport cask to vehicle loading area	1	150 ton	A to B
1.3.3.2	Bridge Crane	2	Move cask to service pad	1	Main Hook (24 to 185 ton)	B to C
	Bridge Crane	2	Install service platform around cask	1	Auxiliary Hook (5 to 25 ton)	C
	Cask Service Platform	3	Support personnel working on cask	1	1 to 5 ton	C
1.3.3.3	Bridge Crane	2	Move cask outer lid to service pad	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move service platform away from cask	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move cask to cask loading area	1	Main Hook (24 to 185 ton)	C to D
1.3.3.3	Bridge Crane	2	Move cask inner lid to service pad	1	Auxiliary Hook (5 to 25 ton)	D to C
	Fuel Handling Bridge Crane	4	Transfer SFAs from cask to temporary storage	1	1 SFA	D to E
	Bridge Crane	2	Move cask inner lid to cask	1	Auxiliary Hook (5 to 25 ton)	C to D
1.3.3.3	Bridge Crane	2	Move cask to service pad	1	Main Hook (24 to 185 ton)	D to C
	Bridge Crane	2	Move cask to service pad	1	Main Hook (24 to 185 ton)	D to C

TABLE 4.6. (contd)

Function Reference Number	Equipment Title	Equipment Identification (b)	Function/Activity	Number of Units	Size or Capacity	Locations (Figures 4.11 to 4.13)
1.3.3.3	Bridge Crane	2	Install service platform around cask	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move cask outer lid to cask	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move service platform away from cask	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move cask to vehicle loading area	1	Main Hook (24 to 185 ton)	C to B
	Bridge Crane	2	Load cask onto transporter	1	Main Hook (24 to 185 ton)	B
4.3.5 1.4.1 + 1.5.1	Onsite Drive Unit	1	Move vehicle and cask from vehicle loading area to storage facility	1	10 Railcars	B to A
	Onsite Drive Unit	1	Move vehicles carrying casks into vehicle loading area	1	10 Railcars	A to B
	Bridge Crane	2	Remove impact limiters and cask tiedowns	1	Auxiliary Hook (5 to 25 ton)	B
	Bridge Crane	2	Move cask to service pad	1	Main Hook (24 to 185 ton)	B to C
	Bridge Crane	2	Install service platform around cask	1	Auxiliary Hook (5 to 25 ton)	C
	Cask Service Platform	3	Support personnel working on cask	1	1 to 5 ton	C
	Onsite Drive Unit	1	Move vehicle without cask to parking area	1	10 Railcars	B to A
	Bridge Crane	2	Move cask outer lid to service pad	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move service platform away from cask	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move cask to cask loading area	1	Main Hook (24 to 185 ton)	C to D
4.3.5	Bridge Crane	2	Move cask inner lid to service pad	1	Auxiliary Hook (5 to 25 ton)	D to C

TABLE 4.4. (contd)

Function Reference Number	Equipment Title	Equipment Identification (b)	Function/Activity	Number of Units	Size or Capacity	Locations (Figures 4.11 to 4.13)
1.4.3 + 1.5.3	Bridge Crane	2	Move cask to service pad	1	Main Hook (24 to 185 ton)	D to C
	Bridge Crane	2	Install service platform around cask	1	Auxiliary Hook (5 to 25 ton)	C
	Cask Service Platform	3	Support personnel working on cask	1	1 to 5 ton	C
	Onsite Drive Unit	1	Move vehicle into cask loading area	1	10 Railcars	A to B
	Bridge Crane	2	Move cask outer lid to cask	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move service platform away from cask	1	Auxiliary Hook (5 to 25 ton)	C
	Bridge Crane	2	Move cask to vehicle loading area	1	Main Hook (24 to 185 ton)	C to B
	Bridge Crane	2	Load cask onto vehicle	1	Main Hook (24 to 185 ton)	B
	Bridge Crane	2	Install tie-downs and impact limiters	1	Auxiliary Hook (5 to 25 ton)	B
	Onsite Drive Unit	1	Move vehicle and cask out of vehicle loading area	1	10 Railcars	B to A
1.5.2	Fuel handling Bridge Crane	4	Remove waste from cask and place in storage	1	1 SFA	D to E
	Bridge Crane	2	Move cask inner lid to cask	1	Auxiliary Hook (5 to 25 ton)	C to D
1.6	Onsite Drive Unit	1	Move vehicles carrying casks from outer guardhouse to washdown area and on to vehicle storage area	1	10 Railcars	A
1.8	Onsite Drive Unit	1	Move vehicle and cask to onsite dispatch area	1	10 Railcars	A

(a) Because the type of secondary storage has not been selected, this table contains the equipment needed for three potential types of storage (S/T casks, concrete casks and concrete storage modules). The equipment used in equipment analyses will have to be selected after the storage type is selected.

(b) Equipment identification included as an aid to equipment cost and utilization studies.

**TABLE 4.5. Major Waste Handling Equipment at Pool Storage Sites (Module 1A) -
Listed by Equipment Item(a)**

Equipment Title	Equipment (b) Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity	Locations (Figures 4.11 to 4.13)
Onsite Drive Unit	1	1.4.1	Move vehicles carrying casks into vehicle loading area	1	10 Railcars	A to B
		1.4.1	Move vehicle without cask to parking area			B to A
		1.4.3	Move vehicle into cask loading area			A to B
		1.3.3.3	Move vehicle and cask from vehicle loading area to storage facility			B to A
		1.5.1	Move vehicles carrying casks into vehicle loading area			A to B
		1.5.1	Move vehicle without cask to parking area			B to A
		1.5.3	Move vehicle into cask loading area			A to B
		1.4.3	Move vehicle and cask out of vehicle loading area			B to A
		1.5.3	Move vehicle and cask out of vehicle loading area			B to A
		1.6	Move vehicles carrying casks from outer guardhouse to washdown area and on to vehicle storage area			A
		1.8	Move vehicle and cask to onsite dispatch area			A
Bridge Crane	2	1.3.1.1	Install service platform around cask	1	Auxiliary Hook (5 to 25 ton)	C
		1.3.1.1	Move cask outer lid to service pad			C
		1.3.1.1	Move service platform away from cask			C
		1.3.1.1	Move cask inner lid to service pad			C
		1.3.1.2	Move cask inner lid to cask			C to D
		1.4.2	Move cask inner lid to cask			C to D
		1.3.1.3	Install service platform around cask			C
		1.3.1.3	Move cask outer lid to cask			C

TABLE 4.5. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity Auxiliary Hook (5 to 25 ton)	Locations (Figures 4.11 to 4.13)
Bridge Crane (contd)	2	1.3.1.3	Move service platform away from cask			C
		1.3.3.2	Install service platform around cask			C
		1.3.3.2	Move cask outer lid to service pad			C
		1.3.3.2	Move service platform away from cask			C
		1.3.3.2	Move cask inner lid to service pad			D to C
		1.3.3.3	Move cask inner lid to cask			C to D
		1.4.3	Install service platform around cask			C
		1.4.3	Move cask outer lid to cask			C
		1.4.3	Move service platform away from cask			C
		1.4.1	Remove impact limiters and cask tie-downs			B
		1.4.1	Install service platform around cask			C
		1.4.1	Move cask outer lid to service pad			C
		1.4.1	Move service platform away from cask			C
		1.4.1	Move cask inner lid to service pad			D to C
		1.5.2	Move cask inner lid to cask			C to D
		1.3.3.3	Install service platform around cask			C
		1.3.3.3	Move cask outer lid to cask			C
		1.3.3.3	Move service platform away from cask			C
		1.4.3	Install tie-downs and impact limiters			B
		1.5.1	Remove impact limiters and cask tie-downs			B
		1.5.1	Install service platform around cask			C
		1.5.1	Move cask outer lid to service pad			C

TABLE 4.5. (contd)

Equipment Title	Equipment (b) Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity	Locations (Figures 4.11 to 4.13)
Bridge Crane (contd)	2	1.5.1	Move service platform away from cask		Auxiliary Hook (5 to 25 ton)	C
		1.5.1	Move cask inner lid to service pad			D to C
		1.5.3	Install service platform around cask			C
		1.5.3	Move cask outer lid to cask			C
		1.5.3	Move service platform away from cask			C
		1.5.3	Install tie-downs and impact limiters			B
		1.3.1.1	Move cask to service pad	1	Main Hook (24 to 185 ton)	D
		1.3.1.1	Move cask to loading area			C
		1.3.1.3	Move cask to service pad			D to C
		1.3.1.3	Move cask to vehicle loading area			C to B
		1.3.1.3	Load cask onto transporter			B
		1.3.3.1	Move cask to service pad			B to C
		1.3.3.2	Move cask to cask loading area			C to D
		1.3.1.3	Move cask to service pad			D to C
		1.4.3	Move cask to vehicle loading area			C to B
		1.3.1.3	Load cask onto transporter			
		1.4.1	Move cask to service pad			B to C
		1.4.1	Move cask to cask loading area			C to D
		1.4.3	Move cask to service pad			D to C
		1.3.3.3	Move cask to vehicle loading area			C to B

TABLE 4.5. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity	Locations (Figures 4.11 to 4.13)
Bridge Crane (contd)	2	1.3.3.3	Load cask onto transporter			B
		1.4.3	Load cask onto vehicle			B
		1.5.1	Move cask to service pad			B to C
		1.5.1	Move cask to cask loading area			C to D
		1.5.3	Move cask to service pad			D to C
		1.5.3	Move cask to vehicle loading area			C to B
		1.5.3	Load cask onto vehicle			B
		1.3.1.1	Support personnel working on cask	1	1 to 5 ton	C
Cask Service Platform	3	1.3.1.3	Support personnel working on cask			C
		1.3.3.2	Support personnel working on cask			C
		1.4.1	Support personnel working on cask			C
		1.4.3	Support personnel working on cask			C
		1.5.1	Support personnel working on cask			C
		1.5.3	Support personnel working on cask			C
		1.1	Move SFAs in spent fuel pool	1	1 SFA	E
		1.3.1.2	Load SFAs into cask			E to D
Fuel Handling Bridge Crane	4	1.5.2	Remove wastes from cask and place in storage			D to E
		1.4.2	Load SFAs into cask			E to D
		1.3.3.2	Transfer SFAs from cask to temporary storage			D to E

TABLE 4.5. (contd)

Equipment Title	Equipment (b) Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity	Locations (Figures 4.11 to 4.13)
Cask Transporter	5	1.3.1.1	Move cask into vehicle loading area	1	150 ton	A
		1.3.1.3	Move vehicle and cask to secondary storage area			B to A
		1.3.3.1	Transport cask to vehicle loading area			A to B
Mobile Crane	6	1.3.1.1	Load cask onto transporter	1	150 ton	A
		1.3.1.3	Transfer cask from transporter to storage pad or support transfer cask during transfer of wastes into secondary storage			A
		1.3.3.1	Transfer storage cask from storage pad to transporter or support transfer cask during removal of wastes from secondary storage			A

(a) Because the type of secondary storage has not been selected, this table contains the equipment needed for three potential types of storage (S/T casks, concrete casks and concrete storage modules). The equipment used in equipment analyses will have to be selected after the storage type is selected.

(b) Equipment identification included as an aid to equipment cost and utilization studies.

**TABLE 4.6. Major Waste Handling Equipment at Dry-Vault Storage Sites (Module 1A) -
Listed in Process Step Order**

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units	Size or Capacity	Location (Figure 4.17)
1.1	Hot Cell Bridge Crane	5	Move canisters in dry vault	1	25 ton	E
1.4.1	Onsite Drive Unit	1	Move vehicles carrying casks into vehicle loading area	1	10 Railcars	B
	Bridge Crane	2	Remove impact limiters and cask tie-downs	1	Auxiliary Hook (25 ton)	B
	Cask Cart	3	Support cask	2	150 ton	C
	Bridge Crane	2	Move cask to cask cart	1	Main Hook (200 ton)	B to C
	Cask Service Platform	4	Support personnel working on cask	1	5 ton	C
	Onsite Drive Unit	1	Move vehicle without cask to parking area	1	10 Railcars	B
	Bridge Crane	2	Move cask outer lid to service pad	1	Auxiliary Hook (25 ton)	C
	Cask Cart	3	Move cask to cask loading area	2	150 ton	C to D
	Cask Contamination Barrier	6	Installed to prevent spread of contamination	4	1 Cask	D
	Hot Cell Bridge Crane	5	Move hot cell port plug and cask inner lid to storage areas	1	25 ton	D
1.4.2	Hot Cell Bridge Crane	5	Load canisters into cask	1	25 ton	E to D
	Hot Cell Bridge Crane	5	Move cask inner lid to cask. Install hot cell port plug	1	25 ton	D
	Cask Cart	3	Support cask	2	150 ton	D

TABLE 4.6. (contd)

Function Reference Number	Equipment Title	Equipment Identification	Function/Activity	Number of Units	Size or Capacity	Location (Figure 4.17)
1.4.3	Cask Contamination Barrier	6	Disconnected from cask	4	1 Cask	D
	Cask Cart	3	Move cask to service pad	1	150 ton	D to C
	Cask Service Platform	4	Support personnel working on cask	1	5 ton	C
	Onsite Drive Unit	1	Move vehicle into vehicle loading area	1	10 Railcars	B
	Bridge Crane	2	Move cask outer lid to cask	1	Auxiliary Hook (25 ton)	C
	Bridge Crane	2	Move cask to vehicle loading area	1	Main Hook (200 ton)	C to B
	Bridge Crane	2	Load cask onto vehicle	1	Main Hook (200 ton)	B
	Bridge Crane	2	Install tiedowns and impact limiters	1	Auxiliary Hook (25 ton)	B
	Onsite Drive Unit	1	Move vehicle and cask out of vehicle loading area to holding area	1	10 Railcars	B
1.6	Onsite Drive Unit	1	Move vehicles carrying casks from outer guardhouse to washdown area and on to vehicle storage area	1	10 Railcars	--
1.8	Onsite Drive Unit	1	Move vehicle and cask to onsite dispatch area	1	10 Railcars	--

(a) Equipment identification included as an aid to equipment cost and utilization studies.

**TABLE 4.7. Major Waste Handling Equipment at Dry-Vault Storage Sites (Module 1A) -
Listed by Equipment Item**

Equipment Title	Equipment (a) Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity	Location (Figure 4.17)
Onsite Drive Unit	1	1.4.1	Move vehicles carrying casks into vehicle loading area	1	10 Railcars	B
		1.4.1	Move vehicle without cask to parking area			B
		1.4.3	Move vehicle into vehicle loading area			B
		1.4.3	Move vehicle and cask out of vehicle loading area to holding area			B
		1.6	Move vehicles carrying casks from outer guardhouse to washdown area and on to vehicle storage area			--
		1.8	Move vehicle and cask to onsite dispatch area			--
		1.4.1	Remove impact limiters and cask tiedowns	1	Auxiliary Hook (25 ton)	B
		1.4.1	Move cask outer lid to service pad			C
Cask Cart	3	1.4.3	Move cask outer lid to cask			C
		1.4.3	Install tiedowns and impact limiters			B
		1.4.1	Move cask to cask cart	1	Main Hook (200 ton)	B to C
		1.4.3	Move cask to vehicle loading area			C to B
		1.4.3	Load cask onto vehicle			B
		1.4.1	Support cask	2	150 ton	C
		1.4.1	Move cask to cask loading area			C to D
		1.4.2	Support cask			D
Cask Service Platform	4	1.4.3	Move cask to service pad			D to C
		1.4.1	Support personnel working on cask	1	5 ton	C
		1.4.3	Support personnel working on cask			C

TABLE 4.7. (contd)

Equipment Title	Equipment (a) Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity	Location (Figure 4.17)
Hot Cell Bridge Crane	5	1.1	Move canisters in dry vault	1	25 ton	E
		1.4.1	Move hot cell port plug and cask inner lid to storage areas			D
		1.4.2	Move cask inner lid to cask. Install hot cell port plug			D
		1.4.2	Load canisters into cask			E to D
Cask Contamination Barrier	6	1.4.1	Installed to prevent spread of contamination	4	1 Cask	D
		1.4.3	Disconnected from cask			D

(a) Equipment identification included as an aid to equipment cost and utilization studies.

TABLE 4.8. Reactor Plant Spent Fuel Pool Information and Shipping Crane Capacities(a)

ID	STATE	REACTOR	REACTOR TYPE	POOL SHARING	POOL MAXIMUM CAPACITY (ASSEMBLIES)	REACTOR FULL CORE RESERVE (ASSEMBLIES)	CANISTERS OF FUEL IN POOL (AS OF 12-88)	CRANE CAPACITY --- RATING (TONS)	CRANE CAPACITY CURRENT DEBATED CAP. (TONS)	SHIPPING MODE ASSUMED POSSIBLE	CURRENT FUEL TYPE
0101	AL	FARLEY	1	PWR	NO	1407	157	125		RAIL	WE17JWST
0102	AL	FARLEY	2	PWR	NO	1407	157	125		RAIL	WE17JWST
0301	AZ	PALO VERDE	1	PWR	NO	1329	241	160		RAIL	CE160CS8
0302	AZ	PALO VERDE	2	PWR	NO	1329	241	160		RAIL	CE160CS8
0303	AZ	PALO VERDE	3	PWR	NO	1329	241	160		RAIL	CE160
0401	AR	ARK NUCLEAR	1	PWR	NO	968	177	100	160	RAIL	BW16KQUB
0402	AR	ARK NUCLEAR	2	PWR	NO	988	177	100	100	RAIL	CE16HCSO
0501	MD	CALVERT CLF 1	1	PWR	YES	1839	217	160		TRUCK	CE14ICST
0502	MD	CALVERT CLF 2	2	PWR	YES	0	217	160		TRUCK	CE14ICST
0601	MA	PILGRIM	1	BWR	NO	2328	580	100		TRUCK	GE08LG81
0701	NC	BRUNSWICK	1	BWR	NO	1803	650	125		TRUCK	GE08LG72
0702	NC	BRUNSWICK	2	BWR	NO	1839	580	125		TRUCK	GE08LG72
0703	NC	HARRIS	1	PWR	NO	1832	167	160		TRUCK	WE17J
0705	SC	ROBINSON	2	PWR	NO	544	157	125		TRUCK	EX16JEVE
0711	NC	BRUNSWICK 1 PWR	1	PWR	NO	100	0	125		TRUCK	CARETAKR
0712	NC	BRUNSWICK 2 PWR	2	PWR	NO	144	0	125		TRUCK	CARETAKR
0713	NC	HARRIS 1 BWR POOL	1	BWR	NO	968	0	160		TRUCK	CARETAKR
0901	OH	PERRY	1	BWR	NO	4029	748	125	125	RAIL	GE08L
0902	OH	PERRY	2	BWR	NO	9999	748	0		RAIL	GH 8*
1001	IL	BRAIDWOOD	1	PWR	YES	1013	193	125	15	RAIL	WE17JWOF
1002	IL	BRAIDWOOD	2	PWR	YES	0	193	125	15	RAIL	WE17J
1003	IL	BYRON	1	PWR	YES	2864	193	125		RAIL	WE17JWOF
1004	IL	BYRON	2	PWR	YES	0	193	125		RAIL	WE17JWOF
1005	IL	DRESDEN	1	BWR	NO	720	464	75		TRUCK	EX06EEGO
1006	IL	DRESDEN	2	BWR	NO	3537	724	125		RAIL	EX08LEG3
1007	IL	DRESDEN	3	BWR	NO	3537	724	125		RAIL	EX08LEG3
1008	IL	LASALLE CITY 1	1	BWR	YES	8146	784	125		RAIL	GE08LGS2
1009	IL	LASALLE CITY 2	2	BWR	YES	0	784	125		RAIL	GE08LG72
1010	IL	QUAD CITIES 1	1	BWR	YES	7651	724	125		RAIL	GE08LG71
1011	IL	QUAD CITIES 2	2	BWR	YES	0	724	125		RAIL	GE08LG71
1012	IL	ZION	1	PWR	YES	2879	193	125		RAIL	WE16JWOF
1013	IL	ZION	2	PWR	YES	0	193	125		RAIL	WE16JWOF
1101	NY	INDIAN PT 1	1	PWR	NO	766	120	75	75	TRUCK	WE14FWIP
1102	NY	INDIAN PT 2	2	PWR	NO	988	193	40	40	TRUCK	WE16JWZZ
1201	MT	BIG ROCK	1	BWR	NO	441	84	75	24	TRUCK	EX11AE8R
1204	WI	PALISADES	1	PWR	NO	892	204	100		TRUCK	EX16IEPR
1301	WI	LACROSSE	1	BWR	NO	440	72	50		TRUCK	EX10CEAC
1402	WI	EHRLIC FERMU2	2	BWR	NO	2383	784	125		RAIL	GE08L
1501	SC	CATAWBA	1	PWR	NO	2615	193	125	125	RAIL	WE17JWOF
1502	SC	CATAWBA	2	PWR	NO	2615	193	125	125	RAIL	WE17J
1504	NC	MCGUIRE	1	PWR	NO	1449	193	125		RAIL	WE17JWOF
1505	NC	MCGUIRE	2	PWR	NO	1437	193	125		RAIL	WE17JWOF
1506	SC	OCONEE	1	PWR	YES	1312	177	100	100	TRUCK	BW16KBBZ
1507	SC	OCONEE	2	PWR	YES	0	177	125	125	TRUCK	BW16KBBZ

TABLE 4.8. (contd)

ID	STATE	REACTOR	REACTOR TYPE	POOL SHARING	POOL CAPACITY (ASSEMBLIES)	REACTOR FULL CORE RESERVE (ASSEMBLIES)	CANISTERS OF FUEL IN POOL (AS OF 12-87)	CRANE CAPACITY NAMEPLATE RATING (TONS)	CRANE CAPACITY DERATED CAP. (TONS)	SHIPPING MODE ASSUMED POSSIBLE TYPE	CURRENT FUEL TYPE
1588	SC	OCONEE	PWR	NO	825	177		180	180	TRUCK	BW16KBBZ
1681	PA	BEAVER VALLEY 1	PWR	NO	833	167	1	130	125	RAIL	WE17JNST
1682	PA	BEAVER VALLEY 2	PWR	NO	1088	167		125		RAIL	WE17J
1781	FL	CRYSTAL RVR 3	PWR	NO	642	177		120		TRUCK	BW16KBMB
1881	FL	ST LUCIE 1	PWR	NO	1788	217		185	25	TRUCK	EX14IECE
1882	FL	ST LUCIE 2	PWR	NO	1684	217		160	180	TRUCK	CE16NCSL
1883	FL	TURKEY PT 3	PWR	YES	1378	167	1	105	25	TRUCK	WE15JNZZ
1884	FL	TURKEY PT 4	PWR	YES	614	167		105	25	TRUCK	WE16JNZZ
1981	PA	3 WILE ISL 1	PWR	NO	762	177		110		RAIL	BW16KBMB
1983	NJ	OYSTER CRK 1	BWR	NO	2680	560	17	100		TRUCK	EX08LEG3
2081	GA	HATCH 1	BWR	YES	5780	560	4	125		RAIL	GE08LG72
2082	GA	HATCH 2	BWR	YES	0	560		125		RAIL	GE08LG72
2083	GA	VOGUE 1	PWR	YES	2388	193		125		RAIL	WE17JNST
2084	GA	VOGUE 2	PWR	YES	0	193		125		RAIL	WE17J
2181	LA	RVR BEND 1	BWR	NO	3172	624		125		RAIL	GE08LG72
2281	TX	SOUTH TEXAS 1	PWR	NO	1969	193		160		RAIL	WE17P
2282	TX	SOUTH TEXAS 2	PWR	NO	1969	193		150		RAIL	WE17P
2381	IL	CLINTON 1	BWR	NO	2672	624		125		RAIL	GE08L
2481	IA	DUANE ARNOLD	BWR	NO	2850	368		180	180	TRUCK	GE08LG82
2581	KS	WOLF CREEK 1	PWR	NO	1340	193		150		RAIL	WE17JNST
2681	NY	SHOREHAM	BWR	NO	2686	560		125	125	TRUCK	GE08LG82
2781	LA	WATERFORD 3	PWR	NO	1088	217	1	125		RAIL	CE10NCSO
2881	ME	MAINE YANKEE	PWR	NO	1478	217	4	125		RAIL	EX14IECE
2981	MS	GRAND GULF 1	BWR	NO	3931	800		150		TRUCK	GE08LG82
3081	NE	COOPER STN	BWR	NO	2368	548		100		TRUCK	GE08LG82
3181	NY	NINE MILE PT1	BWR	NO	2778	532		125		RAIL	GE08LG81
3182	NY	NINE MILE PT2	BWR	NO	4049	784		125		RAIL	GE08L
3281	CT	MILLSTONE 1	BWR	NO	2184	680		110		TRUCK	GE08LG71
3282	CT	MILLSTONE 2	PWR	NO	1112	217	4	100		RAIL	WE14TMC
3283	CT	MILLSTONE 3	PWR	NO	1838	193		125		RAIL	WE17JNST
3381	MA	MONTICELLO	BWR	NO	2237	484		85		TRUCK	GE08LG81
3382	WI	PRAIRIE ISL 1	PWR	YES	1388	121	20	125		RAIL	EX14JEIR
3383	WI	PRAIRIE ISL 2	PWR	YES	0	121		125		RAIL	EX14IEFC
3481	NE	FORT CALHOUN	PWR	NO	729	133		75		TRUCK	WE17JNST
3581	CA	DIABLO CANYON 1	PWR	NO	1324	193		125		TRUCK	WE17JNST
3582	CA	DIABLO CANYON 2	PWR	NO	1324	193		125		TRUCK	WE17JNST
3583	CA	HUMBOLDT BAY	BWR	NO	488	184	1	75		TRUCK	EX06DEGH
3681	PA	SUSQUEHANNA 1	BWR	YES	5688	784	1	125		RAIL	GE08LG82
3682	PA	SUSQUEHANNA 2	BWR	YES	0	784		125	110	RAIL	GE08LG82
3781	PA	LIMERICK 1	BWR	YES	4880	784		125		RAIL	GE08LG72
3782	PA	LIMERICK 2	BWR	YES	0	764		125	110	RAIL	GE08L
3784	PA	PEACHBOTOM 2	BWR	NO	3814	784	2	125		TRUCK	GE08LG72
3785	PA	PEACHBOTOM 3	RAIL	NO	3819	764	1	125	110	TRUCK	GE08LG82
3881	OR	TROJAN	PWR	NO	1488	193		125		RAIL	WE17JNST
3981	NY	FITZPATRICK	BWR	NO	2854	560		125		RAIL	GE08LG72

TABLE 4.8. (contd)

ID	STATE	REACTOR	REACTOR TYPE	POOL SHARING	POOL MAXIMUM CAPACITY (ASSEMBLIES)	REACTOR FULL CORE RESERVE (ASSEMBLIES)	CANISTERS OF FUEL IN POOL (AS OF 12-87)	CRANE NAMEPLATE RATING (TONS)	CRANE CAPACITY DERATED CAP. (TONS)	SHIPPING MODE ASSUMED POSSIBLE	CURRENT FUEL TYPE
3982	NY	INDIAN PT	3	NO	1346	193		0		TRUCK	WE16JHOF
4201	NJ	HOPE CREEK		BWR	3978	784		160		TRUCK	GE98LG2
4202	NJ	SALEM	1	NO	1170	193		110		TRUCK	WE17JHST
4203	NJ	SALEM	2	NO	1170	193	1	110		TRUCK	WE17JHST
4481	NY	GINNA		NO	1910	121	8	40	32	TRUCK	WE14JHOF
4501	CA	RANCHO SECO	1	NO	1980	177		185		TRUCK	WE16KQMB
4681	SC	SUMNER	1	NO	1270	167		125		TRUCK	WE17JHST
4701	CA	SAN ONOFRE	1	YES	210	167		116	106	TRUCK	WE14FTSS
4702	CA	SAN ONOFRE	2	YES	800	217	1	125		RAIL	CE16WCSO
4703	CA	SAN ONOFRE	3	YES	800	217	1	125		RAIL	CE16WCSO
4801	AL	BELLEFRONTE	1	NO	1050	205		150		RAIL	WE16K
4802	AL	BELLEFRONTE	2	NO	1050	295		150		RAIL	WE16K
4803	AL	BROWN'S FERRY	1	YES	6942	784		125		TRUCK	GE98LG2
4804	AL	BROWN'S FERRY	2	YES	704	784		125		TRUCK	GE98LG2
4805	AL	BROWN'S FERRY	3	NO	3471	784		125		TRUCK	GE98LG2
4806	TN	SEQUOYAH	1	YES	1381	193		125		RAIL	WE17JHST
4809	TN	SEQUOYAH	2	YES	0	193		125		RAIL	WE17JHST
4810	TN	WATTS BAR	1	YES	1294	193		125		RAIL	WE17J
4811	TN	WATTS BAR	2	YES	0	193		125		RAIL	WE17J
4901	TX	COMANCHE PK	1	YES	3382	193		130	130	TRUCK	WE17J
4902	TX	COMANCHE PK	2	YES	0	193		130	130	TRUCK	WE17J
6001	OH	DAVIS-BESSE	1	YES	735	177		140		RAIL	WE16KQMB
6101	MO	CALLAWAY	1	NO	1340	193	1	169		TRUCK	WE17JHST
6201	VA	NORTH ANNA	1	YES	1737	167		125	125	RAIL	WE17JHST
6202	VA	NORTH ANNA	2	YES	0	167		125	125	RAIL	WE17JHST
6203	VA	SURRY	1	YES	1044	167	1	125	125	TRUCK	WE14JHST
6204	VA	SURRY	2	YES	0	167		125	125	TRUCK	WE16JH75
6301	EA	BNP-1		NO	9999	999		0		RAIL	CH17
6302	WA	WASH NUCLEAR	2	NO	2650	784		125		TRUCK	GE98LG2
6401	WI	POINT BEACH	1	YES	1387	121	12	125		TRUCK	WE14JHOF
6402	WI	POINT BEACH	2	YES	0	121		125		TRUCK	WE14JHOF
6501	WI	KEWAUNEE		NO	990	121		125		TRUCK	EX14JEWE
6601	MA	YANKEE-ROWE	1	NO	721	70	4	75		TRUCK	CE16DCYR
6701	CT	HADDAM NECK	1	NO	1168	167		100		TRUCK	WE16GBH
6801	MI	COOK	1	YES	2940	193		150	160	RAIL	WE16JHOF
6802	MI	COOK	2	YES	0	193		150	160	RAIL	EX17JEWE
6901	NH	SEABROOK	1	NO	1230	193		125		RAIL	WE17J
6001	VT	VT YANKEE	1	NO	2870	368		110		RAIL	GE98LG2
6401	NY	WEST VALLEY-B		NO	992	0		100	100	RAIL	CARETAKR
6402	NY	WEST VALLEY-P		NO	832	0		100	100	RAIL	CARETAKR
6601	IL	MORRIS-BWR		NO	3776	0		125	125	RAIL	CARETAKR
6602	IL	MORRIS-PWR		NO	1000	0		125	125	RAIL	CARETAKR

(a) Information provided by ORNL based on CY-1988 RW-859 Nuclear Fuel Data and other sources.

4.2 WASTE TRANSPORTATION (Module 2A)

The transportation of the wastes between the DOE waste management facilities requires two general types of activities: cask transportation between the facilities and cask servicing.

4.2.1 Cask Transportation

The transportation activities move waste transport casks between the waste generators, the MRS facility and the repository. The major requirements of these transportation activities will be to:

- provide transport casks appropriately designed for loading and unloading at the waste generators, MRS facility and repository, ready decontamination after submersion in wet storage facilities, satisfaction of regulatory requirements for routine radiation doses and accident resistance, and low system costs
- deliver empty casks to the waste generators and MRS facility
- transport casks in a safe, economically efficient manner that provides minimum adverse impacts on the general public and transport employees.

These requirements provide the reference basis for this physical description of the cask transportation activities.

4.2.1.1 Level 1 Physical Description (Module 2A)

Cask transportation from the waste generators requires three activities:

- inspection and acceptance (Function 2.1)
- transportation over railroads and waterways (Function 2.2)
- transportation over highways (Function 2.2).

Facilities and equipment required for each of these transportation activities are discussed below. A central cask fleet dispatching center in the support services building at the MRS facility (or at the repository if the MRS facility is not built) will control cask scheduling.

The information in this subsection was obtained primarily from DOE (1987a), Sandia (1983), Wooden (1986), 40 CFR 173, and the unpublished U.S. DOE Transportation System Data Base.

Function 2.1 - Inspection and Acceptance. The inspection and acceptance of the transport casks occurs at the vehicle dispatch areas on the waste generator's property and the DOE facilities. These are a railroad track and/or a truck parking area inside the facility perimeter fence so that the casks have normal facility security surveillance. The truck parking area has to have a capacity of only one truck. The railroad vehicle parking area, on the other hand, must have sufficient capacity for at least three cask cars at reactor sites or five cars at reprocessing plant sites. However, this parking area may be distributed among several locations if a single location with ample capacity is not available.

The tools and equipment for the inspection consist only of hand-held wrenches, pry bars and radiation monitors for determining the integrity of the personnel barriers, tightness of bolts, and the radiation fields.

Function 2.2.1 - Truck Transport for Waste Generators. A truck cask on a truck trailer may be either a legal weight truck (LWT) cask (less than 80,000 pounds for cask and truck) or an overweight truck (OWT) cask that requires a special permit to travel.

A truck shipment starts at the dispatch area near the perimeter fence of the waste generator. The shipment uses the connecting first-class highway to an interstate highway, interstate highways to the turnoff interchange to the destination, and a first-class connecting highway to the destination. Intermediate stops are made at truck stops for refueling, driver meals, and periodic check-in phone calls to the dispatch center, and at state inspection stations for inspections and check-in phone calls.

Generally, the transport route avoids high population areas when this can be done on first-class highways without incurring excessive extra travel distance.

The empty casks are returned to the waste generators as normal non-radioactive freight shipments.

Function 2.2.2 - Rail/Barge Transport for Waste Generators. A rail cask on a railroad car may be a commercial-weight cask (e.g., less than 110 tons) or an overweight cask (110 to 150 tons). Commercial-weight shipments (defined as total car plus cask weight of less than 263,000 pounds) can travel at normal freight-train speeds and as part of a normal freight train. Overweight cars must travel at lower speeds and only on tracks with adequate strength.

A rail shipment starts at the dispatch area near the perimeter fence of the waste generators. The shipment then proceeds over the connecting railroads to a main-line railroad and then over main-line railroads to the destination. During the shipment, short stops are made at classification terminals for crew changes, refueling, engine changes, and car inspections. Generally, because the shipments are by dedicated trains, no switch engines are needed at the classification terminals.

The spent fuel and HLW shipments are planned to be dedicated shipments. Such shipments are expected to consist of an engine, one to three cask cars from reactor sites and five cask cars from reprocessing plant sites, two to six buffer cars, several cars for non-fuel wastes, and a caboose. One buffer car is placed between the engine and the cask cars containing fuel, between adjacent cask cars and between the cask cars and the caboose.

A waterway shipment will be initiated as a truck or rail shipment from the dispatch area at the origin facility. The vehicle will carry the cask to a barge dock and will be loaded onto the barge. Because of the large capacity of barges, several casks will be shipped on one barge.

The barge will then transport the casks over canals, rivers, lakes and oceans to a barge dock as close as possible to the destination. The casks will be transported from the barge dock to the destination as truck or rail shipments.

The empty casks will be returned to the waste generators as normal non-radioactive truck or railcar freight shipments.

Function 2.2.3 - Rail Transport for the MRS Facility

All shipments to the repository from the MRS facility are by rail. The cask is an overweight cask weighing 150 tons when loaded. Overweight cars must travel at low speeds and only on tracks having adequate strength. In some scenarios, 100-ton rail casks from reactors may be received at the MRS facility and organized into five-cask-car shipments to the repository without unloading the spent fuel at the MRS facility.

The shipments are planned to be dedicated shipments. Such shipments are expected to consist of an engine, five cask cars, at least six buffer cars, several cars for non-fuel wastes, and a caboose. One buffer car is placed between the engine and the cask cars containing fuel, between adjacent cask cars and between the cask cars and the caboose.

A rail shipment starts at the dispatch area near the perimeter fence of the MRS facility. The shipment then proceeds over the connecting railroads to a main-line railroad and then as a single-destination shipment to the repository.

During the shipment, short stops are made at classification terminals for crew changes, refueling, engine changes, and car inspections. No car switching (other than engine changes) occurs. Generally, no switch engines are needed at the classification terminals.

The casks are returned to the MRS facility as overweight nonradioactive freight shipments.

4.2.1.2 Level 2 Physical Description (Module 2A)

The waste shipments will have three general configurations:

1. Truck casks on truck trailers (Functional step 2.2.1). A shipment consists of a tractor and a trailer carrying one cask.
2. Rail casks on railcars (Functional steps 2.2.2 and 2.2.3). A shipment consists of an engine, cask cars, buffer cars between the cask cars, and a caboose.
3. Intermodal transport of casks on trucks, railcars and barges (Functional steps 2.2.1 and 2.2.2). A shipment consists of many

shipments to and from the barges as described above, a tugboat and a barge loaded with many casks.

As shown in Table 4.3, the wastes will originate from several hundred different sources scattered throughout the country. They will be transported primarily over interstate highways and mainline railroads plus barge routes between those sources and the MRS facility and repository. The method selected for transport of specific shipments will depend on several variables such as the ability of the waste generator shipment facilities to handle rail and truck casks, the availability of barge transport at a lower cost than for railroad transport, and the effects of weather conditions on the available transport routes.

The general characteristics of the transport casks are listed in Table 4.9. Typical casks are illustrated in Figure 4.18.

The designs of these casks are based on the regulatory radiation dose maxima for the system design basis of PWR fuel exposed to 35,000 MWD/MTU and cooled for 5 years after discharge, and BWR fuel exposed to 50,000 MWD/MTU and cooled for 10 years. Since most fuel shipped will have other characteristics (designs, cooling, etc.), analyses to determine radiation doses should be based on radiation fields expected for the material in the casks. The wastes that may be shipped in each type of cask are listed in Table 4.10.

The transportation distances and times from the waste generators to the candidate repository site and to an example generic eastern MRS site are presented in Table 4.11. Except for connections at the origins, the routes are either mainline railroads or interstate highways. The connections to the MRS and the repository are expected to be either first-class railroads or highways.

Table 4.12 lists the general characteristics of truck shipments (Functional step 2.2.1). Table 4.13 lists the general characteristics of dedicated rail shipments of loaded casks (Functional steps 2.2.2 and 2.2.3). Table 4.14 lists the general characteristics of barge shipments (Functional step 2.2.2). The general characteristics of rail shipments of empty casks are listed in Table 4.15.

TABLE 4.9. Typical Waste Transport Cask Descriptions

Cask Type	Cask (c) Symbol	Cask Weight (tons) (a)		Cask Exterior Dimensions (a)		Capacity (b)					HLW Canisters
		Empty	Loaded	Length (in.)	Diameter (in.)	Intact PMR SFAS	Intact BMR SFAS	Intact (d,h)	Consolidated PMR	Consolidated BMR	
Rail/Barge	RC100	80	100	235	85	21	52(d,h)	42(d)	42(d)	104(d)	n.a.(e)
Legalweight Truck (BMR)	TC288	26	28	225	44	--	9(d,h)	--	--	9(d,f)	n.a.
Legalweight Truck (PMR)	TC28P	26	28	215	44	4	--	4	4	--	n.a.
Overweight Truck	TC40	36	40	215	51	5	12	6	6	14	n.a.
Storage/Transportation	RC125ST	95	125	235	72	24	61	48(d)	48(d)	122(d)	n.a.
HLW Truck	TC25HLW	23	26	151	46	n.a.	n.a.	n.a.	n.a.	n.a.	1
HLW Rail - Defense	RC100HLW	88	100	151	106	n.a.	n.a.	n.a.	n.a.	n.a.	5
HLW Rail - MRS	RC150HLW	133	150	151	106	n.a.	n.a.	n.a.	n.a.	n.a.	7
MRS Rail (g)	RC150MRS	112	150	208	76	34	80	56	56	140	n.a.
Long Rail	RC100L	87	108	260	69	18	42	36(d)	36(d)	84(d)	n.a.

- (a) Cask weights and dimensions obtained from DOE (1990a), DOE (1990b) or estimated by use of information in DOE (1987a). Cask empty weight includes the sealed empty cask, impact limiters and any ancillary equipment.
- (b) Capacities obtained from DOE (1990a), DOE (1990b) or estimated by use of information in DOE (1987a). Consolidation assumed to double the number of fuel pins shipped in the volume occupied by an intact SFA.
- (c) See Appendix A for explanation of symbols.
- (d) Current design studies indicate that these capacities may have to be reduced because of crane capacity limits at the waste generators and legalweight truck weight limits.
- (e) Not applicable.
- (f) Cask capacity limited by total permissible cask weight.
- (g) Cask also used to transport 4 cages or canisters of SFA hardware or 4 containers of spent fuel containing 12 intact PMR, 24 intact BMR, 24 consolidated PMR or 72 consolidated BMR SFAS, or 7 canisters of HLW.
- (h) Capacities without flow channels. If the flow channels are included, the capacities are 40 assemblies in a rail/barge cask or 5 in a legalweight truck cask.

FIGURE 4.18. Typical Transport Cask Designs

TABLE 4.10. Potential Contents in Transport Casks

Waste Forms and Canister or Container (b)	Transport Casks (a)									
	<u>RC100</u>	<u>RC100L</u>	<u>RC125ST</u>	<u>IC28</u>	<u>IC40</u>	<u>RC150MRS</u>	<u>RC100HLW</u>	<u>RC150HLW</u>	<u>IC25HLW</u>	
SFA_P	X	X	X	X	X					
AR9_SFA_P	X	X	X	X	X					
M9_SFA_P						X				
SFA_B	X		X	X	X					
AR6_SFA_B	X		X	X	X					
M6_SFA_B						X				
AR9_CON_P	X	X	X	X	X					
M9_CON_P						X				
AR6_CON_B	X		X	X	X					
M9_CON_B						X				
AR9_NFB_P	X	X	X	X	X					
MC_DRMNF_B_P						X				
AR6_NFB_B	X		X	X	X					
MC_DRMNF_B_B						X				
AR9_GTC_P	X	X	X	X	X					
AR6_GTC_B	X		X	X	X					

TABLE 4.10. (contd)

Waste Forms and Canister or Container (b)	Transport Casks (a)								
	RC100	RC100L	RC125ST	IC28	IC40	RC150MRS	RC100HLW	RC150HLW	IC25HLW
OU_SFA_U	X	X		X	X				
MU_OUSFA_O						X			
OU_GTC_O	X	X		X	X				
MU_OUGTC_O						X			
CRP_HLW_W							X	X	X
CRP_GTC_W							X	X	X
CRP_HLW_D							X	X	X
CRP_MSC_D							X	X	X
MC_MDRMGTC_M						X			
MU_GTC_M						X			
Y26I3_SFA_P						X			
Y26I6_SFA_B						X			
Y26I6_CON_B						X			
Y26I6_CON_P						X			
Y26I3_AR9SFA_P						X			
Y26I6_AR6SFA_B						X			
Y26I3_AR9CON_P						X			
Y26I6_AR6CON_B						X			
Y26I3_AR9NFB_P						X			
Y26I6_AR6NFB_B						X			
Y26I3_AR9GTC-P						X			
Y26I6_AR6GTC_B						X			

TABLE 4.10. (contd)

Waste Forms and Canister or Container (b)	Transport Casks (a)								
	RC100	RC100L	RC125ST	TC28	TC40	RC150MRS	RC100HLW	RC150HLW	TC25HLW
Y28C_OUSFA_O						X			
Y28C_OUGTC_O						X			
Y26H_CRPHLW_W						X			
Y26H_CRPGTC_W						X			
Y26H_CRHHLW_D						X			
Y26H_CRPGTC_D						X			
Y26C_DRMGTC_M						X			
Y26C_UGTC_M						X			
Y28BP_SFA_BP						X			
Y28I4_SFA_P						X			
Y28I10_SFA_B						X			
Y28I4_AR9SFA_P						X			
Y28I4_AR9CON_P						X			
Y28I4_AR9NFB_P						X			
Y28I4_AR9GTC_P						X			
Y28I10_AR6SFA_B						X			
Y28I10_AR6CON_B						X			
Y28I10_AR6NFB_B						X			
Y28I10_AR6GTC_B						X			

(a) Cask baskets are assumed to correspond to geometry of wastes and canisters. More than one type of waste form may be placed in a cask for a specific shipment.

(b) See Appendix A for explanation of symbols.

TABLE 4.11. Transportation Distances for Waste Shipments

INIS ID	Shipment Origin	Transport Distances (miles)			
		MRS		Candidate Repository Site	
		Highway	Railroad	Highway	Railroad
1901	3 Mile Island 1	413	387	2666	2815
401	Arkansas Nuclear 1	1155	1227	1744	2067
402	Arkansas Nuclear 2	1155	1227	1744	2067
1601	Beaver Valley 1	418	478	2347	2572
1602	Beaver Valley 2	418	478	2347	2572
1201	Big Rock Point	908	1033	2391	2481
1001	Braidwood 1	828	908	1902	2061
1002	Braidwood 2	828	908	1902	2061
4803	Browns Ferry 1	804	929	2279	2365
4804	Browns Ferry 2	804	929	2279	2365
4805	Browns Ferry 3	804	929	2279	2365
701	Brunswick 1	520	663	2836	3033
711	Brunswick 1 PWR Pool	520	663	2836	3033
702	Brunswick 2	520	663	2836	3033
712	Brunswick 2 PWR Pool	520	663	2836	3033
1003	Byron 1	894	947	1862	2095
1004	Byron 2	894	947	1862	2095
5101	Callaway 1	1001	1179	1807	1834
501	Calvert Cliffs 1	457	422	2714	2967
502	Calvert Cliffs 2	457	422	2714	2967
1501	Catawba 1	531	586	2528	2819
1502	Catawba 2	531	586	2628	2819
2301	Clinton	867	1001	1927	2077
4901	Comanche Peak 1	1442	1929	1747	1694
4902	Comanche Peak 2	1442	1929	1747	1694
5801	Cook 1	770	876	1985	2078
5802	Cook 2	770	876	1985	2078
3001	Cooper Station	1253	1473	1516	1620
1701	Crystal River 3	1044	1159	2837	3009
5001	Davis-Besse 1	552	617	2186	2387
3501	Diablo Canyon 1	2922	3200	546	687
3502	Diablo Canyon 2	2922	3200	546	687
1005	Dresden 1	826	894	1900	2003
1006	Dresden 2	826	894	1900	2003
1007	Dresden 3	826	894	1900	2003
2401	Duane Arnold	1041	1082	1721	1794
1402	Enrico Fermi 2	590	662	2179	2363
101	Farley 1	969	1024	2533	2956
102	Farley 2	969	1024	2533	2956
3901	Fitzpatrick	446	542	2622	2805
3401	Fort Calhoun	1262	1321	1458	1531
4101	Fort St. Vrain	TBD	TBD	897	1114
4401	Ginna	430	444	2533	2752
2901	Grand Gulf 1	1089	1123	2080	2419
5701	Haddam Neck	564	682	2809	3104
7003	Hanford Reservation	2771	3000	----	1302

TABLE 4.11.. (contd)

INIS ID	Shipment Origin	Transport Distances (miles)			
		MRS		Candidate Repository Site	
		Highway	Railroad	Highway	Railroad
703	Harris 1	450	678	2732	2962
713	Harris 1 BWR Pool	450	678	2732	2962
2001	Hatch 1	761	872	2619	2899
2002	Hatch 2	761	872	2619	2899
4201	Hope Creek	475	537	2755	2947
3503	Humboldt Bay	3327	3314	1003	1158
7002	Idaho Chemical Proc. Plant	2358	2454	----	756
1101	Indian Point 1	510	600	2728	3022
1102	Indian Point 2	510	600	2728	3022
3902	Indian Point 3	510	600	2728	3022
5501	Kewaunee	1004	1085	2098	2214
1301	La Crosse	1124	1108	1944	2094
1008	LaSalle City 1	845	920	1875	2046
1009	LaSalle City 2	845	920	1875	2046
3701	Limerick 1	486	449	2755	2881
3702	Limerick 2	486	449	2755	2881
2801	Maine Yankee	766	897	3029	3243
1504	McGuire 1	527	714	2597	2882
1505	McGuire 2	527	714	2597	2882
3201	Milestone 1	591	794	2813	3115
3202	Milestone 2	591	794	2813	3115
3203	Milestone 3	591	794	2813	3115
3301	Monticello	1250	1303	1863	1933
6601	Morris BWR Pool	828	892	1902	2001
6602	Morris PWR Pool	828	892	1902	2001
3101	Nine Mile Point 1	447	541	2623	2804
3102	Nine Mile Point 2	447	541	2623	2804
5201	North Anna 1	426	479	2741	2789
5202	North Anna 2	426	479	2741	2789
1506	Oconee 1	628	739	2536	2769
1507	Oconee 2	628	739	2536	2769
1508	Oconee 3	628	739	2536	2769
1903	Oyster Creek 1	516	573	2791	3030
1204	Palisades	763	906	2014	2108
301	Palo Verde 1	2376	2599	607	696
302	Palo Verde 2	2376	2599	607	696
303	Palo Verde 3	2376	2599	607	696
3704	Peach Bottom 2	431	406	2713	2860
3705	Peach Bottom 3	431	406	2713	2860
901	Perry 1	459	579	2290	2453
601	Pilgrim 1	651	781	2922	3203
5401	Point Beach 1	1000	1017	2094	2146
5402	Point Beach 2	1000	1017	2094	2146
3302	Prairie Island 1	1233	1248	1858	1894
3303	Prairie Island 2	1233	1248	1858	1894
1010	Quad Cities 1	951	1078	1770	2012

TABLE 4.11. (contd)

INIS ID	Shipment Origin	Transport Distances (miles)			
		MRS		Candidate Repository Site	
		Highway	Railroad	Highway	Railroad
1011	Quad Cities 2	951	1078	1770	2012
4501	Rancho Seco	2882	3334	680	821
2101	River Bend 1	1191	1296	2134	2676
705	Robinson 2	530	658	2681	2865
4202	Salem 1	475	543	2755	2953
4203	Salem 2	475	543	2755	2953
4701	San Onofre 1	2684	3112	415	455
4702	San Onofre 2	2684	3112	415	455
4703	San Onofre 3	2684	3112	415	455
7001	Savannah River Plant	624	735	----	2763
5901	Seabrook	661	800	2924	3146
4808	Sequoyah 1	735	723	2318	2537
4809	Sequoyah 2	735	723	2318	2537
2201	South Texas 1	1534	1607	1862	2613
2202	South Texas 2	1534	1607	1862	2613
1801	St. Lucie 1	1025	1192	2957	3116
1802	St. Lucie 2	1025	1192	2957	3116
4601	Summer 1	566	709	2600	2779
5203	Surry 1	463	600	2843	2891
5204	Surry 2	463	600	2843	2891
3601	Susquehanna 1	434	420	2565	2880
3602	Susquehanna 2	434	420	2565	2880
3801	Trojan	2948	3093	1328	1476
1803	Turkey Point 3	1171	1481	3103	3340
1804	Turkey Point 4	1171	1481	3103	3340
6001	Vermont Yankee 1	595	667	2848	3089
2003	Vogtle 1	650	739	2606	2934
2004	Vogtle 2	650	739	2606	2934
5302	Washington Nuclear 2	2786	3008	1166	1310
2701	Waterford 3	1146	1293	2200	2611
4810	Watts Bar 1	685	688	2368	2502
4811	Watts Bar 2	685	688	2368	2502
6401	West Valley BWR Pool	430	499	2452	2652
6402	West Valley PWR Pool	430	499	2452	2652
2501	Wolf Creek 1	1242	1333	1669	1766
5601	Yankee Rowe 1	632	622	2885	2968
----	Yucca Mountain, Nevada	----	2886	----	----
1012	Zion 1	861	894	1955	2023
1013	Zion 2	861	894	1955	2023

Source: Generic MRS distances derived from route-specific data provided by Geographic Data Systems Section, Computing and Telecommunication Division, Oak Ridge National Laboratory (ORNL), August 1988. Route-specific distances to Yucca Mountain, Nevada, also provided by ORNL, February 1988.

TABLE 4.12. General Characteristics of Truck Transport of Loaded Casks

	<u>Legal Weight Trucks</u>	<u>Overweight Trucks</u>
Transport mode	Single truck with trailer	Single truck with trailer
Total shipment weight	80,000 lb	110,000 lb
General transport methods	Continuous trip with short intermediate stops	Continuous trip with short intermediate stops routed to avoid states that prohibit night travel
Average speed while moving	40 mph	40 mph
Stop frequency		
Refueling	500 miles	500 miles
Food and rest	Every 6 to 7 hours	Every 6 to 7 hours
Communication stops	Every 2 hours	Every 2 hours
Inspection stops	Each state line	Each state line
Average	2 hours	2 hours
Daily travel	900 miles	900 miles

TABLE 4.13. General Characteristics of Rail Transport of Loaded Casks

	<u>Normal Weight Shipments</u>	<u>Overweight Shipments</u>
Transport mode	Dedicated train	Dedicated train
Number of casks per train	Variable(a)	Variable(a)
Total car and cask weight	<263,000 lb	380,000 lb
General transport method	Continuous trip with intermediate stops	Continuous trip with intermediate stops
Average speed	~7 mph	27 mph
Stop frequency	150 miles	150 miles
Daily travel	650 miles	650 miles

(a) Number of casks per train varies because: 1) a shipment from a reactor plant will contain all fuel expected to be shipped during 1 year and 2) shipments from the MRS to the repository will contain five cars of spent fuel plus a variable number of cars of hardware. Shipments from reprocessing plants will contain five cars of HLW.

TABLE 4.14. General Characteristics of Barge Transport of Loaded Casks

Transport mode	Dedicated barge
Number of casks per barge	10 to 50
General transport method	Continuous trip with intermediate stops
Average trip speed	2 mph
Stop frequency	Infrequent
Daily travel	48 miles

TABLE 4.15. General Characteristics of Rail Transport of Empty Casks

Transport mode	Normal freight shipments
Total shipment weight	240,000 lb
General transport method	Normal freight shipment
Average speed	22 mph
Stop frequency	150 miles
Daily travel	530 miles

4.2.2 Cask Servicing

The major requirement for this activity will be to maintain all waste management system transport casks and vehicles in satisfactory condition such that there is no significant reduction in the safety and efficiency of the transportation systems because of cask or vehicle deterioration.

The cask servicing facilities provide major maintenance, decontamination, inspection and testing of the transport casks and associated transport vehicles. Scheduling and control of these activities and of cask dispatching will occur at the central cask fleet dispatching center in the support services building at the MRS facility.

The transport casks and vehicles will be serviced in a support services facility at the MRS facility (or at the repository if there is no MRS) solely for that purpose. Casks and vehicles will be moved to and from that facility by the onsite drive vehicles that service the process buildings.

Figures 4.19 and 4.20 present a cutaway perspective and a plan view of the facility, respectively. Table 4.16 lists the process areas in that

facility, the functions of those areas, the internal dimensions, and location keys that indicate where on Figure 4.20 the various process areas are located in that building. The major process equipment needed for the fleet servicing facility is listed in Table 4.17.

The information in this subsection was obtained primarily from DOE (1987b), Sandia (1987a) and AGNS (1980).

FIGURE 4.19. Fleet Service Facility

Note: Letters in squares identify process areas listed in Table 4.16.

FIGURE 4.20. Plan View of Integrated Fleet Service Facility

TABLE 4.16. Support Services Facility Process Room Dimensions

<u>Process Room</u>	<u>Approximate Dimension (feet)</u>			<u>Location Symbol (a)</u>
	<u>Length</u>	<u>Width</u>	<u>Height</u>	
Cask and Vehicle Washdown	105	46	27	A
Cask Unloading	70	68	50	B
Test and Inspection	102	68	27	C
Test and Repair	71	68	50	D
Cask and Insert Cleaning	70	42	29	E
Transfer Hall	49	42	50	F

(a) Letter symbol indicates location on Figure 4.20.

TABLE 4.17. Major Process Equipment in Fleet Servicing Facility

<u>Equipment Title</u>	<u>Equipment Identification</u>	<u>Function/Activity</u>	<u>Number of Units</u>	<u>Size or Capacity</u>
Cask Pit Covers	1	Provide shielding and ventilation control on cask pits	20	1 pit
Bridge Crane	2	Move casks between servicing stations	1	150/30 ton
Jib Cranes	3	Move cask lids and inserts	4	--
Storage Bay Crane	4	Move cask tiedowns and impact limiters between railcars and storage area	1	15 ton
Insert Service Crane	5	Move cask inserts between service stations	1	10 ton
Test Bay Crane	6	Move test equipment	1	15 ton
Cask Service Cart	7	Support and move cask service equipment	1	--

4.3 MONITORED RETRIEVABLE STORAGE FACILITY

The MRS facility may provide spent fuel consolidation, preparation of wastes for storage or repository emplacement, and temporary storage of wastes awaiting further processing or permanent disposal in a geologic repository. (The actual activities will depend on the scenario being evaluated.) Possible requirements for this facility could include:

- receive and ship spent fuel and other wastes from civilian and defense nuclear facilities
- consolidate spent fuel into more compact configurations as a means for reducing waste management system costs
- package the spent fuel and other wastes as needed for storage or disposal
- safely store no more than 15,000 MTU of spent fuel and other wastes until it can be accommodated at the geologic repository
- continuously monitor and manage spent fuel and other wastes while in storage
- remove stored spent fuel and other wastes for further processing and/or shipment to the geologic repository.

These requirements provide the reference basis for this physical description of the eight MRS modules (Modules 3A through 3H).

There are three general types of facilities at an MRS facility: 1) the support facilities, 2) the waste receiving, handling, and processing facilities, and 3) the interim storage facilities. The general characteristics of these facilities and their alternatives are described here. A layout of an example MRS facility employing sealed-storage-cask storage is shown in Figure 4.21. Table 4.18 lists the primary support facilities at the MRS, their purposes and typical building areas. The locations of the larger buildings are shown in Figure 4.21. Similar support facilities are required regardless of what other components are included.

The information in this subsection is based primarily on Parsons (1985), Woods (1988), Woods (1990), and Weston (1989).

FIGURE 4.21. Example MRS Facility Layout

TABLE 4.18. MRS Primary Support Facilities(a)

Facility Title	Facility Purpose	Approximate Area (b) (ft ²)
Administration Building	House facility administrative activities	19,000
Security Building	House security administrative activities	9,100
Main Gate Badgehouse	Control access to support services facilities	1,500
Inspection Gatehouse	Control access for waste shipments to protected area	1,200
Protected Area Gatehouse	Control access for personnel and operation materials to protected area	6,500
Storage Area Gatehouse	Control access to waste interim storage area	100
Site Services Building	House site services activities	68,000
Warehouse	Store operations materials and spare parts	39,000
Vehicle Maintenance	Vehicle maintenance	18,000
Fire Station	House fire fighting vehicles and personnel	8,400
Standby Generator	House standby generators	10,850
Sewage Treatment	House chemical makeup and sewage treatment control activities	3,840
Water Treatment	House water treatment activities	1,360
Cask Manufacturing	Sealed storage cask manufacturing	117,000

(a) See Figure 4.21 for locations of the larger buildings.

(b) Example areas for a facility containing a sealed-storage-cask storage facility and an RHB with consolidation. Scenarios with smaller or less facilities will have smaller support facility areas.

4.3.1 Transfer Facility (Module 3A)

The primary purposes of the Transfer Facility (TF) are to receive shipments of loaded transport casks, unload the wastes from these casks, place the wastes in sealed storage or transfer casks, remove wastes from sealed storage or transfer casks, and place wastes in transport casks.(a)

4.3.1.1 Level 1 Physical Description of the TF (Module 3A)

The TF is a temporary facility that can be built rapidly to permit receipt of wastes before an SFHB or RHB is available. Figures 4.22 and 4.23 present simplified floor plans for the TF. Location numbers for facilities and functions that will be referred to later are shown on these figures. Numbers in circles identify locations of functions described in the functional descriptions. Letters in squares identify locations of waste processing areas listed in tables in these physical descriptions. Letters in diamonds identify locations of support facilities listed in tables in these physical descriptions.

The TF is composed of a single transfer cell system. The primary process areas are a transport cask receiving, inspection, and shipping area; two transport cask handling, preparation and decontamination areas; two shipping cask unloading/loading cells; a transfer cell; a storage cask loadout and decontamination cell; and a storage cask transfer/discharge corridor. In addition to these basic process areas, rooms are provided for supporting activities, storage space and corridors. Table 4.19 lists the approximate process area internal dimensions and location keys that indicate where (on Figures 4.22 and 4.23) the various functions are located in the TF.

The TF support facilities are shown in Figures 4.22 and 4.23. The TF contains numerous support facilities necessary for safe and efficient performance of its operations. The primary support facilities, their functions and location keys for locating these facilities in Figures 4.22 and 4.23 are listed in Table 4.20.

-
- (a) Although the TF was designed for placing wastes in sealed storage casks, relatively minor equipment and building changes would permit placing wastes in transfer casks so that the wastes can be stored in drywells or vaults.

NOTE: Letters and numbers relate facility locations to descriptions in text.
 NUMBERS: Numbers in circles identify locations of functions.
 Letters in squares identify waste processing areas listed in Table 4.19.
 Letters in diamonds identify building support facilities listed in Table 4.20.

FIGURE 4.22. First-Level Plan for the TF

S9101032.8

S9101032.7

NOTE: Letters and numbers relate facility locations to descriptions in text.
 NUMBERS: Numbers in circles identify locations of functions.
 Letters in squares identify waste processing areas listed in Table 4.19.
 Letters in diamonds identify building support facilities listed in Table 4.20.

FIGURE 4.23. Second-Level Plan for the TF

TABLE 4.19. TF Process Area Dimensions

<u>Process Room</u>	<u>Approximate Dimension (feet)</u>			<u>Location Symbol (a)</u>
	<u>Length</u>	<u>Width</u>	<u>Height</u>	
Air-Control Vestibules	142(b)	47	34	A
Receiving, Inspection and Shipping	174	47	51	B
Cask Unloading				
Loading/Unloading Platform	112	34	48	C
Cask Preparation	39	32	30	D
Cask Unloading	21	26	30	E
Transfer Cell	81	39	40	F
Cask Loadout and Decontamination	29	39	30	G
Transfer/Discharge Corridor	47	73	51	H

(a) Letter symbol indicates location (letter in square) on Figures 4.22 and 4.23.

(b) Length of each vestibule.

TABLE 4.20. TF Primary Process Support Facilities

<u>Facility</u>	<u>Function</u>	<u>Location Key (a)</u>	
		<u>Building Level</u>	<u>Symbol</u>
Administration	Management functions	1	H
Health Physics	Health physics offices, laboratories and ready rooms	1	I
Operation Support	Equipment rooms, material handling and storage	All	O
Maintenance	Maintenance shops and storage	1	P
Air Conditioning	Air purification, distribution and exhaust treatment.	All	R

(a) Symbol indicates location (letter in diamond) on Figures 4.22 and 4.23.

Function 3.1 - Transport Cask Receipt. The casks are received at the inspection gatehouse. They travel from that gatehouse on the facility roads and railroad tracks to either a lag storage holding area or the TF.

Function 3.2 - Transport Cask Lag Storage. The cask and vehicle holding areas are truck parking areas for trucks and railroad car spurs for railroad cars. All are located inside the MRS facility protected area to assure proper security surveillance.

Function 3.3 - Cask Preshipment Inspection and Servicing. These activities occur in the cask and vehicle holding areas described above for Function 3.2.

Function 3.4 - Transport Cask Unloading. The cask receiving facilities in the TF are illustrated in Figure 4.24, and the general location of these facilities in the TF is shown in Figure 4.22. The casks are received in the receiving, inspection and shipping area. This room has facilities and equipment for receiving trucks and railroad cars transporting loaded casks, unloading the casks from the transport vehicles, placing the casks on transfer carts, and reversing those processes (after the casks have been unloaded) for loading casks back onto the vehicles (i.e., moving the casks back to the vehicles, loading the casks on the vehicles, and then moving the vehicles out of the building).

FIGURE 4.24. Receiving, Inspection and Shipping Area

This large unshielded room contains a railroad track, extending the full length of the room. Large doors at both ends permit entrance and exit of vehicles, and walls containing doors at approximately 140 feet from each end create air-control vestibules so that vehicles can enter and leave without compromising the controlled ventilation system. The vestibules contain washdown equipment and are used for inspection of the casks and vehicles after washing. Overhead bridge cranes have capacity for lifting the loaded transport casks and transporting them to cask carts on the loading/unloading platforms on the process side of the receiving, inspection, and shipping area.

The locations of the cask unloading facilities are shown in Figures 4.22 and 4.23, and the facilities are illustrated in Figure 4.25. Cask unloading occurs in the cask unloading areas and the transfer cell. The cask unloading areas have equipment for transporting the casks from the receiving, inspection, and shipping areas to a shielded cell under the transfer cell, preparing the casks for unloading, connecting the casks to the transfer cell, and reversing those processes to return the empty casks to the receiving, inspection, and shipping area. With the casks sitting in the unloading cells, the contents are lifted out of the casks through a port in the cell ceiling into the transfer cell by use of the cell bridge crane.

The cask unloading areas consist of two transport cask unloading/loading cells (one for each port in Figure 4.22) and associated cask preparation and decontamination rooms. Each unloading cell is connected by rail tracks supporting a cask cart to the associated preparation and decontamination room and to the loading/unloading platforms in the receiving, inspection, and shipping areas. Ventilation doors separate the receiving, inspection, and shipping areas from the preparation and decontamination rooms, and shield doors separate the preparation and decontamination rooms from the unloading cells. The preparation and decontamination rooms contain movable work platforms and jib cranes for personnel working on the cask tops. Each unloading cell contains a port in the ceiling that is connected to the cask tops for unloading operations.

FIGURE 4.25. Cask Unloading Area

There is one transfer cell at the TF. The cell has two transport cask receiving ports in the floor. Each port connects the transfer cell to an unloading cell directly underneath. Each cell also includes a separate port for mating to the MRS storage or transfer casks. Overhead cranes in the cell lift the wastes out of the casks and transport them inside the cell. These transfer cells are equipped to unload wastes from transport casks, place them in the cell lag storage, and load the wastes into storage or transfer casks and to also reverse these operations.

The routine cask preparation for shipment occurs in the unloading, preparation and receiving, inspection, and shipping areas described above and uses the same equipment as is used for cask receipt and unloading.

Function 3.5 - Waste Lag Storage. The waste lag storage is illustrated in Figure 4.25. The transfer cell contains a lag storage facility, and the general location is shown in Figure 4.23. The facility is of modular construction with separate modules for PWR and BWR assemblies. The maximum

number of assemblies that can be stored is equal to the contents of one concrete storage cask. The facility is served by the cell overhead cranes and by power masts attached to the cranes.

Function 3.8 - Interface to Long-Term Storage. The interface to long-term storage activities in the TF is illustrated in Figure 4.26. The location in the TF is shown in Figure 4.22. The transfer cell is connected by a loading port in the floor to a storage cask loadout and decontamination room directly underneath. The loadout and decontamination room is designed for receiving storage or transfer casks on straddle carriers, preparing those casks for loading or unloading, connecting the tops of those casks to the port in the transfer cell floor, disconnecting those casks from the port, preparing the casks for storage, and then moving the casks and straddle carriers out of the building. The loadout and decontamination room is large enough to accommodate a cask on a cart underneath the loading port and also in another position, as shown in Figure 4.26 for removal and installation of the outer lid and for decontamination. The casks are transported to the storage facilities over the facility roads or transfer cask rail system.

FIGURE 4.26. Sealed Storage Cask in Loadout and Decontamination Room

Function 3.9 - MRS Transport Cask Loading. Transport cask loading occurs at the TF in the same facilities as are described in Function 3.4 for cask unloading. The transport casks to be loaded are handled in the same manner as the casks that are unloaded except that wastes are placed in the casks, rather than removed, and the casks are inerted and more thoroughly inspected before shipment.

Function 3.16 - Balance-of-Plant Operations and Support. These activities occur both in the process buildings and the many support buildings, as appropriate, for the most efficient performance of those activities.

4.3.1.2 Level 2 Physical Description (Module 3A)

The TF was designed to receive, transfer, and ship a minimum of 500 MTU of waste per year. It would operate 24 hours per day, 5 days per week for waste transfers. But shipments could be picked up or received on a 24-hour, 7-day-per-week schedule.

As the development of the base-case preconceptual design proceeded, it became obvious that there was a minimum size of facility that would be necessary to provide the required functions with assurance of continued performance, and that this facility would have throughput capabilities greatly in excess of the minimum required to avoid deployment of additional dry storage capacity at the reactors during the first 2 years of system operation. Thus, while the original study basis postulated an incremental addition to the larger, previously considered TF MRS SFHB configuration, one of the study results shows that it is very likely that the stand-alone TF could receive and store spent fuel at annual rates of 3,000 MTU/yr or more.

Table 4.21 contains general descriptions of the waste packages handled at the TF. All of these packages pass through the transfer cells and are placed in storage. They also pass back through the transfer cells when being removed from storage and are shipped to the repository.

TABLE 4.21. Descriptions of the Wastes Received at the TF

Generic Waste Form	Outer Canister or Container Symbol (d)	Cross Section		Typical Lengths (a)		Source	Contents (c)		Symbol (d)
		Geometry (e)	Dimension (b) (in.)	Outer Item (in.)	Contents (in.)		Waste		
PUR SFA	None	Square	<9	160 to 180	--	PUR	PUR SFA		SFA_P
BWR SFA	None	Square	<6	170 to 180	--	BWR	BWR SFA		SFA_B
At-Reactor PUR Canister	AR9_P	Square	~9	186	160 to 180	PUR	PUR SFA		SFA_P
					152	PUR	PUR Fuel Rods		CON_P
					180	PUR	PUR SFA Hardware		NFB_P
					180	PUR	PUR Misc. Wastes		GTC_P
At-Reactor BWR Canister	AR6_B	Square	~6	186	170 to 180	PUR	BWR SFA		SFA_B
					164	BWR	BWR Fuel Rods		CON_B
					180	BWR	BWR SFA Hardware		NFB_B
					180	BWR	BWR Misc. Wastes		GTC_B

(a) Lengths accommodate most wastes, canisters and containers. Other lengths needed for a few exceptions.

(b) Approximate dimensions. Canister and container dimensions are selected such that they can be nested.

(c) Wastes listed are the basic waste form inserted into the canister or container identified in column 2. The symbol identifies any canisters that were used to contain the waste prior to insertion into the canister or container identified in column 2. The symbol does not include the outer canister or container listed in the first two columns.

(d) See Appendix A for further explanation of symbols.

(e) See Figures 4.1 and 4.10 for square cross section.

The major process equipment needed for waste handling at the TF is listed in Table 4.22. The equipment lists in this table are keyed to the functional description reference numbers. This table includes the equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information.

Table 4.23 provides a cross-referenced list of the information in Table 4.22 by equipment item that shows the number of functions for which each equipment item is used.

The TF will be decommissioned by demolition of all surface facilities, burial of all radioactive components in appropriate burial grounds, and restoration of the surface to near natural conditions.

4.3.2 Spent Fuel Handling Building (Module 3B)

The primary purposes of the Spent Fuel Handling Building (SFHB) module are to receive shipments of loaded transport casks, unload the wastes from those casks, place the wastes in sealed storage casks or transfer casks, remove wastes from sealed storage casks or transfer casks, and place wastes in transport casks.

4.3.2.1 Level 1 Physical Description of SFHB (Module 3B)

Figures 4.27 to 4.29 present simplified floor plans for the building. Location numbers for facilities and functions that will be referred to later are shown on these figures. Numbers in circles identify locations of functions described in the functional descriptions. Letters in squares identify locations of waste processing areas listed in tables in these physical descriptions. Letters in diamonds identify locations of support facilities listed in tables in these physical descriptions.

The SFHB is composed of two parallel transfer cell systems. The primary process areas are a single transport cask receiving, inspection and shipping area, transport cask handling, preparation and decontamination areas, six shipping cask unloading/loading cells, two parallel transfer cells, two parallel storage cask loadout and decontamination cells, and a storage cask transfer/discharge corridor. In addition to these basic process areas, rooms are provided for supporting activities, storage space and corridors.

TABLE 4.22. Major Waste Handling Equipment at the TF, SFHB and RHB - Listed in Process Step Order

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module				Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D		
3.1.1	Onsite Drive Unit	60	Connect to transport vehicle	2	2	2	2	8 Railcars	Around Process Building
3.1.2	Onsite Drive Unit	60	Connect to transport vehicle	2	2	2	2	8 Railcars	Around Process Building
3.2.1	Onsite Drive Unit	60	Move cask and vehicle to cask holding area	2	2	2	2	8 Railcars	Around Process Building
			Move cask and vehicle to support services facility						Around Process Building
3.2.2	Onsite Drive Unit	60	Move cask and vehicle to cask holding area	2	2	2	2	8 Railcars	Around Process Building
			Move cask and vehicle during makeup of shipments						Around Process Building
3.3.1	Onsite Drive Unit	60	Move cask and vehicles during inspections, repairs and train makeup	2	2	2	2	8 Railcars	Around Process Building
3.3.2	Onsite Drive Unit	60	Move cask and vehicle during inspections, repairs and train makeup	2	2	2	2	8 Railcars	Around Process Building
3.4.1.1	Onsite Drive Unit	60	Move cask and vehicle to washdown area or to support services facility	2	2	2	2	8 Railcars	Around Process Building and A
3.4.1.2	Truck Trailer Fifth Wheel	1	Support truck trailers inside process building	4	4	8	8	1 Truck Trailer	A, B
	Car Puller	2	Move vehicles and casks inside process building	3	3	6	6	10,000 lb	A, B
	Mobile Crane	3	Remove impact limiters and cask tie-downs	2	2	2	2	40 ton	B
3.4.1.3	Bridge Crane	4	Move casks from vehicles to cask carts	2	2	4	4	200 ton	B to C
	Truck Trailer Fifth Wheel	1	Support truck trailers inside process building	4	4	8	8	1 Truck Trailer	B
	Cask Cart	5	Move casks from shipping dock to cask preparation room	3	6	10	10	200 Ton	C to D

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module				Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D		
3.4.1.4	Cask Service Platform	6	Support personnel working on cask	3	6	10	10	--	D
	Monorail Hoist	7	Remove cask outer lid	3	4	6	6	5 ton	D
3.4.1.5	Cask Service Platform	6	Support personnel working on cask	3	6	10	10	--	D
	Cask Contamination Barrier Adaptor	8	Provide connection between cask top and cell port	7	19	38	38	1 Cask	D
	Monorail Hoist	7	Install contamination barrier adaptor	3	4	6	6	5 ton	D
3.4.1.6	Cask Cart	5	Move cask to unloading room	3	3	10	10	200 ton	D to E
	Cask Contamination Barrier	9	Provide connection between cask top and cell port	2	6	10	10	1 Cask	E
3.4.1.7	Transfer, Canyon or Process Cell Input Port Plug	10	Removed from port	2	6	10	10	1 Port	F
	Transfer Cell Bridge Crane	64	Remove input port plug, remove cask inner lid	2	2	0	0	35 Ton	F
	Process Cell Bridge Crane	11	Remove input port plug, remove cask inner lid	0	0	4	4	20 ton	F
3.4.2	Transfer Cell Bridge Crane	64	Remove lag storage cover, transfer wastes from cask to lag storage, storage cask, or transport cask, replace lag storage cover	2	2	0	0	20 ton	F
	Process Cell Bridge Crane	11	Remove lag storage cover, transfer wastes from cask to lag storage or process, replace lag storage cover	0	0	4	4	20 ton	F
	Lag Storage Covers	12	Removed and replaced for waste movement into lag storage	2	10	20	20	--	F

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module				Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D		
3.4.3.1	Transfer Cell Bridge Crane	64	Inspect cask interior, replace cask inner lid, replace cell input port plug	2	2	0	0	35 ton	F
	Process Cell Bridge Crane	11	Inspect cask interior, replace cask inner lid, replace cell input port plug	0	0	4	4	20 ton	F
	Transfer Canyon or Process Cell Input Port Plug	10	Replaced in port	2	6	10	10	1 Port	F
3.4.3.2	Cask Contamination Barrier	9	Disconnected from cask	2	6	10	10	1 Cask	E
3.4.3.3	Cask Cart	5	Move cask to preparation room	3	6	10	10	200 ton	E to D
	Cask Service Platform	6	Support personnel working on cask	3	6	10	10	--	D
	Cask Contamination Barrier Adaptor	8	Removed from cask	7	19	38	38	1 Cask	D
	Monorail Hoist	7	Remove contamination barrier adaptor	3	4	6	6	5 ton	D
3.4.3.4	Monorail Hoist	7	Install cask outer lid	3	4	6	6	5 ton	D
3.4.3.5	Cask Cart	5	Move cask to shipping dock	3	6	10	10	200 ton	D to C
	Bridge Crane	4	Move cask to vehicle	2	2	4	4	200 ton	C to B
	Truck Trailer Fifth Wheel	1	Support truck trailers inside process building	4	4	8	8	1 Truck Trailer	B
3.4.3.6	Mobile Crane	3	Install impact limiters and cask tie-downs	2	2	2	2	40 ton	B
	Truck Trailer Fifth Wheel	1	Support truck trailers inside process building	4	4	8	8	1 Truck Trailer	B
3.4.4	Car Puller	2	Move vehicles and casks inside process building	3	3	6	6	10,000 lb	A,B
	Onsite Drive Unit	60	Move cask and vehicle to cask holding area	2	2	2	2	8 Railcars	Around Process Buildings A and B

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module						Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D	M3E	M3F		
3.5	Lag Storage Covers	12	Removed and replaced for waste insertion and removal	2	10	20	20	--			F
	Transfer Cell Bridge Crane	64	Remove and replace lag storage covers, move wastes in and out of storage	2	2	0	0	35 ton			F
	Process Cell Bridge Crane	11	Remove and replace lag storage covers, move wastes in and out of storage	0	0	4	4	20 ton			F
3.6.1	Lag Storage Covers	12	Remove and replace for SFA removal	2	10	20	20	--			F
	Process Cell Bridge Crane	11	Move SFAs to disassembly station	0	0	0	4	20 ton			F
	Disassembly Station	13	Receive SFAs for disassembly	0	0	0	4	(c)			F
3.6.2.1	Disassembly Station	13	Disassemble SFAs	0	0	0	4	(c)			F
	Consolidation Station	14	Consolidate fuel rods	0	0	0	4	(c)			F
3.6.2.2	Volume Reduction Station	17	Shred non-fuel bearing materials from SFAs	0	0	0	4	--			F
3.6.2.3	Clean Drum Supply System	18	Move clean drums into decontamination cell	0	0	0	2	1 Drum			I
	Drum Transport Equipment	19	Move clean drums to drum loading station	0	0	0	4	1 Drum			I to F
	Drum Loading Station	20	Load shredded materials into drums	0	0	0	4	1 Drum			F
	Drum Lidding Equipment	21	Place lids on drums	0	0	0	4	1 Drum			F
3.6.2.4	Drum Transport Equipment	19	Move loaded drums to decontamination cell	0	0	0	4	1 Drum			F to I
	Jib Crane	22	Move drums to decontamination station	0	0	0	2	1.5 ton			I
	Jib Crane	23	Decontamination cell operations	0	0	0	2	0.75 ton			I
	Decontamination Station	24	Decontamination drums	0	0	0	2	1 Drum			I

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module				Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D		
3.6.2.5	Undefined Equipment for Processing Non-Standard Wastes	28	Process waste	0	0	4	4	--	F
	Wall-Mounted Manipulator	35	Support operations	0	0	4	4	--	F
	Process Cell Bridge Crane	11	Support operations	0	0	4	4	--	F
3.6.3.1	Wall Manipulator	15	Equipment operation and maintenance	0	0	4	4	TBD	F
	Process Cell Wall Crane	16	Equipment operation and maintenance	0	0	4	4	1.5 ton	F
	Fuel Assembly Upender	36	Move SFAs and other wastes into canyon cell	0	0	4	4	1 SFA	F
	Clean Canister Supply System	37	Move clean canisters into canyon cells	0	0	0	1	1 Canister	J
	Canister Pass-Through Cart	38	Move canisters between canyon cells	0	0	0	1	1 Canister	J
	Canister Upender	39	Support canisters during filling	0	0	0	2	1 Canister	J
3.6.4.1	Canister Upender	39	Move filled canister to weld station	0	0	0	2	1 Canister	J
	Canister Lid Supply System	40	Move lids into canyon cells	0	0	0	3	1 Lid	J
	Weld Station	41	Install lids, helium test welds	0	0	0	3	1 Canister	J
3.6.4.2	Canister Lid Supply System	40	Move lids into canyon cells	0	0	0	3	1 Lid	J
	Weld Station	41	Decontaminate canister, install lids	0	0	0	3	1 Canister	J
	Ultrasonic Test Station	42	Test canister weld	0	0	0	3	1 Canister	J

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module					Size or Capacity		Locations (b)
				M3A	M3B	M3C	M3D	M3E			
3.6.4.2	Canister Cutting Station	43	Cut lids off defective canisters	0	0	0	3		1 Canister		J
	Canister Upender	39	Move canisters between process stations	0	0	0	2		1 Canister		J
3.6.3.2	Wall Manipulator	15	Equipment operation and maintenance	0	0	4	4		TBD		F
	Process Cell Wall Crane	16	Equipment operation and maintenance	0	0	4	4		1.5 ton		F
3.6.4.3	Fuel Assembly Upender	36	Move SFAs and other wastes into canyon cell	0	0	4	4		1 SFA		F
	Container Supply System	29	Move clean containers into canyon cells	0	0	1	1		1 Container		J
3.6.4.4	Container Pass-Through Cart	56	Move containers between canyon cells	0	0	1	1		1 Container		J
	Container Upender	34	Support containers during filling	0	0	2	2		1 Container		J
3.6.4.3	Container Upender	34	Move filled container to weld station	0	0	2	2		1 Container		J
	Container Lid Supply System	57	Move lids into canyon cells	0	0	3	3		1 Lid		J
3.6.4.4	Container Weld Station	30	Install lids, helium test welds	0	0	3	3		1 Container		J
	Container Weld Station	30	Decontaminate container, install lids	0	0	3	3		1 Container		J
3.6.4.4	Container Ultrasonic Test Station	32	Test container welds	0	0	3	3		1 Container		J
	Container Cutting Station	33	Cut lids off defective containers	0	0	3	3		1 Container		J
3.7.1	Container Upender	34	Move containers between process stations	0	0	2	2		1 Container		J
	Container Lid Supply System	57	Move lids into canyon cells	0	0	3	3		1 Lid		J
3.7.1	Canyon Cell Bridge Crane	27	Move canisters or containers to process lag storage or to casks	0	0	4	4		35 ton		J

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module				Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D		
3.7.1	Process Lag Storage Covers	59	Remove and replace to permit movement of wastes in and out of storage	Variable (f)				--	J
3.7.2	Canyon Cell Bridge Crane	27	Move canisters and containers to outgoing lag storage or to casks	0	0	4	4	35 ton	J
	Canyon Cell Outgoing Lag Storage Covers	44	Remove and replace to permit movement of wastes in and out of storage	Variable (f)				--	J
3.8.1.1	Cask Service Platform	46	Support personnel working on cask	1	2	2	2	1 Cask	H
	Monorail Hoist	47	Remove cask outer lid	1	2	2	2	3 ton	H
	SCC Transporter (d)	45	Move SSC to loadout area	4	4	4	4	600 ton	H to G
	TC Transporter (e)	49	Move transfer cask to loadout area	4	4	4	4	30 ton	H to G
	Tracked Transporter (f)	58	Move transfer cask to loadout area	3	3	3	3	30 ton	H to G
	Cask Contamination Barrier	48	Connect cask to transfer cell port	1	2	2	2	1 Cask	G
3.8.1.2	Transfer or Canyon Cell Exit Port Plug	55	Removed from port	1	2	2	2	1 Port	F or J
	Transfer Cell Bridge Crane	64	Remove exit port plug, remove cask shield plug	2	2	0	0	35 ton	F
	Canyon Cell Bridge Crane	27	Remove exit port plug, remove cask shield plug	0	0	4	4	35 ton	J
3.8.2	Lag Storage Covers	12	Removed and replaced to permit movement of wastes in and out of storage	2	10	20	20	--	F or J
	Transfer Cell Bridge Crane	64	Remove and replace lag storage covers, load wastes into cask	2	2	0	0	35 ton	F
	Canyon Cell Bridge Crane	27	Remove and replace lag storage covers, load wastes into cask	0	0	4	4	35 ton	J

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module				Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D		
3.8.3.1	Transfer Cell Bridge Crane	64	Replace cask shield plug, replace exit port plug	2	2	0	0	35 ton	F
	Canyon Cell Bridge Crane	27	Replace cask shield plug, replace exit port plug	0	0	4	4	35 ton	J
	Transfer or Canyon Cell Exit Port Plug	55	Replaced in port	2	2	4	4	1 port	F or J
3.8.3.2	Cask Contamination Barrier	48	Disconnected from cask	1	2	2	2	1 Cask	G
	SSC Transporter (d)	45	Move SSC to transfer/discharge corridor	4	4	4	4	600 ton	G to H
	TC Transporter (e)	49	Move transfer cask to transfer/discharge corridor	4	4	4	4	30 ton	G to H
	Tracked Transporter (f)	58	Move transfer cask to transfer/discharge corridor	3	3	3	3	30 ton	G to H
3.8.3.3	Cask Service Platform	46	Support personnel working on cask	1	2	2	2	1 Cask	H
	Cask Service Platform	46	Support personnel working on cask	1	2	2	2	1 Cask	H
	Monorail Hoist	47	Install lid on cask	1	2	2	2	3 ton	H
3.8.3.4	Welding Equipment	50	Weld outer lid on cask	1	2	2	2	1 Cask Lid	H
	Cask Service Platform	46	Support personnel working on cask	1	2	2	2	1 Cask	H
	Cask Service Platform	46	Support personnel working on cask	1	2	2	2	1 Cask	H
3.8.4.1	Cask Service Platform	46	Support personnel working on cask	1	2	2	2	1 Cask	H
	Grinding Equipment	51	Grind off lid welds on SSCs	1	2	2	2	1 Cask Lid	H
	Monorail Hoist	47	Remove cask outer lid	1	2	2	2	3 ton	H
	SSC Transporter (d)	45	Move SSC to loadout area	4	4	4	4	600 ton	H to G
	TC Transporter (e)	49	Move transfer cask to loadout area	4	4	4	4	30 ton	H to G

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module						Size or Capacity	Locations (b)
				MSA	MSB	MSC	MSD	MSD	MSD		
3.8.4.1	Tracked Transporter ^(f)	58	Move transfer cask to loadout area	3	3	3	3	3	3	30 ton	H to G
	Cask Contamination Barrier	48	Connect cask to cell port	1	2	2	2	2	2	1 Cask	G
3.8.4.2	Transfer or Canyon Cell Exit Port Plug	55	Removed from port	1	2	2	2	2	2	1 Port	F or J
	Transfer Cell Bridge Crane	64	Remove exit port plug, remove cask plug	2	2	0	0	0	0	35 ton	F
	Canyon Cell Bridge Crane	27	Remove exit port plug, remove cask plug	0	0	4	4	4	4	35 ton	J
3.8.5	Transfer Cell Bridge Crane	64	Remove wastes from cask, remove and replace lag storage covers	2	2	0	0	0	0	35 ton	F
	Canyon Cell Bridge Crane	27	Remove wastes from cask, remove and replace lag storage covers	0	0	4	4	4	4	35 ton	J
	Lag Storage Covers	12	Removed and replaced to permit movement of wastes into storage	2	10	20	20	20	20	--	F or J
3.8.6.1	Transfer Cell Bridge Crane	64	Replace cask shield plug, replace exit port plug, inspect cask interior	2	2	0	0	0	0	35 ton	F
	Canyon Cell Bridge Crane	27	Replace cask shield plug, replace exit port plug, inspect cask interior	0	0	4	4	4	4	35 ton	J
	Transfer or Canyon Cell Exit Port Plug	55	Replaced in port	1	2	4	4	4	4	1 Port	F
3.8.6.2	Cask Contamination Barrier	48	Disconnected from cask	1	2	2	2	2	2	1 Cask	G
	SSC Transporter ^(d)	45	Move cask to discharge corridor	4	4	4	4	4	4	600 ton	G to H
	TC Transporter ^(e)	49	Move cask to discharge corridor	4	4	4	4	4	4	30 ton	G to H
	Tracked Transporter ^(f)	58	Move cask to discharge corridor	3	3	3	3	3	3	30 ton	G to H

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module					Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D	M3E		
3.8.6.2	Cask Service Platform	46	Support personnel working on cask	1	2	2	2	2	1 Cask	H
	Monorail Hoist	47	Replace cask outer lid	1	2	2	2	2	3 ton	H
3.9.1.1	Onsite Drive Unit	60	Move cask and vehicle to washdown area	2	2	2	2	2	8 Railcars	Around Process Building and A
3.9.1.2	Car Puller	2	Move vehicles and casks inside process building	3	3	6	6	6	10,000 lb	B
	Mobile Crane	3	Remove impact limiters and cask tie-downs	2	2	2	2	2	40 ton	B
3.9.1.3	Bridge Crane	4	Move casks from vehicles to cask cart	2	2	4	4	4	200 ton	B to C
	Cask Cart	5	Move cask from shipping dock to cask preparation or lidding room	3	6	10	10	10	200 ton	C to D or K
3.9.1.4	Monorail Hoist	7	Remove cask outer lid and install contamination barrier adaptor	3	4	6	6	6	5 ton	D or K
	Cask Service Platform	6	Support personnel working on cask	3	6	10	10	10	--	D or K
	Cask Contamination Barrier Adaptor	8	Installed on cask	7	19	38	38	38	1 cask	D or K
	Cask Cart	5	Move cask to unloading room	3	6	10	10	10	200 ton	D to E or K
	Cask Contamination Barrier	9	Connect cask to cell port	2	6	10	10	10	1 Cask	E or K
3.9.1.5	Transfer Cell Bridge Crane	64	Remove input port plug, remove cask inner lid	2	2	0	0	0	35 ton	F
	Transfer, Canyon or Cell Input Port Plugs	10	Removed from ports	2	6	10	10	10	1 Port	F
	Canyon Cell Bridge Crane	27	Remove input port plug, remove cask inner lid	0	0	4	4	4	35 ton	J

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module					Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D	M3D		
3.9.2	Transfer Cell Bridge Crane	64	Place waste in transport cask. Remove and replace lag storage covers	2	2	0	0	35 ton		F
	Canyon Cell Bridge Crane	27	Place waste in transport cask. Remove and replace lag storage covers	0	0	4	4	35 ton		J
	Lag Storage Covers	12	Removed and replaced to permit waste movements to cask	2	10	20	20	20 ton		F
	Process Lag Storage Covers	59	Removed and replaced to permit waste movements to cask	Variable (f)						J
3.9.3.1	Transfer Cell Bridge Crane	64	Inspect cask interior, install cask inner lid, install input and exit port plugs	2	2	0	0	35 ton		F
	Canyon Cell Bridge Crane	27	Inspect cask interior, install cask inner lid, install input and exit port plugs	0	0	4	4	35 ton		J
	Transfer or Canyon Cell Input Port Plugs	10	Replaced in ports	2	6	10	10	1 Port		F
3.9.3.2	Cask Contamination Barrier	9	Disconnected from cask	2	6	10	10	1 Cask		E or K
	Cask Cart	5	Move cask to preparation room	3	6	10	10	200 ton		K or E to D
	Cask Contamination Barrier Adapter	8	Removed from cask	7	19	38	38	1 Cask		D or K
	Cask Service Platform	6	Support personnel working on cask	3	6	10	10	--		D or K
	Monorail Hoist	7	Install cask outer lid	3	4	6	6	5 ton		D or K
3.9.3.3	Cask Cart	5	Move cask to shipping dock	3	6	10	10	200 ton		K or D to C
	Bridge Crane	4	Load cask onto railcar	2	2	4	4	200 ton		C to B
3.9.3.4	Mobile Crane	3	Install impact limiters and cask tie-downs	2	2	2	2	40 ton		B

TABLE 4.22. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units for Each Module						Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D	M3E	M3F		
3.9.4	Car Puller	2	Move vehicles and casks inside process building	3	3	6	6			10,000 lb	A, B
	Onsite Drive Unit	60	Move cask and vehicle to cask holding area	2	2	2	2			8 Railcars	Around Process Building A and B

(a) Equipment identification included as an aid to equipment cost and utilization studies.

(b) Locations for the items with letters are on Figures 4.22, 4.23, 4.27, 4.28, 4.34, 4.35, 4.44 and 4.45 as appropriate. See Figure 4.21 for general location of process buildings.

(c) Capacity or size depends on types of SFAs and packages being handled and the scenario being evaluated (which determines the designs of the bundles of fuel rods and packages being handled).

(d) Optional equipment needed only for SSC storage.

(e) Optional equipment needed only for drywell storage.

(f) Optional equipment needed only for vault storage.

TABLE 4.23. Major Waste Handling Equipment at the TF, SFHB, and RHB - Listed by Equipment Item(a)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units for Each Module				Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D		
Truck Trailer Fifth Wheel	1	3.4.1.2	Support truck trailers inside process building	4	4	8	8	1 Truck Trailer	A, B
		3.4.1.3	Support truck trailers inside process building	4	4	8	8	1 Truck Trailer	B
		3.4.3.5	Support truck trailers inside process building	4	4	8	8	1 Truck Trailer	B
		3.4.3.6	Support truck trailers inside process building	4	4	8	8	1 Truck Trailer	B
Car Puller	2	3.4.1.2	Move vehicles and casks inside process building	3	3	6	6	10,000 lb	A, B
		3.4.4	Move vehicles and casks inside process building	3	3	6	6	10,000 lb	A, B
		3.9.1.2	Move vehicles and casks inside process building	3	3	6	6	10,000 lb	B
		3.9.4	Move vehicles and casks inside process building	3	3	6	6	10,000 lb	A, B
Mobile Crane	3	3.4.1.2	Remove impact limiters and cask tiedowns	2	2	2	2	40 ton	B
		3.4.3.6	Install impact limiters and cask tiedowns	2	2	2	2	40 ton	B
		3.9.1.2	Remove impact limiters and cask tiedowns	2	2	2	2	40 ton	B
		3.9.3.4	Install impact limiters and cask tiedowns	2	2	2	2	40 ton	B
Bridge Crane	4	3.4.1.3	Move casks from vehicles to cask cart	2	2	4	4	200 ton	B to C
		3.4.3.5	Move cask to vehicle	2	2	4	4	200 ton	C to B
		3.9.1.3	Move casks from vehicles to cask cart	2	2	4	4	200 ton	B to C
		3.9.3.3	Load cask onto railcar	2	2	4	4	200 ton	C to B
Cask Cart	5	3.4.1.2	Move casks from shipping dock to cask preparation room	3	6	10	10	200 Ton	C to D
		3.4.1.6	Move cask to unloading room	3	6	10	10	200 ton	D to E

TABLE 4.23. (contd)

Equipment Title	Equipment (b) Identification	Function Reference Number	Function/Activity	Number of Units for Each Module				Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D		
Cask Cart	5	3.4.3.3	Move cask to preparation room	3	6	10	10	200 ton	E to D
		3.4.3.5	Move cask to shipping dock	3	6	10	10	200 ton	D to C
		3.9.1.3	Move cask from shipping dock to cask preparation or lidding room	3	6	10	10	200 ton	C to D or K
		3.9.1.4	Move cask to unloading room	3	6	10	10	200 ton	D to E or K
		3.9.3.2	Move cask to preparation room	3	6	10	10	200 ton	K or E to D
Cask Service Platform	6	3.9.3.3	Move cask to shipping dock	3	6	10	10	200 ton	K or D to C
		3.4.1.4	Support personnel working on cask	3	6	10	10	--	D
		3.4.1.5	Support personnel working on cask	3	6	10	10	--	D
		3.4.3.3	Support personnel working on cask	3	6	10	10	--	D
		3.9.1.4	Support personnel working on cask	3	6	10	10	--	D or K
Monorail Hoist	7	3.9.3.2	Support personnel working on cask	3	6	10	10	--	D or K
		3.4.1.4	Remove cask outer lid	3	4	6	6	5 ton	D
		3.4.1.5	Install contamination barrier adaptor	3	4	6	6	5 ton	D
		3.4.3.3	Remove contamination barrier adaptor	3	4	6	6	5 ton	D
		3.4.3.4	Install cask outer lid	3	4	6	6	5 ton	D
Cask Contamination Barrier Adaptor	8	3.9.1.4	Remove cask outer lid and install contamination barrier adaptor	3	4	6	6	5 ton	D or K
		3.9.3.2	Install cask outer lid	3	4	6	6	5 ton	D or K
		3.4.1.5	Provide connection between cask top and cell port	7	19	38	38	1 Cask	D
		3.4.3.3	Removed from cask	7	19	38	38	1 Cask	D
		3.9.1.4	Installed on cask	7	19	38	38	1 cask	D or K
3.9.3.2	Removed from cask	7	19	38	38	1 Cask	D or K		

TABLE 4.23. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units for Each Module					Size or Capacity		Locations (b)
				M3A	M3B	M3C	M3D				
Cask Contamination Barrier	9	3.4.1.6	Provide connection between cask top and cell port	2	6	10	10	1	Cask		E
		3.4.3.2	Disconnected from cask	2	6	10	10	1	Cask		E
		3.9.1.4	Connect cask to cell port	2	6	10	10	1	Cask		E or K
		3.9.3.2	Disconnected from cask	2	6	10	10	1	Cask		E or K
		3.4.1.7	Removed from port	2	6	10	10	1	Port		F
Transfer, Canyon or Process Cell Input Port Plug	10										
		3.4.3.1	Replaced in port	2	6	10	10	1	Port		F
		3.9.1.5	Removed from ports	2	6	10	10	1	Port		F
		3.9.3.1	Replaced in ports	2	6	10	10	1	Port		F
		3.4.1.7	Remove input port plug, remove cask inner lid	0	0	4	4	20	ton		F
Process Cell Bridge Crane	11										
		3.4.2	Remove lag storage cover, transfer wastes from cask to lag storage or process, replace lag storage cover	0	0	4	4	20	ton		F
		3.4.3.1	Inspect cask interior, replace cask inner lid, replace cell input port plug	0	0	4	4	20	ton		F
		3.5	Remove and replace lag storage covers, move wastes in and out of storage	0	0	4	4	20	ton		F
		3.6.1	Move SFAs to disassembly station	0	0	4	4	20	ton		F
Lag Storage Covers	12	3.6.2.5	Support operations	0	0	4	4	--			F
		3.4.2	Removed and replaced for waste movement into lag storage	2	10	20	20	--			F
		3.5	Removed and replaced for waste insertion and removal	2	10	20	20	--			F
		3.6.1	Remove and replace for SFA removal	2	10	20	20	--			F
		3.8.2	Removed and replaced to permit movement of wastes in and out of storage	2	10	20	20	--			F or J

TABLE 4.23. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units for Each Module							Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D	2	10	20	20	F or J
Lag Storage Covers	12	3.8.5	Removed and replaced to permit movement of wastes into storage					2			--	F or J
		3.9.2	Removed and replaced to permit waste movements to cask					2	10	20	20 ton	F
Disassembly Station	13	3.6.1	Receive SFAs for disassembly					0	0	0	4 (c)	F
		3.6.2.1	Disassemble SFAs					0	0	0	4 (c)	F
Consolidation Station	14	3.6.2.1	Consolidate fuel rods					0	0	0	4 (c)	F
Wall Manipulator	15	3.6.3.1	Equipment operation and maintenance					0	0	4	TBD	F
		3.6.3.2	Equipment operation and maintenance					0	0	4	TBD	F
Process Cell Wall Crane	16	3.6.3.1	Equipment operation and maintenance					0	0	4	4 1.5 ton	F
		3.6.3.2	Equipment operation and maintenance					0	0	4	4 1.5 ton	F
Volume Reduction Station	17	3.6.2.2	Shred non-fuel bearing materials from SFAs					0	0	0	4 --	F
Clean Drum Supply System	18	3.6.2.3	Move clean drums into decontamination cell					0	0	0	2 1 Drum	I
Drum Transport Equipment	19	3.6.2.3	Move clean drums to drum loading station					0	0	0	4 1 Drum	I to F
		3.6.2.4	Move loaded drums to decontamination cell					0	0	0	4 1 Drum	F to I
Drum Loading Station	20	3.6.2.3	Load shredded materials into drums					0	0	0	4 1 Drum	F
Drum Lidding Equipment	21	3.6.2.3	Place lids on drums					0	0	0	4 1 Drum	F
Jib Crane	22	3.6.2.4	Move drums to decontamination station					0	0	0	2 1.5 ton	I
Jib Crane	23	3.6.2.4	Decontamination cell operations					0	0	0	2 0.75 ton	I
Decontamination Station	24	3.6.2.4	Decontamination drums					0	0	0	2 1 Drum	I
Canyon Cell Bridge Crane	27	3.7.1	Move canisters or containers to process lag storage or to casks					0	0	4	4 35 ton	J
		3.7.2	Move canisters and containers to outgoing lag storage or to casks					0	0	4	4 35 ton	J
		3.8.1.2	Remove exit port plug, remove cask shield plug					0	0	4	4 35 ton	J

TABLE 4.23. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units for Each Module					Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D			
Canyon Cell Bridge Crane	27	3.8.2	Remove and replace lag storage covers, load wastes into cask	0	0	4	4	35 ton	J	
		3.8.3.1	Replace cask shield plug, replace exit port plug	0	0	4	4	35 ton	J	
		3.8.4.2	Remove exit port plug, remove cask plug	0	0	4	4	35 ton	J	
		3.8.5	Remove wastes from cask, remove and replace lag storage covers	0	0	4	4	35 ton	J	
		3.8.6.1	Replace cask shield plug, replace exit port plug, inspect cask interior	0	0	4	4	35 ton	J	
		3.9.1.5	Remove input port plug, remove cask inner lid	0	0	4	4	35 ton	J	
		3.9.2	Place waste in transport cask, remove and replace lag storage covers	0	0	4	4	35 ton	J	
		3.9.3.1	Inspect cask interior, install cask inner lid, install input and exit port plugs	0	0	4	4	35 ton	J	
Undefined Equipment for Processing Non-Standard Wastes	28	3.6.2.5	Process waste	0	0	4	4	--	F	
Container Supply System	29	3.6.3.2	Move clean containers into canyon cells	0	0	1	1	1 Container	J	
Container Weld Station	30	3.6.4.3	Install lids, helium test welds	0	0	3	3	1 Container	J	
		3.6.4.3	Decontaminate container, install lids	0	0	3	3	1 Container	J	
Container Ultrasonic Test Station	32	3.6.4.4	Test container welds	0	0	3	3	1 Container	J	
Container Cutting Station	33	3.6.4.4	Cut lids off defective containers	0	0	3	3	1 Container	J	
Container Upender	34	3.6.3.2	Support containers during filling	0	0	2	2	1 Container	J	
		3.6.4.3	Move filled container to weld station	0	0	2	2	1 Container	J	
		3.6.4.4	Move containers between process stations	0	0	2	2	1 Container	J	
Wall-Mounted Manipulator	35	3.6.2.5	Support operations	0	0	4	4	--	F	

TABLE 4.23. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units for Each Module				Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D		
Fuel Assembly Upender	36	3.6.3.1	Move SFAs and other wastes into canyon cell	0	0	4	4	1 SFA	F
		3.6.3.2	Move SFAs and other wastes into canyon cell	0	0	4	4	1 SFA	F
Clean Canister Supply System	37	3.6.3.1	Move clean canisters into canyon cells	0	0	0	1	1 Canister	J
Canister Pass-Through Cart	38	3.6.3.1	Move canisters between canyon cells	0	0	0	1	1 Canister	J
Canister Upender	39	3.6.3.1	Support canisters during filling	0	0	0	2	1 Canister	J
		3.6.4.1	Move filled canister to weld station	0	0	0	2	1 Canister	J
Canister Upender	39	3.6.4.2	Move canisters between process stations	0	0	0	2	1 Canister	J
Canister Lid Supply System	40	3.6.4.1	Move lids into canyon cells	0	0	0	3	1 Lid	J
		3.6.4.2	Move lids into canyon cells	0	0	0	3	1 Lid	J
Weld Station	41	3.6.4.1	Install lids, helium test welds	0	0	0	3	1 Canister	J
		3.6.4.2	Decontaminate canister, install lids	0	0	0	3	1 Canister	J
Ultrasonic Test Station	42	3.6.4.2	Test canister weld	0	0	0	3	1 Canister	J
Canister Cutting Station	43	3.6.4.2	Cut lids off defective canisters	0	0	0	3	1 Canister	J
Canyon Cell Outgoing Lag Storage Covers	44	3.7.2	Remove and replace to permit movement of wastes in and out of storage	Variable (f)				--	J
SCC Transporter (d)	45	3.8.1.1	Move SSC to loadout area	4	4	4	4	600 ton	H to G
		3.8.3.2	Move SSC to transfer/discharge corridor	4	4	4	4	600 ton	G to H
		3.8.4.1	Move SSC to loadout area	4	4	4	4	600 ton	H to G
		3.8.6.2	Move cask to discharge corridor	4	4	4	4	600 ton	G to H
Cask Service Platform	46	3.8.1.1	Support personnel working on cask	1	2	2	2	1 Cask	H
		3.8.3.2	Support personnel working on cask	1	2	2	2	1 Cask	
		3.8.3.3	Support personnel working on cask	1	2	2	2	1 Cask	H
		3.8.3.4	Support personnel working on cask	1	2	2	2	1 Cask	H
		3.8.4.1	Support personnel working on cask	1	2	2	2	1 Cask	H

TABLE 4.23. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units for Each Module				Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D		
Cask Service Platform	46	3.8.6.2	Support personnel working on cask	1	2	2	2	1 Cask	H
Monorail Hoist	47	3.8.1.1	Remove cask outer lid	1	2	2	2	3 ton	H
		3.8.3.3	Install lid on cask	1	2	2	2	3 ton	H
		3.8.4.1	Remove cask outer lid	1	2	2	2	3 ton	H
		3.8.6.2	Replace cask outer lid	1	2	2	2	3 ton	H
		3.8.1.1	Connect cask to transfer cell port	1	2	2	2	1 Cask	G
Cask Contamination Barrier	48	3.8.3.2	Disconnected from cask	1	2	2	2	1 Cask	G
		3.8.4.1	Connect cask to cell port	1	2	2	2	1 Cask	G
		3.8.6.2	Disconnected from cask	1	2	2	2	1 Cask	G
		3.8.1.1	Move transfer cask to loadout area	4	4	4	4	30 ton	H to G
TC Transporter(e)	49	3.8.3.2	Move transfer cask to transfer/discharge corridor	4	4	4	4	30 ton	G to H
		3.8.4.1	Move transfer cask to loadout area	4	4	4	4	30 ton	H to G
		3.8.6.2	Move cask to discharge corridor	4	4	4	4	30 ton	G to H
		3.8.3.4	Weld outer lid on cask	1	2	2	2	1 Cask Lid	H
Welding Equipment	50	3.8.4.1	Grind off lid welds on SSCs	1	2	2	2	1 Cask Lid	H
Grinding Equipment	51	3.8.1.2	Removed from port	1	2	2	2	1 Port	F or J
Transfer or Canyon Cell Exit Port Plug	55	3.8.3.1	Replaced in port	2	2	4	4	1 port	F or J
		3.8.4.2	Removed from port	1	2	2	2	1 Port	F or J
		3.8.6.1	Replaced in port	1	2	4	4	1 Port	F
		3.6.3.2	Move containers between canyon cells	0	0	1	1	1 Container	J
Container Pass-Through Cart	56	3.6.4.3	Move lids into canyon cells	0	0	3	3	1 Lid	J
Container Lid Supply System	57	3.6.4.4	Move lids into canyon cells	0	0	3	3	1 Lid	J

TABLE 4.23. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units for Each Module						Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D	M3D	M3D		
Tracked Transporter (f)	58	3.8.1.1	Move transfer cask to loadout area	3	3	3	3	3	3	30 ton	H to G
		3.8.3.2	Move transfer cask to transfer/discharge corridor	3	3	3	3	3	3	30 ton	G to H
		3.8.4.1	Move transfer cask to loadout area	3	3	3	3	3	3	30 ton	H to G
		3.8.6.2	Move cask to discharge corridor	3	3	3	3	3	3	30 ton	G to H
Process Lag Storage Covers	59	3.7.1	Remove and replace to permit movement of wastes in and out of storage	Variable (f)						--	J
		3.9.2	Removed and replaced to permit waste movements to cask	Variable (f)						--	J
Onsite Drive Unit	60	3.1.1	Connect to transport vehicle	2	2	2	2	2	2	8 Railcars	Around Process Building
		3.1.2	Connect to transport vehicle	2	2	2	2	2	2	8 Railcars	Around Process Building
		3.2.1	Move cask and vehicle to cask holding area	2	2	2	2	2	2	8 Railcars	Around Process Building
		3.2.1	Move cask and vehicle to support services facility								Around Process Building
		3.2.2	Move cask and vehicle to cask holding area	2	2	2	2	2	2	8 Railcars	Around Process Building
		3.2.2	Move cask and vehicle during makeup of shipments								Around Process Building
		3.3.1	Move cask and vehicles during inspections, repairs and train makeup	2	2	2	2	2	2	8 Railcars	Around Process Building
		3.3.2	Move cask and vehicle during inspections, repairs and train makeup	2	2	2	2	2	2	8 Railcars	Around Process Building
		3.4.1.1	Move cask and vehicle to washdown area or to support services facility	2	2	2	2	2	2	8 Railcars	Around Process Building and A
		3.4.4	Move cask and vehicle to cask holding area	2	2	2	2	2	2	8 Railcars	Around Process Buildings A and B

TABLE 4.23. (contd)

Equipment Title	Equipment (b) Identification	Function Reference Number	Function/Activity	Number of Units for Each Module						Size or Capacity	Locations (b)
				M3A	M3B	M3C	M3D	M3E	M3F		
Onsite Drive Unit	60	3.9.1.1	Move cask and vehicle to washdown area	2	2	2	2	2	2	8 Railcars	Around Process Building and A
		3.9.4	Move cask and vehicle to cask holding area	2	2	2	2	2	2	8 Railcars	Around Process Building A and B
Transfer Cell Bridge Crane	64	3.4.1.7	Remove input port plug, remove cask inner lid	2	2	0	0	0	0	35 Ton	F
		3.4.2	Remove lag storage cover, transfer wastes from cask to lag storage, storage cask, or transport cask, replace lag storage cover	2	2	0	0	0	0	20 ton	F
		3.4.3.1	Inspect cask interior, replace cask inner lid, replace cell input port plug	2	2	0	0	0	0	35 ton	F
		3.5	Remove and replace lag storage covers, move wastes in and out of storage	2	2	0	0	0	0	35 ton	F
		3.8.1.2	Remove exit port plug, remove cask shield plug	2	2	0	0	0	0	35 ton	F
		3.8.2	Remove and replace lag storage covers, load wastes into cask	2	2	0	0	0	0	35 ton	F
		3.8.3.1	Replace cask shield plug, replace exit port plug	2	2	0	0	0	0	35 ton	F
		3.8.5	Remove wastes from cask, remove and replace lag storage covers	2	2	0	0	0	0	35 ton	F
		3.8.6.1	Replace cask shield plug, replace exit port plug, inspect cask interior	2	2	0	0	0	0	35 ton	F
		3.8.4.2	Remove exit port plug, remove cask plug	2	2	0	0	0	0	35 ton	F
		3.9.1.5	Remove input port plug, remove cask inner lid	2	2	0	0	0	0	35 ton	F

TABLE 4.23. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units for Each Module					Size of Capacity	Locations (b)
				M3A	M3B	M3C	M3D	M3E		
Transfer Cell Bridge Crane	64	3.9.2	Place waste in transport cask, remove and replace leg storage covers	2	2	0	0	0	35 ton	F
		3.9.3.1	Inspect cask interior, install cask inner lid, install input and exit port plugs	2	2	0	0	0	35 ton	F

(a) Equipment identification included as an aid to equipment cost and utilization studies.

(b) Locations for the items with letters are on Figures 4.22, 4.23, 4.27, 4.28, 4.34, 4.35, 4.44 and 4.45 as appropriate. See Figure 4.21 for general location of process buildings.

(c) Capacity or size depends on types of SFAs and packages being handled and the scenario being evaluated (which determines the designs of the bundles of fuel rods and packages being handled).

(d) Optional equipment needed only for SSC storage.

(e) Optional equipment needed only for drywell storage.

(f) Optional equipment needed only for vault storage.

59002095.1

NOTE: Letters and numbers relate facility locations to descriptions in text.

NUMBERS: Numbers in circles identify locations of functions.

Letters in squares identify waste processing areas listed in Table 4.24.

Letters in diamonds identify building support facilities listed in Table 4.25.

FIGURE 4.27. First-Level Plan for the SFHB

Table 4.24 lists the approximate process area internal dimensions and location keys that indicate where (on Figures 4.27 to 4.29) the various functions are located in the SFHB.

The arrangements and functions of the two parallel transfer cells are essentially identical except for differences in the capacity of the lag storages and the substitution of a maintenance hatch for one lag storage module in one cell.

S9002095.5

NOTE: Letters and numbers relate facility locations to descriptions in text.

NUMBERS: Numbers in circles identify locations of functions.

Letters in squares identify waste processing areas listed in Table 4.24.

Letters in diamonds identify building support facilities listed in Table 4.25.

FIGURE 4.28. Second-Level Plan for the SFHB

The SFHB support facilities are shown in Figures 4.27 to 4.29. The SFHB contains numerous support facilities necessary for safe and efficient performance of its operations. The primary support facilities, their functions and location keys for locating these facilities (in Figures 4.27 to 4.29) are listed in Table 4.25.

Function 3.1 - Transport Cask Receipt. The casks are received at the inspection gatehouse. They travel from the gatehouse on facility roads and railroad tracks to either a lag storage holding area or the SFHB.

SD002095.12

NOTE: Letters and numbers relate facility locations to descriptions in text.

NUMBERS: Numbers in circles identify locations of functions.

Letters in squares identify waste processing areas listed in Table 4.24.

Letters in diamonds identify building support facilities listed in Table 4.25.

FIGURE 4.29. Third-Level Plan for the SFHB

Function 3.2 - Transport Cask Lag Storage. The cask and vehicle holding areas are truck parking areas for trucks and railroad car spurs for railroad cars. All are located inside the MRS protected area to assure proper security surveillance.

Function 3.3 - Cask Preshipment Inspection and Servicing. These activities occur in the cask and vehicle holding areas described above for Function 3.2.

TABLE 4.24. SFHB Process Area Dimensions

Process Room	Approximate Dimension (feet)			Location Symbol (a)
	Length	Width	Height	
Air-Control Vestibules	110(b)	59	34	A
Receiving, Inspection and Shipping	238	53	66	B
Cask Unloading				
Loading/Unloading Platform	102	26	51	C
Cask Preparation	102	32	34	D
Cask Unloading	102	32	34	E
Transfer Cells	102	104	40	F
Cask Loadout and Decontamination	102	62	34	G
Transfer/Discharge Corridor	102	58	34	H

(a) Letter symbol indicates location (letter in square) in Figures 4.27 to 4.29.

(b) Length of each vestibule.

Function 3.4 - Transport Cask Unloading. The cask receiving facilities in the SFHB are illustrated in Figure 4.30, and the general location of these facilities in the SFHB is shown in Figure 4.27. The casks are received in the receiving, inspection, and shipping areas. These rooms have facilities and equipment for receiving trucks and railroad cars transporting loaded casks, unloading the casks from the transport vehicles, placing the casks on transfer carts, and reversing those processes (after the casks have been unloaded) for loading casks back onto the vehicles (i.e., moving the casks back to the vehicles, loading the casks on the vehicles, and then moving the vehicles out of the building).

These large unshielded rooms contain two railroad tracks, extending the full length of the rooms. Large doors at both ends permit entrance and exit of vehicles, and walls containing doors at approximately 140 feet from each end create air-control vestibules so that vehicles can enter and leave without compromising the controlled ventilation system. The vestibules at the end where the casks and vehicles enter the building contain washdown equipment and are used for inspection of the casks and vehicles after washing.

TABLE 4.25. SFHB Primary Process Support Facilities

Facility	Function	Location Key(a)	
		Building Level	Symbol
Administration	Management functions	1	F
Health Physics	Health physics offices, laboratories and ready rooms	1	G
Material Receiving	Material receiving docks and storage	1	H
Laundry	Laundry activities	1	I
Low-Level Waste	Low-level waste receipt, treatment and shipment	1	J
Electrical Facilities	Electrical switch gear and emergency backup equipment	1 Mezzanine	K
Operation Support	Equipment rooms, material handling and storage	All	L
Maintenance	Maintenance shops and storage	1	M
Control Room	Process control	2	N
Air Conditioning	Air purification, distribution and exhaust treatment	All	O

(a) Symbol indicates location (letter in diamond) in Figures 4.27 to 4.29.

FIGURE 4.30. Receiving, Inspection, and Shipping Area

Overhead bridge cranes have capacity for lifting the loaded transport casks and transporting them to cask carts on the loading/unloading platforms on the process sides of the receiving, inspection, and shipping areas.

The locations of the cask unloading facilities are shown in Figures 4.27 and 4.28, and the facilities are illustrated in Figure 4.31. Cask unloading occurs in the cask unloading areas and the transfer cells. The cask unloading areas have equipment for transporting the casks from the receiving, inspection, and shipping areas to a shielded cell under a transfer cell, preparing the casks for unloading, connecting the casks to the transfer cells, and reversing those processes to return the empty casks to the receiving, inspection, and shipping area. With the casks sitting in the unloading cells, the contents are lifted out of the cask through a port in the cell ceiling into the transfer cell by use of the cell bridge crane.

FIGURE 4.31. Cask Unloading Area

The cask unloading areas consist of six transport cask unloading/loading cells (one for each port in Figure 4.27) and associated cask preparation and decontamination rooms. Each unloading cell is connected by rail tracks supporting a cask cart to the associated preparation and decontamination room and to the loading/unloading platforms in the receiving, inspection, and shipping areas. Ventilation doors separate the receiving, inspection, and shipping areas from the preparation and decontamination rooms, and shield doors separate the preparation and decontamination rooms from the unloading cells. The preparation and decontamination rooms contain movable work platforms and jib cranes for personnel working on the cask tops. Each unloading cell contains a port in the ceiling that is connected to the cask tops for unloading operations.

There are two transfer cells at the SFHB. Each cell has three transport cask receiving ports in the floor, one of which is specifically designed to handle the large MRS transport cask. Each port connects the transfer cell to an unloading cell directly underneath. Each cell also includes a separate port for mating to the large MRS storage casks. An overhead crane in each cell lifts the wastes out of the casks and transports them inside the cell. These transfer cells are equipped to unload waste material from transport casks, place it in the cell lag storage, and load the wastes into storage casks and to also reverse these operations.

The routine cask preparation for shipment occurs in the unloading, preparation and receiving, inspection, and shipping areas described above and uses the same equipment as is used for cask receipt and unloading.

Function 3.5 - Waste Lag Storage. The waste lag storage is illustrated in Figure 4.31. Each transfer cell contains a lag storage facility, and the general locations are shown in Figure 4.28. The facilities are of modular construction with separate modules for PWR and BWR assemblies. The maximum number of assemblies that can be stored is equal to approximately 6 weeks of waste receipts. The facilities are served by the cell overhead cranes and by power masts attached to the cranes.

Function 3.8 - Interface to Long-Term Storage. The interface to long-term storage activities in the SFHB is illustrated in Figure 4.32. The location in the SFHB is shown in Figure 4.27. Each transfer cell is connected by a loading port in the floor to a storage cask loadout and decontamination room directly underneath. The loadout and decontamination room is designed for receiving storage casks on transporters, preparing those casks for loading or unloading, connecting the tops of those casks to ports in the transfer cell floor, disconnecting those casks from the ports, preparing the casks for storage, and then moving the casks and transporters out of the building. The loadout and decontamination room is large enough to accommodate a cask on a transporter underneath the loading port and also in another position, as shown in Figure 4.32 for removal and installation of the outer lid and for decontamination. The casks are transported to the storage facilities over the facility roads.

Function 3.9 - MRS Transport Cask Loading. Transport cask loading occurs at the SFHB in the same facilities as are described in Function 3.4 for cask unloading. The transport casks to be loaded are handled in the same manner as the casks that are unloaded except that wastes are placed in the casks, rather than removed, and the casks are inerted and more thoroughly inspected before shipment.

FIGURE 4.32. Sealed Storage Cask Loadout and Decontamination Room

Function 3.16 - Balance-of-Plant Operations and Support. These activities occur both in the process buildings and the many support buildings, as appropriate, for the most efficient performance of those activities.

4.3.2.2 Level 2 Physical Description (Module 3B)

The SFHB is currently scheduled to receive, transfer, and ship 3000 MTU of wastes per year. It will operate 24 hours per day, 5 days per week for waste transfers. But shipments can be picked up or received on a 24-hour, 7-day-per-week schedule.

Table 4.26 contains general descriptions of the waste packages handled at the SFHB. All of these packages pass through the transfer cells and are placed in storage. They also pass back through the transfer cells when being removed from storage and are shipped to the repository.

The major process equipment needed for waste handling at the MRS facility is listed in Table 4.22. The equipment lists in this table are keyed to the functional description reference numbers. This table includes the equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information.

Table 4.23 provides a cross-referenced list of the information in Table 4.22 by equipment item that shows the number of functions for which each equipment item is used.

The SFHB will be decommissioned by demolition of all surface facilities, burial of all radioactive components in appropriate burial grounds, and restoration of the surface to near natural conditions.

TABLE 4.26. Descriptions of the Wastes Received at the SFHB

Generic Waste Form	Outer Canister or Container Symbol (d)	Cross Section		Typical Lengths (a)		Source	Contents (c)		Symbol (d)
		Geometry (e)	Dimension (b) (in.)	Outer Item (in.)	Contents (in.)		Waste		
PWR SFA	None	Square	<9	160 to 180	--	PWR	PWR SFA		SFA_P
BWR SFA	None	Square	<6	170 to 180	--	BWR	BWR SFA		SFA_B
At-Reactor PWR Canister	AR9_P	Square	~9	186	160 to 180	PWR	PWR SFA		SFA_P
					162	PWR	PWR Fuel Rods		CON_P
					180	PWR	PWR SFA Hardware		NFB_B
					180	PWR	PWR Misc. Wastes		GTC_P
At-Reactor BWR Canister	AR6_B	Square	~6	186	170 to 180	BWR	BWR SFA		SFA_B
					164	BWR	BWR Fuel Rods		CON_B
					180	BWR	BWR SFA Hardware		NFB_B
					180	BWR	BWR Misc. Wastes		GTC_B

(a) Lengths accommodate most wastes, canisters and containers. Other lengths needed for a few exceptions.

(b) Approximate dimensions. Canister and container dimensions are selected such that they can be nested.

(c) Wastes listed are the basic waste form inserted into the canister or container identified in column 2. The symbol identifies any canisters that were used to contain the waste prior to insertion into the canister or container identified in column 2. The symbol does not include the outer canister or container listed in the first two columns.

(d) See Appendix A for further explanation of symbols.

(e) See Figures 4.1 and 4.10 for square cross section.

4.3.3 Receiving and Handling Building Without Consolidation (Module 3C)

The primary purposes of the receiving and handling building (RHB) without consolidation module are to receive shipments of wastes in transport casks, unload the wastes from the casks, place those wastes in containers, place the containers of wastes in sealed storage casks or transfer casks, remove the containers of wastes from sealed storage casks or transfer casks, and place the containers of wastes in transport casks.

4.3.3.1 Level 1 Physical Description of RHB Without Consolidation (Module 3C)

Figure 4.33 presents a cutaway perspective view of one-half of a typical RHB. ^(a) Figures 4.34 to 4.36 present simplified floor plans for the RHB without consolidation. Location numbers and letters for facilities and functions that will be referred to later are shown on these figures. Numbers in circles identify locations of functions described in the functional descriptions. Letters in squares identify locations of waste processing areas listed in tables in these physical descriptions. Letters in diamonds identify locations of support facilities listed in tables in these physical descriptions.

The RHB is composed of two halves, with each half having equivalent capability and containing a complete set of process areas: a receiving, inspection, and shipping area, a cask unloading area, two process cells, a canyon cell, a storage cask loading and decon area, and a transport cask loading and discharge area. In addition to these basic process areas, rooms for supporting activities, storage space, and corridors are provided. Table 4.27 lists the approximate process area internal dimensions and location keys that indicate where (on Figures 4.34 to 4.36) the various functions are located in the RHB.

-
- (a) This is a general view of the RHB with consolidation equipment. If there is no consolidation, the consolidation equipment would not be installed and the process cells and support facilities would be smaller. However, the locations of all parts of the building would be essentially the same as shown in this figure.

FIGURE 4.33. Cutaway View of One-Half of Typical MRS RHB

The arrangement and functions of the two sides of the facility are identical except that one of the canyon cells designated for BWR spent fuel assembly processing (cell number 6) has the capability for welding and testing HLW containers or other miscellaneous similar containers. Containers requiring special handling that originate in canyon cell 5 can be transferred to canyon cell 6 for processing.

The RHB support facilities are shown in Figures 4.34 to 4.36. The R&H building contains numerous support facilities necessary for safe and efficient performance of its operations. The primary process support facilities, their functions, and location keys for locating these facilities in Figures 4.34 to 4.36 are listed in Table 4.28.

NOTE: Letters and numbers relate facility locations to descriptions in text.
 LEGEND: Numbers in circles identify locations of functions.
 Letters in squares identify waste processing areas listed in Table 4.27.
 Letters in diamonds identify building support facilities listed in Table 4.28.

FIGURE 4.34. Schematic First-Level Plan for the MRS RHB Without Consolidation

Function 3.1 - Transport Cask Receipt. The casks are received at the inspection gatehouse. They travel from the gatehouse on facility roads and railroad tracks to either a lag storage holding area or the RHB.

50101032.10

NOTE: Letters and numbers relate facility locations to descriptions in text.
 LEGEND: Numbers in circles identify locations of functions.
 Letters in squares identify waste processing areas listed in Table 4.27.
 Letters in diamonds identify building support facilities listed in Table 4.28.

FIGURE 4.35. Schematic Second-Level Plan for the MRS RHB Without Consolidation

Function 3.2 - Transport Cask Lag Storage. The cask and vehicle holding areas are a truck parking area for trucks and a railroad car spur for railroad cars. Both are located inside the MRS protected area to assure proper security surveillance.

NOTE: Letters and numbers relate facility locations to descriptions in text.
 LEGEND: Letters in diamonds identify building support facilities listed
 in Table 4.28.

FIGURE 4.36. Schematic Third-Level Plan for the MRS RHB
 Without Consolidation

Function 3.3 - Cask Preshipment Inspection and Servicing. These activities occur in the cask and vehicle holding areas described above for Function 3.2.

Function 3.4 - Transport Cask Unloading. The cask receiving facilities are illustrated in Figure 4.37 and the general location is shown in Figure 4.33. The casks are received in the receiving, inspection and shipping areas. These rooms have facilities and equipment for receiving trucks and railroad cars transporting loaded casks, unloading the casks from the transport vehicles, placing the casks on transfer carts, and reversing

TABLE 4.27. Building Process Area Dimensions for RHB Without Consolidation

Process Room	Approximate Dimensions (feet)			Location Symbol (a)
	Length	Width	Height	
Air-Control Vestibules	142(b)	59	34	A
Receiving, Inspection and Shipping	320	59	66	B
Cask Unloading				
Loading/Unloading Platform	120	26	51	C
Preparation and Decontamination Rooms	120	21	27	D
Unloading Cells	120	31	27	E
Process Cells	89	52	40	F
Canyon Cells	304	70	40	J
Storage Cask Loadout and Decontamination Room	64	39	34	G
Transfer/Discharge Area	48	39	34	H
Transport Cask Loading and Discharge Area	116	31	34	K

(a) Letter symbol indicates location (letter in square) on Figures 4.34 and 4.35.

(b) Length of each vestibule.

those processes (after the casks have been unloaded) for loading casks back onto the vehicles (i.e., moving the casks back to the vehicles, loading the casks on the vehicles, and then moving the vehicles out of the building).

These large unshielded rooms contain two railroad tracks, extending the full length of the rooms. Large doors at both ends permit entrance and exit of vehicles, and walls containing doors at approximately 140 feet from each end create air-control vestibules so that vehicles can enter and leave without compromising the controlled ventilation system. The vestibules at the end where the casks and vehicles enter the building contain washdown equipment and are used for inspection of the casks and vehicles after washing.

TABLE 4.28. Primary Process Support Facilities for RHB Without Consolidation

Facility	Function	Location Key(a)	
		Building Level	Symbol
Administration Area	Management functions	1	H
Health Physics	Health physics offices, labs and ready rooms	1	I
Material Receiving	Material receiving docks and storage	1	J
Laundry	Laundry activities	1	K
Low-Level Waste	Low-level waste receipt, treatment and shipment	1	L
High-Activity Waste	High-activity waste treatment	1	M
Electrical Facilities	Electrical switch gear and emergency backup equipment	All	N
Operations Support	Compressor rooms, test rooms, equipment rooms, chemical handling, material storage	1	O
Maintenance	Maintenance shops and storage	All	P
Control Room	Process control	2	Q
Air Conditioning	Air purification, distribution and exhaust treatment	All	R

(a) Symbol indicates locations (letter in diamond) on Figures 4.34 to 4.36.

Overhead bridge cranes have capacity for lifting the loaded transport casks and transporting them to cask carts on the loading/unloading platforms on the process sides of the receiving, inspection, and shipping areas.

The locations of the cask unloading facilities are shown in Figures 4.33 and 4.34, and the facilities are illustrated schematically in Figure 4.38. Cask unloading occurs in the cask unloading areas and the process cells. The cask unloading areas have equipment for transporting the casks from the receiving, inspection, and shipping areas to a shielded cell under a process cell, preparing the casks for unloading, connecting the casks to the process cells, and reversing those processes to return the empty casks to the receiving, inspection, and shipping area. With the casks sitting in the

FIGURE 4.37. Receiving, Inspection, and Shipping Area

FIGURE 4.38. Cask Unloading Area

unloading cells, the contents are lifted out of the cask through a port in the cell ceiling into the process cell by use of the cell bridge crane.

The cask unloading areas consist of eight unloading cells and four associated cask preparation and decontamination rooms (one for each pair of adjacent unloading cells). Each unloading cell is connected by rail tracks supporting a cask cart to the associated preparation and decontamination room and to the loading/unloading platforms in the receiving, inspection, and shipping areas. Ventilation doors separate the receiving, inspection, and shipping areas from the preparation and decontamination rooms, and shield doors separate the preparation and decontamination rooms from the unloading cells. The preparation and decontamination rooms contain movable work platforms and jib cranes for personnel working on the cask tops. Each unloading cell contains a port in the ceiling that is connected to the cask tops for unloading operations.

There are four process cells at the RHB. Each cell has two ports in the floor, each port connecting the process cell to an unloading cell directly underneath. An overhead crane in each cell lifts the wastes out of the casks and transports them inside the cell. These process cells are equipped to unload waste materials from casks, store the waste materials, and transfer the wastes into the canyon cells.

Function 3.5 - Waste Lag Storage. The incoming lag storage is illustrated in Figure 4.38. Each process cell contains a lag storage facility, and the locations are shown in Figure 4.35. The facilities are of modular construction with separate modules for PWR and BWR assemblies. The maximum number of intact assemblies that can be stored in each cell is 180 PWR assemblies or 320 BWR assemblies. The facilities are served by the cell overhead cranes and power masts attached to the cranes.

Function 3.6 - Waste Processing. The only processing that occurs for this module is placing the wastes in a container and welding the lid on.

The container closure equipment is illustrated in Figure 4.39. The location is illustrated in Figure 4.35. Containerizing occurs in the canyon cells. Each canyon contains transfer mechanisms for transporting clean, empty containers into the canyon and then into the loading position.

FIGURE 4.39. Container Closure Area

For container loading, an upender holds the open end of the container in line with a port through the shield wall between the canyon cell and a process cell. The waste is inserted through the shield wall port into the container. After the waste is loaded into the container, the container is transported by the upender to the closure area in the canyon cell where the closure equipment evacuates the container, fills it with inert gas, welds on the lid, tests the weld, and repairs the weld as necessary.

Function 3.7 - Process Lag Storages. The main canyon cell in-process lag storage is illustrated in Figure 4.40. Each canyon cell contains a lag storage for about 500 MTU of spent fuel. It is served by the canyon cell overhead crane and power mast.

In addition, each canyon cell has a small discharge lag storage for accumulating enough waste for loading one cask. It has a capacity of five containers.

Function 3.8 - Interface to Long-Term Storage. Transfer to storage activities in the RHB are illustrated in Figure 4.41. The location in the RHB is shown on Figures 4.34 and 4.35. Each canyon cell is connected by a loading port in the floor to a cask loadout and decontamination room directly underneath. The loadout and decontamination room is designed for

FIGURE 4.40. Canyon Cell In-Process Lag Storage

FIGURE 4.41. Sealed Storage Cask Loadout and Decontamination Room

receiving storage or transfer casks on transporters, preparing those casks for loading, connecting the tops of those casks to ports in the transfer cell floor, disconnecting those casks from the ports, preparing the casks for storage, and then moving the casks and transporters out of the building.^(a) It can also be used for receiving and unloading storage or transfer casks. The loadout and decontamination room is large enough to accommodate a cask on a transporter underneath the loading port and also in another position, as shown in Figure 4.41 for installation of the outer lid and for decontamination. The casks are transported to the storage facilities over the facility roads or through a special corridor with rail tracks to the vault storage facility.

Transfer from storage activities occur in the facilities described above in this subsection for transfer to storage. The activities are the same as for transfer to storage, except that they occur in opposite sequence.

Function 3.9 - Transport Cask Loading. The facilities for loading transport casks are illustrated in Figure 4.42. Their locations are shown in Figures 4.34 and 4.35. The wastes are shipped to the repository either after processing in the canyon cell or after storage in the interim storage facilities. If the wastes have been stored in the interim storage facilities, they are returned to the canyon cell by use of the facilities described above for Function 3.8.

The loading of transport casks is similar to but in a location adjacent to the sealed or transfer cask loading. Each canyon cell is connected by a loading port in the floor to a transport cask loading and discharge area directly underneath. The transport cask loading and discharge area is designed for receiving transport casks on cask carts, preparing those casks for loading, connecting the tops of those casks to ports in the canyon cell floor, disconnecting those casks from the ports, preparing those casks for shipment, and moving the casks and carts to the receiving, inspection, and shipping area. The loading area is large enough to accommodate a transport cask on a cask cart underneath the loading port. Steel tracks in the floor

---

(a) See Sections 4.3.6 and 4.3.7 for a description of the transfer casks, and Section 4.3.8 for a description of the sealed storage casks.

FIGURE 4.42. Transport Cask in Lidding Position

connect the shipping loadout room (directly under the port in the canyon cell floor) to the adjacent shipping cask lidding room (shown as containing the cask in Figure 4.42), a transport cask transfer room, and a loading/unloading platform in a receiving, inspection, and shipping room, where the transport casks are loaded onto railcars for shipment to the repositories. An inner cask lid is removed and installed, respectively, before and after cask loading, while the cask is in position mated to the loading port. The outer cask lid is removed and installed in the lidding room adjacent to the loading port. The equipment used for preparing the casks for shipment is the same as that used during the cask receipt operations described above for Function 3.4. These transport cask facilities also can be used for unloading materials directly from casks into the canyon cell.

4.3.3.2 Level 2 Physical Description of the RHB Without Consolidation (Module 3C)

The RHB currently is scheduled to receive, process, store and ship 2650 MTU of waste per year. It will operate 24 hours per day, 5 days per week for waste processing. A 1-shift-per-day, 5-days-per-week schedule

should suffice for storing, loading out, and preparing wastes for shipment. But shipments can be picked up or received on a 24-hour, 7-day-per-week schedule.

Table 4.29 contains general descriptions of the waste packages handled in the RHB without consolidation, including information on locations in the facilities. Figure 4.2 illustrates typical containers produced at the RHB.

The major process equipment needed for waste handling at this RHB is listed in Table 4.22. The equipment lists in this table are keyed to the functional description reference numbers. This table includes the equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information.

Table 4.23 provides cross-referenced lists of the major process equipment by equipment item that show the number of functions for which each equipment item is used.

The MRS facility will be decommissioned by demolition of all surface facilities, burial of all radioactive components in appropriate burial grounds, and restoration of the surface to near natural conditions.

4.3.4 Receiving and Handling Building with Consolidation (Module 3D)

The primary purposes of the RHB with consolidation module are to receive shipments of wastes in transport casks, unload the wastes from those casks, consolidate intact fuel assemblies, place the wastes in canisters or containers, place the canisters or containers of wastes in sealed storage casks or transfer casks, remove the canisters or containers of wastes from sealed storage casks or transfer casks, and place the canisters or containers of wastes in transport casks.

4.3.4.1 Level 1 Physical Description of the RHB with Consolidation (Module 3D)

Figure 4.43 presents a cutaway perspective view of one-half of the RHB. Figures 4.44 to 4.46 present simplified floor plans for the RHB with consolidation. Location numbers and letters for facilities and functions that will be referred to later are shown on these figures. Numbers in circles identify locations of functions described in the functional descriptions.

TABLE 4.29. Waste Packages Handled at the RHB Without Consolidation (Module 3C)

Waste Description (a)									
Facility Location	Location Symbol	Contents	Content(s) Symbol	Geometry	Length (in.)	Width or Diameter (in.)	Total Weight (lb)	Outer Receptacle Symbol	Receptacle and/or Content(s) Symbol
Cask receiving to process cell input and then to canyon cell	A to F to J	One PWR SFA	SFA_P	Long square assembly	180	8.5	1700	None	SFA_P
		One BWR SFA	SFA_B	Long square assembly	180	5.5	600	None	SFA_B
		Rods from SFAs	CON_P	Long square canisters	170	9	3500	AR9_P	AR9_CON_P
			CON_B	Long square canisters	170	6	1300	AR6_B	AR6_CON_B
		Hardware from consolidated SFAs	NFB_P	Long square canisters	170	9	600	AR9_P	AR9_NFB_P
			NFB_B	Long square canisters	170	9	600	AR6_B	AR6_NFB_B
		Miscellaneous wastes	GTC_P	Long square canisters	186	9	TBD	AR9_P	AR9_GTC_P
			GTC_B	Long square canisters	186	6	TBD	AR6_B	AR6_GTC_B
			GTC_O	Miscellaneous sizes	TBD	TBD	TBD	OJ	OJ_GTC_O
		Canistered SFAs	SFA_P	Long square canisters	186	9	2000	AR9_P	AR9_SFA_P
Transport cask unloading area to canyon cell	K to J		SFA_B	Long square canisters	186	9	800	AR6_B	AR6_SFA_B
			SFA_O	TBD	TBD	TBD	TBD	OJ	OJ_SFA_O
		West Valley HLW	HLW_W	Cylinder	118	24	TBD	CRP	CRP_HLW_W
		Defense HLW	HLW_D	Cylinder	118	24	TBD	CRP	CRP_HLW_D
		Commercial reprocessing plant miscellaneous wastes	GTC_W	Cylinder	118	24	TBD	CRP	CRP_GTC_W
		Defense reprocessing plant miscellaneous wastes	GTC_D	Cylinder	118	24	TBD	CRP	CRP_GTC_D
		Miscellaneous MRS wastes	GTC_M	Miscellaneous sizes	TBD	TBD	TBD	MC	MC_GTC_M
All MRS radioactive facilities to canyon cell	J								

TABLE 4.29. (contd)

Waste Description (a)									
Facility Location	Location Symbol (b)	Contents	Contents Symbol (c)	Geometry	Length (in.)	Width or Diameter (in.)	Total Weight (lb)	Outer Receptacle Symbol (d)	Receptacle and/or Contents Symbol (e)
Canyon cell to storage cask loadout area and return	J to G	Assemblies	SFA_P + SFA_B	Cylinder	80-210	28	9800	Y288P	Y288P_SFA_BP
			SFA_P	Cylinder	80-210	28	8500	Y2814	Y2814_SFA_P
			SFA_B	Cylinder	80-180	28	9500	Y28110	Y28110_SFA_B
Assemblies canistered at reactor			SFA_P	Cylinder	80-210	28	8500	Y2814	Y2814_AR9SFA_P
			SFA_B	Cylinder	80-180	28	9500	Y28110	Y28110_AR6SFA_B
			SFA_O	Cylinder	26-144	28	TBD	Y28C	Y28C_QUSFA_O
Miscellaneous wastes			GTC_P	Cylinder	188	28	TBD	Y28C	Y28C_AR9GTC_P
			GTC_B	Cylinder	188	28	TBD	Y28C	Y28C_AR6GTC_B
			GTC_O	Cylinder	188	28	TBD	Y28C	Y28C_OUGTC_O
			GTC_H	Cylinder	188	28	TBD	Y28C	Y28C_MCGTC_H
Fuel rods canistered at-reactor			CON_P	Cylinder	188	28	8500	Y2814	Y2814_AR9CON_P
			CON_B + CON_P	Cylinder	188	28	9500	Y288P	Y288P_ARCON_BP
			NFB_P	Cylinder	188	28	TBD	Y2814	Y2814_AR9NFB_P
Assembly hardware canistered at-reactor			NFB_B + NFB_P	Cylinder	188	28	TBD	Y288P	Y288P_ARNFB_BP
			NFB_P	Cylinder	130	28	TBD	Y26H	Y26H_CRPHLM_W
			HLW_W	Cylinder	130	28	TBD	Y26H	Y26H_CRPHLM_D
Defense HLW			HLW_D	Cylinder	130	28	TBD	Y26H	Y26H_CRPGTC_W
Commercial reprocessing plant miscellaneous wastes			GTC_W	Cylinder	130	28	TBD	Y26H	Y26H_CRPGTC_W
Defense reprocessing plant miscellaneous wastes			GTC_D	Cylinder	130	28	TBD	Y26H	Y26H_CRPGTC_D

TABLE 4.29. (contd)

Waste Description (a)									
Facility Location	Location (b) Symbol	Contents	Content (g) Symbol	Geometry	Length (in.)	Width or Diameter (in.)	Total Weight (lb)	Outer Re- ceptacle (g) Symbol	Receptacle and/or Contents (g) Symbol
Canyon cell to transport cask shipping area		J to K							
Same materials as from canyon cell to storage cask loadout area									

(a) Typical maximum dimension and weights.

(b) Locations on Figures 4.34 and 4.35, which show the related process functions.

(c) See Appendix A for explanation of symbols.

FIGURE 4.43. Cutaway View of One-Half of Typical MRS RHB

Letters in squares identify locations of waste processing areas listed in tables in these physical descriptions. Letters in diamonds identify locations of support facilities listed in tables in these physical descriptions.

The RHB is composed of two halves with each half having equivalent capability and containing a complete set of process areas: a receiving, inspection and shipping area, a cask unloading area, two process cells, a drum decontamination cell, a canyon cell, a storage cask loading and discharge area, and a transport cask loading and discharge area. In addition to these basic process areas, rooms for supporting activities, storage space, and corridors are provided. Table 4.30 lists the approximate process area internal dimensions and location keys that indicate where (on Figures 4.44 and 4.45) the various receiving and handling functions are located in the RHB.

S9101032.9

NOTE: Letters and numbers relate facility locations to descriptions in text.

LEGEND: Numbers in circles identify locations of functions. Letters in squares identify waste processing areas listed in Table 4.30.

Letters in diamonds identify building support facilities listed in Table 4.31.

FIGURE 4.45. Schematic Second-Level Plan for the MRS RHB with Consolidation

NOTE: Letters and numbers relate facility locations to descriptions in text.

LEGEND: Letters in diamonds identify building support facilities listed in Table 4.31.

FIGURE 4.46. Schematic Third-Level Plan for the MRS RHB with Consolidation

TABLE 4.30. Process Room Dimensions for RHB with Consolidation

Process Room	Approximate Dimensions (feet)			Location Symbol (a)
	Length	Width	Height	
Air-Control Vestibules	142(b)	59	66	A
Receiving, Inspection and Shipping	320	59	66	B
Cask Unloading				
Loading/Unloading Platform	120	26	51	C
Preparation and Decontamination Rooms	120	21	27	D
Unloading Cells	120	31	27	E
Process Cell	89	52	40	F
Drum Decon Cell	89	16	40	I
Canyon Cell	304	70	40	J
Storage Cask Loadout Area	64	39	34	G
Transfer/Discharge Area	48	39	34	H
Transport Cask Loading and Discharge Area	150	31	34	K

(a) Letter symbol indicates location (letter in square) on Figures 4.44 and 4.45.

(b) Length of each vestibule.

Containers requiring special handling that originate in canyon cell 5 can be transferred to canyon cell 6 for processing.

The RHB support facilities are shown in Figures 4.44 to 4.46. The RHB contains numerous support facilities necessary for safe and efficient performance of its operations. The primary process support facilities, their functions, and location keys for locating these facilities in Figures 4.44 to 4.46 are listed in Table 4.31.

Function 3.1 - Transport Cask Receipt. The casks are received at the inspection gatehouse. They travel from that gatehouse on the facility roads and railroad tracks to either a lag storage holding area or the RHB.

Function 3.2 - Transport Cask Lag Storage. The cask and vehicle holding areas are a truck parking area for trucks and a railroad car spur for railroad cars. Both are located inside the MRS protected area to assure proper security surveillance.

TABLE 4.31. Primary Process Support Facilities for RHB With Consolidation (Module 3D)

Facility	Function	Location Key(a)	
		Building Level	Symbol
Administration Area	Management functions	1	H
Health Physics	Health physics offices, labs and ready rooms	1	I
Material Receiving	Material receiving docks and storage	1	J
Laundry	Laundry activities	1	K
Low-Level Waste	Low-level waste receipt, treatment and shipment	1	L
High-Activity Waste	High-activity waste treatment	1	M
Electrical Facilities	Electrical switch gear and emergency backup equipment	All	N
Operations Support	Compressor rooms, test rooms, equipment rooms, chemical handling, material storage	1	O
Maintenance	Maintenance shops and storage	All	P
Control Room	Process control	2	Q
Air Conditioning	Air purification, distribution and exhaust treatment	All	R

(a) Symbol indicates locations (letter in diamond) on Figures 4.44 to 4.46.

Function 3.3 - Cask Preshipment Inspection and Servicing. These activities occur in the cask and vehicle holding areas described above for Function 3.2.

Function 3.4 - Transport Cask Unloading. The cask receiving facilities are illustrated schematically in Figure 4.47 and the general location is shown in Figure 4.43. The casks are received in the receiving, inspection, and shipping areas. These rooms have facilities and equipment for receiving trucks and railroad cars transporting loaded casks, unloading the casks from the transport vehicles, placing the casks on transfer carts, and reversing those processes (after the casks have been unloaded) for loading casks back

FIGURE 4.47. Receiving, Inspection and Shipping Area

onto the vehicles (i.e., moving the casks back to the vehicles, loading the casks on the vehicles, and then moving the vehicles out of the building).

These large unshielded rooms contain two railroad tracks, extending the full length of the rooms. Large doors at both ends permit entrance and exit of vehicles, and walls containing doors at approximately 140 feet from each end create air-control vestibules so that vehicles can enter and leave without compromising the controlled ventilation system. The vestibules at the end where the casks and vehicles enter the building contain washdown equipment and are used for inspection of the casks and vehicles after washing. Overhead bridge cranes have capacity for lifting the loaded transport casks and transporting them to cask carts on the loading/unloading platforms on the process sides of the receiving, inspection, and shipping areas.

The locations of the cask unloading facilities are shown in Figures 4.43 and 4.44, and the facilities are illustrated schematically in Figure 4.48. Cask unloading occurs in the cask unloading areas and the process cells. The cask unloading areas have equipment for transporting the casks from the receiving, inspection, and shipping areas to a shielded cell under a process cell, preparing the casks for unloading, connecting the casks to the process cells, and reversing those processes to return the empty casks to the

FIGURE 4.48. Cask Unloading Area

receiving, inspection, and shipping area. With the casks sitting in the unloading cells, the contents are lifted out of the cask through a port in the cell ceiling into the process cell by use of the cell bridge crane.

The cask unloading areas consist of eight unloading cells and four associated cask preparation and decontamination rooms (one for each pair of adjacent unloading cells). Each unloading cell is connected by rail tracks supporting a cask cart to the associated preparation and decontamination room and to the loading/unloading platforms in the receiving, inspection, and shipping areas. Ventilation doors separate the receiving, inspection and shipping areas from the preparation and decontamination rooms, and shield doors separate the preparation and decontamination rooms from the unloading cells. The preparation and decontamination rooms contain movable work platforms and jib cranes for personnel working on the cask tops. Each unloading cell contains a port in the ceiling that is connected to the cask tops for unloading operations.

There are four process cells at the RHB. Each cell has two ports in the floor, each port connecting the process cell to an unloading cell directly underneath. An overhead crane in each cell lifts the waste out of the casks and transports it inside the cell. These process cells are equipped to unload waste materials from casks, store the waste materials, process the wastes, and transfer the wastes into the canyon cells.

Function 3.5 - Waste Lag Storage. The incoming lag storage is illustrated in Figure 4.48. Each process cell contains a lag storage facility, and the locations are shown in Figure 4.45. The facilities are of modular construction with separate modules for PWR and BWR assemblies. The maximum number of assemblies that can be stored in each cell is 180 PWR assemblies or 320 BWR assemblies. The facilities are served by the cell overhead cranes and power masts attached to the cranes.

Function 3.6 - Waste Processing. This module has the following processing functions:

- Consolidation is illustrated in Figure 4.49. Each process cell contains a laser cutting system, a fuel disassembly station for disassembling spent fuel assemblies, and a consolidation station for placing the fuel rods in a close-packed bundle.
- Volume-Reduction activities are illustrated in Figure 4.50. In each of the process cells, the nonfuel-bearing fuel assembly components remaining after consolidation are shredded and placed in drums. The drums are then sealed and transported to the adjacent drum decontamination cell by a drum conveyor for external cleaning prior to shipment or placing in canisters or containers. This equipment can also be used to shred and drum other metallic wastes.
- Canister and Container Closure Equipment is illustrated in Figure 4.51. The location is illustrated in Figure 4.45. Containerizing occurs in the canyon cells. Each canyon contains transfer mechanisms for transporting clean, empty receptacles into the canyon and then into the loading position. For most receptacle loading, an upender holds the open end of the receptacle in line with a port through the shield wall between the canyon cell and a

FIGURE 4.49. Disassembly and Consolidation Area

FIGURE 4.50. Fuel Hardware Shredding and Packaging

FIGURE 4.51. Canister and Container Closure Area

process cell. The wastes are inserted through the shield wall port into the receptacle. (Some wastes may be loaded into receptacles by use of the canyon cell bridge cranes.) After the wastes are loaded into the receptacle, the receptacle is transported by the upender to the closure area in the canyon cell where the closure equipment evacuates the receptacle, fills it with inert gas, welds on the lid, tests the weld, and repairs the weld as necessary.

Function 3.7 - Process Lag Storage. The main canyon cell in-process lag storage is illustrated in Figure 4.52. Each canyon cell contains a lag storage for about 500 MTU of spent fuel. It is served by the canyon cell overhead crane and power mast. In addition, each canyon cell has a small discharge lag storage for accumulating enough wastes for loading one cask. It has a capacity of 28 spent fuel canisters or five containers.

Function 3.8 - Interface to Long-Term Storage. Transfer to storage activities in the RHB is illustrated in Figure 4.53. The location in the RHB is shown in Figures 4.44 and 4.45. Each canyon cell is connected by a loading port in the floor to a cask loadout and decontamination room directly underneath. The loadout and decontamination room is designed for receiving storage or transfer casks on transporters, preparing those casks for loading, connecting the tops of those casks to ports in the transfer cell floor,

Container Storage

Canister Storage

FIGURE 4.52. Canyon Cell In-Process Lag Storage

FIGURE 4.53. Sealed Storage Cask Loadout and Decontamination Room

disconnecting those casks from the ports, preparing the casks for storage and then moving the casks and transporters out of the building.^(a) It can also be used for receiving and unloading storage or transfer casks. The loadout and decontamination room is large enough to accommodate a cask on a transporter underneath the loading port and also in another position, as shown in Figure 4.53, for installation of the outer lid and for decontamination. The casks are transported to the storage facilities over the facility roads or through a special corridor with rail tracks to the vault storage facility.

Transfer from storage activities occur in the facilities described above in this subsection for transfer to storage. The activities are the same as for transfer to storage except that they occur in opposite sequence.

Function 3.9 - Transport Cask Loading. The facilities for loading transport casks are illustrated in Figure 4.54. The location is shown in Figures 4.44 and 4.45. The wastes are shipped to the repository either after processing in the canyon cell or after storage in the interim storage

FIGURE 4.54. Transport Cask in Lidding Position

(a) See Sections 4.3.6 and 4.3.7 for a description of the transfer casks and Section 4.3.8 for a description of the sealed storage casks.

facilities. If they have been stored in the interim storage facilities, they are returned to the canyon cell by use of the facilities described above for Function 3.8.

The loading of transport casks is similar to but in a location adjacent to the sealed or transfer cask loading. Each canyon cell is connected by a loading port in the floor to a transport cask loading and discharge area directly underneath. The transport cask loading and discharge area is designed for receiving transport casks on cask carts, preparing those casks for loading, connecting the tops of those casks to ports in the canyon cell floor, disconnecting those casks from the ports, preparing those casks for shipment, and moving the casks and carts to the receiving, inspection, and shipping area. The loading area is large enough to accommodate a transport cask on a cask cart underneath the loading port. Steel tracks in the floor connect the shipping loadout room (directly under the port in the canyon cell floor) to the adjacent shipping cask lidding room (shown as containing the cask in Figure 4.54), a transport cask transfer room, and a loading/unloading platform in a receiving, inspection, and shipping room, where the transport casks are loaded onto railcars for shipment to the repositories. An inner cask lid is removed and installed, respectively, before and after cask loading, while the cask is in position mated to the loading port. The outer cask lid is removed and installed in the lidding room adjacent to the loading port. The equipment used for preparing the casks for shipment is the same as that used during the cask receipt operations described above for Function 3.4. These transport cask facilities also can be used for unloading materials directly from casks into the canyon cell.

4.3.4.2 Level 2 Physical Description of the RHB with Consolidation (Module 3D)

This RHB is currently scheduled to receive, process, store, and ship 2650 MTU of wastes per year. It will operate 24 hours per day, 5 days per week for waste processing. A 1-shift-per-day, 5-days-per-week schedule should suffice for processing, storing, and loading out and preparing wastes for shipment. But shipments can be picked up or received on a 24-hour, 7-day-per-week schedule.

Table 4.32 contains general descriptions of the waste packages handled in this RHB, including information on locations in the facilities.

The major process equipment needed for waste handling at this RHB is listed in Table 4.22. The equipment lists in this table are keyed to the functional description reference numbers. This table includes the equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information.

Table 4.23 provides a cross-referenced list of the information in Table 4.22 by equipment item that shows the number of functions for which each equipment item is used.

The MRS facility will be decommissioned by demolition of all surface facilities, burial of all radioactive components in appropriate burial grounds, and restoration of the surface to near natural conditions.

4.3.5 S/T Cask Storage Area (Module 3E)

The purposes of the transportable storage (S/T) cask storage area module are to receive shipments of wastes in S/T casks, move those casks from the transport vehicles to storage saddles, store the casks, move the casks from the storage saddles to onsite transporters, and transport the casks to a process building.

4.3.5.1 Level 1 Physical Description of S/T Cask Storage (Module 3E)

The primary S/T cask facilities consist of a Receiving Building (RB) and a storage yard. Figure 4.55 presents a floor plan and cross section for the RB. The RB consists essentially of a large hall for transferring loaded transport casks from transport vehicles to onsite transporters. A lower structure on one side of the building provides space for support services (administration, etc.).

Figure 4.56 illustrates storage casks in storage. The storage facility may consist of a field of saddles (as illustrated in the figure) or of rows of saddles that are part of a larger storage facility for both S/T casks and other methods of storage. (See, for example, sealed storage casks, as illustrated in Figure 4.57.)

TABLE 4.32. Waste Packages Handled at the RHB with Consolidation

Waste Description (a)							Receptacle and/or Content Symbol (e)	
Facility Location	Location Symbol (b)	Contents	Contents Symbol (c)	Geometry	Length (in.)	Width or diameter (in.)	Total Weight (lb)	Outer Receptacle Symbol (d)
Cask receiving to process cell input and then to canyon cell	B to F to J	One PWR SFA	SFA_P	Long square assembly	180	8.5	1700	None
		One BWR SFA	SFA_B	Long square assembly	180	5.5	600	None
	Rods from SFAs	CON_P	Long square canisters	170	9	3500	AR9_P	
		CON_B	Long square canisters	170	6	1300	AR6_B	
	Hardware from consolidated SFAs	NFB_P	Long square canisters	170	9	600	AR9_NFB_P	
		NFB_B	Long square canisters	170	9	600	AR6_NFB_B	
	Miscellaneous wastes	GTC_P	Long square canisters	186	9	TBD	AR9_GTC_P	
		GTC_B	Long square canisters	186	6	TBD	AR6_GTC_B	
	Process cell output to canyon cell	Canistered SFAs	GTC_O	Miscellaneous sizes	TBD	TBD	TBD	CU_GTC_O
			SFA_P	Long square canisters	186	9	2000	AR9_P
SFA_B		Long square canisters	186	9	800	AR6_B		
SFA_O		Miscellaneous sizes	TBD	TBD	TBD	CU_SFA_O		
Bundles of SFA rods		CON_P	Long bundles	170	(d)	(d)	None	
		CON_B	Long bundles	170	(d)	(d)	None	
Shredded metals		NFB_P	Cylinder	36	24	700	MDRM_NFB_P	
		NFB_B	Cylinder	36	24	700	MDRM_NFB_B	
Shredded metals		NFB_P	Cylinder	36	24	700	MDRM_NFB_P	
		NFB_B	Cylinder	36	24	700	MDRM_NFB_B	
Fuel rods	CON_P	Long square canister	170	9	3500	M9_CON_P		
	CON_B	Long square canister	170	9	3100	M9_CON_B		
Shredded metals	NFB_P	Cylinder	192	24	7500	MC_MDRM_NFB_P		
	NFB_B	Cylinder	192	24	7500	MC_MDRM_NFB_B		

TABLE 4.32. (contd)

Facility Location	Location Symbol	Waste Description(a)					Receptacle and/or Contents Symbol	
		Contents	Contents Symbol	Geometry	Length (in.)	Width or Diameter (in.)		Total Weight (lb)
		Assemblies	SFA_P	Cylinder	188	6	TBD	Y2613_SFA_P
			SFA_B	Cylinder	188	6	TBD	Y2616_SFA_B
		Assemblies canistered at reactors	SFA_P	Cylinder	188	26	TBD	Y2613_AR9SFA_P
			SFA_B	Cylinder	188	26	TBD	Y2616_AR6SFA_B
			SFA_O	Cylinder	188	26	TBD	Y28C_OUSFA_O
		Miscellaneous wastes	GTC_P	Cylinder	188	26	TBD	Y2814_AR9GTC_P
			GTC_B	Cylinder	188	26	TBD	Y2819_AR6GTC_B
			GTC_O	Cylinder	188	26	TBD	Y28C_OUGTC_O
			GTC_M	Cylinder	188	26	TBD	Y28C_MDRMGTC_M
		Fuel rods canistered at reactor	CON_P	Cylinder	188	26	8500	Y2814_AR9CON_P
			CON_B	Cylinder	188	26	9500	Y2819_AR6CON_B
		Assembly hardware canistered at-reactor	NFB_P	Cylinder	188	26	TBD	Y2613_AR9NFB_P
			NFB_B	Cylinder	188	26	TBD	Y2616_AR6NFB_B
		West Valley HLW	HLW_M	Cylinder	130	26	TBD	Y26H_CRPHLW_M
		Defense HLW	HLW_D	Cylinder	130	26	TBD	Y26H_CRPHLW_D
		Commercial reprocessing plant miscellaneous wastes	GTC_M	Cylinder	130	26	TBD	Y26H_CRPGTC_M
		Defense reprocessing plant miscellaneous waste	GTC_D	Cylinder	130	26	TBD	Y26H_CRPGTC_M
		Fuel rods and assembly hardware	CON_P + NFB_P	Cylinder	180	26	TBD	Y2616_CONNFB_P
			CON_B + NFB_P	Cylinder	180	26	TBD	Y2616_CONNFB_B

TABLE 4.32. (contd)

Facility Location	Location Symbol	Waste Description (a)					Total Weight (lb)	Outer Receptacle Symbol	Receptacle and/or Contents Symbol
		Contents	Content Symbol	Geometry	Length (in.)	Width or Diameter (in.)			
Canyon cell to storage cask loadout area and return	J to G	Assemblies	SFA_P	Long square canister	186	9	2000	M9	M9_SFA_P
			SFA_B	Long square canister	186	6	800	M6	M6_SFA_B
	Assemblies canistered at reactor	SFA_P	Long square canister	192	9	2300	AR9_P	AR9_SFA_P	
		SFA_B	Long square canister	192	6	1000	AR6_B	AR6_SFA_B	
	Miscellaneous wastes	SFA_O	Miscellaneous sizes	TBD	TBD	TBD	MJ	MJ_QUSFA_O	
		GTC_P	Long square canister	192	9	TBD	AR9_P	AR9_GTC_P	
		GTC_B	Long square canister	192	6	TBD	AR6_B	AR6_GTC_B	
		GTC_O	Miscellaneous sizes	TBD	TBD	TBD	MJ	MJ_OUGTC_O	
		GTC_M	Cylinder	36	24	TBD	MC	MC_MDRMGTC_M	
		GTC_M	Miscellaneous sizes	TBD	TBD	TBD	MJ	MJ_GTC_M	
	Fuel rods canistered at-reactor	CON_P	Long square canister	176	9	3800	AR9_P	AR9_CON_P	
		CON_B	Long square canister	176	6	1600	AR6_B	AR6_CON_B	
	Assembly hardware canistered at-reactor	NFB_P	Long square canister	192	9	1000	AR9_P	AR9_NFB_P	
		NFB_B	Long square canister	192	6	900	AR6_B	AR6_NFB_B	
	Assemblies	SFA_P + SFA_B	Long square canister	170-210	28	9800	Y28BP	Y28BP_SFA_BP	
		SFA_P	Long square canister	170-210	28	8500	Y2814	Y2814_SFA_P	
		SFA_B	Long square canister	170-210	28	9500	Y28110	Y28110_SFA_B	
		SFA_P	Long square canister	170-210	28	8500	Y2814	Y2814_AR9SFA_P	
	Assemblies canistered at reactor	SFA_B	Long square canister	170-210	28	9500	Y2819	Y2819_AR6SFA_B	
		SFA_O	Miscellaneous sizes	170-210	28	TBD	Y28C	Y28C_QUSFA_O	
Miscellaneous wastes	GTC_P	Long square canister	188	28	TBD	Y2814	Y2814_AR9GTC_P		
	GTC_B	Long square canister	188	28	TBD	Y2819	Y2819_AR6GTC_B		

TABLE 4.32. (contd)

Facility Location	Location (B) Symbol	Waste Description (a)					Receptacle and/or Contents Symbol	
		Contents	Contents Symbol	Geometry	Length (in.)	Width or Diameter (in.)		Total Weight (lb)
			GTC_O	Cylinder	188	28	TBD	Y28C_MUOFGTC_O
			GTC_M	Cylinder	188	28	TBD	Y28C_MDRMGTC_M
		Fuel rods canistered at-reactor	CON_P	Cylinder	188	28	8500	Y2814_AR9CON_P
			CON_B + CON_P	Cylinder	188	28	9500	Y288P_ARCON_BP
		Assembly hardware canis- tered at-reactor	NFB_P	Cylinder	188	28	TBD	Y2814_AR9NFB_P
			NFB_B + NFB_P	Cylinder	188	28	TBD	Y288P_ARNFB_BP
		West Valley HLW	HLW_W	Cylinder	130	28	TBD	Y26H_CRPHLW_W
		Defense HLW	HLW_D	Cylinder	130	28	TBD	Y26H_CRPHLW_D
		Commercial reprocessing plant miscellaneous wastes	GTC_W	Cylinder	130	28	TBD	Y26H_CRPGTC_W
		Defense reprocessing plant miscellaneous wastes	GTC_D	Cylinder	130	28	TBD	Y26H_CRPGTC_D
Transport cask unloading area to canyon cell	K to J	West Valley HLW	HLW_W	Cylinder	118	24	TBD	CRP_HLW_W
		Defense HLW	HLW_D	Cylinder	118	24	TBD	CRP_HLW_D
		Commercial reprocessing plant miscellaneous wastes	GTC_W	Cylinder	118	24	TBD	CRP_GTC_W
		Defense reprocessing plant miscellaneous wastes	GTC_D	Cylinder	118	24	TBD	CRP_GTC_D

TABLE 4.32. (contd)

Facility Location	Location Symbol (b)	Waste Description (a)					Receptacle and/or Contents Symbol (e)	
		Contents	Contents Symbol (c)	Geometry	Length (in.)	Width or Diameter (in.)		Total Weight (lb)
All MRS radioactive facilities to canyon cell	J	Miscellaneous MRS wastes	GTC_M	Miscellaneous sizes	TBD	TBD	TBD	MC_GTC_M
Canyon cell to transport cask shipping area	J to K	Same materials as from canyon cell to storage cask loadout area						

- (a) Typical maximum dimension and weights.
 (b) Locations on Figures 4.44 and 4.45, which show the related process functions.
 (c) See Appendix A for explanation of symbols.
 (d) Dimensions and weights depend on the design of the canisters or containers that the fuel bundles will be loaded into.
 (e) Each drum contains the shredded hardware from 8 PMR SFAs or 10 BWR SFAs. Each canister contains 5 drums.

FIGURE 4.55. Floor Plan and Cross Section of RB

FIGURE 4.56. Transportable Storage Casks in Storage

Function 3.1 - Transport Cask Receipt. The casks are received at the inspection gatehouse. They travel from that gatehouse on the facility roads and railroad tracks to either a lag storage holding area or the RB.

Function 3.2 - Transport Cask Lag Storage. The cask and vehicle holding areas are truck parking areas for trucks and railroad car spurs for railroad cars. All are located inside the MRS protected area to assure proper security surveillance.

FIGURE 4.57. Plan View of Typical Interim Cask Storage Facility

Function 3.10.1 - S/T Cask Storage The cask transfer facilities in the RB are illustrated in Figure 4.55. The main hall in the RB has facilities and equipment for receiving trucks and railroad cars transporting loaded casks, unloading the casks from the transport vehicles, and placing the casks on onsite transporters.

The main hall contains one set of railroad tracks, extending the full length of the hall. Large doors at both ends permit entrance and exit of vehicles. A single overhead bridge crane has capacity for lifting the loaded transport casks and transporting them to an onsite transporter parked in the hall.

The transporter carries the casks to the cask interim storage facility by use of the facility roads. A mobile crane lifts the casks off the transporters and places them on the storage saddles. After the storage period, the crane lifts the casks off the saddles and places them on the transporters. The transporter then transports the casks to the TF, SFHB or RHB over the MRS facility roads.

4.3.5.2 Level 2 Physical Description of S/T Storage (Module 3E)

The S/T storage is currently scheduled at a maximum rate of 250 MTU of waste per year and with a maximum storage of 1100 MTU or 55 casks. The casks will be transferred to and from storage on a 1-shift-per-day, 5-days-per-week schedule.

Table 4.33 contains a general description of the wastes expected to be in the S/T casks.

The S/T casks are described in Table 4.9.

The major equipment needed for handling the S/T casks is listed in Table 4.34.

4.3.6 Vault Storage (Module 3F)

The purposes of the vault storage module are to receive transfer casks containing wastes, transfer those wastes into the vault storage, store the wastes, transfer the wastes from the vault storage to transfer casks, and transport the wastes to the TF, SFHB, or RHB.

4.3.6.1 Level 1 Physical Description of Vault Storage (Module 3F)

Figure 4.58 presents a cut-away perspective view of one-half of the vault storage building. Figures 4.59 and 4.60 present simplified floor plans for the building. Figures 4.61 and 4.62 present longitudinal and lateral cross sections of the building. Location numbers and letters for facilities and functions that will be referred to later are shown on these figures. Numbers in circles identify locations of functions described in the functional descriptions. Letters in squares identify locations of waste processing areas listed in tables in these physical descriptions. Letters in diamonds identify locations of support facilities listed in tables in these physical descriptions.

The primary process areas in the building are the transfer corridor for receiving, unloading, and loading transfer casks; the vault access rooms; and the storage vaults. The two vault access rooms and the two vaults are separated by a central ventilation discharge duct. Table 4.35 lists the approximate process area internal dimensions and location keys that indicate where

TABLE 4.33. Descriptions of the Wastes Handled in the Receiving Building

Generic Waste Form	Outer Canister or Container Symbol (d)	Cross Section		Typical Lengths (a)		Source	Contents (c)		Symbol (d)
		Geometry (e)	Dimension (in.) (b)	Outer Item (in.)	Contents (in.)		Waste		
PWR SFA	None	Square	<9	160 to 180	--	PWR	PWR SFA		SFA_P
BWR SFA	None	Square	<6	170 to 180	--	BWR	BWR SFA		SFA_B
At-Reactor PWR Canister	AR9_P	Square	~9	186	160 to 180	PWR	PWR SFA		SFA_P
					162	PWR	PWR Fuel Rods		CON_P
					180	PWR	PWR SFA Hardware		NFB_P
					180	PWR	PWR Misc. Wastes		GTC_P
At-Reactor BWR Canister	AR6_B	Square	~6	186	170 to 180	BWR	BWR SFA		SFA_B
					164	BWR	BWR Fuel Rods		CON_B
					180	BWR	BWR SFA Hardware		NFB_B
					180	BWR	BWR Misc. Wastes		GTC_B

(a) Lengths accommodate most wastes, canisters and containers. Other lengths needed for a few exceptions.

(b) Approximate dimensions. Canister and container dimensions are selected such that they can be nested.

(c) Wastes listed are the basic waste form inserted into the canister or container identified in column 2. The symbol identifies any canisters that were used to contain the waste prior to insertion into the canister or container identified in column 2. The symbol does not include the outer canister or container listed in the first two columns.

(d) See Appendix A for further explanation of symbols.

(e) See Figures 4.1 and 4.10 for square cross section.

TABLE 4.34. Major Waste Handling Equipment for the S/T Cask Module

Function Reference Number	Equipment Title	Equipment Identification	Function/Activity	Number of Units	Size or Capacity	Locations (Figure Number)
3.1	Onsite Drive Unit	1	Connect to transport vehicle	2	8 Railcars	4.21
3.2	Onsite Drive Unit	1	Move vehicle and cask into cask holding area	2	8 Railcars	4.21
3.10.1	Onsite Drive Unit	1	Move transport vehicle and cask to washdown area and then into RB	2	8 Railcars	4.55
	RB Bridge Crane	2	Remove personnel barrier, impact limiters and cask tiedowns	1	40 ton auxiliary hooks	4.55
	RB Bridge Crane	2	Move casks from vehicles to onsite transporters	1	150 ton	4.55
	Onsite Transporter	3	Move to RB and receive cask removed from vehicle	2	150 ton	4.55
	RB Bridge Crane	2	Replace cask tiedowns, impact limiters and personnel barrier on transport vehicle	1	40 ton auxiliary hooks	4.55
	Onsite Transporter	3	Transport cask to interim waste storage yard	2	150 ton	4.21
	Mobile Crane	4	Transfer S/T casks from transporter to storage saddles	1	150 ton	4.57
	Mobile Crane	4	Transfer S/T casks from storage saddles to transporter	1	150 ton	4.57
	Onsite Transporter	3	Support S/T cask during transportation to process building	1	150 ton	4.21

FIGURE 4.58. Cutaway View of Typical Vault Storage Building

Note: Letters relate facility locations to descriptions in text.

Legend: Letters in squares identify waste processing areas listed in Table 4.35. Letters in diamonds identify process support facilities listed in Table 4.36.

FIGURE 4.59. Schematic First-Level Plan for Vault Storage Building

FIGURE 4.62. Lateral Section of Vault Storage Building

TABLE 4.35. Process Areas in Vault Storage Building

Process Room	Approximate Dimension (feet)			Location Symbol (a)
	Length	Width	Height	
Operating Gallery	130	25	26	A
Unloading Corridor	200(b)	32	26	B
Storage Vault	(c)	79	46	C

(a) Letter symbol indicates location on Figures 4.59 and 4.60.

(b) Portion of corridor in the vault building.

(c) Length depends on characteristics and quantity of wastes being stored.

on Figures 4.59 and 4.60 the various functions are located. A typical storage vault location is illustrated in Figure 4.63.

The vault support facilities are shown in Figures 4.58 to 4.62. The vault building contains numerous support facilities necessary for safe and efficient performance of its operations. The primary process support facilities, their functions, and location keys for locating these facilities on the figures are presented in Table 4.36.

FIGURE 4.63. Typical Vault Storage Position
Source: Agarwal (1989)

TABLE 4.36. Process Support Facilities in Vault Storage Building

Facility	Function	Location Key(a)	
		Building Floor	Symbol
Health Physics	Radiological control	1	I
Material Receiving	Receive and store nonradioactive material	1	J
Radioactive Waste	Treat and store radioactive wastes	1	L
Electrical	Electrical switch gear	1	N
Personnel Annex	Administrative offices, change rooms	1	S
Operating Support	Storage, boiler room	1+2	O
Maintenance	Maintenance shops and storage	1+2	P
Air Conditioning and Exhaust Treatment	Air purification, distribution	1+2	R

(a) Symbol indicates location on Figures 4.59 and 4.60.

The description herein is based on a vault storage capacity of 3000 MTU of bare intact fuel. Because of the modular nature of the vault, the capacity can be increased or decreased from this amount by either changing the lengths of the vaults or by adding additional vaults in parallel to the two vaults described here. Also, the sizes of the vaults will be different if 3000 MTU of canistered-consolidated fuel or fuel in repository containers is stored.

Function 3.10.2 - Vault Storage. The wastes are transferred from the transfer casks to the vault storage in the vault building.

The top of a transfer cask in the unloading corridor is connected to a transfer port in the corridor ceiling. The fuel handling machine (FHM) in the corresponding vault access room is connected to the top of that transfer port (see Figure 4.61). After the waste is transferred to the FHM, the FHM travels through the vault access room to the selected vault storage location. The FHM then is connected to the storage location and the wastes are placed in that location, as shown in Figure 4.58.

The transfer from storage uses the same vault facilities and equipment as described above for placement in storage. In addition, the loaded transfer cask travels from the vault to the TF, SFHB, or RHB on tracks in enclosed corridors.

4.3.6.2 Level 2 Physical Description of Vault Storage (Module 3F)

The vault storage is currently scheduled at a maximum rate of 3000 MTU/yr and with a maximum storage of 15,000 MTU. The wastes will be transferred to and from storage on a 1-shift-per-day, 5-days-per-week schedule.

The wastes expected to be handled in the vault storage are the same as those handled in the loadout areas of the TF, SFHB, and RHB.

The major equipment needed for the vault storage module is listed in Table 4.37.

4.3.7 Drywell Storage (Module 3G)

The purposes of the drywell storage module are to receive transfer casks containing wastes, transfer those wastes into the drywell storage, store the

TABLE 4.37. Major Equipment for the Vault Storage Module

Function Reference Number	Equipment Title	Equipment Identification	Function/Activity	Number of Units	Size or Capacity	Locations (Figures 4.59 and 4.60)
3.10.2	Transfer Cask	1	Transfer wastes to vault and shield wastes during cask unloading	2	5 tons	B
	Cask Transporter	2	Move transfer cask to vault	2	5 tons	B
	Transfer Port Plug	3	Provide shielding in transfer ports	4	1 port	C
	FHM	4	Remove storage shield plugs, remove transfer port plugs, lift wastes from transfer casks into FHM, replace transfer port plug, transport wastes to vault storage position, place wastes in storage position, replace storage shield plugs, inert storage tubes	2	5 tons	C
	Storage Shield Plugs	5	Provide shielding on vault storage tubes	1 per storage tube	1 tube	C
	Vault Baskets	6	Support wastes in vault	1 per vault tube	1 vault tube	C
	FHM	4	Remove storage shield plug, lift wastes into FHM, replace storage shield plug, transport wastes to transfer port, remove transfer port plug, lower wastes into transfer cask, replace transfer port plug	2	5 tons	C
	Transfer Port Plug	3	Provide shielding in transfer port	4	1 port	C
	Cask Transporter	2	Move transfer cask to vault	2	5 tons	B
	Transfer Cask	1	Shield wastes during waste transfer, transport wastes to TF, SFHB or RHB	2	5 tons	B

wastes, transfer the wastes from the drywell storage to transfer casks, and transport the wastes to the TF, SFHB, or RHB.

4.3.7.1 Level 1 Physical Description of Drywell Storage (Module 3G)

Figure 4.64 presents an illustration of a drywell and a general view of part of a drywell storage facility. A storage capacity of 15,000 MTU of bare fuel assemblies would require a total storage facility area of approximately 150 acres.

Function 3.10.3 - Drywell Storage. The wastes are transferred from the transfer casks to the drywells at the drywell storage facility.

The transfer cask is connected to the top of a drywell. The drywell plug is removed from the drywell and stored in the transfer cask. The waste is then lowered from the transfer cask into the drywell. The drywell plug is then replaced in the drywell. The transfer cask is removed. The drywell plug is sealed and the drywell is filled with inert gas.

FIGURE 4.64. Typical Drywell Installation

The transfer from storage uses the same transfer cask as described above for transfer to storage. In addition, the loaded transfer cask on a transporter travels from the drywell storage facility to the TF, SFHB, or RHB on the MRS facility roads.

4.3.7.2 Level 2 Physical Description of Drywell Storage (Module 3G)

The drywell storage is currently scheduled at a maximum rate of 3000 MTU/yr and with a maximum capacity of 15,000 MTU. The wastes will be transferred to and from storage on a 1-shift-per-day, 5-days-per-week schedule.

The wastes expected to be handled in the drywell storage are the same as those handled in the loadout area at the TF, SFHB, and RHB.

The major equipment needed for the drywell storage module is listed in Table 4.38. All of this equipment is used at the storage facility.

4.3.8 Sealed Storage Cask Storage (Module 3H)

The primary purposes of the sealed storage cask storage module are to receive sealed storage casks, transfer these casks to the storage pads, store the casks, transfer the casks back to the transporters and transport the casks to a process building. This module also includes the cask fabrication facilities.

TABLE 4.38. Major Equipment for the Drywell Storage Module

<u>Function Reference Number</u>	<u>Equipment Title</u>	<u>Equipment Identification</u>	<u>Function/Activity</u>	<u>Number of Units</u>	<u>Size or Capacity</u>
3.10.3	Transfer Cask	1	Remove drywell plug, lower wastes into drywell, replace drywell plug	8	5 tons
	Cask Transporter	2	Support cask	8	1 cask
	Drywell Plugs	3	Provide shielding in top of drywell and seal drywell gas tight	1 per drywell	1 drywell
	Drywell Baskets	4	Support wastes in drywell	1 per drywell	1 drywell
	Cask Transporter	2	Remove wastes from storage and move transfer cask to vault	8	1 cask
	Transfer Cask	1	Shield wastes during transfer to TF, SFHB or RHB	8	5 tons

4.3.8.1 Level 1 Physical Description of Sealed Storage Cask Storage (Module 3H)

Figure 4.65 presents an illustration of a sealed storage cask (SSC). Figure 4.66 shows transfer of a cask from a transporter to storage and storage of the casks. The storage facility consists of a group of concrete slabs, as shown in Figure 4.67.

Function 3.10.4 - MRS Storage. The casks are transferred from the onsite transporter to the storage pads and are stored at the interim storage facility.

Then, after storage, the casks are transferred from the storage pads to the transporter at the storage facility. The casks are then transported to the TF, SFHB, or RHB over the MRS facility roads.

FIGURE 4.65. Sealed Storage Cask

FIGURE 4.66. Placing Sealed Storage Casks in Storage

FIGURE 4.67. Plan View of Typical Interim Cask Storage Facility

4.3.8.2 Level 2 Physical Description of Sealed Storage Cask Storage (Module 3H)

The SSC storage is currently scheduled at a maximum rate of 3000 MTU/yr and a maximum capacity of 15,000 MTU. The casks will be transferred to and from the storage facility on a 1-shift-per-day, 5-days-per-week schedule.

The major equipment needed for the SSC storage module is listed in Table 4.39. The designs of the SSCs are presented in Table 4.40.

TABLE 4.39. Major Waste Handling Equipment for SSC Storage Module

Function Reference Number	Equipment Title	Equipment Identification	Function/Activity	Number of Units	Size or Capacity	Locations (Figures 4.21 and 4.67)
3.10.4	SSC Transporter	1	Support loaded storage cask at storage pad	4	600 ton	Storage facility
	Cask Handling Crane	2	Move cask from transporter to storage pad	1	250 ton	Storage facility
	Cask Handling Fixtures	3	Connect crane to casks during cask movements by crane	4	250 ton	Storage facility
	Cask Handling Fixtures	3	Connect crane to casks during cask removal from storage	4	250 ton	Storage facility
	Cask Handling Crane	2	Move cask from storage pad to transporter	1	250 ton	Storage facility
	SSC Transporter	1	Transport storage casks to TF, SFHB or RHB	4	600 ton	MRS facility roads

TABLE 4.40. Sealed Storage Cask Description

Cask symbol (b)	PMR Spent Fuel Casks (a)		Nonfuel-Bearing Hardware Casks		HLW Casks		Miscellaneous Wastes		Container Casks	
	MSC_P	MSC_B	MSC_NFB	MSC_HLW	MSC_U	MSC_R				
Cask outer diameter	12 ft 8 in.	12 ft. 8 in.	12 ft 8 in.	12 ft 8 in.	12 ft 8 in.	12 ft 8 in.	12 ft 8 in.	12 ft 8 in.	MSC_R	12 ft 8 in.
Cask inner diameter	5 ft 8 in.	5 ft 8 in.	4 ft 11 in.	6 ft 5 in.	4 ft 11 in.	TBD	4 ft 11 in.	TBD		TBD
Cask height	22 ft 2 in.	22 ft 2 in.	22 ft 2 in.	22 ft 2 in.	22 ft 2 in.	22 ft 2 in.	22 ft 2 in.	22 ft 2 in.		22 ft 2 in.
Cask inner cavity height	16 ft 2 in.	16 ft 2 in.	15 ft 8 in.	15 ft 10 in.	15 ft 8 in.	TBD	15 ft 8 in.	TBD		TBD
Cask capacity										
Spent fuel canisters (9 in. square)	28	--	--	--	--	Internal structure not designed. Will depend on material being stored.	--	--		--
Spent fuel canisters (6 in. square)	--	70	--	--	--	--	--	--		--
Nonfuel-bearing hardware drums	--	--	15	--	--	--	--	--		--
High-activity RHTRU canisters (>50 R/hr)	--	--	--	--	--	--	--	--		--
Low-activity RHTRU canisters (<50 R/hr)	--	--	--	--	--	--	--	--		--
High-Level Waste canisters containers	--	--	--	5	--	--	--	--		--
Cask maximum heat load (kW)	24	24	70	--	--	Unknown	24	24		24
Symbols for canisters or containers loaded into storage cask (b)	M9	M6	MC	CRP Y26H	MU AR9 AR6 OU	Y2613 Y26C Y2616				

TABLE 4.40. (contd)

	PMR Spent Fuel Casks (a)	BWR Spent Fuel Casks	Nonfuel-Bearing Hardware Casks	HLW Casks		Miscellaneous Wastes	Container Casks
Symbols for containers, canisters and contents that might be loaded into storage cask	M9_SFA_P	M6_SFA_B	MC_HDRMMFB_P	CRP_HLW_W	TBD		Y2613_SFA_P
	M9_CON_P	AR6_SFA_B	MC_HDRMMFB_B	CRP_HLW_D			Y2616_SFA_B
	M9_CON_B	AR6_GTC_B		CRP_GTC_W			Y2613_CON_P
	AR9_SFA_P	AR6_NFB_B		CRP_GTC_D			Y2613_CON_B
	AR9_GTC_P	AR6_CON_B		Y26H_CRPHLW_W			Y2613_AR9SFA_P
	AR9_NFB_P	SFA_B		Y26H_CRPHLW_D			Y2616_AR6SFA_B
	AR9_CON_P			Y26H_CRPGTC_W			Y2613_AR9CON_P
	SFA_P			Y26H_CRPGTC_D			Y2616_AR6CON_B
							Y2616_NFB_P
							Y2616_NFB_B
							Y2616_AR6GTC_B
							Y2613_AR9GTC_P
							Y2613_AR9NFB_P
							Y2616_AR6NFB_B
							Y26C_OUGTC_O
							Y26C_DRMGTC_O
							Y26C_GTC_W
							Y26C_OUSFA_O
							Y26C_CRPHLW_W
							Y26C_CRPHLW_D
							Y26C_CRPGTC_W
							Y26C_CRPGTC_D

(a) Cask for all SFAs except the Westinghouse extra long assemblies. Special casks will have to be designed for those assemblies if they are stored at the MRS.

(b) See Appendix A for explanation of symbols.

4.4 TUFF REPOSITORY

The tuff repository, at Yucca Mountain in Nevada, will provide waste preparation, emplacement, and disposal in a geologic repository. The major requirements of this facility will be to:

- receive packaged and unpackaged spent nuclear fuel and wastes from nuclear power generating facilities, research facilities, and the MRS facility, and high-level wastes from reprocessing plants or the MRS
- process and package spent fuel and other wastes as needed for final disposal
- safely emplace no more than 70,000 MTU of spent fuel and other wastes
- continuously monitor and manage spent fuel and wastes during the repository caretaker period
- remove selected disposal containers from the repository for performance confirmation testing during a 50-year emplacement and caretaker period
- retrieve all wastes in the event some disqualifying feature is found in the repository within 50 years of the time when waste emplacement operations are initiated
- close the repository for safe disposal of the wastes by backfilling and sealing of the underground facilities and decommissioning the surface facilities.

These requirements provide the reference basis for this physical description of the ten tuff repository modules.

The Yucca Mountain site is in Nye County, Nevada, on and adjacent to the southwest portion of the DOE's Nevada Test Site, about 100 miles northwest of Las Vegas (see Figure 4.68).

There are three general types of facilities at the repository: 1) the support facilities, 2) the waste receiving, handling and temporary storage

FIGURE 4.68. Location of Yucca Mountain Repository Site in Southern Nevada

facilities, and 3) the underground disposal facilities. A typical layout of these facilities is shown in Figure 4.69. The general characteristics of these facilities and their alternatives are described here.

Figure 4.70 presents a typical plan view of a waste handling building (WHB) and the support facilities for the repository. Table 4.41 lists the primary support facilities and states their purposes and typical floor areas. Their locations are keyed to Figure 4.70.

The descriptions in this subsection are based on information from Bechtel (1985), DOE (1988b), and Weston (1989).

4.4.1 Transportable Storage Cask Storage (Module 4A)

The purposes of this module are to receive shipments of transportable storage (S/T) casks on railcars, remove those casks from the railcars, place those casks on onsite transporters, move the casks and transporters to the storage facility, move those casks from the transporters to storage saddles, store the casks, move the casks from the storage saddles to onsite transporters, and transport those casks to the WHB.

The transportable storage cask facilities for the repository have not been designed. It is assumed that this Module 4A is identical to Module 3E, the transportable storage cask module for the MRS facility.

4.4.2 Pass-Through WHB-1 for Containerized Intact SFAs (Module 4B)

The primary purposes of this module are to receive 3400 MTU/yr of containerized intact SFAs and HLW from the MRS facility, unload those wastes from the transport casks, inspect the wastes, and load the wastes into transporters.

4.4.2.1 Level 1 Physical Description of Pass-Through WHB-1 for Containerized Intact SFAs (Module 4B)

Figure 4.71 presents a typical schematic process flow diagram for this WHB that illustrates its primary functions. Figures 4.72 and 4.73 present simplified floor plans for the building.

The general process areas are the receiving, inspection, and shipping area; the cask preparation area; two cask unloading hot cells; the inspection

FIGURE 4.69. Typical Tuff Repository Perspective View

LEGEND: Letters in diamonds identify facilities listed in Table 4.41.

FIGURE 4.70. Plan View of Typical Repository Central Surface Facilities

TABLE 4.41. Tuff Repository Primary Support Facilities

<u>Facility Title</u>	<u>Facility Purpose</u>	<u>Approximate Area (ft²) (a)</u>	<u>Location Symbol (b)</u>
Waste Receiving and Inspection Area	Receive waste shipments, store shipments, wash casks and vehicles	600,000	L
Waste Treatment Building	Prepare site-generated radioactive wastes for shipment offsite	21,000	M
Decontamination Building	Decontaminate and repair radioactive equipment	5,400	N
Performance Confirmation Building	Determine condition of wastes removed from repository	24,000	O
Electrical Substation and Emergency Generators	Supply electricity during normal and emergency conditions	14,000	P
Fire Station	House fire department personnel and equipment	5,000	Q
Medical Facilities	Provide routine and emergency medical activities	6,400	R
Underground Personnel Building	Provide changerooms and supervisory offices for underground personnel	15,000	S
Mock-Up Building	Train personnel on mock-ups of repository equipment and facilities	6,300	T
Administration	House repository administrative activities	32,000	U

TABLE 4.41. (contd)

Facility Title	Facility Purpose	Approximate Area (ft ²) (a)	Location Symbol (b)
Training Auditorium	Auditorium for personnel training and other activities requiring a large auditorium	1,000	V
Food Service	Cafeteria	5,400	W
Computer Building	House repository computers	5,400	X
Central Warehouse	Warehouse materials	51,000	Y
Shops	Maintenance activities	24,000	Z

(a) Typical areas for the repository that both consolidate spent fuel and containerize all wastes. Some of these facilities will be smaller for repositories that do not consolidate and/or do not containerize wastes.

(b) Locations on Figure 4.70.

FIGURE 4.71. Conceptual Schematic Process Flow Diagram for the WHB

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.42, 4.43, and 4.45.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.72. General Plan View of the Module 4B WHB Main Floor

cell; the container transfer tunnel; and a surface storage vault. The two unloading hot cells contain three cask unloading ports. In addition to these basic process areas, rooms for supporting activities, storage space, and corridors are provided. Table 4.42 lists the approximate process area dimensions and location keys that indicate where (on Figures 4.72 and 4.73) the various functions are located in the WHB.

The WHB contains a number of support facilities necessary for safe and efficient performance of its operations. These support facilities and their location keys are listed in Table 4.43.

The WHB facilities needed for each of the repository functional activities are described in the following subsections. The activities are described in the functional description section of this document. The locations of these activities in the WHB are shown in Figures 4.72 and 4.73 as circles containing the functional activity numbers.

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.42, 4.43, and 4.45.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.73. General Plan View of the Module 4B WHB Basement

TABLE 4.42. Module 4B WHB Process Room Dimensions

Process Room	Approximate Dimension (feet)			Location Symbol (a)
	Length	Width	Height	
Air Control Vestibules	140	35	25	A
Receiving and Shipping Area	416	35	75	B
Cask Preparation Area	267	25	100	C
Cask Unloading Rooms	64 + 32	40	30	D
Cask Unloading Hot Cells	185 + 113	40	40	E
Inspection Cell	64	33	40	F
Waste Transfer Tunnel	137	23	23	I
Surface Storage Vault	224	81	55	J

(a) Letter symbol indicates location on Figures 4.72 and 4.73.

TABLE 4.43. Module 4B WHB Process Support Facilities

<u>Facility</u>	<u>Function</u>	<u>Location Key(a)</u>	
		<u>Building Floor</u>	<u>Symbol</u>
Material Receiving	Receive and store nonradioactive material	1	J
Operations Support	Operating gallery, weld power supply	1	O
Maintenance	Maintenance shops and storage	Basement	P
Air Conditioning and Exhaust Treatment	Air purification, distribution	2	R
Personnel Annex	Administrative offices, change rooms, training facilities, auditorium	1	S
Container Storage and Transfer	Store clean empty container and transfer to waste transfer tunnel	1	T

(a) Symbol indicates location on Figures 4.72 and 4.73.

Function 4.1 - Transport Cask Receipt. Cask receipt occurs at the waste receiving and inspection area where the railroad lines enter the facility (area L in Figure 4.70).

Function 4.2 - Transport Cask Lag Storage. Lag storage of the casks occurs on one of the railcar parking lines at the waste receiving and inspection area (area L in Figure 4.70).

Function 4.3 - Cask Preshipment Inspection and Servicing. The routine cask servicing occurs in the cask receipt area described above and uses the same equipment as is used for cask receipt.

Function 4.4 - Transport Cask Unloading. The cask receiving facilities in the WHB are illustrated schematically in Figure 4.74 and the general location is shown in Figure 4.72. The casks are received at the receiving, inspection, and shipping area. This area has facilities and equipment for receiving trucks and railroad cars transporting loaded casks, removing those casks from those vehicles, placing the casks on transfer carts and reversing these procedures for placing casks back onto the vehicles.

FIGURE 4.74. Typical WHB Cask Receiving Facilities

This large unshielded receiving and shipping area contains railroad tracks, extending the full length of the area. Large doors near the center of the area create airlocks at the outer ends so that vehicles can enter and leave without compromising the controlled ventilation system. Overhead bridge cranes have capacity for lifting the transport casks and transporting them to the transfer carts in the cask preparation area at the side of the receiving and shipping area.

Cask unloading occurs in the cask preparation area, the cask transfer tunnels, and the cask unloading hot cells (see Figures 4.71 to 4.73). The unloading facilities have equipment for transporting the casks from the

preparation area to rooms under the cask unloading cells, preparing the casks for unloading, connecting the casks to the cask unloading cells, and reversing those processes to return the casks to the cask preparation area. With the casks sitting in rooms under the cask unloading cells, the contents are lifted out of the casks through ports in the room ceilings into the cells by the unloading cell bridge cranes.

The cask preparation area and cask transfer tunnels have a set of cart tracks for each unloading port in the unloading cells and a transfer cart for each set of tracks. Ventilation doors separate the cask preparation area from the cask transfer tunnels and shadow shields attached to the roof of the transfer tunnels can be lowered to provide radiation shielding between the open unloading cell entry ports and the cask preparation area. The preparation room contains movable work platforms for personnel working on the cask tops. Jib cranes in the cask preparation area are used for removing and replacing the cask outer lids, and robots are used for routine operations such as loosening and tightening bolts.

The cask unloading hot cells have overhead bridge cranes that remove and replace the hot cell port plugs, remove and replace the cask inner lids, lift the wastes out of the casks, and transport the wastes inside the cells. The cells also are equipped for storage of the waste materials, inspecting containers, cutting lids off containers, welding lids on containers, and placing the containers on transfer carts in a transfer tunnel to the surface storage vault area.

Function 4.5 - Waste Lag Storage. The cask unloading cell lag storage is illustrated in Figure 4.75 and the location is shown in Figure 4.72. The facilities are of modular construction with capacity for one shipment of waste containers.

Function 4.6 - Waste Processing. The unloading and inspection hot cells contain several processing stations such as leak-test stations, welding stations, weld inspection stations, canister inspection stations, container inspection stations, container decontamination stations, and fuel inspection stations. These are listed below in Section 4.4.2.2. This equipment has not been designed.

FIGURE 4.75. Cask Unloading Cell Lag Storage

Representative containers are illustrated in Figure 4.2.

Function 4.7 - Container Vault Storage. A separate surface storage vault provides lag storage between the hot cell operations and the waste emplacement. The wastes are transported from the cask unloading hot cells to the vault by transfer carts in the waste transfer tunnels. A shielded transfer machine transfers the wastes between the transfer carts, the vault storage areas, and the out-transfer station, where the canisters of waste are loaded into the waste transporter cask (see Figure 4.71).

4.4.2.2 Level 2 Physical Description of Pass-Through WHB-1 for Containerized Intact SFAs (Module 4B)

The pass-through WHB for containerized intact fuel is scheduled to receive and handle 3000 MTU of SNF and 400 MTU equivalent of HLW per year. It will operate 24 hours per day, 5 days per week and 250 days per year for all primary functions (unloading shipments, processing wastes, and loading waste transporters). Shipments will be accepted 7 days per week, 365 days per year.

Table 4.44 contains general descriptions of the waste packages handled by this pass-through WHB.

The major process equipment needed for the waste handling buildings is listed in Table 4.45. This table contains the functional description reference numbers, equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information. The equipment is listed in this table by functional description reference number.

Table 4.46 lists the information in Table 4.45 by equipment item to show the number of functions for which each equipment item is used.

4.4.3 Pass-Through WHB-1 for Containerized Consolidated SFAs (Module 4C)

The primary purposes of this module are to receive 3000 MTU/yr of containerized consolidated SFAs and 400 MTU/yr of containerized HLW from the MRS facility, unload those wastes from the transport casks, inspect the wastes, and load the wastes into transporters.

4.4.3.1 Level 1 Physical Description for Pass-Through WHB-1 for Containerized Consolidated SFAs (Module 4C)

Figure 4.76 presents a typical schematic process flow diagram for this WHB that illustrates its primary functions. Figures 4.77 and 4.78 present simplified floor plans for the building. The general process areas are the receiving, inspection, and shipping areas; the cask preparation area; a cask unloading hot cell; an inspection cell; a container transfer tunnel; and the surface storage vault. The cask unloading hot cell contains two cask

TABLE 4.44. Wastes Handled by Module at the Repository WHB(a)

Facility Location	Location Symbol(b)	Contents	Contents Symbol(c)	Wastes Handled by Module						
				M4B	M4C	M4D	M4E	M4F	M4G	M4I
Cask Receiving to Cask Unloading Cell	A to E (from reactors)	One PUR SFA	SFA_P			X	X	X	X	X
		One BMR SFA	SFA_B			X	X	X	X	X
		Rods from SFAs	CON_P CON_B				X	X	X	X
		Hardware from consolidated SFAs	NFB_P NFB_B			X	X	X	X	X
A to E (from NRS)	Miscellaneous wastes		GTC_P GTC_B			X	X	X	X	X
						X	X	X	X	X
	Canistered SFAs		SFA_P SFA_B			X	X	X	X	X
						X	X	X	X	X
	Fuel rods		CON_P CON_B						X	
	PUR SFAs		SFA_P		X					X
						X				
Assemblies canistered at-reactor	BMR SFAs		SFA_B							
	Assemblies canistered at-reactor		SFA_P							

TABLE 4.44. (contd)

Facility Location	Location Symbol (b)	Contents	Contents Symbol (c)	Canister and/or Contents Symbol (c)	Wastes Handled by Module																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																						
					M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																															
Shredded Metals	NFB_P			MC_MDRNFB_P																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																							

TABLE 4.44. (contd)

Facility Location	Location Symbol (b)	Contents	Contents Symbol (c)	Canister and/or Contents Symbol (c)	Wastes Handled by Module									
					M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I		
Cask Unloading Cell to Repository	A to E (from reprocessing plants)	Commercial HLW	HLW_W	CRP_HLW_W Y26H_CRPHLW_W	X	X		X	X	X				
		Defense HLW	HLW_D	CRP_HLW_D Y26H_CRPHLW_D	X	X		X	X	X				
	Commercial reprocessing plant miscellaneous wastes	GTC_W		CRP_GTC_W Y26H_CRPGTC_W	X	X		X	X	X				
		GTC_D		CRP_GTC_D Y26H_SRPGTC_D	X	X		X	X	X				
	PWR SFAs	SFA_P		Y26I3_SFA_P Y288P_SFA_BP Y28I4_SFA_P Y26I6_SFA_B Y288P_SFA_BP Y28I0_SFA_B Y28I9_SFA_B	X	X		X	X		X		X	
		SFA_B			X	X		X	X	X		X		X
	Rods from SFAs consolidated at-reactor	CON_P		Y26I3_AR9CON_P Y288P_AR9CON_P Y28I4_AR9CON_P Y26I6_AR6CON_B Y288P_AR6CON_B Y28I9_AR6CON_B Y28I10_AR6CON_B	X	X		X	X		X		X	
		CON_B			X	X		X	X	X		X		X
	Hardware from SFAs consolidated at-reactor	NFB_P		Y26I3_AR9NFB_P Y288P_AR9NFB_P Y28I4_AR9NFB_P Y26I6_AR6NFB_B Y288P_AR6NFB_B Y28I9_AR6NFB_B Y28I10_AR6NFB_B	X	X		X	X		X		X	
		NFB_B			X	X		X	X	X		X		X
Miscellaneous at-reactor wastes	GTC_P		Y26I3_AR9GTC_P Y288P_AR9GTC_P Y28I4_AR9GTC_P Y26I6_AR6GTC_B Y288P_AR6GTC_B Y28I9_AR6GTC_B Y28I10_AR6GTC_B	X	X		X	X		X		X		X
	GTC_B			X	X		X	X	X		X		X	

TABLE 4.44. (contd)

Facility Location	Location Symbol (b)	Contents	Contents Symbol (c)	Canister and/or Contents Symbol (c)	Wastes Handled by Module									
					M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I		
At-reactor canistered SFAs	SFA_P	At-reactor canistered SFAs	SFA_P	Y2613_AR9SFA_P		X						X	X	
				Y288P_AR9SFA_P	X				X	X				
				Y2814_AR9SFA_P	X				X	X				
				Y2616_AR6SFA_B		X					X			
				Y2819_AR6SFA_B							X			
				Y288P_AR6SFA_B	X			X	X					
Fuel rods canistered at HRS	SFA_O	SFA_O	SFA_O	Y2811G_AR6SFA_B	X			X	X					
				Y28C_QUSFA_O	X	X		X	X					
Assemblies canistered at HRS	SFA_P	SFA_P	SFA_P	Y2814_M9CON_P							X			
				Y2814_M9CON_P							X			
Shredded metals from HRS	NFB_P	NFB_P	NFB_P	Y26C_MCHDRMNF_B		X					X			
				Y26C_MCHDRMNF_B		X					X			
Miscellaneous wastes from HRS	GTC_O	GTC_O	GTC_O	Y28C_MCHDRMNF_B		X					X			
				Y26C_MCHDRMNF_B	X	X				X	X			
				Y28C_MCHDRMNF_B	X	X				X	X			
Miscellaneous repository wastes	GTC_R	GTC_R	GTC_R	Y28C_GTC_R			X	X		X	X	X		
West Valley HLW	HLW_W	HLW_W	HLW_W	Y26H_CRPHLW_W	X	X	X	X	X	X				
Defense HLW	HLW_D	HLW_D	HLW_D	Y26H_CRPHLW_D	X	X	X	X	X	X				
Commercial reprocessing plant miscellaneous wastes	GTC_W	GTC_W	GTC_W	Y26H_CRPGLW_W	X	X	X	X	X	X				
Defense reprocessing plant miscellaneous wastes	GTC_D	GTC_D	GTC_D	Y26H_CRPGLW_D	X	X	X	X	X	X				

(a) See Table 4.1 for description of wastes.

(b) Locations on Figures 4.72, 4.77, 4.82, 4.87, 4.92, 4.97, 4.102, and 4.107, as appropriate for module of interest, which show the related process functions.

(c) See Appendix A for explanation of symbols.

TABLE 4.45. Major Waste Handling Equipment for the WHBs - Listed in Process Step Order

Function Reference Number	Equipment Title	Equipment Identification	Function/Activity	Number of Units in Module										Size or Capacity	Equipment (a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I	M4J	M4K		
4.1	Onsite Drive Unit	37	Connect to train cars	2	2	2	2	2	2	2	2	2	2	2 8 Railcars	L
4.2.1	Onsite Drive Unit	37	Move train cars to holding area	2	2	2	2	2	2	2	2	2	2	2 8 Railcars	L
4.2.2	Car Puller	1	Move vehicles in waste handling building	3	3	3	3	3	3	3	3	3	3	3 10,000 lb	A,B
	Onsite Drive Unit	37	Move casks and cars to dispatch holding area	2	2	2	2	2	2	2	2	2	2	2 8 Railcars	A to L
	Onsite Drive Unit	37	Make up shipment train	2	2	2	2	2	2	2	2	2	2	2 8 Railcars	L
4.4.1.1	Onsite Drive Unit	37	Move casks and cars to washdown area	2	2	2	2	2	2	2	2	2	2	2 8 Railcars	L to A
4.4.1.2	Car Puller	1	Move vehicles inside waste handling building	3	3	3	3	3	3	3	3	3	3	3 10,000 lb	A,B
	Airlock Bridge Crane	2	Remove impact limiters tiedowns and personnel barriers, perform radiological surveys	2	2	2	2	2	2	2	2	2	2	2 5 ton	A
4.4.1.3	Bridge Crane	3	Move casks from vehicles to cask carts	2	2	2	3	2	2	2	3	2	3	2 200 ton	B to C
	Cask Cart	4	Receive cask and carry it to cask handling room	3	2	2	7	5	3	5	3	5	3	3 200 ton	C
4.4.1.4	Cask Service Platform	5	Support personnel during work on cask tops	3	2	2	7	5	3	5	3	5	3	3 --	C
	Jib Crane	6	Move cask outer lid to service pad	2	2	2	3	3	2	3	3	3	3	3 10 ton	C
	Floor-Mounted Robot	7	Remote work on cask tops	3	2	2	7	5	3	5	3	5	3	3 1 ton	C
4.4.1.5	Floor-Mounted Robot	7	Remote work on cask tops	3	2	2	7	5	3	5	3	5	3	3 1 ton	C
4.4.1.6	Cask Contamination Barrier Adaptor	8	Installed to provide connection between cask top and cask contamination barrier	9	6	6	21	15	9	15	9	15	9	9 1 cask	C
	Jib Crane	6	Install contamination barrier adaptor	2	2	2	3	3	2	3	2	3	3	3 10 ton	C

TABLE 4.45. (contd)

Function Reference Number	Equipment Title	Equipment Identification	Function/Activity	Number of Units in Module										Size or Capacity	Equipment ^(a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I				
4.4.1.7	Cask Cart	4	Move cask to unloading room	3	2	2	7	5	3	5	3	200 ton	C to D		
	Cask Contamination Barrier	9	Installed to provide connection between cask top and process cell port	3	2	2	7	5	3	5	3	1 Cask	D		
	Cask Shadow Shield	11	Installed to shield preparation area when cask unloading cell port plug is out	3	2	2	7	5	3	5	3	--	D		
4.4.1.8	Cask Unloading Cell Shield Plug	10	Provide shielding in cask unloading cell port. Removed to permit cask unloading	3	2	2	7	5	3	5	3	1 Port	E		
	Cask Unloading Cell Bridge Crane	12	Remove cask unloading cell port plugs, remove cask inner lid	2	2	2	4	5	4	5	4	20 ton	E		
4.4.2	Cask Shadow Shield	11	Shields preparation area when cask unloading cell port plug is out	3	2	2	7	5	3	5	3	--	D		
	Lag Storage Covers	13	Ventilation cover on lag storage, removed and replaced during waste transfers into storage	6	6	6	12	12	12	15	15	--	E or G		
	Cask Unloading Cell Bridge Crane	12	Remove and replace lag storage covers, inspect and remove cask contents and transfer contents to lag storage or next process step	2	2	2	4	3	2	5	4	20 ton	E		
4.4.3.1	Cask Unloading Cell Bridge Crane	12	Inspect cask interior, replace cask inner lid and cask unloading cell port plugs	2	2	2	4	3	2	5	4	20 ton	E		
	Cask Unloading Cell Shield Plug	10	Installed to provide shielding in cask unloading cell port	3	2	2	7	5	3	5	3	1 Port	E		
4.4.3.2	Cask Contamination Barrier	9	Removed to eliminate connection between cask top and cask unloading cell port	3	2	2	7	5	3	5	3	1 Cask	D		
	Cask Shadow Shield	11	Retracted to permit cask movement	3	2	2	7	5	3	5	3	--	D		
	Cask Cart	4	Move cask to preparation room	3	2	2	7	5	3	5	3	200 ton	D to C		

TABLE 4.45. (contd)

Function Reference Number	Equipment Title	Equipment Identification	Function/Activity	Number of Units in Module										Equipment (a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I	Size or Capacity		
4.4.3.3	Cask Service Platform	5	Support personnel during work on cask tops	3	2	2	7	5	3	5	3	--	C	
	Jib Crane	6	Remove contamination barrier adaptor	2	2	2	3	3	2	3	3	10 ton	C	
	Cask Contamination Barrier Adaptor	8	Removed from cask	9	6	6	21	15	9	15	9	1 Cask	C	
	Floor Mounted Robot	7	Remote work on cask tops	3	2	2	7	5	3	5	3	1 ton	C	
	Decontamination Station	14	Decontaminate cask	2	2	2	2	2	2	2	2	1 Cask	C	
	Bridge Crane	3	Move cask to and from decontamination station	2	2	2	3	3	2	3	2	200 ton	C	
4.4.3.4	Floor Mounted Robot	7	Remote work on cask top	3	2	2	7	5	3	5	3	1 ton	C	
	Jib Crane	6	Move cask outer lid to cask	2	2	2	3	3	2	3	3	10 ton	C	
4.4.3.5	Bridge Crane	3	Move cask to transport vehicle	2	2	2	3	2	2	3	2	200 ton	C to B	
	Onsite Drive Unit	37	Move casks and cars to support services facilities	2	2	2	2	2	2	2	2	8 Railcars	A	
	Cask Cart	4	Move cask to loading dock	3	2	2	7	5	3	5	3	200 ton	D to C	
4.4.3.6	Airlock Bridge Crane	2	Install impact limiters and cask tie-downs	2	2	2	2	2	2	2	2	5 ton	A	
	Car Puller	1	Move vehicles in waste handling buildings	3	3	3	3	3	3	3	3	10,000 lb	A,B	
4.4.4	Onsite Drive Unit	37	Move loaded vehicle to holding area	2	2	2	2	2	2	2	2	6 Railcars	A to L	
4.5	Lag Storage Covers	13	Removed and replaced when wastes are moved in and out of lag storage	6	6	6	12	12	12	15	15	--	E or G	
	Cask Unloading Cell Bridge Crane	12	Remove and replace lag storage covers, move waste in and out of lag storage	2	2	2	4	3	2	5	4	20 ton	E	
	Consolidation Cell Bridge Crane	17	Remove and replace lag storage covers, move waste in and out of lag storage	0	0	0	0	0	0	4	4	20 ton	G	

TABLE 4.45. (contd)

Function Reference Number	Equipment Title	Equipment Identification	Function/Activity	Number of Units in Module												Size or Capacity	Equipment(a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I						
4.6.1	Lag Storage Covers	13	Removed and replaced for waste removal from storage	6	6	6	12	12	12	15	15	--		E or G			
	Cask Unloading Cell Bridge Crane	12	Move wastes from transport casks or lag storage to next process operation	2	2	2	4	3	2	3	2	20 ton		E			
	Consolidation Cell Bridge Crane	17	Move wastes in consolidation cell	0	0	0	0	0	0	4	4	20 ton		G			
	Transfer Cart	15	Move spent fuel from unloading cell to consolidation cell	0	0	0	0	0	0	8	8	--		E to G			
4.6.2.1	Consolidation Equipment	19	Receive and consolidate spent fuel	0	0	0	0	0	0	4	4	--		G			
4.6.2.2	Volume-Reduction Machine	20	Receive and shred hardware from consolidation machine	0	0	0	0	0	0	4	4	--		G			
4.6.2.3	Undefined equipment for preprocessing wastes before containerizing	18	Preprocess wastes for containerizing	0	0	0	1	1	1	1	1	--		E or G			
4.6.3	Cask Unloading Cell or Packaging Cell Bridge Crane	12	Move clean containers to weld station, move waste to weld station	2	2	2	4	3	2	5	4	20 ton		E or H			
	Container Supply System	21	Move clean containers into hot cell	0	0	1	3	3	2	3	3	1 Container		E or H			
	Lag Storage Covers	13	Removed and replaced for waste removal from storage	6	6	6	12	12	12	15	15	--		E			
4.6.4.1	Container Lid Supply System	23	Supply and handle container lids in cells	0	0	1	3	3	2	3	3	1 Lid		E or H			
	Welding Module	24	Weld lids on containers	1	1	1	3	3	2	3	3	1 Container		E or H			
	Master Slave Manipulator	25	Equipment operation and maintenance	1	1	1	5	5	2	3	3	T&O		E or H			
4.6.4.2	Cask Unloading Cell or Packaging Cell Bridge Crane	12	Move container to weld inspection station	2	2	2	4	3	2	5	4	20 ton		E or H			
4.6.4.3	Weld Inspection System	27	Inspect welds	1	1	1	3	3	2	3	3	1 Container		E or H			

TABLE 4.45. (contd)

Function Reference Number	Equipment Title	Equipment Identification	Function/Activity	Number of Units in Variable										Size or Capacity	Equipment (a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I				
4.6.4.4	Cask Unloading Cell or Packaging Cell Bridge Crane	12	Move container to leak test station	2	2	2	4	3	2	5	4	20 ton	E or H		
4.6.4.5	Leak-Test Station	28	Leak-test containers	1	1	1	3	3	2	3	3	1 Container	E or H		
4.6.4.6	Cask Unloading Cell or Packaging Cell Bridge Crane	12	Move container to decontamination chamber	2	2	2	4	3	2	5	4	20 ton	E or H		
4.6.4.7	Decontamination Chamber	26	Decontaminate containers	1	1	1	3	3	2	3	3	1 Container	E or H		
4.6.4.8	Decontamination Chambers	26	Move wastes to inspection cell	1	1	1	3	3	2	3	3	1 Container	E to F		
4.6.4.9	Decontamination Chambers	26	Rotate container during swabbing	1	1	1	3	3	2	3	3	1 Container	F or H		
4.6.4.10	Cask Unloading Cell or Packaging Cell Bridge Crane	12	Move container between process stations	2	2	2	4	3	2	5	4	20 ton	E or H		
4.7.1.1	Master Slave Manipulators	25	Equipment operation and maintenance	1	1	1	5	5	2	3	3	TBD	E or H		
	Welding Module	24	Repair defective welds	1	1	1	3	3	2	3	3	1 Container	E or H		
	Inspection Cell Bridge Crane	31	Transfer containers to transfer carts	1	1	0	2	2	1	0	0	5 ton	F		
4.7.1.2	Cask Unloading Cell or Packaging Cell Bridge Crane	12	Transfer containers to transfer carts	2	2	2	4	3	2	5	4	20 ton	E or H		
	Transfer Cart	33	Receive containers	2	2	2	4	4	2	6	6	12.5 MT	I		
	Transfer Cart	33	Move containers from inspection, cask unloading, or packaging cell to waste package storage vault	2	2	2	4	4	2	6	6	12.5 MT	I		
4.7.1.3	Surface Storage Vault Entrance Port Plugs	34	Removed and replaced to permit waste transfers	4	4	2	4	4	4	4	4	1 Port	J		

TABLE 4.45. (contd)

Function Reference Number	Equipment Title	Equipment Identification	Function/Activity	Number of Units in Module										Size or Capacity	Equipment (a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I				
4.7.1.3	Container Transfer Machine	35	Remove and replace storage vault area port plugs, move containers between container transfer carts and storage positions	2	2	1	2	2	2	2	2	2	2	1 Container	J
	Vault Storage Position plugs	36	Removed and replaced to permit waste transfers	270	270	135	270	270	270	270	270	270	270	1 Port	J
4.7.3	Surface Storage Vault Entrance Port Plugs	34	Removed and replaced to permit waste transfers	4	4	2	4	4	4	4	4	4	4	1 Port	J
4.7.3	Container Transfer Machine	35	Remove and replace storage vault area port plugs, move containers between storage positions and container transfer carts	2	2	1	2	2	2	2	2	2	2	1 Container	J
	Transfer Cart	33	Receive containers	2	2	2	4	4	4	2	6	6	6	12.5 MT	I
	Vault Storage Position plugs	36	Removed and replaced to permit waste transfers	270	270	135	270	270	270	270	270	270	270	1 Port	J
4.11.1.1	Waste Transporter	58	Moved to vault building	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	1 port	J
4.11.1.2	Waste Transporter	58	Lift container out of transfer cart and into itself	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	1 port	J
	Surface Storage Vault Entrance Port Plugs	34	Removed and replaced to permit transfer of containers from cart to waste transporter	4	4	2	4	4	4	4	4	4	4	1 port	J

(a) Figures 4.70, 4.72, 4.73, 4.77, 4.78, 4.82, 4.83, 4.87, 4.88, 4.92, 4.93, 4.97, 4.98, 4.102, 4.103, 4.107 and 4.108, as appropriate for module of interest.

TABLE 4.46. Major Waste Handling Equipment for the WHBs - Listed by Equipment Item

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units in Module										Size or Capacity	Equipment(a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I				
Car Puller	1	4.2.2	Move vehicles in waste handling building	3	3	3	3	3	3	3	3	3	3	10,000 lb	A, B
		4.4.1.2	Move vehicles inside waste handling building												A, B
		4.4.3.6	Move vehicles in waste handling buildings												A, B
Airlock Bridge Crane	2	4.4.1.2	Remove impact limiters tiedowns and personnel barriers, perform radiological surveys	2	2	2	2	2	2	2	2	2	2	5 ton	A
		4.4.3.6	Install impact limiters and cask tiedowns												A
Bridge Crane	3	4.4.1.3	Move casks from vehicles to cask carts	2	2	2	3	2	2	2	3	2	2	200 ton	B to C
		4.4.3.3	Move cask to and from decontamination station												C
Cask Cart	4	4.4.3.5	Move cask to transport vehicle												C to B
		4.4.1.3	Receive cask and carry it to cask handling room	3	2	2	7	5	3	5	3	5	3	200 ton	C
		4.4.1.7	Move cask to unloading room												C to D
		4.4.3.2	Move cask to preparation room												D to C
Cask Service Platform	5	4.4.3.5	Move cask to loading dock												
		4.4.1.4	Support personnel during work on cask tops	3	2	2	7	5	3	5	3	5	3	--	C
		4.4.3.3	Support personnel during work on cask tops												C
Jib Crane	6	4.4.1.4	Move cask outer lid to service pad	2	2	2	3	3	2	3	3	3	3	10 ton	C
		4.4.1.6	Install contamination barrier adaptor												C
		4.4.3.3	Remove contamination barrier adaptor												C
		4.4.3.4	Move cask outer lid to cask												C

TABLE 4.46. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units in Module											Size or Capacity	Equipment (a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I					
Floor-Mounted Robot	7	4.4.1.4	Remote work on cask tops	3	2	2	7	5	3	5	3	1	ton	C		
		4.4.1.5	Remote work on cask tops											C		
		4.4.3.3	Remote work on cask tops											C		
		4.4.3.4	Remote work on cask tops											C		
Cask Contamination Barrier Adaptor	8	4.4.1.6	Installed to provide connection between cask top and cask contamination barrier	9	6	6	21	21	9	15	9	1	cask	C		
		4.4.3.3	Removed from cask											C		
Cask Contamination Barrier	9	4.4.1.7	Install to provide connection between cask top and process cell port	3	2	2	7	5	3	5	3	1	cask	D		
		4.4.3.2	Remove to eliminate connection between cask top and cask unloading cell port											D		
Cask Unloading Cell Shield Plug	10	4.4.1.8	Provide shielding in cask unloading cell port. Remove to permit cask unloading	3	2	2	7	5	3	5	3	1	port	E		
		4.4.3.1	Installed to provide shielding in cask unloading cell port											E		
Cask Shadow Shield	11	4.4.1.7	Installed to shield preparation area when cask unloading cell port plug is out	3	2	2	7	5	3	5	3	--		D		
		4.4.2	Shields preparation area when cask unloading cell port plug is out											D		
Cask Unloading Cell or Packaging Cell Bridge Crane	12	4.4.3.2	Retracted to permit cask movement											D		
		4.4.1.8	Remove cask unloading cell port plugs, remove cask inner lid	2	2	2	4	3	2	5	4	20 ton	E			
		4.4.2	Remove and replace lag storage covers, inspect and remove cask contents and transfer contents to lag storage or next process step											E		

TABLE 4.46. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units in Module											Size or Capacity	Equipment (a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I					
Cask Unloading Cell or Packaging Cell Bridge Crane (contd)	12	4.4.3.1	Inspect cask interior, replace cask inner lid and cask unloading cell port plugs	2	2	2	4	3	2	5	4	20 ton	E			
		4.5	Remove and replace lag storage covers, move waste in and out of lag storage											E		
		4.6.1	Move wastes from transport casks or lag storage to next process operation											E		
		4.6.3	Move clean containers to weld station, move waste to weld station											E or H		
		4.6.4.2	Move container to weld inspection station											E or H		
		4.6.4.4	Move container to leak test station											E or H		
		4.6.4.6	Move container to decontamination chamber											E or H		
		4.6.4.10	Move container between process stations											E or H		
		4.7.1.1	Transfer containers to transfer carts											E or H		
		4.4.2	Ventilation cover on lag storage, removed and replaced during waste transfers into storage	6	6	6	12	12	12	15	15	--	E or G			
Lag Storage Covers	13	4.5	Removed and replaced when wastes are moved in and out of lag storage										E or G			
		4.6.1	Removed and replaced when wastes are moved in and out of lag storage										E or G			
		4.6.3	Removed and replaced for waste removal from storage										E or G			
		4.4.3.3	Decontaminate cask	2	2	2	2	2	2	2	2	2	1 Cask	C		
Decontamination Station	14															

TABLE 4.46. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units in Module										Size or Capacity	Equipment (a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I				
Transfer Cart	15	4.6.1	Move spent fuel from unloading cell to consolidation cell	0	0	0	0	0	0	0	4	4	--	E to G	
Consolidation Cell Bridge Crane	17	4.5	Remove and replace lag storage covers, move waste in and out of lag storage	0	0	0	0	0	0	0	4	4	20 ton	G	
		4.6.1	Move wastes in consolidation cell												
Undefined Equipment for Preprocessing Wastes before Containerizing	18	4.6.2.3	Preprocess wastes for containerization	0	0	0	0	0	1	1	1	1	--	E or G	
Consolidation Equipment	19	4.6.2.1	Receive and consolidate spent fuel	0	0	0	0	0	0	0	4	4	--	G	
Volume-Reduction Machine	20	4.6.2.2	Receive and shred hardware from consolidation machine	0	0	0	0	0	0	0	4	4	--	G	
Container Supply System	21	4.6.3	Move clean containers into hot cell	0	0	1	3	3	2	3	3	3	1 Container	E or H	
Container Lid Supply System	23	4.6.4.1	Supply and handle container lids in cells	0	0	1	3	3	2	3	3	3	1 Lid	E or H	
Welding Module	24	4.6.4.1	Weld lids on containers	1	1	1	3	3	2	3	3	3	1 Container	E or H	
		4.6.4.10	Repair defective welds											E	
Master Slave Manipulator	25	4.6.4.1	Equipment operation and maintenance	1	1	1	5	5	2	3	3	3	TBD	E or H	
		4.6.4.10	Equipment operation and maintenance											E or H	
Decontamination Chamber	26	4.6.4.7	Decontaminate containers	1	1	1	3	3	2	3	3	3	1 Container	E or H	
		4.6.4.8	Move wastes to inspection cell											E to F	
		4.6.4.9	Rotate container during swabbing											F or H	
Weld Inspection System	27	4.6.4.3	Inspect welds	1	1	1	3	3	2	3	3	3	1 Container	E or H	
Leak-Test Station	28	4.6.4.5	Leak-test containers	1	1	1	3	3	2	3	3	3	1 Container	E or H	

TABLE 4.46. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units in Module										Size or Capacity	Equipment (a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I	M4J	M4K		
Inspection Cell Bridge Crane	31	4.7.1.1	Transfer containers to transfer carts	1	1	0	2	2	1	0	0	0	5	ton	F
Transfer Cart	33	4.7.1.1	Receive containers	2	2	2	4	4	2	6	6	12.5	MT		I
		4.7.1.2	Move containers from inspection, cask unloading or packaging cell to waste package storage vault												I
		4.7.3	Receive containers												I
Surface Storage Vault Entrance Port Plugs	34	4.7.1.3	Removed and replaced to permit waste transfers	4	4	2	4	4	4	4	4	4	1	Foot	J
		4.7.3	Remove and replace to permit waste transfers												J
		4.11.1.2	Removed and replaced to permit transfer of containers from cask to waste transporter												J
Container Transfer Machine	35	4.7.1.3	Remove and replace storage vault area port plugs, move containers between container transfer carts and storage positions	2	2	1	2	2	2	2	2	2	1	Container	J
		4.7.3	Remove and replace storage vault area port plugs, move containers between storage positions and container transfer carts												J
Vault Storage Position plugs	36	4.7.1.3	Removed and replaced to permit waste transfers	270	270	135	270	270	270	270	270	270	1	Port	J
		4.7.3	Removed and replaced to permit waste transfers												J
Onsite Drive Unit	37	4.1	Connect to train cars	2	2	2	2	2	2	2	2	2	8	Railcars	L
		4.2.1	Move train cars to holding area												L
		4.2.2	Move casks and cars to dispatch holding area												A to L
		4.2.2	Make up shipment train												L

TABLE 4.46. (contd)

Equipment Title	Equipment Identification	Function Reference Number	Function/Activity	Number of Units in Module							Size or Capacity	Equipment ^(a) Locations
				M4B	M4C	M4D	M4E	M4F	M4G	M4H	M4I	
		4.4.1.1	Move casks and cars to washdown area									L to A
		4.4.3.5	Move casks and cars to support services facilities									A
		4.4.4	Move loaded vehicle to holding area									A to L
Waste Transporter	58	4.11.1.1	Moved to vault building	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	J
		4.11.1.2	Lift container out of transfer cart and into itself									

(a) Figures 4.70, 4.72, 4.73, 4.77, 4.78, 4.82, 4.83, 4.87, 4.88, 4.92, 4.93, 4.97, 4.98, 4.102, 4.103, 4.107, and 4.108, as appropriate for module of interest.

FIGURE 4.76. Conceptual Schematic Process Flow Diagram for the WHB

89101002.1b

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.47, and 4.48.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letter in diamonds identify building support facilities.

FIGURE 4.77. General Plan View of the Module 4C WHB Main Floor

unloading ports. Table 4.47 lists the approximate process area dimensions and location keys that indicate where (on Figures 4.77 and 4.78) the various functions are located in the WHB.

The WHB contains a number of support facilities necessary for safe and efficient performance of its operations. These support facilities and their location keys are listed in Table 4.48.

The WHB facilities needed for each of the repository functional activities are described in the following subsections. The activities themselves are described in the functional description section of this document. The locations of these activities in the WHB are shown in Figures 4.77 and 4.78 as circles containing the functional activity numbers.

Function 4.1 - Transport Cask Receipt. Cask receipt occurs at the waste receiving and inspection area where the railroad lines enter the facility (area L in Figure 4.70).

50101032.1a

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.47, and 4.48.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letter in diamonds identify building support facilities.

FIGURE 4.78. General Plan View of the Module 4C WHB Basement

TABLE 4.47. Module 4C WHB Process Room Dimensions

Process Room	Approximate Dimension (feet)			Location Symbol ^(a)
	Length	Width	Height	
Air Control Vestibules	140	35	27	A
Receiving and Shipping Area	165	35	75	B
Cask Preparation Area	165	25	100	C
Cask Unloading Rooms	64	40	30	D
Cask Unloading Hot Cell	200	40	40	E
Inspection Cell	64	33	40	F
Waste Transfer Tunnel	137	23	23	I
Surface Storage Vault	224	81	55	J

(a) Letter symbol indicates location on Figures 4.77 and 4.78.

TABLE 4.48. Module 4C WHB Process Support Facilities

<u>Facility</u>	<u>Function</u>	<u>Location Key(a)</u>	
		<u>Building Floor</u>	<u>Symbol</u>
Material Receiving	Receive and store nonradioactive material	1	J
Operations Support	Operating gallery, weld power supply	1	O
Maintenance	Maintenance shops and storage	Basement	P
Air Conditioning and Exhaust Treatment	Air purification, distribution	2	R
Personnel Annex	Administrative offices, change rooms, training facilities, auditorium	1	S
Container Storage and Transfer	Store clean empty container and transfer to waste transfer tunnel	1	T

(a) Symbol indicates location on Figures 4.77 and 4.78.

Function 4.2 - Cask and Vehicle Holding Area. Lag storage of the casks occurs on one of the railcar parking lines at the waste receiving and inspection area (area L in Figure 4.70).

Function 4.3 - Cask Preshipment Inspection and Servicing. The routine cask servicing occurs in the cask receipt area described above and uses the same equipment as is used for cask receipt.

Function 4.4 - Transport Cask Unloading. The cask receiving facilities in the WHB are illustrated schematically in Figure 4.79, and the general location is shown in Figure 4.77. The casks are received at the receiving, inspection, and shipping area. This area has facilities and equipment for receiving trucks and railroad cars transporting loaded casks, removing those casks from those vehicles, placing the casks on transfer carts, and reversing these procedures for placing casks back onto the vehicles.

This large unshielded receiving and shipping area contains railroad tracks, extending the full length of the area. Large doors near the center of the area create airlocks at the outer ends so that vehicles can enter and leave without compromising the controlled ventilation system. Overhead

bridge cranes have capacity for lifting the transport casks and transporting them to the transfer carts in the cask preparation area at the side of the receiving and shipping area.

Cask unloading occurs in the cask preparation area, the cask transfer tunnels, and the cask unloading hot cells (see Figures 4.76 and 4.79). The unloading facilities have equipment for transporting the casks from the preparation area to rooms under the cask unloading cells, preparing the casks for unloading, connecting the casks to the cask unloading cells, and reversing those processes to return the casks to the cask preparation area. With the casks sitting in rooms under the cask unloading cells, the contents are lifted out of the casks through ports in the room ceilings into the cells by the unloading cell bridge cranes.

FIGURE 4.79. Typical WHB Cask Receiving Facilities

The cask preparation area and cask transfer tunnels have a set of cart tracks for each unloading port in the unloading cells and a transfer cart for each set of tracks. Ventilation doors separate the cask preparation area from the cask transfer tunnels, and shadow shields attached to the roof of the transfer tunnels can be lowered to provide radiation shielding between the open unloading cell entry ports and the cask preparation area. The preparation room contains movable work platforms for personnel working on the cask tops. Jib cranes in the cask preparation area are used for removing and replacing the cask outer lids, and robots are used for routine operations such as loosening and tightening bolts.

The cask unloading hot cells have overhead bridge cranes that remove and replace the hot cell port plugs, remove and replace the cask inner lids, lift the wastes out of the casks, and transport the wastes inside the cells. The cells also are equipped for storage of the waste materials, inspecting containers, cutting lids off containers, welding lids on containers, and placing the containers on transfer carts in a transfer tunnel to the surface storage vault area.

Function 4.5 - Waste Lag Storage. The cask unloading cell lag storage is illustrated in Figure 4.80 and the location is shown in Figure 4.77. The facilities are of modular construction with capacity for one shipment of waste containers.

Function 4.6 - Waste Processing. The unloading and inspection hot cells contain several processing stations such as leak-test stations, welding stations, weld inspection stations, canister inspection stations, container inspection stations, container decontamination stations, and fuel inspection stations. These are listed below in Section 4.4.3.2. This equipment has not been designed.

Representative containers are illustrated in Figure 4.2.

Function 4.7 - Container Vault Storage. A separate surface storage vault provides lag storage between the hot cell operations and the waste emplacement. The wastes are transported from the cask unloading hot cells to the vault by transfer carts in the waste transfer tunnels. A shielded transfer machine transfers the wastes between the transfer carts, the vault

FIGURE 4.80. Cask Unloading Cell Lag Storage

storage areas, and the out-transfer station, where the canisters of wastes are loaded into the waste transporter cask (see Figure 4.76).

4.4.3.2 Level 2 Physical Description for Pass-Through WHB-1 for Containerized Consolidated SFAs (Module 4C)

The pass-through WHB-1 for containerized, consolidated fuel is scheduled to receive and process 3000 MTU of SNF and 400 MTU equivalent of HLW from the MRS facility per year. It will operate 24 hours per day, 5 days per week and 250 days per year for all primary functions (unloading shipments and processing wastes). Shipments will be accepted 7 days per week, 365 days per year.

Table 4.44 contains general descriptions of the waste packages handled by this module, including information on locations in the facilities.

The major process equipment needed for the waste handling is listed in Table 4.45. This table contains the functional description reference numbers, equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information. The equipment is listed in this table by functional description reference number. Table 4.46

lists the information in Table 4.45 by equipment item to show the number of functions for which each equipment item is used.

4.4.4 Low-Volume Intact Fuel WHB-1 (Module 4D)

The primary purposes of this module are to receive 400 MTU of intact spent fuel or HLW from the waste generators or MRS facility, unload those wastes from the transport casks, and place those wastes in repository containers. This module would first receive only intact fuel for several years until a WHB-2 (Module 4H or 4I) starts operating. Then, this WHB-1 would be decontaminated and used subsequently for receiving and containerizing HLW.

4.4.4.1 Level 1 Physical Description for Low-Volume WHB-1 (Module 4D)

Figure 4.81 presents a typical schematic process flow diagram for the WHB. Figures 4.82 and 4.83 present general floor plans for the building. The primary process areas are a receiving, inspection, and shipping area; a cask preparation area; a cask unloading hot cell; a container transfer tunnel; and a surface storage vault. The unloading cell contains two cask unloading ports. In addition to these basic process areas, rooms for supporting activities, storage space, and corridors are provided. Table 4.49 lists the approximate process area dimensions and location keys that indicate where (on Figures 4.82 and 4.83) the various functions are located in the WHB.

The WHB contains a number of support facilities necessary for safe and efficient performance of its operations. These support facilities and their location keys are listed in Table 4.50.

The WHB facilities needed for each of the repository functional activities are described in the following subsections. The activities themselves are described in the functional description section of this document. The locations of these activities in the WHB are shown in Figures 4.82 and 4.83 as circles containing the functional activity numbers.

FIGURE 4.81. Conceptual Schematic Process Flow Diagram for the WHB

S9101032.3b

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.49, and 4.50.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.82. General Plan View of the Module 4D WHB Main Floor

S9101032.3a

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.49, and 4.50.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.83. General Plan View of the Module 4D WHB Basement

TABLE 4.49. Module 4D WHB Process Room Dimensions

Process Room	Approximate Dimension (feet)			Location Symbol (a)
	Length	Width	Height	
Air-Control Vestibules	98	80	25	A
Receiving and Shipping Area	98	75	75	B
Cask Preparation Area	98	25	100	C
Cask Unloading Rooms	64	40	30	D
Cask Unloading Hot Cell	168	40	40	E
Waste Transfer Tunnel	171	23	25	I
Surface Storage Vault	143	81	55	J

(a) Letter symbol indicates location on Figures 4.82 and 4.83.

TABLE 4.50. Module 4D WHB Process Support Facilities

Facility	Function	Location Key(a)	
		Building Floor	Symbol
Material Receiving	Receive and store nonradioactive material	1	J
Operations Support	Operating gallery, weld power supply	1	O
Maintenance	Maintenance shops and storage	Basement	P
Air Conditioning and Exhaust Treatment	Air purification, distribution	2	R
Personnel Annex	Administrative offices, change rooms, training facilities, auditorium	1	S
Container Storage and Transfer	Store clean empty container and transfer to waste transfer tunnel	1	T

(a) Symbol indicates location on Figures 4.82 and 4.83.

Function 4.1 - Transport Cask Receipt. Cask receipt occurs at the waste receiving and inspection area where the railroad lines enter the facility (area L in Figure 4.70).

Function 4.2 - Transport Cask Lag Storage. Lag storage of the casks occurs on one of the railcar parking lines at the waste receiving and inspection area (area L in Figure 4.70).

Function 4.3 - Cask Preshipment Inspection and Servicing. The routine cask servicing occurs in the cask receipt area described above and uses the same equipment as is used for cask receipt.

Function 4.4 - Transport Cask Unloading. The cask receiving facilities in the WHB are illustrated schematically in Figure 4.84 and the general location is shown in Figure 4.82. The casks are received at the receiving, inspection, and shipping area. This area has facilities and equipment for receiving trucks and railroad cars transporting loaded casks, removing those casks from those vehicles, placing the casks on transfer carts, and reversing these procedures for placing casks back onto the vehicles.

FIGURE 4.84. Typical WHB Cask Receiving Facilities

This large unshielded receiving and shipping area contains railroad tracks, extending the full length of the area. Large doors near the center of the area create airlocks at the outer ends so that vehicles can enter and leave without compromising the controlled ventilation system. Overhead bridge cranes have capacity for lifting the transport casks and transporting them to the transfer carts in the cask preparation area at the side of the receiving and shipping area.

Cask unloading occurs in the cask preparation area, the cask transfer tunnels, and the cask unloading hot cells (see Figures 4.81 and 4.84). The unloading facilities have equipment for transporting the casks from the preparation area to rooms under the cask unloading cells, preparing the casks for unloading, connecting the casks to the cask unloading cells, and reversing those processes to return the casks to the cask preparation area. With the casks sitting in rooms under the cask unloading cells, the contents are lifted out of the casks through ports in the room ceilings into the cells by the unloading cell bridge cranes.

The cask preparation area and cask transfer tunnels have a set of cart tracks for each unloading port in the unloading cells and a transfer cart for each set of tracks. Ventilation doors separate the cask preparation area from the cask transfer tunnels, and shadow shields attached to the roof of the transfer tunnels can be lowered to provide radiation shielding between the open unloading cell entry ports and the cask preparation area. The preparation room contains movable work platforms for personnel working on the cask tops. Jib cranes in the cask preparation area are used for removing and replacing the cask outer lids, and robots are used for routine operations such as loosening and tightening bolts.

The cask unloading hot cells have overhead bridge cranes that remove and replace the hot cell port plugs, remove and replace the cask inner lids, lift the wastes out of the casks, and transport the wastes inside the cells. The cells also are equipped for storage of the waste materials, inspecting containers, cutting lids off containers, welding lids on containers, and placing the containers on transfer carts in a transfer tunnel to the surface storage vault area.

Function 4.5 - Waste Lag Storage. The cask unloading cell lag storage is illustrated in Figure 4.85 and the location is shown in Figure 4.82. The facilities are of modular construction with capacity for one shipment of waste containers.

Function 4.6 - Waste Processing. The unloading and inspection hot cells contain several processing stations such as leak-test stations, welding stations, weld inspection stations, canister inspection stations, container inspection stations, container decontamination stations, and fuel inspection stations. These are listed below in Section 4.4.4.2. This equipment has not been designed.

Representative containers are illustrated in Figure 4.2.

Function 4.7 - Container Vault Storage. A separate surface storage vault provides lag storage between the hot cell operations and the waste emplacement. The wastes are transported from the cask unloading hot cells to the vault by transfer carts in the waste transfer tunnels. A shielded transfer machine transfers the wastes between the transfer carts, the vault

FIGURE 4.85. Cask Unloading Cell Lag Storage

storage areas, and the out-transfer station, where the canisters of wastes are loaded into the waste transporter cask (see Figure 4.81).

4.4.4.2 Level 2 Physical Description for Low-Volume WHB-1 (Module 4D)

The low-volume intact fuel WHB is scheduled to receive and process 400 MTU of SNF from the reactors during the first phase of its operations and 400 MTU equivalent of HLW per year during the second phase. It will operate 24 hours per day, 5 days per week and 250 days per year for all primary functions (unloading shipments and processing wastes). Shipments will be accepted 7 days per week, 365 days per year.

Table 4.44 contains general descriptions of the waste packages handled by this module, including information on locations in the facilities.

The major process equipment needed for the waste handling is listed in Table 4.45. This table contains the functional description reference numbers, equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information. The equipment is

listed in this table by functional description reference number. Table 4.46 lists the information in Table 4.45 by equipment item to show the number of functions for which each equipment item is used.

4.4.5 Intact Fuel WHB-1 Without an MRS (Module 4E)

The primary purposes of this module are to receive 3400 MTU/yr of intact fuel, or HLW, from the waste generators, unload those wastes from the transport casks and place those wastes in repository containers.

4.4.5.1 Level 1 Physical Description for Intact Fuel WHB-1 Without an MRS (Module 4E)

Figure 4.86 presents a typical schematic process flow diagram for the WHB. Figures 4.87 and 4.88 present simplified general floor plans for the building.

The primary process areas are a receiving, inspection, and shipping area; a cask preparation area; two cask unloading hot cells; two inspection cells; two container transfer tunnels; and a surface storage vault. The cask unloading cells contain seven cask unloading ports. In addition to these basic process areas, rooms for supporting activities, storage space, and corridors are provided. Table 4.51 lists the approximate process area dimensions and location keys that indicate where (on Figures 4.87 and 4.88) the various functions are located in the WHB.

The WHB contains a number of support facilities necessary for safe and efficient performance of its operations. These support facilities and their location keys are listed in Table 4.52.

The WHB facilities needed for each of the repository functional activities are described in the following subsections. The activities themselves are described in the functional description section of this document. The locations of these activities in the WHB are shown in Figures 4.87 and 4.88 as circles containing the functional activity numbers.

Function 4.1 - Transport Cask Receipt. Cask receipt occurs at the waste receiving and inspection area where the railroad lines enter the facility (area L in 4.70).

FIGURE 4.86. Conceptual Schematic Process Flow Diagram for the WHB

S9002095.17

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.51, and 4.52.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.87. General Plan View of the Module 4E WHB Main Floor

Function 4.2 - Transport Cask Lag Storage. Lag storage of the casks occurs on one of the railcar parking lines at the waste receiving and inspection area (area L in Figure 4.70).

Function 4.3 - Cask Preshipment Inspection and Servicing. The routine cask servicing occurs in the cask receipt area described above and uses the same equipment as is used for cask receipt.

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.51, and 4.52.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.88. General Plan View of the Module 4E WHB Basement

Function 4.4 - Transport. The cask receiving facilities in the WHB are illustrated schematically in Figure 4.89 and the general location is shown in Figure 4.87. The casks are received at the receiving, inspection, and shipping area. This area has facilities and equipment for receiving trucks and railroad cars transporting loaded casks, removing those casks from those vehicles, placing the casks on transfer carts, and reversing these procedures for placing casks back onto the vehicles.

This large unshielded receiving and shipping area contains railroad tracks, extending the full length of the area. Large doors near the center of the area create airlocks at the outer ends so that vehicles can enter and leave without compromising the controlled ventilation system. Overhead bridge cranes have capacity for lifting the transport casks and transporting them to the transfer carts in the cask preparation area at the side of the receiving and shipping area.

TABLE 4.51. Module 4E WHB Process Room Dimensions

<u>Process Room</u>	<u>Approximate Dimension (feet)</u>			<u>Location Symbol (a)</u>
	<u>Length</u>	<u>Width</u>	<u>Height</u>	
Air-Control Vestibules	452	80	25	A
Receiving and Shipping Area	452	75	75	B
Cask Preparation Area	452	25	100	C
Cask Unloading Rooms	64 + 160	40	30	D
Cask Unloading Hot Cell	159 + 353	40	40	E
Inspection Cell	42 + 64	33	40	F
Waste Transfer Tunnel	137	23	23	I
Surface Storage Vault	286	81	55	J

(a) Letter symbol indicates location on Figures 4.87 and 4.88.

Cask unloading occurs in the cask preparation area, the cask transfer tunnels, and the cask unloading hot cells (see Figures 4.86 and 4.89). The unloading facilities have equipment for transporting the casks from the preparation area to rooms under the cask unloading cells, preparing the casks for unloading, connecting the casks to the cask unloading cells, and reversing those processes to return the casks to the cask preparation area. With the casks sitting in rooms under the cask unloading cells, the contents are lifted out of the casks through ports in the room ceilings into the cells by the unloading cell bridge cranes.

The cask preparation area and cask transfer tunnels have a set of cart tracks for each unloading port in the unloading cells and a transfer cart for each set of tracks. Ventilation doors separate the cask preparation area from the cask transfer tunnels, and shadow shields attached to the roof of

TABLE 4.52. Module 4E WHB Process Support Facilities.

Facility	Function	Location Key(a)	
		Building Floor	Symbol
Material Receiving	Receive and store nonradioactive material	1	J
Operations Support	Operating gallery, weld power supply	1	O
Maintenance	Maintenance shops and storage	Basement	P
Air Conditioning and Exhaust Treatment	Air purification, distribution	2	R
Personnel Annex	Administrative offices, change rooms, training facilities, auditorium	1	S
Container Storage and Transfer	Store clean empty container and transfer to waste transfer tunnel	1	T

(a) Symbol indicates location on Figures 4.87 and 4.88.

FIGURE 4.89. Typical WHB Cask Receiving Facilities

the transfer tunnels can be lowered to provide radiation shielding between the open unloading cell entry ports and the cask preparation area. The preparation room contains movable work platforms for personnel working on the cask tops. Jib cranes in the cask preparation area are used for removing and replacing the cask outer lids, and robots are used for routine operations such as loosening and tightening bolts.

The cask unloading hot cells have overhead bridge cranes that remove and replace the hot cell port plugs, remove and replace the cask inner lids, lift the wastes out of the casks, and transport the wastes inside the cells. The cells also are equipped for storage of the waste materials, inspecting containers, cutting lids off containers, welding lids on containers and placing the containers on transfer carts in a transfer tunnel to the surface storage vault area.

Function 4.5 - Waste Lag Storage. The cask unloading cell lag storage is illustrated in Figure 4.90 and the location is shown in Figure 4.87. The facilities are of modular construction with capacity for one shipment of waste containers.

Function 4.6 - Waste Processing. The unloading and inspection hot cells contain several processing stations such as leak-test stations, welding stations, weld inspection stations, canister inspection stations, container inspection stations, container decontamination stations, and fuel inspection stations. These are listed below in Section 4.4.5.2. This equipment has not been designed.

Representative containers are illustrated in Figure 4.2.

Function 4.7 - Container Vault Storage. A separate surface storage vault provides lag storage between the hot cell operations and the waste emplacement. The wastes are transported from the inspection hot cells to the vault by transfer carts in the waste transfer tunnels. A shielded transfer machine transfers the wastes between the transfer carts, the vault storage areas, and the out-transfer station, where the canisters of wastes are loaded into the waste transporter cask (see Figure 4.86).

FIGURE 4.90. Cask Unloading Cell Lag Storage

4.4.5.2 Level 2 Physical Description for Intact Fuel WHB-1 Without an MRS (Module 4E)

The high-throughput intact fuel WHB-1 is scheduled to receive and process 3000 MTU of SNF from the reactors and 400 MTU equivalent of HLW per year. It will operate 24 hours per day, 5 days per week and 250 days per year for all primary functions (unloading shipments and processing wastes). Shipments will be accepted 7 days per week, 365 days per year.

Table 4.44 contains general descriptions of the waste packages handled by this module, including information on locations in the facilities.

The major process equipment needed for the waste handling is listed in Table 4.45. This table contains the functional description reference numbers, equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information. The equipment is listed in this table by functional description reference number. Table 4.46

lists the information in Table 4.45 by equipment item to show the number of functions for which each equipment item is used.

4.4.6 Intact Fuel WHB-1 with an MRS (Module 4F)

The primary purposes of this module are to receive 3000 MTU per year of intact fuel (primarily from the MRS) and 400 MTU per year of HLW, unload these wastes from the transport casks, and place them in repository containers.

4.4.6.1 Level 1 Physical Description for Intact Fuel WHB-1 with an MRS (Module 4F)

Figure 4.91 presents a typical schematic process flow diagram for this WHB that illustrates its primary functions. Figures 4.92 and 4.93 present simplified floor plans for the building.

The general process areas are the receiving, inspection, and shipping area; the cask preparation area; two cask unloading hot cells; two inspection cells; two container transfer tunnels; and the surface storage vault. The two unloading hot cells contain five cask unloading ports (two in one cell for HLW and three in the other cell for intact fuel). Table 4.53 lists the approximate process area dimensions and location keys that indicate where (on Figures 4.92 and 4.93) the various functions are located in the WHB.

The WHB contains a number of support facilities necessary for safe and efficient performance of its operations. These support facilities and their location keys are listed in Table 4.54.

The WHB facilities needed for each of the repository functional activities are described in the following subsections. The activities are described in the functional description section of this document. The locations of these activities in the WHB are shown in Figures 4.92 and 4.93 as circles containing the functional activity numbers.

Function 4.1 - Transport Cask Receipt. Cask receipt occurs at the waste receiving and inspection area where the railroad lines enter the facility (area L in Figure 4.70).

FIGURE 4.91. Conceptual Schematic Process Flow Diagram for the WHB

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.53, and 4.54.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.92. General Plan View of the Module 4F WHB Main Floor

Function 4.2 - Transport Cask Lag Storage. Lag storage of the casks occurs on one of the railcar parking lines at the waste receiving and inspection area (area L in Figure 4.70).

Function 4.3 - Cask Preshipment Inspection and Servicing. The routine cask servicing occurs in the cask receipt area described above and uses the same equipment as is used for cask receipt.

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.53, and 4.54.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.93. General Plan View of the Module 4F WHB Basement

Function 4.4 - Transport Cask Unloading. The cask receiving facilities in the WHB are illustrated schematically in Figure 4.94 and the general location is shown in Figure 4.92. The casks are received at the receiving, inspection, and shipping area. This area has facilities and equipment for receiving trucks and railroad cars transporting loaded casks, removing those casks from those vehicles, placing the casks on transfer carts, and reversing these procedures for placing casks back onto the vehicles.

This large unshielded receiving and shipping area contains railroad tracks, extending the full length of the area. Large doors near the center of the area create airlocks at the outer ends so that vehicles can enter and leave without compromising the controlled ventilation system. Overhead bridge cranes have capacity for lifting the transport casks and transporting them to the transfer carts in the cask preparation area at the side of the receiving and shipping area.

TABLE 4.53. Module 4F WHB Process Room Dimensions

<u>Process Room</u>	<u>Approximate Dimension (feet)</u>			<u>Location Symbol (a)</u>
	<u>Length</u>	<u>Width</u>	<u>Height</u>	
Air-Control Vestibule	373	80	25	A
Receiving and Shipping Area	373	75	75	B
Cask Preparation Area	373	25	100	C
Cask Unloading Rooms	64 + 96	40	30	D
Cask Unloading Hot Cell	159 + 274	40	40	E
Inspection Cell	42 + 64	33	40	F
Waste Transfer Tunnel	137	23	23	I
Surface Storage Vault	286	81	55	J

(a) Letter symbol indicates location on Figure 4.92 and 4.93.

Cask unloading occurs in the cask preparation area, the cask transfer tunnels and the cask unloading hot cells (see Figures 4.91 and 4.94). The unloading facilities have equipment for transporting the casks from the preparation area to rooms under the cask unloading cells, preparing the casks for unloading, connecting the casks to the cask unloading cells, and reversing those processes to return the casks to the cask preparation area. With the casks sitting in rooms under the cask unloading cells, the contents are lifted out of the casks through ports in the room ceilings into the cells by the unloading cell bridge cranes.

TABLE 4.54. Module 4F WHB Process Support Facilities

Facility	Function	Location Key(a)	
		Building Floor	Symbol
Material Receiving	Receive and store nonradioactive material	1	J
Operations Support	Operating gallery, weld power supply	1	O
Maintenance	Maintenance shops and storage	Basement	P
Air Conditioning and Exhaust Treatment	Air purification, distribution	2	R
Personnel Annex	Administrative offices, change rooms, training facilities, auditorium	1	S
Container Storage and Transfer	Store clean empty container and transfer to waste transfer tunnel	1	T

(a) Symbol indicates location on Figures 4.92 and 4.93.

The cask preparation area and cask transfer tunnels have a set of cart tracks for each unloading port in the unloading cells and a transfer cart for each set of tracks. Ventilation doors separate the cask preparation area from the cask transfer tunnels, and shadow shields attached to the roof of the transfer tunnels can be lowered to provide radiation shielding between the open unloading cell entry ports and the cask preparation area. The preparation room contains moveable work platforms for personnel working on the cask tops. Jib cranes in the cask preparation area are used for removing and replacing the cask outer lids, and robots are used for routine operations such as loosening and tightening bolts.

The cask unloading hot cells have overhead bridge cranes that remove and replace the hot cell port plugs, remove and replace the cask inner lids, lift the wastes out of the casks, and transport the wastes inside the cells. The cells also are equipped for storage of the waste materials, inspecting containers, cutting lids off containers, welding lids on containers and placing the containers on transfer carts in a transfer tunnel to the surface storage vault area.

FIGURE 4.94. Typical WHB Cask Receiving Facilities

Function 4.6 - Waste Lag Storage. The cask unloading cell lag storage is illustrated in Figure 4.95 and the location is shown in Figure 4.92. The facilities are of modular construction with capacity for one shipment of waste containers.

Function 4.6 - Waste Processing. The unloading and inspection hot cells contain several processing stations such as leak-test stations, welding stations, weld inspection stations, canister inspection stations, container inspection stations, container decontamination stations, and fuel inspection stations. These are listed below in Section 4.4.6.2. This equipment has not been designed.

Representative containers are illustrated in Figure 4.2.

FIGURE 4.95. Cask Unloading Cell Lag Storage

Function 4.7 - Container Vault Storage. A separate surface storage vault provides lag storage between the hot cell operations and the waste emplacement. The wastes are transported from the inspection hot cells to the vault by transfer carts in the waste transfer tunnels. A shielded transfer machine transfers the wastes between the transfer carts, the vault storage areas, and the out-transfer station, where the canisters of wastes are loaded into the waste transporter cask (see Figure 4.91).

4.4.6.2 Level 2 Physical Description for Intact Fuel WHB-1 with an MRS (Module 4F)

This intact fuel WHB-1 is scheduled to receive and handle 3000 MTU of SNF from the reactors and MRS and 400 MTU equivalent of HLW per year. It will operate 24 hours per day, 5 days per week and 250 days per year for all primary functions (unloading shipments, processing wastes, and loading waste transporters). Shipments will be accepted 7 days per week, 365 days per year.

Table 4.44 contains general descriptions of the waste packages handled by this WHB.

The major process equipment needed for the waste handling is listed in Table 4.45. This table contains the functional description reference numbers, equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information. The equipment is listed in this table by functional description reference number. Table 4.46 lists the information in Table 4.45 by equipment item to show the number of functions for which each equipment item is used.

4.4.7 The WHB-1 for Containerizing Canistered Wastes (Module 4G)

The primary purposes of this module are to receive 3100 MTU/yr of canistered wastes from the MRS and the reprocessing plants, receive 300 MTU/yr of wastes from nearby reactor plants, unload these wastes from the transport casks, and place them in repository containers.

4.4.7.1 Level 1 Physical Description for WHB-1 for Containerizing Canistered Wastes (Module 4G)

Figure 4.96 presents a typical schematic process flow diagram for the WHB that illustrates its primary functions. Figures 4.97 and 4.98 present simplified floor plans for the building.

The general process areas are the receiving, inspection, and shipping area; the cask preparation area; two cask unloading hot cells; an inspection cell; a container transfer tunnel; and the surface storage vault. The cask unloading hot cells contain three cask unloading ports (one in one cell for intact fuel and two in the other cell for canistered wastes). Table 4.55 lists the approximate process area dimensions and location keys that indicate where (on Figures 4.97 and 4.98) the various functions are located in the WHB.

FIGURE 4.96. Conceptual Schematic Process Flow Diagram for the WHB

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.55, and 4.56.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.97. General Plan View of the Module 4G WHB Main Floor

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.55, and 4.56.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.98. General Plan View of the Module 4G WHB Basement

TABLE 4.55. Module 4G WHB Process Room Dimensions

Process Room	Approximate Dimension (feet)			Location Symbol (a)
	Length	Width	Height	
Air-Control Vestibule	140	35	25	A
Receiving and Shipping Area	275	35	75	B
Cask Preparation Area	275	25	100	C
Cask Unloading Rooms	64 + 32	40	30	D
Cask Unloading Hot Cell	185 + 127	40	40	E
Inspection Cell	64	33	40	F
Waste Transfer Tunnel	137	23	23	I
Surface Storage Vault	224	81	55	J

(a) Letter symbol indicates location on Figures 4.97 and 4.98.

TABLE 4.56. Module 4G WHB Process Support Facilities

Facility	Function	Location Key(a)	
		Building Floor	Symbol
Material Receiving	Receive and store nonradioactive material	1	J
Operations Support	Operating gallery, weld power supply	1	O
Maintenance	Maintenance shops and storage	Basement	P
Air Conditioning and Exhaust Treatment	Air purification, distribution	2	R
Personnel Annex	Administrative offices, change rooms, training facilities, auditorium	1	S
Container Storage and Transfer	Store clean empty container and transfer to waste transfer tunnel	1	T

(a) Symbol indicates location on Figures 4.97 and 4.98.

The WHB contains a number of support facilities necessary for safe and efficient performance of its operations. These support facilities and their location keys are listed in Table 4.56.

The WHB facilities needed for each of the repository functional activities are described in the following subsections. The activities are described in the functional description section of this document. The locations of these activities in the WHB are shown in Figures 4.97 and 4.98 as circles containing the functional activity numbers.

Function 4.1 - Transport Cask Receipt. Cask receipt occurs at the waste receiving and inspection area where the railroad lines enter the facility (area L in Figure 4.70).

Function 4.2 - Transport Cask Lag Storage. Lag storage of the casks occurs on one of the railcar parking lines at the waste receiving and inspection area (area L in Figure 4.70).

Function 4.3 - Cask Preshipment Inspection and Servicing. The routine cask servicing occurs in the cask receipt area described above and uses the same equipment as is used for cask receipt.

Function 4.4 - Transport Cask Unloading. The cask receiving facilities in the WHB are illustrated schematically in Figure 4.99 and the general location is shown in Figure 4.97. The casks are received at the receiving, inspection, and shipping area. This area has facilities and equipment for receiving trucks and railroad cars transporting loaded casks, removing those casks from those vehicles, placing the casks on transfer carts, and reversing these procedures for placing casks back onto the vehicles.

This large unshielded receiving and shipping area contains railroad tracks, extending the full length of the area. Large doors near the center of the area create airlocks at the outer ends so that vehicles can enter and leave without compromising the controlled ventilation system. Overhead bridge cranes have capacity for lifting the transport casks and transporting them to the transfer carts in the cask preparation area at the side of the receiving and shipping area.

FIGURE 4.99. Typical WHB Cask Receiving Facilities

Cask unloading occurs in the cask preparation area, the cask transfer tunnels, and the cask unloading hot cells (see Figures 4.96 and 4.99). The unloading facilities have equipment for transporting the casks from the preparation area to rooms under the cask unloading cells, preparing the casks for unloading, connecting the casks to the cask unloading cells, and reversing those processes to return the casks to the cask preparation area. With the casks sitting in rooms under the cask unloading cells, the contents are lifted out of the casks through ports in the room ceilings into the cells by the unloading cell bridge cranes.

The cask preparation area and cask transfer tunnels have a set of cart tracks for each unloading port in the unloading cells and a transfer cart for each set of tracks. Ventilation doors separate the cask preparation area from the cask transfer tunnels and shadow shields attached to the roof of the transfer tunnels can be lowered to provide radiation shielding between the open unloading cell entry ports and the cask preparation area. The preparation room contains movable work platforms for personnel working on the cask

tops. Jib cranes in the cask preparation area are used for removing and replacing the cask outer lids, and robots are used for routine operations such as loosening and tightening bolts.

The cask unloading hot cells have overhead bridge cranes that remove and replace the hot cell port plugs, remove and replace the cask inner lids, lift the wastes out of the casks, and transport the wastes inside the cells. The cells also are equipped for storage of the waste materials, inspecting containers, cutting lids off containers, welding lids on containers, and placing the containers on transfer carts in a transfer tunnel to the surface storage vault area.

Function 4.5 - Waste Lag Storage. The cask unloading cell lag storage is illustrated in Figure 4.100 and the location is shown in Figure 4.97. The facilities are of modular construction with capacity for one shipment of waste containers.

FIGURE 4.100. Cask Unloading Cell Lag Storage

Function 4.6 - Waste Processing. The unloading and inspection hot cells contain several processing stations such as leak-test stations, welding stations, weld inspection stations, canister inspection stations, container inspection stations, container decontamination stations, and fuel inspection stations. These are listed below in Section 4.4.7.2. This equipment has not been designed.

Representative containers are illustrated in Figure 4.2.

Function 4.7 - Container Vault Storage. A separate surface storage vault provides lag storage between the hot cell operations and the waste emplacement. The wastes are transported from the inspection hot cells to the vault by transfer carts in the waste transfer tunnels. A shielded transfer machine transfers the wastes between the transfer carts, the vault storage areas, and the out-transfer station, where the canisters of waste are loaded into the waste transporter cask (see Figure 4.96).

4.4.7.2 Level 2 Physical Description for WHB-1 for Containerizing Canistered Wastes (Module 4G)

The WHB-1 for containerizing canistered wastes is scheduled to receive, process, and emplace 2650 to 3000 MTU of SNF from the MRS facility, 350 MTU of SNF directly from reactors, and 400 MTU equivalent of HLW per year. It will operate 24 hours per day, 5 days per week and 250 days per year for all primary functions (unloading shipments, processing wastes, and emplacing wastes). Shipments will be accepted 7 days per week, 365 days per year.

Table 4.44 contains general descriptions of the waste packages handled by this module, including information on locations in the facilities.

The major process equipment needed for the waste handling is listed in Table 4.45. This table contains the functional description reference numbers, equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information. The equipment is listed in this table by functional description reference number. Table 4.46 lists the information in Table 4.45 by equipment item to show the number of functions for which each equipment item is used.

4.4.8 The Consolidation and Containerization WHB-2 Without an MRS (Module 4H)

The primary purposes of this module are to receive 3000 MTU/yr of intact fuel wastes from the waste generators, unload these wastes from the transport casks, consolidate spent fuel assemblies, and place these wastes in repository containers.

4.4.8.1 Level 1 Physical Description for Consolidation and Containerizing WHB-2 Without an MRS (Module 4H)

Figure 4.101 presents a typical schematic process flow diagram for the WHB. Figures 4.102 and 4.103 present simplified general floor plans for this WHB.

The primary process areas are a receiving, inspection, and shipping area; a cask preparation area; a cask unloading hot cell; two consolidation hot cells; two packaging hot cells; six waste transfer tunnels; and a surface storage vault. The cask unloading hot cell contains five cask unloading ports. In addition to these basic process areas, rooms for supporting activities, storage space, and corridors are provided. Table 4.57 lists the approximate process area dimensions and location keys that indicate where (on Figures 4.102 and 4.103) the various functions are located in the WHB.

The WHB contains a number of support facilities necessary for safe and efficient performance of its operations. These support facilities and their location keys are listed in Table 4.58.

The WHB facilities needed for each of the repository functional activities are described in the following subsections. The activities themselves are described in the functional description section of this document. The locations of these activities in the WHB are shown in Figures 4.102 and 4.103 as circles containing the functional activity numbers.

Function 4.1 - Transport Cask Receipt. Cask receipt occurs at the waste receiving and inspection area where the railroad lines enter the facility (area L in Figure 4.70).

FIGURE 4.101. Conceptual Schematic Process Flow Diagram for the WHB

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.57, and 4.58.

LEGEND: Numbers in circles identify locations of functions.
Letters in squares identify waste processing areas.
Letters in diamonds identify building support facilities.

FIGURE 4.102. General Plan View of the Module 4H WHB Main Floor

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.57, and 4.58.

LEGEND: Numbers in circles identify locations of functions.
 Letters in squares identify waste processing areas.
 Letters in diamonds identify building support facilities.

FIGURE 4.103. General Plan View of the Module 4H WHB Basement

TABLE 4.57. Module 4H WHB Process Room Dimensions

Process Room	Approximate Dimension (feet)			Location Symbol (a)
	Length	Width	Height	
Air-Control Vestibule	252	80	25	A
Receiving and Shipping Area	252	75	75	B
Cask Preparation Area	252	25	100	C
Cask Unloading Rooms	160	40	30	D
Cask Unloading Hot Cell	388	40	40	E
Consolidation Cells	134	25	40	G
Packaging Cells	86	52	40	H
Waste Transfer Tunnels	93	23	23	I
	+			
	110			
	+			
	288			
Surface Storage Vault	155	81	55	J

(a) Letter symbol indicates location on Figures 4.102 and 4.103.

TABLE 4.58. Module 4H WHB Process Support Facilities

Facility	Function	Location Key(a)	
		Building Floor	Symbol
Material Receiving	Receive and store nonradioactive material	1	J
Operations Support	Operating gallery, weld power supply	1	O
Maintenance	Maintenance shops and storage	Basement	P
Air Conditioning and Exhaust Treatment	Air purification, distribution	2	R
Personnel Annex	Administrative offices, change rooms, training facilities, auditorium	1	S
Container Storage and Transfer	Store clean empty container and transfer to waste transfer tunnel	1	T

(a) Symbol indicates location on Figure 4.102 and 4.103

Function 4.2 - Transport Cask Lag Storage. Lag storage of the casks occurs on one of the railcar parking lines at the waste receiving and inspection area (area L in Figure 4.70).

Function 4.3 - Cask Preshipment Inspection and Servicing. The routine cask servicing occurs in the cask receipt area described above and uses the same equipment as is used for cask receipt.

Function 4.4 - Transport Cask Unloading. The cask receiving facilities in the WHB are illustrated schematically in Figure 4.104 and the general location is shown in Figure 4.102. The casks are received at the receiving, inspection, and shipping area. This area has facilities and equipment for receiving trucks and railroad cars transporting loaded casks, removing those casks from those vehicles, placing the casks on transfer carts, and reversing these procedures for placing casks back onto the vehicles.

This large unshielded receiving and shipping area contains railroad tracks, extending the full length of the area. Large doors near the center of the area create airlocks at the outer ends so that vehicles can enter and leave without compromising the controlled ventilation system. Overhead bridge cranes have capacity for lifting the transport casks and transporting them to the transfer carts in the cask preparation area at the side of the receiving and shipping area.

Cask unloading occurs in the cask preparation area, the cask transfer tunnels, and the cask unloading hot cells (see Figures 4.101 and 4.104). The unloading facilities have equipment for transporting the casks from the preparation area to rooms under the cask unloading cells, preparing the casks for unloading, connecting the casks to the cask unloading cells, and reversing those processes to return the casks to the cask preparation area. With the casks sitting in rooms under the cask unloading cells, the contents are lifted out of the casks through ports in the room ceilings into the cells by the unloading cell bridge cranes.

The cask preparation area and cask transfer tunnels have a set of cart tracks for each unloading port in the unloading cells and a transfer cart for each set of tracks. Ventilation doors separate the cask preparation area

FIGURE 4.104. Typical WHB Cask Receiving Facilities

from the cask transfer tunnels, and shadow shields attached to the roof of the transfer tunnels can be lowered to provide radiation shielding between the open unloading cell entry ports and the cask preparation area. The preparation room contains movable work platforms for personnel working on the cask tops. Jib cranes in the cask preparation area are used for removing and replacing the cask outer lids, and robots are used for routine operations such as loosening and tightening bolts.

The cask unloading hot cells have overhead bridge cranes that remove and replace the hot cell port plugs, remove and replace the cask inner lids, lift the wastes out of the casks, and transport the wastes inside the cells.

Function 4.5 - Waste Lag Storage. The cask unloading cell lag storage is illustrated in Figure 4.105 and the location is shown in Figure 102. The facilities are of modular construction with capacity for one shipment of waste containers.

FIGURE 4.105. Cask Unloading Cell Lag Storage

Function 4.6 - Waste Processing. Consolidation of the intact SFAs occurs in the four consolidation cells and two packaging cells. Six transfer tunnels are needed for moving the wastes between these cells, the cask unloading cell, and the surface vault, as shown in Figure 4.101.

The intact fuel is transported from the cask unloading hot cell to the four consolidation cells, which contain lag storages, consolidation equipment, and volume-reduction equipment for the spent fuel hardware. Adjacent to each pair of consolidation cells is a packaging cell that receives consolidated fuel rods and volume-reduced hardware through ports in the walls between the consolidation and packaging cells.

The packaging cells contain equipment for aligning containers with the ports in the cell wall (so that the wastes are loaded through the ports into those containers), welding lids on the containers, inspecting and repairing those welds, and loading the containers into container carts in a transfer tunnel below the packaging cells. Those container carts then transport the containers through the tunnel to the surface storage vault. Each of the four

transfer tunnels from the cask unloading hot cells to the consolidation cells contains two sets of rails and two transfer carts with a capacity of six spent fuel baskets apiece. The transfer tunnel from the packaging cells contains two sets of tracks and four transfer carts with a capacity of four containers apiece.

Each consolidation hot cell contains a bridge crane for moving SFAs, equipment, and port plugs inside the cell. Each packaging cell also contains a bridge crane for moving containers, equipment, and port plugs inside the cell.

Representative containers are illustrated in Figure 4.2.

Function 4.7 - Container Vault Storage. A separate surface storage vault provides lag storage between the hot cell operations and the waste emplacement. The wastes are transported from the cask unloading and packaging hot cells to the vault by transfer carts in the waste transfer tunnels. A shielded transfer machine transfers the wastes between the transfer carts, the vault storage areas, and the out-transfer station, where the canisters of wastes are loaded into the waste transporter cask (see Figure 4.101).

4.4.8.2 Level 2 Physical Description for Consolidation and Containerizing WHB-2 Without an MRS (Module 4H)

This WHB-2 is scheduled to received and process 3000 MTU of SNF from the reactors per year. It will operate 24 hours per day, 5 days per week and 250 days per year for all primary functions (unloading shipments and processing wastes). Shipments will be accepted 7 days per week, 365 days per year.

Table 4.44 contains general descriptions of the waste packages handled by this module, including information on locations in the facilities.

The major process equipment needed for the waste handling is listed in Table 4.45. This table contains the functional description reference numbers, equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information. The equipment is listed in this table by functional description reference number. Table 4.46 lists the information in Table 4.45 by equipment item to show the number of functions for which each equipment item is used.

4.4.9 The Consolidation and Containerization WHB-2 with an MRS (Module 4I)

The primary purposes of this module are to receive 3000 MTU/yr of intact spent fuel from the MRS and reactors, unload these wastes from the transfer casks, consolidate spent fuel assemblies, and place these wastes in repository containers.

4.4.9.1 Level 1 Physical Description for Consolidation and Containerizing WHB-2 with an MRS (Module 4I)

Figure 4.106 presents a typical schematic process flow diagram for this WHB that illustrates its primary functions. Figures 4.107 and 4.108 presents a simplified floor plan for the building.

The general process areas are the receiving, inspection, and shipping area; the cask preparation area; a cask unloading hot cell; two consolidation hot cells; two packaging hot cells; six container transfer tunnels; and the surface storage vault. The cask unloading hot cell contains three cask unloading ports. Table 4.59 lists the approximate process area dimensions and location keys that indicate where (on Figures 4.107 and 4.108) the various functions are located in the WHB.

The WHB contains a number of support facilities necessary for safe and efficient performance of its operations. These support facilities and their location keys are listed in Table 4.60.

The WHB facilities needed for each of the repository functional activities are described in the following subsections. The activities themselves are described in the functional description section of this document. The locations of these activities in the WHB are shown in Figures 4.107 and 4.108 as circles containing the functional activity numbers.

Function 4.1 - Transport Cask Receipt. Cask receipt occurs at the waste receiving and inspection area where the railroad lines enter the facility (area L in Figure 4.70).

Function 4.2 - Transport Cask Lag Storage. Lag storage of the casks occurs on one of the railcar parking lines at the waste receiving and inspection area (area L in Figure 4.70).

FIGURE 4.106. Conceptual Schematic Process Flow Diagram for the WHB

NOTE: Letters and numbers relate facility locations to descriptions in Tables 4.45, 4.59, and 4.60.

LEGEND: Numbers in circles identify locations of functions.
 Letters in squares identify waste processing areas.
 Letters in diamonds identify building support facilities.

FIGURE 4.107. General Plan View of the Module 4I WHB Main Floor

TABLE 4.59. Module 4I WHB Process Room Dimensions

Process Room	Approximate Dimension (feet)			Location Symbol (a)
	Length	Width	Height	
Air-Control Vestibule	188	80	25	A
Receiving and Shipping Area	188	75	75	B
Cask Preparation Area	188	25	100	C
Cask Unloading Rooms	96	40	30	D
Cask Unloading Hot Cell	324	40	40	E
Consolidation Cells	134	25	40	G
Packaging Cells	86	52	40	H
Waste Transfer Tunnels	93 + 110 + 288	23	23	I
Surface Storage Vault	155	91	55	J

(a) Letter symbol indicates location on Figures 4.107 and 4.108.

TABLE 4.60. Module 4I WHB Process Support Facilities

Facility	Function	Location Key (a)	
		Building Floor	Symbol
Material Receiving	Receive and store nonradioactive material	1	J
Operations Support	Operating gallery, weld power supply	1	O
Maintenance	Maintenance shops and storage	Basement	P
Air Conditioning and Exhaust Treatment	Air purification, distribution	2	R
Personnel Annex	Administrative offices, change rooms, training facilities, auditorium	1	S
Container Storage and Transfer	Store clean empty container and transfer to waste transfer tunnel	1	T

(a) Symbol indicates location on Figures 4.107 and 4.108.

Function 4.3 - Cask Preshipment Inspection and Servicing. The routine cask servicing occurs in the cask receipt area described above and uses the same equipment as is used for cask receipt.

Function 4.4 - Transport Cask Unloading. The cask receiving facilities in the WHB are illustrated schematically in Figure 4.109 and the general location is shown in Figure 4.107. The casks are received at the receiving, inspection, and shipping area. This area has facilities and equipment for receiving trucks and railroad cars transporting loaded casks, removing those casks from those vehicles, placing the casks on transfer carts, and reversing these procedures for placing casks back onto the vehicles.

This large unshielded receiving and shipping area contains railroad tracks, extending the full length of the area. Large doors near the center of the area create airlocks at the outer ends so that vehicles can enter and leave without compromising the controlled ventilation system. Overhead

FIGURE 4.109. Typical WHB Cask Receiving Facilities

bridge cranes have capacity for lifting the transport casks and transporting them to the transfer carts in the cask preparation area at the side of the receiving and shipping area.

Cask unloading occurs in the cask preparation area, the cask transfer tunnels, and the cask unloading hot cells (see Figures 4.106 and 4.109). The unloading facilities have equipment for transporting the casks from the preparation area to rooms under the cask unloading cells, preparing the casks for unloading, connecting the casks to the cask unloading cells, and reversing those processes to return the casks to the cask preparation area. With the casks sitting in rooms under the cask unloading cells, the contents are lifted out of the casks through ports in the room ceilings into the cells by the unloading cell bridge cranes.

The cask preparation area and cask transfer tunnels have a set of cart tracks for each unloading port in the unloading cells and a transfer cart for each set of tracks. Ventilation doors separate the cask preparation area from the cask transfer tunnels, and shadow shields attached to the roof of the transfer tunnels can be lowered to provide radiation shielding between the open unloading cell entry ports and the cask preparation area. The preparation room contains movable work platforms for personnel working on the cask tops. Jib cranes in the cask preparation area are used for removing and replacing the cask outer lids, and robots are used for routine operations such as loosening and tightening bolts.

The cask unloading hot cells have overhead bridge cranes that remove and replace the hot cell port plugs, remove and replace the cask inner lids, lift the wastes out of the casks, and transport the wastes inside the cells.

Function 4.5 - Waste Lag Storage. The cask unloading cell lag storage is illustrated in Figure 4.110 and the location is shown in Figure 4.107. The facilities are of modular construction with capacity for one shipment of waste containers.

Function 4.6 - Waste Processing. Consolidation of the intact SFAs occurs in the four consolidation cells and two packaging cells. Six transfer tunnels are needed for moving the wastes between these cells, the cask unloading cell, and the surface vault, as shown in Figure 4.107.

FIGURE 4.110. Cask Unloading Cell Lag Storage

The intact fuel is transported from the cask unloading hot cell to the four consolidation cells, which contain lag storages, consolidation equipment, and volume-reduction equipment for the spent fuel hardware. Adjacent to each pair of consolidation cells is a packaging cell that receives consolidated fuel rods and volume-reduced hardware through ports in the walls between the consolidation and packaging cells.

The packaging cells contain equipment for aligning containers with the ports in the cell wall (so that the wastes are loaded through the ports into those containers), welding lids on the containers, inspecting and repairing those welds, and loading the containers into container carts in a transfer tunnel below the packaging cells. Those container carts then transport the containers through the tunnel to the surface storage vault. Each of the four transfer tunnels from the cask unloading hot cells to the consolidation cells contains two sets of rails and two transfer carts with a capacity of six

spent fuel baskets apiece. The transfer tunnel from the packaging cell contains two sets of tracks and four transfer carts with a capacity of four containers apiece.

Each consolidation hot cell contains a bridge crane for moving SFAs, equipment, and port plugs inside the cell. Each packaging cell also contains a bridge crane for moving containers, equipment, and port plugs inside the cell.

Representative containers are illustrated in Figure 4.2.

Function 4.7 - Container Vault Storage. A separate surface storage vault provides lag storage between the hot cell operations and the waste emplacement. The wastes are transported from the cask unloading and packaging hot cells to the vault by transfer carts in the waste transfer tunnels. A shielded transfer machine transfers the wastes between the transfer carts, the vault storage areas, and the out-transfer station, where the canisters of wastes are loaded into the waste transporter cask (see Figure 4.106).

4.4.9.2 Level 2 Physical Description for Consolidation and Containerizing WHB-2 with an MRS (Module 4I)

This WHB-2 is scheduled to receive and process 3000 MTU/yr of SNF from the MRS and reactors. It will operate 24 hours per day, 5 days per week and 250 days per year for all primary functions (unloading shipments and processing wastes). Shipments will be accepted 7 days per week, 365 days per year.

Table 4.44 contains general descriptions of the waste packages handled by this module, including information on locations in the facilities.

The major process equipment needed for the waste handling is listed in Table 4.45. This table contains the functional description reference numbers, equipment titles, equipment functions, number of equipment items, equipment size or capacity, and location information. The equipment is listed in this table by functional description reference number. Table 4.46 lists the information in Table 4.45 by equipment item to show the number of functions for which each equipment item is used.

4.4.10 The Repository Underground Facilities (Module 4J)

The purposes of the repository underground facilities are to transport containerized wastes to the emplacement locations, emplace the wastes, store the wastes without significant releases to the environment, and remove or retrieve the wastes for transport to the surface before the repository is closed.

4.4.10.1 Level 1 Physical Description for Repository Underground Facilities (Module 4J)

The repository underground facilities, based on a vertical borehole emplacement concept, are illustrated in Figures 4.69, 4.111 and 4.112. The primary facilities are the waste ramp, the tuff ramp, the main drifts, the several personnel and ventilation shafts, the emplacement drifts, and the underground support facilities. The repository facilities needed for each of the underground functional activities are described in the following subsections. The activities are described in the functional description section of this document. Except for specific activities carried out at the out-transfer station in the WHB, the road connecting the station to the waste ramp, and the tuff pile near the adit for the tuff ramp, these activities are carried out throughout the underground facilities.

Function 4.12 - Waste Emplacement Operations. Emplacement facilities and equipment are illustrated in Figures 4.69, and 4.111 to 4.118. The facilities needed for emplacement are the out-transfer station at the WHB surface storage vault, the roads connecting the out-transfer station to the underground waste ramp, the underground waste ramp, the main drifts, the panel access drifts, the emplacement drifts, and the boreholes. The waste transporter carries the wastes from the surface storage vault through the ramp and drifts to the borehole and places them in the borehole.

Figure 4.113 illustrates a vertical borehole. The vertical boreholes are long enough for only one container of waste and are only partially lined near the top to provide support for the shield plug and shielding closure and to prevent rock from falling on the containers.

FIGURE 4.111. Plan View of Repository Underground Facilities

FIGURE 4.112. Repository Underground Mining Activities

FIGURE 4.113. Conceptual Design of Vertical Borehole

Emplacement Mode

Transport Mode

FIGURE 4.114. Waste Transporter

FIGURE 4.115. Borehole Preparation

FIGURE 4.116. Container Transfer to Underground Borehole

FIGURE 4.117. Emplacement of Container in Borehole

FIGURE 4.118. Closure of Borehole

Figure 4.114 illustrates the waste transporter in the transport mode and in the emplacement mode when the transporter is connected to a borehole in the emplacement drift. Figure 4.115 illustrates the preparation of a vertical borehole prior to waste emplacement. Figure 4.116 illustrates transfer of a container from the surface storage vault to the underground borehole. Figure 4.117 illustrates emplacement of the container in a vertical borehole and return of the empty transporter to the surface. Figure 4.118 illustrates closure of a vertical borehole by insertion of a plug, removal of the closure, and installation of the cover.

If the wastes are removed from the boreholes, the same facilities and equipment will be used for removing the wastes but operating in reverse order.

During the caretaker period, the shafts, ramps, drifts, and underground support facilities remain in operation to permit surveillance of the repository performance.

Function 4.13 - Performance Testing. Performance testing during the caretaker period will use all of the equipment and facilities described above for periodic removal, transport to and from the examination facility, and re-emplacement of selected waste containers. The mining equipment also may be used if some of the boreholes become unusable because of testing after removal of the wastes. In addition, the performance testing uses the surface performance confirmation building and associated equipment.

Function 4.14 - Mining. The underground facilities are excavated using tunnel-boring machines for long straight runs and drill-and-blast mining for short runs or drifts that are not circular in cross-section. Roof bolting will be installed as needed.

The shafts, ramps, and common areas will be developed during the initial construction of the repository. Then, after the start of operations, the ventilation drifts, common areas, and emplacement panels will be extended as necessary for emplacement of the wastes.

The current reference waste emplacement concept calls for vertical boreholes in the floor of the emplacement rooms (drifts). The vertical

emplacement boreholes will be drilled by a two-pass procedure. First, a pilot hole will be drilled and then the hole will be reamed to final diameter. The excavated tuff will be transported to the surface by a combination of load/haul/dump units and conveyors.

An alternative borehole emplacement concept, under consideration but not described here, is based on **horizontal borehole emplacement** in the sides of drifts.

Function 4.15 - Final Waste Isolation. After the caretaker period, closure of the repository will use the same rock transfer equipment as was used for conveying the rock out of the underground facilities. In addition, rock grading and crushing equipment will be used at the surface for preparing rock of the proper size for the closure, and mechanical and pneumatic compactors will be used for placing fill in the drifts. Drift, shaft, and ramp seals will be made with normal concrete placement equipment and procedures.

4.4.10.2 Level 2 Physical Description for Repository Underground Facilities (Module 4J)

The conceptual repository is scheduled to emplace 3000 MTU of spent fuel wastes and 400 MTU equivalent of HLW per year. It will operate 24 hours per day, 5 days per week and 250 days per year for emplacing wastes.

Table 4.44 contains a general description of the waste packages handled by the underground facilities. The specific packages considered during a case study would be determined by the WHB module and types of wastes assumed for that case.

Table 4.61 provides general characteristics of the repository underground facilities. This information consists primarily of a list of facilities and general characteristics (areas, general design, functions, etc.).

The major process equipment needed for the underground activities is listed in Table 4.62. This table contains the functional description reference numbers, equipment titles, equipment functions, number of equipment

TABLE 4.61. Repository Underground Excavations for Vertical Borehole Storage

Facility Title	Number	Function/Activity	Approximate Internal Dimensions (ft)		
			Geometry	Width	Height
Waste Ramp	1	Transport wastes to and from repository. Ventilation for emplacement area	Inverted U	21	16
Tuff Ramp	1	Transport tuff to and from repository. Ventilation exhaust for development area	Inverted U	24	21
Men-and-Materials Shaft	1	Personnel and materials transportation utility route. Ventilation exhaust for emplacement area	Round	20	20
Emplacement Area Exhaust Shaft	1	Ventilation exhaust for emplacement area	Round	20	20
Exploratory Shaft 1	1	Ventilation intake for emplacement area	Round	12	12
Exploratory Shaft 2	1	Ventilation intake for emplacement area	Round	6	6
Waste Main	1	Waste transport ventilation intake for emplacement area. Transport of wastes	Round	24	21.5
Tuff Main	1	Tuff transport. Ventilation exhaust for development area	Inverted U	24	18.5
Service Main	1	Personnel access to development area. Ventilation intake to development area	Inverted U	24	14.5
Panel Access Drifts		Access to emplacement drifts	Inverted U	24	13.5
Emplacement Drifts		Access to emplacement boreholes	Inverted U	15	21.5
Perimeter Drift	1	Ventilation exhaust for emplacement area	Round	22	20.83
Midpanel Drift		Ventilation control for emplacement panels	Round	15	13.5
Shop Areas		Maintenance, administration and personnel facilities for underground operations	Inverted U	25	Varies
					2,400

TABLE 4.62. Major Process Equipment for Waste Emplacement at the Repository - Listed in Process Step Order

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units	Size or Capacity	Locations (Figure Number)
4.12.1.1	Waste Transporter	58	Transport wastes to waste ramp	TBD	1 Container	4.69
4.12.1.2	Waste Transporter	58	Transport wastes to underground borehole	TBD	1 Container	4.116
4.12.1.3	Waste Transporter	58	Insert container into borehole	TBD	1 Container	4.117
4.12.1.4	Temporary Borehole Shield Closure	56	Opened and closed during container placement in boreholes	TBD	1 Borehole	4.117
	Waste Transporter	58	Moved to waste handling building, performance confirmation building or holding area	TBD	1 Container	4.69
4.12.1.5	Borehole Forklift	57	Transport borehole equipment	TBD		4.115
	Shield Plug	59	Provide shielding in boreholes	1 per Borehole	1 Borehole	4.118
	Shield Plug Installer	60	Install shield plugs in boreholes	TBD	1 Plug	4.118
	Temporary Borehole Shield Closure	56	Removed from borehole	TBD	1 Borehole	4.115
4.12.3	Borehole Cover	61	Installed on borehole to provide borehole seal	1 per Borehole	1 Borehole	4.118
	Borehole Cover	61	Removed and later replaced to permit access to borehole	1 per Borehole	1 Borehole	4.118
	Temporary Borehole Shield Closure	56	Installed to permit access to borehole during waste removal, then removed	1 per Borehole	1 Borehole	4.115
	Borehole Forklift	57	Transport borehole equipment	TBD		4.115
	Shield Plug Installer	60	Remove and later replace shield plugs	TBD	1 Plug	4.118
	Shield Plug	59	Removed to permit access to wastes	TBD	1 Borehole	4.118
	Waste Transporter	58	Retrieve waste containers. Transport them to performance confirmation building.	TBD	1 Container	4.114

TABLE 4.62. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units	Size or Capacity	Locations (Figure Number)
4.14.1.1	25-ft-Diameter Tunnel-Boring Machine	38	Excavate tunnels and rooms	1	25 ft	4.69, 4.111, 4.112
	23-ft-Diameter Tunnel-Boring Machine	39	Excavate tunnels and rooms	1	23 ft	4.69, 4.111, 4.112
	Conveyor Belt System	40	Excavate tunnels and rooms	1		4.69, 4.111, 4.112
	Conveyor Belt System	41	Excavate tunnels and rooms	2		4.69, 4.111, 4.112
	Conveyor Belt System	51	Transport tuff through mains and ramps	10		4.69, 4.111, 4.112
	Concrete Truck	42	Carry concrete for paving tunnels and rooms	3	5 yd ³	4.69, 4.111, 4.112
	Concrete-Paving Spreader	43	Pave tunnels and rooms	2		4.69, 4.111, 4.112
	Feeder/Breaker	44	Excavate tunnels and rooms	4		4.69, 4.111, 4.112
	Drill Jumbo	45	Excavate tunnels and rooms	4	2 Boom	4.69, 4.111, 4.112
	Anfo-Loading Truck	46	Excavate tunnels and rooms	4		4.69, 4.111, 4.112
4.14.1.2	Load/Haul/Dump Unit	47	Excavate tunnels and rooms	4	5 yd ³	4.69, 4.111, 4.112
	Roof-Bolting Machine	48	Construct tunnels and rooms	5	3 Boom	4.69, 4.111, 4.112
	Scaling Machine	49	Construct tunnels and rooms	4	1 Pick	4.69, 4.111, 4.112
	Shotcrete Truck	50	Line tunnels and rooms	5		4.69, 4.111, 4.112
	Conveyor Belt System	40	Excavate tunnels and rooms	1		4.69, 4.111, 4.112
	Conveyor Belt System	41	Excavate tunnels and rooms	2		4.69, 4.111, 4.112
	Concrete Truck	42	Line emplacement drifts and rooms	3	5 yd ³	4.111, 4.112
	Concrete-Paving Spreader	43	Pave tunnels and rooms	2		4.69, 4.111, 4.112
	Feeder/Breaker	44	Excavate emplacement drifts and rooms	4		4.111, 4.112
	Drill Jumbo	45	Excavate emplacement drifts and rooms	4	2 Booms	4.111, 4.112
	Anfo-Loading Truck	46	Excavate emplacement drifts and rooms	4		4.111, 4.112
	Load/Haul/Dump Unit	47	Excavate emplacement drifts and rooms	4	5 yd ³	4.111, 4.112

TABLE 4.62. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units	Size or Capacity	Locations (Figure Number)
4.14.1.2	Roof-Bolting Machine	48	Excavate emplacement drifts and rooms	5	3 Booms	4.111, 4.112
	Sealing Machine	49	Excavate emplacement drifts and rooms	4	1 Pick	4.111, 4.112
	Shotcrete Truck	50	Line emplacement drifts and rooms	3		4.111, 4.112
	Conveyor Belt System	51	Transport tuff through mains and ramps	10		4.69, 4.111, 4.112
4.14.2.1	Pilot Hole Drill	52	Drill pilot holes for vertical boreholes	5	11 in.	4.112
	Reamer Drill	53	Ream vertical boreholes to final diameter	7	29 in.	4.112
	Load/Haul/Dump Unit	47	Convey tuff to conveyors	10	5 yd ³	4.112
	Conveyor Belt System	40	Excavate boreholes	2		4.112
	Conveyor Belt System	41	Excavate boreholes	2		4.112
	Conveyor Belt System	51	Convey tuff in tuff main and ramp	10		4.112
4.14.2.2	Support Plate	54	Support waste container in vertical boreholes	1 per borehole	1 Borehole	4.113
	Vertical Borehole Liner	55	Line upper portion of vertical boreholes to prevent rock fall	1 per borehole	36 in.	4.113
	Temporary Borehole Shield Closure	56	Provide shielding during waste emplacement in boreholes	TBD	1 Borehole	4.115
	Borehole Forklift	57	Transport borehole equipment	TBD		4.115
4.14.3.1	Conveyor Belt System	63	Convey tuff in tuff storage pile	5		4.69

TABLE 4.62. (contd)

Function Reference Number	Equipment Title	Equipment Identification (a)	Function/Activity	Number of Units	Size or Capacity	Locations (Figure Number)
4.15	Rock Excavator	62	Excavate tuff in tuff pile	1		4.69
	Conveyor Belt System	63	Convey excavated tuff to grinding equipment	5		4.69
	Grinding Equipment	64	Grind tuff	1		4.69
	Sorting Equipment	65	Sort ground tuff by size	1		4.69
	Conveyor Belt System	51	Convey tuff to underground facilities	10		4.69
	Conveyor Belt System	41	Convey tuff in underground facilities	2		4.69, 4.111
	Conveyor Belt System	40	Convey tuff in emplacement drifts	2		4.111
	Load/Haul/Dump Unit	47	Convey tuff underground	TBD	5 yd ³	4.112
	Bulldozers	66	Move tuff underground	TBD		4.112
	Pneumatic Backfillers	67	Emplace tuff underground	TBD		4.112
	Vibratory Rollers	68	Compact tuff underground	TBD		4.112
	Concrete Truck	42	Carry concrete for seal work	2	5 yd ³	4.112
	Bulldozers	66	Demolish structures and level site	TBD		4.69
	Trucks	69	Transport waste materials to disposal pit	TBD		4.69
	Excavators	70	Excavate disposal pits	TBD		4.69
	Drill Jumbo	45	Drill concrete for demolition	TBD	2 Boom	4.69
	Rippers	71	Destroy roads and other surface structures	TBD		4.69
	Load/Haul/Dump Unit	47	Transport waste materials and load into trucks	TBD	5 yd ³	4.69

(a) Equipment identification included as an aid to equipment cost and utilization studies.

items, equipment size or capacity, and location information. The equipment is listed in that table by functional description reference number.

Table 4.63 lists the information in Table 4.62 by equipment item to show the number of functions for which each equipment item is used.

Table 4.64 lists general design characteristics of the repository.

TABLE 4.63. Major Process Equipment for Waste Emplacement at the Repository - Listed by Equipment Item

Equipment Title	Equipment (a) Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity	Locations (Figure Number)
25-ft-Diameter Tunnel- Boring Machine	38	4.14.1.1	Excavate tunnels and rooms	1	25 ft	4.69, 4.111, 4.112
23-ft-Diameter Tunnel- Boring Machine	39	4.14.1.1	Excavate tunnels and rooms	1	23 ft	4.69, 4.111, 4.112
Conveyor Belt System	40	4.14.1.1	Excavate tunnels and rooms	2		4.69, 4.111, 4.112
		4.14.1.2	Excavate tunnels and rooms	2		4.69, 4.111, 4.112
		4.14.2.1	Excavate boreholes	2		4.112
		4.15	Convey tuff in emplacement drafts	2		4.69
Conveyor Belt System	41	4.14.1.1	Excavate tunnels and rooms	2		4.69, 4.111, 4.112
		4.14.1.2	Excavate tunnels and rooms	2		4.69, 4.111, 4.112
		4.14.2.1	Excavate boreholes	2		4.69, 4.111, 4.112
		4.15	Convey tuff in underground facilities	2		4.69, 4.111
Concrete Truck	42	4.14.1.1	Carry concrete for paving tunnels and rooms	3	5 yd ³	4.69, 4.111, 4.112
		4.14.1.2	Line emplacement drifts and rooms	3	5 yd ³	4.111, 4.112
		4.15	Carry concrete for seal work	2	5 yd ³	4.112
Concrete-Paving Spreader	43	4.14.1.1	Pave tunnels and rooms	2		4.69, 4.111, 4.112
Feeder/Breaker	44	4.14.1.1	Excavate tunnels and rooms	4		4.69, 4.111, 4.112
		4.14.1.2	Excavate emplacement drifts and rooms	4		4.111, 4.112
Drill Jumbo	45	4.14.1.1	Excavate tunnels and rooms	4	2 Booms	4.69, 4.111, 4.112
		4.14.1.2	Excavate emplacement drifts and rooms	4	2 Booms	4.111, 4.112

TABLE 4.63. (contd)

Equipment Title	Equipment (a) Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity	Locations (Figure Number)
Drill Jumbo (contd)	45	4.15	Drill concrete for demolition	TBD	2 Booms	4.69
Anfo-Loading Truck	46	4.14.1.1	Excavate tunnels and rooms	4		4.69, 4.111, 4.112
		4.14.1.2	Excavate emplacement drifts and rooms	4		4.111, 4.112
Load/Haul/Dump Unit	47	4.14.1.1	Excavate tunnels and rooms	4	5 yd ³	4.69, 4.111, 4.112
		4.14.1.2	Excavate emplacement drifts and rooms	4	5 yd ³	4.111, 4.112
		4.14.2.1	Convey tuff to conveyors	10	5 yd ³	4.112
		4.15	Convey tuff underground	TBD	5 yd ³	4.112
		4.15	Transport waste materials and load into trucks	TBD	5 yd ³	4.69
Roof-Bolting Machine	48	4.14.1.1	Construct tunnels and rooms	5	3 Booms	4.69, 4.111, 4.112
		4.14.1.2	Excavate emplacement drifts and rooms	5	3 Booms	4.111, 4.112
Scaling Machine	49	4.14.1.1	Construct tunnels and rooms	4	1 Pick	4.69, 4.111, 4.112
		4.14.1.2	Excavate emplacement drifts and rooms	4	1 Pick	4.111, 4.112
Shotcrete Truck	50	4.14.1.1	Line tunnels and rooms	5		4.69, 4.111, 4.112
		4.14.1.2	Line emplacement drifts and rooms	3		4.111, 4.112
Conveyor Belt System	51	4.14.1.1	Transport tuff through mains and ramps	10		4.69, 4.111, 4.112
		4.14.1.2	Transport tuff through mains and ramps	10		4.69, 4.111, 4.112
		4.14.2.1	Convey tuff in tuff main and ramp	10		4.112
		4.15	Convey tuff to underground facilities	10		4.69
Pilot Hole Drill	52	4.14.2.1	Drill pilot holes for vertical boreholes	5	11 in.	4.112
Reamer Drill	53	4.14.2.1	Ream vertical boreholes to final diameter	7	29 in.	4.112
Support Plate	54	4.14.2.2	Support waste container in vertical boreholes	1 per borehole	1 Borehole	4.113
Vertical Borehole Liner	55	4.14.2.2	Line upper portion of vertical boreholes to prevent rock fall	1 per borehole	36 in.	4.113

TABLE 4.63. (contd)

Equipment Title	Equipment (a) Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity	Locations (Figure Number)
Temporary Borehole Shield Closure	56	4.12.1.3	Opened and closed during container placement in boreholes	TBD	1 Borehole	4.117
		4.12.1.5	Removed from borehole	TBD	1 Borehole	4.115
		4.12.3	Installed to permit access to borehole during waste removal, then removed	1 per Borehole	1 Borehole	4.115
		4.14.2.2	Provide shielding during waste emplacement in boreholes	TBD	1 Borehole	4.115
Borehole Forklift	57	4.12.1.5	Transport borehole equipment	TBD		4.115
		4.12.3	Transport borehole equipment	TBD		4.115
		4.14.2.2	Transport borehole equipment	TBD		4.115
		4.12.1.1	Transport waste to waste ramp	TBD	1 Container	4.69
Waste Transporter	58	4.12.1.2	Transport waste to underground borehole	TBD	1 Container	4.116
		4.12.1.3	Insert container into borehole	TBD	1 Container	4.116
		4.12.1.4	Moved to waste handling building, performance confirmation building or holding area	TBD	1 Container	4.69
		4.12.3	Retrieve waste containers. Transport them to performance confirmation building.	TBD	1 Container	4.114
Shield Plug	59	4.12.1.5	Provide shielding in boreholes	1 per Borehole	1 Borehole	4.118
Shield Plug Installer	60	4.12.3	Removed to permit access to wastes	TBD	1 Borehole	4.118
		4.12.1.5	Install shield plugs in boreholes	TBD	1 Plug	4.118
		4.12.3	Remove and later replace shield plugs	TBD	1 Plug	4.118

TABLE 4.63. (contd)

Equipment Title	Equipment (a) Identification	Function Reference Number	Function/Activity	Number of Units	Size or Capacity	Locations (Figure Number)
Borehole Cover	61	4.12.1.5	Installed on borehole to provide borehole seal	1 per Borehole	1 Borehole	4.118
		4.12.3	Removed and later replaced to permit access to borehole	1 per Borehole	1 Borehole	4.118
Rock Excavator	62	4.15	Excavate tuff in tuff pile	1		4.69
Conveyor Belt System	63	4.14.3.1	Convey excavated tuff to storage pile	5		4.69
		4.15	Convey excavated tuff to grinding equipment	5		4.69
Grinding Equipment	64	4.15	Grind tuff	1		4.69
Sorting Equipment	65	4.15	Sort ground tuff by size	1		4.69
Bulldozers	66	4.15	Move tuff underground	TBD		4.112
Pneumatic Backfillers	67	4.15	Demolish structures and level site	TBD		4.69
Vibratory Rollers	68	4.15	Emplace tuff underground	TBD		4.112
Trucks	69	4.15	Compact tuff underground	TBD		4.112
		4.15	Transport waste materials to disposal pit	TBD		4.69
Excavators	70	4.15	Excavate disposal pits	TBD		4.69
Rippers	71	4.15	Destroy roads and other surface structures	TBD		4.69

(a) Equipment identification included as an aid to equipment cost and utilization studies.

TABLE 4.64. Reference Repository Characteristics and Data

Reference emplacement configuration:	Vertical boreholes		
Number of waste packages per borehole:	1		
Maximum thermal loading:	3.5 kW/package		
Reference areal thermal load:	57.0 kW/acre ^(a)		
Reference repository capacity:	70,000 MTU		
Spent Fuel	63,000 MTU		
HLW	7,000 MTU		
Typical rock mining			
Total rock mining:	15,600,000 tons		
Mining per package of intact fuel:	313 tons		
Backfill fraction	0.76		
Typical annual package emplacements:	No Consoli- dation	Consoli- dation at MRS	Consoli- dation at Repository
Intact fuel	1500	260	120
Consolidated fuel	0	900	1030
Hardware	0	250	50
HLW	<u>800</u>	<u>800</u>	<u>800</u>
Total	2300	2210	2000

(a) Maximum for 10-yr-old 33,000 MWd/MTU PWR fuel.

5.0 REFERENCES

40 CFR 173. 1985. U.S. Department of Transportation, "Transportation Shippers - General Requirements for Shipment and Packaging." U.S. Code of Federal Regulations, Title 40, Part 173.

Agarwal, B. K., et al. 1989. The Status of the Modular Vault Dry Store and Its Relevance to the Federal MRS. Spent Fuel Management Seminar. Sponsored by the Institute of Nuclear Materials Management, Washington, D.C., January 11-13, 1989.

Allied-General Nuclear Services (AGNS). May 1980. Fleet Servicing Facilities for Servicing, Maintaining and Testing Rail and Truck Radioactive Waste Transport Systems: Functional Requirements, Technical Design Concepts and Options, Cost Estimates and Comparisons. ORNL/Sub-79/13866/1, AGNS-SFP-5, TTC-0002.

Bechtel National, Inc. August 1985. Integrated MRS/Repository Waste Management Systems Study--Repository in Tuff. SAND85-7112, Prepared for Sandia National Laboratories, Albuquerque, New Mexico.

Energy Information Administration (EIA). 1988. Form RW-859, "Nuclear Fuel Data."

McKee, R. W., J. R. Young, and G. J. Konzek. 1991a. System Description of the Basic MRS System for the FY 1990 Systems Integration Program Studies. PNL-7508, Pacific Northwest Laboratory, Richland, Washington.

McKee, R. W., J. R. Young, and G. J. Konzek. 1991b. System Description of the Repository-Only System for the FY 1990 Systems Integration Program Studies. PNL-7628, Pacific Northwest Laboratory, Richland, Washington.

Oak Ridge National Laboratory (ORNL). 1988. A Classification Scheme for LWR Fuel Assemblies. ORNL/TM-10901, prepared by ORNL, Oak Ridge, Tennessee. Operated by Martin Marietta Energy Systems, Inc., for the U.S. Department of Energy.

Oak Ridge National Laboratory (ORNL). 1991. Distribution of Characteristics of LWR Spent Fuel. ORNL/TM-11670, prepared by ORNL, Oak Ridge, Tennessee. Operated by Martin Marietta Energy Systems, Inc., for the U.S. Department of Energy.

Ralph M. Parsons Company (Parsons). September 1985. Monitored Retrievable Storage (MRS) Facility, Conceptual Design Report. MRS-11. The Ralph M. Parsons Company of Delaware.

Sandia National Laboratories (Sandia). 1983. NWTS Transportation Interface Technology Development. SAND82-1804, Sandia National Laboratories, Albuquerque, New Mexico.

Sandia National Laboratories (Sandia). 1987a. Cost Estimate of the Yucca Mountain Repository Based on the Site Characterization Plan Conceptual Design. Nevada Nuclear Waste Storage Investigation Report, SAND85-1964, Sandia National Laboratories, Albuquerque, New Mexico.

Sandia National Laboratories (Sandia). 1987b. Site Characterization Plan, Conceptual Design Report. Nevada Nuclear Waste Storage Investigation Report, SAND84-2641, Sandia National Laboratories, Albuquerque, New Mexico.

U.S. Department of Energy (DOE). 1987a. Analysis of Radiation Doses from Operation of Postulated Commercial Spent Fuel Transportation Systems. DOE-CH/TPO-OCI, Chicago Operations Office, Argonne, Illinois.

U.S. Department of Energy (DOE). 1987b. Characteristics of Spent Fuel, High-Level Waste, and Other Radioactive Wastes Which May Require Long-Term Isolation. DOE/RW-0184, Office of Civilian Radioactive Waste Management, Washington, D.C.

U.S. Department of Energy (DOE). 1988. Site Characterization Plan, Yucca Mountain Site, Nevada Research and Development Area, Nevada. DOE/RW-0199, Office of Civilian Radioactive Waste Management, Washington, D.C.

U.S. Department of Energy (DOE). 1989a. MRS System Study Summary Report. DOE/RW-0235, Office of Civilian Radioactive Waste Management, Washington, D.C.

U.S. Department of Energy (DOE). 1989b. Final Version Dry Cask Storage Study. DOE/RW-0220, Office of Civilian Radioactive Waste Management, Washington, D.C.

U.S. Department of Energy (DOE). 1990a. Babcock and Wilcox BR-100 Cask - Preliminary Design Report Executive Summary. DOE/ID/12701-1 Ex. Sum., prepared for U.S. Department of Energy, Office of Civilian Radioactive Waste Management, by Babcock and Wilcox, Lynchburg, Virginia.

U.S. Department of Energy (DOE). 1990b. General Atomics GA-4/GA-9 Casks - Preliminary Design Report Executive Summary. DOE/ID/12698-1 Ex. Sum., prepared for U.S. Department of Energy, Office of Civilian Radioactive Waste Management, by General Atomics, San Diego, California.

Roy F. Weston, Inc. (Weston). 1989. MRS System Studies, Task B - Facility Design (Repository/MRS) and Task D - HLW Packaging Location, prepared by Roy F. Weston, Inc. for the U.S. Department of Energy, Office of Civilian Radioactive Waste Management, Washington, D.C.

Wooden, D. G. .1986. Railroad Transportation of Spent Nuclear Fuel. SAND86-7083, Sandia National Laboratories, Albuquerque, New Mexico.

Woods, W. D., A. K. Jowdy, R. I. Smith. 1990. Preconceptual Design for an MRS Transfer Facility. PNL-7400, prepared by The Ralph M. Parsons Company of Delaware for Pacific Northwest Laboratory, Richland, Washington.

Woods, W. D., A. K. Jowdy, C. H. Keehn, R. M. Gale, and R. I. Smith. December 1988. MRS Action Plan Task B Report: Analysis of Alternative Designs and Operating Approaches for a Monitored Retrievable Storage Facility. PNL-6770, prepared by The Ralph M. Parsons Company of Delaware for Pacific Northwest Laboratory, Richland, Washington.

APPENDIX A

ALPHANUMERIC SYMBOLS FOR IDENTIFICATION OF WASTE RECEPTACLES AND RADIOACTIVE WASTE MATERIALS

APPENDIX A

ALPHANUMERIC SYMBOLS FOR IDENTIFICATION OF WASTE RECEPTACLES AND RADIOACTIVE WASTE MATERIALS

The alphanumeric symbol system presented in this document has been developed to provide a standardized shorthand symbolic representation method for use in identifying the wastes, drums, canisters, containers and casks handled by the federal radioactive waste management system.

Because of the variety of waste types, canisters, containers and casks expected to be handled in the system, this unique identification system has been established to facilitate analyses and to aid proper identification of the wastes, canisters, containers and casks during the analyses. Not all of the combinations of wastes, canisters and containers will necessarily be utilized in the deployed system. However, the ones not to be used cannot yet be identified and system modeling should consider all possibilities.

This appendix describes the symbols and the proposed uses for them. The symbols can be used for five purposes:

- to identify waste materials
- to identify waste receptacles (drums, canisters or containers)
- to identify the receptacles plus the contained waste material
- to identify transportation and/or storage casks and any contained wastes
- to identify drywells, storage casks or vaults and contents.

These uses are described sequentially in the following sections.

A.1 IDENTIFICATION OF WASTE MATERIALS

Symbols that identify waste materials consist of a lead group of letters that defines the type of waste and a following group of letters that defines the source facility for the waste.

The lead three letter symbols are:

CON for consolidated SFA pins
 GTC for greater than class C wastes other than non-fuel bearing components
 HLW for solidified high-level wastes (in canisters)
 LLW for classes A, B and C wastes
 NFB for non-fuel bearing components
 SFA for spent fuel assemblies.

The following groups of letters for the sources are:

B for BWR
 BP for a combination of BWR and PWR
 D for defense
 M for Monitored Retrievable Storage
 O for other facility
 P for PWR
 R for repository
 W for West Valley

The resultant typical waste symbols include:

<u>Waste Description</u>	<u>Symbols</u>
Intact PWR SFA	SFA_P
Intact BWR SFA	SFA_B
A combination of intact BWR and PWR SFAs	SFA_BP
Other reactor intact SFA	SFA_O
Consolidated PWR fuel pins	CON_P
Consolidated BWR fuel pins	CON_B
PWR SFA NFBC	NFB_P
BWR SFA NFBC	NFB_B
PWR greater than class C wastes	GTC_P
BWR greater than class C wastes	GTC_B
Other facility greater than class C wastes	GTC_O
MRS greater than class C wastes	GTC_M
Repository greater than class C wastes	GTC_R
West Valley solidified high-level wastes	HLW_W
Defense solidified high-level wastes	HLW_D
West Valley reprocessing plant greater than class C wastes	GTC_W
Defense reprocessing plant greater than class C wastes	GTC_D
MRS class A, B and C wastes	LLW_M
Repository class A, B, and C wastes	LLW_R

A.2 IDENTIFICATION OF WASTE RECEPTACLES AND THE CONTAINED RADIOACTIVE WASTE MATERIALS

Symbols used in the identification of waste receptacles and the contained radioactive waste materials are described in the following subsections.

A.2.1 Identification of Waste Receptacles (Drums, Canisters, and Containers)

Symbols that identify a receptacle are read from left to right:

- a. The lead letters identify the basic design of the receptacle and in most cases infer a source:

AR means a power reactor plant canister

CAG means a cage for 55-gallon drums

CRP means a chemical reprocessing plant canister (either defense or West Valley)

DRM means a 55-gallon drum

OF means other facility canister

M means Monitored Retrievable Storage canister

Y means the Yucca Mountain candidate repository site container.

- b. The remainder of the symbol describes the general design of the receptacle. Definitions of the receptacle description symbols are presented in Table A.1, together with examples of typical contents for each receptacle. The receptacles are assumed to have the lengths defined in that table. Spacers may be used to fill the empty portion of the receptacle if the contents are shorter than the receptacle. Any of the symbols in the table may be added to the above lead group symbols to define a specific design. As an example, a YBP lead group would mean a repository container designed to hold a mix of 4 BWR and 3 PWR fuel assemblies. Also, two of the receptacles definition symbols may be added to the lead symbol to obtain full definition of the receptacle. As an

TABLE A.1. Definition of Receptacle Description Symbols

Symbol	Storage Space Geometry	Standard External Lengths (in.)			Typical Contents
		Reactor or Reprocessing Plant	MRS	Repository (a)	
6	A 6-in. square	180	180	--(b)	1 BWR fuel assembly
9	A 9-in. square	180	180	--	1 PWR fuel assembly(c)
26	A 26-in. O.D. tube with 25-in. I.D.	--	--	188	23 1/4-in. I.D. cylinder with 24-in. O.D.
28	A 28-in. O.D. tube with 27-1/4-in. I.D.	--	--	188	A drum
BP	Four 6-in. spaces and three 9-in. spaces	--	--	188	4 BWR and 3 PWR fuel(c) assemblies
C	A 26-in. O.D. cylindrical receptacle	--	180	188	A drum
DRM	A 55-gallon drum	--	36	36	Shredded metals
H	A 24-in. O.D. tube with 23-1/4-in. I.D.	118	--	126	HLW
I3	An insert with three 9-in. spaces	--	--	188	3 PWR fuel assemblies(c)
I4	An insert with four 9-in. spaces	--	--	188	4 PWR fuel assemblies(c)
I6	An insert with six 6-in. spaces	--	--	188	6 BWR assemblies
I9	An insert with nine 6-in. spaces	--	--	188	9 BWR assemblies
I10	An insert with ten 6-in. spaces	--	--	188	10 BWR assemblies
U	Undefined(d)	TBD	TBD	TBD	Miscellaneous wastes

- (a) These receptacles may be used at the MRS if the wastes are put in containers at the MRS.
 (b) Dashes mean that no receptacle of this type is used.
 (c) Excludes storage of South Texas reactor fuel, which will need about 20 inch longer receptacles.
 (d) If the wastes can be placed in one of the other receptacle, that receptacle probably would be used.

example, Y26I6 means a 26-inch-outer-diameter repository container containing a I6 insert with 6 openings that are 6 inches square for holding 6 BWR spent fuel assemblies.

The external lengths for the canisters and containers were obtained by assuming that the canisters are about 6 inches longer than the longest contained material and that the repository containers are about 8 inches longer than the longest canister or waste expected to be placed in the containers.

A.2.2 Identification of Waste Receptacles Plus the Contained Radioactive Waste Material

A symbol that identifies a single receptacle plus the contents is obtained by identifying the receptacle and then the waste material. The first group of letters identifies the receptacle as described above. The rest of the alphanumeric symbol identifies the contained waste material.

The symbol for the contents is separated from the symbol for the outer receptacle by an underscore line. There also is one underscore line in the symbol for the contents. That second underscore line is placed immediately before the last letter or letters that identify the source for the wastes.

If there is more than one receptacle, plus the waste nested in one or two canisters, the receptacles are identified in sequence starting with the outer one. The final letters identify the contents. The receptacle designs are identified as described above by the identification of the contents.

As an example, a 28-inch-diameter repository container containing a reactor canister that contains consolidated BWR fuel pins would be:

Y28I9_AR6CON_B

In this example, the container and canister are designed for BWR fuel assemblies, that design being identified by the B in the third group of symbols and the I9 in the first group of symbols.

A.3 IDENTIFICATION OF TRANSPORTATION CASKS AND CONTENTS

Symbols that identify transport casks have only one group of letters. The first two letters are RC for rail casks or TC for truck casks. The number that follows is the nominal cask weight in tons. The final letters identify characteristics of the casks as follows:

HLW	High-level wastes
L	Longer than normal spent fuel casks
M	MRS to repository cask
ST	Storage/transportation cask
P	PWR spent fuel
B	BWR spent fuel

As an example, TC25HLW identifies a 25-ton truck cask for transporting HLW canisters.

The cask and contents are identified by adding the symbol for the contents to the symbol for the cask. As an example, RC100_AR9CON_P means a 100-ton rail/barge cask containing PWR canisters originating at a reactor and containing consolidated PWR fuel rods.

A.4 IDENTIFICATION OF STORAGE FACILITIES AND THE CONTAINED RADIOACTIVE WASTE MATERIALS

Symbols that identify storage facilities at the MRS facility start with a symbol for the type of storage facility--drywell (MDW), storage cask (MSC) or vault (MV)--in the first group and have a second group that identifies the type material stored in the cask facility. The second group of symbols may be:

B	for BWR SFAs
O	for other reactor SFAs
P	for PWR SFAs
R	for repository containers
GTC	for greater than class C wastes
HLW	for high-level wastes
NFB	for non-fuel bearing components

As an example, MSC_P identifies a storage cask at the MRS facility for storing 9-inch-square canisters for PWR SFAs.

The drywell, cask or vault and contents are identified by adding the symbol for the contents to the drywell, cask or vault symbol. As an example, MSC_AR9CON_P means a storage cask at the MRS containing canisters originating at a reactor site that contain consolidated PWR fuel rods.

A.5 SUMMARIZED SYMBOLS

The following list summarizes all of the definitions that are used for either the single letters or groups of letters in the symbols.

B	BWR
C	Cylindrical
D	Defense
H	HLW
L	Long
M	Monitored Retrievable Storage
O	Other Facility (other than BWRs, PWRs, MRS, Chemical Reprocessing Plants and Repository)
P	PWR
R	Repository
U	Receptacle of Unknown Geometry
V	Vault
W	West Valley
AR	At-Reactor
BP	A combination of BWR and PWR fuel assemblies
DW	Drywell
I6	6 BWR fuel assemblies
I9	9 BWR fuel assemblies
I10	10 BWR fuel assemblies
I3	3 PWR fuel assemblies
I4	4 PWR fuel assemblies
OU	Other Facility
RC	Rail Cask
SC	Storage Cask

ST	Storage/Transportation
TC	Truck Cask
Y	Yucca Mountain Candidate Repository Site Container
CAG	Drum storage cage
CON	Consolidated SFA Pins
CRP	Chemical Reprocessing Plant
DRM	55-Gallon Drum
GTC	Greater Than Class C Wastes
HLW	Solidified High-Level Wastes
LLW	Low-Level Wastes (classes A, B and C)
NFB	Non-Fuel-Bearing Components
SFA	Spent Fuel Assemblies

APPENDIX B

GLOSSARY

APPENDIX B

GLOSSARY

AC	Allis Chalmers
AGN	Aerojet General Nucleonics
ARRS	Aggregate Receipt Rate Study
Backfill	1) The fill placed in the excavated areas of the underground facility, shafts, or ramps. Backfill materials may be either excavated tuff or other earthen materials. 2) The material or process used to refill an excavation.
Borehole	A hole made with a drill, auger, or other tools for exploring strata in search of minerals, supplying water for blasting, emplacing waste, proving the position of old workings or faults, or releasing accumulations of gas or water. Boreholes include core holes, dry-well-monitoring holes, waste emplacement boreholes, and test holes for geophysical or ground-water characterization.
B&W	Babcock and Wilcox
Emplacement Borehole cover	A cylindrical metallic cap placed on the end of a vertical or horizontal borehole after the waste containers and shielding plug have been emplaced to limit access, to identify borehole contents, and to prevent the accumulation of debris (vertical borehole). The borehole cover does not serve a shielding or containment function.
Borehole liner	See "emplacement borehole liner."
Cage	A structure that supports several drums stacked vertically.
Canistering	Placing material in a metal canister and welding on a lid. Usually the canister is filled with an inert gas before the lid is welded on.
Canister	As used in this document, a canister is the initial metal receptacle in which solid radioactive waste is placed for transport to the repository. The canister is not intended to meet the 300- to 1,000-yr containment requirement of 10 CFR 60.113(a)(1)(ii)(A).

Caretaker period	A period of time after emplacement of a waste container in a repository, but before the waste is either retrieved from the repository or the waste is permanently entombed by filling and sealing the tunnels, shafts, and ramps necessary for retrieving that waste. It corresponds to the retrievability period.
Cask	A receptacle that holds one or more fuel assemblies, canisters, or disposal containers and provides shielding for highly radioactive materials during transportation or storage.
Cask transfer cart	A rail-mounted motorized vehicle located in the cask transfer areas of the waste-handling buildings.
CE	Combustion Engineering
Certification	Demonstration that a cask meets the NRC requirements for a transport cask.
Closure	1) Final backfilling of the remaining open operational areas of the repository underground facility and boreholes after the termination of waste emplacement, culminating in the sealing of the shafts. 2) Any lid, door, etc. used to seal a container, borehole or room.
Commercial high-level wastes	High-level radioactive wastes generated in private industrial and other nongovernment facilities.
Consolidation	The operation performed on spent fuel assemblies during which the upper and lower fuel assembly tie plates are removed, the assembly spacer grids and any other assembly structural members are removed, and the fuel rods are collected and formed into a closely packed bundle for insertion into a canister or container. The nonfuel structural members of the fuel assemblies are reduced in volume and placed in canisters or containers for shipment and disposal.
Containerization	Placing wastes in a container that is designed to assist in attaining long-term waste form integrity in a geologic repository.
Container (disposal container or waste container)	The metal barrier portion of the waste package that is placed around the waste form. The container meets the 300- to 1,000-yr containment requirement of 10 CFR 60 113(A)(1)(ii)(A).

Contamination barrier	A cylindrical mechanism that connects the top of a cask standing on its bottom end to a port in the ceiling above the cask. This mechanism minimizes air exchange between the room containing the cask and the room connected to the top of the cask.
Contamination barrier adaptor	A round metallic plate with a hole in the center the size of the hole at the top of an open cask. The plate is placed on the top of the cask to assist in making up the contamination barrier between the top of the cask and the ceiling above the cask.
Conventional mining	Drill-and-blast mining.
Decommissioning	The permanent removal from service and demolition of surface facilities and components in accordance with regulatory requirements and environmental policies.
Decontamination	The removal of unwanted material (especially radioactive material) from the surface of, or from within, a component.
Dedicated train	A train that transports a shipment from the origin to the destination without switching of the freight cars between trains. There may be multiple origins and destinations clustered near the two ends of a long shipment.
Defense high-level wastes (DHLW)	High-level radioactive wastes generated by activities related to the national defense program, including the manufacture of nuclear weapons, the operation of naval reactors, and research and development at weapons laboratories.
Disposal	The emplacement in a repository of high-level radioactive wastes, spent nuclear fuel, or other highly radioactive material with no foreseeable intent of recovery, whether or not such emplacement permits the recovery of such waste.
Drift	Horizontal, or nearly horizontal, mined passageway.
Drill-and-blast mining	A method of mining in which holes are drilled into the rock and then loaded with explosives. The blast from the explosives breaks the rock so that the rock can be removed. The underground opening is expanded by repeated drilling and blasting.
Emplacement	The act of placing waste containers in prepared positions in the repository. The method of waste emplacement assumed here is based on emplacement of a single waste container in a shallow vertical borehole in the floor of the emplacement drift.

Emplacement borehole liner	A sleeve placed in a vertical or horizontal borehole to prevent sloughed rock from interfering with the emplacement or removal of waste packages. The liner does not serve a shielding or containment function. The liner runs the complete length of horizontal boreholes, but, in vertical boreholes, extends only from the mouth of the borehole to just below the shoulder of the emplaced waste container.
Emplacement drift	A drift in which waste emplacement boreholes are located.
Emplacement horizon	The specific geologic stratum, or portion thereof, in which waste will be emplaced below the earth's surface. A portion of the Topopah Spring Member of the Paintbrush Tuff is currently the target emplacement horizon at the Yucca Mountain candidate site.
End fittings (of spent fuel assemblies)	Part of the mechanical support structure of fuel assemblies.
FFTF	Fast Flux Test Facility
First-class railroad	A railroad with rails of sufficient strength and radii of curvature to permit operation of loaded freight trains at normal maximum speeds.
Fuel assembly	A single mechanical unit consisting of a number of fuel rods held together by a mechanical support structure designed to maintain proper spacing of the fuel rods and facilitate their handling.
Fuel assembly hardware	The non-fuel-bearing mechanical support structure and component of a fuel assembly that is excess waste left after consolidation.
Fuel rod	A long, slender, cylindrical tube (usually made of stainless steel or Zircaloy) containing nuclear fuel in the form of uranium oxide fuel pellets. Also called "fuel pin."
Functional description	A description of the activities or operations in a flow diagram. The level of the description corresponds to the level of the flow diagram.
GA	General Atomics
GE	General Electric

Geologic repository	A system for the disposal of radioactive wastes in excavated geologic media. A geologic repository includes 1) the geologic repository operations area and 2) the portion of the geologic setting that provides isolation of the radioactive waste and is located within the controlled area.
HANF	Hanford
High-level radioactive wastes	As used in this document, the solidified highly radioactive material resulting from the reprocessing of spent nuclear fuel that contains fission products in sufficient concentrations; and other highly radioactive material that the NRC, consistent with existing law, determines by rule to require permanent isolation.
Impact limiter	A structure that reduces damage to the cask or its contents by impact during accidents.
INEL	Idaho National Engineering Laboratory
Inner lid	This lid seals the inner cask cavity and contains the inner cask atmosphere-sampling ports.
Intact SFA	An LWR fuel assembly that has no defects that would make consolidation undesirable.
Intermodal transport	Transport of casks between facilities by use of two types of transport (truck, rail or barge) during a shipment.
Lag storage	Any storage area where process materials can be stored between process activities.
Level 0 flow diagram	A diagram showing the general flow of materials between the major facilities of a system.
Level 1 flow diagram	A diagram showing the general flow of materials through the principal activities in each of the facilities and activities shown in a Level 0 flow diagram.
Level 2 flow diagram	A diagram showing the general flow of materials through the principal operations in each of the principal activities in a Level 1 flow diagram.
LWR	Light water reactor
Low-level wastes (radioactive)	Radioactive material that is neither high-level wastes, spent nuclear fuel, transuranic wastes, or by-product material as defined in Section 11e(2) of the Atomic Energy Act of 1954.

MTR	Materials Test Reactor
NFBC	Non-fuel bearing components of a spent fuel assembly
Outer lid	The secondary containment seal for the cask (the inner lid is the primary seal). The outer lid may contain a port for sampling the atmosphere in the cavity between the inner and outer lids.
Overpack	Any receptacle, wrapper, box, or other structure that becomes an integral part of a radioactive waste package and is used to enclose a waste container for purposes of providing additional protection or for meeting the requirements of an acceptance or isolation criterion for a specific site. An overpack is often used to encase a damaged or contaminated waste package for which repair or decontamination is impractical.
Personnel barrier	A structure on a cask transport vehicle that prevents human contact with the cask.
Physical description	A description of the facilities and equipment needed for accomplishing the activities or operations described in a functional description. The level of the description corresponds to the level of the functional description.
Primary storage	Original storage facilities, e.g., spent fuel storage pool at a reactor.
Retrievability period	The time during which emplaced wastes are capable of being retrieved. For design purposes, this period begins with emplacement of the first wastes and ends 50 years thereafter at the end of the caretaker period.
Retrieval	The act of intentionally removing radioactive wastes from the underground location at which the waste had been previously emplaced for disposal.
RHTRU	Remotely handled transuranium wastes
SFA	Spent fuel assembly
SHLW	Solidified high-level wastes
SNF	Spent nuclear fuel
Secondary storage	Supplemental storage, e.g., dry storage casks at a reactor site.
Shadow shield	A movable radiation shield placed between a radiation source and an area occupied by workers.

Single-Phase Facility	A facility that is built in its entirety before waste handling activities begin. This contrasts to multiple-phase facilities at which waste handling activities begin as soon as construction of a part of the facility is completed even though construction of other parts of the facility is not completed.
SRP	Savannah River Plant
Storage cask	A cask that can be used for storing radioactive materials onsite but is not certified for transporting radioactive materials offsite.
S/T Cask	A cask licensed for both storage and transportation of wastes.
Three-Phase Facility	A facility built in three phases. As each phase is completed, that portion of the facility begins operating.
Transfer cask	A cask for transporting radioactive materials onsite. It is not certified by the NRC for transporting radioactive materials offsite.
Transport cask	A cask certified by the NRC for transporting radioactive materials offsite.
Tuff	A compacted pyroclastic deposit of volcanic ash and dust that contains rock and mineral fragments incorporated during eruption or transport.
Two-Phase Facility	A facility built in two phases. As each phase is completed, that portion of the facility begins operating.
Waste	As used in this document, high-level radioactive wastes, spent fuel or other material requiring geologic disposal.
WE	Westinghouse Electric
West Valley Reprocessing Plant	The West Valley Spent Fuel Reprocessing Plant is the only commercial reprocessing plant ever to operate in the U.S. It is located at West Valley, New York, and was shut down in 1971. A large inventory of liquid HLW remains, which when solidified as a borosilicate glass, will be sent to the repository for disposal.

APPENDIX C

PROCEDURE FOR COMPILING A SPECIFIC SYSTEM DESCRIPTION

APPENDIX C

PROCEDURE FOR COMPILING A SPECIFIC SYSTEM DESCRIPTION

The following discussion outlines a step-by-step procedure for compiling a scenario-specific system description based on the modular description information provided in this document.

1. Define the scenario to be modeled and select the appropriate component modules (see Table 1.2).
2. For Section 1.0, select the appropriate Level 0 flow diagram from Figures 1.1 to 1.7 for inclusion and draft an introduction appropriate to the specific case being described.
3. For Section 2.0, Level 1 Functional Description:
  - (a) Prepare the Level 1 functional flow diagram for the selected system by deleting unused functions from the universal flow diagram in Section 2.0 (Figure 2.1).
  - (b) Prepare the Level 1 functional description by selecting the descriptions to match the flow diagram. Delete the superscripts on the functional descriptions that identify the module numbers.
  - (c) Modify the introductory text to this section as appropriate.
4. For Section 3.0, combined Level 2 and 3 Functional Description:
  - (a) Modify the introductory text in this section as appropriate.
  - (b) Select the matching Level 1 and combined Level 2 and 3 functional flow diagrams for each module and select descriptive text to match the combined Level 2 and 3 flow diagrams.
  - (c) Delete all references to modules.
5. For Section 4.0, Physical Description of System:
  - (a) Modify introductory text as appropriate.
  - (b) Select appropriate waste canister and container information from Table 4.1 and Figures 4.1 and 4.2, and select the applicable Figure 4.3 through 4.9 to represent the flow of wastes, canisters and containers through the system.

- (c) Select the appropriate physical description information for each of the required modules necessary to provide a complete description.
  - (d) If Module 3A, 3B, 3C, or 3D is used: delete the unneeded three columns labeled M3A, M3B, M3C and M3D in Tables 4.22 and 4.23 and change the heading over the remaining column to "Number of Units."
  - (e) If Module 4B, 4C, 4D, 4E, 4F, 4G, 4H, or 4I is used: delete all columns in Tables 4.44, 4.45, and 4.46 labeled with module numbers except for the columns labeled with the module number for the module being used and change the headings over the remaining columns by deleting the references to modules.
6. Change all figure, table and section numbers to provide appropriate continuity for the selected document format.
  7. Review contents of entire description and revise or edit text as appropriate to provide a complete and well-ordered description.
  8. If this modular description is used to describe a system configuration other than those identified in Section 1.0, the procedure may have to be modified somewhat, but the basic elements will be closely similar and some new details may have to be developed.

DISTRIBUTION

No. of
Copies

No. of
Copies

OFFSITE

- 12 DOE/Office of Scientific and
Technical Information
- 9 Office of Civilian Radioactive
Waste Management
U.S. Department of Energy
1000 Independence Ave., S.W.
Washington, DC 20585
ATTN: J. H. Carlson
C. H. Brooks
S. E. Gomberg
C. Kouts
W. Lemeschewsky
T. Nguyen
M. Senderling
T. Truong
J. R. Williams

D. H. Giesler
Yucca Mountain Project Office
U.S. Department of Energy
P.O. Box 98518
Las Vegas, NV 89183-8518

C. A. MacKay
Battelle, Pacific Northwest
Laboratories
370 L'Enfant Promenade
Suite 900
Washington, DC 20024-2115

- 4 E. R. Johnson & Associates,
Inc.
9302 Lee Hwy. #700
Fairfax, VA 22031
ATTN: B. M. Cole
E. R. Johnson
N. B. McLeod
M. White
- 4 Oak Ridge National Laboratory
P.O. Box 2008
Oak Ridge, TN 37831
ATTN: D. Joy
J. Nehls
K. Notz
P. Johnson
- 10 TRW Environmental Safety
Systems, Inc.
10306 Eaton Place
Fairfax, VA 22030
Attn: W. Bailey
G. Carruth
L. Ford
P. Gottlieb
C. Kerrigan
D. Nitti
B. Packer
F. Ridolphi
S. Sareen
L. Wildman

DOE Richland Field Office

D. C. Langstaff

No. of
Copies

No. of
Copies

ONSITE

22 Pacific Northwest Laboratory

G. J. Konzek
M. R. Kreiter
J. L. McElroy
R. W. McKee (2)
G. W. McNair
S. J. Mitchell
D. R. Payson
M. R. Shay
S. M. Short
R. I. Smith
D. L. Stiles
S. A. Vance
R. C. Walling
T. W. Wood
J. R. Young
Publishing Coordination
Technical Report Files (5)

END

**DATE
FILMED**

11 / 3 / 92