DOE/BC/14600-33
Distribution Category UC-122

A Three-Dimensional Laboratory Steam Injection Model
Allowing In Situ Saturation Measurements

DOE/BC/14600--33
DE92 001059

SUPRI TR 83

By
Birol M.R. Demiral
Paul A. Pettit
Louis M. Castanier
William E. Brigham

August 1992

Work Performed Under Contract No. DE-FG22-90BC14600

Prepared for
U. S. Department of Energy
Assistant Secretary for Fossil Energy

Thomas B. Reid, Project Manager
Bartlesville Project Office
P. O. Box 1398
Bartlesville, OK 74005

Prepared by
Stanford University
Petroleum Research Institute
Stanford, CA 94305-4042

MASTER

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

Abstract

The CT imaging technique together with temperature and pressure measurements were used to follow the steam propagation during steam and steam foam injection experiments in a three dimensional laboratory steam injection model. During the design period, the advantages and disadvantages of different geometries were examined to find out which could best represent radial and gravity override flows and also fit the dimensions of the scanning field of the CT scanner. As a result of this analysis a 3D rectangular box with dimensions 20x20x7.5 cm was constructed. This box simulates one quarter of a five spot pattern. Aluminum, TeflonTM and FiberfraxTM were chosen as supporting and insulating materials. TeflonTM was placed between the porous medium and the aluminum shell so that the rate of heat transfer in the porous medium would be much faster than that in the aluminum during a steam injection run. During experiments, steam was injected continuously at a constant rate into the water saturated model and CT scans were taken at six different cross sections of the model. Pressure and temperature data were collected with time at three different levels in the model. CT pictures and three dimensional temperature distributions were compared and analyzed in terms of observed steam zone at each section. To do that, CT numbers within the scan section were used to determine the steam and water zones, and with the aid of x-ray pictures the position and propagation of the steam zone were determined. In addition, using the three dimensional temperature distribution measurements at the same times, steam displacement fronts could be drawn at the scan section locations. These pictures and drawings were used to compare the results obtained from classical temperature-pressure monitoring and from CT scans.

During steam injection experiments the saturations obtained by CT matched well with the temperature data. That is, the steam override as observed by temperature data was also clearly seen on the CT pictures.

During the runs where foam was present, the saturation distributions obtained from CT pictures showed a piston like displacement. However, the temperature distributions were different depending on the type of steam foam process used. During the experiment which included non-condensable gas (nitrogen) injection, the temperature distributions, contrary to the saturation distributions, still indicated the presence of steam override, although the override was reduced by the foam. However, when there was no nitrogen the temperature distributions followed the saturation distributions. This may possibly indicate that the nitrogen foam ahead of steam foam caused the difference between temperature and saturation distributions. These results clearly show that the pressure/temperature data alone are not sufficient to study steam foam in the presence of non-condensable gas.

Contents

Acknowledgements	ii
Abstract	iii
List of Tables	vi
List of Figures	vii
1 Introduction	1
2 SUPRI 3D Laboratory Steam Injection Model	2
2.1 Design and Development	2
2.2 Preliminary Heat Transfer Calculations	4
2.3 The Final 3D Model	7
2.4 Locations of Thermocouples and Pressure Taps	9
3 Steam and Steam Foam Injection Experiments	11
3.1 Experimental Setup	11
3.2 Experimental Procedure and Program	11
3.2.1 General Experimental Procedure	11
3.2.2 CT Scan Procedure	13
3.2.3 Experimental Program	13
3.2.4 Analysis of the Data	13
3.3 Control Run	17
3.4 Continuous Steam Injection	17
3.5 Steam Foam Injection with Nitrogen	19
3.6 Steam Foam Injection without Nitrogen	21
3.7 Nitrogen Foam	24
3.8 Discussion of the Results	28
3.8.1 Comparison of the Saturation Distributions	28
3.8.2 Comparison of the Rate of Heat Loss	30
3.9 Importance of the CT Scanner in this Study	36
4 Conclusions	38
References	39

A	3D Model Operation Principles	40
A.1	Control Panel	40
A.1.1	Injection Control	40
A.1.2	Valves	40
A.1.3	Demodulators and Heater Controllers	43
A.1.4	Gauges	43
A.1.5	Data Logger Connection Ports	43
A.1.6	Pressure Lines	45
A.2	Prerun Routine	45
A.2.1	Signal Connections	45
A.2.2	3D Model Connections	47
A.2.3	Pressure Line Connections	50
A.3	Computer Programs	50
A.3.1	Data Logging Programs	50
A.3.2	Temperature and Pressure Analysis Programs	52
B	Computer Program for the Pressure Transducer Calibration	56
C	Computer Program for Data Logging	63
D	Computer Program for Data Preparation for Areal Temperature Distributions	76
E	Computer Program for Data Preparation for Sectional Temperature Distributions	78

List of Tables

3.1	Scanner Settings	14
3.2	Positioning Table Indicator Settings	15
3.3	Experimental Conditions	16
A.1	Signal Connections on Signal Port 1	53
A.2	Signal Connections on Signal Port 2	54
A.3	Signal Connections on Signal Port 3	55

List of Figures

2.1	Cylindrical Shape 3D Model (Proposed)	3
2.2	Pie Shape 3D Model (Proposed)	3
2.3	3D Diamond Shaped Model (Proposed)	4
2.4	Proposed 3D Box	5
2.5	Insulation Varieties	5
2.6	Composite Wall Representation of the Insulator	6
2.7	Parallelepiped Shell Assumption	7
2.8	Total Heat Loss Rate with Different Insulation Material Combinations	8
2.9	Effect of Steam Injection Rate and the Thickness of Fiberfrax [®] on Total Heat Lost After 1 PV Steam Injection	8
2.10	Locations of Thermocouples and Pressure Taps Along the Injector Producer Cross-Section of the 3D Model	8
2.11	A-A' Cross-section of the Injection Well	9
2.12	Areal Locations of Thermocouples and Pressure Taps of 3D Model	10
3.1	Schematic Flow Diagram of the Experimental Setup	12
3.2	CT Scanner Positioning System	13
3.3	Positioning Scan Slices in the 3D Model	14
3.4	The Saturation and Temperature Distributions During Continuous Steam In- jection at 0.04 PV Steam Injected	17
3.5	The Saturation and Temperature Distributions During Continuous Steam In- jection at 0.30 PV Steam Injected	18
3.6	The Saturation and Temperature Distributions During Continuous Steam In- jection at 0.54 PV Steam Injected	18
3.7	The Saturation and Temperature Distributions During Continuous Steam In- jection at 1.31 PV Steam Injected	19
3.8	The Saturation and Temperature Distributions During Steam Foam Injection with Nitrogen at 0.05 PV Steam Injected	20
3.9	The Saturation and Temperature Distributions During Steam Foam Injection with Nitrogen at 0.30 PV Steam Injected	20
3.10	The Saturation and Temperature Distributions During Steam Foam Injection with Nitrogen at 0.51 PV Steam Injected	21
3.11	The Saturation and Temperature Distributions During Steam Foam Injection with Nitrogen at 0.58 PV Steam Injected	22
3.12	Behavior of Total Pressure Drop Along the Injector-Producer Diagonal During Steam Foam Injection With Nitrogen	22

3.13	The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 0.05 PV Steam Injected	23
3.14	The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 0.32 PV Steam Injected	23
3.15	The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 0.54 PV Steam Injected	24
3.16	The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 0.69 PV Steam Injected	25
3.17	The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 0.92 PV Steam Injected	25
3.18	The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 1.25 PV Steam Injected	26
3.19	Behavior of Total Pressure Drop Along the Injector-Producer Diagonal During Steam Foam Injection Without Nitrogen	26
3.20	The Saturation Distributions During Nitrogen Foam Injection at 6.80 PV Nitrogen Injected	27
3.21	The Saturation Distributions During Nitrogen Foam Injection at 12.30 PV Nitrogen Injected	27
3.22	The Saturation Distributions During Nitrogen Foam Injection at 24.15 PV Nitrogen Injected	28
3.23	Comparison of Steam Injection Experiments at 0.05 PV Steam Injected . . .	29
3.24	Comparison of Steam Injection Experiments at 0.30 PV Steam Injected . . .	29
3.25	Comparison of Steam Injection Experiments at 0.54 PV Steam Injected . . .	30
3.26	Locations of Heat Flux Sensors	30
3.27	Rate of Heat Loss From Sensor I-RIGHT	31
3.28	Rate of Heat Loss From Sensor P-RIGHT	31
3.29	Rate of Heat Loss From Sensor P-LEFT	32
3.30	Rate of Heat Loss From Sensor I-LEFT	32
3.31	Rate of Heat Loss From Sensor TOP	33
3.32	Rate of Heat Loss From Each Sensor During Continuous Steam Injection . .	34
3.33	Rate of Heat Loss From Each Sensor During Steam Foam Injection with Nitrogen	34
3.34	Rate of Heat Loss From Each Sensor During Steam Foam Injection without Nitrogen	35
3.35	A Typical Areal Temperature Distribution	35
3.36	The Comparison of the Actual and Assumed Rate of Heat Loss	36
A.1	Schematic of the Control Panel	41
A.2	Valves on the Control Panel	42
A.3	Demodulators and Heater Controllers Part of the Control Panel	43
A.4	Sideview of the Control Panel	44
A.5	Schematic Signal Connection System	46
A.6	Front Positioning Table	47
A.7	Back Positioning Table	47
A.8	Schematic of Injection Side Connections of 3D Model	49
A.9	Schematic of Production Side Connections of 3D Model	50
A.10	Screen Appearance During Pressure Transducers Calibration	51

A.11 Screen Appearance During Data Logging	51
--	----

1. Introduction

We don't know if Mr. Hounsfield could imagine that the range of applicability of CT Scanners would be that wide when he first invented the idea in 1972 [1]. Today, CT Scanners are being used in many areas from medical sciences to earth sciences. Although the application of CT to Petroleum Engineering problems is not that old, many institutions have CT Scanners in their research labs.

A CT Scanner in a petroleum research laboratory can be used as a useful tool for in situ saturation and porosity determinations and investigations of core flood experiments [2, 3, 4, 5, 6], comparison of simulation results with core flood experiments [2], and EOR applications [2, 3, 7, 8, 9]. Although CT scanners have been used to investigate the mechanisms of some EOR processes, these experiments were mainly carried out in linear models, with only a few in 3D ones. This leads to poor representation of phenomena such as gravity override and channelling. On the other hand CT scanners aren't used for applications where high temperature and pressure play the main role as they do in thermal recovery processes. This is because the high pressure and temperatures involved in laboratory simulation of thermal EOR methods require metallic core holders making it difficult to use x-ray absorption techniques. The mechanisms of these processes, specifically steam and steam foam injection, have been investigated by using material balance techniques together with temperature and pressure data. Nevertheless, the displacement mechanisms during steam or steam foam processes could be examined in a better way if the in situ fluid saturations are known. Since CT scanning has been proven to be a useful tool in determination of in situ fluid saturations, a laboratory model with x-ray scanning capability would be helpful in understanding displacement mechanisms during steam and steam foam injection experiments.

In this study a three dimensional laboratory model is designed and constructed such that it can be used to measure temperature, pressure and heat loss data. The model is also designed in a way that its construction material is not a limiting factor during scanning. The main advantage of this comprehensive data gathering approach is to offer new insight into the mechanisms of oil displacement by steam and steam foam.

This report gives the details of design steps and describes the model built. The reader will also be provided detailed operational procedures and data acquisition computer programs as well as the analysis of a sample steam injection run.

2. SUPRI 3D Laboratory Steam Injection Model

In this section we describe the steps leading to the final design of the model. The operating principles and the operation manual for the final 3D model and its experimental apparatus can be found in APPENDIX A.

2.1 Design and Development

The objective of a 3-D laboratory model is to represent the mechanisms of field applications as realistically as possible in the laboratory. The starting point originally was to have radial flow in the model, and it was proposed to have a cylindrical shape for the model as shown in Figure 2.1. Although this model had the advantage of complete radial flow, it had some obvious disadvantages too:

1. Considering the dimensions of the scanning field of the SUPRI CT scanner (maximum 33.02 cm), the distance between the injector and the producing zone would be only 10 cm.
2. It would be difficult to sustain a uniform back pressure in the producing zone.
3. It would be almost impossible to clean, dry, and saturate the model between runs.

Considering the importance of these disadvantages, the proposed design was changed to a pie shape (Figure 2.2) so that the injector/producer distance could be increased to 20 cm. There would be complete radial flow due to the cylindrical symmetry of the model. However, this symmetry introduced large heat losses from the sides. Also, the asymmetry at the producing annulus was a problem. There also were the other disadvantages of the previously proposed cylindrical shape, namely, sustaining constant back pressure in the producing zone and cleaning and saturation problems.

The next proposed shape was a diamond shaped model, obtained by adding a triangular area to the producing zone of the pie shaped model as shown on Figure 2.3. By so doing, the asymmetry and the difficulty of sustaining a uniform backpressure at the producing zone of the pie shaped model were eliminated. As shown, the diamond shaped model had only one producing corner instead of a large producing zone. However, the problems of heat losses through the sides and saturating the model after each run were left unsolved.

Considering the disadvantages of a diamond shape it was decided to construct a 3-D box which would represent 1/4th of a 5 spot pattern. However, all temperature and pressure readings would be done in the diamond part of the box as shown in the shaded portion in Figure 2.4. By so doing, it would be assumed that the heat losses through the sides of the diamond would be acceptable as compared to that for the previously proposed shapes. This was later changed to monitoring temperatures and pressures everywhere in the system, since scanning through the model would be difficult as discussed later.

Figure 2.1: Cylindrical Shape 3D Model (Proposed)

Figure 2.2: Pie Shape 3D Model (Proposed)

Figure 2.3: 3D Diamond Shaped Model (Proposed)

As can be seen from the injector producer diagonal cross-section of the model, the heat insulation (Teflon[®]) is in direct contact with the porous medium. We felt it was necessary to use Teflon in contact with the porous medium because of chemical and temperature stability. Fortunately Teflon has a fairly low thermal conductivity ($0.1333 \text{ BTU/hr}^\circ\text{F ft}$). The rate of heat transport in the porous medium (by means of conduction and convection) would be much faster than that of conductive heat transport in the aluminum construction material. Aluminum was necessary to support the Teflon for strength under the proposed pressure and temperature conditions. Aluminum was chosen as the construction material since it absorbs less x-ray energy than other metallic materials. The Teflon box was sealed against gas or liquid leaks by using Chemgrip[®], a special epoxy which bonds Teflon to Teflon or Teflon to metal.

While searching for the optimum heat insulation system for the model, we considered Kynar[®] (a high molecular weight thermoplastic polymer) as an additional insulator as shown in Figure 2.5. The thermal conductivity of Kynar is almost half that of Teflon ($0.0667 \text{ BTU/hr}^\circ\text{F ft}$ versus $0.1333 \text{ BTU/hr}^\circ\text{F ft}$). With the same insulation thickness, the resistance to heat flow will be increased using Kynar. This difference will be discussed later. However, Kynar had disadvantages such as cost and working temperature. The cost of Kynar was almost \$500.00 for a square foot plate, and the working temperature was 300°F maximum. We concluded that another insulation material as good as Kynar was necessary. We chose Fiberfrax[®], a ceramic fiber insulating material which is inexpensive and can be applied as a wet putty which air dries to a semi-permanent cast. Its thermal conductivity is even less than that of Kynar ($0.04830 \text{ BTU/hr}^\circ\text{F ft}$ at 320°F).

2.2 Preliminary Heat Transfer Calculations

Although we would like to prevent heat losses through the walls of the model, there will be some heat loss during the experiments. This heat loss should be computed to decide:

1. the total thickness of the insulation (within the limits of the scanning area) and the relative ratios of Teflon and Fiberfrax (or Kynar) thicknesses.
2. the optimum steam injection rate for which a steam zone could develop.

Preliminary heat calculations were made assuming steady state conditions at steam temperature on the inner surface of the 3-D model. The resultant calculated heat loss would be a maximum estimate and design values for insulation material and steam injection rate would be within allowable limits. Assumptions used were:

1. The 3-D model is surrounded by a composite heat insulator as seen in Figure 2.6.

Figure 2.4: Proposed 3D Box

Figure 2.5: Insulation Varieties

Figure 2.6: Composite Wall Representation of the Insulator

2. The inner surface temperature of this insulator is suddenly brought to the steam injection temperature ($313^{\circ}F$ at 70 psig). The calculated heat loss using this assumption will be a maximum for a steam injection experiment in this model.
3. Steady state heat transfer conditions prevail.
4. The heat transfer mechanism between the outer surface of the insulator and air (at $68^{\circ}F$) is natural convection only.

Thermal resistance of this model can be written using the analogy between heat transport and Ohms law:

$$R_t = \sum_{i=1}^3 \left[\frac{x}{kA} \right]_i + \frac{1}{h_{film}A} \quad (2.1)$$

Hence the rate of heat loss is:

$$\dot{Q}_L = \frac{T_s - T_{\infty}}{\sum_{i=1}^3 \left[\frac{x}{kA} \right]_i + \frac{1}{h_{film}A}} \quad (2.2)$$

The cross-sectional area to heat flow for a 3D box is not constant but increases from inside to outside. Therefore the shape factor for a parallelepiped shell is introduced:

$$S = \frac{A_i}{x} + 2.16(a + b + c) + 1.2x \quad (2.3)$$

where:

A_i = inside area

a, b, c = inside dimensions

x = the thickness of the shell in Figure 2.7

Figure 2.7: Parallelepiped Shell Assumption

In this shape factor the edges and the corners of the box were considered. The rate of heat loss can be determined from:

$$\dot{Q}_L = \frac{T_s - T_\infty}{\sum_{i=1}^3 \left[\frac{1}{kS} \right]_i + \frac{1}{h_{film} A_{out}}} \quad (2.4)$$

where:

S_1 = shape factor for Teflon, *ft*

S_2 = shape factor for aluminum, *ft*

S_3 = shape factor for Kynar or Fiberfrax, *ft*

A_{out} = Outside area of 3-D model, *ft*²

Using Equation 2.4 for different combinations of thicknesses of insulation materials, the rate of heat loss was calculated and graphed in Figure 2.8. In these calculations the thickness of aluminum was kept constant at 1/4 in. After analyzing this figure we decided that the thickness of Teflon should be at most 0.3 in. Then, keeping both Teflon and aluminum thicknesses constant at 0.25 inches, we calculated the total heat lost during a steam injection run in which 1.0 PV of steam was injected for different injection rates of steam as cold water equivalent (Figure 2.9). From this figure it can be noticed that it is impossible to have a growing steam zone in the model at a rate of 2.00 cc/min, if the thickness of Fiberfrax is below 0.5 in. So we decided to have a fiberfrax thickness of 0.75 inch.

2.3 The Final 3D Model

The diagonal injector-producer cross-section of the finalized 3D model is given in Figure 2.10. As seen from this figure,

- the top cover of the box has been modified such that the cover can compress the porous medium to assure there is no gas cap above it.

Figure 2.8: Total Heat Loss Rate with Different Insulation Material Combinations

Figure 2.9: Effect of Steam Injection Rate and the Thickness of Fiberfrax[®] on Total Heat Lost After 1 PV Steam Injection

Figure 2.10: Locations of Thermocouples and Pressure Taps Along the Injector Producer Cross-Section of the 3D Model

Figure 2.11: A-A' Cross-section of the Injection Well

- the injection well system is designed to allow injection of 100 % steam through the total depth of the well. This is done by introducing a heater cartridge within an aluminum rod through which the steam flows. Figure 2.11 shows the detailed cross-section of the injector..
- the main insulation sequence used was to be Teflon, Aluminum, Fiberfrax, from inside to outside.
- the thermocouples were positioned such that they could give measurements at three different levels in the model. The top thermocouples are located at 2.75 inches, the center ones are at 1.50 inches, and the bottom ones are at 0.25 inches from the bottom. The areal distribution of the thermocouples will be discussed in the next section.
- the pressure taps are located with the center thermocouples. This was achieved by using a special tee fitting which allowed us to use the thermocouple entry holes as outlets for the pressure lines.
- Heat flux sensors are located at four sides and on the top of the model. The general working principles of these sensors were discussed by Shallcross and Wood [10]. These were used to study the heat loss during the steam injection experiments.

2.4 Locations of Thermocouples and Pressure Taps

Thirty four type J thermocouples and sixteen pressure taps are distributed in the model as shown in Figure 2.12. Sixteen of the thermocouples are center thermocouples which are placed 1.5 inches from the bottom. The pressure taps are also located at the same places but they read the pressure at the very bottom of the model. Nine bottom and nine top thermocouples are placed 0.25 and 2.75 inches from the bottom of the model.

Figure 2.12: Areal Locations of Thermocouples and Pressure Taps of 3D Model

3. Steam and Steam Foam Injection Experiments

This section discusses the experimental program performed to date as well as some of the results.

3.1 Experimental Setup

The general experimental setup, as seen on Figure 3.1, consists of three parts: injection system, 3D steam model and production equipment.

Injection End: Two liquid chromatography pumps are used to inject water or surfactant solution and to feed the steam generator with distilled water.

There is also a gas mass flow controller which can be used to inject nitrogen at a constant rate into the model during the experiments.

3D Steam Model: The details of the 3D steam model were discussed earlier in Section 2.3.

The model is packed with unconsolidated +25-30 mesh size Ottawa sand. The average porosity is 39 % and the absolute permeability is 25 Darcies.

Production End: A back pressure regulator maintains a constant pressure at the producing corner of the model. A cooler is used to condense the produced steam.

3.2 Experimental Procedure and Program

Two simultaneous procedure were followed during the experiments:

- General experimental procedure
- CT scan procedure

These will be discussed next in detail.

3.2.1 General Experimental Procedure

During the experiments the model was first saturated with distilled water, then either steam or nitrogen was injected depending on the experiment type. In the case of continuous steam injection runs, steam is injected at a constant rate of cold water equivalent. During the steam foam injection experiments, steam is injected continuously until a gravity override is observed from both temperature data and CT pictures. Then, the steam injection is stopped, and a 5 % PV slug of 0.25 weight % AOS2024 solution is injected. The steam injection is restarted together with nitrogen when the slug injection is completed. The pressure and temperature data are collected by means of a data logging device every 30 seconds. The production data is collected by a sampling device at every 20 cc of liquid production.

Figure 3.1: Schematic Flow Diagram of the Experimental Setup

Figure 3.2: CT Scanner Positioning System

3.2.2 CT Scan Procedure

The CT scanner used in this study is an EMI 5005 X ray scanner. This is a second generation machine allowing energy levels from 80 keV to 140 keV and an image capability of 320x320 pixels. The importance and the details of this scanner will be discussed in Section 3.9.

The model was scanned at six different locations during the experiments. These scans were taken through the 1.5 cm. clearance between the thermocouples (Section 2.4, Figure 2.12). Scan combinations are given on Table 3.1. With these combinations the total scan time for six slices is 10.38 minutes if they are processed one by one after each slice, and 12.23 minutes if all six slices are processed after completion of all of them. During the experiments we processed the scan pictures one by one such that at about every 11 minutes we could start a new scan session composed of six slices. Scanning and processing one slice at a time gave us enough time between scans to enter the CT Scanner room to position the model at the same scan locations using the positioning table given in Figure 3.2.

The positioning table indicator should be set at the proper distance for each slice location so the same locations will be scanned each time. These locations are given on Table 3.2

3.2.3 Experimental Program

Six experiments were carried out in the model. The experimental conditions are given on Table 3.3.

3.2.4 Analysis of the Data

Figure 3.3 shows how the six scan slices are used to present the 3D saturations. These sections are arranged as shown from the injector to the producer as they appear in the model. The view of the model has been slanted for better 3D presentation. The same approach was followed to image the three dimensional temperature distributions at the same times. They are presented in figures as two slanted boxes on top of each other, the top one being the saturation distributions and the bottom one being the temperature distributions.

Table 3.1: Scanner Settings

Type	Setting
Energy Level	140 keV
Detectors	6
References	7
Photomultiplier Status	7
Scan Mode	4 (160)
Scan Speed	Normal

Figure 3.3: Positioning Scan Slices in the 3D Model

Table 3.2: Positioning Table Indicator Settings

Slice Number	Indicator Setting
1	0.000
2	0.475
3	0.950
4	1.425
5	1.900
6	2.375

Table 3.3: Experimental Conditions

Experiment Type	Steam Injection Rate (cc/min, cwe)	Amount of N ₂ (mole %)	First Slug Injected at (PV Steam or PV N ₂)	Second Slug Injected at (PV Steam or PV N ₂)
Continuous Steam Inj.	4.00,6.00,8.00	0		
Continuous Steam Inj.	6.00	0		
Steam Foam Injection	6.00	2.00	0.41	
Steam Foam Injection	6.00	0	0.42	0.77
N ₂ Foam Injection	0.00	100.00	10.80	23.10
Steam Foam Injection	6.00	2.00	0.41

Figure 3.4: The Saturation and Temperature Distributions During Continuous Steam Injection at 0.04 PV Steam Injected

3.3 Control Run

For calibration purposes the first run consisted of steam injection at different rates. CT scans were taken that allowed us to study the growth of the steam zone as a function of time, thus verifying the design calculations on heat losses. Steam at 100 water equivalent. It was decided to use 6 cc/min rate for all further experiments. This was the optimum design rate to obtain a growing steam zone in a reasonable time.

3.4 Continuous Steam Injection

The second experiment used continuous steam injection. It will be used as reference test to analyze the other steam/nitrogen, and steam foam experiments. As can be seen from the saturation distribution part of Figure 3.4, after injecting 4 % PV of steam in terms of cold water equivalent an overridden zone started to develop. When 30 % PV of steam had been injected this zone became more apparent as a tongue trying to reach the producing corner from the upper region of the model (Figure 3.5). After breakthrough the steam zone started to heat the rest of the model downward as a steam chest (Figures 3.6 and 3.7). The temperature distributions in these figures showed the same behavior, matching reasonably well with the saturation distributions. At the end of the experiment, although 1.31 PV of steam (as cold water equivalent) had been injected, a large part of the bottom of the model was still unswept.

Figure 3.5: The Saturation and Temperature Distributions During Continuous Steam Injection at 0.30 PV Steam Injected

Figure 3.6: The Saturation and Temperature Distributions During Continuous Steam Injection at 0.54 PV Steam Injected

Figure 3.7: The Saturation and Temperature Distributions During Continuous Steam Injection at 1.31 PV Steam Injected

3.5 Steam Foam Injection with Nitrogen

The next run used steam foam injection with 2 mole % of nitrogen. The first part of the run was similar to the previous experiment. Figures 3.8 and 3.9 indicates that the saturations and the temperature distributions were very close to the previous run after 0.04 and 0.30 PV of cold water equivalent steam injection.

Steam was injected continuously at the same rate until steam override was obvious. At this time, (0.41 PV of steam injected), steam injection was stopped and a 5 %PV slug of 0.25 % (by weight) ENORDET surfactant AOS2024 solution was injected. The injection rate of surfactant solution was kept the same as the steam injection rate (cold water equivalent). After the surfactant slug injection, steam injection resumed together with nitrogen at a rate of 160 cc/min (2 mol % of the injected stream).

The three dimensional saturation distributions within the model suddenly changed, showing almost a piston-like displacement front, as seen in Figures 3.10 and 3.11.

The interesting point here is that the three dimensional temperature distributions, which theoretically are the indicator of steam zone propagation during steam injection experiments, were not changed as much as the saturation distributions. Instead they almost followed the same pattern they had followed during the earlier continuous steam injection experiment of Figures 3.4-3.7. In addition to that effect, there was only a minor change in pressure gradient after foam was created in situ. The saturation distribution at a later time (Figure 3.11) indicate a complete swept after 0.58 PV of steam injection. This stage was never achieved during the continuous steam injection experiment although almost 3 times more steam was injected.

The behavior of total pressure drop along the injector/producer diagonal during this run, like temperature distribution data, also shows that in situ foaming did not do much as seen in Figure 3.12. Nevertheless, there are some interesting points that can be derived from

Figure 3.8: The Saturation and Temperature Distributions During Steam Foam Injection with Nitrogen at 0.05 PV Steam Injected

Figure 3.9: The Saturation and Temperature Distributions During Steam Foam Injection with Nitrogen at 0.30 PV Steam Injected

Figure 3.10: The Saturation and Temperature Distributions During Steam Foam Injection with Nitrogen at 0.51 PV Steam Injected

the pressure drop behavior. The total pressure drop went below zero just after injection of the surfactant solution slug, indicating steam condensation at the injection corner. Then it rose up in response to the in situ foaming at the injection corner. However, this rise was small (around 1-2 psi) and did not last long. These results might have let us to conclude that there was not enough foaming to correct the steam profile, if we had not had saturation distributions to tell us otherwise.

3.6 Steam Foam Injection without Nitrogen

The changes in saturation and temperature distributions seen in the previous experiments led us to make another run which might help to understand and analyze steam foam injection experiments in the presence of non-condensable gas. To do this a steam foam injection experiment was conducted without nitrogen under the same experimental conditions as the previous run. Temperature and saturation distributions before surfactant injection were similar to those in the control run (Figures 3.13 and 3.14).

However, after injection of 5 % PV of 0.25 % (by weight) AOS2024 solution, the steam front was satisfactorily corrected by in situ foaming, as seen in Figure 3.15, although there was no non-condensable gas phase in the system. Another interesting point was that the three dimensional saturation distributions closely matched the temperature distributions.

This result very likely indicates that the nitrogen foam ahead of the steam foam in the previous experiment had caused the difference between temperature and saturation distributions in that previous run.

The low temperature, low saturation zone ahead of the steam front is probably filled by "nitrogen foam", a high quality bank of foam with a large amount of non-condensable gas. It would have been impossible to detect this bank without in-situ saturation measurements.

As seen in Figure 3.16, after 0.69 PV steam injection the propagation of the steam

Figure 3.11: The Saturation and Temperature Distributions During Steam Foam Injection with Nitrogen at 0.58 PV Steam Injected

Figure 3.12: Behavior of Total Pressure Drop Along the Injector-Producer Diagonal During Steam Foam Injection With Nitrogen

Figure 3.13: The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 0.05 PV Steam Injected

Figure 3.14: The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 0.32 PV Steam Injected

Figure 3.15: The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 0.54 PV Steam Injected

foam zone slowed, indicating that the condensation of steam decreases the gas phase in the foam, making it unstable and of low quality.

Seeing this behavior, another 5 % PV slug of surfactant solution at the same concentration was injected at 0.77 PV of steam injected. The saturation and temperature distributions looked much like to those after the first slug, as can be seen in Figure 3.17. However, after an additional 0.50 PV of steam injection the system was almost completely swept by steam (Figure 3.18).

The response of total pressure drop along the injector producer diagonal, although not greatly affected by in-situ foaming, was a bit different from the previous run, as shown in Figure 3.19. The total pressure drop also went below zero after surfactant solution injection indicating the steam condensation at the injection corner. However this time the amount of pressure drop below zero was not as much as it was in steam foam injection run with nitrogen. Neither it persist as long as it did during the previous run. Then as a response to in-situ foaming, the total pressure drop rose. But the rise was smaller than that of in the previous run. The reason for this can be attributed to the lack of nitrogen injection during this experiment.

3.7 Nitrogen Foam

The last experiment was a run to investigate the behavior of nitrogen foam alone, with no steam. Nitrogen was continuously injected at the same rate it would be during a steam foam run until nitrogen started to override as seen in Figure 3.20. Then nitrogen injection was stopped and a 5 % PV slug of 0.25 % (by weight) AOS2024 solution was injected. Gas injection was then resumed. The saturation distributions showed little effect of foaming (Figure 3.21).

Figure 3.16: The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 0.69 PV Steam Injected

Figure 3.17: The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 0.92 PV Steam Injected

Figure 3.18: The Saturation and Temperature Distributions During Steam Foam Injection without Nitrogen at 1.25 PV Steam Injected

Figure 3.19: Behavior of Total Pressure Drop Along the Injector-Producer Diagonal During Steam Foam Injection Without Nitrogen

Figure 3.20: The Saturation Distributions During Nitrogen Foam Injection at 6.80 PV Nitrogen Injected

Figure 3.21: The Saturation Distributions During Nitrogen Foam Injection at 12.30 PV Nitrogen Injected

Figure 3.22: The Saturation Distributions During Nitrogen Foam Injection at 24.15 PV Nitrogen Injected

Subsequently, we injected a bigger slug of surfactant solution (10 % PV). The saturation distributions then showed that the gas was moving downward in the model at a very slow rate (Figure 3.22). The foam, if any, was not very effective as blocking agent in that run. This may be caused by the low rate at which the nitrogen was injected. But clearly the results of all these runs indicate that nitrogen alone is not as good as steam alone, but they two together are superior to either alone.

3.8 Discussion of the Results

In this section a general discussion was made by comparing the experimental results. The comparison is made on two basis: the saturation distributions and the heat losses.

3.8.1 Comparison of the Saturation Distributions

In this section the raw CT numbers, the processed and digitized CT number images, and the digitized temperature images of the first slice of the model, all are presented at the same times during each experiment and are used as a basis for comparisons. Figure 3.23 shows these images at 5 % PV steam injected. The images show similar patterns indicating the reproducibilities of steam injection experiments in this 3D model. Figure 3.24, which is just before surfactant solution injection in the foam runs, shows the extent of gravity override during steam injection applications. Again, the results show good reproducibility. On Figure 3.25, which is after surfactant solution injection, the behavior changed depending on the type of injection process used.

During the steam-foam injection run with nitrogen, the saturation distributions, both from real x-ray images and from digitized CT number images, differ considerably from the temperature distributions (Figure 3.25).

The saturation and temperature distributions of the run without nitrogen behave similarly. This behavior indicates that the temperature distributions in the previous run were following the steam distributions. These results show the important effect of nitrogen on the steam foam processes.

Figure 3.23: Comparison of Steam Injection Experiments at 0.05 PV Steam Injected

Figure 3.24: Comparison of Steam Injection Experiments at 0.30 PV Steam Injected

Figure 3.25: Comparison of Steam Injection Experiments at 0.54 PV Steam Injected

Figure 3.26: Locations of Heat Flux Sensors

3.8.2 Comparison of the Rate of Heat Loss

In this section the measured heat flux data are used to compare the behavior of the experiments. The sensor locations are given in Figure 3.26. In this figure, the sensors are named by their geometric positions. The sensors placed at the left side of the injector-producer diagonal were named as I-LEFT (closer to the injector) and P-LEFT (closer to the producer). Similarly the sensors at the right side of the injector-producer diagonal were named as I-RIGHT (closer to the injector) and P-RIGHT (closer to the producer). Finally, the one on the cover of the 3D model was named, TOP.

Figures 3.27, 3.28, 3.29, 3.30 and 3.31 show the behavior of each sensor during different runs. During the analysis of these figures we will divide the steam foam injection experiments into two parts: (1) continuous steam injection before injection of the first surfactant solution slug, and (2) steam foam injection after the first surfactant solution slug. The behavior of the heat flux sensors are similar during the continuous steam injection run and during the continuous steam injection part of the steam foam injection experiment with nitrogen. By contrast, the rate of heat loss was always less during the continuous steam injection part of the steam foam injection experiment without nitrogen. This situation can only be possible if the runs are not reproducible. However, the previous discussion of the temperature and

Figure 3.27: Rate of Heat Loss From Sensor I-RIGHT

Figure 3.28: Rate of Heat Loss From Sensor P-RIGHT

saturation distributions showed us that they were. The only possible explanation for that discrepancy can be the change in room temperature. The experiments with continuous steam injection and steam foam with nitrogen were carried out in January, one week apart. However the steam foam injection without nitrogen was done in May. The room temperature difference could be as great as 10°C, which could easily result in changes in the heat flux seen during those experiments.

The similar effect is also seen after the first slug injection during the experiments. That is, the rate of heat loss during the steam foam injection without nitrogen was always less than that during the other runs. However, after the second slug injection it caught up with or even became greater than the rate of heat loss during continuous steam injection. This indicates that, during the run with continuous steam injection, the outer surface of the model reached a temperature difference with outside equal to or less than seen during steam foam injection with nitrogen.

Figure 3.29: Rate of Heat Loss From Sensor P-LEFT

Figure 3.30: Rate of Heat Loss From Sensor I-LEFT

Figure 3.31: Rate of Heat Loss From Sensor TOP

If the behavior of these sensors is examined together during each experiment (Figures 3.32, 3.33 and 3.34) it can be seen that the sensors at the right (I-RIGHT) and the left (I-LEFT) sides of the injection corner of the model are the first ones which showed heat flux soon after steam injection started.

The top sensor (TOP) followed the side ones with a delay of about 0.01 PV steam injection. The other two sensors (P-RIGHT and P-LEFT) also had a delay of about 0.01 PV steam injection. However in their case the increase in the rate of heat loss was not as rapid as for the others.

For the runs with continuous steam injection (Figure 3.32) the heat flux rate from every side and from the top stopped increasing once the steam front reached their locations. After that point the heat flux dropped and then stayed constant.

An interesting result here is the rate of heat loss from the symmetric sides of the 3D model are not equal to each other. The rate of heat loss at I-LEFT is always more than that at I-RIGHT during all experiments. And the rate of heat loss at P-RIGHT is greater than that of at P-LEFT during the continuous steam injection and steam foam injection with nitrogen runs. In the case of steam foam injection without nitrogen the rate of heat flux at P-LEFT is less than P-RIGHT. This asymmetrical heat loss indicates the steam front is not propagating symmetrically. Figure 3.35, a typical areal temperature distribution during the continuous steam injection experiment, shows that the isotherms are almost symmetrical. Hence the local temperature differences around the 3D model are the main reason for having different rates of heat losses from symmetric sides of the model. The same is true for the other two sides on which P-LEFT and P-RIGHT are located.

During steam foam injection runs with or without nitrogen (Figures 3.33 and 3.34) the effect of surfactant solution injection on the rate of heat loss is obvious after each slug. At these times the amount of heat flux first dropped, then increased to the value which would be expected if there had not been injection of surfactant solution.

We also compared the accuracy of the assumptions on heat lost we made in designing the 3D model. To do that, the rate of heat loss from the 3D model at our experimental conditions, 10 psi back pressure, was calculated and compared with the experimental data.

Figure 3.32: Rate of Heat Loss From Each Sensor During Continuous Steam Injection

Figure 3.33: Rate of Heat Loss From Each Sensor During Steam Foam Injection with Nitrogen

Figure 3.34: Rate of Heat Loss From Each Sensor During Steam Foam Injection without Nitrogen

Figure 3.35: A Typical Areal Temperature Distribution

Figure 3.36: The Comparison of the Actual and Assumed Rate of Heat Loss

Equation 2.4, which uses the shape factor assumption to take the corners and the edges of the model into account, was used to calculate the rate of heat loss. The total experimental rate of heat loss at a given steam injection time is calculated by using the heat flux data and the equation below:

$$\dot{Q} = \sum_{i=1}^4 [q_i A_i] + q_5 2A_5 \quad (3.1)$$

where:

$\dot{Q}$ =instantaneous total rate of heat loss

q =instantaneous rate of heat loss from a single heat flux sensor

A =cross sectional area to heat flow adjacent to the corresponding sensor

In this equation, it was assumed that the rate of heat loss measured at the sensor location was the same everywhere on the side to which the sensor was attached. It was also assumed that the rate of heat loss from the top was equal to that from the bottom. That is why the top area of the 3D model is multiplied by two in Equation 3.1.

Figure 3.36 shows the results of these comparisons. As seen, the rate of heat loss calculated using the design assumptions is more than the actual rate of heat loss during all three experiments, thus verifying the validity of the conservative heat loss design parameters used. In the design, the assumption was made that the entire system was heated immediately.

3.9 Importance of the CT Scanner in this Study

The importance of the CT Scanner in this study could be evaluated by asking the following questions.

- Could we say that in-situ foaming is successful in diverting steam by merely analyzing the temperature and pressure data?

- Could we be sure that there is always a low quality low temperature nitrogen foam ahead of steam foam during steam foam applications which used non-condensable gas?
- Could we have an idea about the in-situ saturation distributions during these dynamic experiments if we didn't have CT numbers?

The answers to the above questions have already been given in the previous sections while discussing the experiments. The answer is, No! This shows the importance of the CT scanner in this study without which we could have not concluded that the in-situ foaming satisfactorily corrected the steam profiles in both steam foam runs. At the same time, the obvious effect of nitrogen would have been speculative without seeing the saturation distributions.

8

All saturation and temperature distribution figures starting from Figure 3.4 are originally in color and contain more detail. The colored versions of these figures can be obtained from the Stanford University Petroleum Research Institute.

4. Conclusions

A new experimental apparatus was designed, built and tested. It allows steam injection in a three dimensional pack and measurements of temperatures, pressures, heat losses and fluid saturation distributions. The model can be CT scanned while performing experiments.

Measured heat losses from the model match well with the analytical calculations.

Steam injection runs are reproducible both in terms of temperature distributions and saturation distributions as function of time (or steam injected).

Steam-foam with a non-condensable gas added shows the presence of a “gas-foam” zone ahead of the steam where both the temperature and the liquid saturations are low.

In-situ saturation measurements are quite useful to help identify the flow mechanisms in the steam-foam process. Thus CT scanning has proven to be a useful tool for thermal recovery laboratory research.

References

- [1] Haunsfield, G.N.: "A Method of and Apparatus for Examination of a Body by Radiation Such as X- or Gamma- Radiation," British Patent No. 1,283,915, London (1972).
- [2] Wellington, S.L. and Vinegar, H.J.: "X-Ray Computerized Tomography," *JPT*, (August 1987), 885-898.
- [3] Withjack, E.M.: "Computed Tomography for Rock-Property Determination and Fluid Flow Visualization," *SPE Formation Evaluation*, (December 1988) 696-704.
- [4] Wang, S.Y., Ayril, S., and Gryte, C.C.: "Computer Assisted Tomography for the Observation of Oil Displacement in Porous Media," *SPEJ*, (February 1984) 53-55.
- [5] Hove, A., Ringen, J.K., and Read, P.A.: "Visualization of Laboratory Corefloods With the Aid of Computerized Tomography of X-Ray," *SPE Reservoir Engineering*, (May 1987) 148-154.
- [6] Vinegar, H.J. and Wellington, S.L.: "Tomographic Imaging of Three-Phase Flow Experiments," *Rev. Sci. Instrum.* Vol. 58 No.1 (January 1987) 97-107.
- [7] Franshan, P.B. and Jaroslaw, J.: "Displacement of Heavy Oil Visualized by CAT Scan," Petroleum Society of CIM Paper No: 86-37-80, presented at the 1986 CIM Annual Technical Meeting, Calgary (June 8-11).
- [8] Chatzis, I., Kantzas, A., and Dullien, F.A.L.: "On the Investigation of Gravity Assisted Inert Gas Injection Using Micromodels, Long Berea Cores and Computer Assisted Tomography," SPE 18204, presented at the 63rd Annual Technical Conference and Exhibition of the SPE, Houston, TX (October 2-5, 1988).
- [9] Withjack, E.M.: "Computed Tomography Studies of 3-D Miscible Displacement Behavior in a Laboratory Five-Spot Model," SPE 18096, presented at the 63rd Annual Technical Conference and Exhibition of the SPE, Houston, TX (October 2-5, 1988).
- [10] Shallcross, D.C. and Wood, D.G.: "The Accurate Measurements of Heat Flux Using Thin Film Heat Flux Sensors with Application to Petroleum Engineering," DOE Fossil Energy Report SUPRI TR 74 DOE/BC/14126-20 (July 1990).

Appendix A. 3D Model Operation Principles

A.1 Control Panel

The control panel is mounted on a roller cart, so that it can be moved within the CT scanner room. The necessary electrical and tubing connections must be done prior to an experiment because it is mobile. The details of these connections are given in the following sections.

The schematic drawing of the control panel is given in Figure A.1.

The control panel is composed of six parts which we will investigate in detail in the following sections.

A.1.1 Injection Control

The control panel has some equipments which allow us to control the injected fluids. One of the two Constametric pumps is used to inject water to the steam generator or directly to the 3D model. The other one is used to inject either water or surfactant solution to the 3D model. Both of the pumps are used to clean and resaturate the model in between the experiments. This part of the control panel also has a N_2 mass flow controller to inject nitrogen at a constant rate during steam foam injection experiments. The valves which direct the injection fluids to specific tubings are discussed in the next section.

A.1.2 Valves

This section of the control panel has two groups of valve systems as seen on Figure A.2:

1. Valves related to the injection sequence and
2. Valves for pressure transducers.

Valves Related to the Injection Sequence:

These valves are labeled by letters A through F on Figure A.2. All except Valve F are three-way-valves.

Valve A This valve directs water coming from Pump 2 either to the steam generator or to the 3D model as cold water.

Valve B Here liquid (water or surfactant solution) pumped by Pump 1 is directed either to the 3D model or to Valve C. The main purpose of this valve is to allow us to apply different injection schemes during the experiments. If it is on the water side, we can inject additives and steam (from Valve C) to the model simultaneously. If it is on the other direction, injection of steam or additives can only be made alternatively through Valve C.

Figure A.1: Schematic of the Control Panel

Figure A.2: Valves on the Control Panel

Valve C This is another three-way-valve, which allows the injection of either steam from the steam generator or surfactant solution/cold water coming from Valve B.

Valve D This valve commands steam coming from Valve A through the steam generator. Valve D either directs steam to the 3D model via Valve C or puts it in a by-pass cycle. The aim of having a by-pass line is to let steam flow through a condenser before the steam injection experiment starts, and allow alternate additive injection during the experiment.

Valve E The main line to this valve comes from the nitrogen mass flow controller. Here Nitrogen is directed either to vent or to the main injection line.

Valve F This valve is to relieve pressure from the main line.

Valves for the Pressure Transducers:

These three-way-valves are numbered as pairs from 1 to 8 on Figure A.2. The upper valve at each pair controls fluid direction coming from the pressure taps on the 3D model. These valves have two directions as ΔP and Loop. The bottom valves control the pressure lines coming from the injection corner of the 3D model. They also have two directions as ΔP and Vent. When both valves of a pair are at the ΔP position we can read differential pressure between this pressure tap and the injection corner of the 3D model. When the top valve is at ΔP and the bottom one is at Vent, we read the absolute pressure at this pressure tap. When the top one is at Loop and the bottom one is at Vent, the pressure transducer for this tap is at zero reading position. These valves are also used to calibrate the pressure transducers before each experiment.

Figure A.3: Demodulators and Heater Controllers Part of the Control Panel

A.1.3 Demodulators and Heater Controllers

There are nine demodulators for pressure transducers. They are used for calibrating the signals from the transducers. On Figure A.3 the demodulators are numbered from 1 to 9. The ninth one is for the back pressure transducer which is located on the side of the control panel (Figure A.4). Two heater controllers are labeled A and B on Figure A.3. Heater A is used to control the temperatures of the steam generator and Heater B controls the injection well temperature.

A.1.4 Gauges

The gauges are mainly located on the top portion of the side of the control panel as seen on Figure A.4. Three of them are small range, 100 psi, gauges which are for injection pressure readings for nitrogen, steam and water. The main injection gauge located at the center is a precise Heise gauge with a 500 psi range. This gauge shows the pressure in the main injection line. There is also a pressure indicator which indicates the pressure in the production line.

A.1.5 Data Logger Connection Ports

Data logger connection ports are to connect the signals coming from the 3D model to the HP data logger that is used to collect the data during the experiments. They are located at the left bottom of the side of the control panel as seen on Figure A.4. While making the connections the numbers of the ports and the ribbon cables should be matched. Ribbon cables which come from the HP data logger are located on the left side of the CT's front table.

Figure A.4: Sideview of the Control Panel

A.1.6 Pressure Lines

The pressure lines allow us to make tubing connections between the eight pressure lines coming from the pressure taps and the line from production end of the 3D model. The tubing used for pressure lines is a high pressure high temperature nylon 1/16 inch in diameter. Celesco differential pressure transducers, with 25 psi plates, are used for pressure measurements.

A.2 Prerun Routine

In this section the basic routine that is followed before each run is explained. Prerun routine is a three-step procedure:

1. Signal connections
2. 3D model connections
 - positioning the 3D model in the CT Scanner
 - injection side connections
 - production side connections
3. Pressure line connections

A.2.1 Signal Connections

The signal connection system is shown on Figure A.5. As seen from this figure three sets of ribbon cable connect the HP data logger in the computer room to the control panel in CT room.

One end of these ribbon cables are mounted on the wall in the computer room. The connections to the multiplexer boards of the HP data logger are made by a set of cables with one end permanently soldered to the boards. The definition of each signal and, their connection locations on the signal ports, channel numbers on the multiplexers and in computer program are given on Tables A.1, A.2, and A.3.

The other end of the ribbon cables is at the left hand side of the front table of the CT scanner. This end should be plugged in the data logger connection ports on the control panel. The numbers on the cables and the ports must match.

The procedure below should be followed before each run:

1. Plug in Ribbon Cables from HP data logger to the matching signal ports on the wall.
2. Plug in the ribbon cables from signal ports to the connection ports on the control panel. The numbers must match.
3. Plug in there sets of signal cables coming from the 3D model and from the control panel:
 - Signal cable number 1 is from the production side of the 3D model
 - Signal cable number 2 is from the injection side of the model
 - Signal cable number 3 is from the control panel

Figure A.5: Schematic Signal Connection System

Figure A.6: Front Positioning Table

Figure A.7: Back Positioning Table

A.2.2 3D Model Connections

Positioning of the 3D Model in the CT Scanner:

The 3D model should be positioned within the CT gantry before making any other connections. To do this job properly, the procedure below should be followed:

1. Free the 3D model from its wooden case by unscrewing the wood screws at each end of its aluminum supporters.
2. Adjust the height of the tables of the CT scanner to the level line for the 3D model. This line can be seen on the inner front left and right sides of the gantry.
3. Pull the front table of the CT scanner all the way out. Adjust the front positioning table according to the dimensions given on Figure A.6.
4. Pull the back table of the CT scanner 19 cm out. Adjust the back positioning table according to the dimensions given on Figure A.7.
5. Unscrew the butterfly nut which holds the rod for signal cable Number 2 at the left side of the front supporter.
6. Place front and back supporters on the positioning tables.
7. Screw the pole back in the hole at the left corner of the front supporter.

8. Place the injection line by tightening its supporting leg on the hole at the right corner of the front supporter.
9. Tighten the other two screws on the front positioning table.
10. Place only one screw at one of the center holes of the back positioning table.
11. Adjust the position of the 3D model within the gantry. To do this, first adjust the location of the front positioning table by pushing or pulling it from the plexiglas end until the black marker line on the front supporter matches the marker light of the gantry. Then try to reposition the model until the front and back laser pointers match with the markers on the 3D model by adjusting screws on the front and back positioning tables, the adjusting screws on the inside face of the front positioning table, and the outside face of the back positioning table. Hopefully you will not need to do this adjustment often.

Injection Side Connections:

The schematic top view of the 3D model given on Figure A.8 is used to explain the necessary connections which should be done before each run at the injection side of the model. Follow these steps:

1. Bring the control panel close to the left side of the front table of the CT scanner.
2. Connect one end (C1 on Figure A.8) of the injection line to the main outlet of the control panel. Then connect the other end (C2) to the common side of the three-way injection valve (V1) of the 3D model.
3. Connect the main vent line to the other end of the same valve.
4. Connect Line 4 to C4. This line is for a reference pressure for the pressure transducers.
5. Plug in signal Cable 2 to the matching port on control panel.
6. Plug in wellbore heater power line (P1), wellbore heater thermocouple (P2), and injection line thermocouple to the corresponding plugs coming from control panel.

Production Side Connections:

In the production side of the 3D model actions are needed prior to each experiment:

1. Plug in signal Cable 1 to its matching port on the control panel. Signal Cable 1 should be extended on the floor around the left side of the gantry.
2. Connect cooling water inlet and outlet lines to locations C1 and C2, shown on Figure A.9.
3. Connect production line to sample collector at V1, of Figure A.8.

Figure A.9: Schematic of Production Side Connections of 3D Model

A.2.3 Pressure Line Connections

The pressure lines numbered and labeled 1 to 9 are located at the injection side of the 3D model. These lines should be connected to the matching fittings on the CT side of the control panel before each experiment. The reference pressure line is also located at the same place and the other end of Line 4 (Figure A.8) should be connected there.

A.3 Computer Programs

A.3.1 Data Logging Programs

Two type of data logging programs are used. One is for pressure transducer calibrations and the other is for data gathering during an experiment.

Pressure Transducer Calibration Program:

The computer program for calibration of pressure transducers, "PRES3DCL.BAS", is written in BASIC. The program listing can be found in Appendix B. When the program is run, the screen will look like the one given on Figure A.10.

While running PRESS3DCL.BAS, the pressure values on the screen are adjusted by using the corresponding demodulators. Zero knob on each demodulator is for zero adjustment when there is no pressure difference over the transducer, with its upper and bottom valves at the Vent position. The span knob is for pressure value adjustment after applying some absolute pressure (maximum of 25 psi) over the transducer with the upper valve set at ΔP and the bottom valve at the Vent position on the transducer.

Data Logging Program:

The name of computer program for data logging is STEAM3D.BAS and it is also written in BASIC also. The program listing can be found in Appendix C. The program first asks for the name of a datafile, then gives the screen output as seen on Figure A.11. It scans data every 30 seconds, writes them on the assigned datafile, and shows them on the screen. The temperature values on the screen change their colors as temperature increases helping the user to visually follow steam propagation in the 3D model.

P/T #1				P/T #5			
		P/T #2				P/T #6	
P/T #7				P/T #3			
		P/T #8				P/T #4	

BACK PRESSURE

Figure A.10: Screen Appearance During Pressure Transducers Calibration

■ STEAM BOILER T/C

■ INJECTION LINE T/C

■ INJECTION WELL T/C

HEAT SENSOR #4

HEAT SENSOR T/C #4

TIME = HH:MM:SS

T/C #1	P/T #1	T/C #2		T/C #3	P/T #5	T/C #4
	T/C #5		T/C #6		T/C #7	
	T/C #8		T/C #9		T/C #10	
T/C #11		T/C #12	P/T #2	T/C #13		T/C #14
	T/C #15		T/C #16		T/C #17	
	T/C #18		T/C #19		T/C #20	
T/C #21	P/T #7	T/C #22		T/C #23	P/T #3	T/C #24
	T/C #25		T/C #26		T/C #27	
	T/C #28		T/C #29		T/C #30	
T/C #31		T/C #32	P/T #8	T/C #33		T/C #34
		HEAT SENSOR T/C #2		PRODUCTION LINE T/C		
		HEAT SENSOR #2		BACK PRESSURE		

1 HEAT SENSOR #1 HEAT SENSOR T/C #1 3 HEAT SENSOR #3 HEAT SENSOR T/C #3 5 HEAT SENSOR #5 HEAT SENSOR T/C #5

Figure A.11: Screen Appearance During Data Logging

A.3.2 Temperature and Pressure Analysis Programs

To analyze the temperature data properly they should be converted to 2D cross-sectional temperature distributions at the same scan slice locations. This is done by following a stepwise computation approach, as follows:

- Digitize the top, center and bottom areal temperature distributions.
- From these distributions use the temperature values in the grids corresponding to the same scan slice locations to digitize 2D cross-sectional temperature distributions.
- Transfer these sectional temperature distributions into an image processor.
- Process these distributions by recoloring with the same colors given to the saturation distributions obtained from the same scan slice locations.

Digitizing the Areal Temperature Distributions:

Areal temperature distributions digitized using the two following steps.

- Prepare the temperature data obtained from data logging. This is done by using program DATPREP.BAS. The coding of this program is given in Appendix D. This program first asks the user to enter the main datafile name from which the data will be prepared. Then the required steam injection times for each slice should be entered. Here three level areal temperature data is prepared for the time steps corresponding to the times of scans of each slice.
- Transfer these data to a UNIX based computer in which a software called GRIDCON[©] digitizes them and creates gridded areal temperature distributions for top, center and bottom of the model at the required times.

Digitizing the Sectional Temperature Distributions:

The sectional temperature distributions are digitized as below:

- First select the temperature data from areal temperature distributions created in the previous section for the grids corresponding to the scan slice locations. This is done by running the computer program NEWSEC.BAS whose listing is given in Appendix E.
- Transfer these data to the UNIX computer and run GRIDCON to digitize them and to create gridded sectional temperature distributions for each section.

Table A.1: Signal Connections on Signal Port 1

CABLE NO / CHANNEL NO	SIGNAL PORT CHANNEL NO	DATA LOGGER MULTIPX NO / CHANNEL NO	COMPUTER CODE CHANNEL NO	SIGNAL DEFINITION
3 / 1	+ 1 - 2	1 / 00	00	Back Pressure Transducer
3 / 2	+ 3 - 4	1 / 01	01	Pressure Transducer # 1
3 / 3	+ 5 - 6	1 / 02	02	Pressure Transducer # 2
3 / 4	+ 7 - 8	1 / 03	03	Pressure Transducer # 3
3 / 5	+ 9 - 10	1 / 04	04	Pressure Transducer # 4
3 / 6	+11 - 12	1 / 05	05	Pressure Transducer # 5
3 / 7	+13 - 14	1 / 06	06	Pressure Transducer # 6
3 / 8	+15 - 16	1 / 07	07	Pressure Transducer # 7
3 / 9	+17 - 18	1 / 08	08	Pressure Transducer # 8
	+19 - 20	1 / 09	09	
	+21 - 22	1 / 10	10	
	+23 - 24	1 / 11	11	
	+25 - 26	1 / 12	12	
	+27 - 28	1 / 13	13	
	+29 - 30	1 / 14	14	
	+31 - 32	1 / 15	15	
	+33 - 34	1 / 16	16	
	+35 - 36	1 / 17	17	
	+37 - 38	1 / 18	18	
	+39 - 40	1 / 19	19	
2 / 1	+41 - 42	2 / 00	20	Injection Well Thermocouple
2 / 2	+43 - 44	2 / 01	21	Sandpack Thermocouple # 1
2 / 3	+45 - 46	2 / 02	22	Sandpack Thermocouple # 2
1 / 1	+47 - 48	2 / 03	23	Sandpack Thermocouple # 3
1 / 2	+49 - 50	2 / 04	24	Sandpack Thermocouple # 4

Table A.2: Signal Connections on Signal Port 2

CABLE NO / CHANNEL NO	SIGNAL PORT CHANNEL NO	DATA LOGGER MULTIPX NO / CHANNEL NO	COMPUTER CODE CHANNEL NO	SIGNAL DEFINITION
2 / 4	+ 1 - 2	2 / 05	25	Sandpack Thermocouple # 5
2 / 5	+ 3 - 4	2 / 06	26	Sandpack Thermocouple # 6
1 / 3	+ 5 - 6	2 / 07	27	Sandpack Thermocouple # 7
2 / 6	+ 7 - 8	2 / 08	28	Sandpack Thermocouple # 8
2 / 7	+ 9 -10	2 / 09	29	Sandpack Thermocouple # 9
1 / 4	+11 -12	2 / 10	30	Sandpack Thermocouple # 10
2 / 8	+13 -14	2 / 11	31	Sandpack Thermocouple # 11
2 / 9	+15 -16	2 / 12	32	Sandpack Thermocouple # 12
1 / 5	+17 -18	2 / 13	33	Sandpack Thermocouple # 13
1 / 6	+19 -20	2 / 14	34	Sandpack Thermocouple # 14
2 / 11	+21 -22	2 / 15	35	Sandpack Thermocouple # 15
2 / 12	+23 -24	2 / 16	36	Sandpack Thermocouple # 16
1 / 9	+25 -26	2 / 17	37	Sandpack Thermocouple # 17
2 / 10	+27 -28	2 / 18	38	Sandpack Thermocouple # 18
1 / 7	+29 -30	2 / 19	39	Sandpack Thermocouple # 19
1 / 8	+31 -32	3 / 00	40	Sandpack Thermocouple # 20
2 / 14	+33 -34	3 / 01	41	Sandpack Thermocouple # 21
2 / 15	+35 -36	3 / 02	42	Sandpack Thermocouple # 22
1 / 10	+37 -38	3 / 03	43	Sandpack Thermocouple # 23
1 / 11	+39 -40	3 / 04	44	Sandpack Thermocouple # 24
2 / 16	+41 -42	3 / 05	45	Sandpack Thermocouple # 25
1 / 14	+43 -44	3 / 06	46	Sandpack Thermocouple # 26
1 / 12	+45 -46	3 / 07	47	Sandpack Thermocouple # 27
2 / 17	+47 -48	3 / 08	48	Sandpack Thermocouple # 28
1 / 13	+49 -50	3 / 09	49	Sandpack Thermocouple # 29

Table A.3: Signal Connections on Signal Port 3

CABLE NO / CHANNEL NO	SIGNAL PORT CHANNEL NO	DATA LOGGER MULTPX NO / CHANNEL NO	COMPUTER CODE CHANNEL NO	SIGNAL DEFINITION
1 / 15	+ 1 - 2	3 / 10	50	Sandpack Thermocouple # 30
2 / 18	+ 3 - 4	3 / 11	51	Sandpack Thermocouple # 31
2 / 13	+ 5 - 6	3 / 12	52	Sandpack Thermocouple # 32
1 / 16	+ 7 - 8	3 / 13	53	Sandpack Thermocouple # 33
1 / 17	+ 9 - 10	3 / 14	54	Sandpack Thermocouple # 34
3 / 22	+11 -12	3 / 15	55	Injection Line Thermocouple
1 / 20	+13 -14	3 / 16	56	Production Line Thermocouple
3 / 24	+15 -16	3 / 17	57	Steam Generator Thermocouple
3 / 25	+17 -18	3 / 18	58	Cold Junction Thermocouple
	+19 -20	3 / 19	59	
	+21 -22	4 / 00	60	
2 / 25	+23 -24	4 / 01	61	Heat Flux Sensor # 1
1 / 25	+25 -26	4 / 02	62	Heat Flux Sensor # 2
1 / 23	+27 -28	4 / 03	63	Heat Flux Sensor # 3
2 / 23	+29 -30	4 / 04	64	Heat Flux Sensor # 4
2 / 21	+31 / 32	4 / 05	65	Heat Flux Sensor # 5
	+33 -34	4 / 06	66	
2 / 24	+35 -36	4 / 07	67	Heat Flux Sensor Thermocouple # 1
1 / 24	+37 -38	4 / 08	68	Heat Flux Sensor Thermocouple # 2
1 / 22	+39 -40	4 / 09	69	Heat Flux Sensor Thermocouple # 3
2 / 22	+41 -42	4 / 10	70	Heat Flux Sensor Thermocouple # 4
2 / 20	+43 -44	4 / 11	71	Heat Flux Sensor Thermocouple # 5
	+45 -46	4 / 12	72	
	+47 -48	4 / 13	73	
	+49 -50		74	

Appendix B. Computer Program for the Pressure Transducer Calibration

```
1  '
2  ' Lines 5-570 are for initialization of the Data Logger
3  ' Lines 580-1000 are to draw 3D model on the screen
4  '
5  ' Copyright Hewlett-Packard 1984, 1985
10 '
15 ' Set up program for MS-DOS HP-IB I/O Library
20 ' For use independent of the PC instrument bus system
25 '
30 DEF SEG
35 CLEAR ,&HFE00
40 I=&HFE00
45 '
50 ' PCIB.DIR$ represents the directory where the library files
55 ' are located
60 ' PCIB is an environment variable which should be set from MS-DOS
65 ' i.e. A:> SET PCIB=A:\LIB
70 '
75 ' If there is insufficient environment space a direct assignment
80 ' can be made here, i.e
85 ' PCIB.DIR$ = "A:\LIB"
90 ' Using the environment variable is the preferred method
95 '
100 PCIB.DIR$ = ENVIRON$("PCIB")
105 I$ = PCIB.DIR$ + "\PCIBILC.BLD"
110 BLOAD I$,&HFE00
115 CALL I(PCIB.DIR$, I%, J%)
120 PCIB.SEG = I%
125 IF J%=0 THEN GOTO 160
130 PRINT "Unable to load.";
135 PRINT " (Error #";J%;"")"
140 STOP
145 '
150 ' Define entry points for setup routines
155 '
160 DEF SEG = PCIB.SEG
165 O.S = 5
170 C.S = 10
175 I.V = 15
```



```

180 I.C      = 20
185 L.P      = 25
190 LD.FILE = 30
195 GET.MEM = 35
200 L.S      = 40
205 PANELS  = 45
210 '
215 '   Establish error variables and ON ERROR branching
220 '
225 DEF.ERR = 50
230 PCIB.ERR$ = STRING$(64,32)
235 PCIB.NAME$ = STRING$(16,32)
240 CALL DEF.ERR(PCIB.ERR,PCIB.ERR$,PCIB.NAME$,PCIB.GLBERR)
245 PCIB.BASERR = 255
250 ON ERROR GOTO 410
255 '
260 J=-1
265 I$=PCIB.DIR$+"\\HPIB.SYN"
270 CALL O.S(I$)
275 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
280 '
285 '   Determine entry points for HP-IB Library routines
290 '
295 I=0
300 CALL I.V(I,IOABORT,IOCLEAR,IOCONTROL,IOENTER)
305 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
310 CALL I.V(I,IOENTERA,IOENTERS,IOEOI,IOEOL)
315 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
320 CALL I.V(I,IOGETTERM,IOLLOCKOUT,IOLLOCAL,IOMATCH)
325 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
330 CALL I.V(I,IOOUTPUT,IOOUTPUTA,IOOUTPUTS,IOPPOLL)
335 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
340 CALL I.V(I,IOPPOLL, IOPPOLLU,IOREMOTE,IORESET)
345 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
350 CALL I.V(I,IOSEND,IOSPOLL,IOSTATUS,IOTIMEOUT)
355 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
360 CALL I.V(I,IOTRIGGER,IODMA,J,J)
365 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
370 CALL C.S
375 I$=PCIB.DIR$+"\\HPIB.PLD"
380 CALL L.P(I$)
385 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
390 GOTO 475
395 '
400 '   Error handling routine
405 '

```

```

410 IF ERR=PCIB.BASERR THEN GOTO 425
415 PRINT "BASIC error #";ERR;" occurred in line ";ERL
420 STOP
425 TMPERR = PCIB.ERR
430 IF TMPERR = 0 THEN TMPERR = PCIB.GLBERR
435 PRINT "PC Instrument error #";TMPERR;" detected at line ";ERL
440 PRINT "Error: ";PCIB.ERR$
445 STOP
450 '
455 '  COMMON declarations are needed if your program is going to chain
460 '    to other programs.  When chaining, be sure to call DEF.ERR as
465 '    well upon entering the chained-to program
470 '
475 COMMON PCIB.DIR$,PCIB.SEG
480 COMMON LD.FILE,GET.MEM,PANELS,DEF.ERR
485 COMMON PCIB.BASERR,PCIB.ERR,PCIB.ERR$,PCIB.NAME$,PCIB.GLBERR
490 COMMON IOABORT,IOCLEAR,IOCONTROL,IOENTER,IOENTERA,IOENTERS,
    IOEOI,IOEOL,IOGETTERM,IOLLOCKOUT,IOLLOCAL,IOMATCH,IOOUTPUT,
    IOOUTPUTA,IOOUTPUTS,IOPPOLL,IOPPOLLIC,IOPPOLLU,IOREMOTE,IORRESET,
    IOSEND,IOSPOLL,IOSTATUS,IOTIMEOUT,IOTRIGGER,IODMA
495 '
500 FALSE      = 0
505 TRUE       = NOT FALSE
510 NOERR      = 0
515 EUNKNOWN   = 100001!
520 ESEL       = 100002!
525 ERANGE     = 100003!
530 ETIME      = 100004!
535 ECTRL      = 100005!
540 EPASS      = 100006!
545 ENUM       = 100007!
550 EADDR      = 100008!
555 COMMON FALSE, TRUE, NOERR, EUNKNOWN, ESEL, ERANGE, ETIME,
    ECTRL, EPASS, ENUM, EADDR
560 '
565 '  End Program Set-up
570 '  User program can begin anywhere past this point
580 COLOR 14,0
590 CLS
670 LOCATE 4,8:PRINT " ":LOCATE 4,9:PRINT STRING$(63," ")
680 LOCATE 4,72:PRINT " "
690 LOCATE 4,9:PRINT " "
700 FOR I=5 TO 21
710 LOCATE I,8:PRINT " ":LOCATE I,72:PRINT " "
720 NEXT
730 LOCATE 21,8:PRINT " ":LOCATE 21,9:PRINT STRING$(63," "):

```

```

740 LOCATE 21,72:PRINT " "
750 FOR I=6 TO 18 STEP 5
760 LOCATE I,8:PRINT " ":LOCATE I,9:PRINT STRING$(63," "):LOCATE I,72:
  PRINT " "
770 LOCATE I+3,8:PRINT " ":LOCATE I+3,9:PRINT STRING$(63," "):
  LOCATE I+3,72:PRINT " "
780 NEXT I
790 FOR I=5 TO 21 STEP 5
800 FOR J=24 TO 56 STEP 16
810 LOCATE I,J:PRINT " "
820 NEXT J:NEXT I
830 FOR J=24 TO 56 STEP 16
840 LOCATE 4,J:PRINT " "
850 LOCATE 21,J:PRINT " "
860 NEXT J
870 FOR I=6 TO 17 STEP 5
880 FOR J=24 TO 56 STEP 16
890 LOCATE I,J:PRINT " "
900 LOCATE I+3,J:PRINT " "
910 NEXT J:NEXT I
920 FOR I=6 TO 17 STEP 5
930 FOR J=20 TO 61 STEP 16
940 LOCATE I,J:PRINT " "
950 LOCATE I,J+8:PRINT " "
960 LOCATE I+3,J:PRINT " "
970 LOCATE I+3,J+8:PRINT " "
980 NEXT J:NEXT I
990 FOR I=7 TO 18 STEP 5
991 FOR J=20 TO 61 STEP 16
992 LOCATE I,J:PRINT " "
993 LOCATE I,J+8:PRINT " "
994 LOCATE I+1,J:PRINT " "
995 LOCATE I+1,J+8:PRINT " "
996 NEXT J:NEXT I
997 LOCATE 21,71:PRINT " "
998 LOCATE 22,71:PRINT " "
999 '
1000 '
1001 '  PRESSURE TRANSDUCER CALIBRATION PROGRAM
1002 '  NOVEMBER 1989
1003 '
1005 '  INITIALIZE TIMER
1010 TIME$="00:00:00"
1070 OPTION BASE 1
1075 '  SET UP ARRAYS
1080 DIM P0(5),P1(5),P2(5),P3(5),P4(5),P5(5),P6(5),P7(5),P8(5)

```

```

1200 ' Initialize Data Logger
1210 ISC=7
1220 DEV=709
1230 CALL IORESET (ISC)
1250 TIMEOUT = 5
1255 MAXI=5
1260 CALL IOTIMEOUT (ISC, TIMEOUT)
1280 CALL IOCLEAR (ISC)
1300 CALL IOREMOTE (ISC)
1310 CODE$="SISO1VAOVF1VS0"
1320 LENGTH=LEN(CODE$)
1330 CALL IOOUTPUTS (DEV,CODE$,LENGTH)
1340 '
1362 ' BEGIN DATA LOGGING
1363 '
1364 ' READ CHANNEL 0 (BACK PRESSURE TRANSDUCER)
1365 '
1440 CODE$="ACOVN5"
1448 LENGTH=6
1450 CALL IOOUTPUTS (DEV,CODE$,LENGTH)
1455 CALL IOENTERA (DEV,P0(1),MAXI,ACTUAL)
1456 '
1460 ' READ CHANNEL 1 TO 8 (SYSTEM PRESSURE TRANSDUCERS)
1461 '
1465 CODE$="AC1"
1470 LENGTH=3
1475 CALL IOOUTPUTS (DEV,CODE$,LENGTH)
1480 CALL IOENTERA (DEV,P1(1),MAXI,ACTUAL)
1490 CODE$="AC2"
1495 CALL IOOUTPUTS (DEV,CODE$,LENGTH)
1500 CALL IOENTERA (DEV,P2(1),MAXI,ACTUAL)
1510 CODE$="AC3"
1515 CALL IOOUTPUTS (DEV,CODE$,LENGTH)
1520 CALL IOENTERA (DEV,P3(1),MAXI,ACTUAL)
1530 CODE$="AC4"
1535 CALL IOOUTPUTS (DEV,CODE$,LENGTH)
1540 CALL IOENTERA (DEV,P4(1),MAXI,ACTUAL)
1550 CODE$="AC5"
1555 CALL IOOUTPUTS (DEV,CODE$,LENGTH)
1560 CALL IOENTERA (DEV,P5(1),MAXI,ACTUAL)
1570 CODE$="AC6"
1575 CALL IOOUTPUTS (DEV,CODE$,LENGTH)
1580 CALL IOENTERA (DEV,P6(1),MAXI,ACTUAL)
1585 CALL IOOUTPUTS (DEV,CODE$,LENGTH)
1590 CODE$="AC7"
1595 CALL IOOUTPUTS (DEV,CODE$,LENGTH)

```

```

1600 CALL IOENTERA (DEV,P7(1),MAXI,ACTUAL)
1610 CODE$="AC8"
1615 CALL IOOUTPUTS (DEV,CODE$,LENGTH)
1620 CALL IOENTERA (DEV,P8(1),MAXI,ACTUAL)
2110 '
2115 '  AVERAGE VALUES FOR THE MV PRESSURE VALUES
2116 '
2120 AP0=(P0(1)+P0(2)+P0(3)+P0(4)+P0(5))/5!
2130 AP1=(P1(1)+P1(2)+P1(3)+P1(4)+P1(5))/5!
2140 AP2=(P2(1)+P2(2)+P2(3)+P2(4)+P2(5))/5!
2150 AP3=(P3(1)+P3(2)+P3(3)+P3(4)+P3(5))/5!
2160 AP4=(P4(1)+P4(2)+P4(3)+P4(4)+P4(5))/5!
2170 AP5=(P5(1)+P5(2)+P5(3)+P5(4)+P5(5))/5!
2175 AP6=(P6(1)+P6(2)+P6(3)+P6(4)+P6(5))/5!
2180 AP7=(P7(1)+P7(2)+P7(3)+P7(4)+P7(5))/5!
2190 AP8=(P8(1)+P8(2)+P8(3)+P8(4)+P8(5))/5!
2200 PB=2.5*AP0
2210 PT1=2.5*AP1
2220 PT2=2.5*AP2
2230 PT3=2.5*AP3
2240 PT4=2.5*AP4
2250 PT5=2.5*AP5
2260 PT6=2.5*AP6
2270 PT7=2.5*AP7
2280 PT8=2.5*AP8
4500 '
4510 '  PRINTING THE RESULTS ON SCREEN
4511 '
4525 COLOR 12,0
4550 LOCATE 5,9:PRINT "PT#1"
4560 LOCATE 15,9:PRINT "PT#7"
4570 LOCATE 10,25:PRINT "PT#2"
4580 LOCATE 20,25:PRINT "PT#8"
4590 LOCATE 5,41:PRINT "PT#5"
4600 LOCATE 15,41:PRINT "PT#3"
4610 LOCATE 10,57:PRINT "PT#6"
4620 LOCATE 20,57:PRINT "PT#4"
4630 LOCATE 23,57:PRINT "BP"
5000 LOCATE 5,15:PRINT USING "####.##";PT1
5010 LOCATE 15,15:PRINT USING "####.##";PT7
5020 LOCATE 10,31:PRINT USING "####.##";PT2
5030 LOCATE 20,31:PRINT USING "####.##";PT8
5040 LOCATE 5,47:PRINT USING "####.##";PT5
5050 LOCATE 15,47:PRINT USING "####.##";PT3
5060 LOCATE 10,63:PRINT USING "####.##";PT6
5070 LOCATE 20,63:PRINT USING "####.##";PT4

```

```
5080 LOCATE 23,63:PRINT USING "####.##";PB
5800 GOTO 1340
5980 END
```

Appendix C. Computer Program for Data Logging

```
1  '
2  ' Lines 5-570 are for initialization of Data-Logger
3  ' Lines 570-1000 are to draw the 3D model on the screen
4  '
5  ' Copyright Hewlett-Packard 1984, 1985
10 '
15 ' Set up program for MS-DOS HP-IB I/O Library
20 ' For use independent of the PC instrument bus system
25 '
30 DEF SEG
35 CLEAR ,&HFE00
40 I=&HFE00
45 '
50 ' PCIB.DIR$ represents the directory where the library files
55 ' are located
60 ' PCIB is an environment variable which should be set from MS-DOS
65 ' i.e. A:> SET PCIB=A:\LIB
70 '
75 ' If there is insufficient environment space a direct assignment
80 ' can be made here, i.e
85 ' PCIB.DIR$ = "A:\LIB"
90 ' Using the environment variable is the preferred method
95 '
100 PCIB.DIR$ = ENVIRON$("PCIB")
105 I$ = PCIB.DIR$ + "\PCIBILC.BLD"
110 BLOAD I$,&HFE00
115 CALL I(PCIB.DIR$, I%, J%)
120 PCIB.SEG = I%
125 IF J%=0 THEN GOTO 160
130 PRINT "Unable to load.";
135 PRINT " (Error #";J%;" )"
140 STOP
145 '
150 ' Define entry points for setup routines
155 '
160 DEF SEG = PCIB.SEG
165 O.S = 5
170 C.S = 10
175 I.V = 15
```

```

180 I.C      = 20
185 L.P      = 25
190 LD.FILE  = 30
195 GET.MEM  = 35
200 L.S      = 40
205 PANELS   = 45
210 '
215 '   Establish error variables and ON ERROR branching
220 '
225 DEF.ERR = 50
230 PCIB.ERR$ = STRING$(64,32)
235 PCIB.NAME$ = STRING$(16,32)
240 CALL DEF.ERR(PCIB.ERR,PCIB.ERR$,PCIB.NAME$,PCIB.GLBERR)
245 PCIB.BASERR = 255
250 ON ERROR GOTO 410
255 '
260 J=-1
265 I$=PCIB.DIR$+"\\HPIB.SYN"
270 CALL O.S(I$)
275 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
280 '
285 '   Determine entry points for HP-IB Library routines
290 '
295 I=0
300 CALL I.V(I,IOABORT,IOCLEAR,IOCONTROL,IOENTER)
305 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
310 CALL I.V(I,IOENTERA,IOENTERS,IOEOI,IOEOL)
315 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
320 CALL I.V(I,IOGETTERM,IOLLOCKOUT,IOLLOCAL,IOMATCH)
325 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
330 CALL I.V(I,IOOUTPUT,IOOUTPUTA,IOOUTPUTS,IOPPOLL)
335 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
340 CALL I.V(I,IOPPOLL,IOPPOLLU,IOREMOTE,IORESET)
345 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
350 CALL I.V(I,IOSEND,IOSPOLL,IOSTATUS,IOTIMEOUT)
355 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
360 CALL I.V(I,IOTRIGGER,IODMA,J,J)
365 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
370 CALL C.S
375 I$=PCIB.DIR$+"\\HPIB.PLD"
380 CALL L.P(I$)
385 IF PCIB.ERR<>0 THEN ERROR PCIB.BASERR
390 GOTO 475
395 '
400 '   Error handling routine
405 '

```



```

410 IF ERR=PCIB.BASERR THEN GOTO 425
415 PRINT "BASIC error #";ERR;" occurred in line ";ERL
420 STOP
425 TMPERR = PCIB.ERR
430 IF TMPERR = 0 THEN TMPERR = PCIB.GLBERR
435 PRINT "PC Instrument error #";TMPERR;" detected at line ";ERL
440 PRINT "Error: ";PCIB.ERR$
445 STOP
450 '
455 '  COMMON declarations are needed if your program is going to chain
460 '    to other programs.  When chaining, be sure to call DEF.ERR as
465 '    well upon entering the chained-to program
470 '
475 COMMON PCIB.DIR$,PCIB.SEG
480 COMMON LD.FILE,GET.MEM,PANELS,DEF.ERR
485 COMMON PCIB.BASERR,PCIB.ERR,PCIB.ERR$,PCIB.NAME$,PCIB.GLBERR
490 COMMON IOABORT,IOCLEAR,IOCONTROL,IOENTER,IOENTERA,IOENTERS,
    IOEOI,IOEOL,IOGETTERM,IOLLOCKOUT,IOLLOCAL,IOMATCH,IOOUTPUT,
    IOOUTPUTA,IOOUTPUTS,IOPPOLL,IOPPOLL, IOPPOLLU,IOREMOTE,IORSET,
    IOSEND,IOSPOLL,IOSTATUS,IOTIMEOUT,IOTRIGGER,IODMA
495 '
500 FALSE      = 0
505 TRUE       = NOT FALSE
510 NOERR      = 0
515 EUNKNOWN   = 100001!
520 ESEL       = 100002!
525 ERANGE     = 100003!
530 ETIME      = 100004!
535 ECTRL      = 100005!
540 EPASS      = 100006!
545 ENUM       = 100007!
550 EADDR      = 100008!
555 COMMON FALSE, TRUE, NOERR, EUNKNOWN, ESEL, ERANGE, ETIME,
    ECTRL, EPASS, ENUM, EADDR
560 '
565 ' End Program Set-up
570 ' User program can begin anywhere past this point
575 KEY OFF
585 CLS
595 GOSUB 10000
600 LOCATE 1,9:PRINT " "
610 LOCATE 1,50:PRINT "TIME = "
650 LOCATE 2,9:PRINT " "
660 LOCATE 3,9:PRINT " "
670 LOCATE 4,8:PRINT " ":LOCATE 4,9:PRINT STRING$(63," ")
680 LOCATE 4,72:PRINT " "

```

```

690 LOCATE 4,9:PRINT " "
700 FOR I=5 TO 21
710 LOCATE I,8:PRINT " ":LOCATE I,72:PRINT " "
720 NEXT
730 LOCATE 21,8:PRINT " ":LOCATE 21,9:PRINT STRING$(63," "):
740 LOCATE 21,72:PRINT " "
750 FOR I=6 TO 18 STEP 5
760 LOCATE I,8:PRINT " ":LOCATE I,9:PRINT STRING$(63," "):LOCATE I,72:
  PRINT " "
770 LOCATE I+3,8:PRINT " ":LOCATE I+3,9:PRINT STRING$(63," "):
  LOCATE I+3,72:PRINT " "
780 NEXT I
790 FOR I=5 TO 21 STEP 5
800 FOR J=24 TO 56 STEP 16
810 LOCATE I,J:PRINT " "
820 NEXT J:NEXT I
830 FOR J=24 TO 56 STEP 16
840 LOCATE 4,J:PRINT " "
850 LOCATE 21,J:PRINT " "
860 NEXT J
870 FOR I=6 TO 17 STEP 5
880 FOR J=24 TO 56 STEP 16
890 LOCATE I,J:PRINT " "
900 LOCATE I+3,J:PRINT " "
910 NEXT J:NEXT I
920 FOR I=6 TO 17 STEP 5
930 FOR J=20 TO 61 STEP 16
940 LOCATE I,J:PRINT " "
950 LOCATE I,J+8:PRINT " "
960 LOCATE I+3,J:PRINT " "
970 LOCATE I+3,J+8:PRINT " "
980 NEXT J:NEXT I
990 FOR I=7 TO 18 STEP 5
991 FOR J=20 TO 61 STEP 16
992 LOCATE I,J:PRINT " "
993 LOCATE I,J+8:PRINT " "
994 LOCATE I+1,J:PRINT " "
995 LOCATE I+1,J+8:PRINT " "
996 NEXT J:NEXT I
997 LOCATE 21,71:PRINT " "
998 LOCATE 22,71:PRINT " "
999 KEY OFF
1000 ' 3 D M O D E L
1010 ' STEAM INJECTION DATA LOGGING PROGRAM
1020 ' B I R O L D E M I R A L
1030 ' MAY 1989

```

```

1040 '    REVISED ON JULY 12,1990
1050 '
1060 '
1070 '    INITIALIZE TIMER
1080 TIME$="00:00:00"
1090 '    SET UP ARRAYS
1100 OPTION BASE 1
1110 DIM PT(90),TC(1000),APT(9),ATC(40),T(40),AT(5)
1120 DIM HF1(50),HF2(50),HF3(50),HF4(50),HF5(50)
1130 DIM HT1(50),HT2(50),HT3(50),HT4(50),HT5(50)
1140 '
1150 '    N O M E N C L A T U R E
1160 '
1170 '    PT      = Signal From Pressure Transducers
1180 '    TC      = Signal From Thermocouples
1190 '    APT     = Average Pressure Values, mv
1200 '    ATC     = Average Temperature Values, mv
1205 '    T       = Average Temperature Values, deg C
1210 '    HF1     = Signal From Heat Flux Sensor #1
1220 '    HF2     = Signal From Heat Flux Sensor #2
1230 '    HF3     = Signal From Heat Flux Sensor #3
1240 '    HF4     = Signal From Heat Flux Sensor #4
1250 '    HF5     = Signal From Heat Flux Sensor #5
1260 '    HT1     = Signal From Heat Flux Sensor Thermocouple #1
1270 '    HT2     = Signal From Heat Flux Sensor Thermocouple #2
1280 '    HT3     = Signal From Heat Flux Sensor Thermocouple #3
1290 '    HT4     = Signal From Heat Flux Sensor Thermocouple #4
1300 '    HT5     = Signal From Heat Flux Sensor Thermocouple #5
1310 '    AHF1    = Average Heat Flux Value at #1
1320 '    AHF2    = Average Heat Flux Value at #2
1330 '    AHF3    = Average Heat Flux Value at #3
1340 '    AHF4    = Average Heat Flux Value at #4
1350 '    AHF5    = Average Heat Flux Value at #5
1360 '    AHT1    = Average Temperature at #1
1370 '    AHT2    = Average Temperature at #2
1380 '    AHT3    = Average Temperature at #3
1390 '    AHT4    = Average Temperature at #4
1400 '    AHT5    = Average Temperature at #5
1405 '    AT      = Average Temperature Values for AHT's, deg C
1435 '
1440 '    INITIALIZE DATA LOGGER
1450 '
1460 ISC=7
1470 DEV=709
1475 CALL IORESET(ISC)
1480 CALL IOTIMEOUT(ISC,TIMEOUT)

```

```

1490 CALL IOCLEAR(ISC)
1495 CALL IOREMOTE(ISC)
1500 CODE$="SIS01SD1VA0VF1VSOAF00AL99"
1510 LENGTH=LEN(CODE$)
1520 CALL IOOUTPUTS(DEV,CODE$,LENGTH)
1523 ON TIMER (30) GOSUB 1530
1524 TIMER ON
1525 GOTO 1525
1526 END
1530 '
1540 ' BEGIN DATA LOGGING
1550 '
1560 ' READ CHANNEL 00 (BACK PRESSURE TRANSDUCER)
1565 '
1570 '
1580 CODE$="AC00VN10VR5"
1590 LENGTH=LEN(CODE$)
1600 MAXI=10
1610 CALL IOOUTPUTS(DEV,CODE$,LENGTH)
1620 CALL IOENTERA(DEV,PT(1),MAXI,ACTUAL)
1630 '
1640 ' READ CHANNELS 01 TO 08 (PRESSURE TRANSDUCERS)
1650 '
1660 CODE$="ASVN10"
1670 LENGTH=LEN(CODE$)
1680 FOR I=1 TO 8
1690 CALL IOOUTPUTS(DEV,CODE$,LENGTH)
1700 CALL IOENTERA(DEV,PT(10*I+1),MAXI,ACTUAL)
1710 NEXT I
1720 '
1730 ' READ CHANNEL 20 (INJECTION WELL THERMOCOUPLE)
1740 CODE$="AC20VN3VR1"
1750 LENGTH=LEN(CODE$)
1760 MAXI=3
1770 CALL IOOUTPUTS(DEV,CODE$,LENGTH)
1775 CALL IORESET(ISC)
1776 TIMEOUT=5
1780 CALL IOENTERA(DEV,TC(1),MAXI,ACTUAL)
1790 '
1800 ' READ CHANNELS 21 TO 58 (SANDPACK,INJECTION LINE,
1810 ' BOILER AND REFERENCE
1820 ' THERMOCOUPLES)
1830 '
1840 CODE$="ASVN3"
1850 LENGTH=5
1855 MAXI=3

```

```

1860 FOR I=1 TO 38
1870     CALL IOOUTPUTS(DEV, CODE$, LENGTH)
1880     CALL IOENTERA(DEV, TC(3*I+1), MAXI, ACTUAL)
1890 NEXT I
1900 '
1910 '   READ CHANNELS 61 TO 65 (HEAT FLUX SENSORS, 10 READING
1920 '                               PER TRIGGER, 5 TRIGGERS)
1930 '
1940 FOR I=0 TO 4
1950     MAXI=10
1960     CODE$="AC61VR1VN10"
1970     LENGTH=LEN(CODE$)
1980     CALL IOOUTPUTS(DEV, CODE$, LENGTH)
1990     CALL IOENTERA(DEV, HF1(10*I+1), MAXI, ACTUAL)
2000     CODE$="AC62VR1VN10"
2010     CALL IOOUTPUTS(DEV, CODE$, LENGTH)
2020     CALL IOENTERA(DEV, HF2(10*I+1), MAXI, ACTUAL)
2030     CODE$="AC63VR1VN10"
2040     CALL IOOUTPUTS(DEV, CODE$, LENGTH)
2050     CALL IOENTERA(DEV, HF3(10*I+1), MAXI, ACTUAL)
2060     CODE$="AC64VR1VN10"
2070     CALL IOOUTPUTS(DEV, CODE$, LENGTH)
2080     CALL IOENTERA(DEV, HF4(10*I+1), MAXI, ACTUAL)
2090     CODE$="AC65VR1VN10"
2100     CALL IOOUTPUTS(DEV, CODE$, LENGTH)
2110     CALL IOENTERA(DEV, HF5(10*I+1), MAXI, ACTUAL)
2120 '
2130 '   READ CHANNELS 67 TO 71 (HEAT FLUX SENSOR
2140 '                               THERMOCOUPLES, 3 READINGS
2150 '                               PER TRIGGER, 5 TRIGGERS)
2160 '
2170     MAXI=3
2180     CODE$="AC67VN3"
2190     LENGTH=LEN(CODE$)
2200     CALL IOOUTPUTS(DEV, CODE$, LENGTH)
2210     CALL IOENTERA(DEV, HT1(3*I+1), MAXI, ACTUAL)
2220     CODE$="AC68VN3"
2230     CALL IOOUTPUTS(DEV, CODE$, LENGTH)
2240     CALL IOENTERA(DEV, HT2(3*I+1), MAXI, ACTUAL)
2250     CODE$="AC69VN3"
2260     CALL IOOUTPUTS(DEV, CODE$, LENGTH)
2270     CALL IOENTERA(DEV, HT3(3*I+1), MAXI, ACTUAL)
2280     CODE$="AC70VN3"
2290     CALL IOOUTPUTS(DEV, CODE$, LENGTH)
2300     CALL IOENTERA(DEV, HT4(3*I+1), MAXI, ACTUAL)
2310     CODE$="AC71VN3"

```

```

2320    CALL IOOUTPUTS(DEV,CODE$,LENGTH)
2330    CALL IOENTERA(DEV,HT5(3*I+1),MAXI,ACTUAL)
2340 NEXT I
2350 '
2360 '   CALCULATE AVERAGE PRESSURE SIGNALS
2370 '
2380 FOR I=1 TO 9
2390     APT(I)=0
2400 NEXT I
2410 FOR J=0 TO 8
2420     FOR I=1 TO 10
2430         APT(J+1)=APT(J+1)+PT(I+J*10)/10!
2440     NEXT I
2450 NEXT J
2451 '
2452 'CALCULATE REAL PRESSURE VALUES IN PSI'S
2453 '
2454 FOR I=1 TO 9
2455     APT(I)=APT(I)*2.5
2456 NEXT I
2460 '
2470 '   CALCULATE AVERAGE TEMPERATURE SIGNALS
2480 '
2490 FOR I=1 TO 39
2500     ATC(I)=(TC(3*I-2)+TC(3*I-1)+TC(3*I))/3!
2510 NEXT I
2520 '
2530 '   CALCULATE AVERAGE VALUES FOR HEAT FLUX INTERMS OF VOLTS
2540 '
2550 AHF1=0:AHF2=0:AHF3=0:AHF4=0:AHF5=0
2560 FOR I=1 TO 50
2570     AHF1=AHF1+HF1(I)*20
2580     AHF2=AHF2+HF2(I)*20
2590     AHF3=AHF3+HF3(I)*20
2600     AHF4=AHF4+HF4(I)*20
2610     AHF5=AHF5+HF5(I)*20
2620 NEXT I
2630 '
2640 '   CALCULATE AVERAGE VALUES FOR THE HEAT FLUX SENSOR THERMOCOUPLES
2650 '
2660 AHT1=0:AHT2=0:AHT3=0:AHT4=0:AHT5=0
2670 FOR I=1 TO 15
2680     AHT1=AHT1+HT1(I)/15!
2690     AHT2=AHT2+HT2(I)/15!
2700     AHT3=AHT3+HT3(I)/15!
2710     AHT4=AHT4+HT4(I)/15!

```

```

2720   AHT5=AHT5+HT5(I)/15!
2730 NEXT I
2790 '
2800 '   CALL SUBROUTINE TO CONVERT TYPE-J THERMOCOUPLE SIGNAL
2810 '   TO TEMPERATURE (DEG C) USING CHANNEL 58 AS THE COLD
2820 '   JUNCTION REFERENCE
2830 '
2840 FOR I=1 TO 38
2850   EMF=(ATC(I)-ATC(39))*1000!
2860   GOSUB 6000
2870   T(I)=TEMP
2880 NEXT I
2890 EMF=-ATC(39)*1000!
2900 GOSUB 6000
2910 T(39)=TEMP
2920 '
2930 '   CALL SUBROUTINES TO CONVERT TYPE-T THERMOCOUPLE SIGNALS
2940 '   TO TEMPERATURE (DEG C) FOR HEAT FLUX SENSOR THERMOCOUPLES
2950 '   USING THE TYPE-J SIGNAL FROM COLD JUNCTION REFERENCE
2960 '
3000 TEMP=T(39)
3010 GOSUB 8000
3020 ET=EMF
3030 EMF=AHT1*1000+ET
3040 GOSUB 7000
3050 AT(1)=TEMP
3060 EMF=AHT2*1000+ET
3070 GOSUB 7000
3080 AT(2)=TEMP
3090 EMF=AHT3*1000+ET
3100 GOSUB 7000
3110 AT(3)=TEMP
3120 EMF=AHT4*1000+ET
3130 GOSUB 7000
3140 AT(4)=TEMP
3150 EMF=AHT5*1000+ET
3160 GOSUB 7000
3170 AT(5)=TEMP
4500 '
4510 '   PRINTING THE RESULTS ON SCREEN
4520 '
4530 COLOR 15,0
4540 LOCATE 1,58:BEEP:PRINT USING "\      \";TIME$
4550 COLOR 2,0
4551 K=38:GOSUB 9000
4560 LOCATE 1,11:PRINT USING "###.##";T(38)

```

```

4561 K=36:GOSUB 9000
4570 LOCATE 2,11:PRINT USING "###.##";T(36)
4571 K=1:GOSUB 9000
4580 LOCATE 3,11:PRINT USING "###.##";T(1)
4581 K=37:GOSUB 9000
4590 LOCATE 22,65:PRINT USING "###.##";T(37)
4595 COLOR 5,0:LOCATE 23,64:PRINT USING "###.####";APT(1)
4600 '
4610 COLOR 12,0
4620 I=2
4630 FOR J=5 TO 20 STEP 5
4631 K=I:GOSUB 9000
4640 LOCATE J,9:PRINT USING "###.##";T(I)
4641 K=I+1:GOSUB 9000
4650 LOCATE J,25:PRINT USING "###.##";T(I+1)
4651 K=I+2:GOSUB 9000
4660 LOCATE J,41:PRINT USING "###.##";T(I+2)
4661 K=I+3:GOSUB 9000
4670 LOCATE J,57:PRINT USING "###.##";T(I+3)
4680 I=I+10
4690 NEXT J
4700 COLOR 10,0
4710 I=6
4720 FOR J=7 TO 17 STEP 5
4721 K=I:GOSUB 9000
4730 LOCATE J,21:PRINT USING "###.##";T(I)
4731 K=I+1:GOSUB 9000
4740 LOCATE J,37:PRINT USING "###.##";T(I+1)
4741 K=I+2:GOSUB 9000
4750 LOCATE J,53:PRINT USING "###.##";T(I+2)
4760 I=I+10:NEXT J
4770 COLOR 9,0
4780 I=9
4790 FOR J=8 TO 18 STEP 5
4791 K=I:GOSUB 9000
4800 LOCATE J,21:PRINT USING "###.##";T(I)
4801 K=I+1:GOSUB 9000
4810 LOCATE J,37:PRINT USING "###.##";T(I+1)
4811 K=I+2:GOSUB 9000
4820 LOCATE J,53:PRINT USING "###.##";T(I+2)
4830 I=I+10:NEXT J
4840 COLOR 5,0
4850 LOCATE 5,16:PRINT USING "###.####";APT(2)
4860 LOCATE 15,16:PRINT USING "###.####";APT(8)
4870 LOCATE 10,32:PRINT USING "###.####";APT(3)
4880 LOCATE 20,32:PRINT USING "###.####";APT(9)

```



```

4890 LOCATE 5,48:PRINT USING "###.###";APT(6)
4900 LOCATE 15,48:PRINT USING "###.###";APT(4)
4910 LOCATE 10,64:PRINT USING "###.###";APT(7)
4920 LOCATE 20,64:PRINT USING "###.###";APT(5)
4930 COLOR 13,0
4940 LOCATE 2,37:PRINT USING "##.##";AHF4
4945 K=40:T(K)=AT(4):GOSUB 9000
4950 LOCATE 3,37:PRINT USING "###.##";AT(4)
4960 K=40:T(K)=AT(2):GOSUB 9000
4979 LOCATE 22,37:PRINT USING "###.##";AT(2)
4980 COLOR 13,0:LOCATE 23,37:PRINT USING "##.###";AHF2
4990 LOCATE 12,1:PRINT USING "##.###";AHF1
5000 K=40:T(K)=AT(1):GOSUB 9000
5010 LOCATE 13,1:PRINT USING "###.##";AT(1)
5020 COLOR 13,0:LOCATE 12,73:PRINT USING "##.###";AHF3
5030 K=40:T(K)=AT(3):GOSUB 9000
5040 LOCATE 13,73:PRINT USING "###.##";AT(3)
5050 COLOR 13,0:LOCATE 8,1:PRINT USING "##.###";AHF5
5060 K=40:T(K)=AT(5):GOSUB 9000
5070 LOCATE 9,1:PRINT USING "###.##";AT(5)
5500 '
5510 ' PRINTING THE RESULTS ON DATA FILE A:THREEDIM.DAT
5520 '
5530 PRINT #1, USING "\      \";TIME$
5540 PRINT #1, USING "###.## ##.## ##.## ##.## ##.##";T(38),
      T(36),T(1),T(37),T(39)
5550 PRINT #1, USING "###.## ##.## ##.## ##.##";T(2),T(3),T(4),T(5)
5560 PRINT #1, USING "###.## ##.## ##.##";T(6),T(7),T(8)
5570 PRINT #1, USING "###.## ##.## ##.##";T(9),T(10),T(11)
5580 PRINT #1, USING "###.## ##.## ##.## ##.##";T(12),T(13),T(14),T(15)
5590 PRINT #1, USING "###.## ##.## ##.##";T(16),T(17),T(18)
5600 PRINT #1, USING "###.## ##.## ##.##";T(19),T(20),T(21)
5610 PRINT #1, USING "###.## ##.## ##.## ##.##";T(22),T(23),T(24),T(25)
5620 PRINT #1, USING "###.## ##.## ##.##";T(26),T(27),T(28)
5630 PRINT #1, USING "###.## ##.## ##.##";T(29),T(30),T(31)
5640 PRINT #1, USING "###.## ##.## ##.## ##.##";T(32),T(33),T(34),T(35)
5650 PRINT #1, USING "###.#### ##.#### ##.#### ##.#### ##.####
      ##.#### ##.#### ##.####";APT(1),APT(2),APT(3),APT(4),APT(5),
      APT(6),APT(7),APT(8)
5660 PRINT #1, USING "##.### ##.### ##.### ##.### ##.###";AHF1,AHF2,
      AHF3,AHF4,AHF5
5670 PRINT #1, USING "###.## ##.## ##.## ##.## ##.##";AHT1,AHT2,
      AHT3,AHT4,AHT5
5680 RETURN
5690 END
6000 '

```

```

6010 ' TYPE-J THERMOCOUPLE CONVERSION PROGRAM    mV to deg C
6020 '
6030 IERR=0
6040 IF EMF<3.556 THEN TEMP=-.00426+EMF*(19.8555+EMF*(-.22977+.0126037*EMF)):
      GOTO 6120
6050 IF EMF<10.237 THEN TEMP=.44759+EMF*(19.4947+EMF*(-.13669+.0042424*EMF)):
      GOTO 6120
6060 IF EMF<17.467 THEN TEMP=4.04157+EMF*(18.4682+EMF*(-.03744+.00102*EMF)):
      GOTO 6120
6070 IF EMF<25.285 THEN TEMP=19.70136+EMF*(15.839+EMF*(.11042-.0017662*EMF)):
      GOTO 6120
6080 IF EMF<33.437 THEN TEMP=24.3252+EMF*(15.0696+EMF*(.14958-.0023976*EMF)):
      GOTO 6120
6090 IF EMF<38.171 THEN TEMP=-89.9797+EMF*(25.2779+EMF*(-.15467+.0006286*EMF)):
6100 TEMP=1219.255+EMF*(-71.5862+EMF*(2.2309-.018928*EMF))
6110 IF EMF < -.995 OR EMF > 42.922 THEN IERR=1
6120 RETURN
7000 '
7010 ' TYPE-T THERMOCOUPLE CONVERSION PROGRAM    mV to deg C
7020 '
7030 IERR=0
7040 IF EMF<3.44 THEN TEMP=-.01102+EMF*(25.887+EMF*(-.69704+.025629*EMF)):
      GOTO 7080
7050 IF EMF<7.3 THEN TEMP=1.0147+EMF*(25.1566+EMF*(-.53147+.014117*EMF)):
      GOTO 7080
7060 TEMP=3.32158+EMF*(24.14043+EMF*(-.38292+.006906*EMF))
7070 IF EMF < -.005 OR EMF > 11.5 THEN IERR=1
7080 RETURN
8000 '
8010 ' TYPE-T THERMOCOUPLE CONVERSION PROGRAM    deg C TO mV
8020 '
8030 IERR=0
8040 EMF=.00103+TEMP*(.038596+.000041*TEMP)
8050 IF TEMP < 10 OR TEMP > 30 THEN IERR=1
8060 RETURN
9000 '
9010 ' COLOR ADJUSMENT WITH RESPECT TO TEMPERATURE
9020 '
9030 IF T(K)<=50!, THEN COLOR 2,0
9040 IF T(K)>50! AND T(K)<=60!, THEN COLOR 2,0
9050 IF T(K)>60! AND T(K)<=70!, THEN COLOR 10,0
9060 IF T(K)>70! AND T(K)<=80!, THEN COLOR 3,0
9070 IF T(K)>80! AND T(K)<=90!, THEN COLOR 11,0
9080 IF T(K)>90! AND T(K)<=100!, THEN COLOR 14,0
9090 IF T(K)>100! AND T(K)<=110!, THEN COLOR 6,0
9100 IF T(K)>110! AND T(K)<=120!, THEN COLOR 12,0

```

```

9110 IF T(K)>120!, THEN COLOR 4,0
9120 RETURN
9130 END
10000 COLOR 9,0
10010 LOCATE 3,19:PRINT " ":LOCATE 3,20:PRINT STRING$(42," "):
      LOCATE 3,62:PRINT " "
10015 LOCATE 4,19:PRINT " ":LOCATE 4,62:PRINT " "
10020 LOCATE 5,19:PRINT " ":LOCATE 5,62:PRINT " "
10025 LOCATE 6,19:PRINT " ":LOCATE 6,62:PRINT " "
10030 LOCATE 7,19:PRINT " ":LOCATE 7,62:PRINT " "
10040 LOCATE 8,19:PRINT " ":LOCATE 8,62:PRINT " "
10050 LOCATE 9,19:PRINT " ":LOCATE 9,62:PRINT " "
10060 LOCATE 10,19:PRINT " ":LOCATE 10,62:PRINT " "
10070 LOCATE 11,19:PRINT " ":LOCATE 11,62:PRINT " "
10075 LOCATE 12,19:PRINT " ":LOCATE 12,62:PRINT " "
10080 LOCATE 13,19:PRINT " ":LOCATE 13,20:PRINT STRING$(42," "):
      LOCATE 13,62:PRINT" "
10090 LOCATE 5,20:COLOR 12,0:PRINT "          STANFORD UNIVERSITY"
10100 LOCATE 6,20:PRINT "          PETROLEUM RESEARCH INSTITUTE"
10110 LOCATE 8,20:PRINT "  THREE DIMENSIONAL STEAM INJECTION MODEL"
10115 LOCATE 9,20:PRINT "          DATA LOGGING PROGRAM"
10117 LOCATE 11,20:PRINT "          BY, BIROL DEMIRAL, JULY 1990"
10118 '
10120 '  CREATE AND OPEN DATA FILE
10130 '
10140 COLOR 9,0
10150 LOCATE 16,9:PRINT " ":LOCATE 16,10:PRINT STRING$(61," "):
      LOCATE 16,71:PRINT" "
10160 LOCATE 17,9:PRINT "
      "
10170 LOCATE 18,9:PRINT " ":LOCATE 18,10:PRINT STRING$(61," "):
      LOCATE 18,71:PRINT" "
10180 LOCATE 18,10:PRINT STRING$(61," ")
10190 LOCATE 17,11:COLOR 10,0:PRINT "PLEASE ENTER THE NAME OF
      TODAY'S DATA FILE
10200 LOCATE 17,54:COLOR 12,0:INPUT FILENAME$
10210 COLOR 15,0
10220 OPEN FILENAME$ FOR APPEND AS #1
10225 CLS
10230 RETURN
10240 END

```

Appendix D. Computer Program for Data Preparation for Areal Temperature Distributions

```
10 ' PROGRAM FOR PREPARING THE DATA FROM
20 ' THREE DIMENSIONAL STEAM INJECTION
30 ' EXPERIMENTS FOR CONTOUR PLOTTING
40 ' (B. DEMIRAL, JANUARY 15, 1991)
100 DIM T(40):CLS
110 COLOR 14,0:INPUT "Please Enter Input Data File Name ";FILENAME$
120 OPEN FILENAME$ FOR INPUT AS #1
130 INPUT "Please Enter the Number of Data Sets ";NUM
140 FOR I=1 TO NUM
150 INPUT "Please Enter the Time as hh:mm:ss ";T$
160 LINE INPUT #1, TIM$
170 IF TIM$=T$ THEN GOSUB 240 ELSE GOTO 160
180 COLOR 14,0:INPUT "Would You Like to go on With Another Time
    Step (Y/N) ";FLAG$
190 IF FLAG$="Y" OR FLAG$="y" THEN GOTO 150 ELSE GOTO 210
200 NEXT I
210 CLOSE #1
220 STOP
230 END
240 BEEP:BEEP:BEEP 'DATA READING
250 COLOR 10,0:INPUT "Please Enter Data File Name For This Data Set ";AD$
260 INPUT #1,T(38),T(36),T(1),T(37),T(39)
270 FOR I=2 TO 35
280 INPUT #1,T(I)
290 NEXT I
300 OPEN AD$ FOR OUTPUT AS #2
310 FOR I=1 TO 39
320 PRINT #2, USING "###.##";T(I)
330 NEXT I
340 CLOSE #2
360 AT$=AD$:AC$=AD$:AB$=AD$
370 TOP$="T.DAT"
380 CENTER$="C.DAT"
390 BOTTOM$="B.DAT"
400 MID$(AT$,8)=TOP$
410 MID$(AC$,8)=CENTER$
420 MID$(AB$,8)=BOTTOM$
430 OPEN AT$ FOR OUTPUT AS #3
```

```

440 OPEN AC$ FOR OUTPUT AS #4
450 OPEN AB$ FOR OUTPUT AS #5
460 N=2
470 FOR J=43 TO 7 STEP -12
480 K=N
490 FOR I=43 TO 7 STEP -12
500 PRINT #4, USING "## ## ###.##";I;J;T(K)
510 K=K+10
520 NEXT I
530 N=N+1
540 NEXT J
550 CLOSE #4
560 N=6:NN=9
570 FOR J=37 TO 13 STEP -12
580 K=N:KK=NN
590 FOR I=37 TO 13 STEP -12
600 PRINT #3, USING "## ## ###.##";I;J;T(K)
605 PRINT #5, USING "## ## ###.##";I;J;T(KK)
610 K=K+10:KK=KK+10
620 NEXT I
630 N=N+1:NN=NN+1
640 NEXT J
650 CLOSE #3
660 CLOSE #5
900 RETURN
910 END

```

Appendix E. Computer Program for Data Preparation for Sectional Temperature Distributions

```
90 '
100 '   THIS PROGRAM PREPARES DATA FOR SECTIONAL TEMPERATURE
110 '   DISTRIBUTIONS
120 '
140 '   IT USES PREGRIDDED DATA BY GRIDCON
150 '
160 '   BY, BIROL DEMIRAL
170 '   JANUARY 16, 1991
180 DIM TT(2401),TC(2401),TB(2401)
190 DIM TEMP(49,19)
200 CLS:COLOR 10,0:INPUT "Please Enter Datafile Name for Top Level   :";
    TNAME$
210 INPUT "Please Enter Datafile Name for Center Level :";CNAME$
220 INPUT "Please Enter Datafile Name for Bottom Level :";BNAME$
230 OPEN TNAME$ FOR INPUT AS #1
240 OPEN CNAME$ FOR INPUT AS #2
250 OPEN BNAME$ FOR INPUT AS #3
260 FOR I=1 TO 2401
270 INPUT #1, TT(I)
280 INPUT #2, TC(I)
290 INPUT #3, TB(I)
300 NEXT I
310 CLOSE #1
320 CLOSE #2
330 CLOSE #3
345 COLOR 15,0:INPUT "Please Enter the Section Number   :";I
355 COLOR 14,0
360     INPUT "Please Enter the Datafile Name for This Section :";SECNAME$
370     OPEN SECNAME$ FOR OUTPUT AS #1
371 IF I=1 THEN KK=1912
372 IF I=2 THEN KK=1618
373 IF I=3 THEN KK=1324
374 IF I=4 THEN KK=1030
375 IF I=5 THEN KK=736
376 IF I=6 THEN KK=442
380 FOR M=1 TO 49
390 TEMP(M,18)=TT(KK)
```

```

400 TEMP(M,10)=TC(KK)
410 TEMP(M,2)=TB(KK)
420 KK=KK+1
440 NEXT M
470 FOR J=2 TO 18 STEP 8
480 FOR N=1 TO 49
490 PRINT #1, USING "### ## ###.####";N;J;TEMP(N,J)
500 NEXT N
510 NEXT J
520 CLOSE #1
540 COLOR 12,0:INPUT "Would You Like to go on With Other File Sets (y/n) :";F$
550 IF F$="Y" OR F$="y" GOTO 200
560 STOP
570 END

```

*U.S.GPO:1992-661-026/60043

END

**DATE
FILMED**

10 / 8 / 92