DOE/PC/89782--T4

DE92 018329

ENVIRONMENTAL IMPACT ASSESSMENT OF SELENIUM FROM COAL MINE SPOILS

Quarterly report, Grant No. : DE-FG22-89PC-89782

Prepared by:

**Asmare Atalay, Assistant Professor
University of Oklahoma
Civil Engineering and Environmental Science
202 West Boyd, Room 334
Norman, Oklahoma 73019**

Date: October 1, 1990

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

MASTER

DISTRIBUTION OF THIS DOCUMENT IS UNLIMITED

TABLE OF CONTENTS

	Page
Introduction	1
Sources of Selenium in Nature	2
Soils	4
Plants	5
Other Natural Sources of Selenium in the Environment	6
Selenium from Coal Mine Spoils	8
Environmental Impact Assessment Procedures for Selenium Pollution	14
Impact Assessment Model for Selenium	17
1. Obtain Regional Maps	17
2. Define the Impact Assessment Boundaries	18
3. Specify Subregions	18
4. Collect Data	20
5. Transport Analysis	22
6. Surface Water Transport Analysis	27
Streams and Rivers	27
Lakes and Impoundments	35
7. Ground Water Transport Analysis	37
Literature Cited	41

INTRODUCTION

The element selenium was first discovered by the Swedish chemist J.J. Berzelius in 1817. It is located between sulfur and tellurium in the periodic table. Selenium is both beneficial and toxic to animals and humans although it is said to be not essential to plants. The narrow gap between essential levels and toxic concentrations of Se makes it imperative to understand and identify the sources and distribution of Se in the environment and the mechanisms by which it accumulates in plants and animals. Much has been learned about selenium from previous studies, yet more research is needed Se about the toxic effect of this important nutrient element. Selenium is a trace element and no large deposits of concentrated selenium have been discovered. High levels of Se are found in copper and coal deposits. The largest source of environmental contamination by selenium results from the natural weathering of seleniferous rocks. Industrial activities also contribute to environmental contamination from Se.

The necessity for increasing domestic energy production in the United States led to greater exploitation of fossil fuels (for the most part, coal) in the 1970's. During such exploitation, a wide range of ecological damage occur, mostly from our ignorance about the sensitivity of the environment. One effect believed certain to follow these operations was an alteration of the geochemical environment in or near the disturbed areas. The operation of coal

mining produces a continuing addition of chemical elements to the surrounding area, often including those elements generally considered undesirable, or toxic if concentrated, such as selenium. Selenium can be distributed to the surrounding environment from mined coal and coal mine spoils. Thus, selenium in coal mine spoils will be a potential contamination source to the environment.

The development of environmental impact assessment of selenium from coal mine spoils will provide a useful guideline to predict the environmental impact of Se from abandoned coal mine operations. Information obtained from such a study can be applied in areas where coal mining has not yet begun in order to predict and identify the geochemistry of rocks, soils, surface waters and groundwaters likely to be disturbed by coal mining operation.

1. Sources of Selenium in Nature

The sources of selenium in nature and its occurrence have been reviewed by a number of authors, the following discussion summarizes these reviews.

Rocks

Selenium is a trace element and determination of the elemental concentration in a variety of materials has indicated that Se is widely distributed throughout the environment. It occurs naturally in all materials of the earth's crust and the element is present in almost all rocks and soils. The average concentration of

selenium in the earth is stated to be 0.09 ppm. The element is 40th in abundance on earth (1). The main natural sources of Se in the environment are volcanic action and weathering of sediments and rocks.

Volcanic eruptions often result in losses of volatile Se from silicate rocks formed from magma. Volatile Se is distributed over the earth's surface eventually to add to the Se content of present-day soils and also to the concentration of the element in sedimentary rocks. These sedimentary rocks may be a source of Se for soils weathered in later geological time or they may serve as a long-term sink of potentially toxic amounts of the element.

Sedimentary rocks usually have Se concentrations much higher than the earth's average of 0.09 ppm. The ranges of Se concentrations of limestone, sandstone and shales in Oklahoma was determined to be 0.10 to 7.40, 0.10 to 1.70, and 0.10 to 12.0 ppm, respectively (2). Igneous rocks are generally impoverished in Se as they are in S because of volatilization of these elements by volcanic activity. Phosphate rocks range from well below 1 to about 300 mg Se/kg (3).

Rock weathering is the major natural source of Se in the environment. Weathering of the earth's crustal material results in an estimated 1.0×10^6 kg S and 7.2×10^6 kg Se being mobilized annually and transported by rivers draining the land mass in the continental USA and the world, respectively (4).

Soils

The Se content in soil reflects the concentration in the parent material from which the soil is derived, the secondary deposition or redistribution of Se within the soil profile by pedogenic activity, the accumulation and deposition to surface horizons by Se-accumulating plants, and erosion or deposition of Se from other rocks or volcanic sources.

Shales are the parent materials for about 40 % of the earth's soils. Sandstones, limestones and igneous rocks are about equally abundant at weathering surfaces. Soils derived from shales are the most likely to be well supplied with Se. The majority of seleniferous soils are weathered from shales. Soils derived from sandstones and limestones may have variable Se concentrations. Soils of igneous origin are most likely to be very low in Se.

Selenium concentrations in soils range from less than 0.1 ppm in a Se-deficient area of New Zealand to as high as 1200 ppm in an organic soil in Ireland (5). Swaine (6) reported that most soils contain 0.1 to 2 mg/kg of total Se. However, we must point out that total Se in a soil is not a satisfactory index of possible Se concentrations in plants. Availability of Se to plants is governed by the chemical form of the element in the soil and by pH and Eh in the root-soil environment (7). Some soils of Puerto Rico and Hawaii have high total Se, but they do not produce seleniferous vegetation, whereas soils in South Dakota containing a lower total selenium concentration and produce Se laden vegetation.

Plants

All plants are capable of taking up some Se if growing in soils where Se is available. Plants absorb and accumulate Se from soil. During plant growth, Se is removed from the soil and rocks and accumulated in the plant tissue. When these plants die and decompose at the soil surface, they release organic and inorganic Se to the local environment.

Some of the Se in plants upon decomposition either in-situ or via animal digestive processes is present as organic compounds, but most of it is in inorganic form as selenite or selenate. Selenite is rapidly fixed as ferric hydroxy selenites of the general type $\text{Fe}_2(\text{OH})_2\text{SeO}_3$. At pH of 4 to 8 these complexes may supply sufficient Se for production of plant materials to provide adequate Se for animals. Selenate forms in well-aerated conditions especially at pH above 7. Selenates are more soluble than selenites and leach more easily from the soil. Almost all instances of Se poisoning of animals by plants occur under such conditions (7).

The relationship among the concentrations of Se in rocks, soils and plants can be summarized as follows (8):

(i) Where rocks with a high content of Se decompose to form well-drained soils in subhumid areas (< about 20 in. of annual rainfall), selenides and other insoluble forms of Se will be converted to selenates and organic Se compounds. These compounds will be available to plants, and vegetation containing potentially toxic levels of Se will probably be produced on these soils.

(ii) Where rocks with a high content of Se weather to form

soils in humid areas, slightly soluble complexes of ferric oxide or hydroxide and selenite ions will be formed. These soils will also be slightly-to-strongly acidic, and the plants produced on them will not contain toxic concentrations of Se, but they may contain sufficient Se to protect livestock consuming them from Se deficiency.

(iii) Where rocks with a high content of Se weather to form poorly drained soils, or where Se from higher lying areas is deposited in poorly drained areas by alluvial action, and the soils are alkaline, plants containing toxic levels of Se are likely to be produced. This will be especially probable if the aeration of these soils is improved by artificial drainage. The more acid the soils in an area, the less likely that the vegetation will contain toxic levels of Se.

(iv) Where rocks with a low content of Se decompose to form soils under either humid or dry conditions, the plants produced are likely to contain insufficient Se to protect animals from Se deficiency. The more humid the area and the more acid the soil, the greater the likelihood for extremely low Se concentrations in the plants.

Other Natural Sources of Selenium in the Environment:

Table 1 lists selected sources of Se in nature. Selenium occurs commonly in fossil fuels. Coal usually can contain up to 10 mg Se/kg, and fuel oil up to 7.5 mg Se/kg. The large amounts of

Table 1. Selected Se concentrations in some natural sources.

Materials	Se, mg/kg	Reference
Earth's crust	0.05	Taylor, 1964
	0.03-0.8	NAS, 1976
Granite	0.01-0.05	Kabata-Pendias, 1984
Limestone	0.08	Ebens & Shacklette, 1982
	0.03-0.1	Kabata-Pendias, 1984
(Oklahoma)	0.19-0.31	Connor & Shacklette, 1975
Sandstone	< 0.05	Ebens & Shacklette, 1982
	0.05-1.12	Lakin & Davison, 1967
(Oklahoma)	0.11	Connor & Shacklette, 1975
Shales	0.06	Ebens & Shacklette, 1982
	0.24-277	Lakin & Davison, 1967
(oklahoma)	0.46-0.64	Connor & Shacklette, 1975
Phosphate rocks	1- 300	NAS-NRC, 1976
	1-178	Rader & Hill, 1935
Soils		
Seleniferous	1-80	Trelease, 1945
	<1200	Fleming, 1962
Other soils		
USA	<0.1-4.3	Shacklette & Boerngen, 1984
England	<0.01-4.7	Thornton et al., 1983

Table 1. (Continued)

Coal	0.46-10.65	Pillay et al., 1969
	0.2-44	Boon & Smith, 1985
	1-20	Mayland et al, 1989
Crude oil	0.06-0.39	Pillay et al, 1969
Atmospheric dust	0.05-10	Lakin & Byers, 1941
Vegetation		
Se accumulators	51-4474	Rosenfeld & Beath, 1964
Crop plants(low-Se)	< 0.05	Rosenfeld & Beath, 1964
Fruits and vegetables	< 0.01	Allaway, 1973
USA plants		
Grasses	0.01-0.04	Kabata-Pendias, 1984
Clover & alfalfa	0.03-0.88	Kabata-Pendias, 1984
Barley	0.2-1.8	Ebens & Shacklette, 1982
Algae		
Marine	0.04 - 0.24	Chau & Riley, 1965
Freshwater	<2.0	Jenkins, 1980
Aquatic range is as those in neighbouring states.		
Ocean waters	0.0001-0.004	Schutz and Turekian, 1965
River waters	0.0001-0.0004	Kharkar et al, 1968
Aquatic plants	0.02-0.14	Sandholm et al, 1973
Fish	0.5-6.2	Lakin, 1972
Anthropogenic		
Petroleum products	0.15-1.65	Lakin, 1972
Fly ash	1.2-16.5	Grtenmann et al, 1976
Sewage sludge	1.8-4.8	Furr et al, 1980

coal residues produced by coal-fired power plants are a potential source of Se in the environment (9). Selenium concentrations in surface waters average 2 ug/L or less (10). Drainage from irrigation and soil leaching are principal sources of Se in waters. Apparently, water can rarely be considered a significant source of the element either from a nutritional or toxicity viewpoint. However, even at the very low levels found in rivers, the large volume of water involved contribute to the transport of rather large amounts of the element. It is estimated that river flow deposits about 8,000 tons of Se per year into oceans (11). Water, therefore, is important in actively and continuously leaching, transporting, and redepositing the element.

Data on the actual presence of Se in air are limited. It appears that Se continuously enters the air and is removed from it. The average concentration of Se in air is very low, probably well below 0.01 ug/M³. It seems unlikely that pollution of the atmosphere by selenium at present constitutes a problem. Selenium concentration in petroleum products was determined to be approximately 1 ppm (12). It is suspected that petroleum products may be important sources of Se pollution in the atmosphere.

A potential Se pollution source, especially in the food chain, may be the use of sewage fertilizers on agricultural lands. Andersen and Nelson (13) measured changes in content of trace elements in soils and plants as the result of applications of sewage sludge. Total and acid extractable soil contents of all elements applied (Mn, Zn, Cu, Ni, Co, Cr, Pb, Cd, Hg, and Se)

increased as would be expected. However, the observed fact that the decreased plant availability of Se from the treated soils was difficult to explain. Two possible postulations based on soil chemistry were suggested. First, if sludge additions result in lowered soil pH, then Se may be less available by virtue of formation of the very insoluble $\text{Fe}_2(\text{OH})_4\text{SeO}_3$. Second, other cations in the sludge, Cd, Co, Cu, Pb, etc., may also form insoluble Se compounds (14). Table 1 lists selected Se sources in nature.

2. Selenium from Coal Mine Spoils

In order to determine the quantity of Se that originate from coal mine spoils, and the release of the element into the surrounding environment, we must first characterize the Se content of the coal. Since Se can replace S in organic complexes and in sulfides, the Se content of coal may be many times its crustal abundance. In fact, Se is the most highly enriched element found in coal. Coal often contains from 1 to 20 mgSe/kg, although some coal from the People's Republic of China is known to contain over 1000 mg Se/kg (15). A survey of 86 samples of coal from U.S.A. (see Table 2) indicates that these samples contain an average of 3.36 ppm of selenium, which is over 34 times the crustal abundance of the element (16). It is evident that selenium concentration in coal can vary over a fairly wide range. This variation occurs not only between coal type and location, but also within seams at a given location. It is expected that the Se content of Oklahoma coal

Table 2. Selenium content of U.S.A. coals (Pillay, K.K.S. et al.)

State	# of Samples	Selenium content		
		Low	High	Average
		(ppm)	(ppm)	(ppm)
Alabama	4	2.20	8.15	5.14
Colorado	3	1.25	2.05	1.65
Illinois	2	1.05	1.97	1.51
Indiana	4	1.41	8.36	3.96
Iowa	1	1.54	1.54	1.54
Kansas	1	2.27	2.27	2.27
Kentucky	5	1.71	4.82	3.13
Maryland	1	1.70	1.70	1.70
Missouri	2	3.41	4.98	4.19
Montana	3	2.20	4.11	3.04
New Mexico	2	4.43	4.82	4.62
North Dakota	1	0.98	0.98	0.98
Ohio	4	2.64	7.30	4.62
Pennsylvania	11	1.35	10.63	3.74
Tennessee	1	4.89	4.89	4.89
Utah	4	1.30	2.37	1.83
Virginia	4	2.24	6.13	4.37
Washington	2	0.46	0.66	0.56
West Virginia	30	0.92	6.80	3.36
Wyoming	1	3.43	3.43	3.43

may be in the same range as those in the neighboring states.

Upon combustion, coal releases large amounts of Se into the ecosystem. About 40 % of the ash occurs as bottom ash or slag, 60 % as fly ash, and < 1 % as aerosols that escape to the atmosphere (17). Most of the bottom ash and the ash from precipitators are transported to landfills as solid residues or flushed with water to ash ponds, in this case Se may be leached from the ash and enter the aquatic environment. Also, during coal combustion, small particles and vapors are discharged as aerosols to the atmosphere, and will enter terrestrial and aquatic environment by wet or dry deposition. It is estimated that 1.5 to 2.5 times as much Se is mobilized through coal burning as by natural weathering processes (18).

The development of large-scale coal mining operations in the western USA has raised concerns regarding the potential for Se contamination of soils, surface water, and groundwaters in and adjacent to these mining operations. Coal mining operations in the resaturated backfill can increase Se solubility and mobility following oxidation of carbonaceous materials. The greatest Se contribution in backfill aquifers of coal mines apparently comes from carbonaceous roof shales and rider seams (19).

The introduction of selenium into the environment will follow some general paths. These potential routes include erosion of coal mine spoils onto land and into aquifer and oxidation and movement of selenates in percolating and runoff mine waters. Literature search has revealed that only a few studies have investigated Se concentration in coal mine spoils and associated materials. Selenium concentration in coal mine spoils and associated materials from eight mines in the western energy region of the United States

was determined by X-ray fluorescence and fluorimetric methods, respectively. Coal mine spoil materials at all mines consisted of claystone and siltstone with lesser amounts of sandstone, shale, and coal. Glacial deposits consisting of gravel, silt, sand, and clay are important spoil materials. Samples of spoil material or a spoil-soil mixture were collected to a depth of about 20 cm. The ground cover consisted of sweetclover and alfalfa that grew within 1 m of the coal spoil site. Table 3 lists the resulting data (20).

Crested wheatgrass was analyzed at the Dave Johnston Mine, Wyoming, to assess the possible effects of coal mine spoils on the chemical composition of this widely used reclamation species. Eight elements (Cd, Co, F, Mn, P, U, V, and Zn) showed significant differences between the samples growing in 10-15 cm of topsoil covering the spoils and the samples from soils nearby. Selenium concentration, however, showed no significant difference. The mean Se concentrations in the topsoil borrow areas and reclaimed spoil areas are 0.23 ppm and 0.27 ppm, respectively (21). Further investigations are needed to determine Se content in spoils and plants that grow on mine spoil and reclaimed soils of abandoned coal mine areas. The possibility that elemental composition of forage grown on reclaimed spoil may be injurious to domestic as well as native animals should receive careful consideration in planning the revegetation of mined areas and proper utilization of these areas.

Table 3. Selenium in coal mine spoils and associated materials in the western energy region in the United States (20).

Sample, collection locality	Mean (ppm)	Observed range (ppm)
Coal mine spoil		
Beulah North mine, North Dakota	0.19	0.1-0.41
Dave Johnston mine, Wyoming	0.28	<0.1-0.69
Hidden Valley mine, Wyoming	0.31	0.18-0.49
Kincaid mine, North Dakota	0.22	<0.1-0.45
Savage mine, Montana	0.20	<0.1-0.66
Velva mine, North Dakota	0.21	<0.1-0.54
Big Sky mine, Montana	0.17	<0.1-0.40
San Juan mine, New Mexico	0.19	<0.2-0.70
Topsoil used in spoil reclamation		
San Juan mine, New Mexico	0.18	<0.2-0.50
Plants (dry-weight basis)		
Yellow sweetclover		
Beulah North mine, North Dakota	0.15	0.08-0.60
Dave Johnston mine, Wyoming	0.37	0.10-3.00
Hidden Valley mine, Wyoming	0.53	0.15-1.20
Kincaid mine, North Dakota	0.17	0.06-0.55
Savage mine, Montana	1.30	0.60-6.00
Velva mine, North Dakota	0.49	0.15-2.00
White sweetclover		
Big Sky mine, Montana	0.42	0.08-1.00
Utility mine, Saskatchewan	0.23	0.06-0.50
Alfalfa		
Beulah North mine, North Dakota	0.18	0.06-0.35
Dave Johnston mine, Wyoming	0.34	0.20-0.80
Savage mine, Montana	1.10	0.75-2.70
Velva mine, North Dakota	0.33	0.30-0.40
Big Sky mine, Montana	0.22	0.10-0.45
San Juan mine, New Mexico		
Fourwing saltbush	0.22	0.10-0.45
Alkali Sacaton	0.096	0.080-0.10

Figure 1. Selenium impact assessment framework ---- Part 1

Figure 2. Selenium impact assessment framework ---- Part 2.

Environmental Impact Assessment Procedures for Se pollution

Selenium released from coal mine spoils can be dispersed and transported into the environment through several pathways. The main routes of Se from coal mine spoils into the surrounding environment are via erosion and runoff. In both cases Se reaches the land and the surface waters, and leaches into ground waters. In order to predict and identify the environmental impact associated with such sources, the method applied must be able to follow Se through the environment and to calculate the concentrations in all media of the region surrounding the mine spoil source.

An outline of the environmental impact assessment process of Se from coal mine spoils is shown in Figures 1 and 2, respectively. Figure 1 traces Se from coal mine spoil through the various environmental transport mechanisms. This figure shows Se originating from various sources subsequently reaches surface and ground water. Selenium that entered the environmental media is dispersed, and transferred within the media. This figure also suggests that such general processes and interactions between media must be considered while determining the distribution and extent of contamination of the surrounding environment. Figure 2 shows that Se concentrations in the environment are passed through the food web and other exposure pathways to generate health risks for the regional population.

IMPACT ASSESSMENT MODEL FOR SELENIUM

Similar to other environmental impact assessment procedures, some simplified environmental transport models can be applied to calculate Se concentrations in soil, surface waters, and groundwaters. The results of such an analysis could be incorporated into environmental impact reports or similar documents and used to respond to public concern about Se potential pollution.

A basic analysis procedure that should be used when doing the impact assessment is as follows:

1. Obtain regional maps.
2. Define the analysis boundaries.
3. Specify subregions.
4. Collect data.
5. Soil transport analysis.
6. Surface water transport analysis.
7. Groundwater transport analysis.

1. Obtain Region Maps

In the beginning of the impact assessment, large scale maps or aerial photographs of the region surrounding the coal mine spoils should be obtained. These maps or photographs should contain the entire area expected to be included in the impact assessment. They can be used to determine the surface water network, locate regional populations, estimate runoff patterns, and define land use

patterns in the area.

2. Define the Impact Assessment Boundaries

Besed on the regional maps and preliminary information, the spatial and temporal boundaries of the impact assessment can be defined. This definition should include (1) study area, (2) overall time period and intervals, (3) environmental media, (4) pollution species, in this case, Se, (5) surface water network, and (6) Se migration routes. This definition can be used to structure the impact assessment and the data collection activities, but can be changed later if it is necessary.

3. Specify Subregions

For the convencience of doing Se impact assessment, the study area can be divided into subregions. The subregion definition is flexible and can probably be based on regional population distribution, water consumption patterns, and the surface water network. For example, Figure 3 show a hypothetical coal mine spoil site near the towns X, Y, Z, and the river XYZ. In order to simplify the impact assessment, yet still have sufficient detail to demonstrate the methodology, we can partition the region into 40 subregions using a combination of angular sectors and radial segments. This type of partitioning can also be used in

Figure 3. A hypothetical coal mine spoil site.

environmental impact assessment of coal mining areas and nuclear power plants. The subregion divisions are shown in Figure 4.

4. Collect Data

The data on the chemical characteristics of natural materials that will most likely be affected by coal mining --that is, background (baseline) geochemistry--are important for identifying and evaluating the environmental changes that occur during coal mining. Included in these materials are the rocks, soils, and plants of the overburden material that will be removed during surface mining, the rocks from underground mining that will be brought to the surface, and the streams that drain out of the mining areas (20). This background data can be used to predict the environmental impact of the proposed coal mining operation.

In general, necessary data should be collected to describe regional population, water sources and consumption, atmospheric conditions, agriculture productions, land uses, regional hydrology, geology, meteorology, background pollutant concentrations, and other variables. This data can be used to refine the problem definition and boundaries and to define the subregions for the impact assessment. For example, the hydrologic data might include:

1. Runoff quantity and quality.
2. Stream flows (low, mean, high, critical) and water quality parameters (for example, temperature, pH,

Figure 4. Description of subregions and surface water network.

dissolved solids, pollutant concentrations).

3. Impoundment/lake residence times, inflows/outflows, stagnant regions, thermal stratification, internal flow patterns, rates of sediment accumulation, and water quality.

Most of these necessary data is be available from governmental organizations such as the USGS, state geological and environmental agencies, and the Corps of Engineers.

5. Soil Transport Analysis

Selenium concentration in surface soil layers and surface runoff water can be calculated by soil transport models. Runoff results become source terms for the appropriate waterways in the subsequent surface water transport analysis.

Soil transport analysis is done to determine Se concentration in surface soil layers, Se infiltration rates through the soil into ground water, runoff flows, and Se concentration in the runoff.

A simplified method can be used in many situations for Se soil transport analysis. In this method (22), a set of location-dependent coefficients are used, they include:

- * Deposition in irrigation water.
- * Uptake by plants.
- * Leaching into subsurface soil.
- * Runoff into surface water.

* Accumulation in surface soil.

Each of these processes is considered in calculating Se concentration in surface soil layers. It can be used as a tool to investigate how each of these processes may affect the distribution of Se in the environment.

The quantity of Se in a volume of surface soil at the end of a particular time period can be determined by the background Se concentration in the soil at the beginning of the period, the deposition rate, and the rate at which Se leaves the soil volume. Se can leave surface soil either through runoff, plant uptake, or infiltration into deeper soil layers and groundwater. The deposition rate is calculated from the following equation:

$$D_t = D_{is} + D_{ig}$$

$$D_{is} = I_s C_s$$

$$D_{ig} = I_g C_g$$

Where D_t = total Se deposition rate ($\text{mg}/\text{m}^2/\text{s}$),

D_{is} = Se deposition rate from surface water irrigation
($\text{mg}/\text{m}^2/\text{s}$),

D_{ig} = Se deposition rate from groundwater irrigation
($\text{mg}/\text{m}^2/\text{s}$),

I_s = irrigation rate for surface water ($\text{L}/\text{m}^2/\text{s}$),

I_g = irrigation rate for groundwater ($\text{L}/\text{m}^2/\text{s}$),

C_s = incremental Se concentration in surface water used
for irrigation (mg/L),

C_g = incremental Se concentration in groundwater used

for irrigation (mg/L).

Note that the Se concentrations in irrigation water should be incremental, since the model deals only with the amount of Se above background levels, that is, the Se added from the coal mine spoils.

Selenium entering a volume of soil may be lost to (1) plant uptake or interception, (2) infiltration into deeper soil layers, and (3) runoff into surface waters. The remaining Se will accumulate in the surface soil layer. If we know the total deposition rate, Se removal rates for infiltration and plant interception can be calculated from the following equations:

$$R_p = D_t f_p T$$

$$R_{d1} = D_t f_{d1} T$$

Where R_p = Se removal rate for plant interception (mg/m²),

R_{d1} = Se removal rate for deep infiltration (mg/m²),

f_p = fraction of total deposition removed by plant interception (dimensionless),

f_{d1} = fraction of total deposition removed by deep infiltration (dimensionless),

T = length of time period (s).

The amount of Se remaining in the soil can be found from:

$$R_s = D_t f_s T$$

Where R_s = Se accumulation rate in surface soil (mg/m^2),

f_s = fraction of total deposition remaining in surface soil
(dimensionless).

This accumulated Se will change the existing background Se concentration in the surface soil. The new Se concentration can be found from the following equation:

$$C_s = C_{sb} + \frac{R_s}{p_s}$$

Where C_s = Se concentration in surface soil (mg/kg),

C_{sb} = background Se concentration in surface soil (mg/kg),

p_s = effective surface soil density (kg/m^2).

The effective surface soil density is calculated from

$$p_s = 10.0 \, p \, d_s$$

Where p = soil density (gm/cm^3),

d_s = depth of surface soil (cm).

The remaining Se may be removed from the area through runoff to surface waters, and the runoff calculation include the subregion area. For a given subregion, total Se runoff can be calculated from

$$O_t = D_t A [f_{sr} f_r + (1.0 - f_{sr}) f_{su}]$$

Where O_s = Se contained in runoff to surface water (mg/s),
 A = subregion area (m^2),
 f_{ar} = fraction of subregion area that is rural
(dimensionless),
 f_{au} = attenuation factor for urban area (dimensionless),
 f_r = fraction of total deposition in rural areas that
enters runoff to surface waters (dimensionless).

This calculation divides Se deposition between urban and rural areas and assigns an effective attenuation factor to urban areas.

In effect, the simplified soil transport model partitions Se between plant interception, deep infiltration, surface soil accumulation, and runoff. Deposition and runoff rates depend on the extent and type of irrigation, soil conditions, precipitation characteristics, and agricultural practices. To simplify the analysis, we can assume uniform soil conditions and irrigation practices across the region. A difficult assumption to make in the application of the above equations to our study would be the deposition period. This is because Se may or may not accumulate in the soil over time, depending on whether or not Se is taken up by plants. If Se is not taken up, it will accumulate and higher concentrations will develop over time. However, if it remains in the soil, it will not pose any health risk to the population. Conversely, if plant uptake is significant, the potential health risk will increase, but surface soil concentration will be lower. As a result, a one-year period can be usually selected based on the fact that plants were harvested once a year. In general, it should

be understood that Se concentration in soils will be influenced by many factors, such as plant types, soil conditions, agricultural and irrigation practices, and meteorological conditions.

6. Surface Water Transport Analysis

Two types of surface water bodies will be considered in Se impact assessment. One type is streams and rivers, and another type is lakes or impoundments. The main route for Se transport into surface water bodies is runoff from coal mine spoils (nonpoint source). At the same time, there may be other transport mechanisms for Se addition into surface waters, which include municipalities and coal fired-power plant discharges (point source). Finally, there is background Se level in surface water bodies (natural source). A useful water quality model should be able to deal with all three types of sources. The two types of surface water bodies will be discussed separately.

Streams and Rivers

Before the developed stream model is applied to a real problem, we must make some simplifying assumptions. These general assumptions are:

- * Steady-state conditions.
- * Plug flow without dispersion.

- * Complete vertical and lateral mixing.
- * First order decay processes.

The steady-state assumption implies that the conditions are independent of time but change over distance along the waterway. The second and third assumptions mean that dispersion effects can be ignored along the waterway and that Se concentration is constant across the entire waterway at all depths at any given location. The assumption of plug flow may give higher Se concentration than it would be with normal dispersion processes. There is limitation on the first-order relationship for all decay and removal processes, so care should be taken in any particular situation while determining the validity of this assumption.

To use the model, we can divide waterways under analysis into several reaches, each of which is assumed to be uniform in character (such as velocity, depth, area, and nonpoint loading rate). Reach determination can be based on consideration of the locations of major point sources and the distribution of nonpoint sources along the stream, since the model equation is based on locating primary point sources at the beginning of each reach and distributing nonpoint sources uniformly along the entire reach. For each reach, some data are needed. These data include stream velocities and flow rates, Se loading rates (point and nonpoint sources), decay rates, and background Se concentrations. Since background Se concentration and other loading rates may vary with season, it may be appropriate to consider mean and extreme

conditions throughout the year.

The model calculates Se concentrations within each reach as a function of distance downstream from the beginning of the reach. For a selected stream, the model begins calculations at the extreme upstream reach, taking the background Se concentration, flow information, Se loading, and the data of the reach at the beginning of that reach. Although the decay and removal mechanisms is supposed to be first-order process, the total decay coefficient, k_t , can vary in different reaches, depending on the physical and chemical conditions of the stream. The following is a basic equation for the model (22),

$$\frac{\partial C}{\partial t} = - \frac{1}{A} \frac{\partial}{\partial x} (QC) - k_t C + \frac{C_d}{A} \left(\frac{\partial Q}{\partial x} \right) + C_p$$

Where C = Se concentration (mg/L),

Q = flow rate (m³/s),

A = stream cross-sectional area (m²),

k_t = total decay coefficient (1/s),

C_d = Se concentration in nonpoint sources (mg/L),

C_p = Se concentration in point sources (mg/L),

x = downstream distance (m).

These calculations assume constant cross-sectional area in each reach of the stream. The mean cross sectional area for a reach can be determined by:

$$A = \frac{Q}{U}$$

There are four different solutions for the above model equation depending on four different types of Se sources in each reach. These four solutions and their application conditions are presented below (22).

Type 1. In this case, there is just only one point Se source in the beginning of the reach. Under this condition, the Se concentrations at any point downstream can be determined by the following equations:

$$C_o = \frac{C_u Q_u + 0.001(W - W_1)}{Q_u + Q_v - Q_1}$$

$$C = C_o \exp \left(\frac{-1000.0 k_t x}{U_o} \right)$$

$$C_a = C_o - C + C_{ua}$$

$$Q_x = Q_u + Q_v - Q_1$$

Where C = Se concentration at location x (mg/L),

C_a = Se product concentration at location x (mg/L),

C_o = Se concentration at upstream end of reach (mg/L),

C_u = Se concentration at upstream reach (mg/L),
 C_{ua} = Se product concentration at upstream end of reach
(mg/L),
 Q_x = stream flow rate at location x (m^3/s),
 Q_u = stream flow rate upstream of reach (m^3/s),
 Q_w = waste flow rate from point source (m^3/s),
 Q_i = water removal rate for irrigation (m^3/s),
 U_o = stream velocity at upstream end of reach (m/s),
 W = Se load from point source (mg/s),
 W_i = Se removal rate for irrigation (mg/s),
 x = distance downstream from beginning of reach (m).

Two things that should be kept in mind are (1) upstream Se concentrations and flow rates are equivalent quantities at the downstream end of the previous reach, and (2) in this and later solutions, the Se product is defined as the result of the decay process. The Se product concentration can give some information about the potential hazards of decay products or the accumulation of Se in river sediment, depending on the sources of Se removal from the water.

Type 2. In this type condition, we suppose that there are a point source at the start of the reach and a distributed nonpoint source without additional flow along the reach. Under these conditions, the solution is:

$$C_p = \frac{0.001(W_p + W_r)}{X_r A}$$

$$C_o = \frac{C_u Q_u + 0.001(W - W_1)}{Q_u + Q_v - Q_1}$$

$$C = \frac{C_p}{k_t} + \left(C_o - \frac{C_p}{k_t} \right) \exp - 1000.0 k_t \left(\frac{x}{U_o} \right)$$

$$C_a = C_o + C_p \left(\frac{x}{U_o} \right) - C + C_{ua}$$

$$Q_x = Q_u + Q_v - Q_1$$

Where C_p = Se flux from nonpoint source (mg/L/s),

W_p = Se load from nonpoint sources without flow (mg/s),

W_r = Se load from soil runoff without flow (mg/s).

Type 3. In this type condition, the reach has a point source at the beginning and a distributed nonpoint source with flow along its length. The flow at any point downstream from the beginning of the reach can be determined as follows:

$$Q_x = Q_u + Q_v + (Q_r - Q_u - Q_v) \frac{x}{X_r}$$

$$\Delta_q = \frac{Q_x - Q_u - Q_v}{x_x}$$

Where Q_x = stream flow rate at end of reach (m^3/s),

Δ_q = incremental stream flow rate ($m^3/s/m$).

The Se concentration at any point x can be determined by the following equation:

$$C_d = 0.001 \frac{W_d + W_q}{\Delta_q}$$

$$C_o = \frac{C_u Q_u + 0.001(W - W_1)}{Q_u + Q_v - Q_1}$$

$$C = \frac{C_d}{E} + \left(C_o - \frac{C_d}{E} \right) \left[\frac{Q_u + Q_v + Q_1}{Q_x} E \right]$$

$$C_s = \frac{C_o (Q_u + Q_v - Q_1) + C_d \Delta_q x}{Q_x} - C + C_{ua}$$

$$E = \frac{k_t A + \Delta_q}{\Delta_q}$$

Where C_d = Se concentration in the nonpoint source with flow (mg/L),
 W_d = Se load in nonpoint source with flow (mg/s/m),
 W_g = Se load in groundwater interaction (mg/s/m).

Type 4. In this condition, there is a point source at the beginning of the reach and nonpoint sources with and without additional flow along the reach. In this condition, the flow rate equations are the same as the third type above, and Se concentrations can be determined by:

$$C_o = \frac{C_u Q_u + 0.001(W - W_i)}{Q_u + Q_v - Q_i}$$

$$C_p = \frac{0.001 W_p}{x_r A}$$

$$C_d = \frac{0.001 \left[(W_d + W_g) + \frac{0.001 W_r}{x_r} \right]}{\Delta_q}$$

$$C = C_o \left(\frac{Q_u + Q_v - Q_i}{Q_x} \right)^E + \frac{C_d \Delta_q + C_p A}{k_t A + \Delta_q}$$

$$* \left[1.0 - \left(\frac{Q_u + Q_v - Q_1}{Q_x} \right)^E \right]$$

$$C_s = C_o(Q_u + Q_v - Q_1) + \frac{(C_d \Delta_q + C_p A)}{Q_x} - C + C_{ua}$$

$$E = \frac{k_t A + \Delta_q}{\Delta_q}$$

When using the above solutions, the runoff flows and Se loadings can be obtained from previous soil transport models.

Lakes or Impoundments

The difference of water quality in lakes or impoundments from that in stream or rivers is the occurrence and strength of thermal stratification. When there is no stratification, lakes will mix well and Se concentrations are uniform throughout the lakes. If there is stratification, it may trap Se in the various water layers, causing greater concentration gradients. Another parameter which can affect Se concentrations in lakes is sedimentation since settling processes can reduce pollutant concentrations. Settled Se accumulates on the bottom of the lakes and acts as a source of pollution in later time if conditions change. Just like in the stream condition, some basic assumptions are made for the lake model. These include:

- * Steady-state conditions.
- * Complete vertical and horizontal mixing within each unstratified volume.
- * First order decay processes.

The physical meaning and implication of these assumptions is the same as discussed in the stream analysis. However, in the lake, we have to assume that the inflowing water mixes completely with the available volume of the lake water body. This available volume can be the entire volume of an unstratified body or the upper mixed layer in the stratification. The concept of "effective volume" that means the water body which mixes well within a time period can be used in the lake analysis. Also, the settling process is separated from decay process in the lake analysis because settling is more significant in lakes than in streams.

The model equation for Se in a lake can be expressed as follows (23):

$$\frac{dC}{dt} = W_a - k_d C - k_s C - \frac{QC}{V}$$

Where C = Se concentration in the lake water (mg/L),
 W_a = mean total Se loading rate from all sources (mg/L),
 k_d = mean total decay coefficient (1/s),
 k_s = mean settling rate (1/s),
 Q = mean outflow rate (L/s),

V = lake active volume (L).

This equation can be solved for the steady-state condition by setting the concentration change to zero, thus we have:

$$C = \frac{W_d}{k_t + k_s + Q/V}$$

The mean total Se loading rate can be obtained from:

$$W_d = W_{db} + W_o - W_1$$

$$W_{db} = C_b V \left(k_t + k_s + \frac{Q}{V} \right)$$

Where W_o = Se loading from incremental soil runoff (mg/s),

W_1 = Se removal from irrigation (mg/s),

W_{db} = mean background Se loading rate (mg/s),

7. Ground water Transport Analysis

The primary release of Se into ground water is leachate from coal mine spoils. The amount and chemical characteristics of such leachate will depend on coal and coal mine spoil composition, and soil characteristics. Other seleniferous parent materials can also contribute to Se contamination of ground water.

Simplified ground water flow and contaminant transport models can be used to determine the distribution of Se in the unsaturated

soil around the coal mine spoils and in the saturated soil of aquifer below the spoil region. Flow models can predict the groundwater movement under the influence of recharge, infiltration, and withdrawal rates. Given these results, contaminant transport models can determine Se transport in the ground water.

There are hundreds of different ground water models described in the literature. Each of these different models has its own assumptions and limitations, but many of them can be used well in any particular situation. Thus, it is not necessary to illustrate the application of these models here because different types of models may be required for different situations. According to Whelan and Brown (24), when selecting a suitable model to calculate Se transport, one should select a particular computer code that:

- * Interfaces well with the soil and surface water transport models.
- * Provide pollutant concentrations at appropriate locations averaged over the time period of the analysis.
- * Incorporate the mechanisms of advection, dispersion, and retention.
- * Considers ground water and contaminant sinks with geometries consistent with drinking water and irrigation wells.
- * Can be applied to a sufficiently large region to incorporate the population of concern.

Oster (25), Thomas et al (26), and Wang et al (27) have done

some literature reviews about ground water transport models. These reviews provide useful information for model selection. Whelan and Brown (23) also describe a set of ground water transport models. Table 4 gives a listing of selected ground water models that have been developed by various investigators.

The result of most groundwater transport models is pollutant concentrations in ground water. They can also give us information about flow rates for interactions between ground water and surface water bodies. This kind of information can be input into surface water transport models discussed above.

Table 4. Some selected groundwater models. (24).

Code Name	Zone	Number of Constituents	solution Method	Aquifer Types
PRZM	U	Single	Numerical	H,I
PESTAN	U	Single	Analytic	HM,I
RAPCON	U	Single	Analytic	HM,I
PATH	S	Single	Analytic	HM,I
CLEARY'S CODE	S	Single	Analytic	HM,I
BAIRN (GETOUT)	S	Multiple	Analytic	HM,I
AT123D	S	Single	Both	HM,I
GRDFLX GROUND	S	Multiple	Both	HM,A

Source: Whelan and Brown (1984)

Notes: All codes can deal with nonconservative substances and multiple dispersion mechanisms in one phase, except PATHS, which assumes conservative substances and advection only.

U--Unsaturated Zones.

S--Saturated Zones.

H--Heterogeneous.

HM--Homogeneous.

I--Isotropic.

A--Anisotropic.

Literature Cited

1. Lansche, A.M. 1965. Selenium. In: Mineral facts and problems. Bull. 630, U.S. Bureau of Mines.
2. Connor J.J., and Shacklette, H.T., 1975. Background geochemistry of some rocks, soils, plants, and vegetables in the conterminous United States. U.S. Geological Survey Professional Paper 574-F, p126.
3. National Academy of Sciences (NAS). 1976. Selenium. NAS, Washington, D.C.
4. Goldberg, E.D and K.K. Turekian. 1971. Marine Chemistry. Radioactivity in the marine environment. NAS-NRC, Washington, DC.
5. Lakin, H.W. 1973. Selenium in our environment. In: Trace elements in the environment. Adv. Chem. Ser. 123, 96.
6. Swaine, D.J. 1955. The trace element content of soils. Commonw. Bur. Soil Sci., Tech. Commun., p.48
7. C.M. Johnson. 1976. Selenium in the environment. Residue Reviews. Vol. 62, p111.
8. Allaway, W.H. 1971. Distribution of selenium. In: Selenium in nutrition. Washington, D.C.: Nat. Acad. Sci.
9. Harry M. Ohlendorf. 1989. Bioaccumulation and effects of selenium in wildlife. Selenium in Agriculture and the environment. SSSA Special Publication Number 23.

10. Robberecht, H., and R. von Grieken. 1982. Selenium in environment waters: Determination, speciation and concentration levels. *Talanta* 29: 823-844.
11. Bertine, K.K., and E.D. Goldberg. 1971. Fossil fuel combustion and the major sedimentary cycle. *Science*. 173: 233-235.
12. Hashimoto, Y., and S. Yanagisawa. 1970. Possible sources of atmospheric pollution of selenium. *Environmental Science and Technology*. 4, 157.
13. Anderson, A., and K.O. Nilsson. 1972. Enrichment of trace elements from sewage sludge fertilizer in soils and plants. *Ambio* 1, 176.
14. Pratley, J.E., and J.D. McFarlane. 1974. The effect of sulphate on the selenium content of pasture plants. *Austral. J. Expt. Agr. Animal Husbandry*. 14, 533.
15. Mayland, H.F., and J.L. Sonderegger. 1989. Selenium in Seleniferous Environments. *Selenium in Agriculture and the Environment*, p19.
16. Pillay, K.K.s., and J.W. Kaminski. 1969. Neutron activation analysis of the selenium content of fossil fuels. *Nucl. Appl. Technol.* 7:478-483.
17. Eisenberg et al. 1986. Chemical characteristics of selected flyash leachates. *J. Environmental Science. Health Part A* 21:383-402.
18. Andren, A.W. and Y. Talmi. 1975. Selenium in coal-fired steam plant emissions. *Environ. Sci. Technol.* 9:856-858

19. Boon,D.Y., and P.J.Smith. 1985. Carbonaceous materials: problems associated with reclamation. Am.Soc. Surface Mining Recl. 2:248-256.
20. Richard,J.E. and Hansford,T.S. 1982. Geochemistry of some rocks, mine spoils, stream sediments, soils, plants, and waters in the western energy region of the conterminous united states. U.S. Geological Survey Professional Paper 1237.
21. James A Erdman and Richard J. Ebens. 1979. Element content of crested wheatgrass grown on reclaimed coal spoils and on soils nearby. J. of Range Management, 32(2), P159-161.
22. J.G.Bolten, et al. 1987. Risk assessment of toxic emissions: Alternative models and practice. EPRI EA-5359 Final Report.
23. Zison, et al. 1977. Water quality assessment: A screening method for nondesignated 208 areas, U.S. Environmental Protection Agency, EPA-600/9-77-023, Athens, Georgia, August 1977.
24. Whelan,G., and S.M.Brown. 1984. Contaminant assessment modeling under the Resource Conservation and Recovery Act. Battelle Pacific Northwest Laboratories, Draft Report, Richland, Washington.
25. Oster,C.A. 1982. Review of groundwater flow and transport models in the unsaturated Zone. Battelle Pacific Northwest Laboratories, PNL-4427, NUREG/CR-2917, Richland, Washington.
26. Thomas,S.D., et al. 1982. A summary of repository siting models, U.S. Nuclear Regulatory Commission, NUREG/CR-2782,

Washington, D.C.

27. Wang, et al. 1980. The State-of-the-Art of Numerical Modeling of Thermodynamic Flow in Fractured Rock Masses, Lawrence Berkeley Laboratory, LBL-10524, Berkeley, CA, 1980.

END

**DATE
FILMED**

8 / 31 / 92