




Design, Construction and Operation of a High Pressure Flow Loop Reactor for Carbon Sequestration

S. J. Gerdemann
L. R. Penner

*AIChE Annual Meeting
November 16-21
San Francisco*



Carbonation Reactions



Olivine



Magnesite






Reaction Conditions

- 3-phase system: Gas/Liquid/Solid
- 1.0 M NaCl & 0.64M NaHCO₃ Solution
- 15 – 30 % solids
- 2500 psi
- 200 °C


Proposed Conceptual Reactor

(Pipe-Line Flow-Through Reactor)





Loop Reactor





Measurements

- Flow Rate
- System Pressure
- Pressure Differentials
 - Across mixers
 - Across pump
- Temperature
- Extent of Reaction
- Wear and Corrosion



Design Tools

- Test Bench: Clear PVC tubing with static mixer and instrumented for pressure and flow
 - Component sizing
 - Determine minimum flow rate
 - Observation of flow and mixing
 - Pressure drop data
 - practice in filling and draining system



Mixer Test Bench



Mixer





Pump Requirements

- Handle 30% solids
- Handle NaCl/NaHCO₃ Solution
- Withstand 2500 psi
- Withstand 200°C
- Flow rate of 10 to 20 l/m




Pump Characteristics

- Magnetic Drive
- 316 SS Casing
- Single-Stage Regenerative Turbine
- Variable-Speed Motor




Slurry Pump






HTHP Flow Loop Reactor






Extent of Reaction






Gas Liquid Ratio






Pressure Drop





Wear and Corrosion

**Worn
Ball
Valve**



**Worn
Ball
Seat**



New mixer



**Used
Mixer**



Conclusions

- Successful operation of high pressure, 3-phase reactor
- Extent of reaction exceed that obtained in batch autoclave tests

CO₂ Sequestration


by Calcium and Magnesium Silicate Minerals





Small bubbles

CO₂ Blanket



Mixers

Coalescing bubbles

Flow direction