

SANDIA REPORT

SAND2008-2971

Unlimited Release

Printed May 2008

Determination of Possible Damage/Degradation of the Sandia National Laboratories Personal Nuclear Accident Dosimeter (PNAD)

Dann C. Ward, Charles A. Potter

Prepared by
Sandia National Laboratories
Albuquerque, New Mexico 87185 and Livermore, California 94550

Sandia is a multiprogram laboratory operated by Sandia Corporation,
a Lockheed Martin Company, for the United States Department of Energy's
National Nuclear Security Administration under Contract DE-AC04-94AL85000.

Approved for public release; further dissemination unlimited.



Sandia National Laboratories

Issued by Sandia National Laboratories, operated for the United States Department of Energy by Sandia Corporation.

NOTICE: This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government, nor any agency thereof, nor any of their employees, nor any of their contractors, subcontractors, or their employees, make any warranty, express or implied, or assume any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represent that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government, any agency thereof, or any of their contractors or subcontractors. The views and opinions expressed herein do not necessarily state or reflect those of the United States Government, any agency thereof, or any of their contractors.

Printed in the United States of America. This report has been reproduced directly from the best available copy.

Available to DOE and DOE contractors from

U.S. Department of Energy
Office of Scientific and Technical Information
P.O. Box 62
Oak Ridge, TN 37831

Telephone: (865) 576-8401
Facsimile: (865) 576-5728
E-Mail: reports@adonis.osti.gov
Online ordering: <http://www.osti.gov/bridge>

Available to the public from

U.S. Department of Commerce
National Technical Information Service
5285 Port Royal Rd.
Springfield, VA 22161

Telephone: (800) 553-6847
Facsimile: (703) 605-6900
E-Mail: orders@ntis.fedworld.gov
Online order: <http://www.ntis.gov/help/ordermethods.asp?loc=7-4->

0#online



Determination of Possible Damage/Degradation of the Sandia National Laboratories Personal Nuclear Accident Dosimeter (PNAD)

Dann C. Ward
Radiation Protection Department
Sandia National Laboratories
P.O. Box 5800
Albuquerque, NM 87185-1103

Charles A. Potter
Instrumentation and Dosimetry Department
Sandia National Laboratories
P.O. Box 5800
Albuquerque, NM 87158-0651

Abstract

This report describes the results of an inspection performed on the existing stock of SNL Personal Nuclear Accident Dosimeters (PNADs). The current stock is approximately 20 years old, and has not been examined since their initial acceptance. A small random sample of PNADs were opened (a destructive process) and the contents visually examined. Sample contents were not degraded and indicate that the existing stock of SNL PNADs is acceptable for continued use.

Acknowledgement

The authors thank B. Elkin of the Radiation Protection Department for his support and guidance regarding this work.

Acronyms and Abbreviations

NaF	Sodium Fluoride
PNAD	Personal Nuclear Accident Dosimeter
SNL	Sandia National Laboratories

Contents

Introduction.....	7
Purpose.....	7
History.....	7
Scope.....	7
Discussion.....	7
Results.....	8
Conclusions.....	11
Recommendations for Further Analysis	11
References.....	11

Figures

Figure 1: An intact PNAD measures 19 mm by 7 mm by 65 mm long.....	8
Figure 2: Diagram showing arrangement of PNAD components.....	8
Figure 3: Each PNAD was opened and displayed as indicated. The numbers shown correspond to the sample ID # in Table 1.	9

Tables

Table 1: PNAD Information	11
---------------------------------	----

This Page Left Blank

Introduction

Purpose

This report describes the results of a random sampling of Sandia National Laboratories (SNL) Personal Nuclear Accident Dosimeters (PNADs) to determine if they have degraded with age.

History

SNL PNADs were designed and fabricated nearly 20 years ago. Figure 1 contains a picture of an intact PNAD plus an opened PNAD with the NaF tablet, cadmium covered copper foil, and metallic foils removed for display. PNADs do not require any type of maintenance. The metallic foils and NaF tablet are protected from potential environmental insults by being sealed inside of a robust plastic housing. When members of the SNL workforce perform tasks that involve potential criticality issues, they are required to wear a PNAD. If an accidental criticality were to occur, the metallic foils and the NaF tablet would become activated. The degree of activation can be used to determine a worker dose from exposure to neutron radiation.

This work was prompted by a Lessons Learned announcement regarding foil degradation in a different style PNAD used by another DOE facility¹. The existing inventory of SNL PNADs is approximately 300, and is adequate for foreseeable needs. A sample size of six (6) was established. This represented a balance between a representative sample size and preserving the existing inventory as much as possible.

A physical description of the SNL PNAD plus experimental results indicating the accuracy for neutron dosimetry purposes is available².

Scope

PNADs were opened (a destructive process) and the contents were visually inspected. Deterioration, if present, would consist of foil oxidation and/or possible crumbling of the NaF tablet.

This activity was performed in accordance with an approved sampling plan³.

Discussion

The style of PNAD mentioned in the Lessons Learned announcement¹ contained a sulfur tablet plus metallic foils. Although the sulfur tablet was physically separated from the

Results

SAUDA NATIONAL LABORATORIES
CATHODICITY USE-METER
Serial No. 1 A 02

Plastic housing with top removed

NaF Pellet

Cd Covered Cu foil

Al, Ni, Ti, & In foils

The diagram illustrates the components of the NaF Tablet assembly. At the top is the **Plastic housing, body**, a light blue rectangular block with a black vertical strip on the left and three circular indentations. Below it is the **Plastic housing, top**, a light blue rectangular block with a yellow **NaF Tablet** in the center. Below the housing are five circular components: **Al** (orange), **Ni** (light gray), **Ti** (dark gray), **In** (light gray), and **Cd covered Cu** (dark gray). The **Cd covered Cu** component is shown in two views: a top view and a side view.

8




Figure 3: Each PNAD was opened and displayed as indicated. The numbers shown correspond to the sample ID # in Table 1.

The Page Left blank

Table 1: PNAD Information

Sample #*	PNAD SN	Comment
1	0515	
2	None	Never Issued
3	None	Never Issued
4	None	Never Issued
5	0522	
6	0520	

* As indicated in figure 2.

Conclusions

The SNL PNADs are of robust design, and unless a plastic housing shows obvious physical damage the devices are suitable for continued use.

Recommendations for Further Analysis

1. PNAD materials used in this evaluation should be retained with the remaining un-issued PNADs and annually inspected for any signs of deterioration. This will allow for a periodic re-assessment of PNAD materials and provide a conservative indicator of PNAD performance. The remaining inventory of intact PNADs will then be protected from being slowly “sampled away”.
2. Determination of a recommended “Shelf Life” is beyond the scope of this report. However, these devices show no signs of deterioration after almost 20 years. As such, it is probably conservative to assume that intact PNADs are good for up to 5 more years from the date of last evaluation.

References

¹DOE Lessons Learned – Foil Degradation in Personal Nuclear Accident Dosimeters Alters Response; Identifier: 2008-LL-PNNL-0001.

²Personal Nuclear Accident Dosimetry at Sandia National Laboratories, SAND96-2204, September 1996.

³Sampling and Analysis Plan for the Determination of Possible Damage/Degradation of the SNL Personal Nuclear Accident Dosimeter (PNAD), SNL Radiation Protection Department (04128), February 22, 2008.

DISTRIBUTION

1	MS1103	B. Elkin, 04128
1	MS0651	B. Forbes, 04121-1
1	MS1050	H. Barclay, 04128-1
1	MS1103	B. Miltenberger, 04128-2
1	MS0651	C. A. Potter, 04121-1
1	MS1103	D. C. Ward, 04128
1	MS0899	Technical Library, 9536 (electronic copy)

